



PLUS+1 Controls Function Block Library

70026747v401

Revision History

This file contains important supplementary and late-breaking information that may not appear in the main product documentation. We recommend that you read this file in its entirety.

Version 4.01 (February 2019)

What is Included

- PLUS+1 GUIDE® Function Blocks (In SDL)
- User Manual (In SDL)
- Service Tool Log Screens

What is New

- Fixed an issue where the Ackermann blocks could overflow in a calculation, resulting in an incorrect output value.
- Aligned spelling across Ackermann blocks.
- Added existing service screens to the library structure.
- Changed font used in service screens from Tahoma to Verdana.
- Corrected referenced signals for the Controller PI service screen.

Known issues

- None

Minimum Requirements

- PLUS+1 GUIDE 10.1 or greater
- PLUS+1 Service Tool 10.1 or greater

Version 4.00 (June 2016)

What is Included

- PLUS+1 GUIDE® Function Blocks (In SDL)
- User Manual (In SDL)
- Service Tool Log Screens

What is New

- Support for Professional Licensing.

- Controller_PID: Adjusted derivative function to use OS.ExecTime for Smpl Tm if Smpl Tm is lower. Increased accuracy of derivative sample calculation when Smpl Tm is not a multiple of OS.ExecTime.
- State_Brake: Added initialization for Dec_Tm to prevent output from following input when commanded direction changes rapidly after startup.

Known issues

- None

Minimum Requirements

- PLUS+1 GUIDE 8.1 or greater

Version 3.00 (April 2014)

What is Included

- PLUS+1 GUIDE® Function Blocks (In SDL)
- User Manual (In SDL)
- Service Tool Log Screens

What is New

This library is a replacement for the controls functions found SD Basic FB Library (PN: 10103408).

- Companion service tool screens that can be imported to P1D files.
- Embedded checkpoints and namespace for each function block to support service tool integration.
- IO bus for alternative connectivity to your application.
- Requires specific data types for all inputs.
- Connection errors now indicate (by page name) which input has a problem.
- Ackermann
 - New block that combines both the speed and angle calculations.
- Ackermann_Spd
 - Added Max Strg Ang output.
 - Combined Steering mode inputs into one signal.
- Ackermann_Strg
 - Added Max Strg Ang output.
 - Combined Steering mode inputs into one signal.
- Controller_PI
 - New block based on the latest version of the Controller_PID, only without the differential calculation.
- Controller_PID
 - Added Error and Saturate outputs.
 - Max/Min limits are now applied on the total output.
 - Integrator sum is now recalculated when either limit is reached.

- Gains now have new ranges and scales. Refer to user manual for more information.
- Integrator calculation now applies gain before integration, thus allowing for variable gains without unintended step changes in output.
- I Stop feature added to prevent oscillations around the setpoint.
- Derivative calculation replaced with one that allows adjustable sample time and includes averaging for more stable control.
- Hysteresis
 - Maximum input is now reduced from 40000 to 32767.
- Inverse_Acker
 - New block that estimates a steering angle command from measured wheel angles.
- Profile_6Pt
 - Output now set to zero when parameters are invalid.
- State_Brake
 - Added Dwell option to force a pause when changing direction/crossing zero.
 - Added output for current state.
 - Added Split option for ramping to a stop at zero when changing direction/crossing zero.

Known issues

- None

Minimum Requirements

- PLUS+1 GUIDE 6.1 or greater

Support

Web

<https://www.danfoss.com/en/products/software/dps/plus1-software-services-support-and-training/plus1-support-and-services/>

Telephone

North America: Toll free number 1-888-50PLUS1 (1-888-507-5871)

Europe: +46 476-569 06

E-mail

plus1helpdesk@danfoss.com

Terms of Use

The Danfoss Software License Agreement completely defines the licensed use of this software.

Information in this document is provided in connection with Danfoss PLUS+1 Tool set. No license, express or implied, to any intellectual property rights is granted by this document.

Danfoss disclaims all warranties and liabilities for the use of this document and the information contained herein and assumes no responsibility for any errors, which may appear in this document, nor does Danfoss make a commitment to update the information contained herein. Danfoss reserves the right to make changes to this document at any time, without notice.

Copyright

© 2019 Danfoss, Inc. All rights reserved.

Third party trademarks and brand names are the property of their respective owners.