

## **COOLING VALVE ASSY**

100281-1, 2, 3, 4, 5, & 199K0029.



Installation and servicing of Danfoss Turbocor® compressors by qualified and product trained personnel only. Follow these instructions and sound refrigeration/electrical/servicing practices relating to installation, commissioning, maintenance, and service.

Consult the appropriate Danfoss LLC Service Manual on www.turbocoroem.com for detailed service instructions.

Never power compressor without covers in place and

Removing the mains input cover will expose you to a voltage hazard of up to 853VDC. Ensure the mains input power is off and locked out before removing cover.

Before removing top cover, wait at least 20 minutes after isolating AC power to allow the high voltage capacitors to discharge.

Always wear appropriately rated safety equipment when from compressor in working around equipment and/or components energized with high voltage.

This equipment contains hazardous voltages that can cause serious injury or death.

Recover all refrigerant accordance with local codes and ensure pressure is fully vented before the removal of refrigerant containing components.

## 1 - Introduction

Please refer to our service manual for the removal and installation procedures.

To access the manual, you may scan the applicable QR code below or you may go to our DTC website at www.turbocoroem.com. At the bottom of the page there is a Section named "Categories" that includes various menus including one for Manuals.

Refer to the applicable QR code below to download the TT/TG Series Service Manual.







## 2 - Kit Contents

**Note:** Any part numbers included in this Kit Contents section are internal part numbers only. Please refer to our Spare Parts Manuals for any kit part numbers.

Kit Number: 100281-1, 100281-2, 100281-3, 100281-4, and 100281-5				
QTY	Part(s) Description Picture(s)			
2	SOLENOID OPERATOR TUBE, PLUNGER AND SEAL SUB ASSY – 901906 (includes O-ring)			
2	NUT-SPECIAL-SOLENOID VALVE – 900561			
2	WASHER BEVELED DISC. SOLENOID VALVE Ø13.8xØ8.7x0.5 – 900562	0		
2	O-RING - 901864	0		
2	O-RING - 902075	0		
2	VALVE - ORIFICE SOLENOID (sizes depends on application)			
1	LUBRICATION-SUPER-O-LUBE-2G – 900578			

Kit Number 199K0029					
QTY	Part(s) Description Picture(s)				
1	SOLENOID OPERATOR TUBE, PLUNGER AND SEAL SUB ASSY – 901906 (includes O-ring)				
1	PLUNGER - LARGER VALVE – 600A0301 (includes O-ring)				
1	NUT SOLENOID VALVE – 600A0372				
1	NUT-SPECIAL-SOLENOID VALVE – 900561				
1	WASHER BEVELED DISC. SOLENOID VALVE Ø13.8xØ8.7x0.5 – 900562	0			



2	O-RING - 901864	0	
2	O-RING - 902075	2075	
1	VALVE - ORIFICE SOLENOID – 701712-2		
1	VALVE - ORIFICE BDY LG CLG – 600A0302		
1	LUBRICATION-SUPER-O-LUBE-2G – 900578		

## 3 - List of Changes

Revision	Date	Description of Change
М	1/19/2022	Kit numbers were updated.  The kit old kit numbers were removed from the top of this instruction and the new ones were added.
		Below is the cross reference from the old numbers to the new numbers.  100150 – No longer supported 100150-1 – Replaced by 100150-10 100150-3 – Replaced by 100150-9 100150-4 – Replaced by 100150-10 100150-5 – Replaced by 100150-6 100150-7 – Replaced by 100150-11 100150-6 – Replaced by 100281-1 100150-8 – Replaced by 100281-2 100150-9 – Replaced by 100281-3 100150-10 – Replaced by 100281-4 100150-11 – Replaced by 100281-5 100150-12 – No longer used
N	7/24/2024	Added kit 199K0029  Re-formatted instructions

Danfoss LLC can accept no responsibility for possible errors in catalogues, brochures, and other printed material. Danfoss LLC reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed.

All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

