# **KIT** COMPLETE COMPRESSOR O-RING REPLACEMENT

110094 & 112037.



Installation and servicing of Danfoss Turbocor® compressors by qualified and product trained personnel only. Follow these instructions and sound refrigeration/electrical/servicing practices relating to installation, commissioning, maintenance and service.

Consult the appropriate **Danfoss Turbocor** Compressors Inc. (DTC) Service Manual on turbocoroem.com for detailed service instructions. Never power compressor without covers in place and secured.

Opening the drive panel will expose you to a voltage hazard of up to 575V AC and 900V DC. Ensure the mains input power is off and locked out before opening panel.

Before opening the drive panel, wait at least 20 minutes after isolating AC power to allow the high voltage capacitors to discharge.

Always wear appropriately rated safety equipment when from compressor in working around equipment and/or components energized with high voltage.

This equipment contains hazardous voltages that can cause serious injury or death.

Recover all refrigerant accordance with local codes and ensure pressure is fully vented before the removal of refrigerant containing components.

## 1 - Introduction

This kit contains all of the replacement O-rings for the compressor. Please refer to our Service Manual for details regarding the replacement of these O-rings.

We have made the VTT/VTX Service Manual available to anyone. To access the manual, you may scan the applicable QR code below or you may go to our DTC website at www.turbocoroem.com. At the top of the page there is a pull-down menu called "Quick Links." Click this menu and select the appropriate service manual.

Refer to the applicable QR code below to download the VTT/VTX Service Manual.





Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

## 2 - Kit Contents

**Note:** Any part numbers included in the kit contents are internal part numbers only. Please refer to our Spare Parts Manuals for any kit part numbers.

Kit numbers		Compressor models		
110094		VIT		
QTY	Part(s	) Description	Picture(s	5)
1	O-RING – Exit Cooling Flange (Rev B and C) – 920222			0
1	O-RING – Economizer – 920331			0
1	O-RING – Bottom Plug – 920019			0
1	O-RING – Discharge – 920354			0
1	O-RING – Suction Inlet VTT – 920365			0
1	O-RING – Volute VTT/VTX – 920383			0
1	O-RING – Inlet Cooling Flange – 920212			0
5	O-RIN	G – Feedthrough – 920120		0
2	O-RIN	G – IFV Pipe – 920333		0
1	O-RIN	G - CUSTOM TOWER		
1	O-RIN	G – Suction Housing – 920386		0
1	O-RIN	G – End Cap – 920382		0
1	O-RIN	G – Touchdown Bearing – 901857		0
3	O-RIN	G – Power/Motor Feedthrough – 901855		0
1	O-RIN 92021	G – Exit Cooling Flange (VTT Rev A only) – 7		0
5	LUBRI	CATION-SUPER-O-LUBE-2G		

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Kit num	nbers	Compressor models			
112037 VTX					
QTY	Part(s	) Description	Picture(s	;)	
1	O-RING – Volute VTT/VTX – 920383			0	
1	O-RING – Exit Cooling Flange – 920222			0	
1	O-RING – Economizer – 920331			0	
1	O-RING – Bottom Plug – 920019			0	
1	O-RING – Discharge – 920354			0	
1	O-RING – Inlet Cooling Flange – 920212			0	
5	O-RING – Feedthrough – 920120			0	
1	O-RIN	G – CUSTOM TOWER			
1	O-RIN	G – End Cap – 920382		0	
1	O-RIN	G – Touchdown Bearing – 901857		0	
3	O-RIN	G – Power/Motor Feedthrough – 901855		0	
1	O-RIN	G – IGV/Suction Housing – 920959		0	
1	O-RIN	G – IGV Feedthrough – 901855		0	
1	O-RIN	G – Discharge – 902954		0	
5	LUBRI	CATION-SUPER-O-LUBE-2G			

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.