


# KIT REAR BEARING POWER FEEDTHROUGH

110027.

 <p><b>Installation and servicing of Danfoss Turbocor® compressors by qualified and product trained personnel only. Follow these instructions and sound refrigeration/electrical/servicing practices relating to installation, commissioning, maintenance and service.</b></p>			
<p>Consult the appropriate Danfoss Turbocor Compressors Inc. (DTC) Service Manual on <a href="http://turbocoroem.com">turbocoroem.com</a> for detailed service instructions.</p>	<p><b>Never power compressor without covers in place and secured.</b></p> <p><b>Opening the drive panel will expose you to a voltage hazard of up to 575V AC and 900V DC. Ensure the mains input power is off and locked out before opening panel.</b></p> <p><b>Before opening the drive panel, wait at least 20 minutes after isolating AC power to allow the high voltage capacitors to discharge.</b></p>	<p>Always wear appropriately rated safety equipment when working around equipment and/or components energized with high voltage.</p> <p><b>This equipment contains hazardous voltages that can cause serious injury or death.</b></p>	<p><b>Recover all refrigerant from compressor in accordance with local codes and ensure pressure is fully vented before the removal of refrigerant containing components.</b></p>

## 1 - Introduction

This kit contains the Rear Bearing Power Feedthrough. Please refer to our Service Manual for details regarding the replacement of this component.

We have made the **VTT/VTX Service Manual** available to anyone. To access the manual, you may scan the applicable QR code below or you may go to our DTC website at [www.turbocoroem.com](http://www.turbocoroem.com). At the top of the page there is a pull-down menu called "Quick Links." Click this menu and select the appropriate service manual.

Refer to the applicable QR code below to download the VTT/VTX Service Manual.

**English**



**Chinese**



**NOTE:** The below instructions are a high-level view of the steps to replace the Rear Bearing Power Feedthrough. Please refer to the Service Manual for the detailed steps.

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

## 2 - REAR BEARING POWER FEEDTHROUGH Removal Instructions





1. Isolate VTT/VTX power as described in Section "Electrical Isolation of the VFD" of the Service Manual (M-SV-VT-001).
2. Isolate the compressor and recover the refrigerant according to industry standards.
3. Remove the compressor End Cap.
4. Disconnect the cables from the internal connectors.
5. Remove the Service Electronics Cover.
6. Disconnect the PWM bearing power cable from the feedthrough.
7. Remove the fasteners holding the Bearing Power Feedthrough to the compressor housing.
8. Carefully remove Bearing Power Feed Through and gently pull the connectors through the housing.
9. Remove the O-ring.

## 3 - REAR BEARING POWER FEEDTHROUGH Installation Instructions






1. Place the new O-ring onto new Bearing Power Feedthrough.
2. Carefully slide the connectors into the housing until the feedthrough is in place.
3. Install the Bearing Power Feedthrough to the housing.
4. Connect the PWM bearing power cable to the feedthrough.
5. Connect the Bearing Power Feedthrough through to the internal connectors.
6. Install the End Cap.
7. Install the Service Side Cover.
8. Leak test and evacuate compressor in accordance with standard industry practices.
9. Return the compressor to normal operation.
10. Test run the compressor to verify proper operation.

## 4 - Kit Contents

**Note:** Any part numbers included in the kit contents are internal part numbers only. Please refer to our Spare Parts Manuals for any kit part numbers.

Kit numbers	Compressor models	
110027	VTT/VTX	
QTY	Part(s) Description	Picture(s)
1	FEEDTHROUGH COMBO POWER	
1	O-RING – Feedthrough – 920120	
1	O-RING – End Cap – 920382	
4	SCREW, M5 – 902480	

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequent changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

4	WASHER, M5 SPLIT – 902488	
12	SCREW, M12 – 902522	
12	WASHER, M12 FLAT – 902122	
12	WASHER, M12 SPLIT – 902123	
1	LUBRICATION-SUPER-O-LUBE-2G	

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.