



Operating Instructions VLT[®] HVAC Drive FC 102

110-1400 kW



Contents

1 How to Read these Operating Instructions	4
2 Safety	6
2.1 Safety Note	6
2.1.1 General Warning	6
2.1.2 Before Commencing Repair Work	7
2.1.3 Special Conditions	7
2.1.4 Avoid Unintended Start	7
2.1.5 Safe Torque Off (STO)	7
2.1.6 IT Mains	8
3 Mechanical Installation	9
3.1 How to Get Started	9
3.2 Pre-installation	9
3.2.1 Planning the Installation Site	9
3.2.2 Receiving the Frequency Converter	10
3.2.3 Transportation and Unpacking	10
3.2.4 Lifting	10
3.2.5 Mechanical Dimensions	12
3.2.6 Rated Power	19
3.3 Mechanical Installation	20
3.3.1 Tools Needed	20
3.3.2 General Considerations	21
3.3.3 Terminal Locations - Enclosure Type D	22
3.3.4 Terminal Locations - E Enclosures	24
3.3.5 Terminal Locations - Enclosure type F	29
3.3.6 Cooling and Airflow	33
3.3.7 Installation on the Wall - IP21 (NEMA 1) and IP54 (NEMA 12) Units	35
3.3.8 Gland/Conduit Entry - IP21 (NEMA 1) and IP54 (NEMA12)	35
3.3.9 IP21 Drip Shield Installation (Enclosure Types D1 and D2)	37
3.4 Field Installation of Options	37
3.4.1 Installation of Duct Cooling Kit in Rittal Enclosures	37
3.4.2 Installation of Top-only Duct Cooling Kit	38
3.4.3 Installation of Top and Bottom Covers for Rittal Enclosures	38
3.4.4 Installation of Top and Bottom Covers	39
3.4.5 Outside Installation/NEMA 3R Kit for Rittal Enclosures	39
3.4.6 Outside Installation/NEMA 3R Kit of Industrial Enclosures	40
3.4.7 Installation of IP00 to IP20 Kits	40
3.4.8 Installation of IP00s D3, D4, & E2 Cable Clamp Bracket	40
3.4.9 Installation on Pedestal	40

3.4.10 Installation of Mains Shield for Frequency Converters	41
3.4.11 F Frame USB Extension Kit	42
3.4.12 Installation of Input Plate Options	42
3.4.13 Installation of D or E Loadshare Option	43
3.5 Frame size F Panel Options	43
3.5.1 Enclosure Type F Options	43
4 Electrical Installation	45
4.1 Electrical Installation	45
4.1.1 Power Connections	45
4.1.2 Grounding	56
4.1.3 Extra Protection (RCD)	56
4.1.4 RFI Switch	56
4.1.5 Torque	56
4.1.6 Shielded Cables	57
4.1.7 Motor Cable	57
4.1.8 Brake Cable for Frequency Converters with Factory Installed Brake Chopper Option	58
4.1.9 Brake Resistor Temperature Switch	58
4.1.10 Load Sharing	58
4.1.11 Shielding against Electrical Noise	58
4.1.12 Mains Connection	59
4.1.13 External Fan Supply	59
4.1.14 Fuses	59
4.1.15 Mains Disconnectors	62
4.1.16 F Enclosure Circuit Breakers	62
4.1.17 F Enclosure Mains Contactors	63
4.1.18 Motor Insulation	63
4.1.19 Motor Bearing Currents	63
4.1.20 Control Cable Routing	63
4.1.21 Access to Control Terminals	65
4.1.22 Electrical Installation, Control Terminals	65
4.1.23 Electrical Installation, Control Cables	66
4.1.24 Switches S201, S202, and S801	68
4.2 Connection Examples	69
4.2.1 Start/Stop	69
4.2.2 Pulse Start/Stop	69
4.3 Final Set-up and Test	70
4.4 Additional Connections	71
4.4.1 Mechanical Brake Control	71
4.4.2 Parallel Connection of Motors	71

4.4.3 Motor Thermal Protection	72
5 How to Operate the Frequency Converter	73
5.1 Operating with LCP	73
5.1.1 3 Ways of Operating	73
5.1.2 How to Operate Graphical LCP (GLCP)	73
5.2 Operating via Serial Communication	76
5.2.1 RS-485 Bus Connection	76
5.3 Operating via PC	77
5.3.1 How to Connect a PC to the Frequency Converter	77
5.3.2 PC Software Tools	77
5.3.3 Tips and Tricks	78
5.3.4 Quick Transfer of Parameter Settings when Using GLCP	78
5.3.5 Initialisation to Default Settings	78
6 How to Programme	80
6.1 Basic Programming	80
6.1.1 Parameter Set-Up	80
6.1.2 Quick Menu Mode	84
6.1.3 Function Set-ups	88
6.1.4 5-1* Digital Inputs	98
6.1.5 Main Menu Mode	110
6.1.6 Parameter Selection	110
6.1.7 Changing Data	110
6.1.8 Changing a Text Value	111
6.1.9 Changing a Group of Numeric Data Values	111
6.1.10 Changing of Data Value, Step-by-Step	111
6.1.11 Read-out and Programming of Indexed Parameters	111
6.2 Parameter Menu Structure	111
7 General Specifications	116
7.1 Electrical Data	120
8 Warnings and Alarms	129
Index	141

1 How to Read these Operating Instructions

VLT HVAC Drive FC 100 Series

Software version: 4.1x

This guide can be used with all FC 102 frequency converters with software version 4.1x or later. The actual software version number can be read from *15-43 Software Version*.

This publication contains information proprietary to Danfoss. By accepting and using this manual the user agrees that the information contained herein is used solely for operating equipment from Danfoss or equipment from other vendors if such equipment is intended for communication with Danfoss equipment over a serial communication link. This publication is protected under the Copyright laws of Denmark and most other countries.

Danfoss does not warrant that a software program produced according to the guidelines provided in this manual functions properly in every physical, hardware or software environment.

Although Danfoss has tested and reviewed the documentation within this manual, Danfoss makes no warranty or representation, neither expressed nor implied, with respect to this documentation, including its quality, performance, or fitness for a particular purpose.

In no event shall Danfoss be liable for direct, indirect, special, incidental, or consequential damages arising out of the use, or the inability to use information contained in this manual, even if advised of the possibility of such damages. In particular, Danfoss is not responsible for any costs, including but not limited to those incurred as a result of lost profits or revenue, loss or damage of equipment, loss of computer programs, loss of data, the costs to substitute these, or any claims by third parties.


Danfoss reserves the right to revise this publication at any time and to make changes to its contents without prior

notice or any obligation to notify former or present users of such revisions or changes.

- *VLT HVAC Drive Design Guide* entails all technical information about the frequency converter and customer design and applications.
- *VLT HVAC Drive Programming Guide* provides information on how to programme and includes complete parameter descriptions.
- *Application Note, Temperature Derating Guide*
- *MCT 10 Set-up Software Operating Instructions* enables the user to configure the frequency converter from a Windows™ based PC environment.
- Danfoss VLT® Energy Box software at www.danfoss.com/BusinessAreas/DrivesSolutions then choose PC Software Download
- *VLT HVAC Drive BACnet, Operating Instructions*
- *VLT HVAC Drive Metasys, Operating Instructions*
- *VLT HVAC Drive FLN, Operating Instructions*

Danfoss technical literature is available in print from local Danfoss Sales Offices or online at:

www.danfoss.com/BusinessAreas/DrivesSolutions/Documentations/Technical+Documentation.htm



The frequency converter complies with UL508C thermal memory retention requirements. For more information, refer to the section *Motor Thermal Protection* in the *Design Guide*.

NOTICE

Imposed limitations on the output frequency (due to export control regulations):

From software version 6.72 the output frequency of the frequency converter is limited to 590 Hz. Software versions 6x.xx also limit the maximum output frequency to 590 Hz, but these versions cannot be flashed, i.e. neither downgraded nor upgraded.

The following symbols are used in this document:

⚠ WARNING

Indicates a potentially hazardous situation which could result in death or serious injury.

⚠ CAUTION

Indicates a potentially hazardous situation which could result in minor or moderate injury. It may also be used to alert against unsafe practices.

NOTICE

Indicates important information, including situations that may result in damage to equipment or property.

1.1.1 Abbreviations and Standards

Abbreviations	Terms	SI-units	I-P units
a	Acceleration	m/s ²	ft/s ²
AWG	American wire gauge		
Auto Tune	Automatic Motor Tuning		
°C	Celsius		
I	Current	A	Amp
I _{LIM}	Current limit		
IT mains	Mains supply with star point in transformer floating to ground		
Joule	Energy	J=N·m	ft-lb, Btu
°F	Fahrenheit		
FC	frequency converter		
f	Frequency	Hz	Hz
kHz	Kilohertz	kHz	kHz
LCP	Local Control Panel		
mA	Milliampere		
ms	Millisecond		
min	Minute		
MCT	Motion Control Tool		
M-TYPE	Motor Type Dependent		
Nm	Newton Metres		in-lbs
I _{M,N}	Nominal motor current		
f _{M,N}	Nominal motor frequency		
P _{M,N}	Nominal motor power		
U _{M,N}	Nominal motor voltage		
PELV	Protective Extra Low Voltage		
Watt	Power	W	Btu/hr, hp
Pascal	Pressure	Pa = N/m ²	psi, psf, ft of water
I _{INV}	Rated Inverter Output Current		
RPM	Revolutions Per Minute		
s	Second		
SR	Size Related		
T	Temperature	C	F
t	Time	s	s,hr
T _{LIM}	Torque limit		
U	Voltage	V	V

Table 1.1 Abbreviation and Standards Table

2

2 Safety

2.1 Safety Note

⚠ WARNING

The voltage of the frequency converter is dangerous whenever connected to mains. Incorrect installation of the motor, frequency converter or fieldbus may cause damage to the equipment, serious personal injury or death. Consequently, the instructions in this manual, as well as national and local rules and safety regulations, must be complied with.

Safety Regulations

1. The frequency converter must be disconnected from mains if repair work is to be carried out. Check that the mains supply has been disconnected and that the necessary time has passed before removing motor and mains plugs.
2. The [STOP/RESET] key on the control panel of the frequency converter does not disconnect the equipment from mains and is thus not to be used as a safety switch.
3. Correct protective earthing of the equipment must be established, the user must be protected against supply voltage, and the motor must be protected against overload in accordance with applicable national and local regulations.
4. The earth leakage currents are higher than 3.5 mA.
5. Protection against motor overload is set by *parameter 1-90 Motor Thermal Protection*. If this function is desired, set *parameter 1-90 Motor Thermal Protection* to data value [4] *ETR trip* (default value) or data value [5] *ETR warning*. Note: The function is initialised at 1.16 x rated motor current and rated motor frequency. For the North American market: The ETR functions provide class 20 motor overload protection in accordance with NEC.
6. Do not remove the plugs for the motor and mains supply while the frequency converter is connected to mains. Check that the mains supply has been disconnected and that the necessary time has passed before removing motor and mains plugs.
7. Note that the frequency converter has voltage inputs other than L1, L2 and L3, when load sharing (linking of DC intermediate circuit) and external 24 V DC have been installed. Check that all voltage inputs have been disconnected and that the necessary time has passed before commencing repair work.

NOTICE

Installation at high altitude:

380 - 480 V: At altitudes above 3,000 m, contact Danfoss regarding PELV.

525 - 690 V: At altitudes above 2,000 m, contact Danfoss regarding PELV.

Warning against Unintended Start

1. The motor can be stopped with digital commands, bus commands, references or a local stop, while the frequency converter is connected to mains. To avoid personal injury, these stop functions are not sufficient to ensure that no unintended start occurs.
2. While parameters are being changed, the motor may start. Consequently, always press [RESET]; following which data can be modified.
3. A motor that has been stopped may start if faults occur in the electronics of the frequency converter, or if a temporary overload or a fault in the supply mains or the motor connection ceases.

⚠ WARNING

Warning:

Touching the electrical parts may be fatal - even after the equipment has been disconnected from mains.

Also make sure that other voltage inputs have been disconnected, such as external 24 V DC, load sharing (linkage of DC intermediate circuit), as well as the motor connection for kinetic back-up.

2.1.1 General Warning

⚠ WARNING

Warning:

Touching the electrical parts may be fatal - even after the equipment has been disconnected from mains. Also make sure that other voltage inputs have been disconnected, (linkage of DC intermediate circuit), as well as the motor connection for kinetic back-up. Before touching any potentially live parts of the frequency converter, wait at least as follows: Be aware that there may be high voltage on the DC link even when the Control Card LEDs are turned off. A red LED is mounted on a circuit board inside the frequency converter to indicate the DC bus voltage. The red LED stays lit until the DC link is 50 V DC or lower.

⚠ WARNING

Leakage Current

The earth leakage current from the frequency converter exceeds 3.5 mA. According to IEC 61800-5-1 a reinforced Protective Earth connection must be ensured by means of: a min. 10mm² Cu or 16mm² Al PE-wire or an additional PE wire - with the same cable cross section as the Mains wiring - must be terminated separately.

Residual Current Device

This product can cause a D.C. current in the protective conductor. Where a residual current device (RCD) is used for extra protection, only an RCD of Type B (time delayed) shall be used on the supply side of this product. See also RCD Application Note MN.90.GX.02. Protective earthing of the frequency converter and the use of RCD's must always follow national and local regulations.

- Grid configuration (IT,TN, grounded leg, etc.)
- Safety of low-voltage ports (PELV conditions)

Consult the relevant clauses in these instructions and in the *Design Guide* for information about the installation requirements.

⚠ WARNING

The frequency converter's DC link capacitors remain charged after power has been disconnected. To avoid an electrical shock hazard, disconnect the frequency converter from the mains before carrying out maintenance. Before doing service on the frequency converter, wait at least the amount of time indicated below:

Voltage	Power size	Min. Waiting Time
380 - 480 V	110 - 250 kW	20 minutes
	315 - 1000 kW	40 minutes
525 - 690 V	45 - 400 kW	20 minutes
	450- 1400 kW	30 minutes

Be aware that there may be high voltage on the DC link even when the LEDs are turned off.

Table 2.1 Discharge Time

2.1.2 Before Commencing Repair Work

1. Disconnect the frequency converter from mains.
2. Disconnect DC bus terminals 88 and 89.
3. Wait at least the time mentioned in chapter 2.1.1 General Warning.

2.1.3 Special Conditions

Electrical ratings

The rating indicated on the nameplate of the frequency converter is based on a typical 3-phase mains power supply, within the specified voltage, current and temperature range, which is expected to be used in most applications.

The frequency converters also support other special applications, which affect the electrical ratings of the frequency converter. Special conditions which affect the electrical ratings might be:

- Single phase applications
- High temperature applications which require derating of the electrical ratings
- Marine applications with more severe environmental conditions.

Consult the relevant clauses in these instructions and in the *Design Guide* for information about the electrical ratings.

Installation requirements

The overall electrical safety of the frequency converter requires special installation considerations regarding:

- Fuses and circuit breakers for over-current and short-circuit protection
- Selection of power cables (mains, motor, brake, loadsharing and relay)

2.1.4 Avoid Unintended Start

⚠ WARNING

While the frequency converter is connected to mains, the motor can be started/stopped using digital commands, bus commands, references or via the Local Control Panel.

- Disconnect the frequency converter from mains whenever personal safety considerations make it necessary to avoid unintended start.
- To avoid unintended start, always activate the [Off] key before changing parameters.
- Unless terminal 37 is turned off, an electronic fault, temporary overload, a fault in the mains supply, or lost motor connection may cause a stopped motor to start.

2.1.5 Safe Torque Off (STO)

To run Safe Torque Off, additional wiring for the frequency converter is required, refer to *Safe Torque Off Operating Instructions for Danfoss VLT® Frequency Converters* for further information.

2.1.6 IT Mains

⚠ WARNING

IT mains

Do not connect frequency converters with RFI-filters to mains supplies with a voltage between phase and earth of more than 440 V for 400 V converters and 760 V for 690 V converters.


For 400 V IT mains and delta earth (grounded leg), mains voltage may exceed 440 V between phase and earth.

For 690 V IT mains and delta earth (grounded leg), mains voltage may exceed 760 V between phase and earth.

Failure to follow recommendations could result in death or serious injury.

14-50 RFI Filter can be used to disconnect the internal RFI capacitors from the RFI filter to ground.

2.1.7 Disposal Instruction



3 Mechanical Installation

3.1 How to Get Started

This chapter covers mechanical and electrical installations to and from power terminals and control card terminals. Electrical installation of options is described in the relevant *Operating Instructions* and *Design Guide*.

The frequency converter is designed to achieve a quick and EMC-correct installation by following the steps described below.

⚠ WARNING

Read the safety instructions before installing the unit. Failure to follow recommendations could result in death or serious injury.

Mechanical Installation

- Mechanical mounting

Electrical Installation

- Connection to Mains and Protecting Earth
- Motor connection and cables
- Fuses and circuit breakers
- Control terminals - cables

Quick Setup

- Local Control Panel, LCP
- Automatic Motor Adaptation, AMA
- Programming

Frame size is depending on enclosure type, power range and mains voltage.




Illustration 3.1 Diagram showing basic installation including mains, motor, start/stop key, and potentiometer for speed adjustment.

3.2 Pre-installation

3.2.1 Planning the Installation Site

⚠ CAUTION

Before performing the installation it is important to plan the installation of the frequency converter. Neglecting this may result in extra work during and after installation.

Select the best possible operation site by considering the following (see details on the following pages, and the respective Design Guides)

- Ambient operating temperature
- Installation method
- How to cool the unit
- Position of the frequency converter
- Cable routing
- Ensure the power source supplies the correct voltage and necessary current
- Ensure that the motor current rating is within the maximum current from the frequency converter
- If the frequency converter is without built-in fuses, ensure that the external fuses are rated correctly.

3

3.2.2 Receiving the Frequency Converter

When receiving the frequency converter, make sure that the packaging is intact, and be aware of any damage that might have occurred to the unit during transport. In case damage has occurred, contact immediately the shipping company to claim the damage.

3.2.3 Transportation and Unpacking

Before unpacking the frequency converter it is recommended that it is located as close as possible to the final installation site.

Remove the box and handle the frequency converter on the pallet, as long as possible.

3.2.4 Lifting

Always lift the frequency converter in the dedicated lifting eyes. For all D and E2 (IP00) enclosures, use a bar to avoid bending the lifting holes of the frequency converter.




Illustration 3.2 Recommended Lifting Method, Enclosure Types D and E

⚠ WARNING

The lifting bar must be able to handle the weight of the frequency converter. See *Mechanical Dimensions* for the weight of the different enclosure type. Maximum diameter for bar is 2.5 cm (1 inch). The angle from the top of the frequency converter to the lifting cable should be 60° or greater.




Illustration 3.3 Recommended Lifting Method, Enclosure Type F1 (460 V, 600 to 900 hp, 575/690 V, 900 to 1150 hp)






Illustration 3.4 Recommended Lifting Method, Enclosure Type F2 (460 V, 1000 to 1200 hp, 575/690 V, 1250 to 1350 hp)




130BA833.1

Illustration 3.5 Recommended Lifting Method, Enclosure Type F3 (460 V, 600 to 900 hp, 575/690 V, 900 to 1150 hp)




130BA835.1

Illustration 3.6 Recommended Lifting Method, Enclosure Type F4 (460 V, 1000 to 1200 hp, 575/690 V, 1250 to 1350 hp)




130BE753.10

Illustration 3.7 Recommended lifting method, Enclosure Type F8



130BE685.10

Illustration 3.8 Recommended lifting method, Enclosure Type F9/F10



130BE685.10

Illustration 3.9 Recommended lifting method, Enclosure Type F11/F12/F13/F14

3


NOTICE

The plinth is provided in the same packaging as the frequency converter but is not attached to enclosure types F1-F4 during shipment. The plinth is required to allow airflow to the frequency converter to provide proper cooling. The F enclosures should be positioned on top of the plinth in the final installation location. The angle from the top of the frequency converter to the lifting cable should be 60° or greater.

In addition to the drawings above, a spreader bar is an acceptable way to lift the F enclosures.


3

3.2.5 Mechanical Dimensions



* Note airflow directions


Illustration 3.10



3

Illustration 3.11

3



* Note airflow directions


Illustration 3.12

E2

IP00 / CHASSIS

130BA445.10

3



* Note airflow directions

Illustration 3.13




Table 3.1




Table 3.2

3

Enclosure type Size		D1		D2		D3	D4
		110-132 kW at 400 V (380-480 V) 45-160 kW at 690 V (525-690 V)		160-250 kW at 400 V (380-480 V) 200-400 kW at 690 V (525-690 V)		110-132 kW at 400 V (380-480 V) 45-160 kW at 690 V (525-690 V)	160 - 250 kW at 400 V (380-480 V) 200-400 kW at 690 V (525-690 V)
IP NEMA		21 Type 1	54 Type 12	21 Type 1	54 Type 12	00 Chassis	00 Chassis
Shipping dimensions [mm]	Height	650	650	650	650	650	650
	Width	1730	1730	1730	1730	1220	1490
	Depth	570	570	570	570	570	570
Frequency converter dimensions [mm]	Height	1209	1209	1589	1589	104	1327
	Width	420	420	420	420	408	408
	Depth	380	380	380	380	375	375
	Max weight [kg]	104	104	151	151	91	138

Table 3.3 Mechanical dimensions, Enclosure type D

Enclosure Type Size		E1	E2	F1	F2	F3	F4
		315-450 kW at 400 V (380-480 V) 450-630 kW at 690 V (525-690 V)	315-450 kW at 400 V (380-480 V) 450-630 kW at 690 V (525-690 V)	500-710 kW at 400 V (380-480 V) 710-900 kW at 690 V (525-690 V)	800-1000 kW at 400 V (380-480 V) 1000-1200 kW at 690 V (525-690 V)	500-710 kW at 400 V (380-480 V) 710-900 kW at 690 V (525-690 V)	800-1000 kW at 400 V (380-480 V) 1000-1400 kW at 690 V (525-690 V)
IP NEMA		21, 54 Type 1/ Type 12	00 Chassis	21, 54 Type 1/Type 12	21, 54 Type 1/Type 12	21, 54 Type 1/Type 12	21, 54 Type 1/Type 12
Shipping dimensions [mm]	Height	840	831	2324	2324	2324	2324
	Width	2197	1705	1569	1962	2159	2559
	Depth	736	736	1130	1130	1130	1130
Frequency converter dimensions [mm]	Height	2000	1547	2204	2204	2204	2204
	Width	600	585	1400	1800	2000	2400
	Depth	494	498	606	606	606	606
Max weight [kg]		313	277	1004	1246	1299	1541

Table 3.4 Mechanical dimensions, Enclosure Types E and F

3.2.6 Rated Power





Enclosure type		D1	D2	D3	D4
		 130BA816.10	 130BA817.10	 130BA819.10	 130BA820.10
Enclosure protection	IP	21/54	21/54	00	00
	NEMA	Type 1/Type 12	Type 1/Type 12	Chassis	Chassis
Normal overload rated power - 110% overload torque		110 - 132 kW at 400 V (380 - 480 V) 45 - 160 kW at 690 V (525-690 V)	150 - 250 kW at 400 V (380 - 480 V) 200 - 400 kW at 690 V (525-690 V)	110 - 132 kW at 400 V (380 - 480 V) 45 - 160 kW at 690 V (525-690 V)	150 - 250 kW at 400 V (380 - 480 V) 200 - 400 kW at 690 V (525-690 V)

Table 3.5

3





Enclosure type		E1	E2	F1/F3	F2/F4
		 130BA818.10	 130BA821.10	 130BA959.10	 130BB092.11
Enclosure protection	IP	21/54	00	21/54	21/54
	NEMA	Type 1/Type 12	Chassis	Type 1/Type 12	Type 1/Type 12
Normal overload rated power -		315 - 450 kW at 400 V (380 - 480 V)	315 - 450 kW at 400 V (380 - 480 V)	500 - 710 kW at 400 V (380 - 480 V)	800 - 1000 kW at 400 V (380 - 480 V)
110% overload torque		450 - 630 kW at 690 V (525-690 V)	450 - 630 kW at 690 V (525-690 V)	710 - 900 kW at 690 V (525-690 V)	1000 - 1400 kW at 690 V (525-690 V)

Table 3.6

NOTICE

The F enclosures are available in 4 different sizes, F1, F2, F3 and F4. The F1 and F2 consist of an inverter cabinet on the right and rectifier cabinet on the left. The F3 and F4 have an additional options cabinet left of the rectifier cabinet. The F3 is an F1 with an additional options cabinet. The F4 is an F2 with an additional options cabinet.

3.3 Mechanical Installation

Preparation of the mechanical installation of the frequency converter must be done carefully to ensure a proper result and to avoid additional work during installation. Start taking a close look at the mechanical drawings at the end of this instruction to become familiar with the space demands.

3.3.1 Tools Needed

To perform the mechanical installation the following tools are needed:

- Drill with 10 or 12 mm drill
- Tape measure
- Wrench with relevant metric sockets (7-17mm)
- Extensions to wrench
- Sheet metal punch for conduits or cable glands in IP21/Nema 1 and IP54 units
- Lifting bar to lift the unit (rod or tube max. Ø 5 mm (1 inch), able to lift minimum 400 kg (880 lbs).
- Crane or other lifting aid to place the frequency converter in position
- A Torx T50 tool is needed to install the E1 in IP21 and IP54 enclosure types.

3.3.2 General Considerations

Wire access

Ensure that proper cable access is present including necessary bending allowance. As the IP00 enclosure is open to the bottom cables must be fixed to the back panel of the enclosure where the frequency converter is mounted, i.e. by using cable clamps.

CAUTION

All cable lugs/shoes must mount within the width of the terminal bus bar.

Space

Ensure proper space above and below the frequency converter to allow airflow and cable access. In addition space in front of the unit must be considered to enable opening of the door of the panel.




Illustration 3.14 Space in Front of IP21/IP54 Rated Enclosure Types D1 and D2




Illustration 3.15 Space in Front of IP21/IP54 Rated Enclosure Type E1




Illustration 3.16 Space in Front of IP21/IP54 Rated Enclosure Type F1




Illustration 3.17 Space in Front of IP21/IP54 Rated Enclosure Type F3




Illustration 3.18 Space in Front of IP21/IP54 Rated Enclosure Type F2




Illustration 3.19 Space in Front of IP21/IP54 Rated Enclosure Type F4

3.3.3 Terminal Locations - Enclosure Type D

Consider the following terminal positions when designing for cables access.

3




Illustration 3.20 Position of Power Connections, Enclosure Types D3 and D4




Illustration 3.21 Position of Power Connections with Disconnect Switch, Enclosure Types D1 and D2

Be aware that the power cables are heavy and hard to bend. Consider the optimum position of the frequency converter for ensuring easy installation of the cables.

NOTICE

All D enclosures are available with standard input terminals or disconnect switch. All terminal dimensions can be found in *Table 3.7*.

3

	IP21 (NEMA 1)/IP54 (NEMA 12)		IP00/Chassis	
	D1	D2	D3	D4
A	277 (10.9)	379 (14.9)	119 (4.7)	122 (4.8)
B	227 (8.9)	326 (12.8)	68 (2.7)	68 (2.7)
C	173 (6.8)	273 (10.8)	15 (0.6)	16 (0.6)
D	179 (7.0)	279 (11.0)	20.7 (0.8)	22 (0.8)
E	370 (14.6)	370 (14.6)	363 (14.3)	363 (14.3)
F	300 (11.8)	300 (11.8)	293 (11.5)	293 (11.5)
G	222 (8.7)	226 (8.9)	215 (8.4)	218 (8.6)
H	139 (5.4)	142 (5.6)	131 (5.2)	135 (5.3)
I	55 (2.2)	59 (2.3)	48 (1.9)	51 (2.0)
J	354 (13.9)	361 (14.2)	347 (13.6)	354 (13.9)
K	284 (11.2)	277 (10.9)	277 (10.9)	270 (10.6)
L	334 (13.1)	334 (13.1)	326 (12.8)	326 (12.8)
M	250 (9.8)	250 (9.8)	243 (9.6)	243 (9.6)
N	167 (6.6)	167 (6.6)	159 (6.3)	159 (6.3)
O	261 (10.3)	260 (10.3)	261 (10.3)	261 (10.3)
P	170 (6.7)	169 (6.7)	170 (6.7)	170 (6.7)
Q	120 (4.7)	120 (4.7)	120 (4.7)	120 (4.7)
R	256 (10.1)	350 (13.8)	98 (3.8)	93 (3.7)
S	308 (12.1)	332 (13.0)	301 (11.8)	324 (12.8)
T	252 (9.9)	262 (10.3)	245 (9.6)	255 (10.0)
U	196 (7.7)	192 (7.6)	189 (7.4)	185 (7.3)
V	260 (10.2)	273 (10.7)	260 (10.2)	273 (10.7)

Table 3.7 Cable Positions Dimensions in mm (inch)

3.3.4 Terminal Locations - E Enclosures

Terminal Locations - E1

Take the following position of the terminals into consideration when designing the cable access.

3





Illustration 3.22 IP21 (NEMA Type 1) and IP54 (NEMA Type 12) Enclosure Power Connection Positions



3

Illustration 3.23 IP21 (NEMA type 1) and IP54 (NEMA type 12)
Enclosure Power Connection Positions (Detail B)

3




Illustration 3.24 IP21 (NEMA type 1) and IP54 (NEMA type 12) Enclosure Power Connection Position of Disconnect Switch

Enclosure types	Unit type	Dimensions [mm]/(inch)					
E1	IP54/IP21 UL AND NEMA1/NEMA12						
	250/315 kW (400 V) AND 355/450-500/630 KW (690 V)	396 (15.6)	267 (10.5)	332 (13.1)	397 (15.6)	528 (20.8)	N/A
	315/355-400/450 kW (400 V)	408 (16.1)	246 (9.7)	326 (12.8)	406 (16.0)	419 (16.5)	459 (18.1)

Table 3.8 Dimensions for Disconnect Terminal

Terminal locations - enclosure type E2

Take the following position of the terminals into consideration when designing the cable access.




Illustration 3.25 IP00 Enclosure Power Connection Positions




Illustration 3.26 IP00 Enclosure Power Connection Positions

3




Illustration 3.27 IP00 Enclosure Power Connections Positions of Disconnect Switch

NOTICE

The power cables are heavy and difficult to bend. Consider the optimum position of the frequency converter for ensuring easy installation of the cables.

Each terminal allows use of up to 4 cables with cable lugs or use of standard box lug. Earth is connected to relevant termination point in the frequency converter.

If lugs are wider than 39 mm, install supplied barriers on the mains input side of the disconnect.




Illustration 3.28 Terminal in Details

NOTICE

Power connections can be made to positions A or B

Enclosure type	Unit type	Dimensions [mm]/(inch)					
		A	B	C	D	E	F
E2	IPOO/CHASSIS						
	250/315 kW (400 V) AND 355/450-500/630 kW (690 V)	396 (15.6)	268 (10.6)	333 (13.1)	398 (15.7)	221 (8.7)	N/A
	315/355-400/450 kW (400 V)	408 (16.1)	239 (9.4)	319 (12.5)	399 (15.7)	113 (4.4)	153 (6.0)

Table 3.9 Dimensions for Disconnect Terminal

3.3.5 Terminal Locations - Enclosure type F

NOTICE

The F enclosures have 4 different sizes, F1, F2, F3 and F4. The F1 and F2 consist of an inverter cabinet on the right and rectifier cabinet on the left. The F3 and F4 have an additional options cabinet left of the rectifier cabinet. The F3 is an F1 with an additional options cabinet. The F4 is an F2 with an additional options cabinet.

Terminal locations - enclosure types F1 and F3




Illustration 3.29 Terminal Locations - Inverter Cabinet - F1 and F3 (Front, Left and Right Side View). The Gland Plate is 42 mm below .0 Level.

- 1) Earth ground bar
- 2) Motor terminals
- 3) Brake terminals

3




Illustration 3.30 Terminal Locations - Regen Terminals - F1 and F3

Terminal locations - enclosure types F2 and F4




Illustration 3.31 Terminal Locations - Inverter Cabinet - F2 and F4 (Front, Left and Right Side View). The Gland Plate is 42 mm below .0 Level.

1) Earth Ground Bar




Illustration 3.32 Terminal Locations - Regen Terminals - F2 and F4

Terminal locations - Rectifier (F1, F2, F3 and F4)




Illustration 3.33 Terminal Locations - Rectifier (Left Side, Front and Right Side View). The Gland Plate is 42 mm below .0 Level.

- 1) Loadshare Terminal (-)
- 2) Earth Ground Bar
- 3) Loadshare Terminal (+)

Terminal locations - Options Cabinet (F3 and F4)




Illustration 3.34 Terminal Locations - Options Cabinet (Left Side, Front and Right Side View). The Gland Plate is 42 mm below .0 Level.

1) Earth Ground Bar

3

Terminal locations - Options Cabinet with circuit breaker/ molded case switch (F3 and F4)




Illustration 3.35 Terminal Locations - Options Cabinet with Circuit Breaker/Molded Case Switch (Left Side, Front and Right Side View). The Gland Plate is 42 mm below .0 Level.

1) Earth Ground Bar

Power size	2	3	4	5
500 kW (480 V), 710-800 kW (690 V)	34.9	86.9	122.2	174.2
560-1000 kW (480 V), 900-1400 kW (690 V)	46.3	98.3	119.0	171.0

Table 3.10 Dimensions for Terminal

See chapter 3.4.1 Installation of Duct Cooling Kit in Rittal Enclosures, for further information.

Back cooling

The backchannel air can also be ventilated in and out the back of a Rittal TS8 enclosure. This offers a solution where the backchannel could take air from outside the facility and return the heat losses outside the facility thus reducing air-conditioning requirements.

3.3.6 Cooling and Airflow

Cooling

Cooling can be obtained in different ways, by using the cooling ducts in the bottom and the top of the unit, by taking air in and out the back of the unit or by combining the cooling possibilities.

Duct cooling

A dedicated option has been developed to optimize installation of IP00/chassis frequency converters in Rittal TS8 enclosures utilizing the fan of the frequency converter for forced air cooling of the backchannel. The air out of the top of the enclosure could but ducted outside a facility so the heat losses from the backchannel are not dissipated within the control room reducing air-conditioning requirements of the facility.

CAUTION

A door fan(s) is required on the enclosure to remove the heat losses not contained in the backchannel of the frequency converter and any additional losses generated from other components installed inside the enclosure. The total required air flow must be calculated so that the appropriate fans can be selected. Some enclosure manufacturers offer software for performing the calculations (i.e. Rittal Therm software). If the frequency converter is the only heat generating component in the enclosure, the minimum airflow required at an ambient temperature of 45 °C for the D3 and D4 frequency converters is 391 m³/h (230 cfm). The minimum airflow required at an ambient temperature of 45°C for the E2 frequency converter is 782 m³/h (460 cfm).

Airflow

The necessary airflow over the heat sink must be secured. The flow rate is in *Table 3.11*.

Enclosure protection	Enclosure type	Door fan(s)/ Top fan airflow	Heat sink fan(s)
IP21/NEMA 1 IP54/NEMA 12	D1 and D2	170 m ³ /h (100 cfm)	765 m ³ /h (450 cfm)
	E1 P315T5, P450T7, P500T7	340 m ³ /h (200 cfm)	1105 m ³ /h (650 cfm)
	E1 P355- P450T5, P560- P630T7	340 m ³ /h (200 cfm)	1445 m ³ /h (850 cfm)
IP21/NEMA 1	F1, F2, F3 and F4	700 m ³ /h (412 cfm)*	985 m ³ /h (580 cfm)*
IP54/NEMA 12	F1, F2, F3 and F4	525 m ³ /h (309 cfm)*	985 m ³ /h (580 cfm)*
IP00/Chassis	D3 and D4	255 m ³ /h (150 cfm)	765 m ³ /h (450 cfm)
	E2 P315T5, P450T7, P500T7	255 m ³ /h (150 cfm)	1105 m ³ /h (650 cfm)
	E2 P355- P450T5, P560- P630T7	255 m ³ /h (150 cfm)	1445 m ³ /h (850 cfm)

* Airflow per fan. enclosure type F contain multiple fans.

Table 3.11 Heat Sink Air Flow

NOTICE

The fan runs for the following reasons:

1. AMA
2. DC Hold
3. Pre-Mag
4. DC Brake
5. 60% of nominal current is exceeded
6. Specific heat sink temperature exceeded (power size dependent)
7. Specific Power Card ambient temperature exceeded (power size dependent)
8. Specific Control Card ambient temperature exceeded

Once the fan is started it will run for minimum 10 minutes.

External ducts

If additional duct work is added externally to the Rittal cabinet the pressure drop in the ducting must be calculated. Use the charts below to derate the frequency converter according to the pressure drop.




Illustration 3.36 D Enclosure Derating vs. Pressure Change
Frequency converter air flow: 450 cfm (765 m³/h)




Illustration 3.37 E Enclosure Derating vs. Pressure Change
(Small Fan), P315T5 and P450T7-P500T7
Frequency converter air flow: 650 cfm (1105 m³/h)




Illustration 3.38 E Enclosure Derating vs. Pressure Change (Large Fan), P355T5-P450T5 and P560T7-P630T7

Frequency converter air flow: 850 cfm (1445 m³/h)




Illustration 3.39 F1, F2, F3, F4 Enclosures Derating vs. Pressure Change

Frequency converter air flow: 580 cfm (985 m³/h)

3.3.7 Installation on the Wall - IP21 (NEMA 1) and IP54 (NEMA 12) Units

This only applies to enclosure types D1 and D2. It must be considered where to install the unit.

Take the relevant points into consideration before selecting the final installation site:

- Free space for cooling
- Access to open the door
- Cable entry from the bottom

Mark the mounting holes carefully using the mounting template on the wall and drill the holes as indicated. Ensure proper distance to the floor and the ceiling for cooling. A minimum of 225 mm (8.9 inch) below the frequency converter is needed. Mount the bolts at the bottom and lift the frequency converter up on the bolts. Tilt the frequency converter against the wall and mount the upper bolts. Tighten all 4 bolts to secure the frequency converter against the wall.




Illustration 3.40 Lifting Method for Mounting Frequency Converter on Wall

3.3.8 Gland/Conduit Entry - IP21 (NEMA 1) and IP54 (NEMA 12)

Cables are connected through the gland plate from the bottom. Remove the plate and plan where to place the entry for the glands or conduits. Prepare holes in the marked area on the drawing.

NOTICE

The gland plate must be fitted to the frequency converter to ensure the specified protection degree, as well as ensuring proper cooling of the unit. If the gland plate is not mounted, the frequency converter may trip on Alarm 69, Pwr. Card Temp




Illustration 3.41 Example of Proper Installation of Gland Plate.

Cable entries viewed from the bottom of the frequency converter - 1) Mains side 2) Motor side




Illustration 3.42 Enclosure Types D1 + D2




Illustration 3.43 Enclosure Type E1

Enclosure types F1-F4: Cable entries viewed from the bottom of the frequency converter - 1) Place conduits in marked areas




Illustration 3.44 Enclosure Type F1




Illustration 3.45 Enclosure Type F2




Illustration 3.46 Enclosure Type F3




Illustration 3.47 Enclosure Type F4

3.3.9 IP21 Drip Shield Installation (Enclosure Types D1 and D2)

To comply with the IP21 rating, a separate drip shield is to be installed as explained below:

- Remove the 2 front screws
- Insert the drip shield and replace screws
- Tighten the screws to 5.6 Nm (50 in-lbs)




Illustration 3.48 Drip Shield Installation.

3.4 Field Installation of Options

3.4.1 Installation of Duct Cooling Kit in Rittal Enclosures

This section deals with the installation of IP00/chassis enclosed frequency converters with duct work cooling kits in Rittal enclosures. In addition to the enclosure a 200 mm base/plinth is required.




Illustration 3.49 Installation of IP00 in Rittal TS8 Enclosure.

The minimum enclosure dimension is:

- D3 and D4 enclosures: Depth 500 mm and width 600 mm.
- E2 enclosure: Depth 600 mm and width 800 mm.

The maximum depth and width are as required by the installation. When using multiple frequency converters in one enclosure, it is recommended that each frequency converter is mounted on its own back panel and

supported along the mid-section of the panel. These duct work kits do not support the “in frame” mounting of the panel (see Rittal TS8 catalogue for details). The duct work cooling kits listed in *Table 3.12* are suitable for use only with IP00/Chassis frequency converters in Rittal TS8 IP 20 and UL and NEMA 1 and IP 54 and UL and NEMA 12 enclosures.

CAUTION

For the E2 enclosures it is important to mount the plate at the absolute rear of the Rittal enclosure due to the weight of the frequency converter.

CAUTION

A doorfan(s) is required on the enclosure to remove the heat losses not contained in the backchannel of the frequency converter and any additional losses generated from other components installed inside the enclosure. The total required airflow must be calculated so that the appropriate fans can be selected. Some enclosure manufacturers offer software for performing the calculations (i.e. Rittal Therm software). If the frequency converter is the only heat generating component in the enclosure, the minimum airflow required at an ambient temperature of 45 °C for the D3 and D4 frequency converters is 391 m³/h (230 cfm). The minimum airflow required at an ambient temperature of 45 °C for the E2 frequency converter is 782 m³/h (460 cfm).

Rittal TS-8 Enclosure	Enclosure type D3 Kit Part No.	Enclosure type D4 Kit Part No.	Enclosure type E2 Part No.
1800 mm	176F1824	176F1823	Not possible
2000 mm	176F1826	176F1825	176F1850
2200 mm			176F0299

Table 3.12 Ordering Information

NOTICE

See the instruction *Duct Work Cooling Kit Instruction for Frames D3, D4 and E2* for further information.

External ducts

If additional duct work is added externally to the Rittal cabinet the pressure drop in the ducting must be calculated. See *chapter 3.3.6 Cooling and Airflow* for further information.

3.4.2 Installation of Top-only Duct Cooling Kit

This description is for the installation of the top section only of the back-channel cooling kits available for frame sizes D3, D4 and E2. In addition to the enclosure a 200 mm vented pedestal is required.

The minimum enclosure depth is 500 mm (600 mm for E2 frame) and the minimum enclosure width is 600 mm (800 mm for E2 frame). The maximum depth and width are as required by the installation. When using multiple frequency converters in one enclosure mount each frequency converter on its own back panel and support along the mid-section of the panel. The back-channel cooling kits are very similar in construction for all frames. The D3 and D443 and 44 kits do not support “in frame” mounting of the frequency converters. The E2 kit is mounted “in frame” for additional support of the frequency converter.

Using these kits as described removes 85% of the losses via the back channel using the frequency converter’s main heat sink fan. The remaining 15% must be removed via the door of the enclosure.

NOTICE

See the *Top-Only Back-Channel Cooling Kit Instruction, 175R1107*, for further information.

Ordering information

Frame size D3 and D4: 176F1775

Frame size E2: 176F1776

3.4.3 Installation of Top and Bottom Covers for Rittal Enclosures

The top and bottom covers, installed onto IP00 frequency converters, direct the heat sink cooling air in and out the back of the frequency converter. The kits are applicable to IP00 frequency converterframes D3, D4 and E2. These kits are designed and tested to be used with IP00/Chassis frequency converters in Rittal TS8 enclosures.

Notes:

1. If external duct work is added to the exhaust path of the frequency converter, additional back pressure reduces the cooling of the frequency converter. The frequency converter must be derated to accommodate the reduced cooling. First, the pressure drop must be calculated, then refer to the derating tables located earlier in this section.
2. A doorfan(s) is required on the enclosure to remove the heat losses not contained in the backchannel of the frequency converter and any

additional losses generated from other components installed inside the enclosure. The total required airflow must be calculated so that the appropriate fans can be selected. Some enclosure manufacturers offer software for performing the calculations (i.e. Rittal Therm software).

If the frequency converter is the only heat generating component in the enclosure, the minimum airflow required at an ambient temperature of 45 °C for the D3 and D4 frame frequency converter is 391 m³/h (230 cfm). The minimum airflow required at an ambient temperature of 45 °C for the E2 frame frequency converter is 782 m³/h (460 cfm).

NOTICE

See the instruction for *Top and Bottom Covers - Rittal Enclosure, 177R0076*, for further information.

Ordering information

Frame size D3: 176F1781

Frame size D4: 176F1782

Frame size E2: 176F1783

3.4.4 Installation of Top and Bottom Covers

Top and bottom covers can be installed on frame sizes D3, D4 and E2. These kits are designed to be used to direct the back-channel airflow in and out the back of the frequency converter as opposed to in the bottom and out the top of the frequency converter (when the frequency converters are being mounted directly on a wall or inside a welded enclosure).

Notes:

1. If external duct work is added to the exhaust path of the frequency converter, additional back pressure reduces the cooling of the frequency converter. The frequency converter must be derated to accommodate the reduced cooling. First, the pressure drop must be calculated, then refer to the derating tables located earlier in this section.
2. A doorfan(s) is required on the enclosure to remove the heat losses not contained in the backchannel of the frequency converter and any additional losses generated from other components installed inside the enclosure. The total required airflow must be calculated so that the appropriate fans can be selected. Some enclosure manufacturers offer software for performing the calculations (i.e. Rittal Therm software).

If the frequency converter is the only heat generating component in the enclosure, the minimum airflow required at an ambient temperature of 45 °C for the D3 and D4 frame frequency converters is 391 m³/h (230 cfm). The minimum airflow required at an ambient temperature of 45 °C for the E2 frame frequency converter is 782 m³/h (460 cfm).

NOTICE

See the *Top and Bottom Covers Only Instruction, 175R1106*, for further information.

Ordering information

Frame size D3 and D4: 176F1862

Frame size E2: 176F1861

3.4.5 Outside Installation/NEMA 3R Kit for Rittal Enclosures




Illustration 3.50

This section is for the installation of NEMA 3R kits available for the frequency converter enclosure types D3, D4 and E2. These kits are designed and tested to be used with IP00/Chassis versions of these enclosure types in Rittal TS8 NEMA 3R or NEMA 4 enclosures. The NEMA-3R enclosure is an outdoor enclosure that provides a degree of protection against rain and ice. The NEMA-4 enclosure is an outdoor

enclosure that provides a greater degree of protection against weather and hosed water.

The minimum enclosure depth is 500 mm (600 mm for enclosure type E2) and the kit is designed for a 600 mm (800 mm for enclosure type E2) wide enclosure. Other enclosure widths are possible, however additional Rittal hardware is required. The maximum depth and width are as required by the installation.

NOTICE

The current rating of frequency converters in enclosure types D3 and D4 are de-rated by 3%, when adding the NEMA 3R kit. Frequency converters in enclosure type E2 require no derating.

NOTICE

A doorfan(s) is required on the enclosure to remove the heat losses not contained in the backchannel of the frequency converter and any additional losses generated from other components installed inside the enclosure. The total required airflow must be calculated so that the appropriate fans can be selected. Some enclosure manufacturers offer software for performing the calculations (i.e. Rittal Therm software). If the frequency converter is the only heat generating component in the enclosure, the minimum airflow required at an ambient temperature of 45 °C for the D3 and D4 frequency converters is 391 m³/h (230 cfm). The minimum airflow required at an ambient temperature of 45 °C for the E2 frequency converter is 782 m³/h (460 cfm).

Ordering information

Enclosure type D3: 176F4600

Enclosure type D4: 176F4601

Enclosure type E2: 176F1852

NOTICE

See the instructions *Installation of NEMA 3R Kit for IP00 Frames D3, D4 & E2* for further information.

3.4.6 Outside Installation/NEMA 3R Kit of Industrial Enclosures

The kits are available for the frame sizes D3, D4 and E2. These kits are designed and tested to be used with IP00/Chassis frequency converters in welded box construction enclosures with an environmental rating of NEMA-3R or NEMA-4. The NEMA-3R enclosure is a dust tight, rain tight, ice resistant, outdoor enclosure. The NEMA-4 enclosure is a dust tight and water tight enclosure.

This kit has been tested and complies with UL environmental rating Type-3R.

Note: The current rating of D3 and D4 frame frequency converters are de-rated by 3% when installed in a NEMA-3R enclosure. E2 frame frequency converters require no derating when installed in a NEMA-3R enclosure.

NOTICE

See the instruction for *Outside Installation/NEMA 3R kit of industrial enclosures, 175R1068*, for further information.

Ordering information

Frame size D3: 176F0296

Frame size D4: 176F0295

Frame size E2: 176F0298

3.4.7 Installation of IP00 to IP20 Kits

The kits can be installed on frame sizes D3, D4, and E2 (IP00).

CAUTION

See the instruction for *Installation of IP20 Kits, 175R1108*, for further information.

Ordering information

Frame size D3/D4: 176F1779

Frame size E2: 176FXXXX

3.4.8 Installation of IP00s D3, D4, & E2 Cable Clamp Bracket

The motor cable clamp brackets can be installed on frame sizes D3 and D4 (IP00).

NOTICE

See the instruction for *Cable Clamp Bracket Kit, 175R1109*, for further information.

Ordering information

Frame size D3: 176F1774

Frame size D4: 176F1746

Frame size E2: 176F1745

3.4.9 Installation on Pedestal

This section describes the installation of a pedestal unit available for the frequency converters enclosure types D1 and D2. This is a 200 mm high pedestal that allows these enclosure types to be floor mounted. The front of the pedestal has openings for input air to the power components.

The frequency converter gland plate must be installed to provide adequate cooling air to the control components of

the frequency converter via the door fan and to maintain the IP21/NEMA 1 or IP54/NEMA 12 degrees of enclosure protections.




Illustration 3.51 Frequency Converter on Pedestal

There is one pedestal that fits both enclosure types D1 and D2. Its ordering number is 176F1827. The pedestal is standard for enclosure type E1.




Illustration 3.52 Mounting of Frequency Converter to Pedestal

NOTICE

See the *Pedestal Kit Instruction Manual*, for further information.

3.4.10 Installation of Mains Shield for Frequency Converters

This section is for the installation of a mains shield for the frequency converter series with enclosure types D1, D2 and E1. It is not possible to install in the IP00/Chassis versions as these have included as standard a metal cover. These shields satisfy VBG-4 requirements.

Ordering numbers:

- Enclosure types D1 and D2: 176F0799
- Enclosure type E1: 176F1851

NOTICE

For further information, see the *Instruction Sheet, 175R5923*

3.4.11 F Frame USB Extension Kit

A USB extension cable can be installed into the door of F frame frequency converters.

Ordering number:

176F1784

NOTICE

For further information, see the Instruction Sheet, 177R0091

3.4.12 Installation of Input Plate Options

This section is for the field installation of input option kits available for frequency converters in all enclosure types D and E. Do not attempt to remove RFI filters from input plates. Damage may occur to RFI filters if they are removed from the input plate.

NOTICE

Where RFI filters are available, there are 2 different type of RFI filters depending on the input plate combination and the RFI filters interchangeable. Field installable kits in certain cases are the same for all voltages.

	380-480 V 380-500 V	Fuses	Disconnect Fuses	RFI	RFI Fuses	RFI Disconnect Fuses
D1	All D1 power sizes	176F8442	176F8450	176F8444	176F8448	176F8446
D2	All D2 power sizes	176F8443	176F8441	176F8445	176F8449	176F8447
E1	FC 102/ FC 202: 315 kW FC 302: 250 kW	176F0253	176F0255	176F0257	176F0258	176F0260
	FC 102/ FC 202: 355 - 450 kW FC 302: 315 - 400 kW	176F0254	176F0256	176F0257	176F0259	176F0262

Table 3.13 Fuses

	525 - 690 V	Fuses	Disconnect Fuses	RFI	RFI Fuses	RFI Disconnect Fuses
D1	FC 102/ FC 202: 45-90 kW FC 302: 37-75 kW	175L8829	175L8828	175L8777	NA	NA
	FC 102/ FC 202: 110-160 kW FC 302: 90-132 kW	175L8442	175L8445	175L8777	NA	NA
D2	All D2 power sizes	175L8827	175L8826	175L8825	NA	NA
E1	FC 102/ FC 202: 450-500 kW FC 302: 355-400 kW	176F0253	176F0255	NA	NA	NA
	FC 102/ FC 202: 560-630 kW FC 302: 500-560 kW	176F0254	176F0258	NA	NA	NA

Table 3.14

NOTICE

For further information, see the Instruction *Installation of Field Installable Kits for VLT Drives*

3.4.13 Installation of D or E Loadshare Option

The loadshare option can be installed on frame sizes D1, D2, D3, D4, E1 and E2.

NOTICE

See the *Loadshare Terminal Kit Instructions, 175R5637 (D frames) or 177R1114 (E frames)*, for further information.

Ordering information

Frame size D1/D3: 176F8456

Frame size D2/D4: 176F8455

Frame size E1/E2: 176F1843

3.5 Frame size F Panel Options

3.5.1 Enclosure Type F Options

Space Heaters and Thermostat

Mounted on the cabinet interior of enclosure type F frequency converters, space heaters controlled via automatic thermostat help control humidity inside the enclosure, extending the lifetime of frequency converter components in damp environments. The thermostat default settings turn on the heaters at 10 °C (50 °F) and turn them off at 15.6 °C (60 °F).

Cabinet Light with Power Outlet

A light mounted on the cabinet interior of enclosure type F frequency converters increase visibility during servicing and maintenance. The housing the light includes a power outlet for temporarily powering tools or other devices, available in two voltages:

- 230 V, 50 Hz, 2.5 A, CE/ENEC
- 120 V, 60 Hz, 5 A, UL/CUL

Transformer Tap Setup

If the cabinet light & outlet and/or the space heaters & thermostat are installed Transformer T1 requires it taps to be set to the proper input voltage. A 380-480/500 V frequency converter is set initially to the 525 V tap and a 525-690 V frequency converter is set to the 690 V tap to insure no overvoltage of secondary equipment occurs if the tap is not changed before power is applied. See *Table 3.15* to set the proper tap at terminal T1 located in the rectifier cabinet. For location in the frequency converter, see *Illustration 4.1*.

Input Voltage Range [V]	Tap to Select
380-440	400 V
441-490	460 V
491-550	525 V
551-625	575 V
626-660	660 V
661-690	690 V

Table 3.15

NAMUR Terminals

NAMUR is an international association of automation technology users in the process industries, primarily chemical and pharmaceutical industries in Germany. Selection of this option provides terminals organized and labeled to the specifications of the NAMUR standard for frequency converter input and output terminals. This requires MCB 112 PTC Thermistor Card and MCB 113 Extended Relay Card.

RCD (Residual Current Device)

Uses the core balance method to monitor ground fault currents in grounded and high-resistance grounded systems (TN and TT systems in IEC terminology). There is a pre-warning (50% of main alarm set-point) and a main alarm set-point. Associated with each set-point is an SPDT alarm relay for external use. Requires an external "window-type" current transformer (supplied and installed by customer).

- Integrated into the frequency converter's safe-stop circuit
- IEC 60755 Type B device monitors AC, pulsed DC, and pure DC ground fault currents
- LED bar graph indicator of the ground fault current level from 10–100% of the set-point
- Fault memory
- [TEST/RESET]

Insulation Resistance Monitor (IRM)

Monitors the insulation resistance in ungrounded systems (IT systems in IEC terminology) between the system phase conductors and ground. There is an ohmic pre-warning and a main alarm set-point for the insulation level. Associated with each set-point is an SPDT alarm relay for external use. Note: only one insulation resistance monitor can be connected to each ungrounded (IT) system.

- Integrated into the frequency converter's safe-stop circuit
- LCD display of the ohmic value of the insulation resistance
- Fault Memory
- [INFO], [TEST], and [RESET]

IEC Emergency Stop with Pilz Safety Relay

Includes a redundant 4-wire emergency-stop push-button mounted on the front of the enclosure and a Pilz relay that monitors it in conjunction with the frequency converter's safe-stop circuit and the mains contactor located in the options cabinet.

Safe Stop + Pilz Relay

Provides a solution for the "Emergency Stop" option without the contactor in F-Enclosure frequency converters.

Manual Motor Starters

Provides 3-phase power for electric blowers often required for larger motors. Power for the starters is provided from the load side of any supplied contactor, circuit breaker, or disconnect switch. Power is fused before each motor starter, and is off when the incoming power to the frequency converter is off. Up to 2 starters are allowed (one if a 30 A, fuse-protected circuit is ordered). Integrated into the frequency converter's safe-stop circuit.

Unit features include:

- Operation switch (on/off)
- Short-circuit and overload protection with test function
- Manual reset function

30 A, Fuse-Protected Terminals

- 3-phase power matching incoming mains voltage for powering auxiliary customer equipment
- Not available if 2 manual motor starters are selected
- Terminals are off when the incoming power to the frequency converter is off
- Power for the fused protected terminals will be provided from the load side of any supplied contactor, circuit breaker, or disconnect switch.

24 V DC Power Supply

- 5 A, 120 W, 24 V DC
- Protected against output over-current, overload, short circuits, and over-temperature
- For powering customer-supplied accessory devices such as sensors, PLC I/O, contactors, temperature probes, indicator lights, and/or other electronic hardware
- Diagnostics include a dry DC-ok contact, a green DC-ok LED, and a red overload LED

External Temperature Monitoring

Designed for monitoring temperatures of external system components, such as the motor windings and/or bearings. Includes five universal input modules. The modules are integrated into the frequency converter's safe-stop circuit and can be monitored via a fieldbus network (requires the purchase of a separate module/bus coupler).

Universal inputs (5)

Signal types:

- RTD inputs (including PT100), 3-wire or 4-wire
- Thermocouple
- Analog current or analog voltage

Additional features:

- One universal output, configurable for analog voltage or analog current
- 2 output relays (N.O.)

- Dual-line LC display and LED diagnostics
- Sensor lead wire break, short-circuit, and incorrect polarity detection
- Interface setup software

4 Electrical Installation

4.1 Electrical Installation

4.1.1 Power Connections

Cabling and Fusing

NOTICE

Cables General

All cabling must comply with national and local regulations on cable cross-sections and ambient temperature. UL applications require 75 °C copper conductors. 75 and 90 °C copper conductors are thermally acceptable for the frequency converter to use in non UL applications.

The power cable connections are situated as shown below. Dimensioning of cable cross section must be done in accordance with the current ratings and local legislation. See the *Specifications* section for details.

For protection of the frequency converter, the recommended fuses must be used or the unit must be with built-in fuses. Recommended fuses can be seen in the tables of the fuse section. Always ensure that proper fusing is made according to local regulation.

The mains connection is fitted to the mains switch if this is included.




Illustration 4.1 Power Cable Connections

NOTICE

The motor cable must be screened/armoured. If an unscreened/unarmoured cable is used, some EMC requirements are not complied with. Use a screened/armoured motor cable to comply with EMC emission specifications. For more information, see *EMC specifications* in the *Design Guide*.

See section *General Specifications* for correct dimensioning of motor cable cross-section and length.

Screening of cables

Avoid installation with twisted screen ends (pigtailed). They spoil the screening effect at higher frequencies. If it is necessary to break the screen to install a motor isolator or motor contactor, the screen must be continued at the lowest possible HF impedance.

Connect the motor cable screen to both the de-coupling plate of the frequency converter and to the metal housing of the motor.

Make the screen connections with the largest possible surface area (cable clamp). This is done by using the supplied installation devices within the frequency converter.

Cable-length and cross-section

The frequency converter has been EMC tested with a given length of cable. Keep the motor cable as short as possible to reduce the noise level and leakage currents.

Switching frequency

When frequency converters are used together with Sine-wave filters to reduce the acoustic noise from a motor, the switching frequency must be set according to the instruction in *14-01 Switching Frequency*.

Term. no.	96	97	98	99	
	U	V	W	PE ¹⁾	Motor voltage 0-100% of mains voltage. 3 wires out of motor
	U1	V1	W1	PE ¹⁾	Delta-connected
	W2	U2	V2		6 wires out of motor
	U1	V1	W1	PE ¹⁾	Star-connected U2, V2, W2 U2, V2 and W2 to be interconnected separately.


Table 4.1

¹⁾Protected Earth Connection

NOTICE

In motors without phase insulation paper or other insulation reinforcement suitable for operation with voltage supply (such as a frequency converter), fit a Sine-wave filter on the output of the frequency converter.

4



175ZA114.11

Illustration 4.2 Star/Delta Connections




Illustration 4.3 Compact IP21 (NEMA 1) and IP54 (NEMA 12), Enclosure Type D1




Illustration 4.4 Compact IP21 (NEMA 1) and IP54 (NEMA 12) with Disconnect, Fuse and RFI Filter, Enclosure Type D2

1)	AUX Relay	5)	Brake
	01 02 03		-R +R
	04 05 06		81 82
2)	Temp Switch	6)	SMPS Fuse (see fuse tables for part number)
	106 104 105	7)	AUX Fan
3)	Mains		100 101 102 103
	R S T		L1 L2 L1 L2
	91 92 93	8)	Fan Fuse (see fuse tables for part number)
	L1 L2 L3	9)	Mains ground
4)	Load sharing	10)	Motor
	-DC +DC		U V W
	88 89		96 97 98
			T1 T2 T3

Table 4.2 Legend to Illustration 4.3 and Illustration 4.4

4




Illustration 4.5 Compact IP00 (Chassis), Enclosure Type D3




Illustration 4.6 Compact IP00 (Chassis) with Disconnect, Fuse and RFI Filter, Enclosure Type D4

1)	AUX Relay	4)	Load sharing	8)	Fan Fuse (see fuse tables for part number)
	01 02 03		-DC +DC	9)	Mains ground
	04 05 06		88 89	10)	Motor
2)	Temp Switch	5)	Brake		U V W
	106 104 105		-R +R		96 97 98
3)	Mains		81 82		T1 T2 T3
	R S T	6)	SMPS Fuse (see fuse tables for part number)		
	91 92 93	7)	AUX Fan		
	L1 L2 L3		100 101 102 103		
			L1 L2 L1 L2		

Table 4.3 Legend to Illustration 4.5 and Illustration 4.6




Illustration 4.7 Position of Earth Terminals IP00, Enclosure Type D




Illustration 4.8 Position of Earth Terminals IP21 (NEMA type 1) and IP54 (NEMA type 12)

NOTICE

D2 and D4 shown as examples. D1 and D3 are equivalent.

4




Illustration 4.9 Compact IP21 (NEMA 1) and IP54 (NEMA 12) Enclosure Type E1




Illustration 4.10 Compact IP00 (Chassis) with Disconnect, Fuse and RFI Filter, Enclosure Type E2

1)	AUX Relay	5)	Load sharing
	01 02 03		-DC +DC
	04 05 06		88 89
2)	Temp Switch	6)	SMPS Fuse (see fuse tables for part number)
	106 104 105	7)	Fan Fuse (see fuse tables for part number)
3)	Mains	8)	AUX Fan
	R S T		100 101 102 103
	91 92 93		L1 L2 L1 L2
	L1 L2 L3	9)	Mains ground
4)	Brake	10)	Motor
	-R +R		U V W
	81 82		96 97 98
			T1 T2 T3

Table 4.4 Legend to *Illustration 4.9* and *Illustration 4.10*






Illustration 4.11 Position of Earth Terminals IP00, Enclosure Type E

4




1)	24 V DC, 5 A	5)	Loadsharing
	T1 Output Taps		-DC +DC
	Temp Switch		88 89
	106 104 105	6)	Control Transformer Fuses (2 or 4 pieces). See fuse tables for part numbers
2)	Manual Motor Starters	7)	SMPS Fuse. See fuse tables for part numbers
3)	30 A Fuse Protected Power Terminals	8)	Manual Motor Controller fuses (3 or 6 pieces). See fuse tables for part numbers
4)	Mains	9)	Line Fuses, enclosure types F1 and F2 (3 pieces). See fuse tables for part numbers
	R S T	10)	30 Amp Fuse Protected Power fuses
	L1 L2 L3		

Illustration 4.12 Rectifier Cabinet, Enclosure Types F1, F2, F3 and F4




1)	External Temperature Monitoring	6)	Motor
2)	AUX Relay		U V W
	01 02 03		96 97 98
	04 05 06		T1 T2 T3
3)	NAMUR	7)	NAMUR Fuse. See fuse tables for part numbers
4)	AUX Fan	8)	Fan Fuses. See fuse tables for part numbers
	100 101 102 103	9)	SMPS Fuses. See fuse tables for part numbers
	L1 L2 L1 L2		
5)	Brake		
	-R +R		
	81 82		

Illustration 4.13 Inverter Cabinet, Enclosure Types F1 and F3



1)	External Temperature Monitoring	6)	Motor
2)	AUX Relay		U V W
	01 02 03		96 97 98
	04 05 06		T1 T2 T3
3)	NAMUR	7)	NAMUR Fuse. See fuse tables for part numbers
4)	AUX Fan	8)	Fan Fuses. See fuse tables for part numbers
	100 101 102 103	9)	SMPS Fuses. See fuse tables for part numbers
	L1 L2 L1 L2		
5)	Brake		
	-R +R		
	81 82		

Illustration 4.14 Inverter Cabinet, Enclosure Types F2 and F4



1)	Pilz Relay Terminal	4)	Safety Relay Coil Fuse with PILZ Relay
2)	RCD or IRM Terminal		See fuse tables for part numbers
3)	Mains	5)	Line Fuses, F3 and F4 (3 pieces)
	R S T		See fuse tables for part numbers
	91 92 93	6)	Contactor Relay Coil (230 VAC), N/C and N/O Aux Contacts (customer supplied)
	L1 L2 L3	7)	Circuit Breaker Shunt Trip Control Terminals (230 V AC or 230 V DC)

Illustration 4.15 Options Cabinet, Enclosure Types F3 and F4

4.1.2 Grounding

The following basic issues need to be considered when installing a frequency converter, so as to obtain electro-magnetic compatibility (EMC).

- Safety grounding: The frequency converter has a high leakage current and must be grounded appropriately for safety reasons. Apply local safety regulations.
- High-frequency grounding: Keep the ground wire connections as short as possible.

Connect the different ground systems at the lowest possible conductor impedance. The lowest possible conductor impedance is obtained by keeping the conductor as short as possible and by using the greatest possible surface area.

The metal cabinets of the different devices are mounted on the cabinet rear plate using the lowest possible HF impedance. This avoids having different HF voltages for the individual devices and avoids the risk of radio interference currents running in connection cables that may be used between the devices. The radio interference has been reduced.

To obtain a low HF impedance, use the fastening bolts of the devices as HF connection to the rear plate. It is necessary to remove insulating paint or similar from the fastening points.

4.1.3 Extra Protection (RCD)

ELCB relays, multiple protective earthing or earthing can be used as extra protection, provided that local safety regulations are complied with.

In case of an ground fault, a DC component may develop in the fault current.

If ELCB relays are used, local regulations must be observed. Relays must be suitable for protection of 3-phase equipment with a bridge rectifier and for a brief discharge on power-up.

See also *Special Conditions* in the *Design Guide*.

4.1.4 RFI Switch

Mains supply isolated from earth

If the frequency converter is supplied from an isolated mains source (IT mains, floating delta and grounded delta) or TT/TN-S mains with grounded leg, the RFI switch is recommended to be turned off (OFF) via *14-50 RFI Filter* on the frequency converter and *14-50 RFI Filter* on the filter. For further reference, see IEC 364-3. In case optimum EMC performance is needed, parallel motors are connected or the motor cable length is above 25 m, it is recommended to set *14-50 RFI Filter* to [ON].

In OFF, the internal RFI capacities (filter capacitors) between the chassis and the intermediate circuit are cut off to avoid damage to the intermediate circuit and to reduce the earth capacity currents (according to IEC 61800-3).

Also refer to the application note *VLT on IT Mains* It is important to use isolation monitors that are capable for use together with power electronics (IEC 61557-8).

4.1.5 Torque

When tightening all electrical connections it is very important to tighten with the correct torque. Too low or too high torque results in a bad electrical connection. Use a torque wrench to ensure correct torque.




Illustration 4.16 Tightening Bolts with a Torque Wrench

Enclosure types	Terminal	Torque [Nm] (in-lbs)	Bolt size
D	Mains Motor	19-40 (168-354)	M10
	Load sharing Brake	8.5-20.5 (75-181)	M8
E	Mains Motor Load sharing	19-40 (168-354)	M10
	Brake	8.5-20.5 (75-181)	M8

Enclosure types	Terminal	Torque [Nm] (in-lbs)	Bolt size
F	Mains	19-40	M10
	Motor	(168-354)	
	Load sharing	19-40	M10 M8 M8
	Brake	(168-354)	
Regen	8.5-20.5 (75-181) 8.5-20.5 (75-181)		

Table 4.5 Torque for Terminals

4.1.6 Shielded Cables

WARNING

Danfoss recommends to use shielded cables between the LCL filter and the AFE unit. Unshielded cables can be between transformer and LCL filter input side.

It is important that shielded and armoured cables are connected in a proper way to ensure the high EMC immunity and low emissions.

The connection can be made using either cable glands or clamps


- EMC cable glands: Generally available cable glands can be used to ensure an optimum EMC connection.
- EMC cable clamp: Clamps allowing easy connection are supplied with the frequency converter.

4.1.7 Motor Cable

The motor must be connected to terminals U/T1/96, V/T2/97, W/T3/98. Earth to terminal 99. All types of 3-phase asynchronous standard motors can be used with a frequency converter unit. The factory setting is for clockwise rotation with the frequency converter output connected as follows:

Terminal No.	Function
96, 97, 98, 99	Mains U/T1, V/T2, W/T3 Earth

Table 4.6 Mains Terminals



- Terminal U/T1/96 connected to U-phase
- Terminal V/T2/97 connected to V-phase
- Terminal W/T3/98 connected to W-phase

Table 4.7

The direction of rotation can be changed by switching 2 phases in the motor cable or by changing the setting of 4-10 Motor Speed Direction.

Motor rotation check can be performed using parameter 1-28 Motor Rotation Check and following the steps shown in the display.

F enclosure requirements

F1/F3 requirements: Motor phase cable quantities must be multiples of 2, resulting in 2, 4, 6, or 8 (1 cable is not allowed) to obtain equal amount of wires attached to both inverter module terminals. The cables are required to be equal length within 10% between the inverter module terminals and the first common point of a phase. The recommended common point is the motor terminals.

F2/F4 requirements: Motor phase cable quantities must be multiples of 3, resulting in 3, 6, 9, or 12 (1 or 2 cables are not allowed) to obtain equal amount of wires attached to each inverter module terminal. The wires are required to be equal length within 10% between the inverter module terminals and the first common point of a phase. The recommended common point is the motor terminals.

Output junction box requirements: The length, minimum 2.5 m, and quantity of cables must be equal from each inverter module to the common terminal in the junction box.

NOTICE

If a retrofit application requires unequal amount of wires per phase, consult the factory for requirements and documentation or use the top/bottom entry side cabinet option.

4.1.8 Brake Cable for Frequency Converters with Factory Installed Brake Chopper Option

(Only standard with letter B in position 18 of typecode).

The connection cable to the brake resistor must be screened and the max. length from frequency converter to the DC bar is limited to 25 m (82 ft).

Terminal No.	Function
81, 82	Brake resistor terminals

Table 4.8 Terminals for Brake Resistor

The connection cable to the brake resistor must be screened. Connect the screen with cable clamps to the conductive back plate at the frequency converter and to the metal cabinet of the brake resistor.

Size the brake cable cross-section to match the brake torque. See also the instructions *Brake Resistor* and *Brake Resistors for Horizontal Applications* for further information regarding safe installation.

⚠ WARNING

Note that voltages up to 1099 V DC, depending on the supply voltage, may occur on the terminals.

F enclosure requirements

The brake resistor(s) must be connected to the brake terminals in each inverter module.

4.1.9 Brake Resistor Temperature Switch

Torque: 0.5-0.6 Nm (5 in-lbs)
Screw size: M3

This input can be used to monitor the temperature of an externally connected brake resistor. If the input between 104 and 106 is established, the frequency converter trips on warning/alarm 27, *Brake IGBT*. If the connection is closed between 104 and 105, the frequency converter trips on warning/alarm 27, *Brake IGBT*.

Install a KLIXON switch that is normally closed. If this function is not used, short circuit 106 and 104 together.

Normally closed: 104-106 (factory installed jumper)

Normally open: 104-105

Terminal No.	Function
106, 104, 105	Brake resistor temperature switch.

Table 4.9 Terminals for Brake Resistor Temperature Switch

NOTICE

If the temperature of the brake resistor gets too high and the thermal switch drops out, the frequency converter stops braking. The motor starts coasting.

4.1.10 Load Sharing

Terminal No.	Function
88, 89	Loadsharing

Table 4.10 Terminals for Load Sharing

The connection cable must be screened and the max. length from the frequency converter to the DC bar is limited to 25 m (82 ft).

Load sharing enables linking of the DC intermediate circuits of several frequency converters.

⚠ WARNING

Voltages up to 1099 V DC may occur on the terminals. Load Sharing calls for extra equipment and safety considerations. For further information, see the instructions *Load Sharing*.

⚠ WARNING

Mains disconnect may not isolate the frequency converter due to DC-link connection.

4.1.11 Shielding against Electrical Noise

Before mounting the mains power cable, mount the EMC metal cover to ensure best EMC performance.

NOTICE

The EMC metal cover is only included in units with an RFI filter.




Illustration 4.17 Mounting of EMC Shield.

4.1.12 Mains Connection

Mains must be connected to terminals 91, 92 and 93. Earth is connected to the terminal to the right of terminal 93.

Terminal No.	Function
91, 92, 93	Mains R/L1, S/L2, T/L3
94	Earth

Table 4.11 Mains Terminals Connection

CAUTION

Check the name plate to ensure that the mains voltage of the frequency converter matches the power supply of the plant.

Ensure that the power supply can supply the necessary current to the frequency converter.

If the unit is without built-in fuses, ensure that the appropriate fuses have the correct current rating.

4.1.13 External Fan Supply

In case the frequency converter is supplied by DC or if the fan must run independently of the power supply, an external power supply can be applied. The connection is made on the power card.

Terminal No.	Function
100, 101	Auxiliary supply S, T
102, 103	Internal supply S, T

Table 4.12 External Fan Supply Terminals

The connector located on the power card provides the connection of line voltage for the cooling fans. The fans are connected from factory to be supplied from a common AC line (jumpers between 100-102 and 101-103). If external supply is needed, the jumpers are removed and the supply is connected to terminals 100 and 101. Use a 5 A fuse for protection. In UL applications, use a Littelfuse KLK-5 or equivalent.

4.1.14 Fuses

It is recommended to use fuses and/or circuit breakers on the supply side as protection in case of component breakdown inside the frequency converter (first fault).

NOTICE

This is mandatory to ensure compliance with IEC 60364 for CE or NEC 2009 for UL.

WARNING

Personnel and property must be protected against the consequence of component break-down internally in the frequency converter.

Branch circuit protection

To protect the installation against electrical and fire hazard, all branch circuits in an installation, switch gear, machines etc., must be protected against short-circuit and overcurrent according to national/international regulations.

NOTICE

The recommendations given do not cover branch circuit protection for UL.

Short-circuit protection:

Danfoss recommends using the fuses/circuit breakers mentioned below to protect service personnel and property in case of component break-down in the frequency converter.

Non UL compliance

If UL/cUL is not to be complied with, use the following fuses to ensure compliance with EN50178:

P110 - P250	380 - 480 V	type gG
P315 - P450	380 - 480 V	type gR

Table 4.13 EN50178 Fuses

UL Compliance
380-480 V, Enclosure types D, E and F

The fuses below are suitable for use on a circuit capable of delivering 100,000 A_{rms} (symmetrical), 240 V, or 480 V, or 500 V, or 600 V depending on the frequency converter voltage rating. With the proper fusing, the frequency converter Short Circuit Current Rating (SCCR) is 100,000 A_{rms} .

Size/ Type	Bussmann E1958 JFHR2**	Bussmann E4273 T/JDDZ**	SIBA E180276 JFHR2	Littelfuse E71611 JFHR2**	Ferraz- Shawmut E60314 JFHR2**	Bussmann E4274 H/JDDZ**	Bussmann E125085 JFHR2*	Internal Option Bussmann
P110	FWH- 300	JJS- 300	2061032.315	L50S-300	A50-P300	NOS- 300	170M3017	170M3018
P132	FWH- 350	JJS- 350	2061032.35	L50S-350	A50-P350	NOS- 350	170M3018	170M3018
P160	FWH- 400	JJS- 400	2061032.40	L50S-400	A50-P400	NOS- 400	170M4012	170M4016
P200	FWH- 500	JJS- 500	2061032.50	L50S-500	A50-P500	NOS- 500	170M4014	170M4016
P250	FWH- 600	JJS- 600	2062032.63	L50S-600	A50-P600	NOS- 600	170M4016	170M4016

Table 4.14 Enclosure Types D, Line Fuses, 380-480 V

Size/ Type	Bussmann PN*	Rating	Ferraz	Siba
P315	170M4017	700 A, 700 V	6.9URD31D08A07 00	20 610 32.700
P355	170M6013	900 A, 700 V	6.9URD33D08A09 00	20 630 32.900
P400	170M6013	900 A, 700 V	6.9URD33D08A09 00	20 630 32.900
P450	170M6013	900 A, 700 V	6.9URD33D08A09 00	20 630 32.900

Table 4.15 Enclosure Types E, Line Fuses, 380-480 V

Size/ Type	Bussmann PN*	Rating	Siba	Internal Bussmann Option
P500	170M7081	1600 A, 700 V	20 695 32.1600	170M7082
P560	170M7081	1600 A, 700 V	20 695 32.1600	170M7082
P630	170M7082	2000 A, 700 V	20 695 32.2000	170M7082
P710	170M7082	2000 A, 700 V	20 695 32.2000	170M7082
P800	170M7083	2500 A, 700 V	20 695 32.2500	170M7083
P1M0	170M7083	2500 A, 700 V	20 695 32.2500	170M7083

Table 4.16 Enclosure Types F, Line Fuses, 380-480 V

Size/Type	Bussmann PN*	Rating	Siba
P500	170M8611	1100 A, 1000 V	20 781 32.1000
P560	170M8611	1100 A, 1000 V	20 781 32.1000
P630	170M6467	1400 A, 700 V	20 681 32.1400
P710	170M6467	1400 A, 700 V	20 681 32.1400
P800	170M8611	1100 A, 1000 V	20 781 32.1000
P1M0	170M6467	1400 A, 700 V	20 681 32.1400

Table 4.17 Enclosure Type F, Inverter Module DC Link Fuses, 380-480 V

*170M fuses from Bussmann shown use the -/80 visual indicator, - TN/80 Type T, -/110 or TN/110 Type T indicator fuses of the same size and amperage may be substituted for external use

**Any minimum 500 V UL listed fuse with associated current rating may be used to meet UL requirements.

525-690 V, Enclosure Types D, E and F

Size/ Type	Buss- mann E1250 85 JFHR2	[A]	SIBA E1802 76 JFHR2	Ferraz- Shawmut E76491 JFHR2	Internal Option Bussmann
P45K	170M 3013	125	20610 32.125	6.6URD30D08 A0125	170M3015
P55K	170M 3014	160	20610 32.16	6.6URD30D08 A0160	170M3015
P75K	170M 3015	200	20610 32.2	6.6URD30D08 A0200	170M3015
P90K	170M 3015	200	20610 32.2	6.6URD30D08 A0200	170M3015
P110	170M 3016	250	20610 32.25	6.6URD30D08 A0250	170M3018
P132	170M 3017	315	20610 32.315	6.6URD30D08 A0315	170M3018
P160	170M 3018	350	20610 32.35	6.6URD30D08 A0350	170M3018
P200	170M 4011	350	20610 32.35	6.6URD30D08 A0350	170M5011
P250	170M 4012	400	20610 32.4	6.6URD30D08 A0400	170M5011
P315	170M 4014	500	20610 32.5	6.6URD30D08 A0500	170M5011
P400	170M 5011	550	20620 32.55	6.6URD32D08 A550	170M5011

Table 4.18 Enclosure Types D, E and F 525-690 V

Size/ Type	Bussmann PN*	Rating	Ferraz	Siba
P450	170M4017	700 A, 700 V	6.9URD31 D08A070 0	20 610 32.700
P500	170M4017	700 A, 700 V	6.9URD31 D08A070 0	20 610 32.700
P560	170M6013	900 A, 700 V	6.9URD33 D08A090 0	20 630 32.900
P630	170M6013	900 A, 700 V	6.9URD33 D08A090 0	20 630 32.900

Table 4.19 Enclosure Type E, 525-690 V

Size/ Type	Bussmann PN*	Rating	Siba	Internal Bussmann Option
P710	170M7081	1600 A, 700 V	20 695 32.1600	170M7082
P800	170M7081	1600 A, 700 V	20 695 32.1600	170M7082
P900	170M7081	1600 A, 700 V	20 695 32.1600	170M7082
P1M0	170M7081	1600 A, 700 V	20 695 32.1600	170M7082
P1M2	170M7082	2000 A, 700 V	20 695 32.2000	170M7082
P1M4	170M7083	2500 A, 700 V	20 695 32.2500	170M7083

Table 4.20 Enclosure Type Size F, Line Fuses, 525-690 V

Size/Type	Bussmann PN*	Rating	Siba
P710	170M8611	1100 A, 1000 V	20 781 32. 1000
P800	170M8611	1100 A, 1000 V	20 781 32. 1000
P900	170M8611	1100 A, 1000 V	20 781 32. 1000
P1M0	170M8611	1100 A, 1000 V	20 781 32. 1000
P1M2	170M8611	1100 A, 1000 V	20 781 32. 1000
P1M4	170M8611	1100 A, 1000 V	20 781 32.1000

Table 4.21 Enclosure Type F, Inverter Module DC Link Fuses, 525-690 V

*170M fuses from Bussmann shown use the -/80 visual indicator, - TN/80 Type T, -/110 or TN/110 Type T indicator fuses of the same size and amperage may be substituted for external use.

Suitable for use on a circuit capable of delivering not more than 100 000 rms symmetrical A, 500/600/690 V maximum when protected by the above fuses.

Supplementary fuses

Enclosure Type	Bussmann PN*	Rating
D, E and F	KTK-4	4 A, 600 V

Table 4.22 SMPS Fuse

Size/Type	Bussmann PN*	Littelfuse	Rating
P110-P315, 380-480 V	KTK-4		4 A, 600 V
P45K-P500, 525-690 V	KTK-4		4 A, 600 V
P355-P1M0, 380-480 V		KLK-15	15A, 600 V
P560-P1M4, 525-690 V		KLK-15	15A, 600 V

Table 4.23 Fan Fuses

Size/Type	[A]	Bussmann PN*	Rating [V]	Alternative Fuses
P500-P1M0, 380-480 V	2.5-4.0	LPJ-6 SP or SPI	6 A, 600	Any listed Class J Dual Element, Time Delay, 6A
P710-P1M4, 525-690 V		LPJ-10 SP or SPI	10 A, 600	Any listed Class J Dual Element, Time Delay, 10 A
P500-P1M0, 380-480 V	4.0-6.3	LPJ-10 SP or SPI	10 A, 600	Any listed Class J Dual Element, Time Delay, 10 A
P710-P1M4, 525-690 V		LPJ-15 SP or SPI	15 A, 600	Any listed Class J Dual Element, Time Delay, 15 A
P500-P1M0, 380-480 V	6.3 - 10	LPJ-15 SP or SPI	15 A, 600	Any listed Class J Dual Element, Time Delay, 15 A
P710-P1M4, 525-690 V		LPJ-20 SP or SPI	20 A, 600	Any listed Class J Dual Element, Time Delay, 20A
P500-P1M0, 380-480 V	10 - 16	LPJ-25 SP or SPI	25 A, 600	Any listed Class J Dual Element, Time Delay, 25 A
P710-P1M4, 525-690 V		LPJ-20 SP or SPI	20 A, 600	Any listed Class J Dual Element, Time Delay, 20 A

Table 4.24 Manual Motor Controller Fuses

Enclosure Type	Bussmann PN*	Rating	Alternative Fuses
F	LPJ-30 SP or SPI	30 A, 600 V	Any listed Class J Dual Element, Time Delay, 30 A

Table 4.25 30 A Fuse Protected Terminal Fuse

Enclosure Type	Bussmann PN*	Rating	Alternative Fuses
F	LPJ-6 SP or SPI	6 A, 600 V	Any listed Class J Dual Element, Time Delay, 6 A

Table 4.26 Control Transformer Fuse

Enclosure Type	Bussmann PN*	Rating
F	GMC-800MA	800 mA, 250 V

Table 4.27 NAMUR Fuse

Enclosure Type	Bussmann PN*	Rating	Alternative Fuses
F	LP-CC-6	6 A, 600 V	Any listed Class CC, 6 A

Table 4.28 Safety Relay Coil Fuse with PILS Relay

4.1.15 Mains Disconnectors

Enclosure Type	Power & Voltage	Type
D1/D3	P110-P132 380-480 V & P110-P160 525-690 V	ABB OETL-NF200A or OT200U12-91
D2/D4	P160-P250 380-480 V & P200-P400 525-690 V	ABB OETL-NF400A or OT400U12-91
E1/E2	P315 380-480 V & P450-P630 525-690 V	ABB OT600U03
E1/E2	P355-P450 380-480 V	ABB OT800U03
F3	P500 380-480 V & P710-P800 525-690 V	Merlin Gerin NPJF36000S12AAYP
F3	P560-P710 380-480 V & P900 525-690 V	Merlin Gerin NRK36000S20AAYP
F4	P800-P1M0 380-480 V & P1M0-P1M4 525-690 V	Merlin Gerin NRK36000S20AAYP

Table 4.29

4.1.16 F Enclosure Circuit Breakers

Enclosure Type	Power & Voltage	Type
F3	P500 380-480 V & P710-P800 525-690 V	Merlin Gerin NPJF36120U31AABSCYP
F3	P560-P710 380-480 V & P900 525-690 V	Merlin Gerin NRJF36200U31AABSCYP
F4	P800 380-480 V & P1M0-P1M4 525-690 V	Merlin Gerin NRJF36200U31AABSCYP
F4	P1M0 380-480 V	Merlin Gerin NRJF36250U31AABSCYP

Table 4.30

4.1.17 F Enclosure Mains Contactors

Enclosure Type	Power & Voltage	Type
F3	P500-P560 380-480 V & P710-P900 525-690 V	Eaton XTCE650N22A
F3	P 630-P710 380-480 V	Eaton XTCEC14P22B
F4	P800-P1M0 380-480 V & P1M0-P1M4 525-690 V	Eaton XTCEC14P22B

Table 4.31

4.1.18 Motor Insulation

For motor cable lengths \leq the maximum cable length listed in *chapter 7 General Specifications*, the recommended motor insulation ratings are in *Table 4.32*. The peak voltage can be up to twice the DC link voltage, 2.8 times the mains voltage, due to transmission line effects in the motor cable. If a motor has a lower insulation rating, use a dU/dt or sine wave filter.

Nominal Mains Voltage	Motor Insulation
$U_N \leq 420$ V	Standard $U_{LL} = 1300$ V
420 V < $U_N \leq 500$ V	Reinforced $U_{LL} = 1600$ V
500 V < $U_N \leq 600$ V	Reinforced $U_{LL} = 1800$ V
600 V < $U_N \leq 690$ V	Reinforced $U_{LL} = 2000$ V

Table 4.32 Motor Insulation at Various Nominal Mains Voltages

4.1.19 Motor Bearing Currents

For motors with a rating 110 kW or higher operating via frequency converters use NDE (Non-Drive End) insulated bearings to eliminate circulating bearing currents due to the physical size of the motor. To minimise DE (Drive End) bearing and shaft currents, proper grounding of the frequency converter, motor, driven machine, and motor to the driven machine is required. Although failure due to bearing currents is rare, if it occurs, use the following mitigation strategies.

Standard mitigation strategies

- Use an insulated bearing
- Apply rigorous installation procedures
 - Ensure the motor and load motor are aligned
 - Strictly follow the EMC Installation guideline
 - Reinforce the PE so the high frequency impedance is lower in the PE than the input power leads

- Provide a good high frequency connection between the motor and the frequency converter by screened cable, which has a 360° connection in the motor and frequency converter
- Ensure that the impedance from frequency converter to building ground is lower than the grounding impedance of the machine. Make a direct earth connection between the motor and load motor

- Apply conductive lubrication
- Try to ensure that the line voltage is balanced to ground. This can be difficult for IT, TT, TN-CS or Grounded leg systems
- Use an insulated bearing as recommended by the motor manufacturer

NOTICE

Motors from reputable manufacturers typically have these fitted as standard in motors of this size.

If none of these strategies works, consult the factory. If necessary after consulting Danfoss:

- Lower the IGBT switching frequency
- Modify the inverter waveform, 60° AVM vs. SFAVM
- Install a shaft grounding system or use an isolating coupling between motor and load
- Use minimum speed settings if possible
- Use a dU/dt or sinus filter

4.1.20 Control Cable Routing

Tie down all control wires to the designated control cable routing as shown in the picture. Remember to connect the shields in a proper way to ensure optimum electrical immunity.

Fieldbus connection

Connections are made to the relevant options on the control card. For details, see the relevant fieldbus instruction. The cable must be placed in the provided path inside the frequency converter and tied down with other control wires (see illustrations).

4




Illustration 4.18 Control Card Wiring Path for the D3. Control Card Wiring for the D1, D2, D4, E1 and E2 use the same Path




Illustration 4.20 Top Connection for Fieldbus.




Illustration 4.21




Illustration 4.19 Control Card Wiring Path for the F1/F3. Control Card Wiring for the F2/F4 use the same Path




Illustration 4.22

In the Chassis (IP00) and NEMA 1 units, it is also possible to connect the fieldbus from the top of the unit as shown in the following pictures. On the NEMA 1 unit a cover plate must be removed.

Kit number for fieldbus top connection: 176F1742

Installation of 24 V external DC Supply

Torque: 0.5 - 0.6 Nm (5 in-lbs)

Screw size: M3

No.	Function
35 (-), 36 (+)	24 V external DC supply

Table 4.33 Terminals for 24 V External DC Supply

24 V DC external supply can be used as low-voltage supply to the control card and any option cards installed. This enables full operation of the LCP (including parameter setting) without connection to mains. Note that a warning of low voltage is given when 24 V DC has been connected; however, there is no tripping.

⚠ WARNING

Use 24 V DC supply of type PELV to ensure correct galvanic isolation (type PELV) on the control terminals of the frequency converter.

4.1.21 Access to Control Terminals

All terminals to the control cables are located beneath the LCP. They are accessed by opening the door of the IP21/ IP54 version or removing the covers of the IP00 version.

4.1.22 Electrical Installation, Control Terminals

To connect the cable to the terminal

1. Strip insulation by about 9-10 mm




Illustration 4.23 Stripping of Insulation

2. Insert a screwdriver¹⁾ in the square hole.
3. Insert the cable in the adjacent circular hole.




Illustration 4.24

4. Remove the screwdriver. The cable is now mounted in the terminal.

To remove the cable from the terminal

1. Insert a screw driver¹⁾ in the square hole.
2. Pull out the cable.




Illustration 4.25

¹⁾ Max. 0.4 x 2.5 mm




Illustration 4.26

4.1.23 Electrical Installation, Control Cables

4




Illustration 4.27

A=Analog, D=Digital

*Terminal 37 (optional) is used for Safe Torque Off. For Safe Torque Off installation instructions, refer to the *Safe Torque Off Operating Instructions for Danfoss VLT® Frequency Converters*.

**Do not connect cable screen.




Illustration 4.28 Diagram Showing all Electrical Terminals with NAMUR Option shown in Dotted Line Box

4

Very long control cables and analog signals may in rare cases and depending on installation result in 50/60 Hz ground loops due to noise from mains supply cables.

If this occurs, it may be necessary to break the screen or insert a 100 nF capacitor between screen and chassis.

Connect the digital and analog inputs and outputs separately to the frequency converter common inputs (terminal 20, 55, 39) to avoid ground currents from both groups to affect other groups. For example, switching on the digital input may disturb the analog input signal.

Input polarity of control terminals




Illustration 4.29




Illustration 4.30

NOTICE

Control cables must be screened/armoured.




Illustration 4.31

Connect the wires as described in the product related *Operating Instructions*. Remember to connect the shields in a proper way to ensure optimum electrical immunity.

4.1.24 Switches S201, S202, and S801

Switches S201 (A53) and S202 (A54) are used to select a current (0-20 mA) or a voltage (-10 to +10 V) configuration of the analog input terminals 53 and 54.

Switch S801 (BUS TER.) can be used to enable termination on the RS-485 port (terminals 68 and 69).

See *Illustration 4.27*.

Default setting:

- S201 (A53) = OFF (voltage input)
- S202 (A54) = OFF (voltage input)
- S801 (Bus termination) = OFF

NOTICE

When changing the function of S201, S202 or S801 be careful not to use force for the switch over. It is recommended to remove the LCP fixture (cradle) when operating the switches. The switches must not be operated with power on the frequency converter.





Illustration 4.32



130BA156.12





Illustration 4.34

4.2 Connection Examples

4.2.1 Start/Stop

Terminal 18 = 5-10 Terminal 18 Digital Input [8] Start
 Terminal 27 = 5-12 Terminal 27 Digital Input [0] No operation (Default coast inverse)
 Terminal 37 = Safe Torque Off



130BA155.12




Illustration 4.33

4.2.2 Pulse Start/Stop

Terminal 18 = 5-10 Terminal 18 Digital Input [9] Latched start
 Terminal 27 = 5-12 Terminal 27 Digital Input [6] Stop inverse
 Terminal 37 = Safe Torque Off

4.2.3 Speed Up/Down

Terminals 29/32 = Speed up/down

Terminal 18 = 5-10 Terminal 18 Digital Input [9] Start (default)


Terminal 27 = 5-12 Terminal 27 Digital Input [19] Freeze reference

Terminal 29 = 5-13 Terminal 29 Digital Input [21] Speed up

Terminal 32 = 5-14 Terminal 32 Digital Input [22] Speed down

NOTICE

Terminal 29 only in FC x02 (x=series type).



130BA021.12

Illustration 4.35 Speed Up/Down

4.2.4 Potentiometer Reference

Voltage reference via a potentiometer

Reference Source 1 = [1] Analog input 53 (default)

Terminal 53, Low Voltage = 0 V

Terminal 53, High Voltage = 10 V

Terminal 53, Low Ref./Feedback = 0 RPM

Terminal 53, High Ref./Feedback = 1500 RPM

Switch S201 = OFF (U)




Illustration 4.36 Potentiometer Reference


4.3 Final Set-up and Test

To test the set-up and ensure that the frequency converter is running, follow these steps.

Step 1. Locate the motor name plate

NOTICE

The motor is either star- (Y) or delta- connected (Δ). This information is located on the motor name plate data.



130BA767.10

THREE PHASE INDUCTION MOTOR				
MOD MCV 315E	Nr.	135189 12 04	IL/IN 6.5	
kW 400	PRIMARY			SF 1.15
HP 536	V 690	A 410.6	CONN Y	COS φ 0.85 40
mm 1481	V	A	CONN	AMB 40 °C
Hz 50	V	A	CONN	ALT 1000 m
DESIGNN	SECONDARY			RISE 80 °C
DUTY S1	V	A	CONN	ENCLOSURE IP23
INSUL I	EFFICIENCY %	95.8%	100%	95.8%
			75%	WEIGHT 1.83 ton
⚠ CAUTION				

Illustration 4.37

Step 2. Enter the motor name plate data in this parameter list.

To access this list first press [Quick Menu] then select "Q2 Quick Setup".

1.	1-20 Motor Power [kW] 1-21 Motor Power [HP]
2.	1-22 Motor Voltage
3.	1-23 Motor Frequency
4.	1-24 Motor Current
5.	1-25 Motor Nominal Speed

Table 4.34

Step 3. Activate the Automatic Motor Adaptation (AMA)

Performing an AMA ensures optimum performance. The AMA measures the values from the motor model equivalent diagram.

1. Connect terminal 37 to terminal 12 (if terminal 37 is available).
2. Connect terminal 27 to terminal 12 or set 5-12 Terminal 27 Digital Input to [0] No function.
3. Activate the AMA 1-29 Automatic Motor Adaptation (AMA).
4. Select between complete or reduced AMA. If a Sine-wave filter is mounted, run only the reduced AMA, or remove the Sine-wave filter during the AMA procedure.

5. Press [OK]. The display shows *Press [Hand On] to start*.
6. Press [Hand On]. A progress bar indicates if the AMA is in progress.

Stop the AMA during operation

1. Press [Off] - the frequency converter enters into alarm mode and the display shows that the AMA was terminated by the user.

Successful AMA

1. The display shows *Press [OK] to finish AMA*.
2. Press [OK] to exit the AMA state.

Unsuccessful AMA

1. The frequency converter enters into alarm mode. A description of the alarm can be found in *chapter 8 Troubleshooting*.
2. "Report Value" in the [Alarm Log] shows the last measuring sequence carried out by the AMA, before the frequency converter entered alarm mode. This number along with the description of the alarm assists in troubleshooting. If contacting Danfoss for service, make sure to mention number and alarm description.

NOTICE

Unsuccessful AMA is often caused by incorrectly registered motor name plate data or a too big difference between the motor power size and the frequency converter power size.

Step 4. Set speed limit and ramp time

3-02 Minimum Reference

3-03 Maximum Reference

Set up the desired limits for speed and ramp time

4-11 Motor Speed Low Limit [RPM] or 4-12 Motor Speed Low Limit [Hz]

4-13 Motor Speed High Limit [RPM] or 4-14 Motor Speed High Limit [Hz]

3-41 Ramp 1 Ramp Up Time

3-42 Ramp 1 Ramp Down Time

4.4 Additional Connections

4.4.1 Mechanical Brake Control

In hoisting/lowering applications, it is necessary to be able to control an electro-mechanical brake:

- Control the brake using any relay output or digital output (terminal 27 or 29).
- Keep the output closed (voltage-free) as long as the frequency converter is unable to support the motor, for example due to the load being too heavy.

- Select *[32] Mechanical brake control* in parameter group *5-4* Relays* for applications with an electro-mechanical brake.
- The brake is released when the motor current exceeds the preset value in *2-20 Release Brake Current*.
- The brake is engaged when the output frequency is less than the frequency set in *2-21 Activate Brake Speed [RPM]* or *2-22 Activate Brake Speed [Hz]*, and only if the frequency converter carries out a stop command.

If the frequency converter is in alarm mode or in an over-voltage situation, the mechanical brake immediately cuts in.

4.4.2 Parallel Connection of Motors

The frequency converter can control several parallel-connected motors. The total current consumption of the motors must not exceed the rated output current $I_{M,N}$ for the frequency converter.

NOTICE

Installations with cables connected in a common joint as in *Illustration 4.38*, is only recommended for short cable lengths.

NOTICE

When motors are connected in parallel, 1-29 *Automatic Motor Adaptation (AMA)* cannot be used.

NOTICE

The electronic thermal relay (ETR) of the frequency converter cannot be used as motor protection for the individual motor in systems with parallel-connected motors. Provide further motor protection by e.g. thermistors in each motor or individual thermal relays (circuit breakers are not suitable as protection).

4.4.3 Motor Thermal Protection

The electronic thermal relay in the frequency converter has received UL-approval for single motor protection, when 1-90 *Motor Thermal Protection* is set for *ETR Trip* and 1-24 *Motor Current* is set to the rated motor current (see motor name plate).

For thermal motor protection it is also possible to use the MCB 112 PTC Thermistor Card option. This card provides ATEX certificate to protect motors in explosion hazardous areas, Zone 1/21 and Zone 2/22. When 1-90 *Motor Thermal Protection* is set to [20] *ATEX ETR* is combined with the use of MCB 112, it is possible to control an Ex-e motor in explosion hazardous areas. Consult the programming guide for details on how to set up the frequency converter for safe operation of Ex-e motors.




Illustration 4.38

Problems may arise at start and at low RPM values if motor sizes are widely different because small motors' relatively high ohmic resistance in the stator calls for a higher voltage at start and at low RPM values.

5 How to Operate the Frequency Converter

5.1 Operating with LCP

5.1.1 3 Ways of Operating

The frequency converter can be operated in 3 ways:

1. Graphical Local Control Panel (GLCP)
2. Numeric Local Control Panel (NLCP)
3. RS-485 serial communication or USB, both for PC connection

If the frequency converter is fitted with fieldbus option, refer to relevant documentation.

5.1.2 How to Operate Graphical LCP (GLCP)

The following instructions are valid for the GLCP (LCP 102).

The GLCP is divided into four functional groups

1. Graphical display with Status lines.
2. Menu keys and indicator lights (LEDs) - selecting mode, changing parameters and switching between display functions.
3. Navigation keys and indicator lights (LEDs).
4. Operation keys and indicator lights (LEDs).

Graphical display

The LCD-display is back-lit with a total of 6 alpha-numeric lines. All data is displayed on the LCP which can show up to 5 operating variables while in [Status] mode.

Display lines

- a. **Status line** Status messages displaying icons and graphics.
- b. **Line 1-2** Operator data lines displaying data and variables defined or selected by the user. By pressing the [Status] key, up to one extra line can be added.
- c. **Status line** Status messages displaying text.




Illustration 5.1 Keypad

The display is divided into 3 sections

Top section

(a) shows the status when in status mode or up to 2 variables when not in status mode and in the case of Alarm/Warning.

The number of the Active Set-up (selected as the Active Set-up in 0-10 Active Set-up) is shown. When programming in another Set-up than the Active Set-up, the number of the Set-up being programmed appears to the right in brackets.

Middle section

(b) shows up to 5 variables with related unit, regardless of status. In case of alarm/warning, the warning is shown instead of the variables.

Bottom section

(c) always shows the state of the frequency converter in Status mode.

5

It is possible to toggle between 3 status read-out displays by pressing the [Status] key. Operating variables with different formatting are shown in each status screen - see below.

Several values or measurements can be linked to each of the displayed operating variables. The values/measurements to be displayed can be defined via 0-20 Display Line 1.1 Small, 0-21 Display Line 1.2 Small, 0-22 Display Line 1.3 Small, 0-23 Display Line 2 Large and 0-24 Display Line 3 Large, which can be accessed via [QUICK MENU], Q3 Function Setups, Q3-1 General Settings, Q3-13 Display Settings.

Each value/measurement readout parameter selected in 0-20 Display Line 1.1 Small to 0-24 Display Line 3 Large has its own scale and number of digits after a possible decimal point. Larger numeric values are displayed with few digits after the decimal point.

Ex.: Current readout
5.25 A; 15.2 A 105 A.

Status display I

This read-out state is standard after start-up or initialisation.

Use [INFO] to obtain information about the value/measurement linked to the displayed operating variables (1.1, 1.2, 1.3, 2, and 3).

See the operating variables shown in the display in this illustration. 1.1, 1.2 and 1.3 are shown in small size. 2 and 3 are shown in medium size.




Illustration 5.2

Status display II

See the operating variables (1.1, 1.2, 1.3, and 2) shown in the display in this illustration.

In the example, Speed, Motor current, Motor power and Frequency are selected as variables in the first and second lines.

1.1, 1.2 and 1.3 are shown in small size. 2 is shown in large size.




Illustration 5.3

Status display III

This state displays the event and action of the Smart Logic Control.




Illustration 5.4

Display Contrast Adjustment

Press [status] and [▲] for darker display
Press [status] and [▼] for brighter display




Illustration 5.5

Indicator lights (LEDs)

If certain threshold values are exceeded, the alarm and/or warning LED lights up. A status and alarm text appear on the control panel.

The On LED is activated when the frequency converter receives power from mains voltage, a DC bus terminal, or an external 24 V supply. At the same time, the back light is on.

- Green LED/On: Control section is working.
- Yellow LED/Warn.: Indicates a warning.
- Flashing Red LED/Alarm: Indicates an alarm.




Illustration 5.6

GLCP keys

Menu keys

The menu keys are divided into functions. The keys below the display and indicator lights are used for parameter set-up, including choice of display indication during normal operation.



Illustration 5.7 Menu Keys

130BP045.1.0

[Status]

indicates the status of the frequency converter and/or the motor. 3 different readouts can be selected by pressing the [Status] key:

5 line readouts, 4 line readouts or Smart Logic Control. Use [Status] for selecting the mode of display or for changing back to Display mode from either the Quick Menu mode, the Main Menu mode or Alarm mode. Also use the [Status] key to toggle single or double read-out mode.

[Quick Menu]

allows quick set-up of the frequency converter. The most common HVAC functions can be programmed here.

The [Quick Menu] consists of

- My Personal Menu
- Quick Set-up
- Function Set-up
- Changes Made
- Loggings

The Function Set-up provides quick and easy access to all parameters required for most HVAC applications including most VAV and CAV supply and return fans, cooling tower fans, primary, secondary and condenser water pumps and other pump, fan and compressor applications. Amongst other features it also includes parameters for selecting which variables to display on the LCP, digital preset speeds, scaling of analog references, closed loop single zone and multi-zone applications and specific functions related to fans, pumps and compressors.

The Quick Menu parameters can be accessed immediately unless a password has been created via *0-60 Main Menu Password*, *0-61 Access to Main Menu w/o Password*, *0-65 Personal Menu Password* or *0-66 Access to Personal Menu w/o Password*.

It is possible to switch directly between Quick Menu mode and Main Menu mode.

[Main Menu]

is used for programming all parameters. The Main Menu parameters can be accessed immediately unless a password has been created via *0-60 Main Menu Password*, *0-61 Access to Main Menu w/o Password*, *0-65 Personal Menu Password* or *0-66 Access to Personal Menu w/o Password*. For most HVAC applications it is not necessary to access the Main Menu parameters but instead the Quick Menu, Quick Set-up and Function Set-up provides the simplest and quickest access to the typical required parameters.

It is possible to switch directly between Main Menu mode and Quick Menu mode.

Parameter shortcut can be carried out by pressing down the [Main Menu] key for 3 seconds. The parameter shortcut allows direct access to any parameter.

[Alarm Log]

displays an Alarm list of the 10 latest alarms (numbered A1-A10). To obtain additional details about an alarm, press the navigation keys to manoeuvre to the alarm number and press [OK]. Information is displayed about the condition of the frequency converter before it enters the alarm mode.

The Alarm log key on the LCP allows access to both Alarm log and Maintenance log.

[Back]

reverts to the previous step or layer in the navigation structure.



Illustration 5.8

[Cancel]

Cancels the last change or command as long as the display has not been changed.



Illustration 5.9

[Info]

displays information about a command, parameter, or function in any display window. [Info] provides detailed information when needed.

Exit Info mode by pressing either [Info], [Back], or [Cancel].



Illustration 5.10

Navigation Keys

The 4 navigation keys are used to navigate between the different choices available in [Quick Menu], [Main Menu] and [Alarm Log]. Press the keys to move the cursor.

[OK]

is used for selecting a parameter marked by the cursor and for enabling the change of a parameter.




Illustration 5.11

Operation Keys

for local control are found at the bottom of the control panel.




Illustration 5.12 Operation Keys

[Hand On]

enables control of the frequency converter via the GLCP. [Hand On] also starts the motor, and it is now possible to enter the motor speed data by means of the navigation keys. The key can be selected as [1] Enable or [0] Disable via 0-40 [Hand on] Key on LCP.

The following control signals are still active when [Hand On] is activated:

- [Hand On] - [Off] - [Auto On]
- Reset
- Coasting stop inverse
- Reversing
- Set-up select lsb - Set-up select msb
- Stop command from serial communication
- Quick stop
- DC brake

NOTICE

External stop signals activated by means of control signals or a serial bus overrides a start command via the LCP.

[Off]

stops the connected motor. The key can be selected as [1] Enabled or [0] Disabled via 0-41 [Off] Key on LCP. If no external stop function is selected and the [Off] key is

inactive the motor can only be stopped by disconnecting the mains supply.

[Auto On]

enables the frequency converter to be controlled via the control terminals and/or serial communication. When a start signal is applied on the control terminals and/or the bus, the frequency converter starts. The key can be selected as [1] Enabled or [0] Disabled via 0-42 [Auto on] Key on LCP.

NOTICE

An active HAND-OFF-AUTO signal via the digital inputs has higher priority than the control keys [Hand On] – [Auto On].

[Reset]

is used for resetting the frequency converter after an alarm (trip). It can be selected as [1] Enable or [0] Disable via 0-43 [Reset] Key on LCP.

The parameter shortcut can be carried out by holding down the [Main Menu] key for 3 seconds. The parameter shortcut allows direct access to any parameter.

5.2 Operating via Serial Communication

5.2.1 RS-485 Bus Connection

One or more frequency converters can be connected to a controller (or master) using the RS-485 standard interface. Terminal 68 is connected to the P signal (TX+, RX+), while terminal 69 is connected to the N signal (TX-,RX-).

If more than one frequency converter is connected to a master, use parallel connections.




Illustration 5.13 Connection Example.

To avoid potential equalizing currents in the screen, ground the cable screen via terminal 61, which is connected to the frame via an RC-link.

Bus termination

The RS-485 bus must be terminated by a resistor network at both ends. If the frequency converter is the first or the last device in the RS-485 loop, set the switch S801 on the control card for ON.

For more information, see the paragraph Switches S201, S202, and S801.

5.3 Operating via PC

5.3.1 How to Connect a PC to the Frequency Converter

To control or program the frequency converter from a PC, install the PC-based configuration tool MCT 10 Set-up Software.

The PC is connected via a standard (host/device) USB cable, or via the RS-485 interface as shown in *chapter 5.2.1 RS-485 Bus Connection*.

NOTICE

The USB connection is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals. The USB connection is connected to protection earth. Use only an isolated laptop as PC connection to the USB connector on the frequency converter.




Illustration 5.14 USB Connection to Frequency Converter

5.3.2 PC Software Tools

PC-based MCT 10 Set-up Software

All Frequency converters are equipped with a serial communication port. Danfoss provides a PC tool for communication between PC and frequency converter, PC-based Configuration Tool MCT 10. Check the section on *Available Literature* for detailed information on this tool.

MCT 10 set-up software

MCT 10 has been designed as an easy to use interactive tool for setting parameters in our frequency converters. The MCT 10 Set-up Software is useful for:

- Planning a communication network off-line. MCT 10 Set-up Software contains a complete frequency converter database.
- Commissioning frequency converters on line.
- Saving settings for all frequency converters.
- Replacing a frequency converter in a network.
- Simple and accurate documentation of frequency converter settings after commissioning.
- Expanding an existing network.
- Future developed frequency converters are supported.

MCT 10 Set-up Software supports Profibus DP-V1 via a Master class 2 connection. It makes it possible to on line read/write parameters in a frequency converter via the Profibus network. This eliminates the need for an extra communication network.

Save frequency converter settings:

1. Connect a PC to the unit via USB com port. (NOTE: Use a PC, which is isolated from the mains, in conjunction with the USB port. Failure to do so may damage equipment.)
2. Open MCT 10 Set-up Software.
3. Select *Read from drive*.
4. Select *Save as*.

All parameters are now stored in the PC.

Load frequency converter settings:

1. Connect a PC to the frequency converter via USB com port.
2. Open MCT 10 Set-up Software.
3. Select *Open* – stored files are shown.
4. Open the appropriate file.
5. Select *Write to drive*.

All parameter settings are now transferred to the frequency converter.

A separate manual for MCT 10 Set-up Software is available from www.Danfoss.com/BusinessAreas/DrivesSolutions/SoftwareDownload/DDPC+Software+Program.htm.

The MCT 10 Set-up software modules

The following modules are included in the software package.

	MCT Set-up 10 Software Setting parameters Copy to and from frequency converters Documentation and print out of parameter settings incl. diagrams
	Ext. user interface Preventive Maintenance Schedule Clock settings Timed Action Programming Smart Logic Controller Set-up

Table 5.1

Ordering number:

Order the CD containing MCT 10 Set-up Software using code number 130B1000.

The software can be downloaded from the Danfoss internet site www.Danfoss.com/BusinessAreas/DrivesSolutions/Softwaredownload/DDPC+Software+Program.htm

5.3.3 Tips and Tricks

- For most HVAC applications the Quick Menu, Quick Set-up and Function Set-up provides the simplest and quickest access to all the typical parameters required
- Whenever possible, performing an AMA, ensures best shaft performance
- Contrast of the display can be adjusted by pressing [Status] and [▲] for darker display or by pressing [Status] and [▼] for brighter display
- Under [Quick Menu] and [Changes Made] all parameters that have been changed from factory settings are displayed
- Press and hold [Main Menu] key for 3 seconds for access to any parameter
- For service purposes it is recommended to copy all parameters to the LCP, see *0-50 LCP Copy* for further information

5.3.4 Quick Transfer of Parameter Settings when Using GLCP

Once the set-up of a frequency converter is complete, it is recommended to store (back up) the parameter settings in the GLCP or on a PC via MCT 10 Set-up Software Tool.

⚠ WARNING

Stop the motor before performing any of these operations.

Data storage in LCP

1. Go to *0-50 LCP Copy*.
2. Press [OK].
3. Select [1] *All to LCP*.
4. Press [OK].

All parameter settings are now stored in the GLCP indicated by the progress bar. When 100% is reached, press [OK].

The GLCP can now be connected to another frequency converter and the parameter settings copied to this frequency converter.

Data transfer from LCP to Frequency converter

1. Go to *0-50 LCP Copy*.
2. Press [OK].
3. Select [2] *All from LCP*.
4. Press [OK]

The parameter settings stored in the GLCP are now transferred to the frequency converter indicated by the progress bar. When 100% is reached, press [OK].

5.3.5 Initialisation to Default Settings

There are 2 ways to initialise the frequency converter to default: Recommended initialisation and manual initialisation.

Be aware that they have different impact according to the below description.

Recommended initialisation (via 14-22 Operation Mode)

1. Select *14-22 Operation Mode*.
2. Press [OK].
3. Select [2] *Initialisation* (for NLCP select "2").
4. Press [OK].
5. Remove power to unit and wait for display to turn off.
6. Reconnect power and the frequency converter is reset. Note that first start-up takes a few more seconds.
7. Press [Reset]

14-22 Operation Mode initialises all except:

14-50 RFI Filter

8-30 Protocol

8-31 Address

8-32 Baud Rate

8-35 Minimum Response Delay

8-36 Max Response Delay

8-37 Maximum Inter-Char Delay

15-00 Operating hours to 15-05 Over Volt's

15-20 Historic Log: Event to 15-22 Historic Log: Time
15-30 Alarm Log: Error Code to 15-32 Alarm Log: Time

NOTICE

Parameters selected in 0-25 My Personal Menu stay present with default factory setting.

Manual initialisation**NOTICE**

When carrying out manual initialisation, serial communication, RFI filter settings and fault log settings are reset. Removes parameters selected in 0-25 My Personal Menu.

1. Disconnect from mains and wait until the display turns off.
2. Press
 - 2a [Status] - [Main Menu] - [OK] at the same time while power up for Graphical LCP (GLCP).
 - 2b [Menu] while power up for LCP 101, Numerical Display.
3. Release the keys after 5 s.
4. The frequency converter is now programmed according to default settings.

This parameter initialises all except:

15-00 Operating hours
15-03 Power Up's
15-04 Over Temp's
15-05 Over Volt's

6 How to Programme

6.1 Basic Programming

6.1.1 Parameter Set-Up

6

Group	Title	Function
0**	Operation and Display	Parameters used to program the fundamental functions of the frequency converter and the LCP including: <ul style="list-style-type: none"> • Selection of language • Selection of which variables are displayed at each position in the display (e.g. static duct pressure or condenser water return temperature can be displayed with the setpoint in small digits in the top row and feedback in large digits in the centre of the display) • Enabling/disabling of the LCP keys • Passwords for the LCP • Upload and download of commissioned parameters to/from the LCP • Setting the built-in clock
1**	Load/Motor	Parameters used to configure the frequency converter for the specific application and motor including: <ul style="list-style-type: none"> • Open or closed loop operation • Type of application such as compressor, fan or centrifugal pump • Motor nameplate data • Auto-tuning of the frequency converter to the motor for optimum performance • Flying start (typically used for fan applications) • Motor thermal protection
2**	Brakes	Parameters used to configure braking functions of the frequency converter which although not common in many HVAC applications, can be useful on special fan applications. Parameters including: <ul style="list-style-type: none"> • DC braking • Dynamic/resistor braking • Over voltage control (which provides automatic adjustment of the deceleration rate (auto-ramping) to avoid tripping when decelerating large inertia fans)
3**	Reference/Ramps	Parameters used to program the <ul style="list-style-type: none"> • minimum and maximum reference limits of speed (RPM/Hz) in open loop or in actual units when operating in closed loop) • digital/preset references • jog speed • definition of the source of each reference (e.g. which analog input the reference signal is connected to) • ramp up and down times • digital potentiometer settings

Group	Title	Function
4**	Limits/Warnings	<p>Parameters used to program limits and warnings of operation including:</p> <ul style="list-style-type: none"> • Allowable motor direction • Minimum and maximum motor speeds (e.g. in pump applications it is typical to program a minimum speed to approx 30-40% to ensure pump seals are adequately lubricated at all times, avoid cavitation and ensure adequate head is produced at all times to create flow) • Torque and current limits to protect the pump, fan or compressor driven by the motor • Warnings for low/high current, speed, reference, and feedback • Missing motor phase protection • Speed bypass frequencies including semi-automatic setup of these frequencies (e.g. to avoid resonance conditions on cooling tower and other fans)
5**	Digital In/Out	<p>Parameters used to program the functions of all</p> <ul style="list-style-type: none"> • digital inputs • digital outputs • relay outputs • pulse inputs • pulse outputs <p>for terminals on the control card and all option cards.</p>
6**	Analog In/Out	<p>Parameters used to program the functions associated with all analog inputs and analog outputs for the terminals on the control card and General Purpose I/O option (MCB 101) including:</p> <ul style="list-style-type: none"> • Analog input live zero timeout function (which for example can be used to command a cooling tower fan to operate at full speed if the condenser water return sensor fails) • Scaling of the analog input signals (for example to match the analog input to the mA and pressure range of a static duct pressure sensor) • Filter time constant to filter out electrical noise on the analog signal which can sometimes occur when long cables are installed • Function and scaling of the analog outputs (for example to provide an analog output representing motor current or kW to an analog input of a DDC controller) and to configure the analog outputs to be controlled by the BMS via a high level interface (HLI) (e.g. to control a chilled water valve) including ability to define a default value of these outputs in the event of the HLI failing
8**	Communication and Options	Parameters used for configuring and monitoring functions associated with the serial communications/high level interface to the frequency converter
9**	Profibus	Parameters only applicable when a Profibus option is installed.
10**	CAN Fieldbus	Parameters only applicable when a DeviceNet option is installed.
11**	LonWorks	Parameters only applicable when a Lonworks option is installed.

Group	Title	Function
13**	Smart Logic Controller	<p>Parameters used to configure the built-in Smart Logic Controller (SLC). The SLC can be used for</p> <ul style="list-style-type: none"> • simple functions such as <ul style="list-style-type: none"> - comparators (e.g. if running above x Hz, activate output relay) - timers (e.g. when a start signal is applied, first activate output relay to open supply air damper and wait x seconds before ramping up) • complex sequence of user-defined actions executed by the SLC when the associated user-defined event is evaluated as TRUE by the SLC. (For example, initiate an economiser mode in a simple AHU cooling application control scheme where there is no BMS. For such an application the SLC can monitor the outside air relative humidity and if it is below a defined value, the supply air temperature setpoint could be automatically increased. With the frequency converter monitoring the outside air relative humidity and supply air temperature via its analog inputs, and controlling the chilled water valve via one of the extended PI(D) loops and an analog output, it would then modulate that valve to maintain a higher supply air temperature). <p>The SLC can often replace the need for other external control equipment.</p>
14**	Special Functions	<p>Parameters used to configure special functions of the frequency converter including:</p> <ul style="list-style-type: none"> • Setting of the switching frequency to reduce audible noise from the motor (sometimes required for fan applications) • Kinetic back-up function (especially useful for critical applications in semi-conductor installations where performance under mains dip/mains loss is important) • Mains imbalance protection • Automatic reset (to avoid the need for a manual reset of Alarms) • Energy optimisation parameters (which typically do not need changing but enable fine tuning of this automatic function (if necessary) ensuring the frequency converter and motor combination operate at their optimum efficiency at full and partial load conditions) • Auto-derating functions (which enable the frequency converter to continue operation at reduced performance under extreme operating conditions ensuring maximum up time)
15**	FC Information	<p>Parameters providing operating data and other frequency converter information including:</p> <ul style="list-style-type: none"> • Operating and running hour counters • kWh counter; resetting of the running and kWh counters • Alarm/fault log (where the past 10 alarms are logged along with any associated value and time) • Frequency converter and option card identification parameters such as code number and software version
16**	Data Readouts	<p>Read only parameters which display the status/value of many operating variables which can be displayed on the LCP or viewed in this parameter group. These parameters can be particularly useful during commissioning when interfacing with a BMS via a high level interface.</p>
18**	Info & Readouts	<p>Read only parameters which display the last 10 preventative maintenance log items, actions and time and the value of analog inputs and outputs on the Analog I/O option card which can be particularly useful during commissioning when interfacing with a BMS via a high level interface.</p>

Group	Title	Function
20**	FC Closed Loop	<p>Parameters used to configure the closed loop PI(D) controller which controls the speed of the pump, fan or compressor in closed loop mode including:</p> <ul style="list-style-type: none"> Defining where each of the 3 possible feedback signals come from (e.g. which analog input or the BMS HLI) Conversion factor for each of the feedback signals (e.g. where a pressure signal is used for indication of flow in an AHU or converting from pressure to temperature in a compressor application) Engineering unit for the reference and feedback (e.g. Pa, kPa, m Wg, in Wg, bar, m3/s, m3/h, °C, °F etc) The function (e.g. sum, difference, average, minimum or maximum) used to calculate the resulting feedback for single zone applications or the control philosophy for multi-zone applications Programming of the setpoint(s) Manual or auto-tuning of the PI(D) loop
21**	Extended Closed Loop	<p>Parameters used to configure the 3 extended closed loop PI(D) controllers which for example can be used to control external actuators (e.g. chilled water valve to maintain supply air temperature in a VAV system) including:</p> <ul style="list-style-type: none"> Engineering unit for the reference and feedback of each controller (e.g. °C, °F etc) Defining the range of the reference/setpoint for each controller Defining where each of the references/setpoints and feedback signals come from (e.g. which analog input or the BMS HLI); programming of the setpoint and manual or auto-tuning of the each of the PI(D) controllers
22**	Application Functions	<p>Parameters used to monitor, protect and control pumps, fans and compressors including:</p> <ul style="list-style-type: none"> No flow detection and protection of pumps (including auto-setup of this function); dry pump protection End of curve detection and protection of pumps Sleep mode (especially useful for cooling tower and booster pump sets) Broken belt detection (typically used for fan applications to detect no air flow instead of using a Δp switch installed across the fan) Short cycle protection of compressors and pump flow compensation of setpoint (especially useful for secondary chilled water pump applications where the Δp sensor has been installed close to the pump and not across the furthest most significant load(s) in the system. Using this function can compensate for the sensor installation and help to realise the maximum energy savings).
23**	Time Based Functions	<p>Time based parameters including:</p> <ul style="list-style-type: none"> Parameters used to initiate daily or weekly actions based on the built-in real time clock (e.g. change of setpoint for night set back mode or start/stop of the pump/fan/compressor start/stop of a external equipment) Preventive maintenance functions which can be based on running or operating hour time intervals or on specific dates and times Energy log (especially useful in retrofit applications or where information of the actual historical load (kW) on the pump/fan/compressor is of interest) Trending (especially useful in retrofit or other applications where there is an interest to log operating power, current, frequency or speed of the pump/fan/compressor for analysis and a payback counter)
24**	Application Functions 2	<p>Parameters used to set-up Fire Mode and/or to control a bypass contactor/starter if designed into the system.</p>
25**	Cascade Controller	<p>Parameters used to configure and monitor the built-in pump cascade controller (typically used for pump booster sets).</p>

Group	Title	Function
26**	Analog I/O Option MCB 109	Parameters used to configure the Analog I/O option (MCB 109) including: <ul style="list-style-type: none"> • Definition of the analog input types (e.g. voltage, Pt1000 or Ni1000) • Scaling and definition of the analog output functions and scaling.

Table 6.1 Parameter Groups

Parameter descriptions and selections are displayed on the graphic (GLCP) or numeric (NLCP) display. (See relevant section for details.) Access the parameters by pressing the [Quick Menu] or [Main Menu] key on the LCP. The Quick Menu is used primarily for commissioning the unit at start-up by providing the parameters necessary to start operation. The Main Menu provides access to all parameters for detailed application programming.

All digital input/output and analog input/output terminals are multifunctional. All terminals have factory default functions suitable for the majority of HVAC applications but if other special functions are required, they must be programmed as explained in parameter group 5-** *Digital In/out* or 6-** *Analog In/out*.

6.1.2 Quick Menu Mode

Parameter Data

The graphical display (GLCP) provides access to all parameters listed under the Quick Menus. The numeric display (NLCP) only provides access to the Quick Setup parameters. To set parameters pressing [Quick Menu] - enter or change parameter data or settings in accordance with the following procedure

1. Press [Quick Menu].
2. Press [▲] and [▼] to find the parameter to change.
3. Press [OK].
4. Press [▲] and [▼] to select the correct parameter setting.
5. Press [OK].
6. To move to a different digit within a parameter setting, use the [◀] and [▶].
7. Highlighted area indicates digit selected for change.
8. Press [Cancel] to disregard change, or press [OK] to accept change and enter the new setting.

Example of changing parameter data

Assume parameter 22-60 *Broken Belt Function* is set to [Off]. To monitor the fan-belt condition - non-broken or broken - follow this procedure

1. Press [Quick Menu]
2. Select Function Setups with [▼].

3. Press [OK].
4. Select Application Settings with [▼] .
5. Press [OK].
6. Press [OK] again for Fan Functions..
7. Select Broken Belt Function by pressing [OK].
8. With [▼], select [2] *Trip*.

The frequency converter now trips if a broken fan-belt is detected.

Select [My Personal Menu] to display personal parameters

For example, an AHU or pump OEM may have pre-programmed personal parameters to be in My Personal Menu during factory commissioning to make on-site commissioning/fine tuning simpler. These parameters are selected in 0-25 *My Personal Menu*. Up to 20 different parameters can be programmed in this menu.

Select [Changes Made] to get information about

- The last 10 changes. Use [▲] and [▼] to scroll between the last 10 changed parameters.
- The changes made since default setting.

[Loggings]

shows information about the display line read-outs. The information is shown as graphs.

Only display parameters selected in 0-20 *Display Line 1.1 Small* and 0-24 *Display Line 3 Large* can be viewed. It is possible to store up to 120 samples in the memory for later reference.

Quick Setup

Efficient Parameter Set-up for HVAC Applications

The parameters can easily be set up for most HVAC applications only by using the [Quick Setup] option. After pressing [Quick Menu], the different choices in the Quick Menu are listed. See also *Illustration 6.1* and *Table 6.3* to *Table 6.6*.

Example of using the Quick Setup option

To set the ramp down time to 100 s:

1. Select [Quick Setup]. parameter 0-01 *Language* in Quick Setup appears.
2. Press [▼] repeatedly until parameter 3-42 *Ramp 1 Ramp Down Time* appears with the default setting of 20 s.
3. Press [OK].

4. Press [◀] to highlight the 3rd digit before the comma.
5. Change '0' to '1' by pressing [▲].
6. Press [▶] to highlight the digit '2'.
7. Change '2' to '0' by pressing [▼].
8. Press [OK].

The new ramp-down time is now set to 100 s.
It is recommended to do the set-up in the order listed.

NOTICE




Illustration 6.1 Quick Menu View

The Quick Setup menu gives access to the 18 most important setup parameters of the frequency converter. After programming, the frequency converter is ready for operation. The 18 Quick Set-up parameters are shown in Table 6.2.

Parameter	[Units]
Parameter 0-01 Language	
Parameter 1-20 Motor Power [kW]	[kW]
Parameter 1-21 Motor Power [HP]	[HP]
Parameter 1-22 Motor Voltage*	[V]
Parameter 1-23 Motor Frequency	[Hz]
Parameter 1-24 Motor Current	[A]
Parameter 1-25 Motor Nominal Speed	[RPM]
Parameter 1-28 Motor Rotation Check	[Hz]
Parameter 3-41 Ramp 1 Ramp Up Time	[s]
Parameter 3-42 Ramp 1 Ramp Down Time	[s]
Parameter 4-11 Motor Speed Low Limit [RPM]	[RPM]
Parameter 4-12 Motor Speed Low Limit [Hz]*	[Hz]
Parameter 4-13 Motor Speed High Limit [RPM]	[RPM]
Parameter 4-14 Motor Speed High Limit [Hz]*	[Hz]
3-19 Jog Speed [RPM]	[RPM]
Parameter 3-11 Jog Speed [Hz]*	[Hz]
5-12 Terminal 27 Digital Input	
Parameter 5-40 Function Relay**	

Table 6.2 Quick Setup Parameters

*The display showing depends on choices made in 0-02 Motor Speed Unit and 0-03 Regional Settings. The default settings of 0-02 Motor Speed Unit and 0-03 Regional Settings depend on which region of

the world the frequency converter is supplied to but can be re-programmed as required.

** Parameter 5-40 Function Relay is an array. Select between [0] Relay1 or [1] Relay2. Standard setting is [0] Relay1 with the default choice [9] Alarm.

For a detailed information about settings and programming, see the VLT HVAC Drive Programming Guide

NOTICE

If [0] No Operation is selected in 5-12 Terminal 27 Digital Input, no connection to +24 V on terminal 27 is necessary to enable start.

If [2] Coast Inverse (factory default value) is selected in 5-12 Terminal 27 Digital Input, a connection to +24 V is necessary to enable start.

0-01 Language		
Option:	Function:	
		Defines the language to be used in the display. The frequency converter is delivered with 4 different language packages English and German are included in all packages. English cannot be erased or manipulated.
[0] *	English	Part of Language packages 1 - 4
[1]	Deutsch	Part of Language packages 1 - 4
[2]	Francais	Part of Language package 1
[3]	Dansk	Part of Language package 1
[4]	Spanish	Part of Language package 1
[5]	Italiano	Part of Language package 1
[6]	Svenska	Part of Language package 1
[7]	Nederlands	Part of Language package 1
[10]	Chinese	Part of Language package 2
[20]	Suomi	Part of Language package 1
[22]	English US	Part of Language package 4
[27]	Greek	Part of Language package 4
[28]	Bras.port	Part of Language package 4
[36]	Slovenian	Part of Language package 3
[39]	Korean	Part of Language package 2
[40]	Japanese	Part of Language package 2
[41]	Turkish	Part of Language package 4
[42]	Trad.Chinese	Part of Language package 2
[43]	Bulgarian	Part of Language package 3
[44]	Srpski	Part of Language package 3

0-01 Language		
Option:	Function:	
[45]	Romanian	Part of Language package 3
[46]	Magyar	Part of Language package 3
[47]	Czech	Part of Language package 3
[48]	Polski	Part of Language package 4
[49]	Russian	Part of Language package 3
[50]	Thai	Part of Language package 2
[51]	Bahasa Indonesia	Part of Language package 2
[52]	Hrvatski	Part of Language package 3

1-20 Motor Power [kW]		
Range:	Function:	
Size related* [0.09 - 3000.00 kW]	Enter the nominal motor power in kW according to the motor nameplate data. The default value corresponds to the nominal rated output of the unit. Depending on the choices made in <i>0-03 Regional Settings</i> , either <i>parameter 1-20 Motor Power [kW]</i> or <i>parameter 1-21 Motor Power [HP]</i> is made invisible.	

1-21 Motor Power [HP]		
Range:	Function:	
Size related* [0.09 - 3000.00 hp]	Enter the nominal motor power in HP according to the motor nameplate data. The default value corresponds to the nominal rated output of the unit. Depending on the choices made in <i>0-03 Regional Settings</i> , either <i>parameter 1-20 Motor Power [kW]</i> or <i>parameter 1-21 Motor Power [HP]</i> is made invisible.	

1-22 Motor Voltage		
Range:	Function:	
Size related* [10 - 1000 V]	Enter the nominal motor voltage according to the motor nameplate data. The default value corresponds to the nominal rated output of the unit.	

1-23 Motor Frequency		
Range:	Function:	
Size related* [20 - 1000 Hz]	Select the motor frequency value from the motor nameplate data. For 87 Hz operation with 230/400 V motors, set the nameplate data for 230 V/50 Hz. Adapt <i>parameter 4-13 Motor Speed High Limit [RPM]</i>	

1-23 Motor Frequency		
Range:	Function:	
	and <i>3-03 Maximum Reference</i> to the 87 Hz application.	

1-24 Motor Current		
Range:	Function:	
Size related* [0.10 - 10000.00 A]	Enter the nominal motor current value from the motor nameplate data. This data is used for calculating motor torque, motor thermal protection etc.	

1-25 Motor Nominal Speed		
Range:	Function:	
Size related* [100 - 60000 RPM]	Enter the nominal motor speed value from the motor nameplate data. This data is used for calculating automatic motor compensations.	

1-28 Motor Rotation Check		
Option:	Function:	
[0] * Off	Following installation and connection of the motor, this function allows the correct motor rotation direction to be verified. Enabling this function overrides any bus commands or digital inputs, except External Interlock and Safe Stop (if included).	
[1]	Motor Rotation Check is enabled.	

NOTICE

Once the motor rotation check is enabled the display shows: **Note! Motor may run in wrong direction.** Pressing [OK], [Back] or [Cancel] dismisses the message and displays a new message: "Press [Hand On] to start the motor. Press [Cancel] to abort". Pressing [Hand On] starts the motor at 5 Hz in forward direction and the display shows: "Motor is running. Check if motor rotation direction is correct. Press [Off] to stop the motor". Pressing [Off] stops the motor and resets *parameter 1-28 Motor Rotation Check*. If motor rotation direction is incorrect, 2 motor phase cables should be interchanged.

WARNING

Remove mains power before disconnecting motor phase cables.

3-11 Jog Speed [Hz]		
Range:		Function:
Size related*	[0 - par. 4-14 Hz]	The jog speed is a fixed output speed at which the frequency converter is running when the jog function is activated. See also 3-80 Jog Ramp Time.

3-41 Ramp 1 Ramp Up Time		
Range:		Function:
Size related*	[1.00 - 3600 s]	Enter the ramp-up time, i.e. the acceleration time from 0 RPM to <i>parameter 1-25 Motor Nominal Speed</i> . Select a ramp-up time such that the output current does not exceed the current limit in 4-18 Current Limit during ramping. See ramp-down time in <i>parameter 3-42 Ramp 1 Ramp Down Time</i> .

$$par.3 - 41 = \frac{t_{acc} \times n_{nom} [par.1 - 25]}{ref [rpm]} [s]$$

3-42 Ramp 1 Ramp Down Time		
Range:		Function:
Size related*	[1.00 - 3600 s]	Enter the ramp-down time, i.e. the deceleration time from <i>parameter 1-25 Motor Nominal Speed</i> to 0 RPM. Select a ramp-down time such that no over-voltage arises in the inverter due to regenerative operation of the motor, and such that the generated current does not exceed the current limit set in 4-18 Current Limit. See ramp-up time in <i>parameter 3-41 Ramp 1 Ramp Up Time</i> .

$$par.3 - 42 = \frac{t_{dec} \times n_{nom} [par.1 - 25]}{ref [rpm]} [s]$$

4-11 Motor Speed Low Limit [RPM]		
Range:		Function:
Size related*	[0 - par. 4-13 RPM]	Enter the minimum limit for motor speed. The motor speed low limit can be set to correspond to the manufacturer's recommended minimum motor speed. The motor speed low limit must not exceed the setting in <i>parameter 4-13 Motor Speed High Limit [RPM]</i> .

4-12 Motor Speed Low Limit [Hz]		
Range:		Function:
Size related*	[0 - par. 4-14 Hz]	Enter the minimum limit for motor speed. The motor speed low limit can be set to correspond to the minimum output frequency of the motor shaft. The speed low limit must not exceed the setting in <i>parameter 4-14 Motor Speed High Limit [Hz]</i> .

4-13 Motor Speed High Limit [RPM]		
Range:		Function:
Size related*	[par. 4-11 - 60000 RPM]	Enter the maximum limit for motor speed. The motor speed high limit can be set to correspond to the manufacturer's maximum rated motor. The motor speed high limit must exceed the setting in <i>parameter 4-11 Motor Speed Low Limit [RPM]</i> . Only <i>parameter 4-11 Motor Speed Low Limit [RPM]</i> or <i>parameter 4-12 Motor Speed Low Limit [Hz]</i> is displayed depending on other parameters in the Main Menu and depending on default settings dependant on global location.

NOTICE

Max. output frequency cannot exceed 10% of the inverter switching frequency (*parameter 14-01 Switching Frequency*).

NOTICE

Any changes in *parameter 4-13 Motor Speed High Limit [RPM]* reset the value in *parameter 4-53 Warning Speed High* to the same value as set in *parameter 4-13 Motor Speed High Limit [RPM]*.

4-14 Motor Speed High Limit [Hz]		
Range:		Function:
Size related*	[par. 4-12 - par. 4-19 Hz]	Enter the max limit for motor speed. <i>parameter 4-14 Motor Speed High Limit [Hz]</i> can match the manufacturer's recommended maximum motor speed. The Motor Speed High Limit must exceed the value in <i>parameter 4-12 Motor Speed Low Limit [Hz]</i> . The output frequency must not exceed 10% of the switching frequency.

NOTICE


Max. output frequency cannot exceed 10% of the inverter switching frequency (*parameter 14-01 Switching Frequency*).

6.1.3 Function Set-ups

The Function Set-up provides quick and easy access to all parameters required for most HVAC applications including most VAV and CAV supply and return fans, cooling tower fans, primary, secondary and condenser water pumps and other pump, fan and compressor applications.

How to access Function Set-up - example


1. Turn on the frequency converter (yellow LED lights).



130BT110.11

Illustration 6.2


2. Press [Quick Menu] (Quick Menu choices appear).



130BT111.10

Illustration 6.3


3. Press [▲] and [▼] to scroll down to Function set-ups. Press [OK].



130BT112.10

Illustration 6.4


4. Function set-ups choices appear. Select Q3-1 General Settings. Press [OK].



130BT113.10

Illustration 6.5


5. Press [▲] and [▼] to scroll down to i.e. Q3-11 Analog Outputs. Press [OK].



130BT114.10

Illustration 6.6


6. Select parameter 6-50 Terminal 42 Output. Press [OK].



130BA115.10

Illustration 6.7

7. Use [▲] and [▼] to select between the different choices. Press [OK].



130BT116.10

Illustration 6.8

Function Set-ups parameters

The Function Set-ups parameters are grouped in the following way

Q3-10 Adv. Motor Settings	Q3-11 Analog Output	Q3-12 Clock Settings	Q3-13 Display Settings
Parameter 1-90 Motor Thermal Protection	Parameter 6-50 Terminal 42 Output	Parameter 0-70 Date and Time	0-20 Display Line 1.1 Small
Parameter 1-93 Thermistor Source	Parameter 6-51 Terminal 42 Output Min Scale	Parameter 0-71 Date Format	0-21 Display Line 1.2 Small
Parameter 1-29 Automatic Motor Adaptation (AMA)	Parameter 6-52 Terminal 42 Output Max Scale	Parameter 0-72 Time Format	0-22 Display Line 1.3 Small
Parameter 14-01 Switching Frequency		Parameter 0-74 DST/Summertime	0-23 Display Line 2 Large
Parameter 4-53 Warning Speed High		Parameter 0-76 DST/Summertime Start	0-24 Display Line 3 Large
		Parameter 0-77 DST/Summertime End	Parameter 0-37 Display Text 1
			Parameter 0-38 Display Text 2
			Parameter 0-39 Display Text 3

Table 6.3 Q3-1 General Settings

Q3-20 Digital Reference	Q3-21 Analog Reference
Parameter 3-02 Minimum Reference	Parameter 3-02 Minimum Reference
3-03 Maximum Reference	3-03 Maximum Reference
Parameter 3-10 Preset Reference	Parameter 6-10 Terminal 53 Low Voltage
5-13 Terminal 29 Digital Input	Parameter 6-11 Terminal 53 High Voltage
5-14 Terminal 32 Digital Input	6-12 Terminal 53 Low Current
5-15 Terminal 33 Digital Input	6-13 Terminal 53 High Current
	Parameter 6-14 Terminal 53 Low Ref./Feedb. Value
	Parameter 6-15 Terminal 53 High Ref./Feedb. Value

Table 6.4 Q3-2 Open Loop Settings

Q3-30 Single Zone Int. Set Point	Q3-31 Single Zone Ext. Set Point	Q3-32 Multi Zone / Adv
Parameter 1-00 Configuration Mode	Parameter 1-00 Configuration Mode	Parameter 1-00 Configuration Mode
20-12 Reference/Feedback Unit	20-12 Reference/Feedback Unit	Parameter 3-15 Reference 1 Source
20-13 Minimum Reference/Feedb.	20-13 Minimum Reference/Feedb.	Parameter 3-16 Reference 2 Source
20-14 Maximum Reference/Feedb.	20-14 Maximum Reference/Feedb.	Parameter 20-00 Feedback 1 Source
Parameter 6-22 Terminal 54 Low Current	Parameter 6-10 Terminal 53 Low Voltage	Parameter 20-01 Feedback 1 Conversion
Parameter 6-24 Terminal 54 Low Ref./Feedb. Value	Parameter 6-11 Terminal 53 High Voltage	20-02 Feedback 1 Source Unit
Parameter 6-25 Terminal 54 High Ref./Feedb. Value	6-12 Terminal 53 Low Current	Parameter 20-03 Feedback 2 Source
Parameter 6-26 Terminal 54 Filter Time Constant	6-13 Terminal 53 High Current	Parameter 20-04 Feedback 2 Conversion
Parameter 6-27 Terminal 54 Live Zero	Parameter 6-14 Terminal 53 Low Ref./Feedb. Value	20-05 Feedback 2 Source Unit
Parameter 6-00 Live Zero Timeout Time	Parameter 6-15 Terminal 53 High Ref./Feedb. Value	Parameter 20-06 Feedback 3 Source
Parameter 6-01 Live Zero Timeout Function	Parameter 6-22 Terminal 54 Low Current	Parameter 20-07 Feedback 3 Conversion
Parameter 20-21 Setpoint 1	Parameter 6-24 Terminal 54 Low Ref./Feedb. Value	20-08 Feedback 3 Source Unit
Parameter 20-81 PID Normal/ Inverse Control	Parameter 6-25 Terminal 54 High Ref./Feedb. Value	20-12 Reference/Feedback Unit

Q3-30 Single Zone Int. Set Point	Q3-31 Single Zone Ext. Set Point	Q3-32 Multi Zone / Adv
20-82 PID Start Speed [RPM]	Parameter 6-26 Terminal 54 Filter Time Constant	20-13 Minimum Reference/Feedb.
20-83 PID Start Speed [Hz]	Parameter 6-27 Terminal 54 Live Zero	20-14 Maximum Reference/Feedb.
Parameter 20-93 PID Proportional Gain	Parameter 6-00 Live Zero Timeout Time	Parameter 6-10 Terminal 53 Low Voltage
Parameter 20-94 PID Integral Time	Parameter 6-01 Live Zero Timeout Function	Parameter 6-11 Terminal 53 High Voltage
20-70 Closed Loop Type	Parameter 20-81 PID Normal/ Inverse Control	6-12 Terminal 53 Low Current
20-71 PID Performance	20-82 PID Start Speed [RPM]	6-13 Terminal 53 High Current
20-72 PID Output Change	20-83 PID Start Speed [Hz]	Parameter 6-14 Terminal 53 Low Ref./Feedb. Value
20-73 Minimum Feedback Level	Parameter 20-93 PID Proportional Gain	Parameter 6-15 Terminal 53 High Ref./Feedb. Value
20-74 Maximum Feedback Level	Parameter 20-94 PID Integral Time	Parameter 6-16 Terminal 53 Filter Time Constant
20-79 PID Autotuning	20-70 Closed Loop Type	Parameter 6-17 Terminal 53 Live Zero
	20-71 PID Performance	Parameter 6-20 Terminal 54 Low Voltage
	20-72 PID Output Change	Parameter 6-21 Terminal 54 High Voltage
	20-73 Minimum Feedback Level	Parameter 6-22 Terminal 54 Low Current
	20-74 Maximum Feedback Level	Parameter 6-23 Terminal 54 High Current
	20-79 PID Autotuning	Parameter 6-24 Terminal 54 Low Ref./Feedb. Value
		Parameter 6-25 Terminal 54 High Ref./Feedb. Value
		Parameter 6-26 Terminal 54 Filter Time Constant
		Parameter 6-27 Terminal 54 Live Zero
		Parameter 6-00 Live Zero Timeout Time
		Parameter 6-01 Live Zero Timeout Function
		Parameter 4-56 Warning Feedback Low
		Parameter 4-57 Warning Feedback High
		Parameter 20-20 Feedback Function
		Parameter 20-21 Setpoint 1
		Parameter 20-22 Setpoint 2
		Parameter 20-81 PID Normal/ Inverse Control
		20-82 PID Start Speed [RPM]
		20-83 PID Start Speed [Hz]
		Parameter 20-93 PID Proportional Gain
		Parameter 20-94 PID Integral Time
		20-70 Closed Loop Type
		20-71 PID Performance
		20-72 PID Output Change
		20-73 Minimum Feedback Level
		20-74 Maximum Feedback Level
		20-79 PID Autotuning

Table 6.5 Q3-3 Closed Loop Settings

Q3-40 Fan Functions	Q3-41 Pump Functions	Q3-42 Compressor Functions
Parameter 22-60 Broken Belt Function	22-20 Low Power Auto Set-up	Parameter 1-03 Torque Characteristics
Parameter 22-61 Broken Belt Torque	Parameter 22-21 Low Power Detection	Parameter 1-71 Start Delay
Parameter 22-62 Broken Belt Delay	Parameter 22-22 Low Speed Detection	Parameter 22-75 Short Cycle Protection
Parameter 4-64 Semi-Auto Bypass Set-up	Parameter 22-23 No-Flow Function	Parameter 22-76 Interval between Starts
Parameter 1-03 Torque Characteristics	Parameter 22-24 No-Flow Delay	Parameter 22-77 Minimum Run Time
Parameter 22-22 Low Speed Detection	Parameter 22-40 Minimum Run Time	Parameter 5-01 Terminal 27 Mode
Parameter 22-23 No-Flow Function	Parameter 22-41 Minimum Sleep Time	Parameter 5-02 Terminal 29 Mode
Parameter 22-24 No-Flow Delay	Parameter 22-42 Wake-up Speed [RPM]	5-12 Terminal 27 Digital Input
Parameter 22-40 Minimum Run Time	Parameter 22-43 Wake-up Speed [Hz]	5-13 Terminal 29 Digital Input
Parameter 22-41 Minimum Sleep Time	Parameter 22-44 Wake-up Ref./FB Difference	Parameter 5-40 Function Relay
Parameter 22-42 Wake-up Speed [RPM]	22-45 Setpoint Boost	Parameter 1-73 Flying Start
Parameter 22-43 Wake-up Speed [Hz]	22-46 Maximum Boost Time	1-86 Trip Speed Low [RPM]
Parameter 22-44 Wake-up Ref./FB Difference	Parameter 22-26 Dry Pump Function	1-87 Trip Speed Low [Hz]
22-45 Setpoint Boost	22-27 Dry Pump Delay	
22-46 Maximum Boost Time	22-80 Flow Compensation	
Parameter 2-10 Brake Function	22-81 Square-linear Curve Approximation	
2-16 AC brake Max. Current	22-82 Work Point Calculation	
Parameter 2-17 Over-voltage Control	22-83 Speed at No-Flow [RPM]	
Parameter 1-73 Flying Start	22-84 Speed at No-Flow [Hz]	
Parameter 1-71 Start Delay	22-85 Speed at Design Point [RPM]	
Parameter 1-80 Function at Stop	22-86 Speed at Design Point [Hz]	
Parameter 2-00 DC Hold/Preheat Current	22-87 Pressure at No-Flow Speed	
Parameter 4-10 Motor Speed Direction	22-88 Pressure at Rated Speed	
	22-89 Flow at Design Point	
	22-90 Flow at Rated Speed	
	Parameter 1-03 Torque Characteristics	
	Parameter 1-73 Flying Start	

Table 6.6 Q3-4 Application Settings

1-00 Configuration Mode		
Option:	Function:	
		NOTICE This parameter cannot be adjusted while the motor is running.
[0]	Open Loop	Motor speed is determined by applying a speed reference or by setting desired speed when in Hand Mode. Open Loop is also used if the frequency converter is of a closed loop control system based on an external PID controller providing a speed reference signal as output.
[3]	Closed Loop	Motor Speed will be determined by a reference from the built-in PID controller varying the motor speed as of a closed loop control process (e.g. constant pressure or flow). The PID controller must be configured in parameter group 20-** Feedback or via the Function Set-ups accessed by pressing [Quick Menus].

NOTICE

When set for Closed Loop, the commands Reversing and Start Reversing do not reverse the direction of the motor.

1-03 Torque Characteristics		
Option:	Function:	
[0]	Compressor torque	For speed control of screw and scroll compressors. Provides a voltage which is optimized for a constant torque load characteristic of the motor in the entire range down to 10 Hz.
[1]	Variable torque	For speed control of centrifugal pumps and fans. Also to be used when controlling more than one motor from the same frequency converter (e.g. multiple condenser fans or cooling tower fans). Provides a voltage which is optimised for a squared torque load characteristic of the motor.
[2]	Auto Energy Optim. CT	For optimum energy efficient speed control of screw and scroll compressors. Provides a

1-03 Torque Characteristics		
Option:	Function:	
		voltage which is optimised for a constant torque load characteristic of the motor in the entire range down to 15 Hz but in addition the AEO feature adapts the voltage exactly to the current load situation, thereby reducing energy consumption and audible noise from the motor. To obtain optimum performance, set the motor power factor cos phi correctly. This value is set in <i>14-43 Motor Cosphi</i> . The parameter has a default value which is automatically adjusted when the motor data is programmed. These settings typically ensure optimum motor voltage, but if the motor power factor cos phi requires tuning, an AMA function can be carried out using <i>parameter 1-29 Automatic Motor Adaptation (AMA)</i> . It is rarely necessary to adjust the motor power factor parameter manually.
[3] *	Auto Energy Optim. VT	For optimum energy efficient speed control of centrifugal pumps and fans. Provides a voltage optimised for a squared torque load characteristic of the motor, but in addition the AEO feature adapts the voltage exactly to the current load situation, thereby reducing energy consumption and audible noise from the motor. To obtain optimum performance, set the motor power factor cos phi correctly. This value is set in <i>14-43 Motor Cosphi</i> . The parameter has a default value and is automatically adjusted when the motor data is programmed. These settings typically ensure optimum motor voltage, but if the motor power factor cos phi requires tuning, an AMA function can be carried out using <i>parameter 1-29 Automatic Motor Adaptation (AMA)</i> . It is rarely necessary to adjust the motor power factor parameter manually.

NOTICE

Parameter 1-03 Torque Characteristics have no effect when 1-10 Motor Construction = [1] PM, non salient SPM.

NOTICE

For pumps or fan applications where the viscosity or density can vary significantly or where excessive flow e.g. due pipe breakage, can occur, it is recommended to select Auto Energy Optim. CT

1-29 Automatic Motor Adaptation (AMA)		
Option:	Function:	
		NOTICE This parameter cannot be adjusted while the motor is running.
[0] *	Off	No function
[1]	Enable Complete AMA	Performs AMA of the stator resistance R_s , the rotor resistance R_r , the stator leakage reactance X_1 , the rotor leakage reactance X_2 and the main reactance X_h .
[2]	Enable Reduced AMA	Performs a reduced AMA of the stator resistance R_s in the system only. Select this option if an LC filter is used between the frequency converter and the motor.

NOTICE

Parameter 1-29 Automatic Motor Adaptation (AMA) have no effect when 1-10 Motor Construction = [1] PM, non salient SPM.

Activate the AMA function by pressing [Hand on] after selecting [1] or [2]. See also the item *Automatic Motor Adaptation* in the *Design Guide*. After a normal sequence, the display reads: *Press [OK] to finish AMA*. After pressing [OK], the frequency converter is ready for operation.

NOTICE

- For the best adaptation of the frequency converter, run AMA on a cold motor
- AMA cannot be performed while the motor is running

NOTICE

Avoid generating external torque during AMA.

NOTICE

If one of the settings in parameter group 1-2* Motor Data is changed, 1-30 Stator Resistance (R_s) to parameter 1-39 Motor Poles return to default settings.

NOTICE

Full AMA should be run without filter only while reduced AMA should be run with filter.

See section: *Application Examples > Automatic Motor Adaptation* in the *Design Guide*.

1-71 Start Delay		
Range:		Function:
00 s*	[0 - 120 s]	When the frequency converter receives the start command, it delays the motor start for the period of time specified in this parameter. The function selected in <i>parameter 1-80 Function at Stop</i> is active in the delay period.

1-73 Flying Start		
Option:		Function:
		<p>This function makes it possible to catch a motor which is spinning freely due to a mains drop-out.</p> <p>When <i>parameter 1-73 Flying Start</i> is enabled, <i>parameter 1-71 Start Delay</i> has no function. Search direction for flying start is linked to the setting in <i>parameter 4-10 Motor Speed Direction</i>.</p> <p><i>[0] Clockwise:</i> Flying start search in clockwise direction. If not successful, a DC brake is carried out.</p> <p><i>[2] Both Directions:</i> The flying start first makes a search in the direction determined by the last reference (direction). If not finding the speed, it makes a search in the other direction. If not successful, a DC brake is activated in the time set in <i>2-02 DC Braking Time</i>. Start then takes place from 0 Hz.</p>
[0]	Disabled	Select <i>[0] Disable</i> if this function is not required
[1]	Enabled	<p>Select <i>[1] Enable</i> to enable the frequency converter to catch and control a spinning motor.</p> <p>The parameter is always set to <i>[1] Enable</i> when <i>1-10 Motor Construction</i> = <i>[1] PM non salient</i>.</p> <p>Important related parameters:</p> <ul style="list-style-type: none"> • <i>1-58 Flystart Test Pulses Current</i> • <i>1-59 Flystart Test Pulses Frequency</i> • <i>1-70 PM Start Mode</i> • <i>2-06 Parking Current</i> • <i>2-07 Parking Time</i> • <i>2-03 DC Brake Cut In Speed [RPM]</i> • <i>2-04 DC Brake Cut In Speed [Hz]</i> • <i>2-06 Parking Current</i> • <i>2-07 Parking Time</i>

1-70 PM Start Mode = *[1] Parking*:

If the speed estimate comes out lower than the setting in *1-59 Flystart Test Pulses Frequency* then the Parking function is engaged (see *2-06 Parking Current* and *2-07 Parking Time*). Otherwise, the frequency converter catches the motor at that speed and resume normal operation. Refer to description of *1-70 PM Start Mode* for recommended settings.

Current limitations of the flystart principle used for PM motors:

- The speed range is up to 100% nominal speed or the field weakening speed (which ever is lowest).
- PMSM with high back EMF (>300 VLL(rms)) and high winding inductance(>10 mH) needed more time for reducing short circuit current to zero and may be susceptible to error in estimation.
- Current testing limited to a speed range up to 300 Hz. For certain units the limit is 250 Hz; all 200-240 V units up to and including 2.2 kW and all 380-480 V units up to and including 4 kW.
- Current testing limited to a machine power size up to 22 kW.
- Pred for salient pole machine (IPMSM) but not yet verified on those types of machine.
- For high-inertia applications (i.e. where the load inertia is more than 30 times larger than the motor inertia) a brake resistor is recommended to avoid overvoltage trip during high speed engagement of the flystart function.

The flystart function used for PM motors is based on an initial speed estimation. The speed is always estimated as the first thing after an active start signal is given. Based on the setting of *1-70 PM Start Mode* the following happens:
1-70 PM Start Mode = *[0] Rotor Detection*:

If the speed estimate comes out as greater than 0 Hz, the frequency converter catches the motor at that speed and resume normal operation. Otherwise, the frequency converter estimates the rotor position and start normal operation from there.

1-80 Function at Stop		
Option:	Function:	
		Select the frequency converter function after a stop command or after the speed is ramped down to the settings in 1-81 <i>Min Speed for Function at Stop [RPM]</i> . Available selections depend on 1-10 <i>Motor Construction</i> : [0] Asynchron: <ul style="list-style-type: none"> [0] coast [1] DC-hold [2] Motor check, warning [6] Motor check, alarm [1] PM non salient: <ul style="list-style-type: none"> [0] coast
[0] *	Coast	Leaves motor in free mode.
[1]	DC Hold/ Motor Preheat	Energizes motor with a DC holding current (see <i>parameter 2-00 DC Hold/Preheat Current</i>).
[2]	Motor check, warning	Issues a warning if the motor is not connected.
[6]	Motor check, alarm	Issues an alarm if the motor is not connected.

1-90 Motor Thermal Protection		
Option:	Function:	
		The frequency converter determines the motor temperature for motor protection in 2 different ways: <ul style="list-style-type: none"> • Via a thermistor sensor connected to one of the analog or digital inputs (<i>parameter 1-93 Thermistor Source</i>). • Via calculation (ETR = Electronic Thermal Relay) of the thermal load, based on the actual load and time. The calculated thermal load is comed with the rated motor current $I_{M,N}$ and the rated motor frequency $f_{M,N}$. The calculations estimate the need for a lower load at lower speed due to less cooling from the fan incorporated in the motor.
[0]	No protection	If the motor is continuously overloaded and no warning or trip of frequency converter is wanted.
[1]	Thermistor warning	Activates a warning when the connected thermistor in the motor reacts in the event of motor overtemperature.

1-90 Motor Thermal Protection		
Option:	Function:	
[2]	Thermistor trip	Stops (trips) the frequency converter when the connected thermistor in the motor reacts in the event of motor over-temperature.
[3]	ETR warning 1	
[4]	ETR trip 1	
[5]	ETR warning 2	
[6]	ETR trip 2	
[7]	ETR warning 3	
[8]	ETR trip 3	
[9]	ETR warning 4	
[10]	ETR trip 4	

ETR (Electronic Thermal Relay) functions 1-4 calculates the load when the set-up where they were selected is active. For example ETR-3 starts calculating when set-up 3 is selected. For the North American market: The ETR functions provide class 20 motor overload protection in accordance with NEC.




Illustration 6.9

WARNING

To maintain PELV, all connections made to the control terminals must be PELV, e.g. thermistor must be reinforced/double insulated

NOTICE

Danfoss recommends using 24 V DC as thermistor supply voltage.

NOTICE

The ETR timer function does not work when *1-10 Motor Construction* = [1] PM, non salient SPM.

NOTICE

For correct operation of the ETR function, the setting in *parameter 1-03 Torque Characteristics* must fit the application (see description of *parameter 1-03 Torque Characteristics*).

1-93 Thermistor Source		
Option:	Function:	
		<p>NOTICE</p> <p>This parameter cannot be adjusted while the motor is running.</p> <p>Select the input to which the thermistor (PTC sensor) should be connected. An analog input option [1] <i>Analog Input 53</i> or [2] <i>Analog Input 54</i> cannot be selected if the analog input is already in use as a reference source (selected in <i>parameter 3-15 Reference 1 Source</i>, <i>parameter 3-16 Reference 2 Source</i> or <i>3-17 Reference 3 Source</i>). When using MCB 112, [0] <i>None</i> must always be selected.</p>
[0] *	None	
[1]	Analog Input 53	
[2]	Analog Input 54	
[3]	Digital input 18	
[4]	Digital input 19	
[5]	Digital input 32	
[6]	Digital input 33	

NOTICE

Digital input should be set to [0] *PNP - Active at 24 V in 5-00 Digital I/O Mode*.

2-00 DC Hold/Preheat Current		
Range:	Function:	
50 %*	[0 - 160 %]	<p>Enter a value for holding current as a percentage of the rated motor current $I_{M,N}$ set in <i>parameter 1-24 Motor Current</i>. 100% DC holding current corresponds to $I_{M,N}$. This parameter holds the motor (holding torque) or pre-heats the motor.</p>

2-00 DC Hold/Preheat Current		
Range:	Function:	
		<p>This parameter is active if [1] <i>DC hold/Motor Preheat</i> is selected in <i>parameter 1-80 Function at Stop</i>.</p>

NOTICE

Parameter 2-00 DC Hold/Preheat Current have no effect when *1-10 Motor Construction* = [1] PM, non salient SPM.

NOTICE

The maximum value depends on the rated motor current.
Avoid 100 % current for too long. It may damage the motor.

2-10 Brake Function		
Option:	Function:	
		<p>Available selections depend on <i>1-10 Motor Construction</i>:</p> <p>[0] <i>Asynchron</i>:</p> <p style="padding-left: 40px;">[0] <i>Off</i></p> <p style="padding-left: 40px;">[1] <i>Resistor brake</i></p> <p style="padding-left: 40px;">[2] <i>AC brake</i></p> <p>[1] <i>PM non salient</i>:</p> <p style="padding-left: 40px;">[0] <i>Off</i></p> <p style="padding-left: 40px;">[1] <i>Resistor brake</i></p>
[0]	Off	No brake resistor installed.
[1]	Resistor brake	<p>Brake resistor incorporated in the system, for dissipation of surplus brake energy as heat. Connecting a brake resistor allows a higher DC-link voltage during braking (generating operation). The resistor brake function is only active in frequency converters with an integral dynamic brake.</p>
[2]	AC brake	<p>AC Brake only works in compressor torque mode in <i>parameter 1-03 Torque Characteristics</i>.</p>

2-17 Over-voltage Control		
Option:	Function:	
[0]	Disabled	No OVC required.
[2] *	Enabled	Activates OVC.

NOTICE

Parameter 2-17 Over-voltage Control has no effect when *1-10 Motor Construction* = [1] PM, non salient SPM.

NOTICE

The ramp time is automatically adjusted to avoid tripping of the frequency converter.

6

3-02 Minimum Reference		
Range:		Function:
Size related*	[-999999.999 - par. 3-03 ReferenceFeed-backUnit]	Enter the Minimum Reference. The Minimum Reference is the lowest value obtainable by summing all references. The Minimum Reference value and unit matches the configuration choice made in <i>parameter 1-00 Configuration Mode</i> and <i>20-12 Reference/Feedback Unit</i> , respectively.
<p>NOTICE</p> <p>This parameter is used in open loop only.</p>		

3-04 Reference Function		
Option:		Function:
[0]	Sum	Sums both external and preset reference sources.
[1]	External/Preset	Use either the preset or the external reference source. Shift between external and preset via a command on a digital input.

3-10 Preset Reference		
Array [8]		
Range:		Function:
0 %*	[-100 - 100 %]	Enter up to eight different preset references (0-7) in this parameter, using array programming. The preset reference is stated as a percentage of the value Ref_{MAX} (3-03 <i>Maximum Reference</i> , for closed loop see 20-14 <i>Maximum Reference/Feedb.</i>). When using preset references, select Preset ref. bit 0/1/2 [16], [17] or [18] for the corresponding digital inputs in parameter group 5-1* <i>Digital Inputs</i> .




Illustration 6.10




Illustration 6.11

3-15 Reference 1 Source		
Option:		Function:
		Select the reference input to be used for the first reference signal. <i>Parameter 3-15 Reference 1 Source</i> , <i>parameter 3-16 Reference 2 Source</i> and <i>3-17 Reference 3 Source</i> define up to 3 different reference signals. The sum of these reference signals defines the actual reference.
[0]	No function	
[1] *	Analog Input 53	
[2]	Analog Input 54	
[7]	Pulse input 29	
[8]	Pulse input 33	
[20]	Digital pot.meter	
[21]	Analog input X30/11	
[22]	Analog input X30/12	
[23]	Analog Input X42/1	
[24]	Analog Input X42/3	

3-15 Reference 1 Source		
Option:	Function:	
[25]	Analog Input X42/5	
[29]	Analog Input X48/2	
[30]	Ext. Closed Loop 1	
[31]	Ext. Closed Loop 2	
[32]	Ext. Closed Loop 3	

NOTICE

This parameter cannot be adjusted while the motor is running.

3-16 Reference 2 Source		
Option:	Function:	
		Select the reference input to be used for the second reference signal. <i>parameter 3-15 Reference 1 Source, parameter 3-16 Reference 2 Source and 3-17 Reference 3 Source</i> define up to 3 different reference signals. The sum of these reference signals defines the actual reference.
[0]	No function	
[1]	Analog Input 53	
[2]	Analog Input 54	
[7]	Pulse input 29	
[8]	Pulse input 33	
[20] *	Digital pot.meter	
[21]	Analog input X30/11	
[22]	Analog input X30/12	
[23]	Analog Input X42/1	
[24]	Analog Input X42/3	
[25]	Analog Input X42/5	
[29]	Analog Input X48/2	
[30]	Ext. Closed Loop 1	
[31]	Ext. Closed Loop 2	
[32]	Ext. Closed Loop 3	

NOTICE

This parameter cannot be adjusted while the motor is running.

4-10 Motor Speed Direction		
Option:	Function:	
		Selects the motor speed direction required. Use this parameter to prevent unwanted reversing.
[0]	Clockwise	Only operation in clockwise direction is allowed.
[2] *	Both directions	Operation in both clockwise and anti-clockwise direction is allowed.

NOTICE

The setting in *parameter 4-10 Motor Speed Direction* has impact on the Flying Start in *parameter 1-73 Flying Start*.

4-53 Warning Speed High		
Range:	Function:	
Size related*	[par. 4-52 - par. 4-13 RPM]	Enter the n _{HIGH} value. When the motor speed exceeds this limit (n _{HIGH}), the display reads SPEED HIGH. The signal outputs can be programmed to produce a status signal on terminal 27 or 29 and on relay output 01 or 02. Programme the upper signal limit of the motor speed, n _{HIGH} , within the normal working range of the frequency converter.

NOTICE

Any changes in *parameter 4-13 Motor Speed High Limit [RPM]* reset the value in *parameter 4-53 Warning Speed High* to the same value as set in *parameter 4-13 Motor Speed High Limit [RPM]*.

If a different value is needed in *parameter 4-53 Warning Speed High*, it must be set after programming of *parameter 4-13 Motor Speed High Limit [RPM]*

4-56 Warning Feedback Low		
Range:	Function:	
-999999.999 ProcessCtrlUnit*	[-999999.999 - par. 4-57 ProcessCtrlUnit]	Enter the lower feedback limit. When the feedback falls below this limit, the display reads Feedb _{Low} . The signal outputs can be programmed to produce a status signal on terminal 27 or 29 and on relay output 01 or 02.

4-57 Warning Feedback High		
Range:	Function:	
999999.999 ProcessCtrlUnit*	[par. 4-56 - 999999.999 ProcessCtrlUnit]	Enter the upper feedback limit. When the feedback exceeds this limit, the display reads Feedb _{High} . The signal outputs can be programmed to produce a status signal on terminal 27 or 29 and on relay output 01 or 02.

4-64 Semi-Auto Bypass Set-up		
Option:	Function:	
[0] *	Off	No function
[1]	Enabled	Starts the Semi-Automatic Bypass set-up and continue with the procedure described above.

5-01 Terminal 27 Mode		
Option:	Function:	
		NOTICE This parameter cannot be adjusted while the motor is running.
[0] *	Input	Defines terminal 27 as a digital input.
[1]	Output	Defines terminal 27 as a digital output.

5-02 Terminal 29 Mode		
Option:	Function:	
		NOTICE This parameter cannot be adjusted while the motor is running.
[0] *	Input	Defines terminal 29 as a digital input.
[1]	Output	Defines terminal 29 as a digital output.

6.1.4 5-1* Digital Inputs

Parameters for configuring the input functions for the input terminals.

The digital inputs are used for selecting various functions in the frequency converter. All digital inputs can be set to the following functions

Digital input function	Select	Terminal
No operation	[0]	All *terminal 19, 32, 33
Reset	[1]	All
Coast inverse	[2]	27
Coast and reset inverse	[3]	All
DC-brake inverse	[5]	All
Stop inverse	[6]	All
External interlock	[7]	All
Start	[8]	All *terminal 18
Latched start	[9]	All
Reversing	[10]	All
Start reversing	[11]	All
Jog	[14]	All *terminal 29
Preset reference on	[15]	All
Preset ref bit 0	[16]	All
Preset ref bit 1	[17]	All
Preset ref bit 2	[18]	All
Freeze reference	[19]	All
Freeze output	[20]	All
Speed up	[21]	All
Speed down	[22]	All
Set-up select bit 0	[23]	All
Set-up select bit 1	[24]	All
Pulse input	[32]	terminal 29, 33
Ramp bit 0	[34]	All

Digital input function	Select	Terminal
Mains failure inverse	[36]	All
Fire mode	[37]	All
Run Permissive	[52]	All
Hand start	[53]	All
Auto start	[54]	All
DigiPot Increase	[55]	All
DigiPot Decrease	[56]	All
DigiPot Clear	[57]	All
Counter A (up)	[60]	29, 33
Counter A (down)	[61]	29, 33
Reset Counter A	[62]	All
Counter B (up)	[63]	29, 33
Counter B (down)	[64]	29, 33
Reset Counter B	[65]	All
Sleep Mode	[66]	All
Reset Maintenance Word	[78]	All
PTC Card 1	[80]	All
Lead Pump Start	[120]	All
Lead Pump Alternation	[121]	All
Pump 1 Interlock	[130]	All
Pump 2 Interlock	[131]	All
Pump 3 Interlock	[132]	All

Table 6.7

5-12 Terminal 27 Digital Input

The parameter contains all options and functions listed in parameter group except for option [32] Pulse input.

5-13 Terminal 29 Digital Input

The parameter contains all options and functions listed in parameter group except for option [32] Pulse input.

5-14 Terminal 32 Digital Input

The parameter contains all options and functions listed in parameter group except for option [32] Pulse input.

5-15 Terminal 33 Digital Input

The parameter contains all options and functions listed in parameter group .

5-40 Function Relay

Array [8]
(Relay 1 [0], Relay 2 [1]
Option MCB 105: Relay 7 [6], Relay 8 [7] and Relay 9 [8]).
Select options to define the function of the relays.
The selection of each mechanical relay is realised in an array parameter.

Option: **Function:**

[0]	No operation	
[1]	Control Ready	
[2]	Drive ready	
[3]	Drive rdy/rem ctrl	
[4]	Standby / no warning	

5-40 Function Relay		
Array [8] (Relay 1 [0], Relay 2 [1]) Option MCB 105: Relay 7 [6], Relay 8 [7] and Relay 9 [8]. Select options to define the function of the relays. The selection of each mechanical relay is realised in an array parameter.		
Option:	Function:	
[5]	Running	Default setting for relay 2.
[6]	Running / no warning	
[8]	Run on ref/no warn	
[9]	Alarm	Default setting for relay 1.
[10]	Alarm or warning	
[11]	At torque limit	
[12]	Out of current range	
[13]	Below current, low	
[14]	Above current, high	
[15]	Out of speed range	
[16]	Below speed, low	
[17]	Above speed, high	
[18]	Out of feedb. range	
[19]	Below feedback, low	
[20]	Above feedback, high	
[21]	Thermal warning	
[25]	Reverse	
[26]	Bus OK	
[27]	Torque limit & stop	
[28]	Brake, no brake war	
[29]	Brake ready, no fault	
[30]	Brake fault (IGBT)	
[33]	Safe stop active	
[35]	External Interlock	
[36]	Control word bit 11	
[37]	Control word bit 12	
[40]	Out of ref range	
[41]	Below reference, low	
[42]	Above ref, high	
[45]	Bus ctrl.	
[46]	Bus ctrl, 1 if timeout	
[47]	Bus ctrl, 0 if timeout	
[60]	Comparator 0	
[61]	Comparator 1	
[62]	Comparator 2	
[63]	Comparator 3	
[64]	Comparator 4	
[65]	Comparator 5	
[70]	Logic rule 0	
[71]	Logic rule 1	
[72]	Logic rule 2	
[73]	Logic rule 3	
[74]	Logic rule 4	
[75]	Logic rule 5	

5-40 Function Relay		
Array [8] (Relay 1 [0], Relay 2 [1]) Option MCB 105: Relay 7 [6], Relay 8 [7] and Relay 9 [8]. Select options to define the function of the relays. The selection of each mechanical relay is realised in an array parameter.		
Option:	Function:	
[80]	SL digital output A	
[81]	SL digital output B	
[82]	SL digital output C	
[83]	SL digital output D	
[84]	SL digital output E	
[85]	SL digital output F	
[160]	No alarm	
[161]	Running reverse	
[165]	Local ref active	
[166]	Remote ref active	
[167]	Start command activ	
[168]	Hand / Off	
[169]	Auto mode	
[180]	Clock Fault	
[181]	Prev. Maintenance	
[188]	AHF Capacitor Connect	
[189]	External Fan Control	
[190]	No-Flow	
[191]	Dry Pump	
[192]	End Of Curve	
[193]	Sleep Mode	
[194]	Broken Belt	
[195]	Bypass Valve Control	
[196]	Fire Mode	
[197]	Fire Mode was Act.	
[198]	Drive Bypass	
[211]	Cascade Pump 1	
[212]	Cascade Pump 2	
[213]	Cascade Pump 3	

6-00 Live Zero Timeout Time		
Range:	Function:	
10 s*	[1 - 99 s]	Enter the Live Zero Time-out time period. Live Zero Time-out Time is active for analog inputs, i.e. terminal 53 or terminal 54, used as reference or feedback sources. If the reference signal value associated with the selected current input falls below 50% of the value set in <i>parameter 6-10 Terminal 53 Low Voltage</i> , <i>6-12 Terminal 53 Low Current</i> , <i>parameter 6-20 Terminal 54 Low Voltage</i> or <i>parameter 6-22 Terminal 54 Low Current</i> for a time period longer than the time set in <i>parameter 6-00 Live Zero Timeout Time</i> , the function selected in <i>parameter 6-01 Live Zero Timeout Function</i> is activated.

6-01 Live Zero Timeout Function		
Option:	Function:	
	<p>Select the time-out function. The function set in <i>parameter 6-01 Live Zero Timeout Function</i> is activated if the input signal on terminal 53 or 54 is below 50% of the value in <i>parameter 6-10 Terminal 53 Low Voltage</i>, <i>6-12 Terminal 53 Low Current</i>, <i>parameter 6-20 Terminal 54 Low Voltage</i> or <i>parameter 6-22 Terminal 54 Low Current</i> for a time period defined in <i>parameter 6-00 Live Zero Timeout Time</i>. If several time-outs occur simultaneously, the frequency converter prioritises the time-out functions as follows</p> <ol style="list-style-type: none"> 1. <i>Parameter 6-01 Live Zero Timeout Function</i> 2. <i>8-04 Control Timeout Function</i> <p>The output frequency of the frequency converter can be:</p> <ul style="list-style-type: none"> • [1] frozen at the present value • [2] overruled to stop • [3] overruled to jog speed • [4] overruled to max. speed • [5] overruled to stop with subsequent trip 	
[0] *	Off	
[1]	Freeze output	
[2]	Stop	
[3]	Jogging	
[4]	Max. speed	
[5]	Stop and trip	

6-10 Terminal 53 Low Voltage		
Range:	Function:	
0.07 V* [0 - par. 6-11 V]	Enter the low voltage value. This analog input scaling value should correspond to the low reference/feedback value set in <i>parameter 6-14 Terminal 53 Low Ref./Feedb. Value</i> .	

6-11 Terminal 53 High Voltage		
Range:	Function:	
10 V* [par. 6-10 - 10 V]	Enter the high voltage value. This analog input scaling value should correspond to the high reference/feedback value set in <i>parameter 6-15 Terminal 53 High Ref./Feedb. Value</i> .	

6-14 Terminal 53 Low Ref./Feedb. Value		
Range:	Function:	
0* [-999999.999 - 999999.999]	Enter the analog input scaling value that corresponds to the low voltage/low current set in <i>parameter 6-10 Terminal 53 Low Voltage</i> and <i>6-12 Terminal 53 Low Current</i> .	

6-15 Terminal 53 High Ref./Feedb. Value		
Range:	Function:	
Size related* [-999999.999 - 999999.999]	Enter the analog input scaling value that corresponds to the high voltage/high current value set in <i>parameter 6-11 Terminal 53 High Voltage</i> and <i>6-13 Terminal 53 High Current</i> .	

6-16 Terminal 53 Filter Time Constant		
Range:	Function:	
0.001 s* [0.001 - 10 s]	<p>NOTICE</p> <p>This parameter cannot be adjusted while the motor is running.</p> <p>Enter the time constant. This is a first-order digital low pass filter time constant for suppressing electrical noise in terminal 53. A high time constant value improves dampening but also increases the time delay through the filter.</p>	




Illustration 6.12

6-17 Terminal 53 Live Zero		
Option:	Function:	
		This parameter makes it possible to disable the Live Zero monitoring. E.g. to be used if the analog outputs are used as of a de-central I/O system (e.g. when not as of any frequency converter related control functions, but feeding a Building Management system with data).
[0]	Disabled	
[1] *	Enabled	

6-20 Terminal 54 Low Voltage		
Range:	Function:	
0.07 V* [0 - par. 6-21 V]		Enter the low voltage value. This analog input scaling value should correspond to the low reference/feedback value, set in <i>parameter 6-24 Terminal 54 Low Ref./Feedb. Value</i> .

6-21 Terminal 54 High Voltage		
Range:	Function:	
10 V* [par. 6-20 - 10 V]		Enter the high voltage value. This analog input scaling value should correspond to the high reference/feedback value set in <i>parameter 6-25 Terminal 54 High Ref./Feedb. Value</i> .

6-24 Terminal 54 Low Ref./Feedb. Value		
Range:	Function:	
0* [-999999.999 - 999999.999]		Enter the analog input scaling value that corresponds to the low voltage/low current value set in <i>parameter 6-20 Terminal 54 Low Voltage</i> and <i>parameter 6-22 Terminal 54 Low Current</i> .

6-25 Terminal 54 High Ref./Feedb. Value		
Range:	Function:	
100* [-999999.999 - 999999.999]		Enter the analog input scaling value that corresponds to the high voltage/high current value set in <i>parameter 6-21 Terminal 54 High Voltage</i> and <i>parameter 6-23 Terminal 54 High Current</i> .

6-26 Terminal 54 Filter Time Constant		
Range:	Function:	
0.001 s* [0.001 - 10 s]		NOTICE This parameter cannot be adjusted while the motor is running. Enter the time constant. This is a first-order digital low pass filter time constant for suppressing electrical noise in terminal

6-26 Terminal 54 Filter Time Constant		
Range:	Function:	
		54. A high time constant value improves dampening but also increases the time delay through the filter.

6-27 Terminal 54 Live Zero		
Option:	Function:	
		This parameter makes it possible to disable the Live Zero monitoring. E.g. to be used if the analog outputs are used as of a de-central I/O system (e.g. when not as of any frequency converter related control functions, but feeding a Building Management System with data).
[0]	Disabled	
[1] *	Enabled	

6-50 Terminal 42 Output		
Option:	Function:	
		Select the function of Terminal 42 as an analog current output. A motor current of 20 mA corresponds to I_{max} .
[0]	No operation	
[100]	Output freq. 0-100	0-100 Hz, (0-20 mA)
[101]	Reference Min-Max	Minimum reference - Maximum reference, (0-20 mA)
[102]	Feedback +-200%	-200% to +200% of 20-14 Maximum Reference/Feedb., (0-20 mA)
[103]	Motor cur. 0-Imax	0 - Inverter Max. Current (16-37 Inv. Max. Current), (0-20 mA)
[104]	Torque 0-Tlim	0 - Torque limit (4-16 Torque Limit Motor Mode), (0-20 mA)
[105]	Torque 0-Tnom	0 - Motor rated torque, (0-20 mA)
[106]	Power 0-Pnom	0 - Motor rated power, (0-20 mA)
[107]	Speed 0-HighLim	0 - Speed High Limit (parameter 4-13 Motor Speed High Limit [RPM] and parameter 4-14 Motor Speed High Limit [Hz]), (0-20 mA)
[113]	Ext. Closed Loop 1	0-100%, (0-20 mA)
[114]	Ext. Closed Loop 2	0-100%, (0-20 mA)
[115]	Ext. Closed Loop 3	0-100%, (0-20 mA)
[130]	Out frq 0-100 4-20mA	0-100 Hz
[131]	Reference 4-20mA	Minimum Reference - Maximum Reference
[132]	Feedback 4-20mA	-200% to +200% of 20-14 Maximum Reference/Feedb.

6-50 Terminal 42 Output		
Option:	Function:	
[133] Motor cur. 4-20mA	0 - Inverter Max. Current (16-37 Inv. Max. Current)	
[134] Torq.0-lim 4-20 mA	0 - Torque limit (4-16 Torque Limit Motor Mode)	
[135] Torq.0-nom 4-20mA	0 - Motor rated torque	
[136] Power 4-20mA	0 - Motor rated power	
[137] Speed 4-20mA	0 - Speed High Limit (4-13 and 4-14)	
[139] Bus ctrl.	0-100%, (0-20 mA)	
[140] Bus ctrl. 4-20 mA	0-100%	
[141] Bus ctrl t.o.	0-100%, (0-20 mA)	
[142] Bus ctrl t.o. 4-20mA	0-100%	
[143] Ext. CL 1 4-20mA	0-100%	
[144] Ext. CL 2 4-20mA	0-100%	
[145] Ext. CL 3 4-20mA	0-100%	

NOTICE

Values for setting the Minimum Reference is found in open loop *parameter 3-02 Minimum Reference* and for closed loop *20-13 Minimum Reference/Feedb.* - values for maximum reference for open loop is found in *3-03 Maximum Reference* and for closed loop *20-14 Maximum Reference/Feedb.*

6-51 Terminal 42 Output Min Scale		
Range:	Function:	
0 %* [0 - 200 %]	Scale for the minimum output (0 or 4 mA) of the analog signal at terminal 42. Set the value to be the percentage of the full range of the variable selected in <i>parameter 6-50 Terminal 42 Output.</i>	

6-52 Terminal 42 Output Max Scale		
Range:	Function:	
100 %* [0 - 200 %]	Scale for the maximum output (20mA) of the analog signal at terminal 42. Set the value to be the percentage of the full range of the variable selected in <i>parameter 6-50 Terminal 42 Output.</i>	

6-52 Terminal 42 Output Max Scale	
Range:	Function:
	<p>Illustration 6.13</p> <p>It is possible to get a value lower than 20mA at full scale by programming values >100% by using a formula as follows:</p>

$20 \text{ mA} / \text{desired maximum current} \times 100\%$

i.e. $10 \text{ mA} : \frac{20 \text{ mA}}{10 \text{ mA}} \times 100\% = 200\%$

Example 1:

Variable= OUTPUT FREQUENCY, range = 0-100 Hz

Range needed for output = 0-50 Hz

Output signal 0 or 4mA is needed at 0 Hz (0% of range) -

set *parameter 6-51 Terminal 42 Output Min Scale* to 0%

Output signal 20 mA is needed at 50 Hz (50% of range) -

set *parameter 6-52 Terminal 42 Output Max Scale* to 50%




Illustration 6.14

Example 2:

Variable= FEEDBACK, range= -200% to +200%

Range needed for output= 0-100%

Output signal 0 or 4 mA is needed at 0% (50% of range) -

set *parameter 6-51 Terminal 42 Output Min Scale* to 50%

Output signal 20 mA is needed at 100% (75% of range) -

set *parameter 6-52 Terminal 42 Output Max Scale* to 75%




Illustration 6.15

Example 3:

Variable value= REFERENCE, range= Min ref - Max ref
 Range needed for output= Min ref (0%) - Max ref (100%), 0-10 mA
 Output signal 0 or 4 mA is needed at Min ref - set parameter 6-51 Terminal 42 Output Min Scale to 0%
 Output signal 10 mA is needed at Max ref (100% of range) - set parameter 6-52 Terminal 42 Output Max Scale to 200% (20 mA/10 mA x 100%=200%).




Illustration 6.16

14-01 Switching Frequency	
Option:	Function:
	Select the inverter switching frequency. Changing the switching frequency can help to reduce acoustic noise from the motor.

14-01 Switching Frequency	
Option:	Function:
	NOTICE The output frequency value of the frequency converter must never exceed 1/10 of the switching frequency. When the motor is running, adjust the switching frequency in parameter 14-01 Switching Frequency until the motor is as noiseless as possible. See also 14-00 Switching Pattern and the section Derating.
[0]	1.0 kHz
[1]	1.5 kHz
[2]	2.0 kHz
[3]	2.5 kHz
[4]	3.0 kHz
[5]	3.5 kHz
[6]	4.0 kHz
[7]	5.0 kHz
[8]	6.0 kHz
[9]	7.0 kHz
[10]	8.0 kHz
[11]	10.0 kHz
[12]	12.0kHz
[13]	14.0 kHz
[14]	16.0kHz

6

20-00 Feedback 1 Source	
Option:	Function:
	Up to three different feedback signals can be used to provide the feedback signal for the frequency converter's PID Controller. This parameter defines which input will be used as the source of the first feedback signal. Analog input X30/11 and Analog input X30/12 refer to inputs on the optional General Purpose I/O board.
[0]	No function
[1]	Analog Input 53
[2] *	Analog Input 54
[3]	Pulse input 29
[4]	Pulse input 33
[7]	Analog Input X30/11
[8]	Analog Input X30/12
[9]	Analog Input X42/1
[10]	Analog Input X42/3
[11]	Analog Input X42/5
[15]	Analog Input X48/2
[100]	Bus Feedback 1
[101]	Bus Feedback 2
[102]	Bus feedback 3

20-00 Feedback 1 Source		
Option:	Function:	
[104]	Sensorless Flow	Requires set up by MCT 10 Set-up Software with sensorless specific plug in.
[105]	Sensorless Pressure	Requires set up by MCT 10 Set-up Software with sensorless specific plug in.

NOTICE

If a feedback is not used, its source must be set to [0] No Function. Parameter 20-20 Feedback Function determines how the three possible feedbacks will be used by the PID Controller.

20-01 Feedback 1 Conversion		
Option:	Function:	
		This parameter allows a conversion function to be applied to Feedback 1.
[0]	Linear	No effect on the feedback.
[1]	Square root	Commonly used when a pressure sensor is used to provide flow feedback (($flow \propto \sqrt{pressure}$)).
[2]	Pressure to temperature	Used in compressor applications to provide temperature feedback using a pressure sensor. The temperature of the refrigerant is calculated using the following formula: $Temperature = \frac{A2}{(\ln(Pe+1) - A1)} - A3,$ where A1, A2 and A3 are refrigerant-specific constants. The refrigerant must be selected in 20-30 Refrigerant. Parameter 20-21 Setpoint 1 through 20-23 Setpoint 3 allow the values of A1, A2 and A3 to be entered for a refrigerant that is not listed in 20-30 Refrigerant.
[3]	Pressure to flow	Used in applications where the air flow in a duct is to be controlled. The feedback signal is represented by a dynamic pressure measurement (pitot tube). $Flow = Duct\ Area \times \sqrt{Dynamic\ Pressure}$ × Air Density Factor See also 20-34 Duct 1 Area [m2] through 20-38 Air Density Factor [%] for setting of duct area and air density.
[4]	Velocity to flow	Used in applications where the air flow in a duct is to be controlled. The feedback signal is represented by an air velocity measurement. $Flow = Duct\ Area \times Air\ Velocity$ See also 20-34 Duct 1 Area [m2] through 20-37 Duct 2 Area [in2] for setting of duct area.

20-03 Feedback 2 Source		
Option:	Function:	
		See parameter 20-00 Feedback 1 Source for details.
[0] *	No function	
[1]	Analog Input 53	
[2]	Analog Input 54	
[3]	Pulse input 29	
[4]	Pulse input 33	
[7]	Analog Input X30/11	
[8]	Analog Input X30/12	
[9]	Analog Input X42/1	
[10]	Analog Input X42/3	
[11]	Analog Input X42/5	
[15]	Analog Input X48/2	
[100]	Bus Feedback 1	
[101]	Bus Feedback 2	
[102]	Bus feedback 3	
[104]	Sensorless Flow	
[105]	Sensorless Pressure	

20-04 Feedback 2 Conversion		
Option:	Function:	
		See parameter 20-01 Feedback 1 Conversion for details.
[0] *	Linear	
[1]	Square root	
[2]	Pressure to temperature	
[3]	Pressure to flow	
[4]	Velocity to flow	

20-06 Feedback 3 Source		
Option:	Function:	
		See parameter 20-00 Feedback 1 Source for details.
[0] *	No function	
[1]	Analog Input 53	
[2]	Analog Input 54	
[3]	Pulse input 29	
[4]	Pulse input 33	
[7]	Analog Input X30/11	
[8]	Analog Input X30/12	
[9]	Analog Input X42/1	
[10]	Analog Input X42/3	
[11]	Analog Input X42/5	
[15]	Analog Input X48/2	
[100]	Bus Feedback 1	
[101]	Bus Feedback 2	
[102]	Bus feedback 3	
[104]	Sensorless Flow	
[105]	Sensorless Pressure	

20-07 Feedback 3 Conversion	
Option:	Function:
	See <i>parameter 20-01 Feedback 1 Conversion</i> for details.
[0] *	Linear
[1]	Square root
[2]	Pressure to temperature
[3]	Pressure to flow
[4]	Velocity to flow

20-20 Feedback Function	
Option:	Function:
	This parameter determines how the 3 possible feedbacks are used to control the output frequency of the frequency converter.
[0]	<p>Sum</p> <p>Sets up the PID Controller to use the sum of Feedback 1, Feedback 2 and Feedback 3 as the feedback.</p> <p>NOTICE</p> <p>Any unused feedbacks must be set to <i>No Function</i> in <i>parameter 20-00 Feedback 1 Source</i>, <i>parameter 20-03 Feedback 2 Source</i>, or <i>parameter 20-06 Feedback 3 Source</i>.</p> <p>The sum of Setpoint 1 and any other references that are enabled (see <i>parameter group 3-1* References</i>) are used as the PID Controller's set-point reference.</p>
[1]	<p>Difference</p> <p>Sets up the PID controller to use the difference between Feedback 1 and Feedback 2 as the feedback. Feedback 3 is not used with this selection. Only Setpoint 1 is used. The sum of Setpoint 1 and any other references that are enabled (see <i>parameter group 3-1* References</i>) are used as the PID controller's set-point reference.</p>
[2]	<p>Average</p> <p>Sets up the PID Controller to use the average of Feedback 1, Feedback 2 and Feedback 3 as the feedback.</p> <p>NOTICE</p> <p>Any unused feedbacks must be set to <i>No Function</i> in <i>parameter 20-00 Feedback 1 Source</i>, <i>parameter 20-03 Feedback 2 Source</i>, or <i>parameter 20-06 Feedback 3 Source</i>. The sum of Setpoint 1 and any other references that are enabled (see <i>parameter group 3-1* References</i>) are used as the PID Controller's set-point reference.</p>
[3] *	<p>Minimum</p> <p>Sets up the PID Controller to com Feedback 1, Feedback 2 and Feedback 3 and uses the lowest value as the feedback.</p>

20-20 Feedback Function	
Option:	Function:
	<p>NOTICE</p> <p>Any unused feedbacks must be set to <i>No Function</i> in <i>parameter 20-00 Feedback 1 Source</i>, <i>parameter 20-03 Feedback 2 Source</i>, or <i>parameter 20-06 Feedback 3 Source</i>. Only setpoint 1 is used. The sum of Setpoint 1 and any other references that are enabled (see <i>parameter group 3-1* References</i>) are used as the PID Controller's setpoint reference.</p>
[4]	<p>Maximum</p> <p>Sets up the PID Controller to com Feedback 1, Feedback 2 and Feedback 3 and use the highest value as the feedback.</p> <p>NOTICE</p> <p>Any unused feedbacks must be set to <i>No Function</i> in <i>parameter 20-00 Feedback 1 Source</i>, <i>parameter 20-03 Feedback 2 Source</i>, or <i>parameter 20-06 Feedback 3 Source</i>.</p> <p>Only Setpoint 1 is used. The sum of Setpoint 1 and any other references that are enabled (see <i>parameter group 3-1* References</i>) are used as the PID Controller's setpoint reference.</p>
[5]	<p>Multi Setpoint Min</p> <p>Sets up the PID Controller to calculate the difference between Feedback 1 and Setpoint 1, Feedback 2 and Setpoint 2, and Feedback 3 and Setpoint 3. It uses the feedback/setpoint pair in which the feedback is the farthest below its corresponding setpoint reference. If all feedback signals are above their corresponding setpoints, the PID Controller uses the feedback/setpoint pair in which the difference between the feedback and setpoint is the least.</p> <p>NOTICE</p> <p>If only 2 feedback signals are used, the feedback that is not to be used must be set to [0] <i>No Function</i> in <i>parameter 20-00 Feedback 1 Source</i>, <i>parameter 20-03 Feedback 2 Source</i> or <i>parameter 20-06 Feedback 3 Source</i>. Note that each setpoint reference is the sum of its respective parameter value (<i>parameter 20-21 Setpoint 1</i>, <i>parameter 20-22 Setpoint 2</i> and <i>20-23 Setpoint 3</i>) and any other references that are enabled (see <i>parameter group 3-1* References</i>).</p>

20-20 Feedback Function		
Option:	Function:	
[6] Multi Setpoint Max	<p>Sets up the PID Controller to calculate the difference between Feedback 1 and Setpoint 1, Feedback 2 and Setpoint 2, and Feedback 3 and Setpoint 3. It uses the feedback/setpoint pair in which the feedback is farthest above its corresponding setpoint reference. If all feedback signals are below their corresponding setpoints, the PID Controller uses the feedback/setpoint pair in which the difference between the feedback and the setpoint reference is the least.</p> <p>NOTICE</p> <p>If only 2 feedback signals are used, the feedback that is not to be used must be set to [0] No Function in parameter 20-00 Feedback 1 Source, parameter 20-03 Feedback 2 Source or parameter 20-06 Feedback 3 Source. Note that each setpoint reference will be the sum of its respective parameter value (parameter 20-21 Setpoint 1, parameter 20-22 Setpoint 2 and 20-23 Setpoint 3) and any other references that are enabled (see parameter group 3-1* References).</p>	

NOTICE

Any unused feedback must be set to [0] No function in its Feedback Source parameter:
 Parameter 20-00 Feedback 1 Source,
 parameter 20-03 Feedback 2 Source or
 parameter 20-06 Feedback 3 Source.

The feedback resulting from the function selected in parameter 20-20 Feedback Function is used by the PID Controller to control the output frequency of the frequency converter. This feedback can also be shown on the frequency converter's display, be used to control a frequency converter's analog output, and be transmitted over various serial communication protocols.

The frequency converter can be configured to handle multi zone applications. 2 different multi-zone applications are supported:

- Multi zone, single setpoint
- Multi zone, multi setpoint

The difference between the 2 is illustrated by the following examples:

Example 1 – Multi zone, single setpoint

In an office building, a VAV (variable air volume) VLT HVAC Drive system must ensure a minimum pressure at selected VAV boxes. Due to the varying pressure losses in each duct, the pressure at each VAV box cannot be assumed to be the same. The minimum pressure required is the same for all VAV boxes. This control method can be set up by setting parameter 20-20 Feedback Function to option [3], Minimum, and entering the desired pressure in parameter 20-21 Setpoint 1. The PID Controller increases the speed of the fan if any one feedback is below the setpoint and decrease the speed of the fan if all feedbacks are above the setpoint.




Illustration 6.17

130BA353.10

Example 2 – Multi zone, multi setpoint

The previous example can be used to illustrate the use of multi zone, multi setpoint control. If the zones require different pressures for each VAV box, each setpoint may be specified in *parameter 20-21 Setpoint 1*, *parameter 20-22 Setpoint 2* and *20-23 Setpoint 3*. By selecting [5] *Multi setpoint minimum* in *parameter 20-20 Feedback Function*, the PID Controller increases the speed of the fan if any one of the feedbacks is below its setpoint and decrease the speed of the fan if all feedbacks are above their individual setpoints.

20-21 Setpoint 1		
Range:	Function:	
0 ProcessCtrlUnit*	[-999999.999 - 999999.999 ProcessCtrlUnit]	Setpoint 1 is used in Closed Loop Mode to enter a setpoint reference that is used by the frequency converter's PID Controller. See the description of <i>parameter 20-20 Feedback Function</i> . NOTICE The setpoint reference entered here is added to any other references that are enabled (see <i>parameter group 3-1* References</i>).

20-22 Setpoint 2		
Range:	Function:	
0 ProcessCtrlUnit*	[-999999.999 - 999999.999 ProcessCtrlUnit]	Setpoint 2 is used in Closed Loop Mode to enter a setpoint reference that may be used by the frequency converter's PID Controller. See the description of <i>Feedback Function</i> , <i>parameter 20-20 Feedback Function</i> . NOTICE The setpoint reference entered here is added to any other references that are enabled (see <i>parameter group 3-1* References</i>).

20-81 PID Normal/ Inverse Control		
Option:	Function:	
[0] *	Normal	The frequency converter's output frequency decreases when the feedback is greater than the

20-81 PID Normal/ Inverse Control		
Option:	Function:	
		setpoint reference. This is common for pressure-controlled supply fan and pump applications.
[1]	Inverse	The frequency converter's output frequency increases when the feedback is greater than the setpoint reference. This is common for temperature-controlled cooling applications, such as cooling towers.

20-93 PID Proportional Gain		
Range:	Function:	
0.50*	[0 - 10]	The proportional gain indicates the number of times the error between the set point and the feedback signal is to be applied.

If (Error x Gain) jumps with a value equal to what is set in *20-14 Maximum Reference/Feedb*. the PID controller tries to change the output speed equal to what is set in *parameter 4-13 Motor Speed High Limit [RPM]/ parameter 4-14 Motor Speed High Limit [Hz]* but in practice of course limited by this setting.

The proportional band (error causing output to change from 0-100%) can be calculated by means of the formula

$$\left(\frac{1}{\text{Proportional Gain}}\right) \times (\text{Max Reference})$$

NOTICE

Always set the desired for *20-14 Maximum Reference/ Feedb*. before setting the values for the PID controller in *parameter group 20-9* PID Controller*.

20-94 PID Integral Time		
Range:	Function:	
20 s*	[0.01 - 10000 s]	Over time, the integrator accumulates a contribution to the output from the PID controller as long as there is a deviation between the Reference/Setpoint and feedback signals. The contribution is proportional to the size of the deviation. This ensures that the deviation (error) approaches zero. Quick response on any deviation is obtained when the integral time is set to a low value. Setting it too low, however, may cause the control to become unstable. The value set, is the time needed for the integrator to add the same contribution as the proportional for a certain deviation. If the value is set to 10,000, the controller acts as a pure proportional controller with a P-band based on the value set in <i>parameter 20-93 PID Proportional Gain</i> . When no deviation is present, the output from the proportional controller is 0.

22-21 Low Power Detection		
Option:	Function:	
[0] *	Disabled	
[1]	Enabled	The Low Power Detection commissioning must be carried out to set the parameters in parameter group 22-3* <i>No-Flow Power Tuning</i> for proper operation.

22-22 Low Speed Detection		
Option:	Function:	
[0] *	Disabled	
[1]	Enabled	Detects when the motor operates with a speed as set in <i>parameter 4-11 Motor Speed Low Limit [RPM]</i> or <i>parameter 4-12 Motor Speed Low Limit [Hz]</i> .

22-23 No-Flow Function		
Common actions for Low Power Detection and Low Speed Detection (Individual selections not possible).		
Option:	Function:	
[0] *	Off	
[1]	Sleep Mode	The frequency converter enters Sleep Mode and stops when a No Flow condition is detected. See parameter group 22-4* <i>Sleep Mode</i> for programming options for Sleep Mode.
[2]	Warning	The frequency converter continues to run, but activates a No-Flow Warning [W92]. A digital output or a serial communication bus can communicate a warning to other equipment.
[3]	Alarm	The frequency converter stops running and activates a No-Flow Alarm [A 92]. A frequency converter digital output or a serial communication bus can communicate an alarm to other equipment.

NOTICE

Do not set 14-20 *Reset Mode*, to [13] *Infinite auto reset*, when *parameter 22-23 No-Flow Function* is set to [3] *Alarm*. Doing so causes the frequency converter to continuously cycle between running and stopping when a No Flow condition is detected.

NOTICE

If the frequency converter is equipped with a constant speed bypass with an automatic bypass function that starts the bypass if the frequency converter experiences a persistent alarm condition, be sure to disable the bypass's automatic bypass function, if [3] *Alarm* is selected as the No-Flow Function.

22-24 No-Flow Delay		
Range:	Function:	
10 s*	[1 - 600 s]	Set the time Low Power/Low Speed must stay detected to activate signal for actions. If detection disappears before run out of the timer, the timer is reset.

22-26 Dry Pump Function		
Select desired action for dry pump operation.		
Option:	Function:	
[0] *	Off	
[1]	Warning	The frequency converter continues to run, but activates a Dry pump warning [W93]. A frequency converter digital output or a serial communication bus can communicate a warning to other equipment.
[2]	Alarm	The frequency converter stops running and activates a Dry pump alarm [A93]. A frequency converter digital output or a serial communication bus can communicate an alarm to other equipment.
[3]	Man. Reset Alarm	The frequency converter stops running and activates a Dry pump alarm [A93]. A frequency converter digital output or a serial communication bus can communicate an alarm to other equipment.

NOTICE

Low Power Detection must be Enabled (*parameter 22-21 Low Power Detection*) and commissioned (using either parameter group 22-3* *No-flow Power Tuning No Flow Power Tuning*, or 22-20 *Low Power Auto Set-up*) to use Dry Pump Detection.

NOTICE

Do not set 14-20 *Reset Mode*, to [13] *Infinite auto reset*, when *parameter 22-26 Dry Pump Function* is set to [2] *Alarm*. Doing so causes the frequency converter to continuously cycle between running and stopping when a Dry Pump condition is detected.

NOTICE

If the frequency converter is equipped with a constant speed bypass with an automatic bypass function that starts the bypass if the frequency converter experiences a persistent alarm condition, be sure to disable the bypass's automatic bypass function, if [2] *Alarm* or [3] *Man. Reset Alarm* is selected as the Dry Pump Function.

22-40 Minimum Run Time		
Range:	Function:	
10 s* [0 - 600 s]	Set the desired minimum running time for the motor after a start command (digital input or Bus) before entering Sleep Mode.	

22-41 Minimum Sleep Time		
Range:	Function:	
10 s* [0 - 600 s]	Set the desired Minimum Time for staying in Sleep Mode. This overrides any wake up conditions.	

22-42 Wake-up Speed [RPM]		
Range:	Function:	
Size related* [par. 4-11 - par. 4-13 RPM]	To be used if 0-02 Motor Speed Unit has been set for RPM (parameter not visible if Hz selected). Only to be used if parameter 1-00 Configuration Mode is set for open loop and speed reference is applied by an external controller. Set the reference speed at which the Sleep Mode should be cancelled.	

22-60 Broken Belt Function		
Selects the action to be performed if the Broken Belt condition is detected		
Option:	Function:	
[0] * Off		
[1] Warning	The frequency converter will continue to run, but activate a Broken Belt Warning [W95]. A frequency converter digital output or a serial communication bus can communicate a warning to other equipment.	
[2] Trip	The frequency converter will stop running and activate a Broken Belt alarm [A 95]. A frequency converter digital output or a serial communication bus can communicate an alarm to other equipment.	

NOTICE

Do not set 14-20 Reset Mode, to [13] Infinite auto reset, when parameter 22-60 Broken Belt Function is set to [2] Trip. Doing so will cause the frequency converter to continuously cycle between running and stopping when a broken belt condition is detected.

NOTICE

If the frequency converter is equipped with a constant speed bypass with an automatic bypass function that starts the bypass if the frequency converter experiences a persistent alarm condition, be sure to disable the bypass's automatic bypass function, if [2] Trip is selected as the Broken Belt Function.

22-61 Broken Belt Torque		
Range:	Function:	
10 %* [0 - 100 %]	Sets the broken belt torque as a percentage of the rated motor torque.	

22-62 Broken Belt Delay		
Range:	Function:	
10 s [0 - 600 s]	Sets the time for which the Broken Belt conditions must be active before carrying out the action selected in parameter 22-60 Broken Belt Function.	

22-75 Short Cycle Protection		
Option:	Function:	
[0] * Disabled	Timer set in parameter 22-76 Interval between Starts is disabled.	
[1] Enabled	Timer set in parameter 22-76 Interval between Starts is enabled.	

22-76 Interval between Starts		
Range:	Function:	
Size related* [par. 22-77 - 3600 s]	Sets the time desired as minimum time between 2 starts. Any normal start command (Start/Jog/Freeze) is disregarded until the timer has expired.	

22-77 Minimum Run Time		
Range:	Function:	
0 s* [0 - par. 22-76 s]	Sets the time desired as minimum run time after a normal start command (start/jog/freeze). Any normal stop command is disregarded until the set time has expired. The timer starts counting following a normal start command (start/jog/freeze). The timer is overridden by a coast (inverse) or an external interlock command.	

NOTICE

Does not work in cascade mode.

6.1.5 Main Menu Mode

Both the GLCP and NLCP provide access to the main menu mode. Select the Main Menu mode by pressing the [Main Menu] key. *Illustration 6.18* shows the resulting read-out, which appears on the display of the GLCP.

Lines 2 through 5 on the display show a list of parameter groups which can be selected by toggling the up and down keys.




Illustration 6.18 Display Example

Each parameter has a name and number which remain the same regardless of the programming mode. In the Main Menu mode, the parameters are divided into groups. The first digit of the parameter number (from the left) indicates the parameter group number.

All parameters can be changed in the Main Menu. The configuration of the unit (*parameter 1-00 Configuration Mode*) determines other parameters available for programming. For example, selecting closed loop enables additional parameters related to closed loop operation. Option cards added to the unit enable additional parameters associated with the option device.

6.1.6 Parameter Selection

In the Main Menu mode, the parameters are divided into groups. Select a parameter group by means of the navigation keys.

The following parameter groups are accessible:

Group no.	Parameter group
0-**	Operation/Display
1-**	Load/Motor
2-**	Brakes
3-**	References/Ramps
4-**	Limits/Warnings
5-**	Digital In/Out
6-**	Analog In/Out
8-**	Comm. and Options
9-**	Profibus
10-**	CAN Fieldbus
11-**	LonWorks
13-**	Smart Logic

Group no.	Parameter group
14-**	Special Functions
15-**	FC Information
16-**	Data Readouts
18-**	Data Readouts 2
20-**	FC Closed Loop
21-**	Ext. Closed Loop
22-**	Application Functions
23-**	Time Actions
25-**	Cascade Controller
26-**	Analog I/O Option MCB 109
27-**	Cascade CTL Option
29-**	Water Application Functions
31-**	Bypass Option

Table 6.8 Parameter Groups

After selecting a parameter group, select a parameter with the navigation keys.

The middle section on the GLCP display shows the parameter number and name as well as the selected parameter value.





Illustration 6.19 Display Example

6.1.7 Changing Data

1. Press [Quick Menu] or [Main Menu] key.
2. Press [▲] and [▼] to find parameter group to edit.
3. Press [OK] key.
4. Press [▲] and [▼] to find parameter to edit.
5. Press [OK] key.
6. Press [▲] and [▼] to select correct parameter setting. Or, to move to digits within a number, press keys. Cursor indicates digit selected to change. [▲] increases the value, [▼] decreases the value.
7. Press [Cancel] to disregard change, or press [OK] to accept change and enter new setting.

6.1.8 Changing a Text Value

If the selected parameter is a text value, change the text value with the [▲]/[▼] keys. [▲] increases the value, and [▼] decreases the value. Place the cursor on the value to be saved and press [OK].




130BP068.10

Illustration 6.20 Display Example

6.1.9 Changing a Group of Numeric Data Values


If the selected parameter represents a numeric data value, change the selected data value with the [◀] and [▶] keys as well as the up/down [▲] [▼] keys. Press [◀] and [▶] to move the cursor horizontally.



130BP069.10

Illustration 6.21 Display Example

Press [▲] and [▼] to change the data value. [▲] increases the data value, and [▼] decreases the data value. Place the cursor on the value to be saved and press [OK].



130BP070.10

Illustration 6.22 Display Example

6.1.10 Changing of Data Value, Step-by-Step

Certain parameters can be changed step by step or infinitely variably. This applies to *parameter 1-20 Motor Power [kW]*, *parameter 1-22 Motor Voltage* and *parameter 1-23 Motor Frequency*.

The parameters are changed both as a group of numeric data values and as numeric data values infinitely variably.

6.1.11 Read-out and Programming of Indexed Parameters

Parameters are indexed when placed in a rolling stack. *15-30 Alarm Log: Error Code* to *15-32 Alarm Log: Time* contain a fault log which can be read out. Select a parameter, press [OK], and use [▲] and [▼] to scroll through the value log.

Use *parameter 3-10 Preset Reference* as another example: Select the parameter, press [OK], and use [▲] and [▼] to scroll through the indexed values. To change the parameter value, select the indexed value and press [OK]. Change the value by [▲] and [▼]. Press [OK] to accept the new setting. Press [Cancel] to abort. Press [Back] to leave the parameter.

6.2 Parameter Menu Structure

0-0*	0-1*	0-2*	0-3*	0-4*	0-5*	0-6*	0-7*	0-8*	0-9*	1-0*	1-1*	1-2*	1-3*	1-4*	1-5*	1-6*	1-7*	1-8*	1-9*	2-0*	2-1*	2-2*	2-3*	2-4*	2-5*	2-6*	2-7*	2-8*	2-9*	3-0*	3-1*	3-2*	3-3*	3-4*	3-5*	3-6*	3-7*	3-8*	3-9*	4-0*	4-1*	4-2*	4-3*	4-4*	4-5*	4-6*	4-7*	4-8*	4-9*	5-0*	5-1*	5-2*	5-3*	5-4*	5-5*	5-6*	5-7*	5-8*	5-9*	6-0*	6-1*	6-2*	6-3*	6-4*	6-5*	6-6*	6-7*	6-8*	6-9*			
Operation / Display	Torque Characteristics	Thermistor Source	Max Output Frequency	Pulse Output Max Freq #X30/6	Basic Settings	Clockwise Direction	Motor Selection	DC-Brake	Adj. Warnings	Warning Current Low	Warning Current High	Warning Speed High	Warning Reference Low	Warning Reference High	Warning Feedback Low	Warning Feedback High	Missing Motor Phase Function	Speed Bypass	Bypass Speed From [RPM]	Bypass Speed From [Hz]	Bypass Speed To [RPM]	Bypass Speed To [Hz]	Semi-Auto Bypass Set-up	Digital In/Out	Digital I/O mode	Digital I/O Mode	Terminal 27 Mode	Terminal 29 Mode	Digital Inputs	Terminal 18 Digital Input	Terminal 19 Digital Input	Terminal 20 Digital Input	Terminal 21 Digital Input	Terminal 22 Digital Input	Terminal 23 Digital Input	Terminal 24 Digital Input	Terminal 25 Digital Input	Terminal 26 Digital Input	Terminal 27 Digital Input	Terminal 28 Digital Input	Terminal 29 Digital Input	Terminal 30/2 Digital Input	Terminal 30/3 Digital Input	Terminal 30/4 Digital Input	Terminal 37 Safe Stop	Digital Outputs	Terminal 29 Digital Output	Terminal 27 Digital Output	Term X30/6 Digi Out (MCB 101)	Term X30/7 Digi Out (MCB 101)	Relays	Function Relay	On Delay, Relay	Off Delay, Relay	Pulse Input	Term. 29 Low Frequency	Term. 29 High Frequency	Term. 29 Low Ref./Feedb. Value	Term. 29 High Ref./Feedb. Value	Pulse Filter Time Constant #29	Term. 33 Low Frequency	Term. 33 High Frequency	Term. 33 Low Ref./Feedb. Value	Term. 33 High Ref./Feedb. Value	Pulse Output	Terminal 27 Pulse Output Variable	Pulse Output Max Freq #27	Terminal 29 Pulse Output Variable	Pulse Output Max Freq #29	Terminal X30/6 Pulse Output Variable	Terminal X30/8 Min. Scale	Terminal X30/8 Max. Scale
Language	Motor Speed Unit	Regional Settings	Operating State at Power-up	Local Mode Unit	Set-up Operations	Active Set-up	Programming Set-up	This Set-up Linked to	Readout: Linked Set-ups / Channel	LCP Display	Display Line 1.1 Small	Display Line 1.2 Small	Display Line 1.3 Small	Display Line 2 Large	Display Line 3 Large	My Personal Menu	LCP Custom Readout	Custom Readout Unit	Custom Readout Min Value	Custom Readout Max Value	Display Text 1	Display Text 2	Display Text 3	[Hand on] Key on LCP	[Off] Key on LCP	[Auto on] Key on LCP	[Reset] Key on LCP	[Off/Reset] Key on LCP	[Drive Bypass] Key on LCP	Copy/Save	LCP Copy	Set-up Copy	Password	Main Menu Password	Access to Main Menu w/o Password	Personal Menu Password	Access to Personal Menu w/o Password	Bus Access Password	Clock Settings	Date and Time	Date Format	Time Format	DST/Summertime	DST/Summertime Start	DST/Summertime End	Clock Fault	Working Days	Additional Working Days	Additional Non-Working Days	Date and Time Readout	Load and Motor	Motor Thermal Protection	Configuration Mode																			
Motor Selection	Motor Construction	WVC+ PM	Damping Gain	Low Speed Filter Time Const.	High Speed Filter Time Const.	Voltage filter time const.	Motor Data	Motor Power [kW]	Motor Power [HP]	Motor Voltage	Motor Frequency	Motor Current	Motor Nominal Speed	Motor Cont. Rated Torque	Motor Rotation Check	Automatic Motor Adaptation (AMA)	Adv. Motor Data	Stator Resistance (Rs)	Rotor Resistance (Rr)	Main Reactance (Xh)	Iron Loss Resistance (Rfe)	d-axis Inductance (Ld)	Motor Poles	Back EMF at 1000 RPM	Position Detection Gain	Load Indep. Setting	Motor Magnetisation at Zero Speed	Min Speed Normal Magnetising [RPM]	Min Speed Normal Magnetising [Hz]	Flystart Test Pulses Current	Flystart Test Pulses Frequency	Load Depen. Setting	Low Speed Load Compensation	High Speed Load Compensation	Slip Compensation	Slip Compensation Time Constant	Resonance Dampening	Resonance Dampening Time Constant	Min. Current at Low Speed	Start Adjustments	PM Start Mode	Start Delay	Start Function	Flying Start	Compressor Start Max Speed [RPM]	Compressor Start Max Speed [Hz]	Compressor Start Max Time to Trip	Stop Adjustments	Function at Stop	Min Speed for Function at Stop [RPM]	Min Speed for Function at Stop [Hz]	Trip Speed Low [RPM]	Trip Speed Low [Hz]	Motor Temperature	Motor Thermal Protection	Motor External Fan																
Motor Selection	Motor Construction	WVC+ PM	Damping Gain	Low Speed Filter Time Const.	High Speed Filter Time Const.	Voltage filter time const.	Motor Data	Motor Power [kW]	Motor Power [HP]	Motor Voltage	Motor Frequency	Motor Current	Motor Nominal Speed	Motor Cont. Rated Torque	Motor Rotation Check	Automatic Motor Adaptation (AMA)	Adv. Motor Data	Stator Resistance (Rs)	Rotor Resistance (Rr)	Main Reactance (Xh)	Iron Loss Resistance (Rfe)	d-axis Inductance (Ld)	Motor Poles	Back EMF at 1000 RPM	Position Detection Gain	Load Indep. Setting	Motor Magnetisation at Zero Speed	Min Speed Normal Magnetising [RPM]	Min Speed Normal Magnetising [Hz]	Flystart Test Pulses Current	Flystart Test Pulses Frequency	Load Depen. Setting	Low Speed Load Compensation	High Speed Load Compensation	Slip Compensation	Slip Compensation Time Constant	Resonance Dampening	Resonance Dampening Time Constant	Min. Current at Low Speed	Start Adjustments	PM Start Mode	Start Delay	Start Function	Flying Start	Compressor Start Max Speed [RPM]	Compressor Start Max Speed [Hz]	Compressor Start Max Time to Trip	Stop Adjustments	Function at Stop	Min Speed for Function at Stop [RPM]	Min Speed for Function at Stop [Hz]	Trip Speed Low [RPM]	Trip Speed Low [Hz]	Motor Temperature	Motor Thermal Protection	Motor External Fan																

6-63	Terminal X30/8 Output Bus Control	9-07	Actual Value	10-39	Devicenet F Parameters	12-94	Broadcast Storm Protection	14-55	Output Filter
6-64	Terminal X30/8 Output Timeout Preset	9-15	PCD Write Configuration	11-1*	LonWorks	12-95	Broadcast Storm Filter	14-59	Actual Number of Inverter Units
8-0*	Comm. and Options	9-16	PCD Read Configuration	11-0*	LonWorks ID	12-96	Port Config	14-6*	Auto Derate
8-01	Control Site	9-18	Node Address	11-00	Neuron ID	12-98	Interface Counters	14-60	Function at Over Temperature
8-02	Control Source	9-22	Telegram Selection	11-1*	Lon Functions	12-99	Media Counters	14-61	Function at Inverter Overload
8-03	Control Timeout Time	9-23	Parameters for Signals	11-10	Drive Profile	13-3*	Smart Logic	14-62	Inv. Overload Derate Current
8-04	Control Timeout Function	9-27	Parameter Edit	11-15	LON Warning Word	13-00*	SLC Settings	14-9*	Fault Settings
8-05	End-of-Timeout Function	9-28	Process Control	11-17	XIF Revision	13-00	SL Controller Mode	15-3**	Drive Information
8-06	Reset Control Timeout	9-44	Fault Message Counter	11-18	LonWorks Revision	13-01	Start Event	15-00	Operating hours
8-07	Diagnosis Trigger	9-45	Fault Code	11-2*	LON Param. Access	13-02	Stop Event	15-01	Running Hours
8-08	Readout Filtering	9-47	Fault Number	12-0*	Ethernet	13-03	Reset SLC	15-03	Power Up's
8-09	Communication Charset	9-52	Fault Situation Counter	12-00	IP Settings	13-1*	Comparators	15-04	Over Temp's
8-1*	Control Settings	9-53	Profibus Warning Word	12-00	IP Address Assignment	13-10	Comparator Operand	15-06	Reset kWh Counter
8-10	Control Profile	9-63	Actual Baud Rate	12-01	IP Address	13-11	Comparator Operator	15-07	Reset Running Hours Counter
8-13	Configurable Status Word STW	9-64	Device Identification	12-02	Subnet Mask	13-12	Comparator Value	15-08	Number of Starts
8-3*	FC Port Settings	9-65	Profile Number	12-03	Default Gateway	13-2*	Timers	15-1*	Data Log Settings
8-30	Protocol	9-67	Control Word 1	12-04	DHCP Server	13-20	SL Controller Timer	15-10	Logging Source
8-31	Address	9-68	Status Word 1	12-05	Lease Expires	13-4*	Logic Rules	15-11	Logging Interval
8-32	Baud Rate	9-70	Programming Set-up	12-06	Name Servers	13-40	Logic Rule Boolean 1	15-12	Trigger Event
8-33	Parity / Stop Bits	9-71	Profibus Save Data Values	12-07	Domain Name	13-41	Logic Rule Operator 1	15-13	Logging Mode
8-34	Estimated cycle time	9-72	ProfibusDriveReset	12-08	Host Name	13-42	Logic Rule Boolean 2	15-14	Samples Before Trigger
8-35	Minimum Response Delay	9-75	DO Identification	12-09	Physical Address	13-43	Logic Rule Operator 2	15-2*	Historic Log
8-36	Maximum Response Delay	9-80	Defined Parameters (1)	12-1*	Ethernet Link Parameters	13-44	Logic Rule Boolean 3	15-20	Historic Log: Event
8-37	Maximum Inter-Char Delay	9-81	Defined Parameters (2)	12-11	Link Status	13-51	SL Controller Event	15-21	Historic Log: Value
8-38	Protocol Firmware version	9-82	Defined Parameters (3)	12-11	Link Duration	13-52	SL Controller Action	15-22	Historic Log: Time
8-4*	FC MC protocol set	9-83	Defined Parameters (4)	12-12	Auto Negotiation	14-0*	Special Functions	15-23	Historic log: Date and Time
8-40	Telegram Selection	9-84	Defined Parameters (5)	12-12	Link Negotiation	14-00	Inverter Switching	15-3*	Alarm Log
8-42	PCD Write Configuration	9-90	Changed Parameters (1)	12-13	Link Speed	14-00	Switching Pattern	15-30	Alarm Log: Error Code
8-43	PCD Read Configuration	9-91	Changed Parameters (2)	12-14	Link Duplex	14-03	Overmodulation	15-32	Alarm Log: Value
8-5*	Digital/Bus	9-92	Changed Parameters (3)	12-2*	Process Data	14-01	Frequency	15-33	Alarm Log: Date and Time
8-50	Coasting Select	9-93	Changed Parameters (4)	12-20	Control Instance	14-03	PWM Random	15-4*	Drive Identification
8-52	DC Brake Select	9-94	Changed Parameters (5)	12-21	Process Data Config Write	14-04	Mains On/Off	15-40	FC Type
8-53	Start Select	9-99	Profibus Revision Counter	12-22	Process Data Config Read	14-1*	Mains On/Off	15-41	Power Section
8-54	Reversing Select	10-0*	CAN Fieldbus	12-28	Store Data Values	14-10	Mains Failure	15-42	Voltage
8-55	Set-up Select	10-00	CAN Protocol	12-29	Store Data Always	14-11	Mains Voltage at Mains Fault	15-43	Software Version
8-56	Preset Reference Select	10-01	Baud Rate Select	12-3*	EtherNet/IP	14-12	Function at Mains Imbalance	15-44	Ordered Typecode String
8-7*	BACnet	10-02	MAC ID	12-30	Warning Parameter	14-2*	Reset Functions	15-45	Actual Typecode String
8-70	BACnet Device Instance	10-05	Readout Transmit Error Counter	12-31	Net Reference	14-20	Reset Mode	15-47	Frequency Converter Ordering No
8-72	MS/TP Max Masters	10-06	Readout Receive Error Counter	12-32	Net Control	14-21	Automatic Restart Time	15-48	LCP Id No
8-73	MS/TP Max Info Frames	10-07	Readout Bus Off Counter	12-33	CIP Revision	14-22	Operation Mode	15-49	SW ID Control Card
8-74	"I-Am" Service	10-1*	DeviceNet	12-34	CIP Product Code	14-23	Typecode Setting	15-50	SW ID Power Card
8-8*	FC Port Diagnostics	10-10	Process Data Type Selection	12-35	EDS Parameter	14-25	Trip Delay at Torque Limit	15-51	Frequency Converter Serial Number
8-80	Bus Message Count	10-11	Process Data Config Write	12-37	COS Inhibit Timer	14-28	Production Settings	15-53	Power Card Serial Number
8-81	Bus Error Count	10-12	Process Data Config Read	12-38	COS Filter	14-29	Service Code	15-54	Config File Name
8-82	Slave Messages Rcvd	10-13	Warning Parameter	12-4*	Modbus TCP	14-3*	Current Limit Ctrl.	15-55	Vendor URL
8-83	Slave Error Count	10-14	Net Reference	12-40	Status Parameter	14-30	Current Lim Ctrl, Proportional Gain	15-56	Vendor Name
8-84	Slave Messages Sent	10-15	Net Control	12-41	Slave Message Count	14-31	Current Lim Ctrl, Integration Time	15-59	CSV Filename
8-85	Slave Timeout Errors	10-2*	COS Filters	12-42	Slave Exception Message Count	14-32	Current Lim Ctrl, Filter Time	15-6*	Option Ident
8-88	Diagnosics Count	10-21	COS Filter 1	12-8*	Other Ethernet Services	14-4*	Energy Optimising	15-60	Option Mounted
8-9*	Bus Jog / Feedback	10-22	COS Filter 2	12-80	FTP Server	14-40	VT Level	15-61	Option SW Version
8-90	Bus Jog 1 Speed	10-23	COS Filter 3	12-81	HTTP Server	14-41	AEO Minimum Magnetisation	15-62	Option Ordering No
8-94	Bus Feedback 1	10-25	COS Filter 4	12-82	SMTP Service	14-42	Minimum AEO Frequency	15-63	Option Serial No
8-95	Bus Feedback 2	10-3*	Parameter Access	12-89	Transparent Socket Channel Port	14-5*	Environment	15-70	Option in Slot A
8-96	Bus Feedback 3	10-30	Array Index	12-90	Cable Diagnostic	14-50	RFI Filter		
9-0*	PROFIdrive	10-31	Store Data Values	12-91	Auto Cross Over	14-51	DC Link Compensation		
		10-32	Store Always	12-92	IGMP Snooping	14-52	Fan Control		
		10-33	Store Always	12-93	Cable Error Length	14-53	Fan Monitor		
		10-34	DeviceNet Product Code						

15-71 Slot A Option SW Version	20-02 Feedback 1 Source Unit	21-14 Ext. 1 Feedback Source	22-33 Low Speed [Hz]
15-72 Option in Slot B	20-03 Feedback 2 Source	21-15 Ext. 1 Setpoint	22-34 Low Speed Power [kW]
15-73 Slot B Option SW Version	20-04 Feedback 2 Conversion	21-17 Ext. 1 Reference [Unit]	22-35 Low Speed Power [HP]
15-74 Option in Slot C0/E0	20-05 Feedback 2 Source Unit	21-18 Ext. 1 Feedback [Unit]	22-36 High Speed [RPM]
15-75 Slot C0/E0 Option SW Version	20-06 Feedback 3 Source	21-19 Ext. 1 Output [%]	22-37 High Speed [Hz]
15-76 Option in Slot C1/E1	20-07 Feedback 3 Conversion	21-20* Ext. CL 1 PID	22-38 High Speed Power [kW]
15-77 Slot C1/E1 Option SW Version	20-08 Feedback 3 Source Unit	21-20 Ext. 1 Normal/Inverse Control	22-39 High Speed Power [HP]
15-8* Operating Data II	20-12 Reference/Feedback Unit	21-21 Ext. 1 Proportional Gain	22-4* Sleep Mode
15-80 Fan Running Hours	20-13 Minimum Reference/Feedb.	21-22 Ext. 1 Integral Time	22-40 Minimum Run Time
15-81 Preset Fan Running Hours	20-20* Feedback/Setpoint	21-23 Ext. 1 Differentiation Time	22-41 Minimum Sleep Time
15-9* Parameter Info	20-20 Feedback Function	21-24 Ext. 1 Dif. Gain Limit	22-42 Wake-up Speed [RPM]
15-92 Defined Parameters	20-21 Setpoint 1	21-30 Ext. 2 Ref./Feedback Unit	22-43 Wake-up Speed [Hz]
15-93 Modified Parameters	20-22 Setpoint 2	21-30 Ext. 2 Ref./Feedback Unit	22-44 Wake-up Ref./FB Difference
15-98 Drive Identification	20-23 Setpoint 3	21-31 Ext. 2 Minimum Reference	22-45 Setpoint Boost
15-99 Parameter Metadata	20-30* Feeds, Adv. Conv.	21-32 Ext. 2 Maximum Reference	22-46 Maximum Boost Time
16** Data Readouts	20-30 Refrigerant	21-33 Ext. 2 Reference Source	22-5* End of Curve
16-0* General Status	20-31 User Defined Refrigerant A1	21-34 Ext. 2 Feedback Source	22-50 End of Curve Function
16-00 Control Word	20-32 User Defined Refrigerant A2	21-35 Ext. 2 Setpoint	22-51 End of Curve Delay
16-01 Reference [Unit]	20-33 User Defined Refrigerant A3	21-37 Ext. 2 Reference [Unit]	22-52 End of Curve Tolerance
16-02 Reference [%]	20-34 Duct 1 Area [m ²]	21-38 Ext. 2 Feedback [Unit]	22-6* Broken Belt Detection
16-03 Status Word	20-35 Duct 1 Area [in ²]	21-39 Ext. 2 Output [%]	22-60 Broken Belt Function
16-05 Main Actual Value [%]	20-36 Duct 2 Area [m ²]	21-40* Ext. CL 2 PID	22-61 Broken Belt Torque
16-09 Custom Readout	20-37 Duct 2 Area [in ²]	21-40 Ext. 2 Normal/Inverse Control	22-62 Broken Belt Delay
16-1* Motor Status	20-38 Air Density Factor [%]	21-41 Ext. 2 Proportional Gain	22-7* Short Cycle Protection
16-10 Power [kW]	20-6* Sensorless	21-42 Ext. 2 Integral Time	22-75 Short Cycle Protection
16-11 Power [hp]	20-60 Sensorless Unit	21-43 Ext. 2 Differentiation Time	22-76 Interval between Starts
16-12 Motor Voltage	20-69 Sensorless Information	21-44 Ext. 2 Dif. Gain Limit	22-77 Minimum Run Time
16-13 Frequency	20-7* PID Autotuning	21-45 Ext. 2 Dif. Gain Limit	22-78 Minimum Run Time Override
16-14 Motor current	20-70 Closed Loop Type	21-50 Ext. 3 Ref./Feedback Unit	22-79 Minimum Run Time Override Value
16-15 Frequency [%]	20-71 PID Performance	21-51 Ext. 3 Minimum Reference	22-8* Flow Compensation
16-16 Torque [Nm]	20-72 PID Output Change	21-52 Ext. 3 Maximum Reference	22-80 Flow Compensation
16-17 Speed [RPM]	20-73 Minimum Feedback Level	21-53 Ext. 3 Reference Source	22-81 Square-linear Curve Approximation
16-18 Motor Thermal	20-74 Maximum Feedback Level	21-54 Ext. 3 Feedback Source	22-82 Work Point Calculation
16-20 Motor Angle	20-79 PID Autotuning	21-55 Ext. 3 Setpoint	22-83 Speed at No-Flow [RPM]
16-22 Torque [Nm]	20-80 PID Basic Settings	21-57 Ext. 3 Reference [Unit]	22-84 Speed at No-Flow [Hz]
16-26 Power Filtered [kW]	20-81 PID Normal/ Inverse Control	21-58 Ext. 3 Feedback [Unit]	22-85 Speed at Design Point [RPM]
16-27 Power Filtered [hp]	20-82 PID Start Speed [RPM]	21-59 Ext. 3 Output [%]	22-86 Speed at Design Point [Hz]
16-3* Drive Status	20-83 PID Start Speed [Hz]	21-60 Ext. CL 3 PID	22-87 Pressure at No-Flow Speed
16-30 DC Link Voltage	20-84 On Reference Bandwidth	21-60 Ext. 3 Normal/Inverse Control	22-88 Pressure at Rated Speed
16-32 Brake Energy /s	20-9* PID Controller	21-61 Ext. 3 Proportional Gain	22-89 Flow at Design Point
16-33 Brake Energy /2 min	20-91 PID Anti Windup	21-62 Ext. 3 Integral Time	22-90 Flow at Rated Speed
16-34 Heatsink Temp.	20-93 PID Proportional Gain	21-63 Ext. 3 Differentiation Time	23-** Time-based Functions
16-35 Inverter Thermal	20-94 PID Integral Time	21-64 Ext. 3 Dif. Gain Limit	23-0* Timed Actions
16-36 Inv. Nom. Current	20-95 PID Differentiation Time	22** Appl. Functions	23-00 ON Time
16-37 Inv. Max. Current	20-96 PID Dif. Gain Limit	22-0* Miscellaneous	23-01 ON Action
16-38 SL Controller State	21-0* Ext. CL Autotuning	22-00 External Interlock Delay	23-02 OFF Time
16-39 Control Card Temp.	21-00 Closed Loop Type	22-01 Power Filter Time	23-03 OFF Action
16-40 Logging Buffer Full	21-01 PID Performance	22-2* No-Flow Detection	23-04 Occurrence
16-41 Logging Buffer Full	21-02 PID Output Change	22-20 Low Power Auto Set-up	23-0* Timed Actions Settings
16-43 Timed Actions Status	21-03 Minimum Feedback Level	22-21 Low Power Detection	23-08 Timed Actions Mode
16-49 Current Fault Source	21-04 Maximum Feedback Level	22-22 Low Speed Detection	23-09 Timed Actions Reactivation
16-5* Ref. & Feeds.	21-09 PID Autotuning	22-23 No-Flow Function	23-1* Maintenance
16-50 External Reference	21-1* Ext. CL 1 Ref./Fb.	22-24 No-Flow Delay	23-10 Maintenance Item
16-52 Feedback[Unit]	21-10 Ext. 1 Ref./Feedback Unit	22-26 Dry Pump Function	23-11 Maintenance Action
16-53 Digi. Pot Reference	21-11 Ext. 1 Minimum Reference	22-27 Dry Pump Delay	23-12 Maintenance Time Base
16-54 Feedback 1 [Unit]	21-12 Ext. 1 Maximum Reference	22-30 No-Flow Power	23-13 Maintenance Time Interval
16-55 Feedback 2 [Unit]	21-13 Ext. 1 Reference Source	22-31 Power Correction Factor	23-14 Maintenance Date and Time
16-56 Feedback 3 [Unit]		22-32 Low Speed [RPM]	23-1* Maintenance Reset
16-58 PID Output [%]			23-15 Reset Maintenance Word

23-16	Maintenance Text	25-25	OBW Time	26-35	Term. X42/5 High Ref./Feedb. Value	35-43	Term. X48/2 High Current
23-5*	Energy Log	25-26	Destage At No-Flow	26-36	Term. X42/5 Filter Time Constant	35-44	Term. X48/2 Low Ref./Feedb. Value
23-50	Energy Log Resolution	25-27	Stage Function	26-37	Term. X42/5 Live Zero	35-45	Term. X48/2 High Ref./Feedb. Value
23-51	Period Start	25-28	Stage Function Time	26-40	Analog Out X42/7	35-46	Term. X48/2 Filter Time Constant
23-53	Energy Log	25-29	Destage Function	26-41	Terminal X42/7 Min. Scale	35-47	Term. X48/2 Live Zero
23-54	Reset Energy Log	25-30	Destage Function Time	26-42	Terminal X42/7 Max. Scale	99-*	Devel support
23-6*	Trending	25-4*	Staging Settings	26-43	Terminal X42/7 Bus Control	99-0*	DSP Debug
23-60	Trend Variable	25-40	Ramp Down Delay	26-44	Terminal X42/7 Timeout Preset	99-00	DAC 1 selection
23-61	Continuous Bin Data	25-41	Ramp Up Delay	26-50	Analog Out X42/9	99-01	DAC 2 selection
23-62	Timed Bin Data	25-42	Staging Threshold	26-51	Terminal X42/9 Output	99-02	DAC 3 selection
23-63	Timed Period Start	25-43	Destaging Threshold	26-52	Terminal X42/9 Min. Scale	99-03	DAC 4 selection
23-64	Timed Period Stop	25-44	Staging Speed [RPM]	26-53	Terminal X42/9 Max. Scale	99-04	DAC 1 scale
23-65	Minimum Bin Value	25-45	Staging Speed [Hz]	26-54	Terminal X42/9 Bus Control	99-05	DAC 2 scale
23-66	Reset Continuous Bin Data	25-46	Destaging Speed [RPM]	26-55	Terminal X42/9 Timeout Preset	99-06	DAC 3 scale
23-67	Reset Timed Bin Data	25-47	Destaging Speed [Hz]	26-60	Analog Out X42/11	99-07	DAC 4 scale
23-8*	Payback Counter	25-5*	Alternation Settings	26-61	Terminal X42/11 Output	99-08	Test param 1
23-80	Power Reference Factor	25-50	Lead Pump Alternation	26-62	Terminal X42/11 Min. Scale	99-09	Test param 2
23-81	Energy Cost	25-51	Alternation Event	26-63	Terminal X42/11 Max. Scale	99-10	DAC Option Slot
23-82	Investment	25-52	Alternation Time Interval	26-64	Terminal X42/11 Bus Control	99-11*	Hardware Control
23-83	Energy Savings	25-53	Alternation Timer Value	30-2*	Special Features	99-11	RFI 2
23-84	Cost Savings	25-54	Alternation Predefined Time	30-2*	Adv. Start Adjust	99-12	Fan
24-*	Appl. Functions 2	25-55	Alternate if Load < 50%	30-22	Locked Rotor Detection	99-1*	Software Readouts
24-0*	Fire Mode	25-56	Staging Mode at Alternation	30-23	Locked Rotor Detection Time [s]	99-13	Idle time
24-00	Fire Mode Function	25-58	Run Next Pump Delay	31-*	Bypass Option	99-14	Paramdb requests in queue
24-01	Fire Mode Configuration	25-59	Run on Mains Delay	31-00	Bypass Mode	99-15	Secondary Timer at Inverter Fault
24-02	Fire Mode Unit	25-80	Cascade Status	31-01	Bypass Start Time Delay	99-16	No of Current Sensors
24-03	Fire Mode Min Reference	25-81	Pump Status	31-02	Bypass Trip Time Delay	99-2*	Heatsink Readouts
24-04	Fire Mode Max Reference	25-82	Lead Pump	31-03	Test Mode Activation	99-20	HS Temp. (PC1)
24-05	Fire Mode Preset Reference	25-83	Relay Status	31-10	Bypass Status Word	99-21	HS Temp. (PC2)
24-06	Fire Mode Reference Source	25-84	Pump ON Time	31-11	Bypass Running Hours	99-22	HS Temp. (PC3)
24-07	Fire Mode Feedback Source	25-85	Relay ON Time	31-19	Remote Bypass Activation	99-23	HS Temp. (PC4)
24-09	Fire Mode Alarm Handling	25-86	Reset Relay Counters	35-*	Sensor Input Option	99-24	HS Temp. (PC5)
24-1*	Drive Bypass	25-9*	Service	35-0*	Temp. Input Mode	99-25	HS Temp. (PC6)
24-10	Drive Bypass Function	25-90	Manual Interlock	35-00	Term. X48/4 Temperature Unit	99-26	HS Temp. (PC7)
24-11	Drive Bypass Delay Time	25-91	Pump Alternation	35-01	Term. X48/4 Input Type	99-27	HS Temp. (PC8)
24-9*	Multi-Motor Funct.	26-*	Analog I/O Option	35-02	Term. X48/7 Temperature Unit	99-2*	Platform Readouts
24-90	Missing Motor Function	26-00	Terminal X42/1 Mode	35-03	Term. X48/7 Input Type	99-29	Platform Version
24-91	Missing Motor Coefficient 1	26-01	Terminal X42/3 Mode	35-04	Term. X48/10 Temperature Unit	99-4*	Software Control
24-92	Missing Motor Coefficient 2	26-02	Terminal X42/5 Mode	35-05	Term. X48/10 Input Type	99-40	StartupWizardstate
24-93	Missing Motor Coefficient 3	26-1*	Analog Input X42/1	35-06	Temperature Sensor Alarm Function	99-5*	PC Debug
24-94	Missing Motor Coefficient 4	26-10	Terminal X42/1 Low Voltage	35-1*	Temp. Input X48/4	99-50	PC Debug Selection
24-95	Locked Rotor Function	26-11	Terminal X42/1 High Voltage	35-14	Term. X48/4 Filter Time Constant	99-51	PC Debug 0
24-96	Locked Rotor Coefficient 1	26-14	Term. X42/1 Low Ref./Feedb. Value	35-15	Term. X48/4 Temp. Monitor	99-52	PC Debug 1
24-97	Locked Rotor Coefficient 2	26-15	Term. X42/1 High Ref./Feedb. Value	35-16	Term. X48/4 Low Temp. Limit	99-53	PC Debug 2
24-98	Locked Rotor Coefficient 3	26-16	Term. X42/1 Filter Time Constant	35-17	Term. X48/4 High Temp. Limit	99-54	PC Debug 3
24-99	Locked Rotor Coefficient 4	26-17	Term. X42/1 Live Zero	35-2*	Temp. Input X48/7	99-55	PC Debug 4
25-*	Cascade Controller	26-18	Term. X42/3 Low Voltage	35-24	Term. X48/7 Filter Time Constant	99-56	Fan 1 Feedback
25-0*	System Settings	26-20	Terminal X42/3 High Voltage	35-25	Term. X48/7 Temp. Monitor	99-57	Fan 2 Feedback
25-00	Cascade Controller	26-21	Terminal X42/3 Low Voltage	35-26	Term. X48/7 High Temp. Limit	99-58	PC Auxiliary Temp.
25-02	Motor Start	26-24	Term. X42/3 Low Ref./Feedb. Value	35-27	Term. X48/7 High Temp. Limit	99-9*	Internal Values
25-04	Pump Cycling	26-25	Term. X42/3 High Ref./Feedb. Value	35-3*	Temp. Input X48/10	99-90	Options present
25-05	Fixed Lead Pump	26-26	Term. X42/3 Filter Time Constant	35-35	Term. X48/10 Filter Time Constant	99-91	Motor Power Internal
25-06	Number of Pumps	26-27	Term. X42/3 Live Zero	35-36	Term. X48/10 Temp. Monitor	99-92	Motor Voltage Internal
25-2*	Bandwidth Settings	26-30	Analog Input X42/5	35-37	Term. X48/10 Low Temp. Limit	99-93	Motor Frequency Internal
25-20	Staging Bandwidth	26-31	Terminal X42/5 Low Voltage	35-4*	Analog Input X48/2	99-94	Imbalance derate [%]
25-21	Override Bandwidth	26-34	Terminal X42/5 High Voltage	35-42	Term. X48/2 Low Current	99-95	Temperature derate [%]
25-22	Fixed Speed Bandwidth					99-96	Overload derate [%]
25-23	SBW Staging Delay						
25-24	SBW Destaging Delay						

7 General Specifications

Mains supply (L1, L2, L3)

Supply voltage	380-480 V \pm 10%
Supply voltage	525-690 V \pm 10%

Mains voltage low/mains drop-out:

During low mains voltage or a mains drop-out, the FC continues until the intermediate circuit voltage drops below the minimum stop level, which corresponds typically to 15% below the FC's lowest rated supply voltage. Power-up and full torque cannot be expected at mains voltage lower than 10% below the FC's lowest rated supply voltage.

Supply frequency	50/60 Hz \pm 5%
Max. imbalance temporary between mains phases	3.0 % of rated supply voltage
True Power Factor (λ)	\geq 0.9 nominal at rated load
Displacement Power Factor ($\cos\phi$) near unity	(> 0.98)
Switching on input supply L1, L2, L3 (power-ups)	maximum once/2 min.
Environment according to EN60664-1	overvoltage category III/pollution degree 2

The unit is suitable for use on a circuit capable of delivering not more than 100.000 RMS symmetrical Amperes, 480/690 V maximum.

Motor output (U, V, W)

Output voltage	0-100% of supply voltage
Output frequency	0-800* Hz
Switching on output	Unlimited
Ramp times	1-3600 s

* Voltage and power dependent

Torque characteristics

Starting torque (Constant torque)	maximum 110% for 1 min.*
Starting torque	maximum 135% up to 0.5 s*
Overload torque (Constant torque)	maximum 110% for 1 min.*

*Percentage relates to the frequency converter's nominal torque.

Cable lengths and cross sections

Max. motor cable length, screened/armoured	150 m
Max. motor cable length, unscreened/unarmoured	300 m
Max. cross section to motor, mains, load sharing and brake *	
Maximum cross section to control terminals, rigid wire	1.5 mm ² /16 AWG (2x0.75 mm ²)
Maximum cross section to control terminals, flexible cable	1 mm ² /18 AWG
Maximum cross section to control terminals, cable with enclosed core	0.5 mm ² /20 AWG
Minimum cross section to control terminals	0.25 mm ²

* See chapter 7.1 Electrical Data for more information!

Digital inputs

Programmable digital inputs	4 (6)
Terminal number	18, 19, 27 ¹⁾ , 29 ¹⁾ , 32, 33,
Logic	PNP or NPN
Voltage level	0-24 V DC
Voltage level, logic '0' PNP	<5 V DC
Voltage level, logic '1' PNP	>10 V DC
Voltage level, logic '0' NPN	>19 V DC
Voltage level, logic '1' NPN	<14 V DC
Maximum voltage on input	28 V DC
Input resistance, R _i	approx. 4 k Ω

All digital inputs are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

1) Terminals 27 and 29 can also be programmed as output.

Analog inputs

Number of analog inputs	2
Terminal number	53, 54
Modes	Voltage or current
Mode select	Switch S201 and switch S202
Voltage mode	Switch S201/switch S202 = OFF (U)
Voltage level	0 to +10 V (scaleable)
Input resistance, R_i	approx. 10 k Ω
Max. voltage	± 20 V
Current mode	Switch S201/switch S202 = ON (I)
Current level	0/4 to 20 mA (scaleable)
Input resistance, R_i	approx. 200 Ω
Max. current	30 mA
Resolution for analog inputs	10 bit (+ sign)
Accuracy of analog inputs	Max. error 0.5% of full scale
Bandwidth	200 Hz

The analog inputs are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.




Illustration 7.1 PELV Isolation of Analog Inputs

Pulse inputs

Programmable pulse inputs	2
Terminal number pulse	29, 33
Max. frequency at terminal, 29, 33	110 kHz (Push-pull driven)
Max. frequency at terminal, 29, 33	5 kHz (open collector)
Min. frequency at terminal 29, 33	4 Hz
Voltage level	see <i>Digital inputs</i>
Maximum voltage on input	28 V DC
Input resistance, R_i	approx. 4 k Ω
Pulse input accuracy (0.1-1 kHz)	Max. error: 0.1% of full scale

Analog output

Number of programmable analog outputs	1
Terminal number	42
Current range at analog output	0/4-20 mA
Max. resistor load to common at analog output	500 Ω
Accuracy on analog output	Max. error: 0.8% of full scale
Resolution on analog output	8 bit

The analog output is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Control card, RS-485 serial communication

Terminal number	68 (P,TX+, RX+), 69 (N,TX-, RX-)
Terminal number 61	Common for terminals 68 and 69

The RS-485 serial communication circuit is functionally seated from other central circuits and galvanically isolated from the supply voltage (PELV).

Digital output	
Programmable digital/pulse outputs	2
Terminal number	27, 29 ¹⁾
Voltage level at digital/frequency output	0-24 V
Max. output current (sink or source)	40 mA
Max. load at frequency output	1 kΩ
Max. capacitive load at frequency output	10 nF
Minimum output frequency at frequency output	0 Hz
Maximum output frequency at frequency output	32 kHz
Accuracy of frequency output	Max. error: 0.1% of full scale
Resolution of frequency outputs	12 bit

1) Terminal 27 and 29 can also be programmed as input.

The digital output is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Control card, 24 V DC output

Terminal number	12, 13
Max. load	200 mA

The 24 V DC supply is galvanically isolated from the supply voltage (PELV), but has the same potential as the analog and digital inputs and outputs.

Relay outputs

Programmable relay outputs		2
Relay 01 Terminal number	1-3 (break), 1-2 (make)	
Max. terminal load (AC-1) ¹⁾ on 1-3 (NC), 1-2 (NO) (Resistive load)	240 V AC, 2 A	
Max. terminal load (AC-15) ¹⁾ (Inductive load @ cosφ 0.4)	240 V AC, 0.2 A	
Max. terminal load (DC-1) ¹⁾ on 1-2 (NO), 1-3 (NC) (Resistive load)	60 V DC, 1 A	
Max. terminal load (DC-13) ¹⁾ (Inductive load)	24 V DC, 0.1 A	
Relay 02 Terminal number	4-6 (break), 4-5 (make)	
Max. terminal load (AC-1) ¹⁾ on 4-5 (NO) (Resistive load) ²⁾³⁾	400 V AC, 2 A	
Max. terminal load (AC-15) ¹⁾ on 4-5 (NO) (Inductive load @ cosφ 0.4)	240 V AC, 0.2 A	
Max. terminal load (DC-1) ¹⁾ on 4-5 (NO) (Resistive load)	80 V DC, 2 A	
Max. terminal load (DC-13) ¹⁾ on 4-5 (NO) (Inductive load)	24 V DC, 0.1 A	
Max. terminal load (AC-1) ¹⁾ on 4-6 (NC) (Resistive load)	240 V AC, 2 A	
Max. terminal load (AC-15) ¹⁾ on 4-6 (NC) (Inductive load @ cosφ 0.4)	240 V AC, 0.2 A	
Max. terminal load (DC-1) ¹⁾ on 4-6 (NC) (Resistive load)	50 V DC, 2 A	
Max. terminal load (DC-13) ¹⁾ on 4-6 (NC) (Inductive load)	24 V DC, 0.1 A	
Min. terminal load on 1-3 (NC), 1-2 (NO), 4-6 (NC), 4-5 (NO)	24 V DC 10 mA, 24 V AC 20 mA	
Environment according to EN 60664-1	overvoltage category III/pollution degree 2	

1) IEC 60947 parts 4 and 5

The relay contacts are galvanically isolated from the rest of the circuit by reinforced isolation (PELV).

2) Overvoltage Category II

3) UL applications 300 V AC 2 A

Control card, 10 V DC output

Terminal number	50
Output voltage	10.5 V ±0.5 V
Max. load	25 mA

The 10 V DC supply is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Control characteristics

Resolution of output frequency at 0-590 Hz	±0.003 Hz
System response time (terminals 18, 19, 27, 29, 32, 33)	≤ 2 ms
Speed control range (open loop)	1:100 of synchronous speed

Speed accuracy (open loop) 30-4000 RPM: Maximum error of ± 8 RPM

All control characteristics are based on a 4-pole asynchronous motor

Surroundings

Enclosure, frame size D and E IP00, IP21, IP54

Enclosure, frame size F IP21, IP54

Vibration test 0.7 g

Relative humidity 5% - 95% (IEC 721-3-3; Class 3K3 (non-condensing) during operation

Aggressive environment (IEC 60068-2-43) H₂S test class kD

Test method according to IEC 60068-2-43 H₂S (10 days)

Ambient temperature (at 60 AVM switching mode)

- with derating max. 55 °C¹⁾

- with full output power, typical EFF2 motors max. 50 °C¹⁾

- at full continuous FC output current max. 45 °C¹⁾

¹⁾ For more information on derating see the Design Guide, section on Special Conditions.

Minimum ambient temperature during full-scale operation 0 °C

Minimum ambient temperature at reduced performance -10 °C

Temperature during storage/transport -25 to +65/70 °C

Maximum altitude above sea level without derating 1000 m

Maximum altitude above sea level with derating 3000 m

Derating for high altitude, see section on special conditions in the Design Guide

EMC standards, Emission EN 61800-3, EN 61000-6-3/4, EN 55011, IEC 61800-3

EN 61800-3, EN 61000-6-1/2,

EMC standards, Immunity EN 61000-4-2, EN 61000-4-3, EN 61000-4-4, EN 61000-4-5, EN 61000-4-6

See section on special conditions in the Design Guide!

Control card performance

Scan interval 5 ms

Control card, USB serial communication

USB standard 1.1 (Full speed)

USB plug USB type B "device" plug

⚠ CAUTION

Connection to PC is carried out via a standard host/device USB cable.

The USB connection is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

The USB connection is not galvanically isolated from protection earth. Use only isolated laptop/PC as connection to the USB connector on the frequency converter or an isolated USB cable/converter.

Protection and Features

- Electronic thermal motor protection against overload.
- Temperature monitoring of the heat sink ensures that the frequency converter trips if the temperature reaches a predefined level. An overload temperature cannot be reset until the temperature of the heat sink is below the values stated in the tables on the following pages (Guideline - these temperatures may vary for different power sizes, frame sizes, enclosure ratings etc.).
- The frequency converter is protected against short-circuits on motor terminals U, V, W.
- If a mains phase is missing, the frequency converter trips or issues a warning (depending on the load).
- Monitoring of the intermediate circuit voltage ensures that the frequency converter trips if the intermediate circuit voltage is too low or too high.
- The frequency converter is protected against earth faults on motor terminals U, V, W.

7.1 Electrical Data

Mains Supply 3x380-480 V AC					
	P110	P132	P160	P200	P250
Typical Shaft output at 400 V [kW]	110	132	160	200	250
Typical Shaft output at 460 V [hp]	150	200	250	300	350
Enclosure IP21	D1	D1	D2	D2	D2
Enclosure IP54	D1	D1	D2	D2	D2
Enclosure IP00	D3	D3	D4	D4	D4
Output current					
Continuous (at 400 V) [A]	212	260	315	395	480
Intermittent (60 s overload) (at 400 V) [A]	233	286	347	435	528
Continuous (at 460/480 V) [A]	190	240	302	361	443
Intermittent (60 s overload) (at 460/480 V) [A]	209	264	332	397	487
Continuous KVA (at 400 V) [KVA]	147	180	218	274	333
Continuous KVA (at 460 V) [KVA]	151	191	241	288	353
Max. input current					
Continuous (at 400 V) [A]	204	251	304	381	463
Continuous (at 460/480 V) [A]	183	231	291	348	427
Max. cable size, mains motor, brake and load share [mm ² (AWG ²)]	2x70 (2x2/0)	2x70 (2x2/0)	2x150 (2x300 mcm)	2x150 (2x300 mcm)	2x150 (2x300 mcm)
Max. external pre-fuses [A] ¹	300	350	400	500	630
Estimated power loss at rated max. load [W] ⁴ , 400 V	3234	3782	4213	5119	5893
Estimated power loss at rated max. load [W] ⁴ , 460 V	2947	3665	4063	4652	5634
Weight, enclosure IP21, IP54 [kg]	96	104	125	136	151
Weight, enclosure IP00 [kg]	82	91	112	123	138
Efficiency ⁴	0.98				
Output frequency	0-800 Hz				
Heat sink overtemp. trip	90 °C	110°C	110°C	110 °C	110°C
Power card ambient trip	60 °C				

Table 7.1



Mains Supply 3x380-480 V AC				
	P315	P355	P400	P450
Typical Shaft output at 400 V [kW]	315	355	400	450
Typical Shaft output at 460 V [HP]	450	500	600	600
Enclosure IP21	E1	E1	E1	E1
Enclosure IP54	E1	E1	E1	E1
Enclosure IP00	E2	E2	E2	E2
Output current				
Continuous (at 400 V) [A]	600	658	745	800
Intermittent (60 sec overload) (at 400 V) [A]	660	724	820	880
Continuous (at 460/ 480 V) [A]	540	590	678	730
Intermittent (60 sec overload) (at 460/ 480 V) [A]	594	649	746	803
Continuous KVA (at 400 V) [KVA]	416	456	516	554
Continuous KVA (at 460 V) [KVA]	430	470	540	582
Max. input current				
Continuous (at 400 V) [A]	590	647	733	787
Continuous (at 460/ 480 V) [A]	531	580	667	718
Max. cable size, mains, motor and load share [mm ² (AWG ²)]	4x240 (4x500 mcm)	4x240 (4x500 mcm)	4x240 (4x500 mcm)	4x240 (4x500 mcm)
Max. cable size, brake [mm ² (AWG ²)]	2 x 185 (2 x 350 mcm)	2 x 185 (2 x 350 mcm)	2 x 185 (2 x 350 mcm)	2 x 185 (2 x 350 mcm)
Max. external pre-fuses [A] ¹	700	900	900	900
Estimated power loss at rated max. load [W] ⁴ , 400 V	6790	7701	8879	9670
Estimated power loss at rated max. load [W] ⁴ , 460 V	6082	6953	8089	8803
Weight, enclosure IP21, IP 54 [kg]	263	270	272	313
Weight, enclosure IP00 [kg]	221	234	236	277
Efficiency ⁴	0.98			
Output frequency	0 - 600 Hz			
Heat sink overtemp. trip	110°C			
Power card ambient trip	68 °C			

7

Table 7.2

7

Mains Supply 3x380-480 V AC						
	P500	P560	P630	P710	P800	P1M0
Typical Shaft output at 400 V [kW]	500	560	630	710	800	1000
Typical Shaft output at 460 V [HP]	650	750	900	1000	1200	1350
Enclosure IP21, 54 without/ with options cabinet	F1/F3	F1/F3	F1/F3	F1/F3	F2/F4	F2/F4
Output current						
Continuous (at 400 V) [A]	880	990	1120	1260	1460	1720
Intermittent (60 sec overload) (at 400 V) [A]	968	1089	1232	1386	1606	1892
Continuous (at 460/ 480 V) [A]	780	890	1050	1160	1380	1530
Intermittent (60 sec overload) (at 460/ 480 V) [A]	858	979	1155	1276	1518	1683
Continuous KVA (at 400 V) [KVA]	610	686	776	873	1012	1192
Continuous KVA (at 460 V) [KVA]	621	709	837	924	1100	1219
Max. input current						
Continuous (at 400 V) [A]	857	964	1090	1227	1422	1675
Continuous (at 460/ 480 V) [A]	759	867	1022	1129	1344	1490
Max. cable size,motor [mm ² (AWG ²)]	8x150 (8x300 mcm)			12x150 (12x300 mcm)		
Max. cable size,mains F1/F2 [mm ² (AWG ²)]	8x240 (8x500 mcm)					
Max. cable size,mains F3/F4 [mm ² (AWG ²)]	8x456 (8x900 mcm)					
Max. cable size, loadsharing [mm ² (AWG ²)]	4x120 (4x250 mcm)					
Max. cable size, brake [mm ² (AWG ²)]	4x185 (4x350 mcm)			6x185 (6x350 mcm)		
Max. external pre-fuses [A] ¹	1600		2000		2500	
Est. power loss at rated max. load [W] ⁴ , 400 V, F1 & F2	10647	12338	13201	15436	18084	20358
Est. power loss at rated max. load [W] ⁴ , 460 V, F1 & F2	9414	11006	12353	14041	17137	17752
Max added losses of A1 RFI, Circuit Breaker or Disconnect, & Contactor, F3 & F4	963	1054	1093	1230	2280	2541
Max Panel Options Losses	400					
Weight, enclosure IP21, IP 54 [kg]	1004/ 1299	1004/ 1299	1004/ 1299	1004/ 1299	1246/ 1541	1246/ 1541
Weight Rectifier Module [kg]	102	102	102	102	136	136
Weight Inverter Module [kg]	102	102	102	136	102	102
Efficiency ⁴	0.98					
Output frequency	0-600 Hz					
Heat sink overtemp. trip	95 °C					
Power card ambient trip	68 °C					

Table 7.3

Mains Supply 3x525-690 V AC					
	P45K	P55K	P75K	P90K	P110
Typical Shaft output at 550 V [kW]	37	45	55	75	90
Typical Shaft output at 575 V [HP]	50	60	75	100	125
Typical Shaft output at 690 V [kW]	45	55	75	90	110
Enclosure IP21	D1	D1	D1	D1	D1
Enclosure IP54	D1	D1	D1	D1	D1
Enclosure IP00	D2	D2	D2	D2	D2
Output current					
Continuous (at 3 x 525-550 V) [A]	56	76	90	113	137
Intermittent (60 sec overload) (at 550 V) [A]	62	84	99	124	151
Continuous (at 3 x 551-690 V) [A]	54	73	86	108	131
Intermittent (60 sec overload) (at 575/ 690 V) [A]	59	80	95	119	144
Continuous KVA (at 550 V) [KVA]	53	72	86	108	131
Continuous KVA (at 575 V) [KVA]	54	73	86	108	130
Continuous KVA (at 690 V) [KVA]	65	87	103	129	157
Max. input current					
Continuous (at 550 V) [A]	60	77	89	110	130
Continuous (at 575 V) [A]	58	74	85	106	124
Continuous (at 690 V) [A]	58	77	87	109	128
Max. cable size, mains, motor, load share and brake [mm ² (AWG)]	2x70 (2x2/0)				
Max. external pre-fuses [A] ¹⁾	125	160	200	200	250
Estimated power loss at rated max. load [W] ⁴⁾ , 600 V	1398	1645	1827	2157	2533
Estimated power loss at rated max. load [W] ⁴⁾ , 690 V	1458	1717	1913	2262	2662
Weight, enclosure IP21, IP 54 [kg]	96				
Weight, enclosure IP00 [kg]	82				
Efficiency ⁴⁾	0.97	0.97	0.98	0.98	0.98
Output frequency	0 - 600 Hz				
Heat sink overtemp. trip	85 °C				
Power card ambient trip	60 °C				

Table 7.4

Mains Supply 3x525-690 V AC				
	P132	P160	P200	P250
Typical Shaft output at 550 V [kW]	110	132	160	200
Typical Shaft output at 575 V [HP]	150	200	250	300
Typical Shaft output at 690 V [kW]	132	160	200	250
Enclosure IP21	D1	D1	D2	D2
Enclosure IP54	D1	D1	D2	D2
Enclosure IP00	D3	D3	D4	D4
Output current				
Continuous (at 550 V) [A]	162	201	253	303
Intermittent (60 sec overload) (at 550 V) [A]	178	221	278	333
Continuous (at 575/ 690 V) [A]	155	192	242	290
Intermittent (60 sec overload) (at 575/ 690 V) [A]	171	211	266	319
Continuous KVA (at 550 V) [KVA]	154	191	241	289
Continuous KVA (at 575 V) [KVA]	154	191	241	289
Continuous KVA (at 690 V) [KVA]	185	229	289	347
Max. input current				
Continuous (at 550 V) [A]	158	198	245	299
Continuous (at 575 V) [A]	151	189	234	286
Continuous (at 690 V) [A]	155	197	240	296
Max. cable size, mains motor, load share and brake [mm ² (AWG)]	2 x 70 (2 x 2/0)	2 x 70 (2 x 2/0)	2 x 150 (2 x 300 mcm)	2 x 150 (2 x 300 mcm)
Max. external pre-fuses [A] ¹	315	350	350	400
Estimated power loss at rated max. load [W] ⁴⁾ , 600 V	2963	3430	4051	4867
Estimated power loss at rated max. load [W] ⁴⁾ , 690 V	3430	3612	4292	5156
Weight, Enclosure IP21, IP 54 [kg]	96	104	125	136
Weight, Enclosure IP00 [kg]	82	91	112	123
Efficiency ⁴⁾	0.98			
Output frequency	0 - 600 Hz			
Heat sink overtemp. trip	90 °C	110°C	110 °C	110 °C
Power card ambient trip	60 °C			

Table 7.5



Mains Supply 3x525-690 V AC			
	P315	P400	P450
Typical Shaft output at 550 V [kW]	250	315	355
Typical Shaft output at 575 V [HP]	350	400	450
Typical Shaft output at 690 V [kW]	315	400	450
Enclosure IP21	D2	D2	E1
Enclosure IP54	D2	D2	E1
Enclosure IP00	D4	D4	E2
Output current			
Continuous (at 550 V) [A]	360	418	470
Intermittent (60 sec overload) (at 550 V) [A]	396	460	517
Continuous (at 575/ 690 V) [A]	344	400	450
Intermittent (60 sec overload) (at 575/ 690 V) [A]	378	440	495
Continuous KVA (at 550 V) [KVA]	343	398	448
Continuous KVA (at 575 V) [KVA]	343	398	448
Continuous KVA (at 690 V) [KVA]	411	478	538
Max. input current			
Continuous (at 550 V) [A]	355	408	453
Continuous (at 575 V) [A]	339	390	434
Continuous (at 690 V) [A]	352	400	434
Max. cable size, mains, motor and load share [mm ² (AWG)]	2 x 150 (2 x 300 mcm)	2 x 150 (2 x 300 mcm)	4 x 240 (4 x 500 mcm)
Max. cable size, brake [mm ² (AWG)]	2 x 150 (2 x 300 mcm)	2 x 150 (2 x 300 mcm)	2 x 185 (2 x 350 mcm)
Max. external pre-fuses [A] ¹	500	550	700
Estimated power loss at rated max. load [W] ⁴⁾ , 600 V	5493	5852	6132
Estimated power loss at rated max. load [W] ⁴⁾ , 690 V	5821	6149	6440
Weight, enclosure IP21, IP 54 [kg]	151	165	263
Weight, enclosure IP00 [kg]	138	151	221
Efficiency ⁴⁾	0.98		
Output frequency	0 - 600 Hz	0 - 500 Hz	0 - 500 Hz
Heat sink overtemp. trip	110 °C	110 °C	110 °C
Power card ambient trip	60 °C	60 °C	68 °C

7

Table 7.6

Mains Supply 3x525-690 V AC			
	P500	P560	P630
Typical Shaft output at 550 V [kW]	400	450	500
Typical Shaft output at 575 V [HP]	500	600	650
Typical Shaft output at 690 V [kW]	500	560	630
Enclosure IP21	E1	E1	E1
Enclosure IP54	E1	E1	E1
Enclosure IP00	E2	E2	E2
Output current			
Continuous (at 550 V) [A]	523	596	630
Intermittent (60 sec overload) (at 550 V) [A]	575	656	693
Continuous (at 575/ 690 V) [A]	500	570	630
Intermittent (60 sec overload) (at 575/ 690 V) [A]	550	627	693
Continuous KVA (at 550 V) [KVA]	498	568	600
Continuous KVA (at 575 V) [KVA]	498	568	627
Continuous KVA (at 690 V) [KVA]	598	681	753
Max. input current			
Continuous (at 550 V) [A]	504	574	607
Continuous (at 575 V) [A]	482	549	607
Continuous (at 690 V) [A]	482	549	607
Max. cable size, mains, motor and load share [mm ² (AWG)]	4x240 (4x500 mcm)	4x240 (4x500 mcm)	4x240 (4x500 mcm)
Max. cable size, brake [mm ² (AWG)]	2 x 185 (2 x 350 mcm)	2 x 185 (2 x 350 mcm)	2 x 185 (2 x 350 mcm)
Max. external pre-fuses [A] ¹	700	900	900
Estimated power loss at rated max. load [W] ⁴⁾ , 600 V	6903	8343	9244
Estimated power loss at rated max. load [W] ⁴⁾ , 690 V	7249	8727	9673
Weight, enclosure IP21, IP 54 [kg]	263	272	313
Weight, enclosure IP00 [kg]	221	236	277
Efficiency ⁴⁾	0.98		
Output frequency	0 - 500 Hz		
Heat sink overtemp. trip	110 °C		
Power card ambient trip	68 °C		

Table 7.7



Mains Supply 3x525-690 V AC						
	P710	P800	P900	P1M0	P1M2	P1M4
Typical Shaft output at 550 V [kW]	560	670	750	850	1000	1100
Typical Shaft output at 575 V [HP]	750	950	1050	1150	1350	1550
Typical Shaft output at 690 V [kW]	710	800	900	1000	1200	1400
Enclosure IP21, 54 without/with options cabinet	F1/ F3	F1/ F3	F1/ F3	F2/F4	F2/ F4	F2/F4
Output current						
Continuous (at 550 V) [A]	763	889	988	1108	1317	1479
Intermittent (60 s overload, at 550 V) [A]	839	978	1087	1219	1449	1627
Continuous (at 575/ 690 V) [A]	730	850	945	1060	1260	1415
Intermittent (60 s overload, at 575/690 V) [A]	803	935	1040	1166	1386	1557
Continuous KVA (at 550 V) [KVA]	727	847	941	1056	1255	1409
Continuous KVA (at 575 V) [KVA]	727	847	941	1056	1255	1409
Continuous KVA (at 690 V) [KVA]	872	1016	1129	1267	1506	1691
Max. input current						
Continuous (at 550 V) [A]	743	866	962	1079	1282	1440
Continuous (at 575 V) [A]	711	828	920	1032	1227	1378
Continuous (at 690 V) [A]	711	828	920	1032	1227	1378
Max. cable size,motor [mm ² (AWG ²)]	8x150 (8x300 mcm)			12x150 (12x300 mcm)		
Max. cable size,mains F1/F2 [mm ² (AWG ²)]	8x240 (8x500 mcm)					
Max. cable size,mains F3/F4 [mm ² (AWG ²)]	8x456 (8x900 mcm)					
Max. cable size, loadsharing [mm ² (AWG ²)]	4x120 (4x250 mcm)					
Max. cable size, brake [mm ² (AWG ²)]	4x185 (4x350 mcm)			6x185 (6x350 mcm)		
Max. external pre-fuses [A] ¹⁾	1600				2000	2500
Est. power loss at rated max. load [W] ⁴⁾ , 600 V, F1 & F2	10771	12272	13835	15592	18281	20825
Est. power loss at rated max. load [W] ⁴⁾ , 690 V, F1 & F2	11315	12903	14533	16375	19207	21857
Max added losses of Circuit Breaker or Disconnect & Contactor, F3 & F4	427	532	615	665	863	1044
Max Panel Options Losses	400					
Weight,enclosure IP21, IP 54 [kg]	1004/1299	1004/1299	1004/1299	1246/1541	1246/1541	1280/1575
Weight, Rectifier Module [kg]	102	102	102	136	136	136
Weight, Inverter Module [kg]	102	102	136	102	102	136
Efficiency ⁴⁾	0.98					
Output frequency	0-500 Hz					
Heat sink overtemp. trip	95 °C					
Power card amb. trip	68 °C					

7

Table 7.8

- 1) For type of fuse see section *Fuses*.
- 2) American Wire Gauge.
- 3) Measured using 5 m screened motor cables at rated load and rated frequency.
- 4) The typical power loss is at nominal load conditions and expected to be within +/-15% (tolerance relates to variety in voltage and cable conditions). Values are based on a typical motor efficiency (eff2/eff3 border line). Motors with lower efficiency also adds to the power loss in the frequency converter and opposite. If the switching frequency is increased comed to the default setting, the power losses may rise significantly. LCP and typical control card power consumptions are included. Further options and customer load may add up to 30 W to the losses. (Though typical only 4 W extra for a fully loaded control card, or options for slot A or slot B, each). Although measurements are made with state of the art equipment, some measurement inaccuracy must be allowed for (+/-5%).

8 Warnings and Alarms

A warning or an alarm is signalled by the relevant LED on the front of the frequency converter and indicated by a code on the display.

A warning remains active until its cause is no longer present. Under certain circumstances operation of the motor may still be continued. Warning messages may be critical, but are not necessarily so.

If an alarm occurs, the frequency converter trips. Alarms must be reset to restart operation once their cause has been rectified.

This may be done in 4 ways:

1. Pressing [Reset] on the LCP
2. Via a digital input with the "Reset" function
3. Via serial communication/optional fieldbus
4. By resetting automatically using the [Auto Reset] function (default)

NOTICE

After a manual reset pressing [Reset], the [Auto On] or [Hand On] must be pressed to restart the motor.

If an alarm cannot be reset, the reason may be that its cause has not been rectified, or the alarm is trip-locked (see also *Table 8.1*).

CAUTION

Alarms that are trip-locked offer additional protection, means that the mains supply must be switched off before the alarm can be reset. After being switched back on, the frequency converter is no longer blocked and may be reset as described above once the cause has been rectified.

Alarms that are not trip-locked can also be reset using the automatic reset function in *14-20 Reset Mode* (Warning: automatic wake-up is possible!)

If a warning and alarm is marked against a code in the table on the following page, this means that either a warning occurs before an alarm, or it can be specified whether it is a warning or an alarm that is to be displayed for a given fault.

This is possible, for instance, in *parameter 1-90 Motor Thermal Protection*. After an alarm or trip, the motor carries on coasting, and the alarm and warning flash on the frequency converter. Once the problem has been rectified, only the alarm continues flashing.

No.	Description	Warning	Alarm/ Trip	Alarm/Trip Lock	Parameter Reference
1	10 Volts low	X			
2	Live zero error	(X)	(X)		6-01
3	No motor	(X)			1-80
4	Mains phase loss	(X)	(X)	(X)	14-12
5	DC link voltage high	X			
6	DC link voltage low	X			
7	DC over voltage	X	X		
8	DC under voltage	X	X		
9	Inverter overloaded	X	X		
10	Motor ETR over temperature	(X)	(X)		1-90
11	Motor thermistor over temperature	(X)	(X)		1-90
12	Torque limit	X	X		
13	Over Current	X	X	X	
14	Earth fault	X	X	X	
15	Hardware mismatch		X	X	
16	Short Circuit		X	X	
17	Control word timeout	(X)	(X)		8-04
23	Internal Fan Fault	X			
24	External Fan Fault	X			14-53
25	Brake resistor short-circuited	X			

No.	Description	Warning	Alarm/ Trip	Alarm/Trip Lock	Parameter Reference
26	Brake resistor power limit	(X)	(X)		2-13
27	Brake chopper short-circuited	X	X		
28	Brake check	(X)	(X)		2-15
29	Drive over temperature	X	X	X	
30	Motor phase U missing	(X)	(X)	(X)	4-58
31	Motor phase V missing	(X)	(X)	(X)	4-58
32	Motor phase W missing	(X)	(X)	(X)	4-58
33	Inrush fault		X	X	
34	Fieldbus communication fault	X	X		
35	Out of frequency range	X	X		
36	Mains failure	X	X		
37	Phase Imbalance	X	X		
38	Internal fault		X	X	
39	Heat sink sensor		X	X	
40	Overload of Digital Output Terminal 27	(X)			5-00, 5-01
41	Overload of Digital Output Terminal 29	(X)			5-00, 5-02
42	Overload of Digital Output On X30/6	(X)			5-32
42	Overload of Digital Output On X30/7	(X)			5-33
46	Pwr. card supply		X	X	
47	24 V supply low	X	X	X	
48	1.8 V supply low		X	X	
49	Speed limit	X	(X)		1-86
50	AMA calibration failed		X		
51	AMA check U_{nom} and I_{nom}		X		
52	AMA low I_{nom}		X		
53	AMA motor too big		X		
54	AMA motor too small		X		
55	AMA Parameter out of range		X		
56	AMA interrupted by user		X		
57	AMA timeout		X		
58	AMA internal fault	X	X		
59	Current limit	X			
60	External Interlock	X			
62	Output Frequency at Maximum Limit	X			
64	Voltage Limit	X			
65	Control Board Over-temperature	X	X	X	
66	Heat sink Temperature Low	X			
67	Option Configuration has Changed		X		
69	Pwr. Card Temp		X	X	
70	Illegal FC configuration			X	
71	PTC 1 Safe Stop	X	X ¹⁾		
72	Dangerous Failure			X ¹⁾	
73	Safe Stop Auto Restart				
76	Power Unit Setup	X			
79	Illegal PS config		X	X	
80	Drive Initialized to Default Value		X		
91	Analog input 54 wrong settings			X	
92	NoFlow	X	X		22-2*
93	Dry Pump	X	X		22-2*
94	End of Curve	X	X		22-5*
95	Broken Belt	X	X		22-6*
96	Start Delayed	X			22-7*

No.	Description	Warning	Alarm/ Trip	Alarm/Trip Lock	Parameter Reference
97	Stop Delayed	X			22-7*
98	Clock Fault	X			0-7*
201	Fire M was Active				
202	Fire M Limits Exceeded				
203	Missing Motor				
204	Locked Rotor				
243	Brake IGBT	X	X		
244	Heat sink temp	X	X	X	
245	Heat sink sensor		X	X	
246	Pwr.card supply		X	X	
247	Pwr.card temp		X	X	
248	Illegal PS config		X	X	
250	New spare parts			X	
251	New Type Code		X	X	

Table 8.1 Alarm/Warning Code List

(X) *Dependent on parameter*

1) *Can not be Auto reset via 14-20 Reset Mode*

A trip is the action when an alarm has appeared. The trip will coast the motor and can be reset by pressing [Reset] or make a reset by a digital input (parameter group 5-1* *Digital Inputs* [1]). The original event that caused an alarm cannot damage the frequency converter or cause dangerous conditions. A trip lock is an action when an

alarm occurs, which may cause damage to frequency converter or connected parts. A Trip Lock situation can only be reset by a power cycling.

Warning	yellow
Alarm	flashing red
Trip locked	yellow and red

Table 8.2 LED Indication

Alarm Word and Extended Status Word					
Bit	Hex	Dec	Alarm Word	Warning Word	Extended Status Word
0	00000001	1	Brake Check	Brake Check	Ramping
1	00000002	2	Pwr. Card Temp	Pwr. Card Temp	AMA Running
2	00000004	4	Earth Fault	Earth Fault	Start CW/CCW
3	00000008	8	Ctrl.Card Temp	Ctrl.Card Temp	Slow Down
4	00000010	16	Ctrl. Word TO	Ctrl. Word TO	Catch Up
5	00000020	32	Over Current	Over Current	Feedback High
6	00000040	64	Torque Limit	Torque Limit	Feedback Low
7	00000080	128	Motor Th Over	Motor Th Over	Output Current High
8	00000100	256	Motor ETR Over	Motor ETR Over	Output Current Low
9	00000200	512	Inverter Overld.	Inverter Overld.	Output Freq High
10	00000400	1024	DC under Volt	DC under Volt	Output Freq Low
11	00000800	2048	DC over Volt	DC over Volt	Brake Check OK
12	00001000	4096	Short Circuit	DC Voltage Low	Braking Max
13	00002000	8192	Inrush Fault	DC Voltage High	Braking
14	00004000	16384	Mains ph. Loss	Mains ph. Loss	Out of Speed Range
15	00008000	32768	AMA Not OK	No Motor	OVC Active
16	00010000	65536	Live Zero Error	Live Zero Error	
17	00020000	131072	Internal Fault	10V Low	
18	00040000	262144	Brake Overload	Brake Overload	
19	00080000	524288	U phase Loss	Brake Resistor	
20	00100000	1048576	V phase Loss	Brake IGBT	
21	00200000	2097152	W phase Loss	Speed Limit	
22	00400000	4194304	Fieldbus Fault	Fieldbus Fault	
23	00800000	8388608	24V Supply Low	24V Supply Low	
24	01000000	16777216	Mains Failure	Mains Failure	
25	02000000	33554432	1.8V Supply Low	Current Limit	
26	04000000	67108864	Brake Resistor	Low Temp	
27	08000000	134217728	Brake IGBT	Voltage Limit	
28	10000000	268435456	Option Change	Unused	
29	20000000	536870912	Drive Initialized	Unused	
30	40000000	1073741824	Safe Stop	Unused	

Table 8.3 Description of Alarm Word, Warning Word and Extended Status Word

The alarm words, warning words and extended status words can be read out via serial bus or optional fieldbus for diagnosis. See also *16-90 Alarm Word*, *16-92 Warning Word* and *16-94 Ext. Status Word*.

The warning/alarm information below defines each warning/alarm condition, provides the probable cause for the condition, and details a remedy or troubleshooting procedure.

WARNING 1, 10 Volts low

The control card voltage is below 10 V from terminal 50. Remove some of the load from terminal 50, as the 10 V supply is overloaded. Max. 15 mA or minimum 590 Ω .

This condition can be caused by a short in a connected potentiometer or improper wiring of the potentiometer.

Troubleshooting

- Remove the wiring from terminal 50
- If the warning clears, the problem is with the customer wiring
- If the warning does not clear, replace the control card

WARNING/ALARM 2, Live zero error

This warning or alarm only appears if programmed by the user in *parameter 6-01 Live Zero Timeout Function*. The signal on one of the analog inputs is less than 50% of the minimum value programmed for that input. Broken wiring or faulty device sending the signal can cause this condition.

Troubleshooting

- Check connections on all the analog input terminals. Control card terminals 53 and 54 for signals, terminal 55 common. MCB 101 terminals 11 and 12 for signals, terminal 10 common. MCB 109 terminals 1, 3, 5 for signals, terminals 2, 4, 6 common).
- Check that the frequency converter programming and switch settings match the analog signal type
- Perform Input Terminal Signal Test

WARNING 3, No motor

No motor has been connected to the output of the frequency converter.

WARNING/ALARM 4, Mains phase loss

A phase is missing on the supply side, or the mains voltage imbalance is too high. This message also appears for a fault in the input rectifier on the frequency converter. Options are programmed at *14-12 Function at Mains Imbalance*.

Troubleshooting

- Check the supply voltage and supply currents to the frequency converter

WARNING 5, DC link voltage high

The intermediate circuit voltage (DC) is higher than the high voltage warning limit. The limit is dependent on the frequency converter voltage rating. The unit is still active.

WARNING 6, DC link voltage low

The intermediate circuit voltage (DC) is lower than the low voltage warning limit. The limit is dependent on the frequency converter voltage rating. The unit is still active.

WARNING/ALARM 7, DC overvoltage

If the intermediate circuit voltage exceeds the limit, the frequency converter trips after a time.

Troubleshooting

- Connect a brake resistor
- Extend the ramp time
- Change the ramp type
- Activate the functions in *parameter 2-10 Brake Function*
- Increase *14-26 Trip Delay at Inverter Fault*

WARNING/ALARM 8, DC under voltage

If the intermediate circuit voltage (DC link) drops below the under voltage limit, the frequency converter checks if a 24 V DC back-up supply is connected. If no 24 V DC back-up supply is connected, the frequency converter trips after a fixed time delay. The time delay varies with unit size.

Troubleshooting

- Check that the supply voltage matches the frequency converter voltage.
- Perform input voltage test.
- Perform soft charge circuit test.

WARNING/ALARM 9, Inverter overload

The frequency converter is about to cut out because of an overload (too high current for too long). The counter for electronic, thermal inverter protection gives a warning at 98% and trips at 100%, while giving an alarm. The frequency converter *cannot* be reset until the counter is below 90%.

The fault is that the frequency converter is overloaded by more than 100% for too long.

Troubleshooting

- Compare the output current shown on the LCP with the frequency converter rated current
- Compare the output current shown on the LCP with measured motor current
- Display the Thermal Drive Load on the LCP and monitor the value. When running above the frequency converter continuous current rating, the counter should increase. When running below the frequency converter continuous current rating, the counter should decrease

WARNING/ALARM 10, Motor overload temperature

According to the electronic thermal protection (ETR), the motor is too hot. Select whether the frequency converter gives a warning or an alarm when the counter reaches 100% in *parameter 1-90 Motor Thermal Protection*. The fault occurs when the motor is overloaded by more than 100% for too long.

Troubleshooting

- Check for motor overheating
- Check if the motor is mechanically overloaded
- Check that the motor current set in *parameter 1-24 Motor Current* is correct
- Ensure that Motor data in parameters 1-20 through 1-25 are set correctly
- If an external fan is in use, check in *1-91 Motor External Fan* that it is selected
- Running AMA in *parameter 1-29 Automatic Motor Adaptation (AMA)* tunes the frequency converter to the motor more accurately and reduces thermal loading

WARNING/ALARM 11, Motor thermistor over temp

The thermistor might be disconnected. Select whether the frequency converter gives a warning or an alarm in *parameter 1-90 Motor Thermal Protection*.

Troubleshooting

- Check for motor overheating
- Check if the motor is mechanically overloaded
- Check that the thermistor is connected correctly between either terminal 53 or 54 (analog voltage input) and terminal 50 (+10 V supply) and that the terminal switch for 53 or 54 is set for voltage. Check *parameter 1-93 Thermistor Source* selects terminal 53 or 54
- When using digital inputs 18 or 19, check that the thermistor is connected correctly between either terminal 18 or 19 (digital input PNP only) and terminal 50
- If a KTY sensor is used, check for correct connection between terminals 54 and 55
- If using a thermal switch or thermistor, check that the programming in *1-93 Thermistor Resource* matches sensor wiring
- If using a KTY sensor, check the programming of *1-95 KTY Sensor Type*, *1-96 KTY Thermistor Resource*, and *1-97 KTY Threshold level* match sensor wiring

WARNING/ALARM 12, Torque limit

The torque has exceeded the value in *4-16 Torque Limit Motor Mode* or the value in *4-17 Torque Limit Generator Mode*. *14-25 Trip Delay at Torque Limit* can change this from a warning only condition to a warning followed by an alarm.

Troubleshooting

- If the motor torque limit is exceeded during ramp up, extend the ramp up time
- If the generator torque limit is exceeded during ramp down, extend the ramp down time

- If torque limit occurs while running, possibly increase the torque limit. Be sure the system can operate safely at a higher torque
- Check the application for excessive current draw on the motor

WARNING/ALARM 13, Over current

The inverter peak current limit (approximately 200% of the rated current) is exceeded. The warning lasts about 1.5 s, then the frequency converter trips and issues an alarm. This fault may be caused by shock loading or fast acceleration with high inertia loads. If extended mechanical brake control is selected, trip can be reset externally.

Troubleshooting

- Remove power and check if the motor shaft can be turned
- Check that the motor size matches the frequency converter
- Check parameters 1-20 to 1-25. for correct motor data

ALARM 14, Earth (ground) fault

There is current from the output phases to ground, either in the cable between the frequency converter and the motor or in the motor itself.

Troubleshooting:

- Remove power to the frequency converter and repair the earth fault
- Check for earth faults in the motor by measuring the resistance to ground of the motor leads and the motor with a megohmmeter
- Perform current sensor test

ALARM 15, Hardware mismatch

A fitted option is not operational with the present control board hardware or software.

Record the value of the following parameters and contact the Danfoss supplier:

- *15-40 FC Type*
- *15-41 Power Section*
- *15-42 Voltage*
- *15-43 Software Version*
- *15-45 Actual Typecode String*
- *15-49 SW ID Control Card*
- *15-50 SW ID Power Card*
- *15-60 Option Mounted*
- *15-61 Option SW Version* (for each option slot)

ALARM 16, Short circuit

There is short-circuiting in the motor or motor wiring.

- Remove power to the frequency converter and repair the short circuit

WARNING/ALARM 17, Control word timeout

There is no communication to the frequency converter. The warning is only active when *8-04 Control Word Timeout Function* is NOT set to OFF.

If *8-04 Control Word Timeout Function* is set to *Stop and Trip*, a warning appears and the frequency converter ramps down until it trips then displays an alarm.

Troubleshooting:

- Check connections on the serial communication cable
- Increase *8-03 Control Word Timeout Time*
- Check the operation of the communication equipment
- Verify a proper installation based on EMC requirements

ALARM 18, Start failed

The speed has not been able to exceed *1-77 Compressor Start Max Speed [RPM]* during start within the allowed time. (set in *1-79 Compressor Start Max Time to Trip*). This may be caused by a blocked motor.

WARNING 23, Internal fan fault

The fan warning function is an extra protective function that checks if the fan is running/mounted. The fan warning can be disabled in *14-53 Fan Monitor ([0] Disabled)*.

For D, E and F enclosures, the regulated voltage to the fan is monitored.

Troubleshooting

- Check fan resistance
- Check soft charge fuses

WARNING 24, External fan fault

The fan warning function is an extra protective function that checks if the fan is running/mounted. The fan warning can be disabled in *14-53 Fan Monitor ([0] Disabled)*.

For D, E and F enclosures, the regulated voltage to the fan is monitored.

Troubleshooting

- Check fan resistance
- Check soft charge fuses

WARNING 25, Brake resistor short circuit

The brake resistor is monitored during operation. If a short circuit occurs, the brake function is disabled and the warning appears. The frequency converter is still operational but without the brake function. Remove power to the frequency converter and replace the brake resistor (see *2-15 Brake Check*).

WARNING/ALARM 26, Brake resistor power limit

The power transmitted to the brake resistor is calculated as a mean value over the last 120 s of run time. The calculation is based on the intermediate circuit voltage and the brake resistance value set in *2-16 AC brake Max. Current*. The warning is active when the dissipated braking is higher than 90% of the brake resistance power. If *[2] Trip*

is selected in *2-13 Brake Power Monitoring*, the frequency converter trips when the dissipated braking power reaches 100%.

WARNING

There is a risk of substantial power being transmitted to the brake resistor if the brake transistor is short-circuited.

WARNING/ALARM 27, Brake chopper fault

The brake transistor is monitored during operation and if a short circuit occurs, the brake function is disabled and a warning is issued. The frequency converter is still operational but, since the brake transistor has short-circuited, substantial power is transmitted to the brake resistor, even if it is inactive.

Remove power to the frequency converter and remove the brake resistor.

This alarm/warning could also occur should the brake resistor overheat. Terminals 104 and 106 are available as brake resistors Klixon ininputs, see *Brake Resistor Temperature Switch* in the *Design Guide*.

WARNING/ALARM 28, Brake check failed

The brake resistor is not connected or not working. Check *2-15 Brake Check*.

ALARM 29, Heat sink temp

The maximum temperature of the heat sink has been exceeded. The temperature fault does not reset until the temperature drops below a defined heat sink temperature. The trip and reset points are different based on the frequency converter power size.

Troubleshooting

Check for the following conditions

- Ambient temperature too high
- Motor cable too long
- Incorrect airflow clearance above and below the frequency converter
- Blocked airflow around the frequency converter
- Damaged heat sink fan
- Dirty heat sink

For the D, E and F enclosures, this alarm is based on the temperature measured by the heat sink sensor mounted inside the IGBT modules. For the F enclosures, this alarm can also be caused by the thermal sensor in the rectifier module.

Troubleshooting

- Check fan resistance
- Check soft charge fuses
- IGBT thermal sensor

ALARM 30, Motor phase U missing

Motor phase U between the frequency converter and the motor is missing.

Troubleshooting

- Remove power from the frequency converter and check motor phase U

ALARM 31, Motor phase V missing

Motor phase V between the frequency converter and the motor is missing.

Remove power from the frequency converter and check motor phase V.

ALARM 32, Motor phase W missing

Motor phase W between the frequency converter and the motor is missing.

Remove power from the frequency converter and check motor phase W.

ALARM 33, Inrush fault

Too many power-ups have occurred within a short time period. Let the unit cool to operating temperature.

WARNING/ALARM 34, fieldbus communication fault

The fieldbus on the communication option card is not working.

WARNING/ALARM 35, Out of frequency range

This warning is active if the output frequency has reached the high limit (set in 4-53 *Warning Speed High*) or low limit (set in 4-52 *Warning Speed Low*). In *Process Control, Closed Loop (1-00 Configuration Mode)* this warning is displayed.

WARNING/ALARM 36, Mains failure

This warning/alarm is only active if the supply voltage to the frequency converter is lost and 14-10 *Mains Failure* is NOT set to [0] *No Function*.

Troubleshooting

- Check the fuses to the frequency converter and mains power supply to the unit

ALARM 38, Internal fault

When an internal fault occurs, a code number defined in the *Table 8.4* is displayed.

Troubleshooting

- Cycle power
- Check that the option is properly installed
- Check for loose or missing wiring

Contact the Danfoss supplier or service department if required. Note the code number for further troubleshooting directions.

No.	Text
0	Serial port cannot be initialised. Contact the Danfoss supplier or Danfoss Service Department.
256-258	Power EEPROM data is defective or too old.
512	Control board EEPROM data is defective or too old.
513	Communication time out reading EEPROM data.
514	Communication time out reading EEPROM data.

No.	Text
515	Application oriented control cannot recognize the EEPROM data.
516	Cannot write to the EEPROM because a write command is on progress.
517	Write command is under time out.
518	Failure in the EEPROM.
519	Missing or invalid barcode data in EEPROM.
783	Parameter value outside of min/max limits.
1024-1279	A centelegram that has to be sent couldn't be sent.
1281	Digital signal processor flash timeout.
1282	Power micro software version mismatch.
1283	Power EEPROM data version mismatch.
1284	Cannot read digital signal processor software version.
1299	Option SW in slot A is too old.
1300	Option SW in slot B is too old.
1301	Option SW in slot C0 is too old.
1302	Option SW in slot C1 is too old.
1315	Option SW in slot A is not supported (not allowed).
1316	Option SW in slot B is not supported (not allowed).
1317	Option SW in slot C0 is not supported (not allowed).
1318	Option SW in slot C1 is not supported (not allowed).
1379	Option A did not respond when calculating platform version.
1380	Option B did not respond when calculating platform version.
1381	Option C0 did not respond when calculating platform version.
1382	Option C1 did not respond when calculating platform version.
1536	An exception in the application oriented control is registered. Debug information written in LCP.
1792	DSP watchdog is active. Debugging of power part data, motor oriented control data not transferred correctly.
2049	Power data restarted.
2064-2072	H081x: option in slot x has restarted.
2080-2088	H082x: option in slot x has issued a powerup-wait.
2096-2104	H983x: option in slot x has issued a legal powerup-wait.
2304	Could not read any data from power EEPROM.
2305	Missing SW version from power unit.
2314	Missing power unit data from power unit.
2315	Missing SW version from power unit.
2316	Missint lo_statepage from power unit.
2324	Power card configuration is determined to be incorrect at power up.
2325	A power card has stopped communicating while main power is applied.

No.	Text
2326	Power card configuration is determined to be incorrect after the delay for power cards to register.
2327	Too many power card locations have been registered as present.
2330	Power size information between the power cards does not match.
2561	No communication from DSP to ATACD.
2562	No communication from ATACD to DSP (state running).
2816	Stack overflow control board module.
2817	Scheduler slow tasks.
2818	Fast tasks.
2819	Parameter thread.
2820	LCP stack overflow.
2821	Serial port overflow.
2822	USB port overflow.
2836	cflistMempool too small.
3072-5122	Parameter value is outside its limits.
5123	Option in slot A: Hardware incompatible with control board hardware.
5124	Option in slot B: Hardware incompatible with Control board hardware.
5125	Option in slot C0: Hardware incompatible with control board hardware.
5126	Option in slot C1: Hardware incompatible with control board hardware.
5376-6231	Out of memory.

Table 8.4 Code Numbers for Internal Faults

ALARM 39, Heat sink sensor

No feedback from the heat sink temperature sensor.

The signal from the IGBT thermal sensor is not available on the power card. The problem could be on the power card, on the gate drive card, or the ribbon cable between the power card and gate drive card.

WARNING 40, Overload of digital output terminal 27

Check the load connected to terminal 27 or remove short-circuit connection. Check *5-00 Digital I/O Mode* and *parameter 5-01 Terminal 27 Mode*.

WARNING 41, Overload of digital output terminal 29

Check the load connected to terminal 29 or remove short-circuit connection. Check *5-00 Digital I/O Mode* and *parameter 5-02 Terminal 29 Mode*.

WARNING 42, Overload of digital output on X30/6 or overload of digital output on X30/7

For X30/6, check the load connected to X30/6 or remove the short-circuit connection. Check *5-32 Term X30/6 Digi Out (MCB 101)*.

For X30/7, check the load connected to X30/7 or remove the short-circuit connection. Check *5-33 Term X30/7 Digi Out (MCB 101)*.

ALARM 46, Power card supply

The supply on the power card is out of range.

There are 3 power supplies generated by the switch mode power supply (SMPS) on the power card: 24 V, 5 V, ±18 V. When powered with 24 V DC with the MCB 107 option, only the 24 V and 5 V supplies are monitored. When powered with 3 phase mains voltage, all 3 supplies are monitored.

WARNING 47, 24V supply low

The 24 V DC is measured on the control card. The external 24 V DC back-up power supply may be overloaded, otherwise contact the Danfoss supplier.

WARNING 48, 1.8V supply low

The 1.8 V DC supply used on the control card is outside of allowable limits. The power supply is measured on the control card. Check for a defective control card. If an option card is present, check for an overvoltage condition.

WARNING 49, Speed limit

When the speed is not within the specified range in *parameter 4-11 Motor Speed Low Limit [RPM]* and *parameter 4-13 Motor Speed High Limit [RPM]*, the frequency converter shows a warning. When the speed is below the specified limit in *1-86 Trip Speed Low [RPM]* (except when starting or stopping) the frequency converter trips.

ALARM 50, AMA calibration failed

Contact the Danfoss supplier or Danfoss Service Department.

ALARM 51, AMA check U_{nom} and I_{nom}

The settings for motor voltage, motor current, and motor power are wrong. Check the settings in parameters 1-20 to 1-25.

ALARM 52, AMA low I_{nom}

The motor current is too low. Check the settings.

ALARM 53, AMA motor too big

The motor is too big for the AMA to operate.

ALARM 54, AMA motor too small

The motor is too small for the AMA to operate.

ALARM 55, AMA parameter out of range

The parameter values of the motor are outside of the acceptable range. AMA does not run.

ALARM 56, AMA interrupted by user

The user has interrupted the AMA.

ALARM 57, AMA internal fault

Try to restart AMA again a number of times, until the AMA is carried out. Note that repeated runs may heat the motor to a level where the resistance R_s and R_r are increased. In most cases, however, this is not critical.

ALARM 58, AMA Internal fault

Contact the Danfoss supplier.

WARNING 59, Current limit

The current is higher than the value in *4-18 Current Limit*. Ensure that motor data in parameters 1-20 to 1-25 are set correctly. Possibly increase the current limit. Be sure that the system can operate safely at a higher limit.

WARNING 60, External interlock

External interlock has been activated. To resume normal operation, apply 24 V DC to the terminal programmed for external interlock and reset the frequency converter (via serial communication, digital I/O, or by pressing [Reset]).

WARNING 62, Output frequency at maximum limit

The output frequency is higher than the value set in *4-19 Max Output Frequency*.

ALARM 64, Voltage Limit

The load and speed combination demands a motor voltage higher than the actual DC-link voltage.

WARNING/ALARM 65, Control card over temperature

The control card has reached its trip temperature of 80 °C.

WARNING 66, Heat sink temperature low

The frequency converter is too cold to operate. This warning is based on the temperature sensor in the IGBT module.

Increase the ambient temperature of the unit. Also, a trickle amount of current can be supplied to the frequency converter whenever the motor is stopped by setting *parameter 2-00 DC Hold/Preheat Current* at 5% and *parameter 1-80 Function at Stop*

Troubleshooting

The heatsink temperature measured as 0 °C could indicate that the temperature sensor is defective, causing the fan speed to increase to the maximum. If the sensor wire between the IGBT and the gate drive card is disconnected, this warning would result. Also, check the IGBT thermal sensor.

ALARM 67, Option module configuration has changed

One or more options have either been added or removed since the last power-down. Check that the configuration change is intentional and reset the unit.

ALARM 68, Safe stop activated

Safe stop has been activated. To resume normal operation, apply 24 V DC to terminal 37, then send a reset signal (via Bus, Digital I/O, or by pressing [Reset]).

ALARM 69, Power card temperaturePower card temperature

The temperature sensor on the power card is either too hot or too cold.

Troubleshooting

- Check the operation of the door fans
- Check that the filters for the door fans are not blocked
- Check that the gland plate is properly installed on IP21/IP54 (NEMA 1/12) frequency converters

ALARM 70, Illegal FC configuration

The control card and power card are incompatible. Contact the supplier with the type code of the unit from the nameplate and the part numbers of the cards to check compatibility.

ALARM 72, Dangerous failure

Safe Stop with Trip Lock. Unexpected signal levels on safe stop and digital input from the PTC thermistor card.

WARNING 73, Safe stop auto restart

Safe stopped. With automatic restart enabled, the motor may start when the fault is cleared.

WARNING 76, Power unit setup

The required number of power units does not match the detected number of active power units. When replacing an F-frame module, this occurs if the power specific data in the module power card does not match the rest of the frequency converter.

Troubleshooting

- Confirm the spare part and its power card are the correct part number

WARNING 77, Reduced power mode

This warning indicates that the frequency converter is operating in reduced power mode (i.e. less than the allowed number of inverter sections). This warning is generated on power cycle when the frequency converter is set to run with fewer inverters and remains on.

ALARM 79, Illegal power section configuration

The scaling card is the incorrect part number or not installed. Also MK102 connector on the power card could not be installed.

ALARM 80, Drive initialised to default value

Parameter settings are initialised to default settings after a manual reset. Reset the unit to clear the alarm.

ALARM 91, Analog input 54 wrong settings

Switch S202 has to be set in position OFF (voltage input) when a KTY sensor is connected to analog input terminal 54.

ALARM 92, No flow

A no-flow condition has been detected in the system. *parameter 22-23 No-Flow Function* is set for alarm. Troubleshoot the system and reset the frequency converter after the fault has been cleared.

ALARM 93, Dry pump

A no-flow condition in the system with the frequency converter operating at high speed may indicate a dry pump. *parameter 22-26 Dry Pump Function* is set for alarm. Troubleshoot the system and reset the frequency converter after the fault has been cleared.

ALARM 94, End of curve

Feedback is lower than the set point. This may indicate leakage in the system. *22-50 End of Curve Function* is set for alarm. Troubleshoot the system and reset the frequency converter after the fault has been cleared.

ALARM 95, Broken belt

Torque is below the torque level set for no load, indicating a broken belt. *parameter 22-60 Broken Belt Function* is set for alarm. Troubleshoot the system and reset the frequency converter after the fault has been cleared.

ALARM 96, Start delayed

Motor start has been delayed due to short-cycle protection. *parameter 22-76 Interval between Starts* is enabled. Troubleshoot the system and reset the frequency converter after the fault has been cleared.

WARNING 97, Stop delayed

Stopping the motor has been delayed due to short cycle protection. *parameter 22-76 Interval between Starts* is enabled. Troubleshoot the system and reset the frequency converter after the fault has been cleared.

WARNING 98, Clock fault

Time is not set or the RTC clock has failed. Reset the clock in *parameter 0-70 Date and Time*.

WARNING 201, Fire mode was active

This indicates the frequency converter had entered fire mode. Cycle power to the unit to remove the warning. See the fire mode data in the alarm log.

WARNING 202, Fire mode limits exceeded

While operating in fire mode one or more alarm conditions have been ignored which would normally trip the unit. Operating in this condition voids unit warranty. Cycle power to the unit to remove the warning. See the fire mode data in the alarm log.

WARNING 203, Missing motor

With a frequency converter operating multi-motors, an under-load condition was detected. This could indicate a missing motor. Inspect the system for proper operation.

WARNING 204, Locked rotor

With a frequency converter operating multi-motors, an overload condition was detected. This could indicate a locked rotor. Inspect the motor for proper operation.

ALARM 243, Brake IGBT

This alarm is only for F Frame frequency converters. It is equivalent to Alarm 27. The report value in the alarm log indicates which power module generated the alarm:

- 1 = left most inverter module.
- 2 = middle inverter module in F2 or F4 frequency converter.
- 2 = right inverter module in F1 or F3 frequency converter.
- 3 = right inverter module in F2 or F4 frequency converter.
- 5 = rectifier module.

ALARM 244, Heatsink temperature

This alarm is only for F Frame frequency converters. It is equivalent to Alarm 29. The report value in the alarm log indicates which power module generated the alarm:

- 1 = left most inverter module.
- 2 = middle inverter module in F2 or F4 frequency converter.
- 2 = right inverter module in F1 or F3 frequency converter.
- 3 = right inverter module in F2 or F4 frequency converter.
- 5 = rectifier module.

ALARM 245, Heatsink sensor

This alarm is only for F Frame frequency converters. It is equivalent to Alarm 39. The report value in the alarm log indicates which power module generated the alarm:

- 1 = left most inverter module.
- 2 = middle inverter module in F2 or F4 frequency converter.
- 2 = right inverter module in F1 or F3 frequency converter.
- 3 = right inverter module in F2 or F4 frequency converter.
- 5 = rectifier module.

ALARM 246, Power card supply

This alarm is only for F Frame frequency converters. It is equivalent to Alarm 46. The report value in the alarm log indicates which power module generated the alarm:

- 1 = left most inverter module.
- 2 = middle inverter module in F2 or F4 frequency converter.
- 2 = right inverter module in F1 or F3 frequency converter.
- 3 = right inverter module in F2 or F4 frequency converter.
- 5 = rectifier module.

ALARM 247, Power card temperature

This alarm is only for F Frame frequency converter. It is equivalent to Alarm 69. The report value in the alarm log indicates which power module generated the alarm:

- 1 = left most inverter module.
- 2 = middle inverter module in F2 or F4 frequency converter.
- 2 = right inverter module in F1 or F3 frequency converter.
- 3 = right inverter module in F2 or F4 frequency converter.
- 5 = rectifier module.

ALARM 248, Illegal power section configuration

This alarm is only for F Frame frequency converters. It is equivalent to Alarm 79. The report value in the alarm log indicates which power module generated the alarm:

1 = left most inverter module.

2 = middle inverter module in F2 or F4 frequency converter.

2 = right inverter module in F1 or F3 frequency converter.

3 = right inverter module in F2 or F4 frequency converter.

5 = rectifier module.

WARNING 250, New spare part

A component in the frequency converter has been replaced. Reset the frequency converter for normal operation.

WARNING 251, New typecode

The power card or other components have been replaced and the typecode changed. Reset to remove the warning and resume normal operation.

Index

A

Abbreviations and Standards..... 5

Access to Control Terminals..... 65

Airflow..... 34

Alarm log..... 139

Alarm/Warning Code List..... 131

Alarms and Warnings..... 129

AMA..... 70, 78, 134, 137

Analog

 inputs..... 117, 133

 output..... 117

 signal..... 133

Auto

 Energy Optimization Compressor..... 92

 Energy Optimization VT..... 92

Automatic Motor Adaptation (AMA)..... 70

B

Back cooling..... 33

Brake

 Cable..... 58

 Resistor Temperature Switch..... 58

Braking..... 135

Branch circuit protection..... 59

C

Cable

 Lengths and Cross Sections..... 116

 positions..... 23

Cable-length and cross-section..... 45

Cabling..... 45

Changes Made..... 84

Changing

 a group of numeric data values..... 111

 a Text Value..... 111

 Data..... 110

 of Data Value..... 111

 parameter data..... 84

Closed Loop..... 136

Coast Inverse..... 85

Coasting..... 76

Communication option..... 136

Control

 cables..... 68

 Cables..... 66

 card..... 133

 Card performance..... 119

 card, 10 V DC output..... 118

 Card, 24 V DC output..... 118

 card, RS-485 serial communication..... 117

 card, USB serial communication..... 119

 characteristics..... 118

 Terminals..... 65

Cooling..... 94, 33

Copyright, limitation of liability and revision rights..... 4

Current rating..... 133

D

DC link..... 133

Default Settings..... 78

Digital

 input..... 134

 inputs..... 116

 Output..... 118

Disposal Instruction..... 8

Drip Shield Installation..... 37

Duct

 cooling..... 33

 work cooling kits..... 37

E

ELCB relays..... 56

Electrical Installation..... 65, 66

Electronic waste..... 8

Enclosure Type F Options..... 43

Example of changing parameter data..... 84

External

 Fan Supply..... 59

 Temperature Monitoring..... 44

F

Feedback..... 137, 138

Fieldbus connection..... 63

Floor Mounting..... 41

Function Set-ups..... 88

Fuse Specifications..... 60

Fuses..... 136, 59

Fusing..... 45

G

General Considerations..... 21

Gland/Conduit Entry - IP21 (NEMA 1) and IP54 (NEMA12)
..... 35

GLCP.....	78	Manual Motor Starters.....	44
Graphical display.....	73	Mechanical	
Grounding.....	56	Brake Control.....	71
		dimensions.....	18, 19
H		Dimensions.....	12
How		Installation.....	20
to Connect a PC to the Frequency Converter.....	77	Motor	
to Operate Graphical LCP (GLCP).....	73	Bearing Currents.....	63
		Cable.....	57
I		current.....	137
IEC Emergency Stop with Pilz Safety Relay.....	43	data.....	134, 138
IGBT.....	63	Insulation.....	63
Indexed Parameters.....	111	name plate.....	70
Indicator lights (LEDs).....	74	output.....	116
Initialisation.....	78	power.....	137
Input		protection.....	94, 119
polarity of control terminals.....	68	Thermal Protection.....	72
terminals.....	133		
Installation		N	
at high altitude.....	6	NAMUR.....	43
of 24 V external DC Supply.....	65	No Operation.....	85
of Duct Cooling Kit in Rittal.....	37	Non UL compliance.....	59
of Input Plate Options.....	42		
of Mains Shield for Frequency Converters.....	41	O	
on Pedestal.....	40	Ordering.....	38
on the Wall - IP21 (NEMA 1) and IP54 (NEMA 12) Units.....	35	Output	
Insulation Resistance Monitor (IRM)	43	current.....	133
IT mains	56	Performance (U, V, W).....	116
		Outside Installation/NEMA 3R Kit for Rittal	39
L		P	
Language package.....	85	Parallel Connection of Motors.....	71
LCP		Parameter	
LCP.....	78	Data.....	84
102.....	73	Selection.....	110
Leakage Current	7	Set-Up.....	3
LEDs	73	PC Software Tools	77
Lifting	10	Pedestal Installation	41
Literature	4	Phase loss	133
Load Sharing	58	Planning the Installation Site	9
Local reference	87	Potentiometer Reference	70
Loggings	84	Power Connections	45
		Profibus DP-V1	77
M		Programming	133
Main		Protection and Features	119
Menu.....	84	Pulse	
Menu mode.....	75	Inputs.....	117
Menu Mode.....	110	Start/Stop.....	69
reactance.....	92		
Mains			
Connection.....	59		
supply (L1, L2, L3).....	116		
Supply 3 x 525- 690 V AC.....	123		

Q

Quick

Menu..... 84
 Menu mode..... 75
 Menu Mode..... 84
 Transfer of Parameter Settings when Using GLCP..... 3

R

RCD (Residual Current Device)..... 43
 Receiving the Frequency Converter..... 10
 Relay Outputs..... 118
 Reset..... 133, 138
 Residual Current Device..... 7
 RFI Switch..... 56
 RS-485 Bus Connection..... 76

S

Safe

Stop + Pilz Relay..... 43
 Torque Off..... 7

Safety note..... 6
 Screened/armoured..... 68
 Screening of cables..... 45
 Serial Communication..... 119
 Shielded Cables..... 57
 Short circuit..... 134
 Sine-wave filter..... 46
 Software Version..... 4
 Space
 Space..... 21
 Heaters and Thermostat..... 43
 Speed Up/Down..... 69
 Start/Stop..... 69
 Stator leakage reactance..... 92
 Status
 Status..... 75
 messages..... 73
 Supply voltage..... 136
 Surroundings..... 119
 Switches S201, S202, and S801..... 68
 Switching frequency..... 45

T

Terminal

54..... 138
 Locations..... 1, 24

Thermal Protection..... 4
 Thermistor..... 94, 134

Torque

Torque..... 56
 Characteristics..... 116
 for Terminals..... 57

U

Unpacking..... 10

V

Voltage

imbalance..... 133
 level..... 117
 reference via a potentiometer..... 70

W

Warning against Unintended Start..... 6
 Wire access..... 21



www.danfoss.com/drives

.....
Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.
.....

