



USER'S MANUAL
NXL FREQUENCY CONVERTERS

LOCAL REMOTE APPLICATION MANUAL
ALFIFF27

1.	Local/Remote Control Application	3
1.1	Introduction.....	3
1.2	Control I/O.....	4
1.3	Control signal logic in Local/Remote Application	5
1.4	Local/Remote control application – Parameter lists	6
1.4.1	Monitoring values (Control keypad: menu M1).....	6
1.4.2	Basic parameters (Control keypad: Menu M2 → G2.1)	7
1.4.3	Input signals (Control keypad: Menu M2 → G2.2)	8
1.4.4	Output signals (Control keypad: Menu M2 → G2.3).....	10
1.4.5	Drive control parameters (Control keypad: Menu M2 → G2.4).....	12
1.4.6	Prohibit frequency parameters (Control keypad: Menu M2 → G2.5)	12
1.4.7	Motor control parameters (Control keypad: Menu M2 → G2.6)	13
1.4.8	Protections (Control keypad: Menu M2 → G2.7)	14
1.4.9	Autorestart parameters (Control keypad: Menu M2 → G2.8)	15
1.4.10	Keypad control (Control keypad: Menu M3)	15
1.4.11	System menu (Control keypad: Menu M6).....	15
1.4.12	Expander boards (Control keypad: Menu M7)	15
2.	Description of parameters	16

1. LOCAL/REMOTE CONTROL APPLICATION

1.1 Introduction

Utilising the NXL Local/Remote Control Application ALFIF27 it is possible to have two different control places. For each control place the frequency reference can be selected from either the control keypad, I/O terminal or fieldbus. The active control place is selected with the digital input DIN6.

- All outputs are freely programmable.

Additional functions:

- Programmable Start/Stop and Reverse signal logic
- Reference scaling
- One frequency limit supervision
- Second ramps and S-shape ramp programming
- Programmable start and stop functions
- DC-brake at stop
- 3 prohibit frequency areas
- Programmable U/f curve and switching frequency
- Autorestart
- Motor thermal and stall protection: Programmable action; off, warning, fault

The parameters of the Local/Remote Control Application are explained in Chapter 2 of this manual. The explanations are arranged according to the individual ID number of the parameter.

1.2 Control I/O




Figure 1-1. Local/Remote application default I/O configuration.

I/O terminals on the option board OPT-AA




Figure 1-2. I/O terminals of option board OPT-AA in Local/Remote application

1.3 Control signal logic in Local/Remote Application






Figure 1-3. Control signal logic of the Local/Remote Control Application

1.4 Local/Remote control application – Parameter lists

On the next pages you will find the lists of parameters within the respective parameter groups. The parameter descriptions are given on pages 16 to 55.

Column explanations:

Code	=	Location indication on the keypad; Shows the operator the present parameter number
Parameter	=	Name of parameter
Min	=	Minimum value of parameter
Max	=	Maximum value of parameter
Unit	=	Unit of parameter value; Given if available
Default	=	Value preset by factory
Cust	=	Customer's own settings
ID	=	ID number of the parameter
	=	In parameter row: Use TTF method to program these parameters.
	=	On parameter number: Parameter value can only be changed after the frequency converter has been stopped.

1.4.1 Monitoring values (Control keypad: menu M1)

The monitoring values are the actual values of parameters and signals as well as statuses and measurements. Monitoring values cannot be edited. See the product's User's Manual for more information.

Code	Parameter	Unit	ID	Description
V1.1	Output frequency	Hz	1	Output frequency to motor
V1.2	Frequency reference	Hz	25	Frequency reference to motor control
V1.3	Motor speed	rpm	2	Motor speed in rpm
V1.4	Motor current	A	3	Output current of motor
V1.5	Motor torque	%	4	Calculated shaft torque
V1.6	Motor power	%	5	Motor shaft power
V1.7	Motor voltage	V	6	Output voltage to motor
V1.8	DC link voltage	V	7	DC Voltage at DC link
V1.9	Unit temperature	°C	8	Heatsink temperature
V1.10	Analogue input 1	V	13	A11
V1.11	Analogue input 2	mA	14	A12
V1.12	DIN1, DIN2, DIN3		15	Digital input statuses
V1.13	DIE1, DIE2, DIE3		16	Option board digital input statuses
V1.14	DO1, RO1, RO2		17	Digital and relay output statuses
V1.15	Analogue I _{out}	mA	26	A01

Table 1-1. Monitoring values

1.4.2 Basic parameters (Control keypad: Menu M2 → G2.1)

Code	Parameter	Min	Max	Unit	Default	Cust	ID	Note
P2.1.1	Min frequency	0,00	Par. 2.1.2	Hz	0,00		101	
P2.1.2	Max frequency	Par. 2.1.1	320,00	Hz	50,00		102	NOTE: If f_{max} > than the motor synchronous speed, check suitability for motor and drive system
P2.1.3	Acceleration time 1	0,1	3000,0	s	3,0		103	
P2.1.4	Deceleration time 1	0,1	3000,0	s	3,0		104	
P2.1.5	Current limit	$0,1 \times I_H$	$2 \times I_H$	A	I_L		107	NOTE: Formulas applies approximately up to MF3. For greater sizes, consult the factory
P2.1.6	Nominal voltage of the motor	180	690	V	NXL2: 230V NXL5: 400V		110	
P2.1.7	Nominal frequency of the motor	30,00	320,00	Hz	50,00		111	Check the rating plate of the motor
P2.1.8	Nominal speed of the motor	300	20 000	rpm	1440		112	The default applies for a 4-pole motor and a nominal size frequency converter.
P2.1.9	Nominal current of the motor	$0,3 \times I_L$	$1,5 \times I_L$	A	I_L		113	Check the rating plate of the motor.
P2.1.10	Motor $\cos\phi$	0,30	1,00		0,85		120	Check the rating plate of the motor
P2.1.11	I/O A reference	0	4		1		117	0=A11 1=A12 2=Keypad 3=Fieldbus 4=Motor potentiometer
P2.1.12	I/O B reference	0	4		0		131	0=A11 1=A12 2=Keypad 3=Fieldbus 4=Motor potentiometer
P2.1.13	Keypad control reference	0	3		2		121	0=A11 1=A12 2=Keypad 3=Fieldbus
P2.1.14	Fieldbus control reference	0	3		3		122	0=A11 1=A12 2=Keypad 3=Fieldbus
P2.1.15	Jogging speed reference	0,00	Par. 2.1.2	Hz	0,00		124	

Table 1-2. Basic parameters G2.1

1.4.3 Input signals (Control keypad: Menu M2 → G2.2)

Code	Parameter	Min	Max	Unit	Default	Cust	ID	Note	
								DIN1	DIN2
P2.2.1	Place A Start/Stop logic selection	0	8		0		30 0	0 Start fwd 1 Start/Stop 2 Start/Stop 3 Start pulse 4 Start fwd 5 Fwd* 6 Start*/Stop 7 Start*/Stop 8 Start fwd*	Start rvs Reverse RunEnable Stop pulse Mot.pot.UP Rvs* Rvs/Fwd RunEnable Mot.pot.UP
P2.2.2	DIN3 function	0	13		1		30 1	0=Not used 1=Ext. fault, closing cont. 2=Ext. fault, opening cont. 3=Run enable 4=Acc./Dec. time select. 5=Force cp. to IO 6=Force cp. to keypad 7=Force cp. to fieldbus 8=Reverse 9=Jogging speed 10=Fault reset 11=Acc./Dec. operation prohibit 12=DC Braking command 13=Motor potentiometer DOWN	
P2.2.3	AI1 signal selection	0	21		10		37 7	10=AI1 (1=Local, 0=input 1) 11=AI2 (1=Local, 1= input 2) 20=Exp. AI1 (2=exp.board 0=input 1) 21=Exp AI2 (2=exp.board 1=input 2)	
P2.2.4	AI1 signal range	0	2		0		32 0	0=0...100%** 1=20...100%** 2=Custom setting range**	
P2.2.5	AI1 custom setting minimum	0,00	100,00	%	0,00		32 1	Analogue input 1 scale minimum	
P2.2.6	AI1 custom setting maximum	0,00	100,00	%	100,0		32 2	Analogue input 1 scale maximum	
P2.2.7	AI1 signal inversion	0	1		0		32 3	Analogue input 1 reference inversion yes/no	
P2.2.8	AI1 signal filter time	0,00	10,00	s	0,10		32 4	Analogue input 1 reference filter time, constant	
P2.2.9	AI2 signal selection	0	21		11		38 8	As par. 2.2.3	
P2.2.10	AI2 signal range	0	2		1		32 5	0=0 - 20 mA** 1=4 - 20 mA** 2=custom setting range	
P2.2.11	AI2 custom setting minimum	0,00	100,00	%	0,00		32 6	Analogue input 2 scale minimum	
P2.2.12	AI2 custom setting maximum	0,00	100,00	%	100,00		32 7	Analogue input 2 scale maximum	
P2.2.13	AI2 signal inversion	0	1		0		32 8	Analogue input 2 reference inversion yes/no	
P2.2.14	AI2 signal filter time	0,00	10,00	s	0,10		32 9	Analogue input 2 reference filter time, constant	

								DIE1	DIE2
								0	Start fwd
1	Start/Stop	Rvs/Fwd							
2	Start/Stop	Run enable							
3	Start pulse	Stop pulse							
4	Fwd*	Rvs*							
5	Start*/Stop	Rvs/Fwd							
6	Start*/Stop	Run enable							
P2.2.15	Place B Start/Stop logic selection	0	6		0		363		
P2.2.16	Place A Reference scaling minimum value	0,00	P2.2.17	Hz	0,00		303	Selects the frequency that corresponds to the min. reference signal	
P2.2.17	Place A Reference scaling maximum value	0,00	320,00	Hz	0,00		304	Selects the frequency that corresponds to the max. reference signal 0,00 = No scaling >0 = scaled max. value	
P2.2.18	Place B Reference scaling minimum value	0,00	P2.2.19	Hz	0,00		364	Selects the frequency that corresponds to the min. reference signal	
P2.2.19	Place B Reference scaling maximum value	0,00	320,00	Hz	0,00		365	Selects the frequency that corresponds to the max. reference signal 0,00 = No scaling >0 = scaled max. value	
P2.2.20	Free analogue input, signal selection	0	2		0		361	0=Not used 1=U _{in} (analogue volt. input) 2=I _{in} (analogue curr. input)	
P2.2.21	Free analogue input, function	0	4		0		362	0=No function 1=Reduces current limit (par. 2.1.5) 2=Reduces DC braking current 3=Reduces accel. and decel. times 4=Reduces torque supervision limit	
P2.2.22	Motor potentiometer ramp time	0,1	2000,0	Hz/s	10,0		331		
P2.2.23	Motor potentiometer frequency reference memory reset	0	2		1		367	0=No reset 1=Reset if stopped or powered down 2=Reset if powered down	
P2.2.24	Start pulse memory	0	1		0		498	0=Run state not copied 1=Run state copied	

Table 1-3. Input signals, G2.2

1.4.4 Output signals (Control keypad: Menu M2 → G2.3)

Code	Parameter	Min	Max	Unit	Default	Cust	ID	Note
P2.3.1	AO1 signal selection	0	21		10		464	TTF programming method used.
P2.3.2	Analogue output function	0	8		1		307	0=Not used 1=Output freq. (0– f_{max}) 2=Freq. reference (0– f_{max}) 3=Motor speed (0–Motor nominal speed) 4=Motor current (0– I_{nMotor}) 5=Motor torque (0– T_{nMotor}) 6=Motor power (0– P_{nMotor}) 7=Motor voltage (0– U_{nMotor}) 8=DC-link volt (0–1000V)
P2.3.3	Analogue output filter time	0,00	10,00	s	1,00		308	0=No filtering
P2.3.4	Analogue output inversion	0	1		0		309	0=Not inverted 1=Inverted
P2.3.5	Analogue output minimum	0	1		0		310	0=0 mA 1=4 mA
P2.3.6	Analogue output scale	10	1000	%	100		311	
P2.3.7	Digital output 1 function	0	22		1		312	0=Not used 1=Ready 2=Run 3=Fault 4=Fault inverted 5=FC overheat warning 6=Ext. fault or warning 7=Ref. fault or warning 8=Warning 9=Reversed 10=Jogging spd selected 11=At speed 12=Mot. regulator active 13=OP freq.limit superv. 1 14=OP freq.limit superv. 2 15=Torque limit superv. 16=Ref. limit superv. 17=Ext. brake control 18= Control place: IO 19=FC temp. limit superv. 20=Unrequested rotation direction 21=Ext. brake control inverted 22=Thermistor fault/warn.
P2.3.8	Relay output 1 function	0	22		2		313	As parameter 2.3.7
P2.3.9	Relay output 2 function	0	22		3		314	As parameter 2.3.7
P2.3.10	Output frequency limit 1 supervision	0	2		0		315	0=No limit 1=Low limit supervision 2=High limit supervision
P2.3.11	Output frequency limit 1; Supervision value	0,00	Par. 2.1.2	Hz	0,00		316	
P2.3.12	Output frequency limit 2 supervision	0	2		0		346	0=No limit 1=Low limit supervision 2=High limit supervision

P2.3.13	Output frequency limit 2; Supervision value	0,00	Par. 2.1.2	Hz	0,00		347	
P2.3.14	Torque limit supervision function	0	2		0		348	0=No 1=Low limit 2=High limit
P2.3.15	Torque limit supervision value	0,0	200,0	%	0,0		349	
P2.3.16	Reference limit supervision function	0	2		0		350	0=No 1=Low limit 2=High limit
P2.3.17	Reference limit supervision value	0,0	100,0	%	0,0		351	
P2.3.18	External brake Off-delay	0,0	100,0	s	0,5		352	
P2.3.19	External brake On-delay	0,0	100,0	s	1,5		353	
P2.3.20	Frequency converter temperature limit supervision	0	2		0		354	0=No 1=Low limit 2=High limit
P2.3.21	Frequency converter temperature limit value	-10	100	°C	40		355	
P2.3.22	Analogue output 2 signal selection	0			0.1		471	TTF programming method used.
P2.3.23	Analogue output 2 function	0	8		4		472	As parameter 2.3.2
P2.3.24	Analogue output 2 filter time	0,00	10,00	s	1,00		473	0=No filtering
P2.3.25	Analogue output 2 inversion	0	1		0		474	0=Not inverted 1=Inverted
P2.3.26	Analogue output 2 minimum	0	1		0		475	0=0 mA 1=4 mA
P2.3.27	Analogue output 2 scaling	10	1000	%	100		476	

Table 1-4. Output signals, G2.3

1.4.5 Drive control parameters (Control keypad: Menu M2 → G2.4)

Code	Parameter	Min	Max	Unit	Default	Cust	ID	Note
P2.4.1	Ramp 1 shape	0,0	10,0	s	0,1		500	0=Linear >0=S-curve ramp time
P2.4.2	Ramp 2 shape	0,0	10,0	s	0,0		501	0=Linear >0=S-curve ramp time
P2.4.3	Acceleration time 2	0,1	3000,0	s	10,0		502	
P2.4.4	Deceleration time 2	0,1	3000,0	s	10,0		503	
P2.4.5	Brake chopper	0	4		0		504	0=Disabled 1=Used when running 2=External brake chopper 3=Used when stopped/ running 4=Used when running (no testing)
P2.4.6	Start function	0	1		0		505	0=Ramp 1=Flying start
P2.4.7	Stop function	0	3		0		506	0=Coasting 1=Ramp 2=Ramp+Run enable coast 3=Coast+Run enable ramp
P2.4.8	DC braking current	0,15x I _N	1,5x I _N	A	Varies		507	
P2.4.9	DC braking time at stop	0,00	600,00	s	0,00		508	0=DC brake is off at stop
P2.4.10	Frequency to start DC braking during ramp stop	0,10	10,00	Hz	1,50		515	
P2.4.11	DC braking time at start	0,00	600,00	s	0,00		516	0=DC brake is off at start
P2.4.12	Flux brake	0	1		0		520	0=Off 1=On
P2.4.13	Flux braking current	0,15x I _N	1,5x I _N	A	0,00		519	

Table 1-5. Drive control parameters, G2.4

1.4.6 Prohibit frequency parameters (Control keypad: Menu M2 → G2.5)

Code	Parameter	Min	Max	Unit	Default	Cust	ID	Note
P2.5.1	Prohibit frequency range 1 low limit	0,00	P2.5.2	Hz	0,00		509	
P2.5.2	Prohibit frequency range 1 high limit	0,00	320,00	Hz	0,0		510	0=Prohibit range 1 is off
P2.5.3	Prohibit frequency range 2 low limit	0,00	P2.5.4	Hz	0,00		511	
P2.5.4	Prohibit frequency range 2 high limit	0,00	320,00	Hz	0,0		512	0=Prohibit range 2 is off
P2.5.5	Prohibit frequency range 3 low limit	0,00	P2.5.6	Hz	0,00		513	
P2.5.6	Prohibit frequency range 3 high limit	0,00	320,00	Hz	0,0		514	0=Prohibit range 3 is off
P2.5.7	Prohibit acc./dec. ramp	0,1	10,0	x	1,0		518	

Table 1-6. Prohibit frequency parameters, G2.5

1.4.7 Motor control parameters (Control keypad: Menu M2 → G2.6)

Code	Parameter	Min	Max	Unit	Default	Cust	ID	Note
P2.6.1	Motor control mode	0	1		0		600	0=Frequency control 1=Speed control
P2.6.2	U/f optimisation	0	1		0		109	0=Not used 1=Automatic torque boost
P2.6.3	U/f ratio selection	0	3		0		108	0=Linear 1=Squared 2=Programmable 3=Linear with flux optim.
P2.6.4	Field weakening point	8,00	320,00	Hz	50,00		602	
P2.6.5	Voltage at field weakening point	10,00	200,00	%	100,00		603	$n\% \times U_{n\text{mot}}$
P2.6.6	U/f curve midpoint frequency	0,00	par. P2.6.4	Hz	50,00		604	
P2.6.7	U/f curve midpoint voltage	0,00	100,00	%	100,00		605	$n\% \times U_{n\text{mot}}$ Parameter max. value = par. 2.6.5
P2.6.8	Output voltage at zero frequency	0,00	40,00	%	0,00		606	$n\% \times U_{n\text{mot}}$
P2.6.9	Switching frequency	1,0	Varies	kHz	Varies	6,0	601	
P2.6.10	Overvoltage controller	0	2		1		607	0=Not used 1=Used (no ramping) 2=Used (ramping)
P2.6.11	Undervoltage controller	0	1		1		608	0=Not used 1=Used

Table 1-7. Motor control parameters, G2.6

1.4.8 Protections (Control keypad: Menu M2 → G2.7)

Code	Parameter	Min	Max	Unit	Default	Cust	ID	Note
P2.7.1	Response to 4mA reference fault	0	5		0		700	0=No response 1=Warning 2=Warning+Previous Freq. 3=Wrrng+PresetFreq 2.7.2 4=Fault,stop acc. to 2.4.7 5=Fault,stop by coasting
P2.7.2	4mA reference fault frequency	0,00	Par. 2.1.2	Hz	0,00		728	
P2.7.3	Response to external fault	0	3		2		701	0=No response 1=Warning 2=Fault,stop acc. to 2.4.7 3=Fault,stop by coasting
P2.7.4	Input phase supervision	0	3		0		730	
P2.7.5	Response to undervoltage fault	0	3		3		727	0=No response 1=Warning 2=Fault,stop acc. to 2.4.7 3=Fault,stop by coasting
P2.7.6	Output phase supervision	0	3		2		702	
P2.7.7	Earth fault protection	0	3		2		703	0=No response 1=Warning 2=Fault,stop acc. to 2.4.7 3=Fault,stop by coasting
P2.7.8	Thermal protection of the motor	0	3		2		704	
P2.7.9	Motor ambient temperature factor	-100,0	100,0	%	0,0		705	
P2.7.10	Motor cooling factor at zero speed	0,0	150,0	%	40,0		706	
P2.7.11	Motor thermal time constant	1	200	min	45		707	
P2.7.12	Motor duty cycle	0	100	%	100		708	
P2.7.13	Stall protection	0	3		0		709	0=No response 1=Warning 2=Fault,stop acc. to 2.4.7 3=Fault,stop by coasting
P2.7.14	Stall current	0,10	I_L	A	1,00		710	
P2.7.15	Stall time limit	1,00	120,00	s	15,00		711	
P2.7.16	Stall frequency limit	1,0	Par. 2.1.2	Hz	25,0		712	
P2.7.17	Underload protection	0	3		0		713	0=No response 1=Warning 2=Fault,stop acc. to 2.4.7 3=Fault,stop by coasting
P2.7.18	Field weakening area load	10	150	%	50		714	
P2.7.19	Zero frequency load	5,0	150,0	%	10,0		715	
P2.7.20	Underload protection time limit	2	600	s	20		716	
P2.7.21	Response to thermistor fault	0	3		2		732	0=No response 1=Warning 2=Fault,stop acc. to 2.4.7 3=Fault,stop by coasting
P2.7.22	Response to fieldbus fault	0	3		2		733	See P2.7.21
P2.7.23	Response to slot fault	0	3		2		734	See P2.7.21

Table 1-8. Protections, G2.7

1.4.9 Autorestart parameters (Control keypad: Menu M2 → G2.8)

Code	Parameter	Min	Max	Unit	Default	Cust	ID	Note
P2.8.1	Wait time	0,10	10,00	s	0,50		717	
P2.8.2	Trial time	0,00	60,00	s	30,00		718	
P2.8.3	Start function	0	2		0		719	0=Ramp 1=Flying start 2=According to par. 2.4.6
P2.8.4	Number of tries after undervoltage trip	0	10		0		720	
P2.8.5	Number of tries after overvoltage trip	0	10		0		721	
P2.8.6	Number of tries after overcurrent trip	0	3		0		722	
P2.8.7	Number of tries after 4mA reference trip	0	10		0		723	
P2.8.8	Number of tries after motor temp fault trip	0	10		0		726	
P2.8.9	Number of tries after external fault trip	0	10		0		725	
P2.8.10	Number of tries after underload fault trip	0	10		0		738	

Table 1-9. Autorestart parameters, G2.8

1.4.10 Keypad control (Control keypad: Menu M3)

The parameters for the selection of control place and direction on the keypad are listed below. See the Keypad control menu in the product's User's Manual.

Code	Parameter	Min	Max	Unit	Default	Cust	ID	Note
P3.1	Control place	1	3		1		125	1=I/O terminal 2=Keypad 3=Fieldbus
R3.2	Keypad reference	Par. 2.1.1	Par. 2.1.2	Hz				
P3.3	Direction (on keypad)	0	1		0		123	0=Forward 1=Reverse
R3.4	Stop button	0	1		1		114	0=Limited function of Stop button 1=Stop button always enabled

Table 1-10. Keypad control parameters, M3

1.4.11 System menu (Control keypad: Menu M6)

For parameters and functions related to the general use of the frequency converter, such as application and language selection, customised parameter sets or information about the hardware and software, see the product's User's Manual.

1.4.12 Expander boards (Control keypad: Menu M7)

The M7 menu shows the expander and option boards attached to the control board and board-related information. For more information, see the product's User's Manual .

2. DESCRIPTION OF PARAMETERS

On the following pages you will find the parameter descriptions arranged according to the individual ID number of the parameter.

101 *Minimum frequency* (2.1.1)

102 *Maximum frequency* (2.1.2)

Defines the frequency limits of the frequency converter.

The maximum value for these parameters is 320 Hz.

The software will automatically check the values of parameters ID105, ID106 and [ID728](#).

103 *Acceleration time 1* (2.1.3)

104 *Deceleration time 1* (2.1.4)

These limits correspond to the time required for the output frequency to accelerate from the zero frequency to the set maximum frequency (par. ID102).

107 *Current limit* (2.1.5)

This parameter determines the maximum motor current from the frequency converter.

The parameter value range differs from size to size. When this parameter is changed the stall current limit (ID710) is internally calculated to 90% of current limit.

108 *U/f ratio selection* (2.6.3)

Linear: The voltage of the motor changes linearly with the frequency in the constant flux area from 0 Hz to the field weakening point where the nominal voltage is supplied to the motor. Linear U/f ration should be used in constant torque applications. **This default setting should be used if there is no special need for another setting.**

Squared: The voltage of the motor changes following a squared curve form with the frequency in the area from 0 Hz to the field weakening point where the nominal voltage is also supplied to the motor. The motor runs undermagnetised below the field weakening point and produces less torque and electro-mechanical noise. Squared U/f ratio can be used in applications where torque demand of the load is proportional to the square of the speed, e.g. in centrifugal fans and pumps.




Figure 2-1. Linear and squared change of motor voltage

Programmable U/f curve:

- 2 The U/f curve can be programmed with three different points. Programmable U/f curve can be used if the other settings do not satisfy the needs of the application.




Figure 2-2. Programmable U/f curve

Linear with flux optimisation:

- 3 The frequency converter starts to search for the minimum motor current in order to save energy, lower the disturbance level and the noise. This function can be used in applications with constant motor load, such as fans, pumps etc.

109 **U/f optimisation** (2.6.2)

Automatic torque boost The voltage to the motor changes automatically which makes the motor produce sufficient torque to start and run at low frequencies. The voltage increase depends on the motor type and power. Automatic torque boost can be used in applications where starting torque due to starting friction is high, e.g. in conveyors.

EXAMPLE:

What changes are required to start with load from 0 Hz?

- ◆ First set the motor nominal values (Parameter group 2.1).

Option 1: Activate the Automatic torque boost.

Option 2: Programmable U/f curve

To get torque you need to set the zero point voltage and midpoint voltage/frequency (in parameter group 2.6) so that the motor takes enough current at low frequencies.

First set par. ID108 to *Programmable U/f curve* (value 2). Increase zero point voltage (ID606) to get enough current at zero speed. Set then the midpoint voltage (ID605) to $1.4142 \cdot \text{ID606}$ and midpoint frequency (ID604) to value $\text{ID606}/100\% \cdot \text{ID111}$.

NOTE! In high torque – low speed applications – it is likely that the motor will overheat. If the motor has to run a prolonged time under these conditions, special attention must be paid to cooling the motor. Use external cooling for the motor if the temperature tends to rise too high.

110 ***Nominal voltage of the motor*** (2.1.6)

Find this value U_n on the rating plate of the motor. This parameter sets the voltage at the field weakening point (ID603) to $100\% \cdot U_{n\text{Motor}}$. Note also used connection Delta/Star.

111 ***Nominal frequency of the motor*** (2.1.7)

Find this value f_n on the rating plate of the motor. This parameter sets the field weakening point (ID602) to the same value.

112 ***Nominal speed of the motor*** (2.1.8)

Find this value n_n on the rating plate of the motor.

113 ***Nominal current of the motor*** (2.1.9)

Find this value I_n on the rating plate of the motor.

114 ***Stop button activated*** (3.4)

If you wish to make the Stop button a "hotspot" which always stops the drive regardless of the selected control place, give this parameter the value 1.
See also parameter ID125.

117 I/O A frequency reference selection (2.1.11)

Defines which frequency reference source is selected when controlled from the I/O control place.

Selection	
0	Analogue volt.ref. Terminals 2-3
1	Analogue curr.ref. Terminals 4-5
2	Keypad reference (Menu M3)
3	Fieldbus reference
4	Motor Potentiometer

Table 2-1. Selections for parameter ID117

120 Motor cos phi (2.1.10)

Find this value "cos phi" on the rating plate of the motor.

121 Keypad frequency reference selection (2.1.13)

Defines which frequency reference source is selected when controlled from the keypad.

Selection	
0	Analogue volt.ref. Terminals 2-3
1	Analogue curr.ref. Terminals 4-5
2	Keypad reference (Menu M3)
3	Fieldbus reference*

Table 2-2. Selections for parameter ID121

*FBSpeedReference

122 Fieldbus frequency reference selection (2.1.14)

Defines which frequency reference source is selected when controlled from the fieldbus. For selections in different applications, see ID121.

125 Control Place (3.1)

The active control place can be changed with this parameter. For more information, see the product's user's manual.

123 Keypad Direction (3.3)

- 0 Forward: The rotation of the motor is forward, when the keypad is the active control place.
- 1 Reverse: The rotation of the motor is reversed, when the keypad is the active control place.

For more information, see the product's user's manual.

124 Jogging speed reference (2.1.15)

Defines the jogging speed selected with the DIN3 digital input which can be programmed for Jogging speed. See parameter [ID301](#).

Parameter value is automatically limited between minimum and maximum frequency ([ID's 101 and 102](#)).

131 *I/O frequency reference selection, place B* (2.1.12)
See the values of the parameter [ID117](#) above

- 0 DIN1: closed contact = start forward
- DIN2: closed contact = start reverse




Figure 2-3. Start forward/Start reverse

- ① The first selected direction has the highest priority.
- ② When the DIN1 contact opens the direction of rotation starts the change.
- ③ If Start forward (DIN1) and Start reverse (DIN2) signals are active simultaneously the Start forward signal (DIN1) has priority.

- 1 DIN1: closed contact = start open contact = stop
- DIN2: closed contact = reverse open contact = forward
- See below.




Figure 2-4. Start, Stop, Reverse

- 2 DIN1: closed contact = start open contact = stop
- DIN2: closed contact = start enabled open contact = start disabled and drive stopped if running
- (DIN3 can be programmed for reverse command)

- 3 3-wire connection (pulse control):
 DIN1: closed contact = start pulse
 DIN2: open contact = stop pulse
 (DIN3 can be programmed for reverse command)
 See Figure 2-5.




Figure 2-5. Start pulse/ Stop pulse.

The selections including the text '**Rising edge required to start**' shall be used to exclude the possibility of an unintentional start when, for example, power is connected, re-connected after a power failure, after a fault reset, after the drive is stopped by Run Enable (Run Enable = False) or when the control place is changed. The Start/Stop contact must be opened before the motor can be started.

- 4 DIN1: closed contact = start forward (**Rising edge required to start**)
 DIN2: closed contact = reference increases (motor potentiometer reference; this parameter is automatically set to 4 if par. ID117 is set to 3 or 4).
- 5 DIN1: closed contact = start Forward (**Rising edge required to start**)
 open contact = stop
 DIN2: closed contact = Start Reverse
 open contact = stop (**Rising edge required to start**)
- 6 DIN1: closed contact = start (**Rising edge required to start**)
 open contact = stop
 DIN2: closed contact = Reverse
 open contact = Forward
- 7 DIN1: closed contact = start (**Rising edge required to start**)
 open contact = stop
 DIN2: closed contact = start enabled
 open contact = start disabled and drive stopped if running
- 8 DIN1: closed contact = start forward (**Rising edge required to start**)

DIN2: closed contact = reference increases (motor potentiometer reference; this parameter is automatically set to 4 if par. ID117 is set to 3 or 4).

301

DIN3 function

(2.2.2)

- 0 Not used
- 1 External fault, closing contact = Fault is shown and motor is stopped when the input is active.
- 2 External fault, opening contact = Fault is shown and motor is stopped when the input is not active.
- 3 Run enable, contact open = Motor start disabled and the motor is stopped
 contact closed = Motor start enabled
- 4 Acc./Dec contact open = Acceleration/deceleration time 1 selected
 time select. contact closed = Acceleration/deceleration time 2 selected
- 5 Closing contact: Force control place to I/O terminal
- 6 Closing contact: Force control place to keypad
- 7 Closing contact: Force control place to fieldbus
 When the control place is forced to change the values of Start/Stop, Direction and Reference valid in the respective control place are used (reference according to parameters ID117, ID121 and ID122).
Note: The value of parameter ID125 Keypad Control Place does not change. When DIN3 opens the control place is selected according to parameter 3.1.
- 8 Reverse contact open = Forward
 contact closed = Reverse
- 9 Jogging sp. contact closed = Jogging speed selected for frequency reference
- 10 Fault reset contact closed = Resets all faults
- 11 Acc./dec. operation prohibited
 contact closed = Stops acceleration or deceleration until the contact is opened
- 12 DC-braking command
contact closed = In Stop mode, the DC-braking operates until the contact is opened, see

Can be used for reversing if start signal 2 is used for other functions

Figure 2-6

- 13 Motor potentiometer down
 contact closed = Reference decreases until the contact is opened




Figure 2-6. DIN3 as DC-brake command input: a) Stop mode = Ramp, b) Stop mode = coasting

303 Reference scaling, minimum value (2.2.16)

304 Reference scaling, maximum value (2.2.17)

Setting value limits: $0 \leq \text{par. ID303} \leq \text{par. ID304} \leq \text{par. ID102}$. If both parameter ID303 and parameter ID394 = 0 scaling is set off. The minimum and maximum frequencies are used for scaling.




Figure 2-7. Left: Reference scaling; Right: No scaling used (par. ID303 = 0).


307 Analogue output function (2.3.2)

This parameter selects the desired function for the analogue output signal.

308 *Analogue output filter time*

(2.3.3)

Defines the filtering time of the analogue output signal. Setting this parameter value



0 will deactivate filtering.

Figure 2-8. Analogue output filtering

309 *Analogue output inversion*

(2.3.4)

Inverts the analogue output signal:

Maximum output signal = Minimum set value

Minimum output signal = Maximum set value

See parameter [ID311](#) below.




Figure 2-9. Analogue output invert

310 *Analogue output minimum*

(2.3.5)

Defines the signal minimum to either 0 mA or 4 mA (living zero). Note the difference in analogue output scaling in parameter [ID311](#) (


Figure 2-10).

- 0 Set minimum value to 0 mA
- 1 Set minimum value to 4 mA

311 **Analogue output scale** (2.3.6)

Scaling factor for analogue output.

Signal	Max. value of the signal
Output frequency	Max frequency (par.ID102)
Freq. Reference	Max frequency (par.ID102)
Motor speed	Motor nom. speed $1 \times n_{nMotor}$
Output current	Motor nom. current $1 \times I_{nMotor}$
Motor torque	Motor nom. torque $1 \times T_{nMotor}$
Motor power	Motor nom. power $1 \times P_{nMotor}$
Motor voltage	$100\% \times U_{nMotor}$



DC-link voltage	1000 V
PI-ref. value	100% x ref. value max.
PI act. value 1	100% x actual value max.
PI act. value 2	100% x actual value max.
PI error value	100% x error value max.
PI output	100% x output max.

Table 2-3. Analogue output scaling

Figure 2-10. Analogue output scaling

312 **Digital output function** (2.3.7)

313 **Relay output 1 function** (2.3.8)

314 **Relay output 2 function** (2.3.9)

Setting value	Signal content
0 = Not used	Out of operation
	<u>Digital output DO1 sinks the current and programmable relay (R01, R02) is activated when:</u>
1 = Ready	The frequency converter is ready to operate
2 = Run	The frequency converter operates (motor is running)

3 = Fault	A fault trip has occurred
4 = Fault inverted	A fault trip <u>not</u> occurred
5 = Vacon overheat warning	The heat-sink temperature exceeds +70°C
6 = External fault or warning	Fault or warning depending on par. ID701
7 = Reference fault or warning	Fault or warning depending on par. ID700 - if analogue reference is 4—20 mA and signal is <4mA
8 = Warning	Always if a warning exists
9 = Reversed	The reverse command has been selected
10 = Jogging speed	The jogging speed has been selected with digital input
11 = At speed	The output frequency has reached the set reference
12 = Motor regulator activated	Overvoltage or overcurrent regulator was activated
13 = Output frequency limit supervision	The output frequency goes outside the set supervision low limit/high limit (see parameter ID's 315 and 316 below)
14 = Output freq.limit 2 supervision	The output frequency goes outside the set supervision low limit/high limit (see parameter ID's 346 and 347 below)
15 = Torque limit supervision	The motor torque goes beyond the set supervision low limit/high limit (par. ID348 and ID349).
16 = Reference limit supervision	Active reference goes beyond the set supervision low limit/high limit (par. ID350 and ID351)
17 = External brake control	External brake ON/OFF control with programmable delay (par. ID352 and ID353)
18 = Control from I/O terminals	External control mode (Menu M3 ; ID125)
19 = Frequency converter temperature limit supervision	Frequency converter heatsink temperature goes beyond the set supervision limits (par. ID354 and ID355).
20 = Unrequested rotation direction	Rotation direction is different from the requested one.
21 = External brake control inverted	External brake ON/OFF control (par. ID352 and ID353); Output active when brake control is OFF
22 = Thermistor fault or warning	The thermistor input of option board indicates overtemperature. Fault or warning depending on parameter ID732 .

Table 2-4. Output signals via D01 and output relays R01 and R02.

315 **Output frequency limit supervision function** (2.3.10)

- 0 No supervision
- 1 Low limit supervision
- 2 High limit supervision

If the output frequency goes under/over the set limit (ID316) this function generates a warning message via the digital output D01 or via the relay output R01 or R02 depending on the settings of parameters [ID312...ID314](#).

316 *Output frequency limit supervision value* (2.3.11)

Selects the frequency value supervised by parameter ID315.




Figure 2-11. Output frequency supervision

320 *AI1 signal range* (2.2.4)

Applic.	3,4,5
Sel.	
0	0...100%
1	20...100%
2	Customised
3	

Table 2-5. Selections for parameter ID320

For selection 'Customised', see parameters ID321 and ID322.

321 *AI1 custom setting minimum* (2.2.5)

322 *AI1 custom setting maximum* (2.2.6)

These parameters set the analogue input signal for any input signal span within 0—160%.

323 *AI1 signal inversion* (2.2.7)

If this parameter = 0, no inversion of analogue U_{in} signal takes place.

Note: In application 3, AI1 is place B frequency reference if parameter ID131 = 0 (default).




Figure 2-12. AI1 no signal inversion

If this parameter = 1 inversion of analogue signal takes place.
 max. AI1 signal = minimum set speed
 min. AI1 signal = maximum set speed




Figure 2-13. AI1 signal inversion

324 **AI1 signal filter time** (2.2.8)

When this parameter is given a value greater than 0 the function that filters out disturbances from the incoming analogue signal is activated.

Long filtering time makes the regulation response slower.




Figure 2-14. AI1 signal filtering


325 **Analogue input AI2 signal range** (2.2.10)

Applic.	3, 4
Sel.	
0	0...20mA
1	4...20mA
2	Customised
3	

Table 2-6. Selections for parameter ID325

326 *Analogue input AI2 custom setting min.* (2.2.11)

327 *Analogue input AI2 custom setting max.* (2.2.12)



These parameters set AI2 for any input signal span within 0...160%.

Figure 2-15. Analogue input AI2 scaling.

328 *Analogue input AI2 inversion* (2.2.13)

See [ID323](#).

Note: AI2 is the place A frequency reference, if parameter [ID117](#) = 1 (default)

329 *Analogue input AI2 (I_{in}) filter time* (2.2.14)

See [ID324](#)

346 *Output freq. limit 2 supervision function* (2.3.12)

- 0 No supervision
- 1 Low limit supervision
- 2 High limit supervision

347 *Output frequency limit 2 supervision value* (2.3.13)

Selects the frequency value supervised by parameter [ID346](#).

348 *Torque limit, supervision function* (2.3.14)

- 0 = No supervision
- 1 = Low limit supervision
- 2 = High limit supervision

349 *Torque limit, supervision value* (2.3.15)

Set here the torque value to be supervised by parameter [ID348](#).

Torque supervision value can be reduced below the setpoint with external free analogue input signal, see parameters [ID361](#) and [ID362](#).

350 Reference limit, supervision function (2.3.16)

- 0 = No supervision
- 1 = Low limit supervision
- 2 = High limit supervision

If the reference value falls below or exceeds the set limit (ID351), this function generates a warning message via the digital output DO1 or via a relay output R01 or R02
Depending on the settings of parameters ID312 to ID314

The supervised reference is the current active reference. It can be place A or B reference depending on DIN6 input, or panel reference if the panel is the active control place.

351 Reference limit, supervision value (2.3.17)

The frequency value to be supervised with the parameter ID350.

352 External brake-off delay (2.3.18)

353 External brake-on delay (2.3.19)

The function of the external brake can be timed to the start and stop control signals with these parameters. See Figure 2-16.

The brake control signal can be programmed via the digital output DO1 or via one of the relay outputs R01 and R02, see parameters ID312 to ID314




Figure 2-16. External brake control:
 a) Start/Stop logic selection, ID300 = 0, 1 or 2
 b) Start/Stop logic selection, ID300= 3

354 Frequency converter temperature limit supervision (2.3.20)

- 0 = No supervision
- 1 = Low limit supervision
- 2 = High limit supervision

If the temperature of the frequency converter unit falls below or exceeds the set limit (ID355), this function generates a warning message via the digital output DO1 or via a relay output R01 or R02
Depending on the settings of parameters ID312 to ID314

355 *Frequency converter temperature limit value* (2.3.21)

This temperature value is supervised by parameter [ID354](#).

361 *Free analogue input, signal selection* (2.2.20)

Selection of input signal of a free analogue input (an input not used for reference signal):

- 0 = Not in use
- 1 = Voltage signal U_{in}
- 2 = Current signal I_{in}

362 *Free analogue input, function* (2.2.21)

This parameter is used for selecting a function for a free analogue input signal:

- 0 = Function is not in use
- 1 = Reduces motor current limit ([ID107](#))

This signal will adjust the maximum motor current between 0 and max. limit set with [ID107](#).




Figure 2-17. Scaling of max. motor current

- 2 = Reduces DC braking current.

DC braking current can be reduced with the free analogue input signal between zero current and the current set with the parameter [ID507](#).




Figure 2-18. Reduction of DC braking current

3 = Reduces acceleration and deceleration times.

Acceleration and deceleration times can be reduced with the free analogue input signal according to the following formulas:

Reduced time = set acc./deceler. time (par. [ID103](#), [ID104](#); [ID502](#), [ID503](#)) divided by the factor R.




Figure 2-19. Reduction of acceleration and deceleration times

4 = Reduces torque supervision limit

Set supervision limit can be reduced with the free analogue input signal between 0 and set supervision limit ([ID349](#)).




Figure 2-20. Reduction of torque supervision limit

- 0 DIE1: closed contact = start forward
- DIE2: closed contact = start reverse




Figure 2-21. Start forward/Start reverse

- ① The first selected direction has the highest priority.
- ② When the DIE1 contact opens the direction of rotation starts the change.
- ③ If Start forward (DIE1) and Start reverse (DIE2) signals are active simultaneously the Start forward signal (DIE1) has priority.

- 1 DIE1: closed contact = start open contact = stop
- DIE2: closed contact = reverse open contact = forward




Figure 2-22. Start, Stop, Reverse

- 2 DIE1: closed contact = start open contact = stop
- DIE2: closed contact = start enabled open contact = start disabled and drive stopped if running

- 3 3-wire connection (pulse control):
 DIE1: closed contact = start pulse
 DIE2: open contact = stop pulse
 (DIN3 can be programmed for reverse command)




Figure 2-23. Start pulse/ Stop pulse.

The selections 4 to 6 shall be used to exclude the possibility of an unintentional start when, for example, power is connected, re-connected after a power failure, after a fault reset, after the drive is stopped by Run Enable (Run Enable = False) or when the control place is changed. The Start/Stop contact must be opened before the motor can be started.

- 4 DIE1: closed contact = start forward (**Rising edge required to start**)
 DIE2: closed contact = start reverse (**Rising edge required to start**)
- 5 DIE1: closed contact = start (**Rising edge required to start**)
 open contact = stop
 DIE2: closed contact = reverse
 open contact = forward
- 6 DIE1: closed contact = start (**Rising edge required to start**)
 open contact = stop
 DIE2: closed contact = start enabled
 open contact = start disabled and drive stopped if running

364 Reference scaling, minimum value, place B (2.2.18)

365 Reference scaling, maximum value, place B (2.2.19)

See parameters [ID303](#) and [ID304](#) above.


331 Motor potentiometer ramp time (2.2.22)

Defines the speed of change of the motor potentiometer value (Hz/s).

377

A11 signal selection

(2.2.3)



Connect the A11 signal to the analogue input of your choice with this parameter.

Figure 1- 1. A11 signal selection

The value of this parameter is formed of the *board indicator* and the *respective input terminal number*. See Figure 1- 2 above.

Board indicator 1	= Local inputs
Board indicator 2	= Expander board inputs
Input number 0	= Input 1
Input number 1	= Input 2
Input number 2	= Input 3
⋮	
Input number 9	= Input 10

Example:

If you set the value of this parameter to **10**, you have selected the local input **1** for the A11 signal. Again, if the value is set to **21**, the expander board input **2** has been selected for the A11 signal.

If you want to use the values of analogue input signal for e.g. testing purposes only, you can set the parameter value to **0 - 9**. In this case, value **0** corresponds to **0%**, value **1** corresponds to **20%** and any value between **2** and **9** corresponds to **100%**.

NOTE: It is possible to use the TTF method with Ncdrive (A.1 = 10, A.2 = 11...)

367

Motor potentiometer memory reset (Frequency reference)

(2.2.23)

- 0 No reset
- 1 Memory reset in stop and powerdown
- 2 Memory reset in powerdown

498

Start pulse memory

(2.2.24)

Giving a value for this parameter determines if the present RUN status is copied when the control place is changed from A to B or vice versa.


- 0 = The RUN status is not copied
- 1 = The RUN status is copied

In order for this parameter to have effect, parameters ID300 and ID363 must have been set the value 3.

464

Analogue output 1 signal selection

(2.3.1)



Connect the A01 signal to the analogue output of your choice with this parameter.
 Figure 1- 2. A01 signal selection

The value of this parameter is formed of the *board indicator* and the *respective output terminal number*. See Figure 1- 1 above.

Board indicator 1	= Local output
Board indicator 2	= Expander board output
Input number 0	= Output 1
Input number 1	= Output 2
Input number 2	= Output 3
⋮	
Input number 9	= Output 10

Example:

If you set the value of this parameter to **10**, you have selected the local analogue output **1** for the A01 signal. Again, if the value is set to **21**, the expander board analogue output **2** has been selected for the A01 signal. (Not available on the OPTAA board)

NOTE: It is possible to use the TTF method with NCdrive (A.1 = 10, A.2 = 11...)

471

Analogue output 2 signal selection

(2.3.22)

See description for ID464 above

472

Analogue output 2 function

(2.3.23)

473

Analogue output 2 filter time

(2.3.24)

474

Analogue output 2 inversion

(2.3.25)

475

Analogue output 2 minimum

(2.3.26)

476

Analogue output 2 scaling

(2.3.27)

For more information on these five parameters, see the corresponding parameters for the analogue output 1.

500

Acceleration/Deceleration ramp 1 shape

(2.4.1)

501 *Acceleration/Deceleration ramp 2 shape* [2.4.2]

The start and end of acceleration and deceleration ramps can be smoothed with these parameters. Setting value **0** gives a linear ramp shape which causes acceleration and deceleration to act immediately to the changes in the reference signal. Setting value 0.1...10 seconds for this parameter produces an S-shaped acceleration/deceleration. The acceleration time is determined with parameters [ID103/ID104](#) ([ID502/ID503](#)).




Figure 2-24. Acceleration/Deceleration (S-shaped)

502 *Acceleration time 2* [2.4.3]

503 *Deceleration time 2* [2.4.4]

These values correspond to the time required for the output frequency to accelerate from the zero frequency to the set maximum frequency (par. [ID102](#)). These parameters give the possibility to set two different acceleration/deceleration time sets for one application. The active set can be selected with the programmable signal DIN3 (par. [ID301](#)).

504 *Brake chopper* [2.4.5]

- 0 = No brake chopper used
- 1 = Brake chopper in use and tested when running. Can be tested also in READY state
- 2 = External brake chopper (no testing)
- 3 = Used and tested in READY state and when running
- 4 = Used when running (no testing)

When the frequency converter is decelerating the motor, the inertia of the motor and the load are fed into an external brake resistor. This enables the frequency converter to decelerate the load with a torque equal to that of acceleration (provided that the correct brake resistor has been selected). See separate Brake resistor installation manual.

505 *Start function* [2.4.6]

Ramp:

- 0 The frequency converter starts from 0 Hz and accelerates to the set reference frequency within the set [acceleration time](#). (Load inertia or starting friction may cause prolonged acceleration times).

Flying start:

- 1 The frequency converter is able to start into a running motor by applying a small torque to motor and searching for the frequency corresponding to the speed the motor is running at. Searching starts from the maximum frequency towards the actual frequency until the correct value is detected. Thereafter, the output frequency will be increased/decreased to the set reference value according to the set acceleration/deceleration parameters.

Use this mode if the motor is coasting when the start command is given. With the flying start it is possible to ride through short mains voltage interruptions.

506 *Stop function* (2.4.7)

Coasting:

- 0 The motor coasts to a halt without any control from the frequency converter, after the Stop command.

Ramp:

- 1 After the Stop command, the speed of the motor is decelerated according to the set deceleration parameters.
If the regenerated energy is high it may be necessary to use an external braking resistor for faster deceleration.

Normal stop: Ramp/ Run Enable stop: coasting

- 2 After the Stop command, the speed of the motor is decelerated according to the set deceleration parameters. However, when Run Enable is selected, the motor coasts to a halt without any control from the frequency converter.

Normal stop: Coasting/ Run Enable stop: ramping

- 3 The motor coasts to a halt without any control from the frequency converter. However, when Run Enable signal is selected, the speed of the motor is decelerated according to the set deceleration parameters. If the regenerated energy is high it may be necessary to use an external braking resistor for faster deceleration.

507 *DC-braking current* (2.4.8)

Defines the current injected into the motor during DC-braking.

508 *DC-braking time at stop* (2.4.9)

Determines if braking is ON or OFF and the braking time of the DC-brake when the motor is stopping. The function of the DC-brake depends on the stop function, parameter [ID506](#).

- 0 DC-brake is not used
>0 DC-brake is in use and its function depends on the Stop function, (param. [ID506](#)). The DC-braking time is determined with this parameter.

Par. ID506 = 0; Stop function = Coasting:

After the stop command, the motor coasts to a stop without control of the frequency converter.

With DC-injection, the motor can be electrically stopped in the shortest possible time, without using an optional external braking resistor.

The braking time is scaled according to the frequency when the DC-braking starts. If the frequency is \geq the nominal frequency of the motor, the set value of parameter ID508 determines the braking time. When the frequency is $\leq 10\%$ of the nominal, the braking time is 10% of the set value of parameter ID508.




Figure 2-25. DC-braking time when Stop mode = Coasting.

Par. ID506 = 1; Stop function = Ramp:

After the Stop command, the speed of the motor is reduced according to the set deceleration parameters, as fast as possible, to the speed defined with parameter ID515, where the DC-braking starts.

The braking time is defined with parameter ID508. If high inertia exists, it is recommended to use an external braking resistor for faster deceleration.




Figure 2-26. DC-braking time when Stop mode = Ramp

515 DC-braking frequency at stop (2.4.10)

The output frequency at which the DC-braking is applied.

518 *Acceleration/deceleration ramp speed scaling ratio between prohibit frequency limits* (2.5.7)

Defines the acceleration/deceleration time when the output frequency is between the selected prohibit frequency range limits (parameters ID509 and ID510). The ramping speed (selected acceleration/ deceleration time 1 or 2) is multiplied with this factor. E.g. value 0.1 makes the acceleration time 10 times shorter than outside the prohibit frequency range limits.




Figure 2-28. Ramp speed scaling between prohibit frequencies

600 *Motor control mode*

- 0 Frequency control: The I/O terminal and keypad references are frequency references and the frequency converter controls the output frequency (output frequency resolution = 0.01 Hz)
- 1 Speed control: The I/O terminal and keypad references are speed references and the frequency converter controls the motor speed compensating the motor slip (accuracy ± 0,5%).

601 *Switching frequency* (2.6.9)

Motor noise can be minimised using a high switching frequency. Increasing the switching frequency reduces the capacity of the frequency converter unit. The range of this parameter depends on the size of the frequency converter:

Type	Min. [kHz]	Max. [kHz]	Default [kHz]
0003—0061 NX_5 0003—0061 NX_2	1.0	16,0	10.0
0072—0520 NX_5	1.0	10.0	3.6
0041—0062 NX_6 0144—0208 NX_6	1.0	6.0	1.5

Table 2-7. Size-dependent switching frequencies

Note! The actual switching frequency might be reduced down to 1,5kHz by thermal management functions. This has to be considered when using sine wave filters or

other output filters with a low resonance frequency.

602 *Field weakening point* (2.6.4)

The field weakening point is the output frequency at which the output voltage reaches the set (ID603) maximum value.

603 *Voltage at field weakening point* (2.6.5)

Above the frequency at the field weakening point, the output voltage remains at the set maximum value. Below the frequency at the field weakening point, the output voltage depends on the setting of the U/f curve parameters. See parameters ID109, ID108, ID604 and ID605.

When the parameters ID110 and ID111 (nominal voltage and nominal frequency of the motor) are set, the parameters ID602 and ID603 are automatically given the corresponding values. If you need different values for the field weakening point and the maximum output voltage, change these parameters **after** setting the parameters ID110 and ID111.

604 *U/f curve, middle point frequency* (2.6.6)

If the programmable U/f curve has been selected with parameter ID108 this parameter defines the middle point frequency of the curve.

605 *U/f curve, middle point voltage* (2.6.7)

If the programmable U/f curve has been selected with the parameter ID108 this parameter defines the middle point voltage of the curve.

606 *Output voltage at zero frequency* (2.6.8)

If the programmable U/f curve has been selected with the parameter ID108 this parameter defines the zero frequency voltage of the curve. NOTE: If the value of parameter ID108 is changed this parameter is set to zero.

607 *Overvoltage controller* (2.6.10)

These parameters allow the under-/overvoltage controllers to be switched out of operation. This may be useful, for example, if the mains supply voltage varies more than -15% to +10% and the application will not tolerate this over-/undervoltage. In this case, the regulator controls the output frequency taking the supply fluctuations into account.

0 Controller switched off

1 Controller switched on (no ramping) = Minor adjustments of OP frequency are made

2 Controller switched on (with ramping) = Controller adjusts OP freq. up to max.freq.

608 *Undervoltage controller* (2.6.11)

See par. ID607.

Note: Over-/undervoltage trips may occur when controllers are switched out of operation.

0 Controller switched off

1 Controller switched on (no ramping) = Minor adjustments of OP frequency are made

2 Controller switched on (with ramping) = Controller adjusts OP freq. up to zero speed

- 700** *Response to the 4mA reference fault* (2.7.1)
- 0 = No response
 1 = Warning
 2 = Warning, the frequency from 10 seconds back is set as reference
 3 = Warning, the Preset Frequency (Par. ID728) is set as reference
 4 = Fault, stop mode after fault according to ID506
 5 = Fault, stop mode after fault always by coasting
- A warning or a fault action and message is generated if the 4...20 mA reference signal is used and the signal falls below 3.5 mA for 5 seconds or below 0.5 mA for 0.5 seconds. The information can also be programmed into digital output DO1 or relay outputs RO1 and RO2.
- 701** *Response to external fault* (2.7.3)
- 0 = No response
 1 = Warning
 2 = Fault, stop mode after fault according to ID506
 3 = Fault, stop mode after fault always by coasting
- A warning or a fault action and message is generated from the external fault signal in the programmable digital inputs DIN3. The information can also be programmed into digital output DO1 and into relay outputs RO1 and RO2.
- 702** *Output phase supervision* (2.7.6)
- 0 = No response
 1 = Warning
 2 = Fault, stop mode after fault according to ID506
 3 = Fault, stop mode after fault always by coasting
- Output phase supervision of the motor ensures that the motor phases have an approximately equal current.
- 703** *Earth fault protection* (2.7.7)
- 0 = No response
 1 = Warning
 2 = Fault, stop mode after fault according to ID506
 3 = Fault, stop mode after fault always by coasting
- Earth fault protection ensures that the sum of the motor phase currents is zero. The overcurrent protection is always working and protects the frequency converter from earth faults with high currents.
- 704** *Motor thermal protection* (2.7.8)
- 0 = No response
 1 = Warning
 2 = Fault, stop mode after fault according to ID506
 3 = Fault, stop mode after fault always by coasting
- If tripping is selected the drive will stop and activate the fault stage. Deactivating the protection, i.e. setting parameter to 0, will reset the thermal stage of the motor to 0%..

705 *Motor thermal protection: Motor ambient temp. factor* (2.7.9)

The factor can be set between -100.0%—100.0%.

706 *Motor thermal protection: Motor cooling factor at zero speed* (2.7.10)

The current can be set between 0—150.0% x I_{nMotor} . This parameter sets the value for thermal current at zero frequency.

The default value is set assuming that there is no external fan cooling the motor. If an external fan is used this parameter can be set to 90% (or even higher).

Note: The value is set as a percentage of the motor name plate data, par. ID113 (Nominal current of motor), not the drive's nominal output current. The motor's nominal current is the current that the motor can withstand in direct on-line use without being overheated.

If you change the parameter Nominal current of motor, this parameter is automatically restored to the default value.

Setting this parameter does not affect the maximum output current of the drive which is determined by parameter ID107 alone.




Figure 2-29. Motor thermal current I_T curve

707 *Motor thermal protection: Time constant* (2.7.11)

This time can be set between 1 and 200 minutes.

This is the thermal time constant of the motor. The bigger the motor, the bigger the time constant. The time constant is the time within which the calculated thermal stage has reached 63% of its final value.

The motor thermal time is specific to the motor design and it varies between different motor manufacturers.

If the motor's t_6 -time (t_6 is the time in seconds the motor can safely operate at six times the rated current) is known (given by the motor manufacturer) the time constant parameter can be set basing on it. As a rule of thumb, the motor thermal time constant in minutes equals to $2xt_6$. If the drive is in stop stage the time constant is internally increased to three times the set parameter value. The cooling in the stop stage is based on convection and the time constant is increased.

708 **Motor thermal protection: Motor duty cycle 234567** [2.7.12]

Defines how much of the nominal motor load is applied. The value can be set to 0%...100%..




Figure 2-30. Motor temperature calculation

709 **Stall protection** [2.7.13]

- 0 = No response
- 1 = Warning
- 2 = Fault, stop mode after fault according to ID506
- 3 = Fault, stop mode after fault always by coasting

Setting the parameter to 0 will deactivate the protection and reset the stall time counter.

710 **Stall current limit** [2.7.14]

The current can be set to 0.0...2*I_H. For a stall stage to occur, the current must have exceeded this limit. See Figure 2-31. The software does not allow entering a greater value than 2*I_H. If parameter ID107 Nominal current limit of motor is changed, this parameter is automatically calculated to 90% of the current limit.




Figure 2-31. Stall characteristics settings

711 Stall time

This time can be set between 1.0 and 120.0s.
 This is the maximum time allowed for a stall stage. The stall time is counted by an internal up/down counter.
 If the stall time counter value goes above this limit the protection will cause a trip (see ID709).

(2.7.15)




Figure 2-32. Stall time count

712 Stall frequency limit

The frequency can be set between $1-f_{max}$ (ID102).
 For a stall state to occur, the output frequency must have remained below this limit.

(2.7.16)

713 Underload protection

- 0 = No response
- 1 = Warning
- 2 = Fault, stop mode after fault according to ID506
- 3 = Fault, stop mode after fault always by coasting

If tripping is set active the drive will stop and activate the fault stage.
 Deactivating the protection by setting the parameter to 0 will reset the underload time counter to zero.

(2.7.17)

714 Underload protection, field weakening area load

The torque limit can be set between $10.0-150.0\% \times T_{nMotor}$.
 This parameter gives the value for the minimum torque allowed when the output frequency is above the field weakening point.

If you change parameter ID113 (Motor nominal current) this parameter is automatically restored to the default value.

(2.7.18)




Figure 2-33. Setting of minimum load

715 *Underload protection, zero frequency load* (2.7.19)

The torque limit can be set between 5.0—150.0 % x TnMotor.
This parameter gives value for the minimum torque allowed with zero frequency.

If you change the value of parameter ID113 (Motor nominal current) this parameter is automatically restored to the default value.

716 *Underload time* (2.7.20)

This time can be set between 2.0 and 600.0 s.

This is the maximum time allowed for an underload state to exist. An internal up/down counter counts the accumulated underload time. If the underload counter value goes above this limit the protection will cause a trip according to parameter ID713). If the drive is stopped the underload counter is reset to zero.




Figure 2-34. Underload time counter function

717 *Automatic restart: Wait time* (2.8.1)

Defines the time before the frequency converter tries to automatically restart the motor after the fault has disappeared.

718 *Automatic restart: Trial time* (2.8.2)

The Automatic restart function restarts the frequency converter when the faults selected with parameters ID720 to ID725 have disappeared and the waiting time has elapsed.




Figure 2-35. Example of Automatic restarts with two restarts

Parameters ID720 to ID725 determine the maximum number of automatic restarts during the trial time set by parameter ID718. The time count starts from the first autorestart. If the number of faults occurring during the trial time exceeds the values of parameters ID720 to ID725 the fault state becomes active. Otherwise the fault is cleared after the trial time has elapsed and the next fault start the trial time count again.

If a single fault remains during the trial time, a fault state is true.

719 Automatic restart: Start function (2.8.3)

The Start function for Automatic restart is selected with this parameter. The parameter defines the start mode:

- 0 = Start with ramp
- 1 = Flying start
- 2 = Start according to ID505

720 Automatic restart: Number of tries after undervoltage fault trip (2.8.4)

This parameter determines how many automatic restarts can be made during the trial time set by parameter ID718 after and undervoltage trip.

- 0 = No automatic restart
- >0 = Number of automatic restarts after undervoltage fault. The fault is reset and the drive is started automatically after the DC-link voltage has returned to the normal level.

721 Automatic restart: Number of tries after overvoltage trip (2.8.5)

This parameter determines how many automatic restarts can be made during the trial time set by parameter [ID718](#) after an overvoltage trip.

- 0 = No automatic restart after overvoltage fault trip
- >0 = Number of automatic restarts after overvoltage fault trip. The fault is reset and the drive is started automatically after the DC-link voltage has returned to the normal level.

722 Automatic restart: Number of tries after overcurrent trip (2.8.6)

(NOTE! IGBT temp fault also included)

This parameter determines how many automatics restarts can be made during the trial time set by [ID718](#).

- 0 = No automatic restart after overcurrent fault trip
- >0 = Number of automatic restarts after overcurrent trip and IGBT temperature faults.

723 Automatic restart: Number of tries after 4mA reference trip (2.8.7)

This parameter determines how many automatics restarts can be made during the trial time set by [ID718](#).

- 0 = No automatic restart after reference fault trip
- >0 = Number of automatic restarts after the analogue current signal (4...20mA) has returned to the normal level ($\geq 4\text{mA}$)

725 Automatic restart: Number of tries after external fault trip (2.8.9)

This parameter determines how many automatics restarts can be made during the trial time set by [ID718](#).

- 0 = No automatic restart after External fault trip
- >0 = Number of automatic restarts after External fault trip

726 Automatic restart: Number of tries after motor temperature fault trip (2.8.8)

This parameter determines how many automatics restarts can be made during the trial time set by [ID718](#).

- 0 = No automatic restart after Motor temperature fault trip
- >0 = Number of automatic restarts after the motor temperature has returned to its normal level

732 Response to thermistor fault (2.7.21)

- 0 = No response
- 1 = Warning
- 2 = Fault, stop mode after fault according to [ID506](#)
- 3 = Fault, stop mode after fault always by coasting

Setting the parameter to 0 will deactivate the protection.

733 ***Response to fieldbus fault****(2.7.22)*

Set here the response mode for the fieldbus fault if a fieldbus board is used. For more information, see the respective Fieldbus Board Manual.

See parameter [ID732](#).

734 ***Response to slot fault****(2.7.23)*

Set here the response mode for a board slot fault due to missing or broken board.

See parameter [ID732](#).

738 ***Automatic restart: Number of tries after underload fault trip****(2.8.10)*

This parameter determines how many automatic restarts can be made during the trial time set by parameter [ID718](#).

- 0** = No automatic restart after Underload fault trip
- >0** = Number of automatic restarts after Underload fault trip

Vaasa

Vacon Plc (Head office and production)
Runsorintie 7
65380 Vaasa
firstname.lastname@vacon.com
telephone: +358 (0)201 2121
fax: +358 (0)201 212 205

Helsinki

Vacon Plc
Äyritie 12
01510 Vantaa
telephone: +358 (0)201 212 600
fax: +358 (0)201 212 699

Tampere

Vacon Plc
Vehnämyllynkatu 18
33700 Tampere
telephone: +358 (0)201 2121
fax: +358 (0)201 212 750

Vacon Traction Oy

Vehnämyllynkatu 18
33700 Tampere
telephone: +358 (0)201 2121
fax: +358 (0)201 212 710

SALES COMPANIES AND REPRESENTATIVE OFFICES:**Austria**

Vacon AT Antriebssysteme GmbH
Aumühlweg 21
2544 Leobersdorf
telephone: +43 2256 651 66
fax: +43 2256 651 66 66

Belgium

Vacon Benelux NV/SA
Interleuvenlaan 62
3001 Heverlee (Leuven)
telephone: +32 (0)16 394 825
fax: +32 (0)16 394 827

France

Vacon France s.a.s.
ZAC du Fresne
1 Rue Jacquard – BP72
91280 Saint Pierre du Perray CDIS
telephone: +33 (0)1 69 89 60 30
fax: +33 (0)1 69 89 60 40

Germany

Vacon GmbH
Gladbecker Strasse 425
45329 Essen
telephone: +49 (0)201 806 700
fax: +49 (0)201 806 7099

Great Britain

Vacon Drives (UK) Ltd.
18, Maizefield
Hinckley Fields Industrial Estate
Hinckley
LE10 1YF Leicestershire
telephone: +44 (0)1455 611 515
fax: +44 (0)1455 611 517

Italy

Vacon S.p.A.
Via F.lli Guerra, 35
42100 Reggio Emilia
telephone: +39 0522 276811
fax: +39 0522 276890

The Netherlands

Vacon Benelux BV
Weide 40
4206 CJ Gorinchem
telephone: +31 (0)183 642 970
fax: +31 (0)183 642 971

Norway

Vacon AS
Langgata 2
3080 Holmestrand
telephone: +47 330 96120
fax: +47 330 96130

PR China

Vacon Suzhou Drives Co. Ltd.
Blk 11A
428 Xinglong Street
Suchun Industrial Square
Suzhou 215126
telephone: +86 512 6283 6630
fax: +86 512 6283 6618

Vacon Suzhou Drives Co. Ltd.

Beijing Office
A205, Grand Pacific Garden Mansion
8A Guanhua Road
Beijing 100026
telephone: +86 10 6581 3734
fax: +86 10 6581 3754

Russia

ZAO Vacon Drives
Bolshaja Jakimanka 31,
stroenie 18
109180 Moscow
telephone: +7 (095) 974 14 47
fax: +7 (095) 974 15 54

ZAO Vacon Drives

Zya Sovetskaya 7, office 210A
191036 St. Petersburg
telephone: +7 (812) 332 1114
fax: +7 (812) 279 9053

Singapore

Vacon Plc
Singapore Representative Office
102F Pasir Panjang Road
#02-06 Citilink Warehouse Complex
Singapore 118530
telephone: +65 6278 8533
fax: +65 6278 1066

Spain

Vacon Drives Ibérica S.A.
Miquel Servet, 2. P.I. Bufalvent
08243 Manresa
telephone: +34 93 877 45 06
fax: +34 93 877 00 09

Sweden

Vacon AB
Torget 1
172 67 Sundbyberg
telephone: +46 (0)8 293 055
fax: +46 (0)8 290 755

Vacon distributor: