



XDBKITS5 BUS / DB TERMINAL KIT (SIZE 5)

INSTALLATION MANUAL

DPD00116

Need Help?

This manual answers most installation and startup questions that may arise. However, if you have any problems, please let your first call be to us.

Vacon, Inc.
Chambersburg, PA 17202

Normal business hours:
(North America)

8:00 AM to 5:00 PM, Eastern time

+1 877-Vacon06

(+1 877-822-6606)

After-hours support is also available



and Vacon, Inc. are trademarks of Vacon Plc, a member of Vacon Group.
All other product names are trademarks of their respective companies.

Copyright 2009, Vacon, Incorporated. All rights reserved.

INSTALLING THE BUS / DB TERMINAL OPTION KIT

INTRODUCTION

The XDBKITS5 option kit is designed to allow the Size 5 X4 and X5 AC drives to be easily adapted to install either external DB resistors or to interconnect the DC bus terminal with another controller. Included in that Size 5 category are the following X4 and X5 drive models:

X4 AC Drive Model No.	X5 AC Drive Model No.
X4C41250D	X5C41250D
X4C41500D	X5C41500D
X4C42000D	X5C42000D
X4C51250D	X5C51250D
X4C51500D	X5C51500D
X4C52000D	X5C52000D

APPLICABLE DOCUMENTS

This manual is supplied as a supplement to the X4 AC Drive User's Manual (DPD 00088; previously Form 1428), and the X5 AC Drive User's Manual (DPD 00089; previously Form 1434).

OPTION KIT CONTENTS

The option kit is illustrated in Figure 1:




Figure 1: The XDBKITS5 option kit

INSTALLATION PROCEDURES

WARNING

SENSITIVE EQUIPMENT

This assembly contains static-sensitive components. It should be handled only by a static-safe installer, using a grounded wrist strap.

Failure to observe this precaution may cause premature equipment failure.

DANGER

HAZARDOUS VOLTAGE

- Disconnect all power before servicing a drive unit or its components. **WAIT 5 MINUTES** until the DC bus capacitors discharge.
- Ensure that any other power sources that may feed control logic have been disconnected.
- **DO NOT** short across DC bus capacitors or touch unshielded components or terminal strip screw connections with voltage present.
- Install all covers before applying power or starting and stopping the drive.
- The user is responsible for conforming to all applicable code requirements with respect to grounding all equipment.
- Many parts in a drive, including printed circuit boards, operate at line voltage. **DO NOT TOUCH.** Use only electrically-insulated tools.

Before servicing any drive.

- Disconnect all power.
- Place a “DO NOT TURN ON” label on the drive disconnect.
- Lock the disconnect in the open position.

Failure to observe these precautions will cause shock or burn, resulting in severe personal injury or death.

STEP 1.

Open the upper enclosure door by unthreading the door screws in four places. Lift and rotate the door into the open position.

STEP 2.

Install four power terminal blocks with the eight M6 Phillips-head screws and corresponding lock washers provided in the kit (see Figure 2). Tighten to a maximum torque of 26 in-lbs..




Figure 2: Installing power terminal blocks

STEP 3.

Remove the nut, washers, hex standoff, and setscrew from the terminal designated 1A (see Figure 3).

Discard the hex standoff and the setscrew, as these will no longer be needed.

Remove the bolt and washers from the terminal designated 2B (see Figure 3).




Figure 3: Location of terminals 1A, 2B

STEP 4.

Install the minus bar over the terminal previously designated 1A and to the respective power terminal block.

Reconnect wire 1A on top of the bus bar. Install and tighten the hardware previously removed in Step 3 using a maximum torque of 26 in-lbs. (See Figure 4.)

STEP 5.

Install the plus bar over the terminal previously designated 2B and to the respective power terminal block. Reconnect wire 2B on top of the bus bar. Install and tighten the hardware previously removed in Step 3 using a maximum torque of 26 in-lbs. (See Figure 4.)




Figure 4: Installing the minus bar and the plus bar




Figure 5: Installing bus bars

STEP 6.

Remove the M6 hex head screws, washers, and the leaded wires from the terminal designated 1B and 2A. (See Figure 5.)

STEP 7.

Install the minus bar to the terminal designated 2A and to the respective power terminal block. Re-install the M6 screws, washers, and leaded wire. Tighten, using a maximum torque of 26 in-lbs. (See Figure 5.)

STEP 8.

Install the collector bus bar to the terminal designated 1B and to the respective power terminal block. Re-install the M6 screws, washers, and leaded wires. Tighten using a maximum torque of 26 in-lbs. (See Figure 5.)

STEP 9.

.Install four flat washers provided in the kit. Tighten the four power terminal block nuts used for connecting the bus bars in the previous steps to a maximum of 132 in-lbs. (See Figure 6.)

The remaining four flat washers are to be used when connecting power wires to the unit.

STEP 10.

Cut the ends of the terminal cover off and snap the covers onto the power terminal blocks in eight places (see Figure 7 and Figure 8). Discard the plastic terminal cover ends.




Figure 6: Tightening power terminal block nuts




Figure 7: Cutting terminal covers




Figure 8: Placing covers on power terminal blocks

STEP 11.

Close the door and tighten the cover screws to a maximum of 26 in-lbs.

HEAD OFFICE AND PRODUCTION:**Vaasa**

Vacon Plc
Runsorintie 7
65380 Vaasa
firstname.lastname@vacon.com
telephone: +358 (0)201 2121
fax: +358 (0)201 212 205

PRODUCTION:**Suzhou, China**

Vacon Suzhou Drives Co. Ltd.
Building 11A
428# Xinglong Street, SIP
Suchun Industrial Square
Suzhou 215126
telephone: +86 512 62836630
fax: +86 512 62836618

Naturno, Italy

Vacon S.R.l
Via Zone Industriale, 11
39025 Naturno

PRODUCTION:**Chambersburg, USA**

3181 Black Gap Road
Chambersburg, PA 17202

TB Wood's (India) Pvt. Ltd.

#27, 'E' Electronics City
Hosur Road
Bangalore - 560 100
India
Tel. +91-80-30280123
Fax. +91-80-30280124

SALES COMPANIES AND REPRESENTATIVE OFFICES:**FINLAND****Helsinki**

Vacon Plc
Äyritie 8
01510 Vantaa
telephone: +358 (0)201 212 600
fax: +358 (0)201 212 699

Tampere

Vacon Plc
Vehnämyllynkatu 18
33580 Tampere
telephone: +358 (0)201 2121
fax: +358 (0)201 212 750

AUSTRALIA

Vacon Pacific Pty Ltd
5/66-74, Micro Circuit
Dandenong South, VIC 3175
telephone: +61 (0)3 9238 9300
fax: +61 (0)3 92389310

AUSTRIA

Vacon AT Antriebssysteme GmbH
Aumühlweg 21
2544 Leobersdorf
telephone: +43 2256 651 66
fax: +43 2256 651 66 66

BELGIUM

Vacon Benelux NV/SA
Interleuvenlaan 62
3001 Heverlee (Leuven)
telephone: +32 (0)16 394 825
fax: +32 (0)16 394 827

BRAZIL

Vacon Brazil
Alameda Mamoré, 535
Alphaville - Barueri -SP
Tel. +55 11 4166-5707
Fax. +55 11 4166-5567

CANADA

Vacon Canada
221 Griffith Road
Stratford, Ontario N5A 6T3
telephone: +1 (519) 508-2323
fax: +1 (519) 508-2324

CHINA

Vacon Suzhou Drives Co. Ltd.
Beijing Branch
A528, Grand Pacific Garden Mansion
8A Guanghua Road
Beijing 100026
telephone: +86 10 51280006
fax: +86 10 65813733

CZECH REPUBLIC

Vacon s.r.o.
Kodanska 1441/46
110 00 Prague 10
telephone: +420 234 063 250
fax: +420 234 063 251

FRANCE

Vacon France
ZAC du Fresne
1 Rue Jacquard - BP72
91280 Saint Pierre du Perray CDIS
telephone: +33 (0)1 69 89 60 30
fax: +33 (0)1 69 89 60 40

GERMANY

Vacon GmbH
Gladbecker Strasse 425
45329 Essen
telephone: +49 (0)201 806 700
fax: +49 (0)201 806 7099

Vacon OEM Business Center GmbH

Industriestr. 13
51709 - Marienheide
Germany
Tel. +49 02264 17-17
Fax. +49 02264 17-126

INDIA

Vacon Drives & Control Plc
Plot No 352
Kapaleeshwar Nagar
East Coast Road
Neelangarai
Chennai-600041
Tel. +91 44 244 900 24/25

ITALY

Vacon S.p.A.
Via F.lli Guerra, 35
42100 Reggio Emilia
telephone: +39 0522 276811
fax: +39 0522 276890

THE NETHERLANDS

Vacon Benelux BV
Weide 40
4206 CJ Gorinchem
telephone: +31 (0)183 642 970
fax: +31 (0)183 642 971

NORWAY

Vacon AS
Bentsrudveien 17
3080 Holmestrand
telephone: +47 330 96120
fax: +47 330 96130

ROMANIA

Vacon Romania - Reprezentanta
Cuza Voda 1
400107 Cluj Napoca
Tel. +40 364 118 981
Fax. +40 364 118 981

RUSSIA

ZAO Vacon Drives
Ul. Letchika Babushkina 1,
Stroenie 3
129344 Moscow
telephone: +7 (495) 363 19 85
fax: +7 (495) 363 19 86

ZAO Vacon Drives
Zya Sovetskaya 7, office 210A
191036 St. Petersburg
telephone: +7 (812) 332 1114
fax: +7 (812) 279 9053

SLOVAKIA

Vacon s.r.o. (Branch)
Seberiniho 1
821 03 Bratislava
Tel. +421 243 330 202
Fax. +421 243 634 389

SPAIN

Vacon Drives Ibérica S.A.
Miquel Servet, 2. P.I. Bufalvent
08243 Manresa
telephone: +34 93 877 45 06
fax: +34 93 877 00 09

SWEDEN

Vacon AB
Anderstorpsvägen 16
171 54 Solna
telephone: +46 (0)8 293 055
fax: +46 (0)8 290 755

THAILAND

Vacon South East Asia
335/32 5th-6th floor
Srinakarin Road, Prawet
Bangkok 10250
Tel. +66 (0)2366 0768

UKRAINE

Vacon Drives Ukraine (Branch)
42-44 Shovkovychna Str.
Regus City Horizon Tower
Kiev 01601, Ukraine
Tel. +380 44 459 0579
Fax +380 44 490 1200

UNITED ARAB EMIRATES

Vacon Middle East and Africa
Block A, Office 4A 226
P.O.Box 54763
Dubai Airport Free Zone
Dubai
Tel. +971 (0)4 204 5200
Fax: +971 (0)4 204 5203

UNITED KINGDOM

Vacon Drives (UK) Ltd.
18, Maizefield
Hinckley Fields Industrial Estate
Hinckley
LE10 1YF Leicestershire
telephone: +44 (0)1455 611 515
fax: +44 (0)1455 611 517

UNITED STATES

Vacon, Inc.
3181, Black Gap Road
Chambersburg, PA 17202
telephone: +1 (877) 822-6606
fax: +1 (717) 267-0140

