

ENGINEERING  
TOMORROW



Application Guide

# iC7 Series Industry Application

for iC7-Automation

OPEN UP A NEW DIMENSION OF INTELLIGENCE

INTEGRATED  
PREDICTIVE MAINTENANCE  
DATA SECURITY  
CONNECTIVITY  
APPLICATION PERFORMANCE  
EFFICIENCY





## Contents

<b>1</b>	<b>Introduction to the Application Guide</b>	<b>7</b>
1.1	Version History	7
1.2	Purpose of this Application Guide	7
1.3	Additional Resources	7
1.4	Safety Symbols	7
<b>2</b>	<b>Industry Application Software Overview</b>	<b>8</b>
2.1	Industry Application Software Overview	8
2.1.1	Basic Functions	8
2.1.2	Controllers	9
2.1.3	Motor Control Features	10
2.1.4	Braking of Load	10
2.1.5	Protection Features	11
2.1.6	Monitoring, Logging, and History Log	12
2.1.7	Functional Safety	12
2.1.8	Software Tools	12
2.1.9	Security Features	13
2.2	Motor Control Features for FVC+ and VVC+ Control	13
2.2.1	High Frequency Voltage Injection	14
2.3	PROFIdrive – Standard Telegram 1	15
2.3.1	Control Word (CTW) in PROFIdrive Standard Telegram 1	15
2.3.2	Status Word (STW) in PROFIdrive Standard Telegram 1	17
2.3.3	PROFIdrive State Machine	18
2.4	iC Speed Profile	18
2.4.1	Control Word (CTW) in iC Speed Profile	19
2.4.2	Status Word (STW) in iC Speed Profile	20
<b>3</b>	<b>User Interfaces and How to Configure</b>	<b>22</b>
3.1	Overview of User Interfaces	22
3.2	Control Panel	22
3.3	MyDrive® Insight	30
<b>4</b>	<b>Application Software Structure and Overview</b>	<b>46</b>
4.1	Understanding Application Software Structure Principles	46
4.2	Parameter Groups, Related Content, and Settings	46
<b>5</b>	<b>Configuration Set-up Examples</b>	<b>49</b>
5.1	Introduction and Prerequisites	49

5.2	Basic setup of a Drive	51
5.3	Configuring Motor, Motor Control, and Motor Thermal Protection	52
5.4	Configuring Speed Control	54
5.5	Configuring Torque Control	56
5.6	Configuring Process Control	58
<b>6</b>	<b>Parameter Descriptions</b>	<b>62</b>
6.1	Reading the Parameter Table	62
6.2	Grid (Menu Index 1)	63
6.2.1	Grid Status (Menu Index 1.1)	63
6.2.2	Grid Settings (Menu Index 1.2)	64
6.2.3	Grid Protection (Menu Index 1.3)	65
6.3	Power Conversion & DC Link (Menu Index 2)	66
6.3.1	Power Conversion & DC Link Status (Menu Index 2.1)	66
6.3.2	Power Unit Settings (Menu Index 2.2)	68
6.3.3	Protection (Menu Index 2.3)	73
6.3.3.2	Overvoltage Protection (Menu Index 2.3.2)	75
6.3.4	Modulation (Menu Index 2.4)	78
6.4	Filters & Brake Chopper (Menu Index 3)	79
6.4.1	Filters & Brake Chopper Status (Menu Index 3.1)	79
6.4.2	Brake Chopper (Menu Index 3.2)	79
6.4.3	Brake Resistor (Menu Index 3.3)	80
6.4.4	Advanced Harmonic Filter (Menu Index 3.4)	81
6.4.5	Output Filter (Menu Index 3.5)	82
6.5	Motor (Menu Index 4)	82
6.5.1	Motor Status (Menu Index 4.1)	82
6.5.2	Motor Data (Menu Index 4.2)	85
6.5.3	Motor Control (Menu Index 4.3)	90
6.5.3.3	FVC+ Settings (Menu Index 4.3.3)	92
6.5.4	Protection (Menu Index 4.5)	96
6.6	Application (Menu Index 5)	97
6.6.1	Application Status (Menu Index 5.1)	97
6.6.2	Protection (Menu Index 5.2)	101
6.6.3	Load (Menu Index 5.3)	109
6.6.4	Operation Mode (Menu Index 5.4)	111
6.6.5	Control Places (Menu Index 5.5)	111
6.6.6	Start Settings (Menu Index 5.6)	129
6.6.7	Stop Settings (Menu Index 5.7)	132

6.6.8	Speed Control (Menu Index 5.8)	135
6.6.8.7.3	Ramp 1 (Menu Index 5.8.6.2)	148
6.6.8.7.5	Ramp 3 (Menu Index 5.8.6.4)	150
6.6.8.7.6	Ramp 4 (Menu Index 5.8.6.5)	151
6.6.9	Torque control (Menu Index 5.9)	156
6.6.10	Process Control (Menu Index 5.10)	165
6.6.11	Inching (Menu Index 5.11)	175
6.6.12	Mechanical Brake Control (Menu Index 5.12)	176
6.6.13	Additional Status Outputs (Menu Index 5.26)	181
6.6.14	Fieldbus Process Data (Menu Index 5.27)	182
6.7	Maintenance & Service (Menu Index 6)	183
6.7.1	Status (Menu Index 6.1)	183
6.7.1.1	Grid Status (Menu Index 1.1)	63
6.7.1.2	Power Conversion & DC Link Status (Menu Index 2.1)	66
6.7.1.3	Filters & Brake Chopper Status (Menu Index 3.1)	79
6.7.1.4	Motor Status (Menu Index 4.1)	82
6.7.1.5	Application Status (Menu Index 5.1)	97
6.7.1.14	Maintenance & Service (Menu Index 6.1.1)	200
6.7.2	Software Information (Menu Index 6.2)	200
6.7.3	Events (Menu Index 6.4)	200
6.7.4	Operational Counters (Menu Index 6.5)	202
6.8	Functional Safety (Menu Index 7)	202
6.8.1	Functional Safety Overview	202
6.8.2	Status (Menu Index 7.1)	203
6.8.3	STO (Menu Index 7.2)	203
6.9	Customization (Menu Index 8)	203
6.9.1	Basic Settings (Menu Index 8.2)	204
6.9.2	Control Panel (Menu Index 8.3)	204
6.10	I/O (Menu Index 9)	214
6.10.1	I/O Overview	214
6.10.2	Basic I/O	214
6.11	Connectivity (Menu Index 10)	229
6.11.1	Connectivity Overview	229
6.11.2	Integrated Communication	229
6.11.2.1	Communication interfaces (Menu Index 10.2)	230
6.11.2.2	Protocols (Menu Index 10.3)	232

---

<b>7</b>	<b>Troubleshooting</b>	<b>236</b>
7.1	Viewing Warnings	236
7.2	Viewing and Resetting Faults	236
7.3	Reading the Event Summary Table	236
7.4	Events Summary for Industry Application Software	237

# 1 Introduction to the Application Guide

## 1.1 Version History

This guide is regularly reviewed and updated. All suggestions for improvement are welcome.

The original language of this guide is in English.

Version	Remarks
AB284850130221en, doc version 04	Information in the version of the manual corresponds to Industry application software version 3.2.4.

## 1.2 Purpose of this Application Guide

This application guide is intended for qualified personnel such as:

- Automation engineers
- Commissioning engineers who have experience operating with parameters and basic knowledge of AC drives

The application guide provides information on the initial configuration of the drive. The purpose of the guide is to provide information on parameters for configuring and controlling the drive, an overview and procedures of the various user interfaces in iC7, typical application examples, and troubleshooting of events in the drive.

## 1.3 Additional Resources

Additional resources are available with related information.

iC7-Automation Frequency Converters Design Guide provides information about the capability and functionality to design motor control systems for Danfoss iC7 series.

iC7 Series Frequency Converters Installation Safety Guide, which provides important safety information related to iC7 drives.

iC7-Automation Frequency Converters Installation Guides, which cover the mechanical and electrical installation of drives

## 1.4 Safety Symbols

### ⚠ D A N G E R ⚠

Indicates a hazardous situation which, if not avoided, will result in death or serious injury.

### ⚠ W A R N I N G ⚠

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

### ⚠ C A U T I O N ⚠

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

### N O T I C E

Indicates information considered important, but not hazard-related (for example, messages relating to property damage).

## 2 Industry Application Software Overview

### 2.1 Industry Application Software Overview

The iC7-Automation is as standard delivered with the Industry application software. The Industry application software offers a wide range of features supporting a large selection of generic applications. The features are briefly described in the following sections.

- Basic Functions
- Controllers
- Protection Features
- Security Features
- Software Tools

#### 2.1.1 Basic Functions

The basic functions of iC7 Series Industry application software include reference handling, I/O control and readouts, and mechanical brake control, among many others. This section briefly describes the basic functions which enable the drive to control any application.

##### 2.1.1.1 I/O Control and Readouts

Depending on the hardware configuration of the drive, digital and analog inputs, as well as digital, analog, and relay outputs are available. The I/Os can be configured and used to control the application from the drive.

If functional extension options are installed in the drive, the relevant parameters and I/O selections are automatically visible in the parameter structure.

##### 2.1.1.2 Reference Handling

References from multiple sources can be defined, depending on the needs of the application.

Reference sources are:

- Analog inputs
- Digital inputs either as pulse input or digital potentiometer
- Reference from a fieldbus
- Up to 8 preset references (selectable by parameter, fieldbus, or digital inputs)
- Local reference from control panel

Reference signals can be added, subtracted, and multiplied, generating the reference to the drive. The final reference is scaled from -100% to 100%.

##### 2.1.1.3 Ramps

Linear and S-ramps are supported. Linear ramps provide a constant acceleration and deceleration. S-ramps provide a non-linear acceleration and deceleration, with a soft transition at the start and end of the acceleration and deceleration process.

##### 2.1.1.4 Quick Stop

In some situations, it may be required to stop the application in a quick way. For this purpose, the drive supports a specific deceleration ramp time from the synchronous motor speed to 0 RPM.

##### 2.1.1.5 Limit Rotation Direction

The rotational direction of the motor can be preset to run in one direction only (positive or negative), avoiding unintended rotation direction.

##### 2.1.1.6 Inching with Jogging modes

Predefined speed settings are available for use during commissioning, maintenance, or service. The features cover Slow Down mode (operation at decreased speed), Jogging mode (operation at preset speed), and Override mode (operation overrides any reference settings).

##### 2.1.1.7 Speed Bypass

Specific motor speeds can be bypassed during operation. The feature helps to minimize and avoid mechanical resonance of the machine, limiting vibration and noise of the system.



### 2.1.1.8 Flying Start

Flying start enables the drive to synchronize to a freely spinning motor, before taking control of the motor. Taking over control of the motor at the actual speed minimizes mechanical stress to the system. For example, the feature is relevant in fan and centrifuge applications.

### 2.1.1.9 Mains Dropout

If there is mains dropout, where the drive cannot continue operation, it is possible to select predefined actions, for example trip, coast or performing a controlled ramp down.

### 2.1.1.10 Kinetic Backup

Kinetic backup enables the drive to remain in control if there is sufficient energy in the system, for example, as inertia or when lowering a load. The function allows a controlled stop of the machine.

### 2.1.1.11 Resonance Damping

High-frequency motor resonance noise can be eliminated by using resonance damping. Both automatic and manually selected frequency dampings are available.

### 2.1.1.12 Motor Preheat

In cold and damp environments, the motor must be preheated to avoid condensation and cold starts. The feature DC Start generates a small DC current through the motor windings, keeping the temperature above the surrounding temperature.

### 2.1.1.13 Mechanical Brake Control

In applications like cranes, lifts and hoists, or downhill conveyors, a mechanical brake is used to keep the load at standstill, when the motor is not controlled by the drive or when power is turned off.

The mechanical brake control feature ensures a smooth transition between the mechanical brake and motor holding the load, by controlling the activation and deactivation of the mechanical brake.

### 2.1.1.14 Load Drooping

The load droop function ensures that multiple motors, each controlled by a drive, and connected to a common mechanical shaft, share the load. The function is typically used in cranes, winches, or larger conveyor systems controlled by 2 or more motors.

## 2.1.2 Controllers

The drive has 3 different controllers which provide optimized control of the actual application. The controllers cover the following:

- Speed Control
- Torque Control
- Process Control

### 2.1.2.1 Speed Controller

A built-in speed PID controller provides accurate control of the motors rotational speed. The controller offers control in both open and closed-loop control.

Open-loop mode does not require an external sensor for measuring the feedback signal. This allows easy installation and commissioning and eliminates the risk of defective sensors.

In closed loop, a speed sensor is added, offering highly accurate control.

The parameters of the speed controller can be optimized by the built-in **auto tuning** function.

### 2.1.2.2 Torque Controller

A built-in torque controller provides optimized control of torque. Typical usage is in tension control for winches or extruders. The drive offers both open-loop control where the current sensors provide the feedback and a closed-loop feedback supported by an external torque sensor.

### 2.1.2.3 Process Controller

The process controller can control a process, for example, in a system where a constant pressure, flow, or temperature is needed. Feedback from the application is connected to the drive, providing the actual process value. By controlling the motor speed, the controller ensures that the output matches the reference provided. The reference source and the feedback signals are converted

## Application Guide

---

and scaled to the actual values controlled. The controller provides full PID control, which includes PID parameter configuration, and is optimized by the built-in auto-tuning function.

### 2.1.3 Motor Control Features

The motor control in iC7 series covers a wide range of applications, control from the most basic applications to applications requiring high-performance motor control.

#### 2.1.3.1 Motor Types

The drive supports standard available motors like:

- Asynchronous motors
- Permanent magnet motors

#### 2.1.3.2 Torque Characteristics

Different load characteristics are supported to match the actual application needs:

- **Variable torque:** Typical load characteristic of fans and centrifugal pumps, where the load is proportional to the square of the speed.
- **Constant torque:** Load characteristic used in machinery where torque is needed across the full speed range. Typical application examples are conveyors, extruders, decanters, compressors, and winches.

#### 2.1.3.3 Motor Control Principle

Different control principles can be selected to control the motor, matching the application needs:

- U/f control for simple open-loop operation.
- VVC+ (Voltage Vector Control) in both open and closed loop, for the general-purpose application needs.
- FVC+ (Flux Vector Control) in both open and closed loop, for demanding application needs.

#### 2.1.3.4 Motor Nameplate Data

Typical motor data for the actual drive are preset from factory, allowing operation of most motors. During commissioning, actual motor data are entered in the settings of the drive to optimize the motor control.

#### 2.1.3.5 Automatic Motor Adaptation (AMA)

Automatic Motor Adaptation (AMA) provides optimization of motor parameters for improved shaft performance. Based on motor product label data and measurements of the motor at standstill, key motor parameters are recalculated, and used to fine-tune the motor control algorithm.

AMA allows automatic detection of the motor type.

#### 2.1.3.6 Automation Energy Optimization (AEO)

The Automatic Energy Optimization (AEO) feature optimizes the control with focus on lowering energy consumption at the actual load point.

### 2.1.4 Braking of Load

For controlled load braking performed by the drive, various functions can be used. The specific function is selected based on the application and the needs for how fast it should be stopped.

#### 2.1.4.1 Resistor Braking

In applications which require fast or continuous braking, a drive fit with a brake chopper is typically used. Excess energy, generated by the motor during braking of the application, is dissipated in a connected brake resistor. Braking performance depends on the specific drive rating and selected brake resistor.

#### 2.1.4.2 Overvoltage Control (OVC)

If braking time is not critical or the load is varying, the overvoltage control (OVC) feature is used to control stopping the application. The drive extends the ramp-down time when it is not possible to brake within the defined ramp-down period. The feature must not be used in hoisting applications, high inertia systems, or applications where continuous braking is required.

### 2.1.4.3 DC Brake

When braking at low speed, the braking of the motor can be improved by using the DC brake feature. The software offers a configurable DC-braking for induction motor control. It injects a DC current defined by the user.

### 2.1.4.4 AC Brake

In applications with non-cyclic operation of the motor, AC braking can be used to shorten the braking time. Excess energy is dissipated by increasing losses in the motor during braking. Performance is motor type dependent and offers best performance on asynchronous motors.

### 2.1.4.5 DC Hold

The software offers the possibility to configure the feature DC Start for DC holding before entering normal motor control.

### 2.1.4.6 Load Sharing

In some applications, 2 or more drives are controlling the application at the same time. If 1 of the drives is braking a motor, the excess energy can be fed to the DC link of a drive driving a motor, with a reduction of the total energy consumption. This feature is typically useful in, for example, decanters and carding machines, where smaller power-sized drives operate in generator mode.

## 2.1.5 Protection Features

The drive offers various features protecting against unexpected conditions on the grid, motor, external connected components, and the drive.

### 2.1.5.1 Grid Protections

The drive protects against conditions on the power grid that can affect proper operation. The grid is monitored for phase imbalance and phase loss. When the imbalance exceeds specified limits, a configurable response takes place and corrective actions can be taken.

The supply frequency is also monitored, and when the drive is outside acceptable limits, it reacts in the configured way. Furthermore, the software of the drive offers an optional protection against undervoltage and a configurable response to grid spikes.

### 2.1.5.2 Drive Protection Features

The drive is monitored and protected during operation.

Inbuilt temperature sensors measure the actual temperature and provide relevant information to protect the drive. If the temperature exceeds its nominal temperature conditions, derating of operational parameters are applied. If the temperature is outside the allowed operating range, the drive stops operation.

The motor current is continuously monitored on all 3 phases. If there is a short circuit between 2 phases, or a fault to ground, the drive detects the short circuit and immediately turns off. If the output current is exceeding its nominal values during operation for longer periods than allowed, the overload capability is reduced until the conditions are restored.

The DC-link voltage of the drive is monitored. If it exceeds critical levels, a warning is issued and if the situation is not resolved, the drive stops operation.

### 2.1.5.3 Motor Protection Features

The drive provides various features to protect the motor and the application.

The output current measurement provides information to protect the motor. Overcurrent, short circuit, ground faults, and lost motor phase connections can be detected and relevant protections initiated.

Monitoring of speed, current, and torque limits provides an extra protection of the motor and the application. Under extreme load conditions, it also provides motor stall protection.

Locked-rotor protection secures that the drive is not starting with a blocked rotor of the motor.

Motor thermal protection is provided, either as a calculation of the motor temperature based on the actual load, or by external temperature sensors connected to the Temperature Measurement Option. Supported sensor types are Pt100, Pt1000, Ni1000, KTY84, and KTY81.

### 2.1.5.4 Protection of External Filters or Brake Resistors

Brake resistors are monitored for thermal overload (calculated thermal load or by external sensor), short circuit, and missing connections.

The drive allows to monitor the temperature of externally connected filters.

## Application Guide

---

### 2.1.5.5 Automatic Derating

Automatic derating of the drive allows continued operation even if the nominal operation conditions are exceeded. Typical factors affecting are temperature, high DC-link voltage, high motor load, or operation close to 0 Hz. Derating is typically applied as a reduction in switching frequency or change in switching pattern, resulting in lower thermal losses.

### 2.1.6 Monitoring, Logging, and History Log

The drive offers monitoring features, logging possibilities and access to historical data from operation. The information provides help to analyze operational conditions and identification of faults.

#### 2.1.6.1 Monitoring Features

The drive offers a wide range of monitoring features that provides information of actual operation conditions. Some examples are:

##### Speed monitoring

The motor speed can be monitored during operation. If the speed exceeds minimum or maximum limits, the user is notified and can initiate appropriate actions.

##### Temperature monitoring

Temperatures of the drive and external connected sensors can be monitored. This provides the opportunity to monitor the operational conditions of the drive and related application.

##### Grid monitoring

During operation, the drive is able to monitor the grid conditions. It measures the grid voltage for each supply phase and the grid frequency and calculates the grid voltage imbalance and total harmonic distortion (THDv).

#### 2.1.6.2 Event Log

An event log provides access to the latest registered warnings and faults, providing relevant information for analysis of events that occur in the drive.

#### 2.1.6.3 Logging and Storage of Data

Logging of operational data from the drive and related process is possible during running. Logging can be continuous or triggered by specific events. Data is stored to the microSD card placed in the drive, or transferred directly to MyDrive Insight. The feature provides the opportunity to collect data for detailed analysis of operation and events happening during operation.

### 2.1.7 Functional Safety

A Safe Torque Off function with dual input is available as standard in the drive. An additional Safe Torque Off feedback signal indicates the status of the drive.

More functional safety features are available as optional selections. The set of features covers a wide range of functional safety features that can operate in both sensorless and closed-loop setup. Safe fieldbus is also supported as option.

### 2.1.8 Software Tools

Danfoss offers a suite of desktop software tools which have been designed to provide easy operation and the highest level of customization of AC drives.

APIs and the Danfoss Device Interface make it possible to integrate the tools into proprietary systems and business processes. The MyDrive® tools support the entire life cycle of the drive, from system design to service. Some of the tools are available free of charge, and some require a subscription.

For more information about the MyDrive® tools, see MyDrive documentation.

#### 2.1.8.1 MyDrive® Select

MyDrive® Select performs frequency converter sizing based on calculated motor load currents, ambient temperature, and current limitations. The sizing results are available in graphical and numerical format, and include calculations of efficiency, power losses, and inverter load currents. The resulting documentation is available in .pdf or .xls format, and can be imported to MyDrive® Harmonics for the evaluation of the harmonic distortion, or validation of compliance towards most recognized harmonic norms and recommendations.

MyDrive® Select is available as a web-based tool at [select.mydrive.danfoss.com](https://select.mydrive.danfoss.com) and as a mobile device app that can be downloaded from app stores.

#### 2.1.8.2 MyDrive® Harmonics

MyDrive® Harmonics estimates the benefits of adding harmonic mitigation solutions to an installation and calculates system harmonic distortion. The evaluation can be done both for new installations and when extending an existing installation.

The free version provides a fast overview of the expected general performance of the system. The expert version of MyDrive® Harmonics requires a subscription, which opens up more features, including the possibility to save and share harmonic projects, importing projects from MyDrive® Select, and the possibility to add Danfoss harmonic mitigation products.

### 2.1.8.3 MyDrive® ecoSmart™

MyDrive® ecoSmart™ determines the energy efficiency of the drive being used and the system efficiency class according to IEC 61800-9.

MyDrive® ecoSmart™ uses information about the selected motor, load points, and AC drive to calculate the efficiency class and part load efficiency for a Danfoss AC drive, either for a free-standing drive (CDM), or a drive with a motor (PDS).

MyDrive® ecoSmart™ is available as a web-based tool at [ecosmart.mydrive.danfoss.com](https://ecosmart.mydrive.danfoss.com) and as a mobile device app that can be downloaded from app stores.

### 2.1.8.4 MyDrive® Insight

MyDrive® Insight is a software tool for commissioning, engineering, and monitoring drives. MyDrive® Insight can be used to configure the parameters, upgrade software, and set up functional safety features and condition-based monitoring.

Backup, restore, and data logging within MyDrive® Insight support the usage of a microSD card as storage device.

## 2.1.9 Security Features

### NOTICE

The drive should not be connected directly to the internet, as end-to-end connectivity is not secured via Danfoss software tools. It is recommended that drives are installed by authorized and educated personnel, who are aware of the security risks in networks and can mitigate threats in the network. Typically, the drive can be accessed and configured by anyone with physical access.

The drive provides the following cybersecurity features:

- Secure bootchain
- Signed and encrypted firmware and application software
- Secure software updates
- License verification
- Secure connectivity for all communication interfaces

## 2.2 Motor Control Features for FVC+ and VVC+ Control

Following is the compatibility of motor types and motor control related features with motor control principles.

Table 1: Motor Control Features and Motor Types

Motor type/Feature		Induction motors		Synchronous motors	
		FVC+	VVC+	FVC+	VVC+
Motor type	Induction motor (IM)	X	X	-	-
	Surface permanent magnet motor (SPM)	-	-	X	X
	Interior permanent magnet motor (IPM)	-	-	X	X
Speed feedback	Open loop	X	X	X	X
	Closed loop (with Encoder, Resolver)	X	X	X	-
Reference handling	Speed control	X	X	X	X
	Torque control	X	-	X	-
	Linear ramp	X	X	X	X
	S-ramp	X	X	X	X

Motor type/Feature		Induction motors		Synchronous motors	
		FVC+	VVC+	FVC+	VVC+
	Load drooping	X	X	X	X
	Windowing in torque control	X	-	X	-
<b>Limit handling</b>	Speed limit	X	X	X	X
	Torque limit	X	X	X	X
	Current limit	X	X	X	X
	Power limit	X	X	X	X
	Overvoltage control	X	X	X	X
	Undervoltage control	X	X	X	X
<b>Auxiliary functions</b>	Flying start	X	X	X	X
	Automatic energy optimization (AEO)	X	X	X	X
	Power loss action	X	X	X	X
	AC-brake (Flux brake)	X	X	-	-
	Start magnetization	X	X	-	-
	DC-brake	X	X	X	X
	DC-injection in stop	X	X	X	X
	Stop state magnetization	X	X	-	-
	Initial position detection	-	-	X	X
	Rotor parking	-	-	X	X
<b>Commissioning functions</b>	AMA standstill	X	X	X	X
	Inertia measurement	X	-	X	-
	Speed control auto-tuning	X	-	X	-
<b>Power options</b>	Sine filter	X	X	-	X
	Advanced harmonic filter	X	X	X	X
<b>Process functionality and protections</b>	Mechanical brake control in closed loop	X	-	X	-
	Missing motor phase	X	X	X	X
	Motor thermal protection	X	X	X	X
	Electronic thermal relay (ETR)	X	X	X	X

### 2.2.1 High Frequency Voltage Injection

For salient pole synchronous motors under FVC+, High Frequency Voltage Injection (HFVI) is an encoder/resolver alternative for rotor position detection at low speeds. If the motor has sufficient saliency (typically larger than 1.1), HFVI allows applications to run open loop with performance like closed loop.

In a salient pole motor, the magnetic material of the rotor is not rotationally symmetric, as opposed to a non-salient pole motor where it is. That means that the magnetic path through different diameters of the rotor varies. This results in different values of  $L_q$  and  $L_d$  inductances, which can be used to determine the orientation of the rotor. The saliency ratio is the ratio between  $L_q$  and  $L_d$ .

Application Guide

Commissioning HFVI

A typical HFVI commissioning workflow could be:

- 1: Set 4.3.1.1 *Motor Control Principle* to FVC+
- 2: Enter the product label data to 4.2.4 *Permanent Magnet Motor* and set 4.2.1.1 *Motor Type*
- 3: Run full AMA: Set 4.2.1.4 *Ama Mode* to Motor Data and start the drive
- 4: Enable HFVI by setting 4.3.3.4 *Low Speed Mode*

While HFVI is enabled, the saliency ratio is validated.

Saliency ratio (Lq/Ld)	Drive response
$SR \leq 1.1$	Motor start prevented.
$1.1 < SR < 1.5$	Warning issued in the event log. Tracking capabilities are possibly reduced.

HFVI parameters

The setup parameters are all located under 4.3.3 *FVC+ Settings* in the 4.3 *Motor Control* menu. HFVI is enabled by setting 4.3.3.4 *Low Speed Mode* (1) to HF Injection.

①	4.3.3.4	Low Speed Mode	Normal Motor Control	Normal Motor Control	0	3	
	4.3.3.5	I/f Control Current %	100	100	0	500	%
	4.3.3.6	I/f Control Threshold Speed	10	300	1	50	rpm
	4.3.3.7	Low Speed Minimum Current	50	50	0	100	%
	4.3.3.8	Minimum Current Threshold Speed	10	10	1	50	Hz
	4.3.3.9	Motor Feedback Mode	Open Loop	Open Loop	0	1	
②	4.3.3.10	HF Inject Voltage Gain %	100	100	5	2000	%
③	4.3.3.11	HF Inject Bandwidth %	100	100	1	1000	%
④	4.3.3.12	HF Inject Angle Comp Gain	0	0	-35	35	°
⑤	4.3.3.13	HF Inject Angle Comp Offset	0	0	-25	25	°
⑥	4.3.3.14	HF Inject Frequency	0	0	0	3.4028234663852886e+38	Hz
⑦	4.3.3.15	Idlq Reference Ratio Pct	0	0	-100	100	%

Basic settings are done with the following 3 parameters:

- 4.3.3.10 *HF Inject Voltage Gain %* (2): Sets the magnitude of the injected voltage as a percentage of the recommended injected voltage.
- 4.3.3.11 *HF Inject Bandwidth %* (3): Sets the bandwidth of the position estimation as a percentage of the recommended bandwidth.
- 4.3.3.14 *HF Inject Frequency* (6): Option to force the injection frequency to a specific value. If set to 0, the recommended injection frequency is used.

The recommended injected voltage and frequency are calculated based on motor data.

To ensure sufficient saliency levels under all load conditions, more advanced settings can be set with these 3 parameters:

- 4.3.3.12 *HF Inject Angle Comp Gain* (4): Load-dependent offset to the estimated rotor angle.
- 4.3.3.13 *HF Inject Angle Comp Offset* (5): Offset to the estimated rotor angle.
- 4.3.3.15 *Idlq Reference Ratio Pct* (7): Disables the existing magnetization current controlling scheme, like MTPA, and introduces a magnetization current as a percentage of the torque current. This parameter can be used to force the motor to run with elevated magnetization current levels, if it is required to ensure sufficient saliency levels.

These 3 parameters require detailed information about the motor flux at various operating conditions.

2.3 PROFIdrive – Standard Telegram 1

Standard telegram 1 is implemented according to PROFIdrive Application Class 1 profile as defined in the PROFIdrive standard and state machine diagram.

2.3.1 Control Word (CTW) in PROFIdrive Standard Telegram 1

Table 2: Control Word Bits in PROFIdrive Standard Telegram 1

Bit number	Name	Description
0	On-Off	1 = On.

## Application Guide

Bit number	Name	Description
		0 = Off.
1	Coast stop	1 = No coast stop. 0 = Coast stop.
2	Quick stop	1 = No quick stop. 0 = Quick stop.
3	Operation	1 = Enable operation. 0 = Disable operation.
4	Ramp generator	1 = Enable Ramp generator (RFG). 0 = Reset Ramp generator. Output of the RFG is set to 0. The drive decelerates along the current limit or along the voltage limit of the DC link.
5	Freeze	1 = Unfreeze ramp generator. 0 = Freeze ramp generator. Freezes the present output frequency (in Hz).
6	Enable setpoint	1 = Enable setpoint. 0 = Disable setpoint.
7	Fault acknowledge	0 → 1 = Acknowledge faults. Acknowledge is edge triggered, when changing from logic 0 to logic 1. 0 = No function.
8	Jog 1	1 = Jog 1 on. 0 = Jog 1 off. Operation is enabled, drive is in standstill and STW1 bit 4, 5, 6 = 0. The drive runs up along the ramp to jogging setpoint 1.
9	Jog 2	1 = Jog 2 on. 0 = Jog 2 off. Operation is enabled, drive is in standstill and STW1 bit 4, 5, 6 = 0. The drive runs up along the ramp to jogging setpoint 1.
10	Control by PLC	1 = Uses the process data (control by PLC). 0 = Ignores the current process data. This is linked to the submodule where the CTW is present. If signals are to be covered, the CTW/STW profile (for example, the iC Speed Profile) must be part of the signals list.
11	Reserved	Reserved for future use.
12	User defined	These bits enable mapping application functionality of the drive to the control word. Mapping is done through parameters. For more information, refer to the <i>Parameter Descriptions</i> chapter in the application guide.
13	User defined	
14	User defined	
15	User defined	



## 2.3.2 Status Word (STW) in PROFIdrive Standard Telegram 1

Table 3: Status Word Bits in PROFIdrive Standard Telegram 1

Bit Number	Name	Description
0	Ready to switch on	1 = Ready to switch on. 0 = Not ready to switch on.
1	Ready to operate	1 = Ready to operate. 0 = Not ready to operate.
2	Operation enabled	1 = Operation enabled. 0 = Operation disabled.
3	Operation fault	1 = Fault present. 0 = No fault.
4	Coast stop	1 = Coast stop not activated (No OFF2). 0 = Coast stop activated (OFF2).
5	Quick stop	1 = Quick stop not activated (No OFF3). 0 = Quick stop activated (OFF3).
6	Switching on inhibited	1 = Switching on inhibited. 0 = Switching on not inhibited.
7	Warning	1 = A warning has occurred. 0 = There are no warnings.
8	Speed=reference/ Speed<>reference	1 = The present motor speed matches the present speed reference within a given tolerance. The tolerance is product specific. 0 = The motor runs, but the present speed is different from the present speed reference. It could, for example, be the case while the speed ramps up/down during start/stop.
9	Bus control/Local operation	1 = The device is controlled and reacting to I/O and Process data 0 = The device does not react on commands from fieldbus, because of one of the following reasons: <ul style="list-style-type: none"> <li>• CTW bit 10 = 0</li> <li>• HMI is in local mode.</li> <li>• MyDrive® Insight has taken control.</li> <li>• Control places do not include fieldbus.</li> </ul>
10	Frequency limit ok/Out of frequency limit	1 = The output frequency is within the defined motor limits. 0 = The output frequency has exceeded the defined motor limits given by parameters. The speed limits are set by parameters: <ul style="list-style-type: none"> <li>• P 5.8.3.4 High Speed Warning</li> <li>• P 5.8.3.9 Low Speed Monitor Limit</li> </ul>
11	User defined	These bits enable mapping application functionality of the drive to the status word. Mapping is done through parameters. For more information, refer to the <i>Parameter Descriptions</i> chapter in the application guide.
12	User defined	

Bit Number	Name	Description
13	User defined	
14	User defined	
15	User defined	


### 2.3.3 PROFIdrive State Machine

In the PROFIdrive control profile, the control bits perform different functions:

- 0–3 perform the basic start-up and power-down functions.
- 4–10 perform application-oriented control.
- 12–15 can be configured for different purposes.

See [Illustration 1](#) for the basic state transition diagram, where control bits 0–3 control the transitions and the corresponding status bit indicates the actual state. The black dots indicate the priority of the control signals. Fewer dots indicate lower priority, and more dots indicate higher priority.

The general state diagram is defined in the PROFIdrive standard.



e30bk784.10

Illustration 1: General State Diagram

### 2.4 iC Speed Profile

The iC Speed profile is used with the iC7 series. iC Speed profile differs from the PROFIdrive profile, because it does not have a State Machine. It is only controlled by the actual state 1/0 of the control bits, not the sequence in which they are manipulated.

## 2.4.1 Control Word (CTW) in iC Speed Profile

Table 4: iC Speed Profile Control Word Bits

Bit number	Name	Description
0+1	Preset reference selector	00 = Preset reference 1 01 = Preset reference 2 10 = Preset reference 3 11 = Preset reference 4
2	Reserved	Reserved for future use. Any control words sent to the device should keep this bit at 0 to ensure compatibility with future extensions of the control word.
3	No coast/Coast	1 = No function. 0 = Causes the frequency converter immediately to coast the motor.
4	No quick stop/Quick stop	1 = No function. 0 = Quick stops the frequency converter and ramps down the motor speed to stop as defined in the quick-stop ramp parameter.
5	No hold/Hold – output frequency	1 = No function. 0 = Holds the present output frequency (in Hz).
6	Start/No start	1 = If the other starting conditions are fulfilled, the selection allows the frequency converter to start the motor. 0 = Stops the frequency converter and ramps down the motor speed as defined in the ramp-down parameter.
7	Fault acknowledge	0→1 = Acknowledge faults. Acknowledge is edge-triggered, when logic is changed from 0 to 1. Faults can only be acknowledged if the trigger condition has been removed and any required acknowledgment has been done. 0 = No function.
8	Jog/No jog	1 = Sets the output frequency to the jog speed defined in the jog speed parameter. 0 = No function.
9	Ramp select	1 = Ramp 2 is active. 0 = Ramp 1 is active.
10	Data valid	1 = Uses the process data (control by PLC). 0 = Ignores the current process data. This is linked to the submodule where the CTW is present. If signals are to be covered, the CTW/STW profile (for example, the iC Speed Profile) must be part of the signals list. Uses the previously processed data when the data valid bit was true (no control by PLC).
11	Reserved	Reserved for future use.
12	User defined	These bits are reserved for application-specific advanced control. For more information, refer to the <i>Parameter Descriptions</i> chapter in the application guide.
13	User defined	
14	User defined	
15	User defined	

## 2.4.2 Status Word (STW) in iC Speed Profile

Table 5: iC Speed Profile Status Word Bits

Bit number	Name	Description
0	Control ready/Control not ready	1 = The device controls are ready and react to process data. 0 = The device controls are not ready do not react to process data.
1	Frequency converter ready/Frequency converter not ready	1 = The frequency converter is ready for operation. 0 = The frequency converter is not ready for operation. This does not involve faults and warnings as they are indicated in their respective bits elsewhere.
2	Coasting/No coast	1 = There are no active coast signals, and the motor can start when a start signal is given. 0 = The frequency converter has an active coast signal and has released the motor.
3	Fault/No fault	1 = A fault has occurred, and an acknowledge signal is required to re-establish operation. 0 = There are no faults.
4	Reserved	Reserved
5	Reserved	Reserved
6	Reserved	Reserved
7	Warning/No warning	1 = A warning has occurred. 0 = There are no warnings.
8	Speed=reference/ Speed<>reference	1 = The present motor speed matches the present speed reference within a given tolerance. The tolerance is product specific. 0 = The motor runs, but the present speed is different from the present speed reference, for example while the speed ramps up or down during start or stop.
9	Bus control/Local operation	1 = The device is controlled and reacting to I/O and process data. 0 = The device does not react on commands from fieldbus, for 1 of the following reasons: <ul style="list-style-type: none"> <li>• CTW Bit 10 = 0.</li> <li>• HMI is in local mode.</li> <li>• MyDrive® Insight has taken control.</li> <li>• Control places do not include fieldbus.</li> </ul>
10	Frequency limit ok/Out of frequency limit	1 = The output frequency is within the defined motor limits. 0 = The output frequency has exceeded the motor limits defined in parameters. The speed limits are set by parameters: <ul style="list-style-type: none"> <li>• P 5.8.3.1 Positive Speed Limit</li> <li>• P 5.8.3.2 Negative Speed Limit</li> <li>• P 5.8.3.3 Minimum Speed Limit</li> </ul>
11	In operation/No operation	1 = The process is running, and the motor could be running or starting at any time. 0 = There are no active start requests, and the process does not run. The motor is in a coasted state and is not started.
12	Reserved	Reserved

Bit number	Name	Description
13	Reserved	Reserved
14	User defined	These bits are reserved for application-specific advanced control. For more information, refer to the <i>Parameter Descriptions</i> chapter in the application guide the <i>Parameter Descriptions</i> chapter in the application guide.
15	User defined	

## 3 User Interfaces and How to Configure

### 3.1 Overview of User Interfaces

To interact with a Danfoss iC7 Series drive, use either a control panel as a simple and direct interface or the software tool MyDrive® Insight for more advanced interaction with the drive. The control panel can be mounted directly on the drive or close to the drive, by using a control panel remote mounting kit.

Using MyDrive® Insight provides the ability to access the drive from a remote place, if infrastructure is in place and network provides the required access rights.

### 3.2 Control Panel

The chapter provides an overview about the different control panel options, the related elements, important features and functionalities, and quick guidance on how to use the control panel.

#### 3.2.1 Control Panel Options

The iC7 Series offers the following 2 different control panel options:




Illustration 2: Control Panel Options

- **Blind Panel OPX00:** The option shows the basic status of the drive and fieldbus indicators. The option is typically used when only limited interaction with the drive is required after installation and commissioning, or when the drives are controlled by fieldbus.
- **Control Panel 2.8 OPX20:** The option is typically the standard user interface and used when frequent interaction with the drive is required. The option enables easy setup of the drive via parameters, monitor drive status, and also shows notifications, in the case of an event.


A more detailed overview of the Control Panel 2.8 OPX20 is as follows:

- 2.8" monochromatic user interface with a display resolution of 240 x 160 pixels.
- Visual LEDs to identify drive status, fieldbus communication.
- Halo indicator with 3 colors to illustrate drive status at a glance.
- Convenient readout of status values in the display which can be customized to show the required or essential information.
- Local operation to control the drive including toggle mechanism to easily switch between local and remote operation.
- Parameter widgets which support alphanumeric and special characters, integers, floating points, date time formats, choice lists, and commands to configure application data.
- Help texts to support operation.

#### 3.2.2 Control Panel Elements

The control panel provides an interface for configuring and controlling the AC drive easily. The section describes the elements for all control panel options.

Application Guide



e=0bj769.12

Illustration 3: Control Panel Elements

Table 6: Control Panel Elements Description

Legend	Name of Element	Description
1	Fieldbus Indicators	<p>The related LEDs indicate the status of the communication interface X1 and X2.</p> <ul style="list-style-type: none"> <li>• <b>[ST]</b> <ul style="list-style-type: none"> <li>- Green LED blink indicates normal operating state of the communication interfaces.</li> <li>- Red LED blink indicates that an error has occurred and communication is not possible.</li> </ul> </li> <li>• <b>[X1]</b> <ul style="list-style-type: none"> <li>- Green LED blink indicates data exchange on communication interface X1.</li> <li>- Red LED blink indicates an error during data exchange on communication interface on X1.</li> </ul> </li> <li>• <b>[X2]</b> <ul style="list-style-type: none"> <li>- Green LED blink indicates data exchange on communication interface X2.</li> <li>- Red LED blink indicates an error during data exchange on communication interface on X2.</li> </ul> </li> </ul>
2	Display	<p>Enables to access content and settings. The display provides detailed information about the status of the drive.</p>
3	Drive Status Indicators	<p>The related LEDs indicate the status of the drive. In Control Panel 2.8, the status of the drive is also shown by the Halo indicator, which has the same color as the drive status LEDs.</p> <ul style="list-style-type: none"> <li>• <b>[WARN]</b> <ul style="list-style-type: none"> <li>- Yellow color on the LED and Halo indicates that a warning has occurred in the drive.</li> </ul> </li> <li>• <b>[READY]</b> <ul style="list-style-type: none"> <li>- White color on the LED and Halo indicates that the drive is ready for operation.</li> </ul> </li> <li>• <b>[FAULT]</b> <ul style="list-style-type: none"> <li>- Red color on the LED and Halo indicates a fault.</li> </ul> </li> </ul>
4	Back button	<p>Navigates to previously viewed screen or a menu level above current menu.</p>
5	REM/LOC	<p>Toggles the drive between remote and local operation.</p>
6	Run button	<p>Starts the operation of the drive.</p>

Legend	Name of Element	Description
7	RUN LED	Indicator has the following states: <ul style="list-style-type: none"> <li>• <b>On:</b> Start command is applied and the drive is modulating.</li> <li>• <b>Off:</b> Drive has stopped and start command is not applied.</li> </ul>
8	OFF LED	Indicator has the following states: <ul style="list-style-type: none"> <li>• <b>Steady on:</b> The indicator is in this state, because of the following 2 reasons: <ul style="list-style-type: none"> <li>- The drive is not modulating and the drive is coasted.</li> <li>- The stop signal is applied, output is active, and the drive is ramping down until coast or restart. Ramp times, protections, and stopping functions prolong this state.</li> </ul> </li> <li>• <b>Flashes for 3 seconds:</b> Indicates that the start command is initiated, but start is blocked.</li> <li>• <b>Off:</b> The drive is in operation, a start signal is applied and the output is active. This also includes ramping, running on reference, and AMA).</li> <li>• <b>Note:</b> When a fault has occurred on the drive, the LED is on though the start command is available. If there is a fault, and the start command is disabled and reinitiated again, the Off LED blinks.</li> </ul>
9	Stop button	Stops the operation of the drive, depending on the setting of parameter 5.5.3.1.4 CP Stop Button Action.
10	Info button	Provides more detailed information about an event that has occurred in the drive. If there is an active event and the button is pressed on the home screen, information on the active event is shown on screen. If parameter information is shown on the screen, pressing Info also shows a help text for the parameter.
11	Arrow buttons	<ul style="list-style-type: none"> <li>• <b>Arrow buttons:</b> To navigate within the different screens and menus.</li> <li>• <b>[OK]:</b> Primarily used to confirm selections and data in the control panel display.</li> </ul>
12	Home/ Menu button	Used to toggle between Home screen and current parameter menu in order to allow quick access to key status information during parameter setup.

### 3.2.3 Control Panel Basic Configurations

Basic configurations of the control panel include:

- Readout status of the motor and the drive which includes warnings and faults.
- Navigate to the menus in order to view or change parameter settings for the drive.

#### 3.2.3.1 Starting the Drive and Control Panel Display

While the drive is powering up until it is ready to operate, the control panel display shows the following:




Illustration 4: Control Panel Display on Startup

Table 7: Legend Table

Legend	Description
1	Shows the software version of the control panel.



N O T I C E

When the drive is started, it takes 25–30 s for the drive to be in ready state and for the control panel display to change to the *Home* screen (default).

### 3.2.3.2 Understanding Readout Screens

When the drive is in ready state, the control panel display shows the *Home* screen. By default, as a factory setting, the *Home* screen is shown as follows.

The *Home* screen can be customized.




Illustration 5: Home Screen (Donut View vs. Line View)

The following are the legends and description of the Home screen.

Table 8: Legend Table

Legend	Description
1	Shows the name of the application software.
2	Shows the status of the drive (see the following table).
3	Shows the current control of the drive. REM indicates remote control and LOC indicates local control. The arrow shows the direction of the motor.
4	Shows the setpoint of the selected operation mode. The local setpoint can only be changed when the drive is in local control.
5	Shows the scroll bar. The scroll bar indicates whether the screen is in the upper Readout Screen 1 or lower Readout Screen 2 position, when in the menu structure or parameters.
6	Shows the readout value as a donut infographic view. By default, the Motor Speed readout is shown. It is possible to show only a single readout in a donut view. When more than 1 readout is configured, the screen changes to a line view. A minimum of 2 and a maximum of 5 readouts are shown in the line view.

The status line of the control panel shows the status of the drive. The status line texts are dynamically generated, based on the configuration of the system. The following are some examples of basic operation:

Drive status in the panel	Description
Drive Ready	Drive is powered and ready to start.
Running at Reference	Drive is running at speed reference.
Running at Standstill	Drive is running with 0 reference.
Stopping	Drive is running towards stop.
Stopped	Drive is stopped due to an active stop command.
Coasted	Drive is coasting due to an active coast command.

## Application Guide

Drive status in the panel	Description
Quick Stop	Drive is stopped due to an active quick stop command.
Start Interlock	Drive is stopped with an active start command. To restart, the start command must be deactivated and given again.
Start Inhibited	Drive is in a state that is preventing start. All start commands are ignored.
Safe Torque Off (STO)	Drive is coasting due to an active STO command.
Inching	Drive is inching or jogging.
Running/Stopping/Inching, with: <ul style="list-style-type: none"> <li>Power Limit</li> <li>Undervoltage Limit</li> <li>Overvoltage Limit</li> <li>Torque Limit</li> <li>Current Limit</li> <li>Speed Limit</li> </ul>	Drive is running, stopping, or inching, and has exceeded the limit that is shown. For example, <i>Running - Power Limit</i> . Some possible limits are listed in the cell on the left. See also the preceding image.
AMA Ready	Advanced Motor Adaptation is activated and is awaiting the start command.
AMA in Progress	Advanced Motor Adaptation is running, measuring motor data.
AMA Finished	Advanced Motor Adaptation has finished. To restart the drive, remove and then reapply the start command.

Press the down arrow on the control panel when in the Readout Screen 1, the control panel screen navigates to the Readout Screen 2. As a factory default setting, the control panel shows 3 readout values, as shown.

### 3.2.3.3 Setting the Intensity of Display Backlight and Contrast

When in *Readout Screen 1* or *Readout Screen 2*, it is possible to adjust the intensity of the display backlight and the contrast can be adjusted according to individual requirement.

To adjust the display backlight and contrast settings, press the *Info* button and any of the arrow buttons of the control panel. The screen changes to as follows.




Illustration 6: Intensity change in Backlight and Contrast


- To change the intensity of the backlight, keep pressing the *Info* button along with either the up and down arrow buttons of the control panel.
- To change the contrast, keep pressing the *Info* button along with either the left and right arrow keys of the control panel.

### 3.2.3.4 Changing the Content of Different Readout Screens

In this section, an example to change or customize the content of *Readout Screen 1* is explained. The same procedure is applicable for *Readout Screen 2*.

- To change the content, press *OK* for a minimum of 5 seconds while in any *Readout Screen 1* or *Readout Screen 2*. The screen changes as shown.


Application Guide



e30bj733.11

Illustration 7: Typical Readout Screen

2. Press the up arrow of the control panel and move to the remove readout button to remove an existing readout. Pressing the left and the right arrow of the control panel, a readout can be added or removed using the add readout or remove readout buttons. When at the add or remove readout buttons, the buttons are highlighted in black as shown.



e30bj732.10


Illustration 8: Add and Remove Readout buttons

3. After selecting the available selections to add or remove from the list, press *OK*.

**NOTICE**

On removing a readout, the last readout from the list is removed.


On selecting the add readout button, select the readout to be added. In this example, the readout *Line-to-Line Voltage (RMS)* is selected, as shown.



e30bj734.10

Illustration 9: Readout Screen Update (Example)

- 4. To add more readouts, continue pressing the add readout button and select required readouts.
- 5. Press *Home* button or *Back* button to return to the required readout screen, after adding required readouts.



e30bj735.10

Illustration 10: Readout Screen Update

**NOTICE**

*Readout Screen 1* and *Readout Screen 2* can also be adjusted using the *parameter group 8 Customization* → Control Panel. For more information, see [6.9 Customization \(Menu Index 8\)](#).

### 3.2.3.5 Parameter Group Screens and Overall Navigation

Pressing the *Home/Menu* button toggles between readout screens and the parameter group screen. The content of the parameter group screen can vary depending on the current level of the parameter group. A typical parameter group screen is shown below.

Application Guide




Illustration 11: Parameter Group Screen

Table 9: Legend Table

Legend	Description
1	Name and control state of the drive.
2	The menu readout header shows the 1 <sup>st</sup> 3 signals selected in <i>Readout Screen 2</i> . Editing this line also affects <i>Readout Screen 2</i> .
3	Press the left and right icon to navigate 1 level above or below, respectively, in the parameter group structure. When the Previous or Next arrows are not shown, this indicates that currently at the top of the menu structure (as in the illustration above) or at the bottom of the menu structure. See illustration for Previous button.
4	Name of the application software that is currently active in the drive.

Basic navigation handling techniques

To navigate through and within the different parameter groups, use the navigation keys of the control panel.

- Press the up or down arrows of the control panel to navigate to different parameter groups.
- Press the left or right arrows of the control panel to navigate to parameter sub groups or parameters within a parameter group.
- Press the *Back* button to navigate to a higher level, and *OK* button to navigate to a lower level, in the parameter/parameter group screens.




Illustration 12: Parameter Navigation

Table 10: Legend Table

Legend	Description
1	Previous button when in the parameter group.
2	When parameters are defined as readout only, the current readout is shown below the parameter name. A black outline around the parameter indicates that the value of the parameter cannot be changed.

3.2.3.6 Changing Selections in a Parameter

In this example, the *parameter 5.8.6.2.1 Ramp 1 Type* is considered. When a parameter has selections, a black highlight is active on the parameter index and name, as shown.

Application Guide




Illustration 13: Changing Selections in a Parameter

1. To view the selections of the parameter, press right arrow of the control panel or *OK*. The selections available for the parameter is shown.




Illustration 14: Selections in a Parameter (Example)

2. Press the up or down arrow to browse through the selections.
3. Press *OK*, at the required selection.

### 3.2.3.7 Changing Parameter Value

In the example, the *parameter 5.8.6.2.2 Ramp 1 Accel. Time* is considered and the illustrations show the change of value from 5 s to 10 s.

1. Go to the *parameter 5.8.6.2.2 Ramp 1 Accel. Time* and press *OK*.

The screen is changed to as shown. The range of the parameter (minimum to maximum values) is shown at the bottom of the control panel display.

2. To go to the values before or after the decimals, use the left and right arrow buttons. A black highlight on the digit indicates the location where the cursor is active.
3. Press the up and down arrow buttons of the control panel to increase or decrease the value.
4. Press *OK*, to confirm the changes.

The following illustration shows all the screens relevant to change the value of a parameter.




Illustration 15: Changing Value in a Parameter

### 3.2.3.8 Locking the Control Panel Display

To avoid unintended interaction via the control panel, the control panel display can be locked.

1. To lock the control panel, press the *Back* button for 3 s. After 3 s, the following screen is shown.




Illustration 16: Control Panel Lock Screen

## Application Guide

When the control panel is locked, no interaction is possible even though buttons on the control panel are pressed. To unlock the control panel, press the *Back* button for 3 s.

### 3.2.4 Control Panel Shortcuts

Following is a list of shortcuts in navigating the control panel.

Table 11: Legend Table

Action	Pre-condition	Buttons	Activate Time
Fast scroll	When in a menu or choice lists	Up and down arrows	1 s. to activate
Factory reset	N/A	<i>Home</i> + <i>Back</i> + down arrow	3 s. to activate
Keypad lock		<i>Back</i>	3 s. to activate or deactivate
Reference set point edit	<ul style="list-style-type: none"> <li><i>Home</i> screen is active.</li> <li>LOC mode is active</li> <li>Control allowed</li> </ul>	[OK]	Single press
Edit <i>Home</i> screen readouts	<i>Home</i> screen active	[OK]	5 s. to activate
Edit Menu Readout header	Any menu is active	[OK]	5 s. to activate
Show active events	<i>Home</i> screen is active	<i>Info</i>	A single press
Screen contrast and brightness	<i>Home</i> screen is active	<i>Info</i> + arrows	Continuous simultaneous press

### 3.3 MyDrive® Insight

MyDrive® Insight is a platform-independent software tool that supports the commissioning, engineering, and monitoring of iC7 series. Some of the key features include:

- Fast and easy configuration and commissioning.
- Monitor the drives as part of daily operations or any others.
- Collect data and information for troubleshooting, maintenance, and service.
- Discovery and access to multiple drives in a network.
- Intuitive user interface.
- Notifications and visualizations on real-time information and events about the drive.
- PC control to perform operations such as starting or stopping the drive, set references, set direction, reset, and coast of the drive.
- Perform updates on single or multiple drives.
- Backup and restore of parameter settings.
- Data logging and analyzing for troubleshooting.

#### NOTICE

The section is documented for MyDrive® Insight version 2.8.0 or above. Make sure to uninstall lower versions of MyDrive® Insight from the workstation to utilize the latest MyDrive® Insight functions.

#### NOTICE

The section MyDrive® Insight in the application guide covers basic information such as getting started with MyDrive® Insight, accessing and viewing or changing the parameters, and PC control to operate the drive using MyDrive® Insight. For further information on the different MyDrive screens, integrated help within MyDrive® Insight will be available in future releases.


### 3.3.1 Getting Started with MyDrive Insight

As a prerequisite, ensure that MyDrive® Insight is installed on the device (PC or laptop). MyDrive® Insight can be downloaded and installed from MyDrive® Suite, available here: <https://suite.mydrive.danfoss.com/>



**Procedure**

1. To establish a point-to-point connection between the drive and the device, use the communication interface X0 and the RJ45 Ethernet port on the device by using a standard ethernet cable.

If the device does not have an RJ45 Ethernet port or it is already in use, then a conventional adapter from USB-C to RJ45 can be used. To connect several drives at the same time, use an Ethernet switch between the PC and the control unit.



2. When the drive is powered up and in *Ready* state, open MyDrive® Insight on the device and the drive is recognized.
3. To establish or confirm the connection, click the arrow button.



4. Select the required interaction for the drive. In this example, the *Device Info* screen is shown.




Illustration 20: Device Info

## NOTICE

The application guide covers basic information such as accessing parameters and using the PC control in MyDrive® Insight.

### 3.3.2 Accessing Parameters and Understanding Parameter Screens in MyDrive Insight

#### Viewing and Changing Parameters

1. To access the parameters of the connected drive, click *Setup and Service*.
2. Click *Parameters* → *Live*, as shown.




Illustration 21: Setup and Service

#### Parameter Screen Overview

The following is an overview of the *Parameters (Live)* screen in MyDrive® Insight.






Illustration 22: Parameters (Live)

Table 12: Legend Table

Legend	Name	Description
1	Parameter group	Navigate through the different parameter groups in the drive.
2	Search field	Use the search function to find a specific parameter.
3	Value field	View and change a parameter value or selection. All the parameters for the drive are shown on the Live screen.
4	PC Control button	Switch to PC control to start or stop the drive using MyDrive Insight.
5	Favorites	Select a parameter as a favorite by clicking the star in its row. Open the favorites panel on the right side of the screen by clicking the star at the top of the page.

Navigate through different parameter groups  
In the following picture, *parameter group 4 Motor* is shown as an example.

Application Guide




Illustration 23: Parameter Group

1. Click the parameter group (1) from the *Live* pane.
2. Click the parameter subgroup (2).
3. Repeat step 2, until the right level of parameter sub group (3) is reached to find the specific parameters (4).

NOTICE

When in a specific parameter subgroup, only parameters relevant to the parameter subgroup can be accessed.

Searching for a specific parameter

In the *Search* field, type the search term. The search returns all parameters that have the search term in the name.

In the following example, all parameters with *DC-Link* in the name are listed in the search results.




Illustration 24: Search button

1	Search term
2	Search results

3.3.3 Viewing and Changing Parameter Settings

When in a specific parameter group, all parameters related to the parameter group are shown. Depending on the access type of the parameter, there is a possibility to view the parameter setting or change the current selection or value of the parameter.

In the following picture, *parameter group 4 Motor* is shown as an example.

Application Guide




Illustration 25: Parameter Overview

Table 13: Legend Table

Number	Field Name	Description
1	<i>Index</i>	Based on the parameter group structure, the index defines the location of the parameter. The index is not used as a unique identifier of a parameter.
2	<i>Name</i>	Name of the parameter.
3	Status parameters	Provides the current status or value of a parameter. The parameter value is shown in a light gray color and cannot be changed.
4	Selection parameters	To see all selections available for the parameter, click the value in the <i>Value</i> field.
5	Range parameters	The parameter value can be modified based on the ranges defined (maximum and minimum values).
6	<i>Value</i>	The current value of the parameter.
7	<i>Default</i>	The factory setting (default value) of the parameter.
8	<i>Min and Max</i>	When applicable, the minimum and maximum values of the parameter are shown in the <i>Min</i> and <i>Max</i> fields.
9	<i>Unit</i>	When applicable, the unit of the parameter is shown in the <i>Unit</i> field.
10	<i>Number</i>	The unique identifier for each parameter. The identifier is independent and decoupled from the parameter index values.
11	<i>Help</i>	Click the ? button to see a description about the parameter. For more detailed descriptions, see <a href="#">6 Parameter Descriptions</a> .
12	<i>Favorites (star)</i>	Clicking the <i>Favorites</i> icon will add the parameter to <i>Favorites</i> .

## Application Guide

## 3.3.4 PC Control to Operate the Drive Using MyDrive® Insight

To operate the drive using PC control, click the *Control Panel* button in MyDrive® Insight. The following illustration shows the different screens to operate the drive via MyDrive® Insight.




Illustration 26: Operate Drive using MyDrive® Insight

To access PC Control in MyDrive® Insight and operate the drive, perform the following:

1. Click *REQUEST CONTROL* button (1).
2. Click *Continue* (2) to confirm secure operational conditions while controlling the drive using MyDrive® Insight.
3. Use the *START*, *STOP*, *STOP COAST* buttons (3) to perform a drive operation. Use the sliders (4) to increase or decrease the reference speed.
4. To reset a drive in case of a fault, click *RESET FAULTS* (5).
5. For ease of access, click the Pin button (6) to make the control panel be constantly visible on the screen.

## 3.3.5 Datalogger

The datalogger in MyDrive Insight enables the monitoring of signals and related information for the selected signals. To access the Datalogger feature, select the drive (1), then go to *Graphs and Reports* (2) → *Datalogger* (3).

Application Guide




Illustration 27: Navigating to Datalogger

The following image shows the Datalogger main controls.




Illustration 28: Datalogger Screen

Table 14: Main controls

Legend	Description
1	Opens the window to select available Datalogger files for viewing.
2	Shows the list of Datalogger settings.
3	Shows the Datalogger status.
4	Enables or disables Datalogger. When disabled, all Datalogger configuration settings are inactive. When enabled, Datalogger is active and operates based on the configuration settings.
5	Activates the force trigger. The 0 – 1 transition (rising edge) triggers Datalogger manually. This function is typically used with automatic triggers.
6	Arms Datalogger. The 0 – 1 transition (rising edge) readies Datalogger for triggering.
7	Applies any changed settings.

### 3.3.5.1 Configuring Datalogger

To configure the datalogger, the following are the 2 main steps:

- Configure the signals to be recorded using the datalogger.
- Configure the datalogger settings.

**Procedure:**

1. Open Datalogger.

The settings view opens.




Illustration 29: Datalogger settings

The description of the user interface elements in the screen is as follows:

Field Name	Field Description
Sample time (ms)	Enter a sample time in ms. The actual sample time is dependent on the switching frequency. Fast sample rate settings result in data changing slowly in the resulting log.
Window time (s)	Defines the size of the capture window. Enter the window time in seconds. High sample rates and large capture times that result in large capture files may be rejected when the configuration is applied.
Storage	Select the location to which datalogger files are stored. Available selections are: <ul style="list-style-type: none"> <li>- <b>RAM:</b> Settings are stored to the RAM of the drive.</li> <li>- <b>Flash:</b> Settings are stored to the flash of the drive.</li> <li>- <b>SD card:</b> Data is stored on the (optional) microSD card.</li> </ul> The microSD cards supported are: SD, SDHC, or SDXC which must be formatted for the FAT32 file system. SDHC is the recommended type, as they are delivered preformatted to FAT32.
Trigger position (s)	Adjust the slider to position the trigger. Setting the trigger position to 0 indicates the datalogger recording starts at the time of the trigger. Setting a negative value indicates that the datalogger recording starts after the trigger has occurred. Setting a positive value indicates that the datalogger recording starts before the trigger has occurred.
Trigger type	Following are the trigger types: <ul style="list-style-type: none"> <li>- <b>No trigger</b> (manual trigger only)</li> <li>- <b>Equal</b> triggers when the value of the trigger source variable is equal to trigger level 1.</li> <li>- <b>Not equal</b> triggers when the value of the trigger source variable is not equal to trigger level 1.</li> <li>- <b>Greater than</b> triggers when the value of the trigger source variable is greater than trigger level 1.</li> <li>- <b>Greater than or equal to</b> triggers when the value of the trigger source variable is greater than or equal to trigger level 1.</li> <li>- <b>Less than</b> triggers when the value of the trigger source variable is less than trigger level 1.</li> </ul>

Field Name	Field Description
	<ul style="list-style-type: none"> <li>- <b>Less than or equal to</b> triggers when the value of the trigger source variable is less than or equal to trigger level 1.</li> <li>- <b>Rising edge</b> triggers when the value of the trigger source variable rises above trigger level 1. If the trigger source is already above trigger level 1, the trigger must first drop below the trigger level.</li> <li>- <b>Falling edge</b> triggers when the value of the trigger source variable falls below trigger level 1. If the trigger source is already below trigger level 1, the trigger must first rise above the trigger level.</li> </ul>
Trigger level 1	Defines the trigger level associated with the defined trigger type. This level is used for all single-level trigger types. The entry in the field defines the lower trigger level for window trigger types, such as bounds and out of bounds.
File name	Name of the file for datalogger recording.
Over-write	<p>Click the toggle button to turn the overwrite function on or off.</p> <ul style="list-style-type: none"> <li>- <b>On:</b> Overwrite is enabled. A file number is not appended to the data log file. The datalogger overwrites a previous datalog file.</li> <li>- <b>Off:</b> Overwrite is disabled. A file number is appended to the log file. For each datalog, the datalog file is incremented and the previous datalog file is not overwritten.</li> </ul>
Next file number	The number entered in this field is appended to the initial datalog file. Entry in the field is useful when datalogs are previously available in the drive. The number is auto-incremented with each datalog recording when the entry in <i>Next file number</i> is enabled.
Trigger mode	<p>Select 1 of the following trigger modes.</p> <ul style="list-style-type: none"> <li>- <b>Single trigger mode:</b> After a datalog recording, the datalogger must be rearmed before another trigger is allowed.</li> <li>- <b>Auto trigger mode:</b> After a datalog recording, the datalogger automatically rearms and starts to accept triggers.</li> </ul>
Trigger source	Click the <i>Add signal</i> button under the <i>Trigger source</i> heading. A <i>Trigger source</i> field appears. Click on the <i>Trigger source</i> field to select the signal source which is used for triggering the datalogger recording. The trigger source list opens in a new window:


Application Guide

Field Name	Field Description
	<p><b>Settings</b></p> <p>Sample time (ms): 1500      Window time (s): 5</p> <p>Storage: Temporal device storage (RAM)      Trigger position (s):</p> <p>Trigger type: Equal</p> <p>File name: user</p> <p>Next file number: 1</p> <p><b>Trigger source</b></p> <p>Trigger source: Control Unit Temperature</p> <p><b>Signals</b></p> <p>Signal 1: Control Unit Temperature</p> <p>Signal 3: Heat Sink Temperature</p> <p>Signal 4: Control Unit Temperature (2952)</p>
<p>Signals</p>	<p>Click the <i>Add signal</i> button under the <i>Signals</i> heading. A <i>Signal</i> field appears. Click on the <i>Signal</i> field to select the signals that are logged. The signal list opens in a new window:</p> <p><b>Settings</b></p> <p>Sample time (ms): 1500      Window time (s): 5</p> <p>Storage: Temporal device storage (RAM)      Trigger position (s):</p> <p>Trigger type: Equal</p> <p>File name: user</p> <p>Next file number: 1</p> <p><b>Trigger source</b></p> <p>Trigger source: Control Unit Temperature</p> <p><b>Signals</b></p> <p>Signal 1: Control Unit Temperature</p> <p>Signal 3: Heat Sink Temperature</p> <p>Signal 4: Control Unit Temperature (2952)</p> <p>Signal 5: Select signal</p> <p>Signal 6: Select signal</p> <p>Signal 7: Select signal</p> <p>Signal 8: Select signal</p> <p>Add more signals as necessary by clicking the <i>Add signal</i> button again.</p>



Application Guide

2. Click *Apply settings*.



After the signal selection and the datalogger settings, the datalogger is ready to record the logs. To view a recorded datalog file, click the icon shown in the following figure.




Illustration 30: Datalogger View Icon

### 3.3.6 Backup and Restore

#### Backup

The Backup feature in MyDrive® Insight allows to store the parameter settings of the drive into a new or existing project file, RAM, or Flash memory of the drive, or to an optional microSD card.

To utilize the microSD card as a storage device, the microSD card must be inserted in the slot on the interface module located behind the control panel, as shown in the image below.




Illustration 31: MicroSD Card Slot

- 1 The microSD card

Following are the types of microSD card supported by the interface module, which must be formatted for the file system FAT32.

- Secure Digital (SD) card
- Secure Digital High Capacity (SDHC)
- Secure Digital Extended Capacity (SDXC)

## NOTICE

It is recommended to use SDHC cards as they are delivered as preformatted to FAT32.

## Application Guide


## 3.3.6.1 Backing up the Drive

## Procedure

1. To back up the drive, select a drive, go to *Setup & Services* → *Parameters*.

➔ The *Parameters Live* screen is shown.

2. Click the icon as shown in the figure.



➔ This opens a screen to select the backup destination. The destinations to back up are:

- **Project:** The user can back up an existing project or a new project.
- **Device file system:** The user can back up to 1 of the available memory devices of the drive.

3. Click *Next*.
4. If *Project* was selected, give the backup file a name and description.  
If *Device file system* was selected, select where to save the backup. The selections are flash, RAM, or an (optional) microSD card. It is possible to specify a name for the backup file as well.
5. Click *Backup* to begin backup.

➔ Once backup is completed, a notification screen about it appears. If a *Project* backup was created, the backup is shown in the device menu under *Parameters*.




Illustration 33: Backup File in the Menu

### 3.3.6.2 Restoring the data to the Drive

**Procedure**

1. To restore data to the drive, select a drive, go to *Setup & Service* → *Parameters*.
2. Click the icon as shown in the image below.




Illustration 34: Restore Data Icon

Application Guide

3. Select the source of the data which has to be restored to the drive.



Illustration 35: Source of Data for Restore

4. Click *Next* to select the backup source device and view the available backup files.
5. If *Project* is the restore source, select the correct backup to restore. Click *Next*.




Illustration 36: Select the Backup

6. Select the files for restoring data into the drive, as shown in the figure below, and click *Next*.

**NOTICE**

It is possible to exclude ethernet port settings when restoring the data.

Application Guide




Illustration 37: Restore Data

- 7. The system asks you to confirm the restore action. Click *Restore*.




Illustration 38: Confirm Restoration

➡ On successful restore of data, a message is displayed.

## 4 Application Software Structure and Overview

### 4.1 Understanding Application Software Structure Principles

The basic design principle of the application software structure and the related hierarchy refers to the setup of a typical iC7 series drive, as shown.

The same application software structure is used across all products within the iC7 series. This means that some of the parameter groups or dedicated parameters may not be visible for all applications. Therefore, the indexes of parameters may not be sequential. This design principle is followed to maintain consistency across all the different application software in the iC7 series. The application software is designed in this manner to have the same look and feel across different iC7 series products, and enable easier and faster troubleshooting.




Illustration 39: Application Software Structure Overview

### 4.2 Parameter Groups, Related Content, and Settings

The detailed structure and hierarchy within the parameter groups can vary, depending on the purpose of the parameter group and the total number of parameters. However, the design principle of the structure is to keep the overall sequence while commissioning or setting up the drive, within a logical structure. One example is the *Status* parameter group which is embedded into each main group (if applicable) to provide quick and easy access to view real time status information of relevant data of parameters within this group.

- All generic settings such as Grid, Power Conversion and DC link, Filters & Brake Chopper, and Motor are accessed via parameter groups 1–4.
- Most of the application-specific parameters and the configuration of external control signals are accessed via parameter group 5 Application.
- Features and functions such as Maintenance & Service, Functional Safety, and Customization are in parameter groups 6,7, and 8.
- The hardware setup for I/O interface, Options, and communication interfaces is done in parameter groups 9 and 10.
- The features and related parameters are grouped in individual parameter groups. Each feature has a parameter group of its own.
- Status information for each parameter group is available separately for easy access.
- The visibility of some parameters and parameter groups depend on the drive hardware used.

Following is the table which provides information about the parameter groups.

Index	Parameter group name	Description
1	Grid	Contains parameters for the configuring and monitoring the energy source of the drive system. Typically, the energy source is the grid. The menu also lets the user configure grid protection settings and view the condition of the grid.
2	Power Conversion & DC Link	Contains parameters to configure, monitor, and control the power conversion of the drive. The menu lets the user configure protection settings of the power unit and settings for the rectifier, DC link, and inverter.
3	Filters & Brake Chopper	Contains parameters to configure, monitor, and control the input filters, output filters, brake chopper, and brake resistors.
4	Motor	Contains parameters to configure motor, motor control, and motor protection.
5	Application	Contains parameters for application specific features such as process control, speed control, torque control, mechanical brake control, and many more.
6	Maintenance & Service	Contains parameters exclusively related to status, events, and backup and restore.
7	Functional Safety	Contains non-safety-related parameters for configuring Safe Torque Off, as well as other safety features.
8	Customization	Contains parameters to customize and adapt the behavior of the drive and user interface design.
9	I/O	Contains hardware-related parameters to configure I/Os and their options.
10	Connectivity	Parameters to configure the inbuilt and optional communication of the drive system.

Application Guide

Parameter group 1st level	Parameter group 2nd level	Parameter group 1st level	Parameter group 2nd level	Parameter group 1st level	Parameter group 2nd level
1 Grid	1.1 Grid Status 1.2 Grid Settings 1.3 Grid Protection	5 Application	5.1 Application Status 5.2 Protection 5.3 Load 5.4 Operation Mode 5.5 Control Places 5.6 Start Settings 5.7 Stop Settings 5.8 Speed Control 5.9 Torque Control 5.10 Process Control 5.11 Inching 5.12 Mechanical Brake Control	6 Maintenance & Service	6.1 Status 6.2 Software Information 6.4 Events 6.5 Operational Counters 6.7 Backup & Restore
2 Power Conversion & DC-link	2.1 Status 2.2 Power Unit Settings 2.3 Protection 2.4 Modulation			7 Functional Safety	7.1 Status 7.2 STO
3 Filters & Brake Chopper	3.1 Filters & Brake Chopper Status 3.2 Brake Chopper 3.3 Brake Resistor 3.4 Advanced Harmonic Filter 3.5 Output Filter			8 Customization	8.2 Basic Settings 8.3 Control Panel
4 Motor	4.1 Motor Status 4.2 Motor Data 4.3 Motor Control 4.5 Protection		5.26 Additional Status Outputs 5.27 Fieldbus Process Data	9 I/O	9.3 I/O Status 9.4 Digital Inputs/Outputs 9.5 Analog Inputs/Outputs
				10 Connectivity	10.2 Communication Interfaces 10.3 Protocols

e30bk019.12

Illustration 40: Parameter Groups



## 5 Configuration Set-up Examples

### 5.1 Introduction and Prerequisites

The section covers the basic configuration steps of a drive. The application may require more steps such as protection settings. Use the following topics as reference during the drive configuration/commissioning process:


- For control panel related configurations, see [3.2.3 Control Panel Basic Configurations](#).
- For information on using MyDrive Insight, see [3.3.1 Getting Started with MyDrive Insight](#).
- For detailed information about the parameters, see [6 Parameter Descriptions](#).

**Prerequisite:**

#### NOTICE

Ensure that the drive is mounted safely according to the installation and safety instructions shipped with the drive.

See also the following schematic for the correct wiring:



e30bk387.11

Illustration 41: Wiring Diagram

## NOTICE

Selection lists with inputs and/or outputs consist of the name of the hardware option and the numbers of the terminals. For example, terminal number 13 of the Basic I/O is named Basic I/O T13 in the selection list.

## 5.2 Basic setup of a Drive

The basic setup of the drive consists of the following configuration steps.

The steps described in detail are as follows.

1. Configure the grid settings using the following parameter.

Index	Parameter name	Example setting	Parameter number
1.2.1	Grid Type	TN	2942

2. Configure the power unit settings using the following parameters.

Index	Parameter name	Example setting	Parameter number
2.2.1.1	Unit Voltage Class	Low-voltage range	2832
2.2.1.2	Overload Mode	High overload (HO1)	2833

3. Configure the operation mode using the following parameters.

Index	Parameter name	Example setting	Parameter number
5.4.2.16	Operation Mode	Speed control	2500
5.4.2.19	Motor Feedback Mode	Open loop	2502

4. Configure the control place settings using the following parameters.

Index	Parameter name	Example setting	Parameter number
5.5.2.1	Control Place Selection	Advanced control	114
5.5.3.1.2	Local Control Mode	Allow local control	107
5.5.6.1.1	Advanced Start Input	Fieldbus start, Basic I/O T13	4722
5.5.6.1.2	Advanced Start Logic	Source 1	1933
5.5.6.1.7	Advanced Coast Inverse Input	Fieldbus coast, Basic I/O T16	4724
5.5.6.1.8	Advanced Coast Inverse Logic	Source 1	1936

5. Configure the fieldbus communication (if applicable). See relevant fieldbus guide.
6. Configure the readouts in the control panel. See [3.2.3.2 Understanding Readout Screens](#).

### 5.3 Configuring Motor, Motor Control, and Motor Thermal Protection

The required configuration steps depend on the motor type selected in parameter 4.2.1.1 *Motor Type*.

#### N O T I C E

The parameters specified in motor configuration cannot be adjusted when the motor is running.

Following are the steps in detail.

1. Configure basic motor data. Go to *Parameter group 4* and specify the following:

Index	Parameter name	Parameter setting	Parameter number
4.2.1.1	Motor Type	Induction motor or Permanent magnet motor	407
4.2.2.1	Nominal Power	As on motor product label.	405
4.2.2.2	Nominal Current	As on motor product label.	400
4.2.2.3	Nominal Speed	As on motor product label.	402
4.2.2.4	Nominal Frequency	As on motor product label.	403
4.2.2.5	Nominal Voltage	As on motor product label.	401

#### N O T I C E

Changing the product label data causes a reset of the advanced motor data to defaults and a loss of AMA results.

2. Perform AMA. To conduct the data measurement (in standstill), use the following parameter.

The advanced motor data, which are needed for optimal motor control performance and which are described in step 3, can be entered manually or measured and calculated based on AMA.

Index	Parameter name	Recommended setting	Parameter number
4.2.1.3	AMA Mode	Motor data	420

#### N O T I C E

AMA requires an active start signal for execution. After AMA is performed, the setting of AMA Mode automatically switches to Off and a notification must be confirmed. A new start signal is required for starting the motor. This is to avoid an unintended start caused by the active start signal. Consult the iC7 Series Frequency Converters Installation Safety Guide for safety information on unintended start.

3. Configure the advanced motor data if AMA is not performed. Setting these parameters are recommended for optimal motor control performance.

Also, if AMA is successfully performed, the results can be read out in the following parameters.

#### Asynchronous Induction Motors

Index	Parameter name	Setting	Parameter number
4.2.3.1	Stator Resistance Rs	Result of AMA or as on motor data sheet.	408
4.2.3.2	Rotor Resistance Rr	Result of AMA or as on motor data sheet.	409
4.2.3.3	Iron Loss Resistance Rfe	Result of AMA or as on motor data sheet.	413

Index	Parameter name	Setting	Parameter number
4.2.3.4	Stator Leakage Reactance Xls	Result of AMA or as on motor data sheet.	440
4.2.3.5	Rotor Leakage Resistance Xlr	Result of AMA or as on motor data sheet.	441
4.2.3.6	Magnetizing Reactance Xm	Result of AMA or as on motor data sheet.	442

#### Permanent Magnet Motors

Index	Parameter name	Setting	Parameter number
4.2.4.2	Stator Resistance Rs	Result of AMA or as on motor product label.	408
4.2.4.3	d-axis Inductance Ld	Result of AMA or as on motor product label.	417
4.2.4.4	d-axis Inductance LdSat	Result of AMA or as on motor product label.	418
4.2.4.5	Ld Saturation Point	Result of AMA or as on motor product label.	426
4.2.4.6	q-axis Inductance Lq	Result of AMA or as on motor product label.	427
4.2.4.7	q-axis Inductance LqSat	Result of AMA or as on motor product label.	422
4.2.4.8	Lq Saturation Point	Result of AMA or as on motor product label.	424
4.2.4.1	Back EMF	Only for Permanent Magnet Motors. As on motor data sheet, as specified at 1000 RPM.	415

#### 4. Configure motor control.

Index	Parameter name	Example setting	Parameter number
4.3.1.1	Motor Control Principle	FVC+ control	2503
4.3.3.1	Continuous Rs Estimation	Enabled	428

**Note:** For motor control principles VVC+ and U/f, the following applies:

- Configure compensations for slip and different application conditions in parameter group 4.3.4.
- Enable and configure Automatic Energy Optimization (AEO) in parameter group 5.3.3 *Torque & AEO*.
- For U/f, define the voltage and frequency points in parameter group 4.3.2 *U/f Settings* as required for the application.

#### 5. Configure motor thermal protection.

The Electronic Thermal Relay (ETR) function protects the motor from thermal overload without connecting an external device, by estimating the motor temperature based on present load and time. The ETR function meets the relevant requirements of UL 61800-5-1, including the Thermal Memory Retention requirement, and ensures a class 20 protection level. ETR can be configured and the motor thermal load can be viewed using the following parameters.

Index	Parameter name	Recommended setting	Parameter number
4.5.4	ETR Overtemperature Response	Fault, ramp to coast	2825
4.1.16	Motor Thermal Load (ETR)	Varies (Readout)	2951

The fault 0x7120-4177 *Motor Thermal Overload* is issued when the motor thermal load has reached 100%.

### 5.4 Configuring Speed Control

The section describes the basic configuration for speed control in open loop.

The following procedure describes the additional steps to control the speed according to the following wiring schematic.




Illustration 42: Wiring Schematic Example - Speed Control with Basic I/O

**Procedure**

1. Perform the steps in [5.2 Basic setup of a Drive](#).
2. Perform the steps in [5.3 Configuring Motor, Motor Control, and Motor Thermal Protection](#).
3. Configure the operation mode for speed control using the following parameters.

Index	Parameter name	Example setting	Parameter number
5.4.2.16	Operation Mode	Speed control	2500
5.4.2.19	Motor Feedback Mode	Open loop	2502

4. Configure the type of speed reference used for the Advanced Control Place

Parameter index	Parameter name	Example setting	Parameter number
5.5.6.2.1	Adv Speed Reference	Fieldbus reference, Reference 1 input	1915
5.5.6.2.2	Adv Speed Reference Logic	Sum	1916

5. Configure speed limit settings using the following parameters.

Index	Parameter name	Example setting	Parameter number
5.8.3.1	Positive Speed Limit	1500 RPM	1729
5.8.3.2	Negative Speed Limit	-1500 RPM	1728
5.8.3.3	Minimum Speed Limit	0 RPM	1722

6. Configure the ramp using the following parameters.

Index	Parameter name	Example setting	Parameter number
5.8.6.1.1	Ramp Selector	Ramp 1	1100
5.8.6.2.1	Ramp 1 Type	Linear ramp	1125
5.8.6.2.2	Ramp 1 Accel. Time	5s	1101
5.8.6.2.3	Ramp 1 Decel. Time	5s	1105

7. Configure the reference and input settings according to the selected reference type, using the following parameters.

Reference Settings			
Index	Parameter name	Example setting	Parameter number
5.8.4.1	Speed Reference 1 Input	Basic I/O T33	501
5.8.4.3	Speed Reference 1 Maximum	1500 RPM	1724
5.8.4.4	Speed Reference 1 Minimum	0 RPM	1725

Basic I/O Settings			
Index	Parameter name	Example setting	Parameter number
9.5.2.1	T33 Terminal Mode	Analog input	2020
9.5.2.2	T33 Terminal Type	Voltage	2273
9.5.2.3	T33 Minimum Value	0 V	2272
9.5.2.4	T33 Maximum Value	10 V	2271

8. Optional: Configure the settings for the Auto Tuning of the speed controller

For achieving optimal motor control performance, perform an Inertia Estimation or, if the inertia is known, enter the inertia manually with parameter 5.3.2.3 *System Inertia*.

Also perform an Auto Tuning of the speed controller settings. Auto tuning requires an inertia estimation value. Besides the settings already described above, adjust the following:

Index	Parameter name	Example setting	Parameter number
5.8.11.1	Speed Controller Auto Tuning	Enabled	4546
5.3.2.1	Inertia Estimation Mode	Without load profile	668

**NOTICE**

The recommended setting for parameter 5.3.2.1 *Inertia Estimation Mode* depends on the torque characteristic configured in parameter 5.3.3.1 *Torque Characteristic*. Select *Without load profile* in case of a constant torque load and *With profile* for a variable torque load.

- Apply a start signal to terminal 13 of the Basic I/O to start the tuning process.

### 5.5 Configuring Torque Control

While the drive is in torque control, the motor speed is monitored but not controlled. Therefore motor speed can reach speed limits, when the load, application, or upper system are not within the speed limits. For this reason, it is important to set the limits of the output frequency as described in [5.4 Configuring Speed Control](#). Since speed ramps can also be used as limiting factor, check the ramp settings in step 6 of [5.4 Configuring Speed Control](#). Torque control is only available with the motor control principle FVC+. The procedure is described below according to the following wiring schematic. The same wiring schematic is used in [5.4 Configuring Speed Control](#).




Illustration 43: Wiring Schematic Example - Torque Control with Basic I/O

To configure torque control, perform the following:

- Perform the steps in [5.2 Basic setup of a Drive](#).
- Perform the steps in [5.3 Configuring Motor, Motor Control, and Motor Thermal Protection](#).



- Configure the operation mode for torque control using the following parameter.

Parameter index	Parameter name	Example setting	Parameter number
5.4.2.16	Operation Mode	Torque control	2500

- Configure the type of torque reference used for the Advanced Control Place.

Parameter index	Parameter name	Example setting	Parameter number
5.5.6.2.4	Adv Torque Reference	Fieldbus reference, Reference 1 input	1929
5.5.6.2.5	Adv Torque Reference Logic	Sum	1919

- Configure the torque limit settings using the following parameters.

Index	Parameter name	Example setting	Parameter number
5.9.2.1	Positive Torque Limit	150%	1810
5.9.2.2	Negative Torque Limit	-150%	1811
5.9.2.3	Motoring Torque Limit	100%	1321
5.9.2.4	Regenerative Torque Limit	100%	1323
5.9.2.5	Speed Limit Mode Torque Ctrl.	Pos./Neg. speed limit	2332

See more information about flexible limit modes in [6.6.9.3 Limits \(Menu Index 5.9.2\)](#).




Illustration 44: Torque Control Limits

- Configure reference settings and terminals used for the reference signal.

Reference Settings			
Index	Parameter name	Example setting	Parameter number
5.9.3.1	Torque Reference 1 Input	Basic I/O T33	4534
5.9.3.3	Torque Reference 1 Maximum	100%	4530
5.9.3.4	Torque Reference 1 Minimum	0%	4531
5.9.3.14	Torque Reference Ramp Time	10s	2330

**Basic I/O Settings**

Index	Parameter name	Example setting	Parameter number
9.5.2.1	T33 Terminal Mode	Analog input	2020
9.5.2.2	T33 Terminal Type	Voltage	2273
9.5.2.3	T33 Minimum Value	0V	2272
9.5.2.4	T33 Maximum Value	10V	2271

## 5.6 Configuring Process Control

The inbuilt process controller is used to control processes based on feedback sensor signal. Examples of controlled process variables are flow, pressure, temperature. The process controller is used as reference source for the speed controller. For this reason, it is a pre-condition to follow the instructions in basic setup of a drive, configuring motor and motor control, and configuring speed control.

The auto-tuning simplifies the configuration and saves time during commissioning, while ensuring accurate PID control adjustment. In addition, the inbuilt controller supports inverse control for applications such as level control or the control of a vacuum pump. In such applications, increasing the drive speed decreases the feedback value.

This section describes the extra configurations required to set up a basic pressure control loop according to the following illustration and wiring diagram.




Illustration 45: Process Controller

This configuration setup contains the following features:

- A pressure transducer to measure the pressure of the system. This data is used as feedback. The sensor is supplied power by the drive's 24 V supply.
- A potentiometer to adjust the setpoint and a switch for the start signal which is connected to digital input 1 (terminal 13) on the Basic I/O. See the following wiring drawing example.




Illustration 46: Wiring Diagram Example - Process Control with Basic I/O

To set up basic pressure control, perform the following:

1. Perform all the steps in [5.2 Basic setup of a Drive](#).
2. Perform all the steps in [5.3 Configuring Motor, Motor Control, and Motor Thermal Protection](#).
3. Perform all the steps in [5.4 Configuring Speed Control](#).
4. Select the process controller as reference in the settings for the control place.

Index	Parameter name	Recommended settings	Parameter number
5.5.6.2.6	Adv. Process Reference	Fieldbus reference/Reference 1 input	6054
5.5.6.2.7	Adv. Process Reference Logic	Source 1	6045

5. Adjust settings for the process reference and for the feedback according to the application. The example considers an operating range from 0–4 bar.

Index	Parameter name	Example settings	Parameter number
5.10.3.1	Process Reference Max.	4 bar	6013
5.10.3.2	Process Reference Min.	0 bar	6014
5.10.3.3	Process Reference 1 Input	Basic I/O T33	6025
5.10.4.1	Feedback Mode	Feedback 1	6008
5.10.4.2	Feedback 1 Type	Analog feedback terminal	6021

Index	Parameter name	Example settings	Parameter number
5.10.4.3	Feedback 1 Maximum Scaling	4 bar	6015
5.10.4.4	Feedback 1 Minimum Scaling	0 bar	6016
5.10.4.5	Analog Input Feedback 1	Basic I/O T34	6027

6. Configure the electrical characteristics of the analog input terminals 33 and 34 for reference and feedback.

Terminal 33 Settings			
Index	Parameter name	Example settings	Parameter number
9.5.2.2	T33 Terminal Type	Voltage	2273
9.5.2.3	T33 Minimum Value	0V	2272
9.5.2.4	T33 Maximum Value	10 V	2271
Terminal 34 Settings			
Index	Parameter name	Example settings	Parameter number
9.5.3.2	T34 Terminal Type	Current	2279
9.5.3.3	T34 Minimum Value	4 mA	2278
9.5.3.4	T34 Maximum Value	20 mA	2277

7. To ensure optimum control performance for the system, perform auto-tuning of the process controller. The optimization of the settings is for the reference or a typical reference of the system.

Index	Parameter name	Example setting	Parameter number
5.10.7.1	Process Controller Auto Tuning	Enabled	6901
5.10.7.2	Auto Tuning Reference	2.3 bar	6902
Notes			
<ul style="list-style-type: none"> <li>- Default setting does not require modification before performing auto tuning.</li> <li>- <i>Parameter 5.10.7.1 Process Controller Auto Tuning</i> is disabled automatically after auto tuning is completed.</li> </ul>			

8. Apply a start signal to terminal 13 of the Basic I/O to start auto-tuning.  
 9. Enable the process controller using the following parameter.

Index	Parameter name	Example setting	Parameter number
5.10.1.10	Process Controller Enabled	Enabled	6053

10. In applications like pressure control with centrifugal pumps, additional energy savings can be achieved by using the AEO (Automatic Energy Optimization) function. To use this feature, configure the following parameters:

Index	Parameter name	Example setting	Parameter number
5.3.3.1	Torque Characterstic	Automatic Energy Optimization (AEO)	2809
5.3.3.2	AEO Minimum Speed	10 Hz	2810
5.3.3.3	AEO Minimum Magnetization	40%	2811

**NOTICE**

To start the application, a start signal is required, if the signal has been removed after completing auto-tuning.

## 6 Parameter Descriptions

### 6.1 Reading the Parameter Table

The application guide includes parameter overview tables. The following descriptions explain how to read the parameters.




Illustration 47: Reading the Parameter Table

1	The parameter name and index. Parameter names start with a P.	5	The data type of the parameter. See <a href="#">6.1.1 Understanding Data Types</a> .
2	The parameter help text which is visible through the control panel and MyDrive® Insight.	6	The type of parameter. Parameters have either defined ranges or selections. See <a href="#">6.1.2 Understanding Parameter Types</a> .
3	The default setting from the factory.	7	The access type of the parameter. See <a href="#">6.1.3 Understanding Access Types</a> .
4	The unit of the parameter.	8	The unique parameter number which is relevant for PLC programming.

#### 6.1.1 Understanding Data Types

Following is an overview of the datatypes used in iC7 application software.

Table 15: Overview on data type

Data type	Description	Size (Bits)	Range
BOOL	Boolean	1	0...1
INT	Integer	16	-32,768...32,767
DINT	Double integer	32	-2,147,483,648 up to 2,147,483,647
USINT	Unsigned short integer	8	0 up to 255
UINT	Unsigned integer	16	0 up to 65,535
UDINT	Unsigned double integer	32	0 up to 4,294,967,295
REAL	Real numbers	32	-3.402823466 E+38 (approximately 7 digits) up to -1.175494351 E-38 (approximately 7 digits) and +1.175494351 E-38 (approximately 7 digits) up to +3.402823466 E+38 (approximately 7 digits)
WORD	Bit string of length 16	16	0...65,535 (16#00...16#FFFF)
STRING	Sequence of characters	N/A	1 Byte per character
ULINT	Unsigned long integer	64	0 - 18446744073709551615
DATE_AND_TIME	Date and time information	64	N/A

#### 6.1.2 Understanding Parameter Types

Following are the different type of parameter information.

Table 16: Parameter Types and Description

Parameter Type	Description
Selection	The parameter provides a list of selections.
Range (0 - 255)	The value of the parameter is within the specified range. In this example, the parameter can have any value between 0 and 255.
Range (* - *)	The value of the parameter can be set within the full range of the datatype REAL. See <a href="#">6.1.1 Understanding Data Types</a> .
Range (0 - *)	The value of the parameter can be set within the upper range of the datatype REAL. See <a href="#">6.1.1 Understanding Data Types</a> .
Range (Unit dependent)	The range depends on the selected unit, and is visible in MyDrive Insight and the Control Panel.

### 6.1.3 Understanding Access Types

Following are the access type of parameters and descriptions.

Table 17: Access Types and Descriptions

Access Type	Descriptions
Read/Write	The parameter information can be read or changed.
Read Only	The parameter information can only be read.
Read/Conditional Write	The parameter information can be read and changed. The parameter settings cannot be modified when the drive is running. The drive must be coasted to edit parameter values.

## 6.2 Grid (Menu Index 1)

This parameter group contains parameters for configuring and monitoring the energy source of the drive system. Typically, the energy source is the grid. The menu also lets the user configure grid protection settings and view the condition of the grid.

### 6.2.1 Grid Status (Menu Index 1.1)

These parameters provide status readouts of grid related information.

#### P 1.1.1 Grid Frequency

**Description:** Shows the actual grid frequency.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 9041
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

#### P 1.1.2 Line-To-Line Voltage (RMS)

**Description:** Shows the average line-to-line voltage (RMS).

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9040
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

#### P 1.1.3 L1-L2 Line Voltage (RMS)

**Description:** Shows the L1-L2 line voltage (RMS).

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9048
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

#### P 1.1.4 L2-L3 Line Voltage (RMS)

**Description:** Shows the L2-L3 line voltage (RMS).

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9049
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 1.1.5 L3-L1 Line Voltage (RMS)

**Description:** Shows the L3-L1 line voltage (RMS).

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9050
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 1.1.6 Grid Voltage Imbalance

**Description:** Shows the grid voltage imbalance in %. A value greater than 3% may indicate grid problems.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 9047
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 1.1.7 Total Harmonic Distortion (THDv)

**Description:** Shows the total harmonic distortion of the grid voltage (THDv) in %.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 9046
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 1.1.12 Grid Active Power

**Description:** Shows the active power at the point of grid connection.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 9064
<b>Unit:</b> kW	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## 6.2.2 Grid Settings (Menu Index 1.2)

## P 1.2.1 Grid Type

**Description:** Select the grid type of the supply system. The selection affects the setting of "1.2.2 RFI filter" and "2.2.1.7 HF DC-link Filter Mode" if set to "As grid type".

<b>Default Value:</b> 0 [TN]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2942
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Conditional Write

The following are the selections for the parameter.

Selection number	Selection name
0	TN
1	TT
2	IT
3	HRG
4	Grounded Delta

## P 1.2.2 RFI Filter Mode

**Description:** Select the Radio Frequency Interference (RFI) filter mode.

<b>Default Value:</b> 2 [Filter matches grid type selection]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2943
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Conditional Write

The following are the selections for the parameter.



Selection number	Selection name
0	Filter inactive
1	Filter active
2	Filter matches grid type selection

### 6.2.3 Grid Protection (Menu Index 1.3)

These parameters allow the setting of various protections related to grid side conditions.

#### P 1.3.1 Invalid Frequency Response

**Description:** Select the response after detection of invalid grid frequency.

<b>Default Value:</b> 1 [Fault]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2337
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter

Selection number	Selection name
1	Fault
2	Automatically derate

#### P 1.3.2 Missing Grid Phase Response

**Description:** Select the response after detection of a missing grid phase.

<b>Default Value:</b> 1 [Fault]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2338
<b>Unit:</b> -	<b>Data Type:</b> UDINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter

Selection number	Selection name
1	Fault
2	Automatically derate
3	Warning

#### P 1.3.3 Undervoltage Protection

**Description:** Enables the undervoltage protection. The drive trips when the grid voltage is 20% below the selected voltage class level. The voltage class is defined in parameter "2.2.1.1 Unit Voltage Class".

<b>Default Value:</b> 0 [Disabled]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2344
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

The following are the selections for the parameter

Selection number	Selection name
0	Disabled
1	Enabled

#### P 1.3.9 Grid Voltage Imbalance Response

**Description:** Select the mode of grid imbalance protection.

<b>Default Value:</b> 0 [Off]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 9056
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter

Selection number	Selection name
0	Off
1	Fault or Warning
2	Automatically derate

### P 1.3.10 Grid Spike Response

**Description:** Select the response to grid voltage spike monitoring. If large spikes occur, it will protect the drive.

<b>Default Value:</b> 3 [Warning]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2342
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter

Selection number	Selection name
3	Warning
9	Fault, ramp to coast

## 6.3 Power Conversion & DC Link (Menu Index 2)

This parameter group contains parameters for configuring, monitoring, and controlling the power conversion of the drive. The group lets the user configure protection settings of the power unit and settings for the rectifier, DC link, and inverter.

### 6.3.1 Power Conversion & DC Link Status (Menu Index 2.1)

These parameters provide status readouts of power unit related information.

#### P 2.1.1 Unit Nominal Voltage

**Description:** Shows the nominal voltage setting as a result of the setting of parameter "2.2.1.1 Unit Voltage Class".

<b>Default Value:</b> 400	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 2830
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

#### P 2.1.2 Unit Nominal Current

**Description:** Shows the nominal current of the unit.

<b>Default Value:</b> 23	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 2831
<b>Unit:</b> A	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

#### P 2.1.3 DC-link Voltage

**Description:** Shows the actual DC-link voltage.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9044
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

#### P 2.1.7 DC-link Power

**Description:** Shows the actual DC-link power.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 5117
<b>Unit:</b> kW	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

#### P 2.1.10 U-phase RMS Current

**Description:** Shows the U-phase RMS current.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9020
<b>Unit:</b> A	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 2.1.11 V-phase RMS Current

**Description:** Shows the V-phase RMS current.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9021
<b>Unit:</b> A	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 2.1.12 W-phase RMS Current

**Description:** Shows the W-phase RMS current.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9022
<b>Unit:</b> A	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 2.1.14 Actual Relative Output Current Limit

**Description:** Shows the actual output current limit relative to the nominal motor current.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 300)	<b>Parameter Number:</b> 2700
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 2.1.15 Heat Sink Temperature

**Description:** Shows the temperature of the power unit heat sink.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-50 — 200)	<b>Parameter Number:</b> 2950
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

## P 2.1.16 Main Fan Speed

**Description:** Shows the speed of the main cooling fan.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 32767)	<b>Parameter Number:</b> 2931
<b>Unit:</b> rpm	<b>Data Type:</b> INT	<b>Access Type:</b> Read Only

## P 2.1.17 Internal Fan Speed

**Description:** Shows the speed of the internal cooling fan.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 32767)	<b>Parameter Number:</b> 2926
<b>Unit:</b> rpm	<b>Data Type:</b> INT	<b>Access Type:</b> Read Only

## P 2.1.19 Heat Sink Temperature Output

**Description:** Select the output indicating if the heat sink temperature is within range.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2312
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

## P 2.1.20 Drive DC-link Voltage Output

**Description:** Select the output indicating if the DC-link voltage is within range.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2311
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

### 6.3.2 Power Unit Settings (Menu Index 2.2)

These parameters allow the setting of power unit related parameters.

#### 6.3.2.1 General Settings (Menu Index 2.2.1)

##### P 2.2.1.1 Unit Voltage Class

**Description:** Select the unit voltage class to optimize the performance of the drive.

<b>Default Value:</b> 1 [Low-voltage range]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2832
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Conditional Write

The following are the selections for the parameter.

Selection number	Selection name
1	Low-voltage range
2	Mid-voltage range
3	High-voltage range

Specifies a focused voltage range within the input voltage rating of the power unit, for optimized drive control. Each power unit is rated for a wide input voltage range within which the drive can operate. This parameter is used to specify a narrow range within the wide range of input voltage, to determine optimized values for the nominal voltage and current of the power unit. Following table describes the selections available for the parameter.

Table 18: Selection Description

Selection Name	Selection Description
Low Voltage Range	Unit nominal voltage and current are configured according to the lowest voltage, of the power unit's voltage range. For example: <ul style="list-style-type: none"> <li>In 380–500 V (3N05) rated units, the range is 380–440 Vac.</li> </ul>
Medium Voltage Range	Unit nominal voltage and current are configured according to medium voltage level, of the power unit's voltage range. For example: <ul style="list-style-type: none"> <li>In 380–500 V (3N05) rated units, the range is 441–480 Vac.</li> </ul>
High Voltage Range	Unit nominal voltage and current are configured according to medium voltage level, of the power unit's voltage range. For example: <ul style="list-style-type: none"> <li>In 380–500 V (3N05) rated units, the range is 481–500 Vac.</li> </ul>

##### P 2.2.1.2 Overload Mode

**Description:** Select the overload mode.

<b>Default Value:</b> 2 [High overload (HO1)]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2833
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Conditional Write

The following are the selections for the parameter.

Selection number	Selection name
0	Automatic
1	Low overload (LO)
2	High overload (HO1)
3	High overload increased duty (HO2)

When configuring a drive, it is important to know the load characteristic and load cycle of the application so that it is possible to get the most out of the drive. The available output current depends on the application load profile. In addition, derating of the output current may be needed, for example, if operational temperature is increased, or the drive is installed in an altitude above 1000 m (3300 ft).

iC7-Automation drives support 4 different overload modes:

- Low overload (LO): 110% load for a minimum of 1 minute every 10 minutes.
- High overload (HO1): Up to 160% load for 1 minute every 10 minutes, with a breakaway torque of up to 200%.
- High Overload with increased duty (HO2): In drive parameters named as High Overload (HO2). Up to 160% load for 1 minute every 5 minutes and with a break-away torque of up to 200% in the start-up of the process.
- Automatic: In this mode, the drive automatically switches between LO and HO1 depending on the load conditions




Illustration 48: Overload Modes

Table 19: Selection Description

Selection Name	Selection Description
Automatic Mode	The selection automatically switches between the modes Low Overload (LO) and High Overload (HO1).
Low Overload Mode (LO)	<p>The selection “Low Overload (LO)” applications running at a non-varying or slowly varying load, where a limited overload capability is required. It is typically used in applications with a variable torque load. The low overload profile allows the drive to run at <b>110% load for a minimum of 1 minute every 10 minutes</b>. Typical applications where the low overload profile is used are:</p> <ul style="list-style-type: none"> <li>• Fans</li> <li>• Centrifugal pumps</li> <li>• Blowers and aerators</li> <li>• Screw compressors</li> </ul>
High Overload Mode (HO1)	<p>The selection is typical for applications which require higher short-term overload and constant torque operations. The typical applications are with continuous motion. With the high overload mode HO1, the drive can run with a load of up to 160% for 1 minute every 10 minutes, with a break-away torque of up to 200%, depending on size. Typical applications applicable for the mode:</p> <ul style="list-style-type: none"> <li>• Conveyors</li> <li>• Centrifuges</li> <li>• Decanters</li> <li>• Piston compressors</li> <li>• Piston pumps</li> <li>• Mixers</li> <li>• Stirrers</li> </ul>

Selection Name	Selection Description
	<ul style="list-style-type: none"> <li>Escalators</li> <li>Extruders (continuous running)</li> </ul>
High Overload Mode (HO2)	<p>The selection is used when the application has intermittent or continuous periodic duty. The resulting cyclic load requires more considerations on the use of the drive to ensure necessary performance and lifetime. Increased short-term starting torque is often also required. To benefit from the increased dynamic performance and not compromising lifetime, the output current is downrated by one motor size compared to HO1. With the high overload profile with increased duty, the drive can run with up to 160% load for 1 minute every 5 minutes, with a break-away torque of up to 200%, depending on the current rating. Typical applications where the high overload profile with increased duty is used are:</p> <ul style="list-style-type: none"> <li>Extruders</li> <li>Continuously accelerating conveyors</li> <li>Lifts and hoists</li> <li>Cranes</li> <li>Positioning applications</li> <li>Dosing pumps</li> </ul>

### P 2.2.1.3 Relative Output Current Limit

**Description:** Set the output current limit relative to the motor nominal current from the nameplate.

<b>Default Value:</b> 150	<b>Parameter Type:</b> Range (0 — 200)	<b>Parameter Number:</b> 1325
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

### P 2.2.1.5 Supply Mode

**Description:** Select the supply mode.

<b>Default Value:</b> 0 [AC]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1328
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	AC
1	DC

### P 2.2.1.7 HF DC-link Filter Mode

**Description:** Select the mode of the high-frequency filter in the DC link.

<b>Default Value:</b> 2 [Filter matches grid type selection]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2944
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Conditional Write

The following are the selections for the parameter.

Selection number	Selection name
0	Filter inactive
1	Filter active
2	Filter matches grid type selection

### P 2.2.1.8 Relative Power Limit Motor

**Description:** Set the power limit in motor mode in % of nominal motor power.

<b>Default Value:</b> 300	<b>Parameter Type:</b> Range (0 — 1000)	<b>Parameter Number:</b> 1814
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 2.2.1.9 Relative Power Limit Generator

**Description:** Set the power limit in generator mode in % of nominal motor power.

<b>Default Value:</b> 300	<b>Parameter Type:</b> Range (0 — 1000)	<b>Parameter Number:</b> 1815
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 2.2.1.12 Output Current Limit Scale Input

**Description:** Select the input for scaling the output current limit between 0% and 100% value as defined in the current limit. Off equals 100%.

<b>Default Value:</b> Off	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1322
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## P 2.2.1.13 Output Current Limit Response

**Description:** Select the desired response for running in current limit after the time delay set.

<b>Default Value:</b> 0 [No response]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2359
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	No response
1	Info
10	Fault

## P 2.2.1.14 Output Current Limit Delay

**Description:** Set the delay before the selected response is triggered after the drive has reached the current limit.

<b>Default Value:</b> 0.0 s	<b>Parameter Type:</b> Range (0 — 65000)	<b>Parameter Number:</b> 2360
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 2.2.1.15 Power Limit Motor Response

**Description:** Select the response for running within power limit after the time delay set.

<b>Default Value:</b> 0 [No response]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2366
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	No response
1	Info
10	Fault

## P 2.2.1.16 Power Limit Motor Delay

**Description:** Set the delay before the selected response is triggered after the drive has reached the power limit.

<b>Default Value:</b> 0 s	<b>Parameter Type:</b> Range (0 — 65000)	<b>Parameter Number:</b> 2364
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 2.2.1.17 Power Limit Generator Response

**Description:** Select the response for running within power limit after the time delay set.

<b>Default Value:</b> 0 [No response]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2367
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	No response
1	Info
10	Fault

## P 2.2.1.18 Power Limit Generator Delay

**Description:** Set the delay before the selected response is triggered after the drive has reached the power limit.

<b>Default Value:</b>	<b>Parameter Type:</b> Range (0 — 65000)	<b>Parameter Number:</b> 2365
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## 6.3.2.2 Cooling Fan Control (Menu Index 2.2.2)

## P 2.2.2.1 Main Fan Minimum Speed

**Description:** Set the minimum speed of the main cooling fan.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 2932
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 2.2.2.2 Internal Fan Minimum Speed

**Description:** Set the minimum speed of the internal cooling fan.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 2928
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 2.2.2.3 Main Fan Fail Response

**Description:** Select the drive response to a main fan fail.

<b>Default Value:</b> 3 [Warning]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2939
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
3	Warning
10	Fault

## P 2.2.2.4 Internal Fan Fail Response

**Description:** Select the drive response to an internal fan fail.

<b>Default Value:</b> 3 [Warning]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2940
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write



The following are the selections for the parameter.

Selection number	Selection name
3	Warning
10	Fault

### 6.3.3 Protection (Menu Index 2.3)

These parameters allow the setting of protections for conditions such as overvoltage, undervoltage, imbalance, ground fault, supply side power loss conditions, and overtemperature of the drive.

#### 6.3.3.1 Settings (Menu Index 2.3.1)

##### P 2.3.1.1 Retry after Fault

**Description:** Enables retry functionality (ride-through) after fault.

<b>Default Value:</b> 1 [Enabled]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2927
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Disabled
1	Enabled

Enables retry functionality (fault ride-through) after 1 of the common power conversion protections has activated. The number of retries or the retrying window depends on the power unit type and rating. The protections that can utilize retry are:

- Output current earth leakage fault
- Output overcurrent faults
- DC-link overvoltage and undervoltage faults
- Brake resistor or switching element short circuit faults

##### P 2.3.1.2 Smart Derate Mode

**Description:** Select the level of derating if the drive's nominal operational limits have been exceeded.

<b>Default Value:</b> 0 [Maximum derating]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2345
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Maximum derating
1	Minimum derating

Selects a level for the derating of the switching frequency whenever it is needed. The drive features multiple protection functions that can derate the switching frequency of the drive, to avoid operating conditions that are harmful for the drive. This parameter can be used to influence the degree of derating. Following are the descriptions of the selections for this parameter:

**Table 20: Selection Description**

Selection Name	Selection Description
Maximum Derating Mode	When switching frequency derating is applied, the drive reduces the switching frequency to the maximum. This depends on the application scenario.
Minimum Derating Mode	When switching frequency derating is applied, the drive reduces the switching frequency to the minimum. This depends on the application scenario.

## P 2.3.1.3 DC-link Voltage Ripple Response

**Description:** Select the mode of excessive DC-link voltage ripple protection.

<b>Default Value:</b> 1 [Fault]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2929
<b>Unit:</b> -	<b>Data Type:</b> UDINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Disabled
1	Fault

Selects a response for excessive DC-link voltage ripple protection. Excessive voltage ripples are detected when the peak-to-peak amplitude of the DC voltage exceeds the internal limit of the drive for a long period. Both the limit and time depend on the power unit type and rating. Following are the selection descriptions for the parameter:

**Table 21: Selection Description**

Selection Name	Selection Description
Disabled	No action is undertaken when excessive rippling is detected.
Trip	After detecting excessive ripples for a long period, the drive issues a fault and performs stop modulation.

## P 2.3.1.4 DC-link Imbalance Response

**Description:** Select a response to an imbalance across the DC-link capacitors' voltage.

<b>Default Value:</b> 10 [Fault]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2346
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
3	Warning
10	Fault

## P 2.3.1.5 Rectifier Thermal Overload Response

**Description:** Select the mode of rectifier thermal overload protection.

<b>Default Value:</b> 1 [Fault]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2340
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
1	Fault
2	Automatically derate

Select a response to the reaction of the drive for rectifier thermal overload protection. Rectifier thermal overload is detected when the drive operates for a long period at a specified rectifier current level. Specific current levels and trip times depend on the power unit type and rating. Following are the descriptions for the selections available for the parameter:

Table 22: Selection Description

Selection Name	Selection Description
Trip	The drive issues a fault and stops modulation.
Automatically derate	The drive derates the rectifier current (DC-link current) to mitigate the cause of rectifier thermal overload. When the drive exits from the overload operation window, derating is stopped.

#### P 2.3.1.6 Inverter Thermal Overload Response

**Description:** Select the mode of inverter thermal overload protection.

<b>Default Value:</b> 1 [Fault]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2341
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
1	Fault
2	Automatically derate

Select a response to the reaction of the drive for Inverter Thermal Overload protection. Inverter thermal overload is detected when the drive operates for a long period at a specified output current level. Specific current levels and trip times depend on the power unit type and rating. Following are the descriptions for the selections available for the parameter:

Table 23: Selection Description

Selection Name	Selection Description
Trip	The drive issues a fault and stops modulation.
Automatically derate	The drive derates the rectifier current (DC-link current) to mitigate the cause of rectifier thermal overload. When the drive exits from the overload operation window, derating is stopped.

#### P 2.3.1.7 Ground Fault 0 Response

**Description:** Select a response if a high-impedance ground fault occurs.

<b>Default Value:</b> 9 [Fault, ramp to coast]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2347
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	No response
9	Fault, ramp to coast

#### P 2.3.1.8 Constant Loss Controller

**Description:** Enables the constant-loss controller. The function maintains a constant temperature in the drive at low-load conditions.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 1)	<b>Parameter Number:</b> 2355
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

### 6.3.3.2 Overvoltage Protection (Menu Index 2.3.2)

#### P 2.3.2.1 Overvoltage Control

**Description:** Enables the DC-link overvoltage controller. It is recommended to disable the overvoltage controller if brake is enabled, or the unit is supplied with a regulated DC.

<b>Default Value:</b> 1 [Enabled]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1802
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Disabled
1	Enabled

Table 24: Selection Description

Selection Name	Selection Description
Disable	<p>On selecting <i>Disable</i>, the following are the consequences:</p> <ul style="list-style-type: none"> <li>The overvoltage controller does not affect motor speed in any manner.</li> <li>DC-link voltage is controlled with a brake chopper.</li> </ul> <p><b>Note:</b> DC-link overvoltage fault is usually triggered when DC-link voltage exceeds acceptable levels.</p>
Enable	When DC-link voltage level exceeds the overvoltage level, motor speed or deceleration is limited by the controller.

#### P 2.3.2.2 Overvoltage Control Kp

**Description:** Set the scaling of the overvoltage control proportional gain.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1803
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 2.3.2.3 Overvoltage Control Ti

**Description:** Set the scaling of the overvoltage control integral time.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1804
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 2.3.2.4 Overvoltage Control Td

**Description:** Set the scaling of the overvoltage control derivation time.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1805
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 2.3.2.5 Overvoltage Control Activation Level

**Description:** Set the level at which the overvoltage control is activated.

<b>Default Value:</b> 796.5	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 1816
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

### 6.3.3.3 Power Loss (Menu Index 2.3.3)

#### P 2.3.3.3 Power Loss Response

**Description:** Select the response to an insufficient supply voltage.

<b>Default Value:</b> 1 [Undervoltage control]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1818
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Conditional Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
1	Undervoltage control
2	Controlled ramp down
3	Coast

Set a selection as the reaction of the drive when the drive has insufficient supply voltage (DC-link voltage). Insufficient voltage is detected when the actual voltage falls below the undervoltage limit.

Table 25: Selection Description

Selection Name	Selection Description
None	During a power loss scenario, the drive takes no action. The undervoltage controlled is disabled.
Undervoltage control	On selection, the following occurs: <ul style="list-style-type: none"> <li>When the voltage falls below the undervoltage level, the undervoltage controller is activated.</li> <li>The controller decelerates the motor speed to regenerate energy to DC-link.</li> <li>For system module drives, select <i>Undervoltage control</i>.</li> </ul>
Controlled Ramp Down	When the voltage falls below the undervoltage level, the drive stops by ramping the motor speed to zero before stopping modulation.
Coast	When the voltage falls below the undervoltage level, the drive immediately stops modulating.

#### P 2.3.3.4 Power Recovery Response

**Description:** Select the action to take when supply voltage returns after a power loss.

<b>Default Value:</b> 0 [Ramp to reference]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1819
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Conditional Write

The following are the selections for the parameter.

Selection number	Selection name
0	Ramp to reference
1	Ramp fast to reference
2	Ramp to zero

Sets the reaction of the drive when the supply voltage (DC-link voltage) returns after a power loss event. The reaction occurs when the actual voltage returns and exceeds the undervoltage limit. Following are the selection descriptions available for this parameter:

Table 26: Selection Description

Selection Name	Selection Description
Ramp to Reference	This is the recommended selection for a system drive. The drive ramps from the actual speed to the reference.
Ramp Fast to Reference	The drive bypasses ramping and operates directly with the reference. <b>Note:</b> This selection is only available with flux motor control principle.

#### P 2.3.3.5 Undervoltage Control Kp

**Description:** Set the scaling of the undervoltage control proportional gain.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0.001 — 10000)	<b>Parameter Number:</b> 1806
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 2.3.3.6 Undervoltage Control Ti

**Description:** Set the scaling of the undervoltage control integral time.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1807
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 2.3.3.7 Undervoltage Control Td

**Description:** Set the scaling of the undervoltage control derivation time.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1808
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 2.3.3.8 Undervoltage Control Activation Level

**Description:** Set the level at which undervoltage control is activated.

<b>Default Value:</b> 425.5 V	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 1817
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 2.3.3.12 Deceleration Time Power Loss

**Description:** Set the deceleration time from nominal speed to 0 when in power-loss mode.

<b>Default Value:</b> 0.5	<b>Parameter Type:</b> Range (0.02 — 10000)	<b>Parameter Number:</b> 1139
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## 6.3.4 Modulation (Menu Index 2.4)

## P 2.4.1 Max. Switching Frequency

**Description:** Set the maximum switching frequency.

<b>Default Value:</b> 16.00	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 2924
<b>Unit:</b> kHz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 2.4.2 Min. Switching Frequency

**Description:** Set the minimum switching frequency.

<b>Default Value:</b> 1.00	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 2925
<b>Unit:</b> kHz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 2.4.3 Switching Frequency

**Description:** Set the switching frequency.

<b>Default Value:</b> 1.00	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 2920
<b>Unit:</b> kHz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 2.4.4 Control Frequency Request

**Description:** Set the requested control frequency. A constant control frequency is enabled by setting this value. If set to 0.0, constant control frequency is disabled.

<b>Default Value:</b> 0.00	<b>Parameter Type:</b> Range (0.00 — 16.00)	<b>Parameter Number:</b> 2921
<b>Unit:</b> kHz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write

## P 2.4.6 Overmodulation

**Description:** Enables the modulation index to exceed 1.0.

<b>Default Value:</b> 1 [Enabled]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 5094
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Disabled
1	Enabled

## 6.4 Filters & Brake Chopper (Menu Index 3)

This parameter group contains parameters for configuring, monitoring, and controlling the input filters, output filters, brake chopper, and brake resistors.

### 6.4.1 Filters & Brake Chopper Status (Menu Index 3.1)

#### P 3.1.1 Brake Power

**Description:** Shows the power dissipated in the brake resistor.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0.00 — \*)	<b>Parameter Number:</b> 2933
<b>Unit:</b> kW	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

#### P 3.1.2 Average Brake Power

**Description:** Shows the average power dissipated in the brake resistor, calculated over 120 s.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0.00 — \*)	<b>Parameter Number:</b> 2934
<b>Unit:</b> kW	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

#### P 3.1.3 AHF Capacitor Connected

**Description:** Shows if the advanced harmonic filter (AHF) capacitor is connected.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 1)	<b>Parameter Number:</b> 5410
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read Only

## 6.4.2 Brake Chopper (Menu Index 3.2)

### P 3.2.1 Brake Chopper

**Description:** Select the brake chopper operation mode.

<b>Default Value:</b> 0 [Disabled]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2935
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Disabled
1	Enabled in Run and Coast
2	Enabled in run only

To use the brake resistor, either 1 [Enabled in run and coast] or 2 [Enabled in run only] must be selected.

#### P 3.2.2 Brake Chopper Voltage Reduce

**Description:** Set the activation level of the brake chopper. If set to 0, the brake chopper is active if the voltage exceeds the overvoltage control activation level. The value set is subtracted from the overvoltage control activation level, lowering the brake chopper activation level, respectively.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 50)	<b>Parameter Number:</b> 2938
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

The brake on/off levels are reduced by the value of this parameter. For example, if the normal levels are 705/685 V, then setting this parameter to 50 V would make them 655/635 V.

A configuration change for the parameter is only needed in rare cases when the brake has to be activated at a lower DC-link voltage level.

### 6.4.3 Brake Resistor (Menu Index 3.3)

#### P 3.3.1 Brake Resistor Test

**Description:** Enables the brake resistor test. The drive conducts a test of brake resistor presence while the drive is coasted. Starting of the drive is prohibited until the test is completed.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 430
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Conditional Write

The following are the selections for the parameter.

Selection number	Selection name
0	Off
1	Enable brake chopper test run

By setting the parameter to 1 [*Enable brake chopper test run*], the function issues a test pulse, to check if the drive registers a connection to the brake resistor. If no brake resistor is detected during the test, a fault message is triggered

#### P 3.3.2 Brake Resistor Resistance

**Description:** Set the resistance value of the brake resistor.

<b>Default Value:</b> 5	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 2936
<b>Unit:</b> Ω	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write

#### P 3.3.3 Brake Resistor Power Limit

**Description:** Set the power limit for resistor braking.

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 2937
<b>Unit:</b> kW	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

The parameter must be configured to set the expected average power dissipated in the brake resistor over a period of 120 s. To calculate the brake resistor power limit, use the following formula .

$$P_{br, avg} (W) = \frac{U_{br}^2 (V) \times t_{br} (s)}{R_{br} (\Omega) \times T_{br} (s)}$$

In the formula, following are the elements used:

- $P_{br, avg}$  is the average power dissipated in the brake resistor.
- $R_{br}$  is the resistance of the brake resistor.
- $t_{br}$  is the active braking time within 120 s ( $T_{br}$ ).



- $U_{br}$  is the DC-link when the brake chopper is active. The correct value depends on the selection of *parameter 2.2.1 Unit Voltage Class* using the following table.

• **Table 27: Power rating and voltage class setting**

Voltage Range	Unit Voltage Class 380-500 Vac (3N05)
Low Voltage Range	705
Medium Voltage Range	770
High Voltage Range (low brake level)	780
High Voltage Range (high brake level)	800

## 6.4.4 Advanced Harmonic Filter (Menu Index 3.4)

### P 3.4.1 Advanced Harmonic Filter

**Description:** Select if the Advanced Harmonic Filter is connected to the drive.

<b>Default Value:</b> 0 [Disabled]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 3410
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Disabled
1	Enabled

### P 3.4.2 Capacitor Disconnect Output

**Description:** Select the output terminal for disconnecting the capacitor.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 3412
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

### P 3.4.3 Thermal Switch Function

**Description:** Select which function to activate if the thermal input indicates a too high temperature.

<b>Default Value:</b> 1 [Fault, ramp down to stop]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 3413
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
1	Fault, ramp down to stop
2	Derate

### P 3.4.4 Thermal Switch Input

**Description:** Select the digital input terminal for the thermal switch.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 3414
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

### P 3.4.5 Power Stabilizer Gain

**Description:** Set the controller gain for power stabilization. The power stabilizer dampens possible resonance with the grid. If set to -1 the value is selected automatically, if set to 0, the controller is disabled.

<b>Default Value:</b> -1	<b>Parameter Type:</b> Range (-1 — 500)	<b>Parameter Number:</b> 3415
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

### P 3.4.6 Power Stabilizer Bandwidth

**Description:** Set the controller bandwidth for power stabilization.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (1 — 10000)	<b>Parameter Number:</b> 3416
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## 6.4.5 Output Filter (Menu Index 3.5)

These parameters allow the setting of output filter operation and related settings.

### P 3.5.1 Output Filter Type

**Description:** Select the output filter type.

<b>Default Value:</b> 0 [None]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 5501
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Conditional Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
1	Sine-wave Filter

### P 3.5.2 Filter Capacitance

**Description:** Set the capacitance of the output filter.

<b>Default Value:</b> 0.00	<b>Parameter Type:</b> Range (0.00 — 1000000.00)	<b>Parameter Number:</b> 5502
<b>Unit:</b> $\mu$ F	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write

Set the  $C_y$  (capacitance) value of the output filter. See the filter product label for the capacitance value. The value is the equivalent star-connected capacitance of the filter. When the filters are installed in parallel, enter the combined capacitance value of the paralleled filter. The value is the equivalent star-connected capacitance ( $C_y$ ) of the filter multiplied by the number of installed paralleled filters.

### P 3.5.3 Filter Inductance

**Description:** Set the inductance of the output filter.

<b>Default Value:</b> 0.00	<b>Parameter Type:</b> Range (0.00 — 1000.00)	<b>Parameter Number:</b> 5503
<b>Unit:</b> mH	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write

Set the inductance of the output filter. See the product label of the filter for the value of inductance. When filters are installed in parallel, enter the combined inductance value of the installed paralleled filters. The inductance value in the parameter is the inductance value of the filter divided by the number of paralleled filters.

## 6.5 Motor (Menu Index 4)

This parameter group contains parameters for configuring the motor, motor control, and motor protection.

### 6.5.1 Motor Status (Menu Index 4.1)

These parameters provide status readouts of motor related information.

#### P 4.1.1 Motor Current

**Description:** Shows the actual motor current.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9000
<b>Unit:</b> A	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 4.1.2 Relative Motor Current

**Description:** Shows the actual motor current in % of the nominal motor current.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 200)	<b>Parameter Number:</b> 9001
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 4.1.3 U-phase RMS Current

**Description:** Shows the U-phase RMS current.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9020
<b>Unit:</b> A	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 4.1.4 V-phase RMS Current

**Description:** Shows the V-phase RMS current.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9021
<b>Unit:</b> A	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 4.1.5 W-phase RMS Current

**Description:** Shows the W-phase RMS current.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9022
<b>Unit:</b> A	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 4.1.6 Motor Voltage

**Description:** Shows the actual motor voltage.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9005
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 4.1.7 Relative Motor Voltage

**Description:** Shows the actual motor voltage in % of the nominal motor voltage.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 200)	<b>Parameter Number:</b> 9006
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 4.1.11 Motor Torque

**Description:** Shows the actual motor torque.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-10000000 — 10000000)	<b>Parameter Number:</b> 9009
<b>Unit:</b> Nm	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Depending on whether metric or imperial units are in use, give the value for the parameter in either newton meters (Nm) or pound-feet (lb ft). The value range is different with the different units.

## P 4.1.12 Relative Motor Torque

**Description:** Shows the motor torque in % of the nominal motor torque.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 1708
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 4.1.13 Motor Shaft Power

**Description:** Shows the actual power at the motor shaft.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 9008
<b>Unit:</b> kW	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Depending on whether metric or imperial units are in use, give the value for the parameter in either kilowatt (kW) or horsepower (HP). The value range is different with the different units.

#### P 4.1.14 Relative Motor Shaft Power

**Description:** Shows the actual motor shaft power in % of the nominal motor shaft power.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 1707
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

#### P 4.1.15 Motor Electrical Power

**Description:** Shows the actual motor power.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 9043
<b>Unit:</b> kW	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

#### P 4.1.16 Motor Thermal Load (ETR)

**Description:** Shows the estimated thermal load of the motor calculated by the ETR function.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 2951
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

#### P 4.1.17 Motor Current Output

**Description:** Select an output for the motor current signal. The scale of the signal is 0–100% of the nominal current.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2302
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

#### P 4.1.18 Motor Voltage Output

**Description:** Select an output for the motor voltage signal. The scale of the signal is 0–100% of the nominal voltage.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2303
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

#### P 4.1.19 Absolute Motor Torque Output

**Description:** Select an output for the motor torque signal. The scale of the signal is 0–100% of the absolute value of the nominal torque.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2306
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

#### P 4.1.20 Extended Motor Torque Output

**Description:** Select an output for the motor torque signal. The scale of the signal is -200...200% of the nominal torque.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2310
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

#### P 4.1.21 Absolute Motor Speed Output

**Description:** Select an output for the motor speed signal. The scale of the signal is 0–100% of the absolute value of the nominal speed.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2301
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

#### P 4.1.22 Extended Motor Speed Output

**Description:** Select an output for the motor speed signal. The scale of the signal is -200...200% of the nominal speed.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2309
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

#### P 4.1.23 Motor Power Output

**Description:** Select an output for the motor power signal. The scale of the signal is 0–100% of the nominal power.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2305
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

#### P 4.1.24 AMA Progress

**Description:** Shows the progress of the Automatic Motor Adaptation (AMA).

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 429
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## 6.5.2 Motor Data (Menu Index 4.2)

These parameters allow the setting of motor related parameters, including detailed settings of induction and permanent magnet motors.

### 6.5.2.1 General Settings (Menu Index 4.2.1)

These parameters allow the setting of basic motor settings like motor type, number of pole pairs and Automatic Motor Adaptation (AMA).

#### P 4.2.1.1 Motor Type

**Description:** Select the motor type.

<b>Default Value:</b> 0 [Induction Motor]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 407
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Conditional Write

The following are the selections for the parameter.

Selection number	Selection name
0	Induction Motor
1	Permanent Magnet Motor

#### P 4.2.1.2 Number of Pole Pairs

**Description:** Set the number of pole pairs. For example, a 4-pole motor is set as 2 pole pairs.

<b>Default Value:</b> 2	<b>Parameter Type:</b> Range (0 — 65535)	<b>Parameter Number:</b> 406
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Conditional Write

**Description:** Motor pole pair number

<b>Default Value:</b> 2	<b>Parameter Type:</b> Range (0 - 65535)	<b>Parameter Number:</b> 406
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Conditional Write

The synchronous speed of a motor can be calculated when the supply frequency and number of pole pairs are known. The formula to calculate the synchronous speed of the motor ( $n_s$ ) with supply frequency ( $f$ ) and number of pole pairs ( $p$ ) is as follows:

$$n_s = \frac{60 \cdot f}{p} \text{ [RPM]}$$




Illustration 49: Two Inductors in 1 Phase Connected in Series to A) 2 Poles B) 4 Poles

While the frequency is determined by the grid or the AC drive, the number of poles is determined by the way the stator inductors are connected. Pole pairs ( $p$ ) or pole number and synchronous motor speed lists the number of poles corresponding to synchronous speed ( $n_0$ ) at 50 and 60 Hz supply.

Table 28: Number of Pole Pairs ( $p$ ) and Nominal Speed ( $\sim nn$ ) for Motors @ 50 Hz and 60 Hz

Number of pole pairs ( $p$ )	$\sim nn$ @ 50 Hz	$\sim nn$ @ 60 Hz
1	2700–2880	3250–3460
2	1350–1450	1625–1730
3	700–960	840–1153

Table 29: Pole Pairs ( $p$ ) or Pole Number and Synchronous Motor Speed

Number of pole pairs ( $p$ )	1	2	3	4	6
Number of poles	2	4	6	8	12
50 Hz supply	3000	1500	1000	750	500
60 Hz supply	3600	1800	1200	900	600

The dependency of the motor’s synchronous speed  $n_s$  in rpm of the frequency  $f$  of the power supply in Hz (*parameter 1.1.1 Grid Frequency*) and the number of pole pairs in *parameter 4.2.1.2 Number of Pole Pairs* is provided by the following formula above.

For example, for a motor with 2 pole pairs (4 poles) and a frequency of the power supply of 50 Hz the synchronous speed of the motor.

$$n_s = \frac{60 \cdot f}{p} \text{ [RPM]} = 1500 \text{ RPM}$$

P 4.2.1.3 AMA Mode

**Description:** Select the Automatic Motor Adaptation (AMA) mode.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 420
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Conditional Write

The following are the selections for the parameter.

Selection number	Selection name
0	Off
3	Motor Data
4	Reduced Motor Data (Rs)

The Automatic Motor Adaptation (AMA) is an automated test procedure providing an optimization of the motor parameters for improved shaft performance. The measurement is performed based on the motor name plate data in *parameter group 4.2.2*. The motor-type-specific parameters in *parameter group Asyn. Induction Motor (Menu Index 4.2.3)* or *parameter group Permanent Magnet Motor (Menu Index 4.2.4)* are recalculated and used to fine-tune the motor control algorithm. Running the AMA procedure also maximizes the automatic energy optimization (AEO) feature of the drive. The AMA also allows the automatic detection of the motor type based on the name plate data.

- The AMA must be run on a cold motor. Note that also running the AMA multiple times will also increase the motor temperature.
- The AMA needs to be conducted with the motor at standstill.
- Avoid generating external torque during AMA.
- The AMA cannot run with a sine-wave filter connected.
- Uncoupling the load from the motor isn't needed.
- The duration of the AMA depends on the power rating of the motor.
- Changing the name plate data in parameter group 4.2.2 will also modify the data in the parameter group *Asyn. Induction Motor (Menu Index 4.2.3)* or in *Permanent Magnet Motor (Menu Index 4.2.4)*.

## NOTICE

The parameter automatically switches back to Off after the AMA has been performed.

### P 4.2.1.5 Motor Cable Length

**Description:** Set the motor cable length.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 425
<b>Unit:</b> m	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write

In some products, depending on the EMC configuration, this parameter may adjust the allowable switching frequency automatically to achieve optimum performance of the drive system.

Depending on whether metric or imperial units are in use, give the value for the parameter in either meters (m) or feet (ft). The value range is different with the different units.

### 6.5.2.2 Motor Nameplate Data (Menu Index 4.2.2)

These parameters allow the setting of motor nameplate data.

In many cases, permanent magnet motors have torque but not power given on the motor nameplate. For those, set the speed and torque nameplate settings, then the system calculates the power value. The system also calculates the torque value for asynchronous motors, when the power and speed values are set.

When a higher priority parameter is set, the lower priority parameter's value is calculated by the system. The parameters have the following priority order:

1. Nominal Power
2. Nominal Speed
3. Nominal Torque

To calculate the nominal torque of the motor, first set nominal power and then nominal speed.

To calculate nominal power of the motor, first set nominal speed and then nominal torque.

#### P 4.2.2.1 Nominal Power

**Description:** Set the nominal motor shaft power.

<b>Default Value:</b> 5.50	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 405
<b>Unit:</b> kW	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write

## P 4.2.2.2 Nominal Current

**Description:** Set the nominal motor current.

<b>Default Value:</b> 11.5	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 400
<b>Unit:</b> A	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write

## P 4.2.2.3 Nominal Speed

**Description:** Set the nominal motor shaft speed.

<b>Default Value:</b> 1450	<b>Parameter Type:</b> Range (0 — 100000)	<b>Parameter Number:</b> 402
<b>Unit:</b> rpm	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write

## P 4.2.2.4 Nominal Frequency

**Description:** Set the nominal motor frequency.

<b>Default Value:</b> 50	<b>Parameter Type:</b> Range (0 — 2000)	<b>Parameter Number:</b> 403
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write

## P 4.2.2.5 Nominal Voltage

**Description:** Set the nominal motor voltage.

<b>Default Value:</b> 400	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 401
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write

## P 4.2.2.6 Nominal Torque

**Description:** Set the nominal torque from the nameplate of the motor.

<b>Default Value:</b> 52521.13	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 9951
<b>Unit:</b> Nm	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write

## 6.5.2.3 Induction Motor (Menu Index 4.2.3)

These parameters allow the setting of dedicated parameters for induction motors.

## P 4.2.3.1 Stator Resistance Rs

**Description:** Set the motor stator resistance. Overwritten by AMA.

<b>Default Value:</b> 1.21	<b>Parameter Type:</b> Range (0 — 1000000)	<b>Parameter Number:</b> 408
<b>Unit:</b> Ω	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write

## P 4.2.3.2 Rotor Resistance Rr

**Description:** Set the motor rotor resistance. Overwritten by AMA.

<b>Default Value:</b> 0.79	<b>Parameter Type:</b> Range (0 — 1000000)	<b>Parameter Number:</b> 409
<b>Unit:</b> Ω	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write

Use any of the following methods for setting Rr:

- Run an AMA on a cold motor. The drive measures the value from the motor. All compensations are reset to 100%.
- Enter the Rr value manually. Obtain the value from the motor supplier.
- Use the Rr default setting. The drive establishes the setting based on the motor nameplate data.

## P 4.2.3.3 Iron Loss Resistance Rfe

**Description:** Set the motor iron-loss equivalent resistance.

<b>Default Value:</b> 874	<b>Parameter Type:</b> Range (0 — 11000000000)	<b>Parameter Number:</b> 413
<b>Unit:</b> Ω	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write



The RFe value cannot be found by performing an AMA. The RFe value is especially important in torque control applications. If RFe is unknown, make sure to keep the default setting of the parameter.

#### P 4.2.3.4 Stator Leakage Reactance Xls

**Description:** Set the motor stator leakage reactance. Overwritten by AMA.

<b>Default Value:</b> 0.03	<b>Parameter Type:</b> Range (0.00 — 62.83)	<b>Parameter Number:</b> 440
<b>Unit:</b> Ω	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write

Use any of the following methods for setting Xls:

- Run an AMA on a cold motor. The drive measures the value from the motor.
- Enter the Xls value manually. Obtain the value from the motor supplier.
- Use the Xls default setting. The drive establishes the setting based on the motor nameplate data.

#### P 4.2.3.5 Rotor Leakage Reactance Xlr

**Description:** Set the motor rotor leakage reactance. Overwritten by AMA.

<b>Default Value:</b> 0.03	<b>Parameter Type:</b> Range (0.00 — 62.83)	<b>Parameter Number:</b> 441
<b>Unit:</b> Ω	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write

Use any of the following methods to set Xlr:

- Run an AMA on a cold motor. The drive measures the value from the motor.
- Enter the Xlr value manually. Obtain the value from the motor supplier.
- Use the Xlr default setting. The drive establishes the setting based on the motor nameplate data.

#### P 4.2.3.6 Magnetizing Reactance Xm

**Description:** Set the motor magnetizing reactance. Overwritten by AMA.

<b>Default Value:</b> 0.94	<b>Parameter Type:</b> Range (0.00 — 62.83)	<b>Parameter Number:</b> 442
<b>Unit:</b> Ω	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write

### 6.5.2.4 Permanent Magnet Motor (Menu Index 4.2.4)

These parameters allow the setting of dedicated parameters for permanent magnet motors.

#### P 4.2.4.1 Back EMF

**Description:** Set the stator nominal induced voltage (back-EMF voltage) when running at 1000 RPM (line-to-line RMS). Overwritten by AMA.

<b>Default Value:</b> 190	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 415
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write

#### P 4.2.4.2 Stator Resistance Rs

**Description:** Set the motor stator resistance. Overwritten by AMA.

<b>Default Value:</b> 1.21	<b>Parameter Type:</b> Range (0 — 1000000)	<b>Parameter Number:</b> 408
<b>Unit:</b> Ω	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write

#### P 4.2.4.3 d-axis Inductance Ld

**Description:** Set the motor non-saturated d-axis inductance. Overwritten by AMA.

<b>Default Value:</b> 23.00	<b>Parameter Type:</b> Range (0.00 — 1000.00)	<b>Parameter Number:</b> 417
<b>Unit:</b> mH	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write

#### P 4.2.4.4 d-axis Inductance LdSat

**Description:** Set the motor saturated d-axis inductance. Overwritten by AMA.

<b>Default Value:</b> 23.00	<b>Parameter Type:</b> Range (0.00 — 1000.00)	<b>Parameter Number:</b> 418
<b>Unit:</b> mH	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write

## P 4.2.4.5 Ld Saturation Point

**Description:** Set the point (in % of nominal motor current) at which the Ld inductance saturates (average of non-saturated and saturated). Overwritten by AMA.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0 — 300)	<b>Parameter Number:</b> 426
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write

## P 4.2.4.6 q-axis Inductance Lq

**Description:** Set the motor non-saturated q-axis inductance. Overwritten by AMA.

<b>Default Value:</b> 85.00	<b>Parameter Type:</b> Range (0.00 — 1000.00)	<b>Parameter Number:</b> 427
<b>Unit:</b> mH	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write

## P 4.2.4.7 q-axis Inductance LqSat

**Description:** Set the motor saturated q-axis inductance. Overwritten by AMA.

<b>Default Value:</b> 85.00	<b>Parameter Type:</b> Range (0.00 — 1000.00)	<b>Parameter Number:</b> 422
<b>Unit:</b> mH	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write

## P 4.2.4.8 Lq Saturation Point

**Description:** Set the point (in % of nominal motor current) at which the Lq inductance saturates (average of non-saturated and saturated). Overwritten by AMA.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0 — 300)	<b>Parameter Number:</b> 424
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Conditional Write

## 6.5.3 Motor Control (Menu Index 4.3)

## 6.5.3.1 General Settings (Menu Index 4.3.1)

## P 4.3.1.1 Motor Control Principle

**Description:** Select the motor control principle.

<b>Default Value:</b> 1 [VVC+ Control]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2503
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Conditional Write

The following are the selections for the parameter

Selection number	Selection name
0	U/f Control
1	VVC+ Control
2	FVC+ Control

## P 4.3.1.2 Breakaway Current Boost

**Description:** Enables the breakaway current boost, which temporarily allows a higher starting current.

<b>Default Value:</b> 0 [Disabled]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2930
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

The following are the selections for the parameter

Selection number	Selection name
0	Disabled
1	Enabled

### 6.5.3.2 U/f Settings (Menu Index 4.3.2)

#### U/f Settings Overview

The parameters are used to set the U/f motor control curve manually. Make sure that the *parameter Motor Control Principle* is set to U/f.




Illustration 50: U/f Settings

#### P 4.3.2.1 Voltage Point 0

**Description:** Set the U/f curve voltage point 0.

<b>Default Value:</b> 8	<b>Parameter Type:</b> Range (0 — 1000 V)	<b>Parameter Number:</b> 2600
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 4.3.2.2 Voltage Point 1

**Description:** Set the U/f curve voltage point 1.

<b>Default Value:</b> 80	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 2601
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 4.3.2.3 Voltage Point 2

**Description:** Set the U/f curve voltage point 2.

<b>Default Value:</b> 160	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 2602
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 4.3.2.4 Voltage Point 3

**Description:** Set the U/f curve voltage point 3.

<b>Default Value:</b> 240	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 2603
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 4.3.2.5 Voltage Point 4

**Description:** Set the U/f curve voltage point 4.

<b>Default Value:</b> 320	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 2604
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 4.3.2.6 Voltage Point 5

**Description:** Set the U/f curve voltage point 5.

<b>Default Value:</b> 400	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 2605
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 4.3.2.7 Frequency Point 0

**Description:** Set the U/f curve frequency point 0.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 2000)	<b>Parameter Number:</b> 2610
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 4.3.2.8 Frequency Point 1

**Description:** Set the U/f curve frequency point 1.

<b>Default Value:</b> 10	<b>Parameter Type:</b> Range (0 — 2000)	<b>Parameter Number:</b> 2611
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 4.3.2.9 Frequency Point 2

**Description:** Set the U/f curve frequency point 2.

<b>Default Value:</b> 20	<b>Parameter Type:</b> Range (0 — 2000)	<b>Parameter Number:</b> 2612
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 4.3.2.10 Frequency Point 3

**Description:** Set the U/f curve frequency point 3.

<b>Default Value:</b> 30	<b>Parameter Type:</b> Range (0 — 2000)	<b>Parameter Number:</b> 2613
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 4.3.2.11 Frequency Point 4

**Description:** Set the U/f curve frequency point 4.

<b>Default Value:</b> 40	<b>Parameter Type:</b> Range (0 — 2000)	<b>Parameter Number:</b> 2614
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 4.3.2.12 Frequency Point 5

**Description:** Set the U/f curve frequency point 5.

<b>Default Value:</b> 50	<b>Parameter Type:</b> Range (0 — 2000)	<b>Parameter Number:</b> 2615
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## 6.5.3.3 FVC+ Settings (Menu Index 4.3.3)

## P 4.3.3.1 Continuous Rs Estimation

**Description:** Enables Rs estimation while running, to compensate for changing operating conditions.

<b>Default Value:</b> 1 [Enabled]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 428
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Disabled
1	Enabled

## P 4.3.3.2 Current Controller Kp

**Description:** Set the scaling of the current controller nominal proportional gain.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0 — 100000)	<b>Parameter Number:</b> 8021
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 4.3.3.3 Current Controller Ti

**Description:** Set the scaling of the current controller nominal integral time.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0.1 — 100000)	<b>Parameter Number:</b> 8022
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 4.3.3.5 Low-speed Mode

**Description:** Select the motor control mode used at low speeds.

<b>Default Value:</b> 0 [Selected motor control]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2816
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Selected motor control
1	Forced current mode (I/f Control)
2	HF injection
3	Low speed minimum current (only in FVC SM)
4	Saliency Tracking

## P 4.3.3.6 I/f Control Current Reference

**Description:** Set the I/f control current reference in % of nominal motor current.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0 — 500)	<b>Parameter Number:</b> 2817
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 4.3.3.7 I/f Control Speed Threshold

**Description:** Set the speed below which the I/f control is used.

<b>Default Value:</b> 10	<b>Parameter Type:</b> Range (1 — \*)	<b>Parameter Number:</b> 2818
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 4.3.3.8 Low Speed Minimum Current

**Description:** Set the low-speed minimum current reference in % of nominal motor current.

<b>Default Value:</b> 50	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 2837
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 4.3.3.9 Minimum Current Speed Threshold

**Description:** Set the speed below which the minimum current control is used.

<b>Default Value:</b> 10	<b>Parameter Type:</b> Range (1 — \*)	<b>Parameter Number:</b> 2838
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 4.3.3.10 Motor Feedback Mode

**Description:** Select the feedback mode.

<b>Default Value:</b> 0 [Open loop]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2502
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Open loop
1	Closed loop

#### P 4.3.3.11 Relative HF Injection Voltage Gain

**Description:** Set the voltage gain for HF injection relative to the recommended voltage.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (5 — 2000)	<b>Parameter Number:</b> 2821
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 4.3.3.12 Relative HF Inject Bandwidth

**Description:** Set the bandwidth for HF injection relative to the recommended bandwidth.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (1 — 1000)	<b>Parameter Number:</b> 2826
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 4.3.3.13 HF Injection Angle Comp. Gain

**Description:** Set the HF injection angle error compensation gain in degrees per nominal load torque.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (-35 — 35)	<b>Parameter Number:</b> 2822
<b>Unit:</b> °	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 4.3.3.14 HF Injection Angle Comp. Offset

**Description:** Set the HF injection angle error compensation offset in degrees.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (-25 — 25)	<b>Parameter Number:</b> 2824
<b>Unit:</b> °	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 4.3.3.15 HF Injection Frequency

**Description:** Set the HF injection frequency. Setting 0 is equal to automatic setting of injection frequency.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 2823
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 4.3.3.16 Id/Iq Reference Ratio

**Description:** Set the synchronous motor Id/Iq current reference ratio in %. It is used instead of the default MTPA, if it is set to be different from 0.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (-100 — 100)	<b>Parameter Number:</b> 1219
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 4.3.3.17 Maximum Motor Voltage

**Description:** Set the maximum output voltage applied to the motor. This can be used to avoid a field-weakening operation when running at speeds above the nominal motor speed, when the drive is supplied with a voltage higher than the nominal motor voltage.

<b>Default Value:</b> 400	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 5433
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

P 4.3.3.18 Encoder Slip Adjustment

**Description:** Enables the encoder slip correction function for permanent magnet motors in closed loop FVC+ control.

<b>Default Value:</b> 0 [Disabled]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 4602
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Disabled
1	Enabled

P 4.3.3.19 Torque Estimation Bandwidth

**Description:** Scaling factor for torque estimation correction bandwidth. 100% = default tuning, 0% = disable.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0 — 1000)	<b>Parameter Number:</b> 4612
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

6.5.3.4 VVC+ & U/f Settings (Menu Index 4.3.4)

P 4.3.4.1 Slip Compensation

**Description:** Set the slip compensation in % of the nominal motor slip.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0 — 1000)	<b>Parameter Number:</b> 2804
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

P 4.3.4.2 Slip Compensation Tc

**Description:** Set the slip compensation time constant.

<b>Default Value:</b> 50	<b>Parameter Type:</b> Range (0 — 100000)	<b>Parameter Number:</b> 2805
<b>Unit:</b> ms	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

P 4.3.4.3 High-speed Load Comp.

**Description:** Set the high-speed load compensation in % of the motor voltage drop.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0 — 1000)	<b>Parameter Number:</b> 2803
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

The parameters 4.4.5.3 *High-speed Load Comp.* and 4.4.5.4 *Low Speed Load Comp.* are setting the % value to compensate voltage in relation to load when the motor is running at high/low speed and obtain the optimum U/f characteristic. The motor size determines the frequency range within which the parameters are active, as shown in the illustration.




Illustration 51: Changeover from Low Speed Load Comp. to High Speed Load Comp

## P 4.3.4.4 Low Speed Load Comp.

**Description:** Low Speed Load Compensation (%)

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0 — 1000)	<b>Parameter Number:</b> 2802
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 4.3.4.5 Res. Damp Gain

**Description:** Resonance Damping Gain (%)

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0 — 50000)	<b>Parameter Number:</b> 2806
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 4.3.4.6 Res. Damp High Pass Tc

**Description:** Resonance damping high pass time constant.

<b>Default Value:</b> 50	<b>Parameter Type:</b> Range (0 — 100000)	<b>Parameter Number:</b> 2807
<b>Unit:</b> ms	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 4.3.4.7 Res. Damp Low Pass Tc

**Description:** Resonance Damping Low Pass Time Constant

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (0 — 100000)	<b>Parameter Number:</b> 2808
<b>Unit:</b> ms	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 4.3.4.9 Res. Damp High Pass Tc (SM)

**Description:** Sets time constant of resonance damping for VVC+ control of synchronous motors (SM).

<b>Default Value:</b> 0.06	<b>Parameter Type:</b> Range (0 — 1)	<b>Parameter Number:</b> 2819
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 4.3.4.10 Motor Model Tc (SM)

**Description:** Sets time constant of the internal model used for VVC+ control of synchronous motors (SM). A lower value improves the dynamic control performance. A higher value improves the noise rejection.

<b>Default Value:</b> 0.25	<b>Parameter Type:</b> Range (0 — 1)	<b>Parameter Number:</b> 2820
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## 6.5.4 Protection (Menu Index 4.5)

## P 4.5.1 Missing Phase Start-up Detection

**Description:** Enables detection of missing motor phase at start-up.

<b>Default Value:</b> 0 [Disabled]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 6070
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Disabled
1	Enabled

## P 4.5.2 Missing Motor Phase Response

**Description:** Select the response to a missing motor phase.

<b>Default Value:</b> 1 [Fault]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2348
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write



The following are the selections for the parameter.

Selection number	Selection name
0	No response
2	Warning
1	Fault

#### P 4.5.3 Disconnected Motor Response

**Description:** Select the response to a disconnected motor.

<b>Default Value:</b> 0 [No response]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2349
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	No response
2	Warning
1	Fault
3	Motor Check

#### P 4.5.4 ETR Overtemperature Response

**Description:** Select the response to motor overtemperature indicated by the electronic thermal relay (ETR).

<b>Default Value:</b> 0 [No response]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2825
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	No response
1	Info
3	Warning
9	Fault, ramp to coast
10	Fault

## 6.6 Application (Menu Index 5)

This parameter group contains parameters for application specific features such as process control, speed control, torque control, mechanical brake control and many more.

### 6.6.1 Application Status (Menu Index 5.1)

#### P 5.1.1 Motor Ctrl. Status Word

**Description:** Shows the motor control status word.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 65535)	<b>Parameter Number:</b> 1714
<b>Unit:</b> -	<b>Data Type:</b> WORD	<b>Access Type:</b> Read Only

The following are the bit descriptions.

Bit	Description
0	Ready
1	Run
2	Reverse
3	Fault
4	Reserved
5	At reference
6	Zero speed
7	Protection mode active

### P 5.1.2 Motor Ctrl. Ready Status Word

**Description:** Shows the motor control ready status word. All status bits must be true before the drive is ready.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 65535)	<b>Parameter Number:</b> 1716
<b>Unit:</b> -	<b>Data Type:</b> WORD	<b>Access Type:</b> Read Only

The *5302 Start Blocked* event is shown if this word is not ready.

The following are the bit descriptions.

Bit	Description
0	Run Enable high.
1	No fault active.
2	DC-link precharging done.
3	DC Voltage within limits.
4	Power manager initialized.
5	Brake test not running.
6	System software is not blocking start.
7	Grid voltage within limits.
8	Temperature within limits.
9	Valid motor data.
10	Valid control configuration.

### P 5.1.3 Motor Regulator Status Word

**Description:** Shows the current state of the motor regulator status word. The status word indicates if a limit controller is active.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 65535)	<b>Parameter Number:</b> 1715
<b>Unit:</b> -	<b>Data Type:</b> WORD	<b>Access Type:</b> Read Only

The following are the bit descriptions.

Bit	Description
0	Current limit control active (motoring side).
1	Current limit control active (generator side).
2	Torque limit control active (motoring side).
3	Torque limit control active (generator side).
4	Overvoltage control active.
5	Undervoltage control active.
6	Power limit control active (motoring side).
7	Power limit control active (generator side).
8	Speed limit control active.
9	AC-brake control active.

## P 5.1.5 Fault Status Word 1

**Description:** Shows the fault status word 1.

<b>Default Value:</b> -	<b>Parameter Type:</b>	<b>Parameter Number:</b> 6203
<b>Unit:</b>	<b>Data Type:</b> DWORD	<b>Access Type:</b> -

The following are the bit descriptions.

Bit	Description	Event number
0	Overcurrent	4384, 4373, 5170, 4368, 4369, 4375, 4377, 4380, 4097
1	Overvoltage	4164, 4162, 4144 4145
2	Undervoltage	4165, 4146
3	Unit temperature high	4117, 4118, 4119
4	Unit temperature low	4116
5	Control board overtemperature	4121, 4122, 4123, 4120
6	Input phase	4160, 4163
7	Output phase	4175, 4176
8	Ground fault	4379, 4352, 4353, 4354, 4355
9	Fan failure	4128, 4129, 4133, 4130
10	Fieldbus communication	5162, 4256, 4257, 4258, 4260, 4261, 4263, 4265, 4266, 4267, 4268, 4269, 4280, 4281, 4270, 4271, 4272, 4273, 4282, 4274, 4275, 4276, 4277, 4283, 4278, 4279
11	HMI connection	5141, 5142
12	Feedback connection	4418
13	Thermistor input	5157
14	Auxiliary device (temperature)	4200, 4201, 4203, 4202
15	External temperature measurement	5132, 5133, 5134, 5135, 5136, 5137, 5158

## P 5.1.8 Warning Status Word 1

**Description:** Shows the warning status word 1.

<b>Default Value:</b> -	<b>Parameter Type:</b>	<b>Parameter Number:</b> 6205
<b>Unit:</b>	<b>Data Type:</b> DWORD	<b>Access Type:</b> -

The following are the bit descriptions.

Bit	Description	Event number
0	Overcurrent	4384, 4373, 5170, 4368, 4369, 4375, 4377, 4380, 4097
1	Overvoltage	4164, 4162, 4144 4145
2	Undervoltage	4165, 4146
3	Unit temperature high	4117, 4118, 4119
4	Unit temperature low	4116
5	Control board overtemperature	4121, 4122, 4123, 4120
6	Input phase	4160, 4163
7	Output phase	4175, 4176
8	Ground fault	4379, 4352, 4353, 4354, 4355
9	Fan failure	4128, 4129, 4133, 4130
10	Fieldbus communication	5162, 4256, 4257, 4258, 4260, 4261, 4263, 4265, 4266 ,4267, 4268, 4269, 4280, 4281, 4270, 4271, 4272, 4273, 4282, 4274, 4275, 4276, 4277, 4283, 4278, 4279
11	HMI connection	5141, 5142
12	Feedback connection	4418
13	Thermistor input	5157
14	Auxiliary device (temperature)	4200, 4201, 4203, 4202
15	External temperature measurement	5132, 5133, 5134, 5135, 5136, 5137, 5158

## P 5.1.13 Application Status Word

**Description:** Shows the application-specific status word.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 65535)	<b>Parameter Number:</b> 1608
<b>Unit:</b> -	<b>Data Type:</b> WORD	<b>Access Type:</b> Read Only

Following are the bits and description.

Bit	Bit = False	Bit = True
0	Reserved	Reserved
1	Inching not Active	Inching Active
2	Process Control not Active	Process Control Active
3	Reserved	Reserved
4	Reserved	Reserved
5	Reserved	Reserved

Bit	Bit = False	Bit = True
6	Reserved	Reserved
7	Reserved	Reserved
8	Reserved	Reserved
9	Reserved	Reserved
10	Reserved	Reserved
11	Reserved	Reserved
12	Reserved	Reserved
13	Normal Reference	Freeze Reference
14	Normal Reference	Reverse Reference
15	Speed Within Limits	Speed Limit Active

## 6.6.2 Protection (Menu Index 5.2)

### 6.6.2.1 Cooling Monitor (Menu Index 5.2.1)

#### P 5.2.1.1 Cooling Monitor Input

**Description:** Select the input for the negated cooling monitor signal.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2400
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The Cooling Monitor feature can also be used for thermally protecting the motor by means of digital signal. (eg, Klixon). The signal needs to be normally closed. Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

#### P 5.2.1.2 Cooling Monitor Fault Delay

**Description:** Set a delay before the cooling monitor issues a fault. Only valid if fault is selected.

<b>Default Value:</b> 3	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 2401
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.2.1.3 Cooling Monitor Response

**Description:** Select the response to a missing cooling monitor signal. The response is selected for both stopped and running states.

<b>Default Value:</b> 2 [Warning, Fault after Timeout]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2402
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	While running, Warning after Timeout
1	Warning
2	Warning, Fault after Timeout
3	No response/Warning, Fault after Timeout

### 6.6.2.2 External Event (Menu Index 5.2.2)

#### P 5.2.2.1 External Event 1 Input

**Description:** Select an input for the external event.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 4557
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.2.2.3 External Event 1 Response

**Description:** Select the response to an external event.

<b>Default Value:</b> 9 [Fault, ramp to coast]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 4559
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	No response
1	Info
3	Warning
9	Fault, ramp to coast
10	Fault

#### P 5.2.2.4 External Event 2 Input

**Description:** Select an input for the external event.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 4560
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.2.2.6 External Event 2 Response

**Description:** Select the response to an external event.

<b>Default Value:</b> 9 [Fault, ramp to coast]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 4562
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	No response
1	Info
3	Warning
9	Fault, ramp to coast
10	Fault

#### P 5.2.2.7 External Event Active Output

**Description:** Select an output indicating an external event.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 5184
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

### 6.6.2.3 Measured Temp. Protection (Menu Index 5.2.3)

These parameters allow the setting of temperature monitoring and protection from externally connected signals.

#### 6.6.2.3.1 Measured Temp. Protection Status (Menu Index 5.2.3.1)

These parameters provide readouts of the temperature measured by the connected temperature sensors.

##### P 5.2.3.1.1 Protection 1 Temp.

**Description:** Shows the temperature measured for the temperature protection.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 5200
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

##### P 5.2.3.1.2 Protection 2 Temp.

**Description:** Shows the temperature measured for the temperature protection.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 5201
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

##### P 5.2.3.1.3 Protection 3 Temp.

**Description:** Shows the temperature measured for the temperature protection.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 5202
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

##### P 5.2.3.1.4 Protection 4 Temp.

**Description:** Shows the temperature measured for the temperature protection.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 5203
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

##### P 5.2.3.1.5 Protection 5 Temp.

**Description:** Shows the temperature measured for the temperature protection.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 5204
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

##### P 5.2.3.1.6 Protection 6 Temp.

**Description:** Shows the temperature measured for the temperature protection.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 5205
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

### 6.6.2.3.2 Temp. 1 Protection (Menu Index 5.2.3.2)

#### P 5.2.3.2.1 Temp. 1 Input

**Description:** Select the temperature sensor input for the temperature protection.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 5206
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.2.3.2.2 Temp. 1 Limit 1

**Description:** Set the temperature level for issuing a warning.

<b>Default Value:</b> 120	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 5207
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

#### P 5.2.3.2.3 Temp. 1 Limit 2

**Description:** Set the temperature level for issuing a protection response.

<b>Default Value:</b> 150	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 5208
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

#### P 5.2.3.2.4 Temp. 1 Limit 2 Response

**Description:** Select the response for exceeding the limit.

<b>Default Value:</b> 9 [Fault, ramp to coast]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 5209
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
3	Warning
9	Fault, ramp to coast
10	Fault

### 6.6.2.3.3 Temp. 2 Protection (Menu Index 5.2.3.3)

#### P 5.2.3.3.1 Temp. 2 Input

**Description:** Select the temperature sensor input for the temperature protection.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 5210
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.2.3.3.2 Temp. 2 Limit 1

**Description:** Set the temperature level for issuing a warning.

<b>Default Value:</b> 120	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 5211
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

#### P 5.2.3.3.3 Temp. 2 Limit 2

**Description:** Set the temperature level for issuing a protection response.



<b>Default Value:</b> 150	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 5212
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

#### P 5.2.3.3.4 Temp. 2 Limit 2 Response

**Description:** Select the response for exceeding the limit.

<b>Default Value:</b> 9 [Fault, ramp to coast]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 5213
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
3	Warning
9	Fault, ramp to coast
10	Fault

### 6.6.2.3.4 Temp. 3 Protection (Menu Index 5.2.3.4)

#### P 5.2.3.4.1 Temp. 3 Input

**Description:** Select the temperature sensor input for the temperature protection.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 5214
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.2.3.4.2 Temp. 3 Limit 1

**Description:** Set the temperature level for issuing a warning.

<b>Default Value:</b> 120	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 5215
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

#### P 5.2.3.4.3 Temp. 3 Limit 2

**Description:** Set the temperature level for issuing a protection response.

<b>Default Value:</b> 150	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 5216
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

#### P 5.2.3.4.4 Temp. 3 Limit 2 Response

**Description:** Select the response for exceeding the limit.

<b>Default Value:</b> 9 [Fault, ramp to coast]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 5217
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
3	Warning
9	Fault, ramp to coast
10	Fault

### 6.6.2.3.5 Temp. 4 Protection (Menu Index 5.2.3.5)

#### P 5.2.3.5.1 Temp. 4 Input

**Description:** Select the temperature sensor input for the temperature protection.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 5218
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.2.3.5.2 Temp. 4 Limit 1

**Description:** Set the temperature level for issuing a warning.

<b>Default Value:</b> 120	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 5219
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

#### P 5.2.3.5.3 Temp. 4 Limit 2

**Description:** Set the temperature level for issuing a protection response.

<b>Default Value:</b> 150	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 5220
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

#### P 5.2.3.5.4 Temp. 4 Limit 2 Response

**Description:** Select the response for exceeding the limit.

<b>Default Value:</b> 9 [Fault, ramp to coast]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 5221
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
3	Warning
9	Fault, ramp to coast
10	Fault

### 6.6.2.3.6 Temp. 5 Protection (Menu Index 5.2.3.6)

#### P 5.2.3.6.1 Temp. 5 Input

**Description:** Select the temperature sensor input for the temperature protection.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 5222
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.2.3.6.2 Temp. 5 Limit 1

**Description:** Set the temperature level for issuing a warning.

<b>Default Value:</b> 120	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 5223
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

#### P 5.2.3.6.3 Temp. 5 Limit 2

**Description:** Set the temperature level for issuing a protection response.

<b>Default Value:</b> 150	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 5224
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

#### P 5.2.3.6.4 Temp. 5 Limit 2 Response

**Description:** Select the response for exceeding the limit.

<b>Default Value:</b> 9 [Fault, ramp to coast]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 5225
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
3	Warning
9	Fault, ramp to coast
10	Fault

### 6.6.2.3.7 Temp. 6 Protection (Menu Index 5.2.3.7)

#### P 5.2.3.7.1 Temp. 6 Input

**Description:** Select the temperature sensor input for the temperature protection.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 5226
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.2.3.7.2 Temp. 6 Limit 1

**Description:** Set the temperature level for issuing a warning.

<b>Default Value:</b> 120	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 5227
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

#### P 5.2.3.7.3 Temp. 6 Limit 2

**Description:** Set the temperature level for issuing a protection response.

<b>Default Value:</b> 150	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 5228
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

#### P 5.2.3.7.4 Temp. 6 Limit 2 Response

**Description:** Select the response for exceeding the limit.

<b>Default Value:</b> 9 [Fault, ramp to coast]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 5229
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
3	Warning
9	Fault, ramp to coast
10	Fault

### 6.6.2.4 Lost Load Detection (Menu Index 5.2.7)

#### P 5.2.7.1 Lost-load Response

**Description:** Select an action for the lost-load detection. The lost-load detection is active if the motor speed is above 15 Hz.

<b>Default Value:</b> 0 [No response]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 9072
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	No response
1	Info
3	Warning
9	Fault, ramp to coast
10	Fault

#### P 5.2.7.2 Lost-load Detection Torque Level

**Description:** Set the minimum allowed torque level in % of nominal motor torque. The lost-load detection can be activated below the set level.

<b>Default Value:</b> 10	<b>Parameter Type:</b> Range (5 — 100)	<b>Parameter Number:</b> 9070
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.2.7.3 Lost-load Detection Delay

**Description:** Set the minimum duration that the torque has to be below the detection limit before activating the lost-load exception.

<b>Default Value:</b> 10	<b>Parameter Type:</b> Range (0 — 600)	<b>Parameter Number:</b> 9071
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

### 6.6.2.5 HMI Connection Loss (Menu Index 5.2.9)

This parameter allows the selection of the response to a lost connection to the control panel or PC tool.

#### P 5.2.9.1 HMI Connection Loss

**Description:** Select the response after lost connection to control panel or PC tool while they are in control. The timeout occurs after 5 s.

<b>Default Value:</b> 0 [No response]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 5420
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter

Selection number	Selection name
0	No response
2	Info
4	Warning - Persistent
9	Fault, ramp to coast
10	Fault

### 6.6.2.6 Live Zero (Menu Index 5.2.15)

#### P 5.2.15.2 Live Zero Response

**Description:** Select the drive response to a missing input signal (live zero).

<b>Default Value:</b> 3 [Warning]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 4555
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	No Action
1	Info
3	Warning
10	Fault

### 6.6.2.7 Feedback Handling (Menu Index 5.2.16)

#### P 5.2.16.1 Failure Handling Response

**Description:** Select the drive response to an encoder/resolver failure.

<b>Default Value:</b> 10 [Coast]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 4600
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
3	Switch to Open Loop and Continue
9	Switch to Open Loop and Ramp to Stop
10	Coast

### 6.6.3 Load (Menu Index 5.3)

#### 6.6.3.1 Load Status (Menu Index 5.3.1)

##### P 5.3.1.1 Inertia Estimation Status

**Description:** Shows the status of the inertia estimation routine. 0 = Inactive, 1 = In progress, 2 = Completed successfully, 3 = Completed unsuccessfully.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 666
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read Only

The following are the selections for the parameter.

Selection number	Selection name
0	Inactive
1	In progress
2	Completed successfully
3	Completed unsuccessfully

### 6.6.3.2 Inertia (Menu Index 5.3.2)

#### P 5.3.2.1 Inertia Estimation Mode

**Description:** Set the mode for the inertia estimation.

<b>Default Value:</b> 0 [Off]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 668
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Conditional Write

The following are the selections for the parameter

Selection number	Selection name
0	Off
1	Without load profile
2	With load profile

#### P 5.3.2.2 Inertia Estimation Timeout

**Description:** Set the time after which an event message will be generated if inertia estimation cannot be finalized.

<b>Default Value:</b> 900	<b>Parameter Type:</b> Range (120 — 1800)	<b>Parameter Number:</b> 669
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.3.2.3 System Inertia

**Description:** Set the system inertia.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 667
<b>Unit:</b> kgm <sup>2</sup>	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Depending on whether metric or imperial units are in use, give the value for the parameter in either kilogram meters squared (kgm<sup>2</sup>) or pound-foot-seconds squared (lbf ft s<sup>2</sup>). The value range is different with the different units.

### 6.6.3.3 Torque & AEO (Menu Index 5.3.3)

#### P 5.3.3.1 Torque Characteristic

**Description:** Select the torque characteristics matching the application needs.

<b>Default Value:</b> 0 [Constant torque (CT)]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2809
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Constant torque (CT)
1	Variable torque (VT)
2	Automatic Energy Optimization (AEO)

## P 5.3.3.2 AEO Minimum Speed

**Description:** Set the speed above which Automatic Energy Optimization (AEO) is active.

<b>Default Value:</b> 10	<b>Parameter Type:</b> Range (0 — 2000)	<b>Parameter Number:</b> 2810
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

## P 5.3.3.3 AEO Minimum Magnetization

**Description:** Set the minimum magnetization current used by Automatic Energy Optimization (AEO).

<b>Default Value:</b> 40	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 2811
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.3.3.4 Variable Torque Zero Speed Magnetization

**Description:** Set the magnetization current level at 0 speed. Used in variable torque (VT) setting.

<b>Default Value:</b> 66	<b>Parameter Type:</b> Range (40 — 90)	<b>Parameter Number:</b> 8020
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## 6.6.4 Operation Mode (Menu Index 5.4)

## 6.6.4.1 Settings (Menu Index 5.4.2)

## P 5.4.2.16 Operation Mode

**Description:** Select the drive operation mode.

<b>Default Value:</b> 0 [Speed control]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2500
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Speed control
1	Torque control
21	Process control

## P 5.4.2.19 Motor Feedback Mode

**Description:** Select the feedback mode.

<b>Default Value:</b> 0 [Open loop]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2502
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Open loop
1	Closed loop

## 6.6.5 Control Places (Menu Index 5.5)

## 6.6.5.1 Control Places Overview

## Overview

The parameters of parameter group 5.5 are used to configure the source from where the drive receives its commands, and what types of references are used. The configuration of the reference sources is part of the application controller parameterization. Com-

mands and references are configured per operation mode of the drive (see also parameter 5.4.2.16). The Industry application software supports the following control places:

- Local control through the Control Panel
- Fieldbus control
- I/O control
- Advanced control

Advanced control additionally allows the logical combination of 2 command sources.

Supported command logic for Advanced control is:

- Source 1
- Source 2
- AND
- OR
- NAND
- NOR
- XOR
- XNOR

Supported reference logic (except for local control) is:

- Source 1
- Source 2
- Sum
- Subtract
- Divide
- Multiply
- Maximum
- Minimum
- Toggle

The following is an illustration of how control places function in the iC7 drive:



5.5.3.1 Settings

(Functionality settings for the control panel)

5.5.3.2 References

(Types of reference for speed control, torque control, and process control when controlled by the panel)

5.5.4.1 References

(Max. 2 reference types per Operation Mode which can be combined by logic)

5.5.5.1 Commands

(Selection of digital inputs for the commands Start, Start Backwards, Stop Inverse, Coast Inverse, Reversing, Reset (one per command))

5.5.5.2 References


(Maximum of 2 reference types per Organisation Mode. Reference types can be combined by logic)

5.5.6.1 Commands

(Selection of input types for the commands Start, Start Backwards, Stop Inverse, Coast inverse, Reversing, Reset (maximum of two per command, input types can be combined by logic))

5.5.6.2 References

(Maximum of two reference types per Operation Mode. Reference types can be combined by logic)



e30bk111.10

Illustration 52: Control Places

6.6.5.2 Control Places Status (Menu Index 5.5.1)

P 5.5.1.1 Active Control Place

**Description:** Shows the control place that controls the drive.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 113
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read Only

The following are the selections for the parameter.

Selection number	Selection name
0	PC control
1	Local control
2	Fieldbus control
3	I/O control
4	Advanced control

P 5.5.1.2 Local Control Active Output

**Description:** Select an output terminal indicating that the drive is in local control.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 5178
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

P 5.5.1.3 Fieldbus Control Active Output

**Description:** Select an output terminal indicating that the drive is in fieldbus control.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 5197
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## P 5.5.1.4 I/O Control Active Output

**Description:** Select an output terminal indicating that the drive is in I/O control.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 5177
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## P 5.5.1.5 Advanced Control Active Output

**Description:** Select an output terminal indicating that the drive is in advanced control.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 4727
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## 6.6.5.3 Control Place Settings (Menu Index 5.5.2)

## P 5.5.2.1 Control Place Selection

**Description:** Select the active control place.

<b>Default Value:</b> 4 [Advanced control]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 114
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
1	Local control
2	Fieldbus control
3	I/O control
4	Advanced control

## P 5.5.2.7 Control Place Independent Reset

**Description:** Enable faults to be reset from all control places.

<b>Default Value:</b> 1 [Enabled]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 109
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Disabled
1	Enabled

## P 5.5.2.9 Alternate Control Place Selection

**Description:** Select the alternate control place.

<b>Default Value:</b> 4 [Advanced control]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 115
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
1	Local control
2	Fieldbus control
3	I/O control
4	Advanced control

#### P 5.5.2.10 Alternate Control Place Input

**Description:** Select the digital input terminal for activating the alternate control place.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 111
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

### 6.6.5.4 Local Control (Menu Index 5.5.3)

These parameters allow the setting of local control settings and reference.

#### 6.6.5.4.1 Settings (Menu Index 5.5.3.1)

##### P 5.5.3.1.1 Allow Local Control Force Stop

**Description:** Select whether the control panel stop button always stops the drive, regardless of the selected control place. Pressing the stop button also places the drive in local control.

<b>Default Value:</b> 1 [Enabled]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 106
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Disabled
1	Enabled

##### P 5.5.3.1.2 Local Control Mode

**Description:** Select restrictions of local control by the control panel.

<b>Default Value:</b> 0 [Allow Local Control]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 107
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Allow Local Control
1	Deny Local Start
2	Deny Local Control

##### P 5.5.3.1.3 Continue Operation in Local Control

**Description:** Enables running state when changing to local control.

<b>Default Value:</b> 1 [Enabled]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 108
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Disabled
1	Enabled

#### P 5.5.3.1.4 Local Control Stop Button Action

**Description:** Select the action of the stop button in the control panel. Selecting 'Stop, Hold to Coast' will stop and coast if the stop button is pressed for 2 s.

<b>Default Value:</b> 2 [Stop, Hold to Coast]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 110
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Stop
1	Coast Stop
2	Stop, Hold to Coast

#### 6.6.5.4.2 References (Menu Index 5.5.3.2)

##### P 5.5.3.2.1 Local Speed Ref. Source

**Description:** Select the speed reference source for when the drive is in local control.

<b>Default Value:</b> 1 [Local reference]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1912
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
1	Local reference
2	Fieldbus reference
3	Reference 1 input
4	Reference 2 input
5	Preset reference

##### P 5.5.3.2.2 Local Torque Ref. Source

**Description:** Select the torque reference source for when the drive is in local control.

<b>Default Value:</b> 1 [Local reference]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1925
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
1	Local reference
2	Fieldbus reference

Selection number	Selection name
3	Reference 1 input
4	Reference 2 input
5	Preset reference

#### P 5.5.3.2.3 Local Process Ref. Source

**Description:** Select the process control reference source for when the drive is in local control.

<b>Default Value:</b> 1 [Local reference]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 6051
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
1	Local reference
2	Fieldbus reference
3	Reference 1 input
4	Reference 2 input
5	Preset reference

### 6.6.5.5 Fieldbus control (Menu Index 5.5.4)

These parameters affect the settings for operation with fieldbus control for speed, torque, and process control modes.

#### 6.6.5.5.1 References (Menu Index 5.5.4.1)

##### P 5.5.4.1.1 Fieldbus Speed Reference

**Description:** Select the speed reference sources for when the drive operates in fieldbus control. Select 2 sources to combine them into 1 reference value.

<b>Default Value:</b> [2,0]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1914
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
2	Fieldbus reference
3	Reference 1 input
4	Reference 2 input
5	Preset reference

##### P 5.5.4.1.2 Fieldbus Speed Reference Logic

**Description:** Select how to form the speed reference out of the 2 inputs when operating in fieldbus control.

<b>Default Value:</b> 0 [Source 1]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1911
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Source 1
1	Source 2
2	Sum
3	Subtract
4	Divide
5	Multiply
6	Maximum
7	Minimum
8	Toggle

#### P 5.5.4.1.3 Fieldbus Speed Reference Toggle Input

**Description:** Select an input for toggling between the 2 speed reference sources selected, when operating in fieldbus control and toggling logic is used. A low signal selects the 1st source and high signal selects the 2nd source.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1939
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.5.4.1.4 Fieldbus Torque Reference

**Description:** Select the torque reference sources for when the drive operates in fieldbus control. Select 2 sources to combine them into 1 reference value.

<b>Default Value:</b> [2,0]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1928
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
2	Fieldbus reference
3	Reference 1 input
4	Reference 2 input
5	Preset reference

#### P 5.5.4.1.5 Fieldbus Torque Reference Logic

**Description:** Select how to form the torque reference out of the 2 sources when operating in fieldbus control.

<b>Default Value:</b> 0 [Source 1]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1918
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Source 1
1	Source 2

Selection number	Selection name
2	Sum
3	Subtract
4	Divide
5	Multiply
6	Maximum
7	Minimum

#### P 5.5.4.1.6 Fieldbus Process Reference

**Description:** Select the process control reference sources for when the drive operates in fieldbus control. Define multiple entries for combining several sources into 1 reference value.

<b>Default Value:</b> [2,0]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 6052
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
2	Fieldbus reference
3	Reference 1 input
4	Reference 2 input
5	Preset reference

#### P 5.5.4.1.7 Fieldbus Process Reference Logic

**Description:** Select how to form the process control reference out of the 2 sources when operating in fieldbus control.

<b>Default Value:</b> 0 [Source 1]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 6057
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Source 1
1	Source 2
2	Sum
3	Subtract
4	Divide
5	Multiply
6	Maximum
7	Minimum

### 6.6.5.6 I/O Control (Menu Index 5.5.5)

These parameters allow the setting of analog and digital I/O control operation for speed, torque, or process reference.

#### 6.6.5.6.1 Commands (Menu Index 5.5.5.1)

##### P 5.5.5.1.1 Start Input

**Description:** Select the digital input for the start command.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 200
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

##### P 5.5.5.1.2 Start Backward Input

**Description:** Select the digital input for the start command in the backward direction.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 210
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

##### P 5.5.5.1.3 Stop Inverse Input

**Description:** Select the digital input for the inverted stop command.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 201
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

##### P 5.5.5.1.4 Coast Inverse Input

**Description:** Select the digital input for the inverted coast command.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 202
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

##### P 5.5.5.1.5 Reversing Input

**Description:** Select the digital input for inverting the reference signal. The reverse command does not provide a start signal.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 204
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

##### P 5.5.5.1.6 Reset Input

**Description:** Select the digital input for resetting faults.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 203
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

##### P 5.5.5.1.8 Start Signal Mode

**Description:** Select the mode of the start signal.

<b>Default Value:</b> 0 [State High Start]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 211
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	State High Start
1	Rising Edge Start
2	High Pulse Start



### 6.6.5.6.2 References (Menu Index 5.5.5.2)

#### P 5.5.5.2.1 I/O Speed Reference

**Description:** Select the speed reference sources for when the drive operates in I/O control. Select 2 sources to combine them into 1 reference value.

<b>Default Value:</b> [3,0]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1913
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
2	Fieldbus reference
3	Reference 1 input
4	Reference 2 input
5	Preset reference

#### P 5.5.5.2.2 I/O Speed Reference Logic

**Description:** Select how to form the speed reference out of the 2 sources when operating in I/O control.

<b>Default Value:</b> 0 [Source 1]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1910
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Source 1
1	Source 2
2	Sum
3	Subtract
4	Divide
5	Multiply
6	Maximum
7	Minimum
8	Toggle

#### P 5.5.5.2.3 I/O Speed Reference Toggle Input

**Description:** Select an input for toggling between the 2 speed reference sources selected, when operating in I/O control and toggling logic is used. A low signal selects the 1st source and high signal selects the 2nd source.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1940
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.5.5.2.4 I/O Torque Reference

**Description:** Select the torque reference sources for when the drive operates in I/O control. Select 2 sources to combine them into 1 reference value.

<b>Default Value:</b> [3,0]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1927
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
2	Fieldbus reference
3	Reference 1 input
4	Reference 2 input
5	Preset reference

#### P 5.5.5.2.5 I/O Torque Reference Logic

**Description:** Select how to form the torque reference out of the 2 sources when operating in I/O control.

<b>Default Value:</b> 0 [Source 1]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1917
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Source 1
1	Source 2
2	Sum
3	Subtract
4	Divide
5	Multiply
6	Maximum
7	Minimum

#### P 5.5.5.2.6 I/O Process Reference

**Description:** Select the process control reference sources for when the drive operates in I/O control. Select 2 sources to combine them into 1 reference value.

<b>Default Value:</b> [3,0]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 6055
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
2	Fieldbus reference

Selection number	Selection name
3	Reference 1 input
4	Reference 2 input
5	Preset reference

#### P 5.5.5.2.7 I/O Process Reference Logic

**Description:** Select how to form the process control reference out of the 2 sources when operating in I/O control.

<b>Default Value:</b> 0 [Source 1]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 6059
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Source 1
1	Source 2
2	Sum
3	Subtract
4	Divide
5	Multiply
6	Maximum
7	Minimum

### 6.6.5.7 Advanced control (Menu Index 5.5.6)

#### 6.6.5.7.1 Commands (Menu Index 5.5.6.1)

##### P 5.5.6.1.1 Advanced Start Input

**Description:** Select inputs for starting in the forward direction when operating in advanced control.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 4722
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

##### P 5.5.6.1.2 Advanced Start Logic

**Description:** Select the combination logic for the start command of advanced control.

<b>Default Value:</b> 3 [OR]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1933
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Source 1
1	Source 2
2	AND
3	OR

Selection number	Selection name
4	NAND
5	NOR
6	XOR
7	XNOR

#### P 5.5.6.1.3 Advanced Start Backward Input

**Description:** Select inputs for starting in the backward direction when operating in advanced control.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 4725
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.5.6.1.4 Advanced Start Backward Logic

**Description:** Select the combination logic for the start-backward command of advanced control.

<b>Default Value:</b> 0 [Source 1]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1934
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Source 1
1	Source 2
2	AND
3	OR
4	NAND
5	NOR
6	XOR
7	XNOR

#### P 5.5.6.1.5 Advanced Stop Inverse Input

**Description:** Select inputs for stopping when operating in advanced control. False means the drive is stopped.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 4723
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.5.6.1.6 Advanced Stop Inverse Logic

**Description:** Select the combination logic for the stop command of advanced control.

<b>Default Value:</b> 0 [Source 1]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1935
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Source 1
1	Source 2

Selection number	Selection name
2	AND
3	OR
4	NAND
5	NOR
6	XOR
7	XNOR

#### P 5.5.6.1.7 Advanced Coast Inverse Input

**Description:** Select inputs for the coast when operating in advanced control. False means the drive is coasted.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 4724
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.5.6.1.8 Advanced Coast Inverse Logic

**Description:** Select the combination logic for the inverted coast command of advanced control.

<b>Default Value:</b> 0 [Source 1]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1936
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Source 1
1	Source 2
2	AND
3	OR
4	NAND
5	NOR
6	XOR
7	XNOR

#### P 5.5.6.1.9 Advanced Reversing Input

**Description:** Select inputs for inverting the reference signal when operating in advanced control. The reverse command does not provide a start signal.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 4730
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.5.6.1.10 Advanced Reverse Logic

**Description:** Select the combination logic for the reverse command of advanced control.

<b>Default Value:</b> 3 [OR]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1937
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Source 1
1	Source 2
2	AND
3	OR
4	NAND
5	NOR
6	XOR
7	XNOR

#### P 5.5.6.1.11 Advanced Reset Input

**Description:** Select inputs for resetting faults when operating in advanced control.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 4731
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.5.6.1.13 Advanced Start Mode

**Description:** Select the starting logic for advanced control.

<b>Default Value:</b> 0 [State High Start]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 4726
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	State High Start
1	Rising Edge Start
2	High Pulse Start

#### P 5.5.6.1.15 Fieldbus CTW Feature Bits

**Description:** Enables non-control-place-dependent control word bits to be active in advanced control place.

<b>Default Value:</b> 1 [Enabled]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 4627
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Disabled
1	Enabled

### 6.6.5.7.2 References (Menu Index 5.5.6.2)

#### P 5.5.6.2.1 Adv. Speed Reference

**Description:** Select the speed reference sources for when the drive operates in advanced control. Select 2 sources to combine them into 1 reference value.

<b>Default Value:</b> [2,3]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1915
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
2	Fieldbus reference
3	Reference 1 input
4	Reference 2 input
5	Preset reference

#### P 5.5.6.2.2 Adv. Speed Reference Logic

**Description:** Select how to form the speed reference out of the 2 sources when operating in advanced control.

<b>Default Value:</b> 2 [Sum]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1916
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Source 1
1	Source 2
2	Sum
3	Subtract
4	Divide
5	Multiply
6	Maximum
7	Minimum
8	Toggle

#### P 5.5.6.2.3 Adv. Speed Reference Toggle Input

**Description:** Select an input for toggling between the 2 speed reference sources selected, when operating in advanced control and toggling logic is used. A low signal selects the 1st source and high signal selects the 2nd source.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1941
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.5.6.2.4 Adv. Torque Reference

**Description:** Select the torque reference sources for when the drive operates in advanced control. Select 2 sources to combine them into 1 reference value.

<b>Default Value:</b> [2,0]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1929
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
2	Fieldbus reference
3	Reference 1 input
4	Reference 2 input
5	Preset reference

#### P 5.5.6.2.5 Adv. Torque Reference Logic

**Description:** Select how to form the torque reference out of the 2 inputs when operating in advanced control.

<b>Default Value:</b> 0 [Source 1]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1919
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Source 1
1	Source 2
2	Sum
3	Subtract
4	Divide
5	Multiply
6	Maximum
7	Minimum

#### P 5.5.6.2.6 Adv. Process Reference

**Description:** Select the process control reference sources for when the drive operates in advanced control. Define multiple entries for combining several sources into 1 reference value.

<b>Default Value:</b> [2,3]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 6054
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
2	Fieldbus reference
3	Reference 1 input
4	Reference 2 input
5	Preset reference

#### P 5.5.6.2.7 Adv. Process Reference Logic

**Description:** Select how to form the process control reference out of the 2 inputs when operating in advanced control.



Default Value: 2 [Sum]	Parameter Type: Selection	Parameter Number: 6045
Unit: -	Data Type: UINT	Access Type: Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Source 1
1	Source 2
2	Sum
3	Subtract
4	Divide
5	Multiply
6	Maximum
7	Minimum

### 6.6.6 Start Settings (Menu Index 5.6)

#### 6.6.6.1 Start Settings Overview

The application software provides the possibility to configure a DC start before entering normal motor control, for purposes of motor pre-heating, pre-magnetization, DC holding, or a start delay.




Illustration 53: Induction Motor Start from Zero Speed with DC Start and Start Zero Speed Time > 0

DC start is configured using 3 parameters, 5.6.2.3 DC Start Current %, 5.6.2.1 DC Start Time and 5.6.2.2 DC Start Rise Time.

By default, DC start is disabled by setting parameter 5.6.2.1 DC Start Time to 0. The following illustration shows an example of starting an induction at zero speed.

DC start is also used as a start delay by setting parameter 5.6.2.1 DC Start Time to the desired delay time and 5.6.2.3 DC Start Current % = 0.

DC start is only applied when starting at zero speed, or when parameter 5.6.1.2 Enable Flying Start to 0 [Disable] and motor back-emf voltage is not detected.

#### Induction motor control start settings

For induction motor control, it is possible to configure a motor magnetization period using the parameter 5.6.1.1 Magnetization Time, before releasing the speed ramp, as shown in illustration. To let the drive automatically determine the magnetization period, set parameter 5.6.1.1 Magnetization Time to -1.

Synchronous motor control start settings

DC start is also possible from zero speed with synchronous motor control.

The following illustration shows a zero speed example with DC start and initial position handling as rotor angle detection. To set the initial position handling to rotor angle detection, set *P 5.6.3.1 Sync. Motor Start Mode* to 0 [Rotor angle detection].




Illustration 54: Synchronous Motor Start from Zero Speed with DC Start

As an alternative to Rotor Angle Detection for synchronous motor, it is possible to set the initial position handling as Rotor Angle Parking. This is achieved by setting parameter *5.6.3.1 Sync. Motor Start Mode* to 1 [Rotor angle parking]. This option forces the motor shaft to move to a fixed position defined by the parameter *P 5.6.3.5 Sync. Motor Parking Angle Reference*, before ramp release.

An illustration of synchronous motor start from zero speed with DC-Start and parking, as shown in the illustration.




Illustration 55: Synchronous Motor Start from Zero Speed with DC Start and Parking

Start Settings Parameters

For more information on parameters for starting the motor, see [6.6.6 Start Settings \(Menu Index 5.6\)](#)

6.6.6.2 General Settings (Menu Index 5.6.1)

P 5.6.1.1 Magnetization Time

**Description:** Set a delay to magnetize the motor or synchronize parallel motors before starting ramping. Set to -1 for automatic calculation.

<b>Default Value:</b> -1	<b>Parameter Type:</b> Range (-1 — 10000)	<b>Parameter Number:</b> 2328
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.6.1.2 Flying Start

**Description:** Enables a flying start. The drive will detect its current speed at the moment the start signal is given, and start to ramp towards the given reference.

<b>Default Value:</b> 0 [Disabled]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 4025
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Disabled
1	Enabled

#### P 5.6.1.5 Run Enable Input

**Description:** Select an input enabling the drive to run.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 103
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

### 6.6.6.3 DC Start (Menu Index 5.6.2)

These parameters allow the setting of DC start capabilities.

#### P 5.6.2.1 DC Start Time

**Description:** Set the duration of the current injection during DC start.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 2264
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.6.2.2 DC Start Current Rise Time

**Description:** Set the time to ramp the current from 0 to the specified injection level.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 2265
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.6.2.3 DC Start Current

**Description:** Set the DC current in % of nominal motor current. This current is injected during the DC start time.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 1000)	<b>Parameter Number:</b> 2263
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

### 6.6.6.4 Synchronous Motor Start (Menu Index 5.6.3)

#### P 5.6.3.1 Sync. Motor Start Mode

**Description:** Set the synchronous motor initial position handling.

<b>Default Value:</b> 1 [Rotor angle detection]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2322
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Disabled
1	Rotor angle detection
2	Rotor angle parking

#### P 5.6.3.2 Sync. Motor Detection Current

**Description:** Set the rotor angle detection gain in % of the nominal motor current.

<b>Default Value:</b> 150	<b>Parameter Type:</b> Range (0 — 200)	<b>Parameter Number:</b> 2323
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.6.3.3 Sync. Motor Parking Time

**Description:** Set the duration of the rotor parking.

<b>Default Value:</b> 3	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 2324
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.6.3.4 Sync. Motor Parking Current

**Description:** Set the rotor angle parking current in % of the nominal motor current.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0 — 1000)	<b>Parameter Number:</b> 2325
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.6.3.5 Sync. Motor Parking Angle

**Description:** Set the electrical parking angle for the rotor.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 360)	<b>Parameter Number:</b> 2326
<b>Unit:</b> °	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## 6.6.7 Stop Settings (Menu Index 5.7)

### 6.6.7.1 Stop Settings Overview

#### DC-braking

The application software enables configuration of DC-braking for induction motor control.

By default, the DC brake is disabled by setting *parameter 5.6.2.1 DC Start Time* to 0.

The user can configure the following settings using parameters.

- Speed at which DC-braking should start by setting the required speed in *parameter 5.7.2.3 DC Brake Speed*.
- Percentage of the brake current to be applied to the motor in *parameter 5.7.2.2 DC Brake Current*.
- Duration for which DC-brake is active for a DC braking current injection is configured in *parameter 5.7.2.1 DC-Brake Time*.

The following illustration shows a DC-brake scenario.




Illustration 56: DC Braking and DC Stop

DC stop and stop delay

Besides DC-brake, the application software allows to configure DC stop which is applicable for DC-hold or magnetization purposes. *Parameter 5.7.2.5 DC Stop Current %* and *5.7.2.4 DC Stop Time* are the 2 parameters which enable to configure DC stop. By default, DC stop is disabled by setting DC Stop Time to 0.

DC stop is always applied at zero speed and as the last activity before the drive begins to coast.




Illustration 57: DC Stop and Stop Delay

When both parameters *5.7.1.1 Stop Zero Speed Time* and *5.7.2.4 DC Stop Time* are set to -1, then *parameter 5.7.1.1 Stop Zero Speed Time* has priority.

To introduce stop delay, use *parameter 5.7.1.1 Stop Zero Speed Time*. By default, stop delay is disabled and *parameter 5.7.1.1 Stop Zero Speed Time* is set to 0. The parameter defines the duration starting from the time of reaching 0 speed to the time when the drive stops modulating or continues with DC stop. During the stop delay duration, the drive remains in run mode, modulates, and reacts to load changes.

NOTICE

When the drive is configured for DC braking, the *parameter 5.7.1.1 Stop Zero Speed Time* has no effect.

For more information on DC-brake stop settings, see [6.6.7.2 Settings \(Menu Index 5.7.1\)](#) and [6.6.7.3 DC Injection \(Menu Index 5.7.2\)](#).

6.6.7.2 Settings (Menu Index 5.7.1)

These parameters allow the setting of basic stop parameters.

P 5.7.1.1 Stop Zero Speed Time

**Description:** Set the time that motor control stays active after reaching 0 speed. The value -1 means indefinitely.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (-1 — 10000)	<b>Parameter Number:</b> 2331
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.7.1.3 Torque Ramp Down Time

**Description:** Set the time for ramping down the remaining torque after reaching standstill.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 2336
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.7.1.4 Zero-speed Detection Level

**Description:** Set the speed that is considered standstill.

<b>Default Value:</b> 0.20	<b>Parameter Type:</b> Range (0 — 2.0)	<b>Parameter Number:</b> 2339
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.7.1.5 Zero-speed Detection Delay

**Description:** Set the time that the speed must be below zero-speed detection level before standstill is detected.

<b>Default Value:</b> 0.02	<b>Parameter Type:</b> Range (0 — 2)	<b>Parameter Number:</b> 2356
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## 6.6.7.3 DC Injection (Menu Index 5.7.2)

These parameters allow the setting of DC injection related parameters.

## P 5.7.2.1 DC-brake Time

**Description:** Set the duration for a DC braking current injection.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 2267
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.7.2.2 DC-brake Current

**Description:** Set the DC braking current in % of nominal motor current.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 1000)	<b>Parameter Number:</b> 2266
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.7.2.3 DC-brake Speed

**Description:** Set the speed below which DC braking is activated.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 2268
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

## P 5.7.2.4 DC Stop Time

**Description:** Set the DC stopping injection duration. The value -1 means indefinitely.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (-1 — 10000)	<b>Parameter Number:</b> 2320
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.7.2.5 DC Stop Current

**Description:** Set the DC stopping current in % of nominal motor current. Applied after the drive has reached standstill.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 1000)	<b>Parameter Number:</b> 2321
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## 6.6.7.4 Quick Stop (Menu Index 5.7.3)

## P 5.7.3.1 Quick Stop Inverse Input

**Description:** Select an input terminal for activating the Quick Stop Inverse function.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 212
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.7.3.2 Quick Stop Ramp Time

**Description:** Set the deceleration time for the quick stop ramp.

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1129
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

### 6.6.7.5 AC Brake (Menu Index 5.7.4)

#### P 5.7.4.1 AC Brake

**Description:** Enables the AC Brake.

<b>Default Value:</b> 0 [Disabled]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 4026
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Disabled
1	Enabled

#### P 5.7.4.2 AC-brake Voltage Control Kp

**Description:** Set the scaling of the proportional gain of the AC-brake controller.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0 — 500)	<b>Parameter Number:</b> 4027
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.7.4.3 AC-brake Voltage Control Ti

**Description:** Set the scaling of the integral time of the AC-brake controller.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0 — 500)	<b>Parameter Number:</b> 4028
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.7.4.4 AC-brake Current


**Description:** Set the maximum allowed motor current in % of nominal motor current when AC brake is enabled.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0 — 150)	<b>Parameter Number:</b> 4057
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

### 6.6.8 Speed Control (Menu Index 5.8)

#### 6.6.8.1 Speed Control Overview

*Parameter group 5.8 Speed Control* contains the settings and the readout values related to the speed controller.



e30bkt13.11

Illustration 58: Reference Handling for Speed Control



### 6.6.8.2 Speed Control Status (Menu Index 5.8.1)

These parameters provide a readout of speed control related status information.

#### P 5.8.1.2 Motor Speed

**Description:** Shows the actual motor speed.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 9011
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.1.3 Output Frequency

**Description:** Shows the output frequency.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 9015
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

#### P 5.8.1.4 Feedback Speed

**Description:** Shows the feedback speed.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-10000 — 10000)	<b>Parameter Number:</b> 9007
<b>Unit:</b> rpm	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

#### P 5.8.1.5 Feedback Electrical Angle

**Description:** Shows the feedback device angle in the electrical domain. Its value is needed for manually tuning the feedback angle offset.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 360)	<b>Parameter Number:</b> 9016
<b>Unit:</b> °	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

#### P 5.8.1.6 Speed Error

**Description:** Shows the difference between speed reference after ramp and motor speed.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 4023
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.1.7 Speed Reference

**Description:** Shows the speed reference.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-2000 — 2000)	<b>Parameter Number:</b> 1718
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.1.8 Speed Reference Before Ramp

**Description:** Shows the value of speed reference before the ramp generator.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-2000 — 2000)	<b>Parameter Number:</b> 6049
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.1.9 Speed Reference After Ramp

**Description:** Shows the value of the speed reference after the ramp generator.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 6150
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Default unit: RPM. The unit can be changed with parameter 4321.

## P 5.8.1.10 Final Speed Reference

**Description:** Shows the value of the speed reference before feeding it to the speed controller.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 6151
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Default unit: RPM. The unit can be changed with parameter 4321.

## P 5.8.1.11 Control Panel Speed Reference

**Description:** Shows the value of the speed reference given from the control panel.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 6153
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

## P 5.8.1.12 Absolute Output Frequency Output

**Description:** Select an output terminal for the output frequency scaled between 0 Hz and positive speed limits in Hz.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2300
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

### N O T I C E

Selection lists with inputs and/or outputs consist of the name of the hardware option and the numbers of the terminals. For example, terminal number 13 of the Basic I/O is named as as Basic I/O T13, in the selection list.

## P 5.8.1.13 Absolute Speed Reference Output

**Description:** Select an output terminal for the absolute speed reference, scaled between 0 and positive speed limit.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2304
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

### N O T I C E

Selection lists with inputs and/or outputs consist of the name of the hardware option and the numbers of the terminals. For example, terminal number 13 of the Basic I/O is named as as Basic I/O T13, in the selection list.

## P 5.8.1.14 Output Frequency Output

**Description:** Select an output terminal for the output frequency scaled between minimum speed limit and positive speed limits in Hz.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2308
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

### N O T I C E

Selection lists with inputs and/or outputs consist of the name of the hardware option and the numbers of the terminals. For example, terminal number 13 of the Basic I/O is named as as Basic I/O T13, in the selection list.

## P 5.8.1.16 Load Drooping Speed

**Description:** Shows the load drooping speed.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 2000)	<b>Parameter Number:</b> 674
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Default unit: RPM. The unit can be changed with parameter 4321.

### 6.6.8.3 Speed Controller (Menu Index 5.8.2)

#### 6.6.8.3.1 Basic Settings (Menu Index 5.8.2.1)

##### P 5.8.2.1.1 Speed Controller Type

**Description:** Select the speed controller type.

<b>Default Value:</b> 1 [PI-Controller]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 5005
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Conditional Write

The following are the selections for the parameter.

Selection number	Selection name
0	P-Controller
1	PI-Controller

##### P 5.8.2.1.2 Speed Controller Kp FVC+

**Description:** Set the proportional gain of the speed controller.

<b>Default Value:</b> 15	<b>Parameter Type:</b> Range (0 — 1000)	<b>Parameter Number:</b> 4020
<b>Unit:</b> PercentPerHertz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

##### P 5.8.2.1.3 Speed Controller Ti FVC+

**Description:** Set the integration time of the speed controller.

<b>Default Value:</b> 0.1	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 4021
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

##### P 5.8.2.1.4 Acceleration Feedforward Gain

**Description:** Set the acceleration feedforward gain. It bypasses the speed controller by adding torque reference based on requested acceleration and system inertia. Improves tracking of speed reference changes.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 4022
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

##### P 5.8.2.1.5 Acceleration Feedforward Filter Tc

**Description:** Set the acceleration feedforward filter time constant.

<b>Default Value:</b> 0.00	<b>Parameter Type:</b> Range (0.00 — 1000000.00)	<b>Parameter Number:</b> 4039
<b>Unit:</b> ms	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

##### P 5.8.2.1.7 Speed Controller Kp VVC+

**Description:** Set the proportional gain of the speed controller.

<b>Default Value:</b> 0.015	<b>Parameter Type:</b> Range (0 — 1)	<b>Parameter Number:</b> 4080
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

##### P 5.8.2.1.8 Speed Controller Ti VVC+

**Description:** Set the integration time of the speed controller.

<b>Default Value:</b> 0.008	<b>Parameter Type:</b> Range (0.001 — 20)	<b>Parameter Number:</b> 4081
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

### 6.6.8.3.2 Advanced Settings (Menu Index 5.8.2.2)

#### P 5.8.2.2.1 Virtual Friction Gain

**Description:** Set the virtual friction gain, adding friction to the speed control loop to increase damping and stability. It is automatically adjusted when the system inertia is changed and parameter "5.8.11.1 Speed Controller Auto Tuning" is enabled.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 4549
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.8.2.2.2 Low-speed Controller

**Description:** Enables the low-speed controller. It should be enabled if fast torque reaction at low speed references is needed.

<b>Default Value:</b> 0 [Disabled]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 4070
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Disabled
1	Enabled

#### P 5.8.2.2.3 Low-speed Controller Gain

**Description:** Set the proportional part of the low-speed controller. A higher value leads to higher dynamics.

<b>Default Value:</b> 50	<b>Parameter Type:</b> Range (0 — 1000)	<b>Parameter Number:</b> 4071
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.8.2.2.4 Kp Ratio at Low Speed

**Description:** Set the gain ratio for the proportional part of the speed controller at frequencies below the value set in "5.8.2.2.5 Kp Adaptation Low Speed".

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (1 — 1000)	<b>Parameter Number:</b> 4072
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.8.2.2.5 Kp Adaptation Low Speed

**Description:** Set the speed below which the speed controller proportional gain is fully using the value set in "5.8.2.2.4 Kp Ratio at Low Speed".

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 4073
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.8.2.2.6 Kp Adaptation High Speed

**Description:** Set the speed above which the speed controller proportional gain is fully using the value set in "5.8.2.1.2 Speed Controller Kp FVC+".

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 4074
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.8.2.2.7 Kp Ratio at Low Torque

**Description:** Set the gain ratio for the proportional part of the speed controller at a torque level below the lower torque limit.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (1 — 1000)	<b>Parameter Number:</b> 4075
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.8.2.2.8 Kp Adaptation Low Torque

**Description:** Set the torque level below which the speed controller proportional gain is fully using the value set in "5.8.2.2.7 Kp Ratio at Low Torque".

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 1000)	<b>Parameter Number:</b> 4077
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.8.2.2.9 Kp Adaptation High Torque

**Description:** Set the torque level above which the speed controller proportional gain is fully using the value set in "5.8.2.1.2 Speed Controller Kp FVC+".

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 1000)	<b>Parameter Number:</b> 4078
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.8.2.2.10 Kp Adaptation Min at Low Flux

**Description:** Set the gain ratio for the proportional part, if flux is reduced by field weakening or Automatic Energy Optimization (AEO).

<b>Default Value:</b> 40	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 4079
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.8.2.2.11 Zero-speed Damping Gain

**Description:** Set the zero-speed damping gain. It dampens speed fluctuations when the speed reference is 0.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0 — 1000)	<b>Parameter Number:</b> 5434
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

### 6.6.8.4 Speed Limits and Monitor (Menu Index 5.8.3)

#### P 5.8.3.1 Positive Speed Limit

**Description:** Set the speed limit for positive direction.

<b>Default Value:</b> 50	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 1729
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.3.2 Negative Speed Limit

**Description:** Set the speed limit for negative direction.

<b>Default Value:</b> -50	<b>Parameter Type:</b> Range (\* — 0)	<b>Parameter Number:</b> 1728
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.3.3 Minimum Speed Limit

**Description:** Set the minimum speed for positive and negative direction.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 1722
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.3.4 High Speed Warning

**Description:** Set the speed value which activates the high speed warning. Activated after 1 s.

<b>Default Value:</b> 1000	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1200
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.3.5 High Speed Fault

**Description:** Set the speed value which activates the high speed fault after a delay.

<b>Default Value:</b> 1000	<b>Parameter Type:</b> Range (0 — 1000)	<b>Parameter Number:</b> 1201
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.3.6 High Speed Fault Delay

**Description:** Set the delay time after which a fault is issued if the speed set for high speed fault is exceeded.

<b>Default Value:</b> 10	<b>Parameter Type:</b> Range (0 — 360)	<b>Parameter Number:</b> 1202
<b>Unit:</b> s	<b>Data Type:</b> UDINT	<b>Access Type:</b> Read/Write

#### P 5.8.3.7 Start Speed Fault

**Description:** Set the speed which must be reached within the delay time after start. Otherwise a fault will be issued.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1203
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.3.8 Start Speed Fault Delay

**Description:** Set the time after which a fault is issued if start speed fault value is not reached.

<b>Default Value:</b> 20	<b>Parameter Type:</b> Range (0 — 360)	<b>Parameter Number:</b> 1204
<b>Unit:</b> s	<b>Data Type:</b> UDINT	<b>Access Type:</b> Read/Write

#### P 5.8.3.9 Low Speed Monitor Limit

**Description:** Set the speed value which activates the low speed fault after a delay.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1205
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.3.10 Low Speed Fault Delay

**Description:** Set the delay after which a fault is issued if speed drops below the level set for low speed monitor limit.

<b>Default Value:</b> 20	<b>Parameter Type:</b> Range (0 — 360)	<b>Parameter Number:</b> 1206
<b>Unit:</b> s	<b>Data Type:</b> UDINT	<b>Access Type:</b> Read/Write

### 6.6.8.5 Speed Reference (Menu Index 5.8.4)

#### P 5.8.4.1 Speed Reference 1 Input

**Description:** Select the input terminal or a predefined fixed value for the speed reference.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 501
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.8.4.2 Speed Reference 2 Input

**Description:** Select the input terminal or a predefined fixed value for the speed reference.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 502
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.8.4.3 Speed Reference 1 Max.

**Description:** Set the maximum value of the reference. It defines the upper point for the scaling of the reference input.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (-1000 — 1000)	<b>Parameter Number:</b> 1724
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.4.4 Speed Reference 1 Min.

**Description:** Set the minimum value of the reference. It defines the lower point for the scaling of the reference input.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (-1000 — 1000)	<b>Parameter Number:</b> 1725
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.4.5 Speed Reference 2 Max.

**Description:** Set the maximum value of the reference. It defines the upper point for the scaling of the reference input.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (-1000 — 1000)	<b>Parameter Number:</b> 1726
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.4.6 Speed Reference 2 Min.

**Description:** Set the minimum value of the reference. It defines the lower point for the scaling of the reference input.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (-1000 — 1000)	<b>Parameter Number:</b> 1727
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.4.7 Preset Speed Reference Selector

**Description:** Select the preset reference. The preset reference can be selected as a fixed value or by 3 digital inputs.

<b>Default Value:</b> 1 [Preset 1]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 702
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Bit Selection
1	Preset 1
2	Preset 2
3	Preset 3
4	Preset 4
5	Preset 5
6	Preset 6
7	Preset 7
8	Preset 8

#### P 5.8.4.8 Preset Speed 1

**Description:** Set the value of the preset reference.

<b>Default Value:</b> 10	<b>Parameter Type:</b> Range (-1000 — 1000)	<b>Parameter Number:</b> 703
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.4.9 Preset Speed 2

**Description:** Set the value of the preset reference.

<b>Default Value:</b> 20	<b>Parameter Type:</b> Range (-1000 — 1000)	<b>Parameter Number:</b> 704
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.4.10 Preset Speed 3

**Description:** Set the value of the preset reference.

<b>Default Value:</b> 30	<b>Parameter Type:</b> Range (-1000 — 1000)	<b>Parameter Number:</b> 705
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.4.11 Preset Speed 4

**Description:** Set the value of the preset reference.

<b>Default Value:</b> 40	<b>Parameter Type:</b> Range (-1000 — 1000)	<b>Parameter Number:</b> 706
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.4.12 Preset Speed 5

**Description:** Set the value of the preset reference.

<b>Default Value:</b> 50	<b>Parameter Type:</b> Range (-1000 — 1000)	<b>Parameter Number:</b> 707
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.4.13 Preset Speed 6

**Description:** Set the value of the preset reference.

<b>Default Value:</b> 60	<b>Parameter Type:</b> Range (-1000 — 1000)	<b>Parameter Number:</b> 708
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.4.14 Preset Speed 7

**Description:** Set the value of the preset reference.

<b>Default Value:</b> 70	<b>Parameter Type:</b> Range (-1000 — 1000)	<b>Parameter Number:</b> 709
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.4.15 Preset Speed 8

**Description:** Set the value of the preset reference.

<b>Default Value:</b> 80	<b>Parameter Type:</b> Range (-1000 — 1000)	<b>Parameter Number:</b> 710
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.4.16 Preset Speed Reference Bit 0 Input

**Description:** Select the digital input used as bit 0 addressing the preset reference.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 711
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.8.4.17 Preset Speed Reference Bit 1 Input

**Description:** Select the digital input used as bit 1 for addressing the preset reference.



<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 712
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

P 5.8.4.18 Preset Speed Reference Bit 2 Input

**Description:** Select the digital input used as bit 2 for addressing the preset reference.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 713
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

P 5.8.4.19 Fieldbus Speed Reference Scale

**Description:** Set the fieldbus reference scale equal to 100% reference.

<b>Default Value:</b> 50	<b>Parameter Type:</b> Range (0 — 1000)	<b>Parameter Number:</b> 1723
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

P 5.8.4.21 Speed Ref. Filter Tc

**Description:** Set the time constant of the reference filter. Set to 0 disables the filter.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 1000)	<b>Parameter Number:</b> 1719
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

### 6.6.8.6 Reference Freeze (Menu Index 5.8.5)

Reference freeze overview

This feature provides the ability to freeze the active reference by a digital input to the actual output speed and to increase/decrease the reference by using 2 other digital inputs. Additionally, independent ramp times, delays, and speed steps can be configured.

When enabling the freeze reference feature the reference is frozen to the actual output. If this reference is out of the allowed speed range, the frozen reference is set to the closest speed limit. After starting up or after cycling the power of the drive the reference for the freeze feature is set to either the last freeze reference or to the minimum speed of the drive. See *parameter 5.8.5.7 Freeze Initialization (1006)*.

When reaching the upper speed limit or the lower speed limit of the drive, the freeze reference is not further increased or decreased in the limited direction. If the drive is configured for both rotation directions and a minimum speed has been parametrized, the reference bypasses the area between the positive and the negative minimum speed, while Freeze Up or Freeze Down are used.




Illustration 59: Reference Freeze (Example)

Table 30: Legend Description

Legend	Description
1	Freeze Up/Down Ramp Time
2	Freeze Up/Down Ramp Delay
3	Freeze Up/Down Step Delta

## P 5.8.5.1 Freeze Input

**Description:** Select the digital input for freezing the reference. Freezing is used to control the speed reference with 2 digital inputs, 1 increasing the reference and the other decreasing the reference.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1000
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## P 5.8.5.2 Freeze Up Input

**Description:** Select the digital input for increasing the reference while reference freezing is activated.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1001
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## P 5.8.5.3 Freeze Down Input

**Description:** Select the digital input for decreasing the reference while reference freezing is activated.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1002
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## P 5.8.5.4 Freeze Ramp Time

**Description:** Set the ramp time for increasing/decreasing the reference while reference freeze is active.

<b>Default Value:</b> 10	<b>Parameter Type:</b> Range (0 — 1000)	<b>Parameter Number:</b> 1003
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.5.5 Freeze Ramp Delay

**Description:** Set the delay before ramping the reference while reference freeze is active.

<b>Default Value:</b> 4	<b>Parameter Type:</b> Range (0 — 3600)	<b>Parameter Number:</b> 1004
<b>Unit:</b> s	<b>Data Type:</b> UDINT	<b>Access Type:</b> Read/Write

## P 5.8.5.6 Freeze Step Delta

**Description:** Set the reference step for increasing/decreasing the reference while reference freeze is active.

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (0 — 1000)	<b>Parameter Number:</b> 1005
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.5.7 Freeze Initialization

**Description:** Enables freeze initialization. If enabled, freeze reference is initialized to the minimum speed after start-up or a start signal is applied. If disabled, the latest value is used.

<b>Default Value:</b> 0 [Disabled]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1006
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Disabled
1	Enabled

#### P 5.8.5.8 Freeze Ramp/Step Mode

**Description:** Select how to increase or decrease the reference while reference freeze is active.

<b>Default Value:</b> 0 [Step and Ramp]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1007
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Step and Ramp
1	Ramp
2	Step

### 6.6.8.7 Speed Ramps (Menu Index 5.8.6)

These parameters allow the setting of speed ramps used during acceleration and deceleration.

#### 6.6.8.7.1 Speed Ramps Overview

##### Overview

Ramps are used for reaching the desired speed reference in a controlled manner. The parameters in *Speed Ramps* parameter group is used to select the ramp type and to adjust their shapes.

Ramps 1–4 can be configured as linear or S-ramps. A linear ramp provides the motor a constant acceleration. The S-ramp allows the drive to compensate for jerk in the application and/or to reduce sway.

The following diagram illustrates how the ramp parameters are used for adjusting the ramp profiles.




Illustration 60: Speed Ramps

Element	Description
1	Ramp acceleration time
2	Ramp deceleration time
3	Ramp acceleration increase time for S-ramps

Element	Description
4	Ramp acceleration decrease time for S-ramps
5	Ramp deceleration increase time for S-ramps
6	Ramp deceleration decrease time for S-ramps

Furthermore, the drive supports a variable ramp profile, which allows to change the acceleration time and the deceleration dynamically with analog inputs.

#### Speed Ramps Parameters

For information on speed ramps parameters, see [6.6.8.7 Speed Ramps \(Menu Index 5.8.6\)](#).

### 6.6.8.7.2 Speed Ramp Settings (Menu Index 5.8.6.1)

#### P 5.8.6.1.1 Ramp Selector

**Description:** Select the speed ramp.

<b>Default Value:</b> 0 [Ramp 1]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1100
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
4	Bit Selection
0	Ramp 1
1	Ramp 2
2	Ramp 3
3	Ramp 4
5	Variable Ramp.

#### P 5.8.6.1.2 Ramp Selection Bit 0 Input

**Description:** Select the digital input used as bit 0 addressing the speed ramp.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1130
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.8.6.1.3 Ramp Selection Bit 1 Input

**Description:** Select the digital input used as bit 1 addressing the speed ramp.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1131
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

### 6.6.8.7.3 Ramp 1 (Menu Index 5.8.6.2)

#### P 5.8.6.2.1 Ramp 1 Type

**Description:** Select the ramp type.

<b>Default Value:</b> 0 [Linear Ramp]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1125
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Linear Ramp
1	S-Ramp

## P 5.8.6.2.2 Ramp 1 Accel. Time

**Description:** Set the acceleration time from 0 to nominal motor speed.

<b>Default Value:</b> 5	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1101
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.6.2.3 Ramp 1 Decel. Time

**Description:** Set the deceleration time from nominal motor speed to 0.

<b>Default Value:</b> 5	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1105
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.6.2.4 S-Ramp 1 Accel. Increase Time

**Description:** Set the ramp acceleration increase time for S-ramp.

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1109
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.6.2.5 S-Ramp 1 Accel. Decrease Time

**Description:** Set the ramp acceleration decrease time for S-ramp.

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1113
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.6.2.6 S-Ramp 1 Decel. Increase Time

**Description:** Set the ramp deceleration increase time for S-ramp.

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1117
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.6.2.7 S-Ramp 1 Decel. Decrease Time

**Description:** Set the ramp deceleration decrease time for S-ramp.

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1121
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## 6.6.8.7.4 Ramp 2 (Menu Index 5.8.6.3)

## P 5.8.6.3.1 Ramp 2 Type

**Description:** Select the ramp type.

<b>Default Value:</b> 0 [Linear Ramp]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1126
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Linear Ramp
1	S-Ramp

## P 5.8.6.3.2 Ramp 2 Accel. Time

**Description:** Set the acceleration time from 0 to nominal motor speed.

<b>Default Value:</b> 5	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1106
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.6.3.3 Ramp 2 Decel. Time

**Description:** Set the deceleration time from nominal motor speed to 0.

<b>Default Value:</b> 5	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1102
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.6.3.4 S-Ramp 2 Accel. Increase Time

**Description:** Set the ramp acceleration increase time for S-ramp.

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1110
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.6.3.5 S-Ramp 2 Accel. Decrease Time

**Description:** Set the ramp acceleration decrease time for S-ramp.

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1114
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.6.3.6 S-Ramp 2 Decel. Increase Time

**Description:** Set the ramp deceleration increase time for S-ramp.

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1118
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.6.3.7 S-Ramp 2 Decel. Decrease Time

**Description:** Set the ramp deceleration decrease time for S-ramp.

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1122
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## 6.6.8.7.5 Ramp 3 (Menu Index 5.8.6.4)

## P 5.8.6.4.1 Ramp 3 Type

**Description:** Select the ramp type.

<b>Default Value:</b> 0 [Linear Ramp]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1127
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Linear Ramp
1	S-Ramp

## P 5.8.6.4.2 Ramp 3 Accel. Time

**Description:** Set the acceleration time from 0 to nominal motor speed.

<b>Default Value:</b> 5	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1103
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.6.4.3 Ramp 3 Decel. Time

**Description:** Set the deceleration time from nominal motor speed to 0.

<b>Default Value:</b> 5	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1107
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.6.4.4 S-Ramp 3 Accel. Increase Time

**Description:** Set the ramp acceleration increase time for S-ramp.

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1111
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.6.4.5 S-Ramp 3 Accel. Decrease Time

**Description:** Set the ramp acceleration decrease time for S-ramp.

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1115
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.6.4.6 S-Ramp 3 Decel. Increase Time

**Description:** Set the ramp deceleration increase time for S-ramp.

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1119
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.6.4.7 S-Ramp 3 Decel. Decrease Time

**Description:** Set the ramp deceleration decrease time for S-ramp.

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1123
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## 6.6.8.7.6 Ramp 4 (Menu Index 5.8.6.5)

## P 5.8.6.5.1 Ramp 4 Type

**Description:** Select the ramp type.

<b>Default Value:</b> 0 [Linear Ramp]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1128
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Linear Ramp
1	S-Ramp

## P 5.8.6.5.2 Ramp 4 Accel. Time

**Description:** Set the acceleration time from 0 to nominal motor speed.

<b>Default Value:</b> 5	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1104
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.6.5.3 Ramp 4 Decel. Time

**Description:** Set the deceleration time from nominal motor speed to 0.

<b>Default Value:</b> 5	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1108
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.6.5.4 S-Ramp 4 Accel. Increase Time

**Description:** Set the ramp acceleration increase time for S-ramp.

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1112
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.6.5.5 S-Ramp 4 Accel. Decrease Time

**Description:** Set the ramp acceleration decrease time for S-ramp.

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1116
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.6.5.6 S-Ramp 4 Decel. Increase Time

**Description:** Set the ramp deceleration increase time for S-ramp.

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1120
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.6.5.7 S-Ramp 4 Decel. Decrease Time

**Description:** Set the ramp deceleration decrease time for S-ramp.

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1124
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## 6.6.8.7.7 Variable Ramp (Menu Index 5.8.6.6)

## P 5.8.6.6.1 Accel. Time Input

**Description:** Select the input or a fixed value for adjusting the variable ramp acceleration time.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1132
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## P 5.8.6.6.2 Accel. Time Maximum

**Description:** Set the maximum of the acceleration time for the variable ramp.

<b>Default Value:</b> 120	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1134
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.6.6.3 Accel. Time Minimum

**Description:** Set the minimum of the acceleration time for the variable ramp.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1135
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.6.6.4 Decel. Time Input

**Description:** Select the input or a fixed value for adjusting the variable ramp deceleration time.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1133
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## P 5.8.6.6.5 Decel. Time Maximum

**Description:** Set the maximum of the deceleration time for the variable ramp.

<b>Default Value:</b> 120	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1136
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write



## P 5.8.6.6.6 Decel. Time Minimum

**Description:** Set the minimum of the deceleration time for the variable ramp.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1137
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## 6.6.8.8 Speed Feedback (Menu Index 5.8.7)

## P 5.8.7.1 Speed Feedback Filter Tc

**Description:** Set the speed feedback filter time constant (when the speed is controlled with speed sensor).

<b>Default Value:</b> 5.00	<b>Parameter Type:</b> Range (0.00 — 1000.00)	<b>Parameter Number:</b> 4544
<b>Unit:</b> ms	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.7.2 Estimated Speed Filter Tc

**Description:** Set the filter time constant for the estimated speed (when the speed is controlled without speed sensor).

<b>Default Value:</b> 10.00	<b>Parameter Type:</b> Range (5.00 — 10000.00)	<b>Parameter Number:</b> 4545
<b>Unit:</b> ms	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.7.3 Feedback Angle Offset

**Description:** Set the offset between permanent magnet (direct axis) angle and absolute feedback angle in the electrical domain. The offset value is summed with the feedback angle to attain the permanent magnet angle used in the control. Its correct setting is important when running FVC+ with synchronous motors in closed loop.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 360)	<b>Parameter Number:</b> 9017
<b>Unit:</b> °	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## 6.6.8.9 Speed Bypass (Menu Index 5.8.8)

## Speed bypass overview

Some systems call for some output frequencies to be avoided due to, for example, mechanical resonance problems. With the parameters of this group, a definition of the bandwidth around each of these parameters can be provided.

These parameters allow the setting of up to 4 speed bands that are avoided.

## P 5.8.8.1 Band 1, Low Limit

**Description:** Set the bypass hysteresis speed band, low limit.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 4520
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.8.2 Band 1, High Limit

**Description:** Set the bypass hysteresis speed band, high limit.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 4521
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.8.3 Band 2, Low Limit

**Description:** Set the bypass hysteresis speed band, low limit.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 4522
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.8.4 Band 2, High Limit

**Description:** Set the bypass hysteresis speed band, high limit.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 4523
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.8.5 Band 3, Low Limit

**Description:** Set the bypass hysteresis speed band, low limit.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 4524
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.8.6 Band 3, High Limit

**Description:** Set the bypass hysteresis speed band, high limit.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 4525
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.8.7 Band 4, Low Limit

**Description:** Set the bypass hysteresis speed band, low limit.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 4526
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.8.8 Band 4, High Limit

**Description:** Set the bypass hysteresis speed band, high limit.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 4527
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## 6.6.8.10 Load Drooping (Menu Index 5.8.9)

## P 5.8.9.1 Load Drooping Mode

**Description:** Select the load drooping mode - Only available in FVC+ mode.

<b>Default Value:</b> 0 [Static]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 670
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Static
1	Dynamic
2	Combined

## P 5.8.9.2 Load Drooping %

**Description:** Set the load drooping amount in % of nominal motor speed at nominal load conditions.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 1000)	<b>Parameter Number:</b> 671
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.9.3 Load Drooping LP Tc

**Description:** Set the load drooping low pass filter time constant.

<b>Default Value:</b> 5.00	<b>Parameter Type:</b> Range (0.00 — 1000.00)	<b>Parameter Number:</b> 672
<b>Unit:</b> ms	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.8.9.4 Load Drooping HP Tc

**Description:** Set the load drooping high pass filter time constant. Only active in dynamic drooping mode.

<b>Default Value:</b> 1000.00	<b>Parameter Type:</b> Range (0.00 — 100000.00)	<b>Parameter Number:</b> 673
<b>Unit:</b> ms	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.8.9.5 Drooping Removal Mode

**Description:** Select the drooping removal mode.

<b>Default Value:</b> 0 [Constant droop]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 4581
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Constant droop
1	Below removal frequency
2	Linear below nom. speed

#### P 5.8.9.6 Drooping Removal Transition Speed

**Description:** Set the drooping removal transition speed.

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (0.001 — 1000)	<b>Parameter Number:</b> 4582
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.8.9.15 Enhanced Static Part

**Description:** Set the % of static drooping at speeds lower than the value set in "5.8.9.16 Enhanced Lower Transition Speed". 0% means dynamic drooping only and 100% static drooping only.

<b>Default Value:</b> 1.5	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 675
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.8.9.16 Enhanced Lower Transition Speed

**Description:** Set the speed at which transition from combined static and dynamic drooping to dynamic drooping only starts.

<b>Default Value:</b> 589.999	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 676
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.8.9.17 Enhanced Higher Transition Speed

**Description:** Set the speed at which the transition from combined static and dynamic drooping to dynamic drooping only is complete.

<b>Default Value:</b> 590	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 677
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

### 6.6.8.11 Auto Tuning (Menu Index 5.8.11)

These parameters allow the activation and setting of the autotuning of the speed controller.

#### P 5.8.11.1 Speed Controller Auto Tuning

**Description:** Enables the auto tuning of the speed controller. Auto tuning is started when the value of the parameter "5.3.2.4 System Inertia" is changed and unequal to "0".

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 1)	<b>Parameter Number:</b> 4546
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Conditional Write

#### P 5.8.11.2 Auto Tuning Bandwidth

**Description:** Set the auto tuning bandwidth. A higher value leads to a faster response to speed or reference changes.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0 — 1000)	<b>Parameter Number:</b> 4547
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write


## P 5.8.11.3 System Friction

**Description:** Set the total system friction in % of the nominal motor torque at nominal motor speed.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 4548
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## 6.6.9 Torque control (Menu Index 5.9)

### 6.6.9.1 Torque Control Overview




e30bk11.6.11

Illustration 61: Reference Handling for Torque Control

While the drive is in torque control, motor speed is not controlled. Motor speed can reach speed limits, when the load application or upper system such as PLC system does not operate within the speed limits. If a speed limit is reached, the drive prevents itself from exceeding the limit depending on the selection in the parameter *Speed Limit Mode Torque Ctrl.*. Detailed descriptions of the selections available in parameter *Speed Limit Mode Torque Ctrl.*

**Pos./neg. frequency limit**


By default, the selection for the parameter *Speed Limit Mode Torque Ctrl* is *Pos./Neg. Frequency Limit*. While the drive is in torque control, the speed is not limited by the speed reference, only by the positive frequency limit and by the negative frequency limit.



**Illustration 62: Pos./Neg. Frequency Limit**

**Limited by ramp**

While the drive is in torque control, the speed is limited by the reference (after ramp). The speed increases with the set ramp time until actual torque is equal to the torque reference. If the speed is below the reference when load is removed from the shaft the speed increases without ramp.



**Illustration 63: Limited by Ramp**

**Neg. limit to ramp**

The torque controller operates in the range between the frequency limit for the negative direction and the speed limit given by the ramp.




Illustration 64: Neg. Limit to Ramp

Ramp to max. limit

The maximum of the speed controller output and the torque reference is selected as final torque reference. The torque controller operates in the range between the frequency limit for the positive direction and the speed limit given by the ramp.




Illustration 65: Ramp to Max. Limit

Window

Torque control is active within a speed window around the speed reference. Speed control activation limit is different from the speed limit. Therefore speed is required to reach first to upper or lower window limit before the speed controller activates.




Illustration 66: Window

6.6.9.2 Torque Control Status (Menu Index 5.9.1)

These parameters provide readouts of torque control related status information.

P 5.9.1.1 Motor Torque

**Description:** Shows the actual motor torque.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-10000000 — 10000000)	<b>Parameter Number:</b> 9009
<b>Unit:</b> Nm	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Depending on whether metric or imperial units are in use, give the value for the parameter in either newton meters (Nm) or pound-feet (lb ft). The value range is different with the different units.

## P 5.9.1.2 Relative Motor Torque

**Description:** Shows the motor torque in % of the nominal motor torque.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 1708
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 5.9.1.3 Torque Limit Motoring

**Description:** Shows the torque limit in motoring mode in % of nominal motor torque.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 500)	<b>Parameter Number:</b> 1812
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.9.1.4 Torque Limit Regenerative

**Description:** Shows the regenerative torque limit in % of nominal motor torque.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 500)	<b>Parameter Number:</b> 1813
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.9.1.5 Local Torque Reference

**Description:** Shows the local torque reference set in the control panel.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 6155
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.9.1.6 Torque Reference

**Description:** Shows the value of the current torque reference in the reference chain in % of nominal motor torque.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 6152
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.9.1.7 Torque Reference Final

**Description:** Shows the value of the final torque reference given to the motor controller in % of nominal motor torque.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 6154
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## 6.6.9.3 Limits (Menu Index 5.9.2)

## P 5.9.2.1 Positive Torque Limit

**Description:** Set the positive torque limit (quadrants 1 and 2) in % of nominal motor torque.

<b>Default Value:</b> 300	<b>Parameter Type:</b> Range (0 — 500)	<b>Parameter Number:</b> 1810
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.9.2.2 Negative Torque Limit

**Description:** Set the negative torque limit (quadrants 3 and 4) in % of nominal motor torque.

<b>Default Value:</b> -300	<b>Parameter Type:</b> Range (-500 — 0)	<b>Parameter Number:</b> 1811
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.9.2.3 Motoring Torque Limit

**Description:** Set the torque limit in motoring mode (quadrants 1 and 3) in % of nominal motor torque.

<b>Default Value:</b> 300	<b>Parameter Type:</b> Range (0 — 500)	<b>Parameter Number:</b> 1321
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write



## P 5.9.2.4 Regenerative Torque Limit

**Description:** Set the torque limit in regenerative mode (quadrants 2 and 4) in % of nominal motor torque.

<b>Default Value:</b> 300	<b>Parameter Type:</b> Range (0 — 500)	<b>Parameter Number:</b> 1323
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.9.2.5 Speed Limit Mode Torque Ctrl.

**Description:** Select the speed limiting mode during torque control.

<b>Default Value:</b> 0 [Pos./Neg. Speed Limit]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2332
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Conditional Write

The following are the selections for the parameter.

Selection number	Selection name
0	Pos./Neg. Speed Limit
1	Speed Limit Setpoint
2	Window around Speed Limit Setpoint

## P 5.9.2.6 Lower Window Limit

**Description:** Set the window size towards the positive speed direction.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 10)	<b>Parameter Number:</b> 2333
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.9.2.7 Upper Window Limit

**Description:** Set the window size towards the negative speed direction.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 10)	<b>Parameter Number:</b> 2334
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.9.2.26 Speed Limit Setpoint

**Description:** Set the variable speed limit setpoint in torque mode. This is used when fixed speed limits are not desired.

<b>Default Value:</b> 50	<b>Parameter Type:</b> Range (0 — 1000)	<b>Parameter Number:</b> 1336
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.9.2.27 Speed Limit Setpoint Ramp Time

**Description:** Set the speed limit setpoint ramp time. When running in speed limit in torque mode, the drive will accelerate/decelerate towards the speed limit setpoint using this ramp time.

<b>Default Value:</b> 5	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 1337
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.9.2.28 Motoring Torque Limit Scale Input

**Description:** Select the input for scaling motoring torque limit between 0% and 100% value defined in motoring torque limit. Off equals 100%.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1324
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## P 5.9.2.29 Regenerative Torque Limit Scale Input

**Description:** Select the input for scaling regenerative torque limit between 0% and 100% value defined in regenerative torque limit. Off equals 100%.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1326
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## P 5.9.2.30 Negative Torque Limit Scale Input

**Description:** Select the input for scaling negative torque limit between 0% and 100% value defined in negative torque limit. Off equals 100%.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1330
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## P 5.9.2.31 Positive Torque Limit Scale Input

**Description:** Select the input for scaling positive torque limit between 0% and 100% value defined in positive torque limit. Off equals 100%.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1333
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## P 5.9.2.32 Speed Limit setpoint Scale Input

**Description:** Select the input for scaling speed limit setpoint in torque mode between 0% and 100% of parameter value. Off equals 100%.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1334
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## P 5.9.2.33 Motoring Torque Limit Response

**Description:** Select the response for running in motoring torque limit after the time delay defined.

<b>Default Value:</b> 0 [No response]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2361
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	No response
1	Info
10	Fault

## P 5.9.2.34 Motoring Torque Limit Delay

**Description:** Set the delay the drive is allowed to be in motoring torque limit before a response is issued.

<b>Default Value:</b>	<b>Parameter Type:</b> Range (0 — 65000)	<b>Parameter Number:</b> 2358
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.9.2.35 Regenerative Torque Limit Response

**Description:** Select the response for running in regenerative torque limit after the time delay defined.

<b>Default Value:</b> 0 [No response]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2362
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	No response
1	Info
10	Fault

#### P 5.9.2.36 Regenerative Torque Limit Delay

**Description:** Set the delay the drive is allowed to be in regenerative torque limit before a response is issued.

<b>Default Value:</b>	<b>Parameter Type:</b> Range (0 — 65000)	<b>Parameter Number:</b> 2363
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

### 6.6.9.4 Torque Reference (Menu Index 5.9.3)

#### P 5.9.3.1 Torque Reference 1 Input

**Description:** Select the input terminal or a predefined fixed value for the torque reference.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 4534
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## NOTICE

Selection lists with inputs and/or outputs consist of the name of the hardware option and the numbers of the terminals. For example, terminal number 13 of the Basic I/O is named Basic I/O T13 in the selection list.

#### P 5.9.3.2 Torque Reference 2 Input

**Description:** Select the input terminal or a predefined fixed value for the torque reference.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 4535
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## NOTICE

Selection lists with inputs and/or outputs consist of the name of the hardware option and the numbers of the terminals. For example, terminal number 13 of the Basic I/O is named Basic I/O T13 in the selection list.

#### P 5.9.3.3 Torque Reference 1 Max.

**Description:** Set the maximum torque reference value in % of nominal motor torque.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 4530
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.9.3.4 Torque Reference 1 Min.

**Description:** Set the minimum torque reference value in % of nominal motor torque.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 4531
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.9.3.5 Torque Reference 2 Max.

**Description:** Set the maximum torque reference value in % of nominal motor torque.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 4532
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.9.3.6 Torque Reference 2 Min.

**Description:** Set the torque minimum reference value in % of nominal motor torque.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 4533
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.9.3.7 Preset Torque Selector

**Description:** Select the preset torque number.

<b>Default Value:</b> 1 [Preset 1]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 724
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Bit Selection
1	Preset 1
2	Preset 2
3	Preset 3
4	Preset 4

## P 5.9.3.8 Preset Torque 1

**Description:** Set the torque preset value in % of the nominal motor torque.

<b>Default Value:</b> 10	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 725
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.9.3.9 Preset Torque 2

**Description:** Set the torque preset value in % of the nominal motor torque.

<b>Default Value:</b> 25	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 726
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.9.3.10 Preset Torque 3

**Description:** Set the torque preset value in % of the nominal motor torque.

<b>Default Value:</b> 50	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 727
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.9.3.11 Preset Torque 4

**Description:** Set the torque preset value in % of the nominal motor torque.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 728
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.9.3.12 Preset Torque Bit 0 Input

**Description:** Select the digital input used as bit 0 addressing the preset reference.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 721
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

**NOTICE**

Selection lists with inputs and/or outputs consist of the name of the hardware option and the numbers of the terminals. For example, terminal number 13 of the Basic I/O is named Basic I/O T13 in the selection list.

**P 5.9.3.13 Preset Torque Bit 1 Input**

**Description:** Select the digital input used as bit 1 addressing the preset reference.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 722
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

**NOTICE**

Selection lists with inputs and/or outputs consist of the name of the hardware option and the numbers of the terminals. For example, terminal number 13 of the Basic I/O is named Basic I/O T13 in the selection list.

**P 5.9.3.14 Torque Reference Ramp Time**

**Description:** Set the ramping time from 0 to nominal motor torque.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 2330
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

**P 5.9.3.15 Torque Ref. Lowpass Filter Tc**


**Description:** Set the time constant of the reference filter. Setting it to 0 disables the filter.

<b>Default Value:</b> 0.00	<b>Parameter Type:</b> Range (0.00 — 1000000.00)	<b>Parameter Number:</b> 2335
<b>Unit:</b> ms	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

**6.6.10 Process Control (Menu Index 5.10)**

**6.6.10.1 Process Control Overview**

The process controller enables to maintain process parameters such as temperature, pressure, flow within a specified range or at a desired value. This is achieved by controlling the output frequency of the drive based on continuous measurement of the actual value of the process parameter (feedback) and the comparison of the process parameter with a setpoint.



**Illustration 67: Process Controller**

The embedded process controller features the following:

- Adjustable proportional gain, Integral time, and Derivative time
- Auto-tuning of the controller
- Bumpless operation
- 8 preset references
- 2 reference sources which can be combined
- Feed forward control
- Inverse control
- 2 feedback sources (analog inputs and fieldbus)

- Feedback calculations include sum, difference, average, minimum, and maximum
- Anti-windup
- Low-pass filtering of setpoint or feedback
- Status of the most important process parameters

### 6.6.10.2 Process Control Status (Menu Index 5.10.1)

#### P 5.10.1.1 On Reference

**Description:** Shows if the controlled process is operating on the current reference.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 1)	<b>Parameter Number:</b> 6074
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read Only

#### P 5.10.1.2 Process Controller Output

**Description:** Shows the process controller's output as normalized value (in the range 0 to 1).

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6075
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

#### P 5.10.1.3 Setpoint Value

**Description:** Shows the actual value of the setpoint.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6092
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.10.1.4 Feedback Value

**Description:** Shows the actual value of the feedback.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 6090
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.10.1.5 Adv. Feedforward Value

**Description:** Shows the actual value of the advanced feedforward.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6086
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.10.1.6 Feedback 1 Value

**Description:** Shows the actual value of feedback 1.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6080
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.10.1.7 Feedback 2 Value

**Description:** Shows the actual value of feedback 2.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6085
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.10.1.9 Control Panel Process Reference

**Description:** Shows the value of the process reference given from the control panel.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6094
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.10.1.10 Process Controller Enabled

**Description:** Enables the process controller.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 1)	<b>Parameter Number:</b> 6053
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

### 6.6.10.3 General Settings (Menu Index 5.10.2)

These parameters allow the setting of tolerance bands for the process controller.

#### P 5.10.2.1 On Reference Relative Tolerance

**Description:** Set the bandwidth for "On Reference" as % of the set point. If the control error is less than the defined percentage of the set point the "On Reference" flag is true. The tolerance used is the highest value of the absolute and relative reference.

<b>Default Value:</b> 0.01	<b>Parameter Type:</b> Range (0 — 1)	<b>Parameter Number:</b> 6050
<b>Unit:</b> PercentageFromFraction	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Set the parameter to allow to set a margin in process units, around the reference.

#### P 5.10.2.2 On Reference Absolute Tolerance

**Description:** Set the bandwidth for "On Reference" as an absolute value. If the control error is less than the defined percentage of the set point the "On Reference" flag is true. The tolerance used is the highest value of the absolute and relative reference.

<b>Default Value:</b> 0.01	<b>Parameter Type:</b> Range (0 — 100000)	<b>Parameter Number:</b> 6064
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

### 6.6.10.4 Process Reference (Menu Index 5.10.3)

#### P 5.10.3.1 Process Reference Max. Limit

**Description:** Set the maximum value of the reference. It defines the upper point for the limiting of the reference input.

<b>Default Value:</b> 10	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6013
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.10.3.2 Process Reference Min. Limit

**Description:** Set the minimum value of the reference. It defines the lower point for the limiting of the reference input.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6014
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.10.3.3 Process Reference 1 Input

**Description:** Select the input terminal or a predefined fixed value for the process reference.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 6025
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.10.3.4 Process Reference 2 Input

**Description:** Select the input terminal or a predefined fixed value for the the process reference.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 6026
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.10.3.5 Process Reference 1 Min.

**Description:** Set the minimum process reference for the input.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6047
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.10.3.6 Process Reference 1 Max.

**Description:** Set the maximum process reference for the input.

<b>Default Value:</b> 10	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6048
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.10.3.7 Process Reference 2 Min.

**Description:** Set the minimum process reference for the input.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6033
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.10.3.8 Process Reference 2 Max.

**Description:** Set the maximum process reference for the input.

<b>Default Value:</b> 10	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6029
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.10.3.9 Preset Process Reference Selector

**Description:** Select the preset reference. The preset reference can be selected as a fixed value or by 3 digital inputs.

<b>Default Value:</b> 1 [Preset 1]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 6032
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Bit Selection
1	Preset 1
2	Preset 2
3	Preset 3
4	Preset 4
5	Preset 5
6	Preset 6
7	Preset 7
8	Preset 8

## P 5.10.3.10 Preset Process Ref. Bit 0 Input

**Description:** Select the digital input used as bit 0 addressing the preset reference.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 6034
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## P 5.10.3.11 Preset Process Ref. Bit 1 Input

**Description:** Select the digital input used as bit 1 addressing the preset reference.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 6035
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## P 5.10.3.12 Preset Process Ref. Bit 2 Input

**Description:** Select the digital input used as bit 2 addressing the preset reference.



<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 6036
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## P 5.10.3.13 Preset Process Ref. 1

**Description:** Set the value of the preset reference.

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6037
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.10.3.14 Preset Process Ref. 2

**Description:** Set the value of the preset reference.

<b>Default Value:</b> 2	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6038
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.10.3.15 Preset Process Ref. 3

**Description:** Set the value of the preset reference.

<b>Default Value:</b> 3	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6039
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.10.3.16 Preset Process Ref. 4

**Description:** Set the value of the preset reference.

<b>Default Value:</b> 4	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6040
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.10.3.17 Preset Process Ref. 5

**Description:** Set the value of the preset reference.

<b>Default Value:</b> 5	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6041
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.10.3.18 Preset Process Ref. 6

**Description:** Set the value of the preset reference.

<b>Default Value:</b> 6	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6042
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.10.3.19 Preset Process Ref. 7

**Description:** Set the value of the preset reference.

<b>Default Value:</b> 7	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6043
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.10.3.20 Preset Process Ref. 8

**Description:** Set the value of the preset reference.

<b>Default Value:</b> 8	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6044
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.10.3.21 Process Ref. Ramp Rise Time

**Description:** Set the rising rate of the ramp for the setpoint.

<b>Default Value:</b> 10000	<b>Parameter Type:</b> Range (0 — 1000000)	<b>Parameter Number:</b> 6005
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.10.3.22 Process Ref. Ramp Fall Time

**Description:** Set the falling rate of the ramp for the setpoint.

<b>Default Value:</b> 10000	<b>Parameter Type:</b> Range (0 — 1000000)	<b>Parameter Number:</b> 6006
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Editing the setpoint falling time ramp defines the ramp-down time. The falling ramp for the setpoint is defined as slew rates which refers to process unit per time such as bar/s, °C/s. Setting the parameter to high values (compared to the dynamics of the requested setpoint) disables the ramp-down function.

#### P 5.10.3.23 Process Ref. Lowpass Filter Tc

**Description:** Set the time constant of the reference filter. Setting it to 0 disables the filter.

<b>Default Value:</b> 0.00	<b>Parameter Type:</b> Range (0.00 — 30000.00)	<b>Parameter Number:</b> 6083
<b>Unit:</b> ms	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.10.3.24 Process Controller Start Speed

**Description:** Set the start speed of the process controller.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (-1000 — 1000)	<b>Parameter Number:</b> 6056
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.10.3.26 Fieldbus Process Reference Scale

**Description:** Set the fieldbus reference scale equal to 100% reference.

<b>Default Value:</b> 10	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6030
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

### 6.6.10.5 Feedback (Menu Index 5.10.4)

These parameters allow setting of feedback handling like feedback source, scaling of feedback, conversion and finally filtering.

#### P 5.10.4.1 Feedback Mode

**Description:** Select the function to combine feedback 1 and feedback 2.

<b>Default Value:</b> 0 [Feedback 1]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 6008
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Feedback 1
1	Feedback 2
2	Sum
3	Difference
4	Average
5	Minimum
6	Maximum

## P 5.10.4.2 Feedback 1 Type

**Description:** Select the type of feedback.

<b>Default Value:</b> 1 [Analog Feedback Terminal]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 6021
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Feedback disabled
1	Analog Feedback Terminal
2	Fieldbus Feedback

## P 5.10.4.3 Feedback 1 Maximum Scaling

**Description:** Set the maximum scaling value of the feedback.

<b>Default Value:</b> 10	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6015
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.10.4.4 Feedback 1 Minimum Scaling

**Description:** Set the minimum scaling value of the feedback.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6016
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.10.4.5 Analog Input Feedback 1

**Description:** Select the input or a predefined fixed value for the feedback.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 6027
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## P 5.10.4.6 Feedback 1 Conversion

**Description:** Select a conversion function for the feedback.

<b>Default Value:</b> 0 [Linear]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 6009
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Linear
1	Quadratic

Square root is typically used in pump and fan applications, when converting pressure to flow while using pressure sensors.

## P 5.10.4.7 Feedback 2 Type

**Description:** Select the type of feedback.

<b>Default Value:</b> 0 [Feedback disabled]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 6022
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Feedback disabled
1	Analog Feedback Terminal
2	Fieldbus Feedback

#### P 5.10.4.8 Feedback 2 Maximum Scaling

**Description:** Set the maximum scaling value of the feedback.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6017
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.10.4.9 Feedback 2 Minimum Scaling

**Description:** Set the minimum scaling value of the feedback.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6018
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.10.4.10 Analog Input Feedback 2

**Description:** Set the input for the feedback.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 6028
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.10.4.11 Feedback 2 Conversion

**Description:** Select a conversion function for the feedback.

<b>Default Value:</b> 0 [Linear]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 6010
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Linear
1	Quadratic

#### P 5.10.4.17 Feedback Filter Tc

**Description:** Set the time constant of the feedback filter.

<b>Default Value:</b> 0.00	<b>Parameter Type:</b> Range (0.00 — 30000.00)	<b>Parameter Number:</b> 6084
<b>Unit:</b> ms	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

### 6.6.10.6 PID Controller (Menu Index 5.10.5)

These parameters allow the setting of PID Controller parameters and functionality. This group covers PID, antiwindup, and inversion of the PID controller.

#### P 5.10.5.1 Proportional Gain

**Description:** Set the proportional gain of the PID controller.

<b>Default Value:</b> 10	<b>Parameter Type:</b> Range (0 — 100000)	<b>Parameter Number:</b> 6065
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.10.5.2 Integral Time

**Description:** Set the integral time of the PID controller.

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (0 — 1000000)	<b>Parameter Number:</b> 6058
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.10.5.3 Integral Reset

**Description:** Resets the I-part of the PID controller. The selection automatically returns to false. Resetting the I-part makes it possible to start from a well-defined point after changing something in the process.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 1)	<b>Parameter Number:</b> 6060
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

#### P 5.10.5.4 Antiwindup Enabled

**Description:** Enables antiwindup which ceases the regulation of an error, when the minimum or maximum speed has been reached.

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (0 — 1)	<b>Parameter Number:</b> 6061
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

#### P 5.10.5.5 Derivative Time

**Description:** Set the derivative time of the PID controller. The differentiator does not react to a constant error, but provides a gain only when the error changes. The shorter the PID differentiation time, the stronger the gain from the differentiator. When set to 0 the derivative part is disabled.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 1000)	<b>Parameter Number:</b> 6068
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.10.5.6 Derivative Gain

**Description:** Set a limit for the differentiator gain. If there is no limit, the differentiator gain increases when there are fast changes. To obtain a pure differentiator gain at slow changes and a constant differentiator gain where fast changes occur, limit the differentiator gain.

<b>Default Value:</b> 5	<b>Parameter Type:</b> Range (1 — 100)	<b>Parameter Number:</b> 6069
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.10.5.7 PID Inverted

**Description:** Inverts the output of the PID controller.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 1)	<b>Parameter Number:</b> 6066
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

### 6.6.10.7 Feedforward Controller (Menu Index 5.10.6)

These parameters allow the setting of feedforward controller, the improves the response to setpoint settings.

#### P 5.10.6.1 Feedforward Factor

**Description:** Set the PID feedforward factor. The factor sends a constant fraction of the reference signal to bypass the PID control. The feedforward factor provides less overshoot and higher dynamics when the reference is changed.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 6063
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Feedforward is activated when setting a value higher than 0. Enter the value in percentage. The factor sends a constant fraction of the reference signal to bypass the PID control. When the feed forward factor is activated, the process control provides less overshoot and improves the control performance (better step response) incase of setpoint changes.

#### P 5.10.6.2 Adv. Feedforward Maximum

**Description:** Set the advanced feedforward scaling value that corresponds to the maximum value for its selected reference source.

<b>Default Value:</b> 10	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6011
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.10.6.3 Adv. Feedforward Minimum

**Description:** Set the advanced feedforward scaling value that corresponds to the minimum value for its selected reference source.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6012
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.10.6.4 Adv. Feedforward Ref. Mode

**Description:** Select the reference source for the advanced feedforward controller.

<b>Default Value:</b> 0 [None]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 6019
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
1	Reference 1 input
2	Reference 2 input
3	Analog Input Reference 1+2
4	Fieldbus Reference

## P 5.10.6.5 Adv. Feedforward AI 1 Ref.

**Description:** Select the input for the reference number 1 of the advanced feedforward controller.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 29999)	<b>Parameter Number:</b> 6023
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## P 5.10.6.6 Adv. Feedforward AI 2 Ref.

**Description:** Set the input for the reference number 2 of the advanced feedforward controller.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 29999)	<b>Parameter Number:</b> 6024
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## P 5.10.6.7 Adv. Feedforward Inverted

**Description:** Inverts the reaction of the advanced feedforward controller.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 1)	<b>Parameter Number:</b> 6073
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

## 6.6.10.8 Auto Tuning (Menu Index 5.10.7)

These parameters allow the activation and setting of the autotuning of the process controller.

## P 5.10.7.1 Process Controller Auto Tuning

**Description:** Enables the auto tuning procedure of the process controller. Requires start signal and returns to false after completion.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 1)	<b>Parameter Number:</b> 6901
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

0 indicates auto-tuning is disabled. To enable auto-tuning, set to 1. When auto tuning is enabled, the P, I, and D values are automatically set by the drive.

## P 5.10.7.2 Auto Tuning Reference

**Description:** Set the reference point where the auto tuning is executed. Values are entered in process units.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6902
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

### 6.6.11 Inching (Menu Index 5.11)

#### P 5.11.1 Inching Mode

**Description:** Select the inching mode. Inching is used for operating the motor for periods with a specific inching reference.

<b>Default Value:</b> 1 [Jogging Mode]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1081
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Slow Down Mode
1	Jogging Mode
2	Override Mode

#### P 5.11.2 Enable Inching Input

**Description:** Select a terminal to enable inching.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1080
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.11.3 Inching Ramp Time

**Description:** Set the ramp time for inching.

<b>Default Value:</b> 10	<b>Parameter Type:</b> Range (0.01 — 3600)	<b>Parameter Number:</b> 1083
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.11.4 Inching Reference 1

**Description:** Set reference 1 for inching.

<b>Default Value:</b> 15	<b>Parameter Type:</b> Range (-1000 — 1000)	<b>Parameter Number:</b> 1082
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.11.5 Inching Activate Input 1

**Description:** Select the terminal to inching with reference 1. Enable inching input must be active.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1084
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.11.6 Inching Reference 2

**Description:** Set reference 2 for inching.

<b>Default Value:</b> -15	<b>Parameter Type:</b> Range (-1000 — 1000)	<b>Parameter Number:</b> 1085
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.11.7 Inching Activate Input 2

**Description:** Select the terminal to inching with reference 2. Enable inching input must be active.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1086
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

#### P 5.11.8 Inching Active Output

**Description:** Select the output terminal or status bit indicating that inching is active.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1087
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

## 6.6.12 Mechanical Brake Control (Menu Index 5.12)

### 6.6.12.1 Mechanical Brake Control Overview

#### Overview

The feature controls opening and closing of the mechanical brake and ensures the smooth transition of load between drive and mechanical brake. The mechanical brake holds the load when the drive is not running. Mechanical brake can be closed or released by controlling the torque, speed, and position. The following load types are supported by the feature:

- **Unidirectional load:** Typically used in scenarios when the load moves in the same direction such as in conveyors, winches, crane applications.
- **Bidirectional load:** Typically used in scenarios when the direction of the load is not known during startup, such as in elevator applications.

The mechanical brake control supports the following function:

- 2 channels for mechanical braking feedback to offer further protection against unintended behavior resulting from broken cable.
- Monitoring of mechanical braking feedback throughout the complete cycle. This helps to protect the mechanical brake, especially if more drives are connected to the same shaft.
- No ramp-up until feedback confirms that mechanical brake is open.
- Improved load control at stop. If the value of the delay is too low, a warning is activated and the torque is not allowed to ramp down.
- The transition when motor takes over the load from the brake can be configured. Parameter Release Bandwidth can be increased to minimize the movement.
- To achieve smooth transition, change the setting from the speed control to the position control during the change over.

#### Starting with mechanical brake

- The motor must be primed by gradually applying a holding torque against the brake so that the torque step is minimized when the brake is released.
- When configured torque is applied and priming time has passed, brake is released. The torque and priming time is set via parameters *5.12.2.2 Brake Priming Torque* and *5.12.2.4 Brake Priming Time*. After priming, the brake is released.
- There is a physical delay between electrical release of brake and physical release of brake. This is referred to as brake release time and is set via the parameter *5.12.2.6 Brake Release Time*. When this happens, load is shifted from mechanical brake to the motor instantaneously.

#### Stopping with mechanical brake

- When stopping, the mechanical brake control monitors the motor speed and is ramping down to 0 speed, to close the brake.
- When closing speed is achieved, the brake is activated, and the motor is held at 0 speed while the brake physically closes.
- When closed, torque is ramped down to 0, thereby gradually shifting load from motor to brake.

The following image represents the different functions of Mechanical Brake Control.






Illustration 68: Mechanical Brake without Hovering




Illustration 69: Mechanical Brake Control with Hovering

The following are features of mechanical brake control:

- **Control:** Control brake via digital output and relay.
- **Optimization:** Automatically adapts to motor construction and control principle.
- **Feedback:** Supports digital brake feedback for open and closed loop which provides faster control and monitoring.
- User configuration of mechanical brake control via parameters.
  - Digital inputs for brake feedback
  - Timeouts for release and close when using brake feedback
  - Digital output/relay for mechanical brake
  - Timing and direction of applied torque for engaging or disengaging mechanical brake
  - Mechanical brake release and close time
  - Hover delay

- Brake close speed
- Priming timeout

## N O T I C E

Mechanical Brake Control requires operation in FVC+ in closed loop.

### 6.6.12.2 Mechanical Brake Control Status (Menu Index 5.12.1)

These parameters provide readouts of mechanical brake control status information.

#### P 5.12.1.1 Mechanical Brake Status Word

**Description:** Shows the mechanical brake status word.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 65535)	<b>Parameter Number:</b> 3016
<b>Unit:</b> -	<b>Data Type:</b> WORD	<b>Access Type:</b> Read Only

Following are the status words and its description:

Table 31: Status Word Description

Bit Number	Bit Name	Description
0	Enabled	Mechanical brake is enabled by a parameter.
1	Start	A start signal is provided to mechanical brake control.
2	Brake open feedback signal	Brake feedback is enabled and brake open is active.
3	Brake close feedback	Brake feedback is enabled and brake closed is active.
4-10	NA	
11	Priming Timeout	The required release torque could not be generated.
12	Brake release timeout	Feedback is enabled but brake open feedback was not provided during brake release time.
13	Brake close timeout	Feedback is enabled but brake close feedback was not provided during brake close time
14	BrakeCtrl active	Brake control is either in progress of opening or closing brake.
15	Brake open	Brake control has activated digital output.

#### P 5.12.1.2 Mechanical Brake State

**Description:** Shows the state of the mechanical brake controller.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 32767)	<b>Parameter Number:</b> 3017
<b>Unit:</b> -	<b>Data Type:</b> INT	<b>Access Type:</b> Read Only

#### P 5.12.1.3 Brake Release Time Detected

**Description:** Shows the time from brake release until load change is detected, where motor takes over the load from mechanical brake.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 3041
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

### 6.6.12.3 Brake Settings (Menu Index 5.12.2)

#### P 5.12.2.1 Brake Output

**Description:** Select the output terminal for controlling the mechanical brake.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 3007
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

0 Indicates that mechanical brake is disabled. Use the value 10105 to set the digital output, where 1 refers to the control card, 01 refers to the option, and 05 refers to the terminal number.

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

#### P 5.12.2.2 Brake Priming Torque

**Description:** Set the torque to be build up against the mechanical brake during priming before releasing the brake.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0 — 200)	<b>Parameter Number:</b> 3012
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

The value is set as percent of nominal torque. The value defines the torque applied against the closed mechanical brake before release. The torque/load on a crane is positive and is 10– 160%. To obtain the best starting point, set the parameter to approximately 70%. The torque/load on a lift can be both positive and negative and between -160% and +160%. To obtain the best starting point, set the parameter to 0%. The higher the torque error, the more movement during load takeover.

#### P 5.12.2.3 Brake Priming Direction

**Description:** Select the direction of the applied torque during priming before releasing the brake.

<b>Default Value:</b> 0 [Clockwise]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 3001
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Clockwise
1	Counter clockwise
2	Reference Direction

#### P 5.12.2.4 Brake Priming Time

**Description:** Set the priming time duration.

<b>Default Value:</b> 0.2	<b>Parameter Type:</b> Range (0 — 5)	<b>Parameter Number:</b> 3000
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

The value in the parameter defines the duration of the torque ramp up in clockwise direction. Torque is ramped up during this period of time.

#### P 5.12.2.5 Brake Priming Timeout

**Description:** Set the time after which a warning will be generated if priming cannot be finalized.

<b>Default Value:</b> 5	<b>Parameter Type:</b> Range (2 — 10)	<b>Parameter Number:</b> 3006
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 5.12.2.6 Brake Release Time

**Description:** Set the time it takes for the mechanical brake to open and to release the load.

<b>Default Value:</b> 0.5	<b>Parameter Type:</b> Range (0.1 — 30)	<b>Parameter Number:</b> 3003
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

The value in the parameter defines the time taken for the mechanical brake to open. The configuration in the parameter acts as a timeout when brake feedback is activated.

#### P 5.12.2.7 Brake Open Input

**Description:** Select the input terminal for an open indication signal from the mechanical brake.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 3010
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

#### P 5.12.2.8 Brake Hover Time

**Description:** Set the hover time. Hover time is the duration where the drive holds the load before the mechanical brake closes to allow an instant restart.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 60)	<b>Parameter Number:</b> 3013
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Defines the time at 0 speed. The value in the parameter defines the time interval from the moment when the motor is stopped until the brake closes. To adjust transition of the load to the mechanical braking, set both Brake Close Time and Hover Time parameters. This parameter is a part of the stop function.

#### P 5.12.2.9 Brake Closing Speed

**Description:** Set the speed at which the brake gets active (control terminal goes low).

<b>Default Value:</b> 5	<b>Parameter Type:</b> Range (0 — 25)	<b>Parameter Number:</b> 3002
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Using the parameter, set the motor speed for the activation of the mechanical brake when a stop condition is present.

#### P 5.12.2.10 Brake Close Time

**Description:** Set the time it takes for the mechanical brake to close and to hold the load.

<b>Default Value:</b> 0.5	<b>Parameter Type:</b> Range (0.1 — 30)	<b>Parameter Number:</b> 3004
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Defines the delay from electrical closing of brake to when the brake physically closes. When closing, the load is transferred from motor to mechanical brake during disengaging. Enter the brake close time of the coast after ramp-down time. The shaft is held at 0 speed with full holding torque. Ensure that the mechanical braking has locked the load before the motor enters coast mode. To adjust transition of the load to the mechanical braking, set parameters *5.12.2.10 Brake Close Time* and *5.12.2.8 Brake Hover Time*. Setting of brake delay parameters does not affect the torque. The drive does not register that mechanical braking is holding the load. After setting parameter *5.12.2.10 Brake Close Time*, the torque drops to 0 after a few minutes. The sudden torque change leads to movement and noise.

#### P 5.12.2.11 Brake Closed Input

**Description:** Select the input terminal for a closed signal from the mechanical brake.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 3011
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

#### P 5.12.2.12 Brake Disengaging Time

**Description:** Set the duration from the brake is closed to the holding torque is released.

<b>Default Value:</b> 0.2	<b>Parameter Type:</b> Range (0 — 5)	<b>Parameter Number:</b> 3005
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

The value configured in this parameter defines the torque ramp down time to gradually transition the load from the motor to the brake. After the mechanical brake is closed, the motor still provides a holding torque. During disengage, holding torque is ramped to zero, gradually transferring load to mechanical brake.

#### P 5.12.2.13 Brake Release Bandwidth

**Description:** Set the release control bandwidth.

<b>Default Value:</b> 100	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 3015
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

### P 5.12.2.15 Brake Close Immediately On Fault

**Description:** Enables immediate brake closure in case of a fault. Some faults will ramp to zero - if not set brake will wait for speed to be low enough.

<b>Default Value:</b> 1 [Enabled]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 3040
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Disabled
1	Enabled

## 6.6.13 Additional Status Outputs (Menu Index 5.26)

These parameters allow the setting of dedicated outputs to indicate various drive status information.

### 6.6.13.1 General Digital Outputs (Menu Index 5.26.1)

#### P 5.26.1.1 Ready Output

**Description:** Select an output to indicate that the unit is in ready mode.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 205
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.26.1.2 Run Output

**Description:** Select an output to indicate that the unit is in run mode.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 206
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.26.1.3 On Reference Output

**Description:** Select an output to indicate that the unit is on reference.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 207
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.26.1.4 Fault Event Output

**Description:** Select an output to indicate that a fault has occurred.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 208
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.26.1.5 Warning Event Output

**Description:** Select an output to indicate that a warning has occurred.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 209
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

#### P 5.26.1.26 Motor Disconnected Output

**Description:** Select an output to indicate that the motor is disconnected. Motor check must be enabled in disconnected motor response.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 216
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## 6.6.14 Fieldbus Process Data (Menu Index 5.27)

These parameters allow access to various fieldbus process data information.

### 6.6.14.1 Fieldbus Process Data Status (Menu Index 5.27.1)

#### P 5.27.1.42 Fieldbus Control Word

**Description:** Shows the profile specific fieldbus control word.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 1335
<b>Unit:</b> -	<b>Data Type:</b> WORD	<b>Access Type:</b> Read/Write

The fieldbus control word is either the PROFIdrive control word described in [2.3 PROFIdrive – Standard Telegram 1](#) or the iC Speed control word described in [2.4 iC Speed Profile](#). The fieldbus profile is selected with *parameter 10.3.1.2 Fieldbus Profile*.

#### P 5.27.1.43 Fieldbus Speed Reference 1

**Description:** Shows the fieldbus speed reference.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-32768 — 32767)	<b>Parameter Number:</b> 1339
<b>Unit:</b> -	<b>Data Type:</b> INT	<b>Access Type:</b> Read/Write

#### P 5.27.1.44 Fieldbus Torque Reference

**Description:** Shows the fieldbus torque reference.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-32768 — 32767)	<b>Parameter Number:</b> 1343
<b>Unit:</b> -	<b>Data Type:</b> INT	<b>Access Type:</b> Read/Write

#### P 5.27.1.50 Fieldbus Status Word

**Description:** Shows the profile specific fieldbus status word.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 65535)	<b>Parameter Number:</b> 1307
<b>Unit:</b> -	<b>Data Type:</b> WORD	<b>Access Type:</b> Read Only

The fieldbus status word is either the PROFIdrive status word described in [2.3 PROFIdrive – Standard Telegram 1](#) or the iC Speed status word described in [2.4 iC Speed Profile](#). The fieldbus profile is selected with *parameter 10.3.1.2 Fieldbus Profile*.

#### P 5.27.1.51 Fieldbus Speed Main Actual Value

**Description:** Shows the actual motor speed.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-32768 — 32767)	<b>Parameter Number:</b> 1308
<b>Unit:</b> -	<b>Data Type:</b> INT	<b>Access Type:</b> Read Only

#### P 5.27.1.54 Fieldbus Speed Reference

**Description:** Shows the fieldbus speed reference.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-1000 — 1000)	<b>Parameter Number:</b> 1345
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.27.1.73 Fieldbus Torque Main Actual Value

**Description:** Shows the torque applied by the motor.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-32768 — 32767)	<b>Parameter Number:</b> 1346
<b>Unit:</b> -	<b>Data Type:</b> INT	<b>Access Type:</b> Read/Write

Depending on whether metric or imperial units are in use, give the value for the parameter in either newton meters (Nm) or pound-feet (lb ft). The value range is different with the different units.

#### P 5.27.1.89 Fieldbus Control Word 2

**Description:** Shows the fieldbus control word 2.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 1347
<b>Unit:</b> -	<b>Data Type:</b> WORD	<b>Access Type:</b> Read/Write

The fieldbus control and status words are freely configurable, and specific features can be assigned to the bits.

#### P 5.27.1.90 Fieldbus Status Word 2

**Description:** Shows the profile specific fieldbus status word 2.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 65535)	<b>Parameter Number:</b> 1344
<b>Unit:</b> -	<b>Data Type:</b> WORD	<b>Access Type:</b> Read Only

The fieldbus control and status words are freely configurable, and specific features can be assigned to the bits.

#### P 5.27.1.100 Fieldbus Process Reference

**Description:** Shows the fieldbus process reference used in the process controller.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (-32768 — 32767)	<b>Parameter Number:</b> 6046
<b>Unit:</b> -	<b>Data Type:</b> INT	<b>Access Type:</b> Read/Write

## 6.7 Maintenance & Service (Menu Index 6)

This parameter group contains parameters exclusively related to status, events, and backup and restore.

### 6.7.1 Status (Menu Index 6.1)

#### 6.7.1.1 Grid Status (Menu Index 1.1)

These parameters provide status readouts of grid related information.

##### P 1.1.1 Grid Frequency

**Description:** Shows the actual grid frequency.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 9041
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

##### P 1.1.2 Line-To-Line Voltage (RMS)

**Description:** Shows the average line-to-line voltage (RMS).

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9040
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

##### P 1.1.3 L1-L2 Line Voltage (RMS)

**Description:** Shows the L1-L2 line voltage (RMS).

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9048
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

##### P 1.1.4 L2-L3 Line Voltage (RMS)

**Description:** Shows the L2-L3 line voltage (RMS).

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9049
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

##### P 1.1.5 L3-L1 Line Voltage (RMS)

**Description:** Shows the L3-L1 line voltage (RMS).

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9050
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 1.1.6 Grid Voltage Imbalance

**Description:** Shows the grid voltage imbalance in %. A value greater than 3% may indicate grid problems.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 9047
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 1.1.7 Total Harmonic Distortion (THDv)

**Description:** Shows the total harmonic distortion of the grid voltage (THDv) in %.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 9046
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 1.1.12 Grid Active Power

**Description:** Shows the active power at the point of grid connection.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 9064
<b>Unit:</b> kW	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## 6.7.1.2 Power Conversion &amp; DC Link Status (Menu Index 2.1)

These parameters provide status readouts of power unit related information.

## P 2.1.1 Unit Nominal Voltage

**Description:** Shows the nominal voltage setting as a result of the setting of parameter "2.2.1.1 Unit Voltage Class".

<b>Default Value:</b> 400	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 2830
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 2.1.2 Unit Nominal Current

**Description:** Shows the nominal current of the unit.

<b>Default Value:</b> 23	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 2831
<b>Unit:</b> A	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 2.1.3 DC-link Voltage

**Description:** Shows the actual DC-link voltage.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9044
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 2.1.7 DC-link Power

**Description:** Shows the actual DC-link power.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 5117
<b>Unit:</b> kW	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 2.1.10 U-phase RMS Current

**Description:** Shows the U-phase RMS current.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9020
<b>Unit:</b> A	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 2.1.11 V-phase RMS Current

**Description:** Shows the V-phase RMS current.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9021
<b>Unit:</b> A	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only



## P 2.1.12 W-phase RMS Current

**Description:** Shows the W-phase RMS current.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9022
<b>Unit:</b> A	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 2.1.14 Actual Relative Output Current Limit

**Description:** Shows the actual output current limit relative to the nominal motor current.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 300)	<b>Parameter Number:</b> 2700
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 2.1.15 Heat Sink Temperature

**Description:** Shows the temperature of the power unit heat sink.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-50 — 200)	<b>Parameter Number:</b> 2950
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

## P 2.1.16 Main Fan Speed

**Description:** Shows the speed of the main cooling fan.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 32767)	<b>Parameter Number:</b> 2931
<b>Unit:</b> rpm	<b>Data Type:</b> INT	<b>Access Type:</b> Read Only

## P 2.1.17 Internal Fan Speed

**Description:** Shows the speed of the internal cooling fan.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 32767)	<b>Parameter Number:</b> 2926
<b>Unit:</b> rpm	<b>Data Type:</b> INT	<b>Access Type:</b> Read Only

## P 2.1.19 Heat Sink Temperature Output

**Description:** Select the output indicating if the heat sink temperature is within range.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2312
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

## P 2.1.20 Drive DC-link Voltage Output

**Description:** Select the output indicating if the DC-link voltage is within range.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2311
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

## 6.7.1.3 Filters &amp; Brake Chopper Status (Menu Index 3.1)

## P 3.1.1 Brake Power

**Description:** Shows the power dissipated in the brake resistor.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0.00 — \*)	<b>Parameter Number:</b> 2933
<b>Unit:</b> kW	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 3.1.2 Average Brake Power

**Description:** Shows the average power dissipated in the brake resistor, calculated over 120 s.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0.00 — \*)	<b>Parameter Number:</b> 2934
<b>Unit:</b> kW	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

### P 3.1.3 AHF Capacitor Connected

**Description:** Shows if the advanced harmonic filter (AHF) capacitor is connected.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 1)	<b>Parameter Number:</b> 5410
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read Only

## 6.7.1.4 Motor Status (Menu Index 4.1)

These parameters provide status readouts of motor related information.

### P 4.1.1 Motor Current

**Description:** Shows the actual motor current.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9000
<b>Unit:</b> A	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

### P 4.1.2 Relative Motor Current

**Description:** Shows the actual motor current in % of the nominal motor current.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 200)	<b>Parameter Number:</b> 9001
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

### P 4.1.3 U-phase RMS Current

**Description:** Shows the U-phase RMS current.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9020
<b>Unit:</b> A	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

### P 4.1.4 V-phase RMS Current

**Description:** Shows the V-phase RMS current.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9021
<b>Unit:</b> A	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

### P 4.1.5 W-phase RMS Current

**Description:** Shows the W-phase RMS current.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9022
<b>Unit:</b> A	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

### P 4.1.6 Motor Voltage

**Description:** Shows the actual motor voltage.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — \*)	<b>Parameter Number:</b> 9005
<b>Unit:</b> V	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

### P 4.1.7 Relative Motor Voltage

**Description:** Shows the actual motor voltage in % of the nominal motor voltage.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 200)	<b>Parameter Number:</b> 9006
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

### P 4.1.11 Motor Torque

**Description:** Shows the actual motor torque.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-10000000 — 10000000)	<b>Parameter Number:</b> 9009
<b>Unit:</b> Nm	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Depending on whether metric or imperial units are in use, give the value for the parameter in either newton meters (Nm) or pound-feet (lb ft). The value range is different with the different units.

#### P 4.1.12 Relative Motor Torque

**Description:** Shows the motor torque in % of the nominal motor torque.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 1708
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

#### P 4.1.13 Motor Shaft Power

**Description:** Shows the actual power at the motor shaft.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 9008
<b>Unit:</b> kW	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Depending on whether metric or imperial units are in use, give the value for the parameter in either kilowatt (kW) or horsepower (HP). The value range is different with the different units.

#### P 4.1.14 Relative Motor Shaft Power

**Description:** Shows the actual motor shaft power in % of the nominal motor shaft power.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 1707
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

#### P 4.1.15 Motor Electrical Power

**Description:** Shows the actual motor power.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 9043
<b>Unit:</b> kW	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

#### P 4.1.16 Motor Thermal Load (ETR)

**Description:** Shows the estimated thermal load of the motor calculated by the ETR function.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 2951
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

#### P 4.1.17 Motor Current Output

**Description:** Select an output for the motor current signal. The scale of the signal is 0–100% of the nominal current.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2302
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

#### P 4.1.18 Motor Voltage Output

**Description:** Select an output for the motor voltage signal. The scale of the signal is 0–100% of the nominal voltage.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2303
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

#### P 4.1.19 Absolute Motor Torque Output

**Description:** Select an output for the motor torque signal. The scale of the signal is 0–100% of the absolute value of the nominal torque.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2306
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

#### P 4.1.20 Extended Motor Torque Output

**Description:** Select an output for the motor torque signal. The scale of the signal is -200...200% of the nominal torque.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2310
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

#### P 4.1.21 Absolute Motor Speed Output

**Description:** Select an output for the motor speed signal. The scale of the signal is 0–100% of the absolute value of the nominal speed.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2301
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

#### P 4.1.22 Extended Motor Speed Output

**Description:** Select an output for the motor speed signal. The scale of the signal is -200...200% of the nominal speed.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2309
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

#### P 4.1.23 Motor Power Output

**Description:** Select an output for the motor power signal. The scale of the signal is 0–100% of the nominal power.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2305
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

#### P 4.1.24 AMA Progress

**Description:** Shows the progress of the Automatic Motor Adaptation (AMA).

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 100)	<b>Parameter Number:</b> 429
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

### 6.7.1.5 Application Status (Menu Index 5.1)

#### P 5.1.1 Motor Ctrl. Status Word

**Description:** Shows the motor control status word.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 65535)	<b>Parameter Number:</b> 1714
<b>Unit:</b> -	<b>Data Type:</b> WORD	<b>Access Type:</b> Read Only

The following are the bit descriptions.

Bit	Description
0	Ready
1	Run
2	Reverse

Bit	Description
3	Fault
4	Reserved
5	At reference
6	Zero speed
7	Protection mode active

### P 5.1.2 Motor Ctrl. Ready Status Word

**Description:** Shows the motor control ready status word. All status bits must be true before the drive is ready.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 65535)	<b>Parameter Number:</b> 1716
<b>Unit:</b> -	<b>Data Type:</b> WORD	<b>Access Type:</b> Read Only

The *5302 Start Blocked* event is shown if this word is not ready.

The following are the bit descriptions.

Bit	Description
0	Run Enable high.
1	No fault active.
2	DC-link precharging done.
3	DC Voltage within limits.
4	Power manager initialized.
5	Brake test not running.
6	System software is not blocking start.
7	Grid voltage within limits.
8	Temperature within limits.
9	Valid motor data.
10	Valid control configuration.

### P 5.1.3 Motor Regulator Status Word

**Description:** Shows the current state of the motor regulator status word. The status word indicates if a limit controller is active.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 65535)	<b>Parameter Number:</b> 1715
<b>Unit:</b> -	<b>Data Type:</b> WORD	<b>Access Type:</b> Read Only

The following are the bit descriptions.

Bit	Description
0	Current limit control active (motoring side).
1	Current limit control active (generator side).
2	Torque limit control active (motoring side).
3	Torque limit control active (generator side).

Bit	Description
4	Overvoltage control active.
5	Undervoltage control active.
6	Power limit control active (motoring side).
7	Power limit control active (generator side).
8	Speed limit control active.
9	AC-brake control active.

## P 5.1.5 Fault Status Word 1

**Description:** Shows the fault status word 1.

<b>Default Value:</b> -	<b>Parameter Type:</b>	<b>Parameter Number:</b> 6203
<b>Unit:</b>	<b>Data Type:</b> DWORD	<b>Access Type:</b> -

The following are the bit descriptions.

Bit	Description	Event number
0	Overcurrent	4384, 4373, 5170, 4368, 4369, 4375, 4377, 4380, 4097
1	Overvoltage	4164, 4162, 4144 4145
2	Undervoltage	4165, 4146
3	Unit temperature high	4117, 4118, 4119
4	Unit temperature low	4116
5	Control board overtemperature	4121, 4122, 4123, 4120
6	Input phase	4160, 4163
7	Output phase	4175, 4176
8	Ground fault	4379, 4352, 4353, 4354, 4355
9	Fan failure	4128, 4129, 4133, 4130
10	Fieldbus communication	5162, 4256, 4257, 4258, 4260, 4261, 4263, 4265, 4266, 4267, 4268, 4269, 4280, 4281, 4270, 4271, 4272, 4273, 4282, 4274, 4275, 4276, 4277, 4283, 4278, 4279
11	HMI connection	5141, 5142
12	Feedback connection	4418
13	Thermistor input	5157
14	Auxiliary device (temperature)	4200, 4201, 4203, 4202
15	External temperature measurement	5132, 5133, 5134, 5135, 5136, 5137, 5158

## P 5.1.8 Warning Status Word 1

**Description:** Shows the warning status word 1.

<b>Default Value:</b> -	<b>Parameter Type:</b>	<b>Parameter Number:</b> 6205
<b>Unit:</b>	<b>Data Type:</b> DWORD	<b>Access Type:</b> -

The following are the bit descriptions.

Bit	Description	Event number
0	Overcurrent	4384, 4373, 5170, 4368, 4369, 4375, 4377, 4380, 4097
1	Overvoltage	4164, 4162, 4144 4145
2	Undervoltage	4165, 4146
3	Unit temperature high	4117, 4118, 4119
4	Unit temperature low	4116
5	Control board overtemperature	4121, 4122, 4123, 4120
6	Input phase	4160, 4163
7	Output phase	4175, 4176
8	Ground fault	4379, 4352, 4353, 4354, 4355
9	Fan failure	4128, 4129, 4133, 4130
10	Fieldbus communication	5162, 4256, 4257, 4258, 4260, 4261, 4263, 4265, 4266, 4267, 4268, 4269, 4280, 4281, 4270, 4271, 4272, 4273, 4282, 4274, 4275, 4276, 4277, 4283, 4278, 4279
11	HMI connection	5141, 5142
12	Feedback connection	4418
13	Thermistor input	5157
14	Auxiliary device (temperature)	4200, 4201, 4203, 4202
15	External temperature measurement	5132, 5133, 5134, 5135, 5136, 5137, 5158

#### P 5.1.13 Application Status Word

**Description:** Shows the application-specific status word.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 65535)	<b>Parameter Number:</b> 1608
<b>Unit:</b> -	<b>Data Type:</b> WORD	<b>Access Type:</b> Read Only

Following are the bits and description.

Bit	Bit = False	Bit = True
0	Reserved	Reserved
1	Inching not Active	Inching Active
2	Process Control not Active	Process Control Active
3	Reserved	Reserved
4	Reserved	Reserved
5	Reserved	Reserved
6	Reserved	Reserved
7	Reserved	Reserved
8	Reserved	Reserved
9	Reserved	Reserved

Bit	Bit = False	Bit = True
10	Reserved	Reserved
11	Reserved	Reserved
12	Reserved	Reserved
13	Normal Reference	Freeze Reference
14	Normal Reference	Reverse Reference
15	Speed Within Limits	Speed Limit Active

### 6.7.1.6 Measured Temp. Protection Status (Menu Index 5.2.3.1)

These parameters provide readouts of the temperature measured by the connected temperature sensors.

#### P 5.2.3.1.1 Protection 1 Temp.

**Description:** Shows the temperature measured for the temperature protection.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 5200
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

#### P 5.2.3.1.2 Protection 2 Temp.

**Description:** Shows the temperature measured for the temperature protection.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 5201
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

#### P 5.2.3.1.3 Protection 3 Temp.

**Description:** Shows the temperature measured for the temperature protection.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 5202
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

#### P 5.2.3.1.4 Protection 4 Temp.

**Description:** Shows the temperature measured for the temperature protection.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 5203
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

#### P 5.2.3.1.5 Protection 5 Temp.

**Description:** Shows the temperature measured for the temperature protection.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 5204
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.



## P 5.2.3.1.6 Protection 6 Temp.

**Description:** Shows the temperature measured for the temperature protection.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 5205
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Depending on whether metric or imperial units are in use, give the value for the parameter in either Celsius (C) or Fahrenheit (F). The value range is different with the different units.

## 6.7.1.7 Load Status (Menu Index 5.3.1)

## P 5.3.1.1 Inertia Estimation Status

**Description:** Shows the status of the inertia estimation routine. 0 = Inactive, 1 = In progress, 2 = Completed successfully, 3 = Completed unsuccessfully.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 666
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read Only

The following are the selections for the parameter.

Selection number	Selection name
0	Inactive
1	In progress
2	Completed successfully
3	Completed unsuccessfully

## 6.7.1.8 Control Places Status (Menu Index 5.5.1)

## P 5.5.1.1 Active Control Place

**Description:** Shows the control place that controls the drive.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 113
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read Only

The following are the selections for the parameter.

Selection number	Selection name
0	PC control
1	Local control
2	Fieldbus control
3	I/O control
4	Advanced control

## P 5.5.1.2 Local Control Active Output

**Description:** Select an output terminal indicating that the drive is in local control.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 5178
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## P 5.5.1.3 Fieldbus Control Active Output

**Description:** Select an output terminal indicating that the drive is in fieldbus control.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 5197
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## P 5.5.1.4 I/O Control Active Output

**Description:** Select an output terminal indicating that the drive is in I/O control.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 5177
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## P 5.5.1.5 Advanced Control Active Output

**Description:** Select an output terminal indicating that the drive is in advanced control.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 4727
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## 6.7.1.9 Speed Control Status (Menu Index 5.8.1)

These parameters provide a readout of speed control related status information.

## P 5.8.1.2 Motor Speed

**Description:** Shows the actual motor speed.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 9011
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Default unit: RPM. The unit can be changed with parameter 4321.

## P 5.8.1.3 Output Frequency

**Description:** Shows the output frequency.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 9015
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 5.8.1.4 Feedback Speed

**Description:** Shows the feedback speed.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-10000 — 10000)	<b>Parameter Number:</b> 9007
<b>Unit:</b> rpm	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 5.8.1.5 Feedback Electrical Angle

**Description:** Shows the feedback device angle in the electrical domain. Its value is needed for manually tuning the feedback angle offset.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 360)	<b>Parameter Number:</b> 9016
<b>Unit:</b> °	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 5.8.1.6 Speed Error

**Description:** Shows the difference between speed reference after ramp and motor speed.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 4023
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Default unit: RPM. The unit can be changed with parameter 4321.

## P 5.8.1.7 Speed Reference

**Description:** Shows the speed reference.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-2000 — 2000)	<b>Parameter Number:</b> 1718
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.1.8 Speed Reference Before Ramp

**Description:** Shows the value of speed reference before the ramp generator.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-2000 — 2000)	<b>Parameter Number:</b> 6049
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.1.9 Speed Reference After Ramp

**Description:** Shows the value of the speed reference after the ramp generator.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 6150
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.1.10 Final Speed Reference

**Description:** Shows the value of the speed reference before feeding it to the speed controller.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 6151
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.1.11 Control Panel Speed Reference

**Description:** Shows the value of the speed reference given from the control panel.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 6153
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.8.1.12 Absolute Output Frequency Output

**Description:** Select an output terminal for the output frequency scaled between 0 Hz and positive speed limits in Hz.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2300
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## NOTICE

Selection lists with inputs and/or outputs consist of the name of the hardware option and the numbers of the terminals. For example, terminal number 13 of the Basic I/O is named as Basic I/O T13, in the selection list.

#### P 5.8.1.13 Absolute Speed Reference Output

**Description:** Select an output terminal for the absolute speed reference, scaled between 0 and positive speed limit.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2304
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## NOTICE

Selection lists with inputs and/or outputs consist of the name of the hardware option and the numbers of the terminals. For example, terminal number 13 of the Basic I/O is named as as Basic I/O T13, in the selection list.

## P 5.8.1.14 Output Frequency Output

**Description:** Select an output terminal for the output frequency scaled between minimum speed limit and positive speed limits in Hz.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2308
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

### N O T I C E

Selection lists with inputs and/or outputs consist of the name of the hardware option and the numbers of the terminals. For example, terminal number 13 of the Basic I/O is named as Basic I/O T13, in the selection list.

## P 5.8.1.16 Load Drooping Speed

**Description:** Shows the load drooping speed.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 2000)	<b>Parameter Number:</b> 674
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Default unit: RPM. The unit can be changed with parameter 4321.

## 6.7.1.10 Torque Control Status (Menu Index 5.9.1)

These parameters provide readouts of torque control related status information.

## P 5.9.1.1 Motor Torque

**Description:** Shows the actual motor torque.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-10000000 — 10000000)	<b>Parameter Number:</b> 9009
<b>Unit:</b> Nm	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

Depending on whether metric or imperial units are in use, give the value for the parameter in either newton meters (Nm) or pound-feet (lb ft). The value range is different with the different units.

## P 5.9.1.2 Relative Motor Torque

**Description:** Shows the motor torque in % of the nominal motor torque.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 1708
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 5.9.1.3 Torque Limit Motoring

**Description:** Shows the torque limit in motoring mode in % of nominal motor torque.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 500)	<b>Parameter Number:</b> 1812
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.9.1.4 Torque Limit Regenerative

**Description:** Shows the regenerative torque limit in % of nominal motor torque.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 500)	<b>Parameter Number:</b> 1813
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.9.1.5 Local Torque Reference

**Description:** Shows the local torque reference set in the control panel.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 6155
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.9.1.6 Torque Reference

**Description:** Shows the value of the current torque reference in the reference chain in % of nominal motor torque.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 6152
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.9.1.7 Torque Reference Final

**Description:** Shows the value of the final torque reference given to the motor controller in % of nominal motor torque.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-300 — 300)	<b>Parameter Number:</b> 6154
<b>Unit:</b> %	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## 6.7.1.11 Process Control Status (Menu Index 5.10.1)

## P 5.10.1.1 On Reference

**Description:** Shows if the controlled process is operating on the current reference.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 1)	<b>Parameter Number:</b> 6074
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read Only

## P 5.10.1.2 Process Controller Output

**Description:** Shows the process controller's output as normalized value (in the range 0 to 1).

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6075
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## P 5.10.1.3 Setpoint Value

**Description:** Shows the actual value of the setpoint.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6092
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.10.1.4 Feedback Value

**Description:** Shows the actual value of the feedback.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 6090
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.10.1.5 Adv. Feedforward Value

**Description:** Shows the actual value of the advanced feedforward.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6086
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.10.1.6 Feedback 1 Value

**Description:** Shows the actual value of feedback 1.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6080
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.10.1.7 Feedback 2 Value

**Description:** Shows the actual value of feedback 2.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6085
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.10.1.9 Control Panel Process Reference

**Description:** Shows the value of the process reference given from the control panel.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-1000000 — 1000000)	<b>Parameter Number:</b> 6094
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 5.10.1.10 Process Controller Enabled

**Description:** Enables the process controller.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 1)	<b>Parameter Number:</b> 6053
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

## 6.7.1.12 Mechanical Brake Control Status (Menu Index 5.12.1)

These parameters provide readouts of mechanical brake control status information.

## P 5.12.1.1 Mechanical Brake Status Word

**Description:** Shows the mechanical brake status word.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 65535)	<b>Parameter Number:</b> 3016
<b>Unit:</b> -	<b>Data Type:</b> WORD	<b>Access Type:</b> Read Only

Following are the status words and its description:

Table 32: Status Word Description

Bit Number	Bit Name	Description
0	Enabled	Mechanical brake is enabled by a parameter.
1	Start	A start signal is provided to mechanical brake control.
2	Brake open feedback signal	Brake feedback is enabled and brake open is active.
3	Brake close feedback	Brake feedback is enabled and brake closed is active.
4-10	NA	
11	Priming Timeout	The required release torque could not be generated.
12	Brake release timeout	Feedback is enabled but brake open feedback was not provided during brake release time.
13	Brake close timeout	Feedback is enabled but brake close feedback was not provided during brake close time
14	BrakeCtrl active	Brake control is either in progress of opening or closing brake.
15	Brake open	Brake control has activated digital output.

## P 5.12.1.2 Mechanical Brake State

**Description:** Shows the state of the mechanical brake controller.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 32767)	<b>Parameter Number:</b> 3017
<b>Unit:</b> -	<b>Data Type:</b> INT	<b>Access Type:</b> Read Only

## P 5.12.1.3 Brake Release Time Detected

**Description:** Shows the time from brake release until load change is detected, where motor takes over the load from mechanical brake.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 10000)	<b>Parameter Number:</b> 3041
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

### 6.7.1.13 Fieldbus Process Data Status (Menu Index 5.27.1)

#### P 5.27.1.42 Fieldbus Control Word

**Description:** Shows the profile specific fieldbus control word.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 1335
<b>Unit:</b> -	<b>Data Type:</b> WORD	<b>Access Type:</b> Read/Write

The fieldbus control word is either the PROFIdrive control word described in [2.3 PROFIdrive – Standard Telegram 1](#) or the iC Speed control word described in [2.4 iC Speed Profile](#). The fieldbus profile is selected with *parameter 10.3.1.2 Fieldbus Profile*.

#### P 5.27.1.43 Fieldbus Speed Reference 1

**Description:** Shows the fieldbus speed reference.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-32768 — 32767)	<b>Parameter Number:</b> 1339
<b>Unit:</b> -	<b>Data Type:</b> INT	<b>Access Type:</b> Read/Write

#### P 5.27.1.44 Fieldbus Torque Reference

**Description:** Shows the fieldbus torque reference.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-32768 — 32767)	<b>Parameter Number:</b> 1343
<b>Unit:</b> -	<b>Data Type:</b> INT	<b>Access Type:</b> Read/Write

#### P 5.27.1.50 Fieldbus Status Word

**Description:** Shows the profile specific fieldbus status word.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 65535)	<b>Parameter Number:</b> 1307
<b>Unit:</b> -	<b>Data Type:</b> WORD	<b>Access Type:</b> Read Only

The fieldbus status word is either the PROFIdrive status word described in [2.3 PROFIdrive – Standard Telegram 1](#) or the iC Speed status word described in [2.4 iC Speed Profile](#). The fieldbus profile is selected with *parameter 10.3.1.2 Fieldbus Profile*.

#### P 5.27.1.51 Fieldbus Speed Main Actual Value

**Description:** Shows the actual motor speed.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-32768 — 32767)	<b>Parameter Number:</b> 1308
<b>Unit:</b> -	<b>Data Type:</b> INT	<b>Access Type:</b> Read Only

#### P 5.27.1.54 Fieldbus Speed Reference

**Description:** Shows the fieldbus speed reference.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-1000 — 1000)	<b>Parameter Number:</b> 1345
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

Default unit: RPM. The unit can be changed with parameter 4321.

#### P 5.27.1.73 Fieldbus Torque Main Actual Value

**Description:** Shows the torque applied by the motor.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-32768 — 32767)	<b>Parameter Number:</b> 1346
<b>Unit:</b> -	<b>Data Type:</b> INT	<b>Access Type:</b> Read/Write

Depending on whether metric or imperial units are in use, give the value for the parameter in either newton meters (Nm) or pound-feet (lb ft). The value range is different with the different units.

#### P 5.27.1.89 Fieldbus Control Word 2

**Description:** Shows the fieldbus control word 2.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 1347
<b>Unit:</b> -	<b>Data Type:</b> WORD	<b>Access Type:</b> Read/Write

The fieldbus control and status words are freely configurable, and specific features can be assigned to the bits.

#### P 5.27.1.90 Fieldbus Status Word 2

**Description:** Shows the profile specific fieldbus status word 2.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 65535)	<b>Parameter Number:</b> 1344
<b>Unit:</b> -	<b>Data Type:</b> WORD	<b>Access Type:</b> Read Only

The fieldbus control and status words are freely configurable, and specific features can be assigned to the bits.

#### P 5.27.1.100 Fieldbus Process Reference

**Description:** Shows the fieldbus process reference used in the process controller.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (-32768 — 32767)	<b>Parameter Number:</b> 6046
<b>Unit:</b> -	<b>Data Type:</b> INT	<b>Access Type:</b> Read/Write

### 6.7.1.14 Maintenance & Service (Menu Index 6.1.1)

#### P 6.1.1.1 Last Fault Number

**Description:** Shows the number of the most recent active fault.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 65535)	<b>Parameter Number:</b> 1610
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read Only

#### P 6.1.1.2 Last Warning Number

**Description:** Shows the number of the most recent active warning.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 65535)	<b>Parameter Number:</b> 1609
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read Only

#### P 6.1.1.3 Control Unit Temperature

**Description:** Shows the temperature of the control unit.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-50 — 200)	<b>Parameter Number:</b> 2952
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

### 6.7.2 Software Information (Menu Index 6.2)

#### P 6.2.1 Application Version

**Description:** Shows the version of the application software.

<b>Default Value:</b> -	<b>Parameter Type:</b>	<b>Parameter Number:</b> 151
<b>Unit:</b>	<b>Data Type:</b> STRING	<b>Access Type:</b> -

### 6.7.3 Events (Menu Index 6.4)

#### 6.7.3.1 Event Simulation (Menu Index 6.4.3)

##### P 6.4.3.1 Simulate Event

**Description:** Select a response to trigger a simulated event.

<b>Default Value:</b> 0 [No Action]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1400
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter



Selection number	Selection name
0	No Action
1	Response 1
2	Response 2
3	Response 3
4	Response 4
5	Response 5
6	Response 6
7	Response 7
8	Response 8
9	Response 9
10	Response 10

#### P 6.4.3.2 Simulate Persisting Event

**Description:** Select a response to trigger a persisting simulated event. Set back to 0 to allow a reset.

<b>Default Value:</b> 0 [No Action]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1401
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter

Selection number	Selection name
0	No Action
1	Response 1
2	Response 2
3	Response 3
4	Response 4
5	Response 5
6	Response 6
7	Response 7
8	Response 8
9	Response 9
10	Response 10

#### P 6.4.3.3 Simulate Event Number

**Description:** Set the number of the event to be simulated.

<b>Default Value:</b> 5260	<b>Parameter Type:</b> Range (0 — 65535)	<b>Parameter Number:</b> 1402
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

## 6.7.4 Operational Counters (Menu Index 6.5)

These parameters provide readouts of the operational counters of the drive, like operational hours, energy consumption, and various faults.

### P 6.5.1 Control Unit On Time

**Description:** Shows the total operating time for the control unit.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 4294967295)	<b>Parameter Number:</b> 2000
<b>Unit:</b> h	<b>Data Type:</b> UDINT	<b>Access Type:</b> Read Only

### P 6.5.2 Power Unit On Time

**Description:** Shows the total operating time for the power unit. The counter only increments if the DC link is powered.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 4294967295)	<b>Parameter Number:</b> 2001
<b>Unit:</b> h	<b>Data Type:</b> UDINT	<b>Access Type:</b> Read Only

### P 6.5.3 Energy Consumption

**Description:** Shows the energy consumed from the grid.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 18446744073709600000)	<b>Parameter Number:</b> 2002
<b>Unit:</b> kWh	<b>Data Type:</b> ULINT	<b>Access Type:</b> Read Only

### P 6.5.4 Ground Faults

**Description:** Shows the total number of ground faults.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 50000)	<b>Parameter Number:</b> 2004
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read Only

### P 6.5.5 Overvoltage Faults

**Description:** Shows the total number of overvoltage faults.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 50000)	<b>Parameter Number:</b> 2005
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read Only

### P 6.5.6 Overcurrent Faults

**Description:** Shows the total number of overcurrent faults.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 50000)	<b>Parameter Number:</b> 2006
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read Only

### P 6.5.7 Short Circuit Faults

**Description:** Shows the total number of short-circuit faults.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 50000)	<b>Parameter Number:</b> 2007
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read Only

## 6.8 Functional Safety (Menu Index 7)

This parameter group contains non-safety-related parameters for configuring Safe Torque Off, as well as other safety features.

### 6.8.1 Functional Safety Overview

#### N O T I C E

Select and apply the components in the safety control system appropriately to achieve the required level of operational safety. Before integrating and using STO in an installation, carry out a thorough risk analysis on the installation to determine whether the STO functionality and safety levels are appropriate and sufficient.

The *parameter Functional Safety (Menu Index 7.2)* contains the non-safe parameters related to Functional Safety. They are used to configure the behavior of the drive after a functional safety event (for example, STO). Refer to Functional Safety Operating Guide for more information.

## 6.8.2 Status (Menu Index 7.1)

### P 7.1.1 Functional Safety Status Word

**Description:** Shows the functional safety status word.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 4024
<b>Unit:</b> -	<b>Data Type:</b> WORD	<b>Access Type:</b> Read/Write

## 6.8.3 STO (Menu Index 7.2)

### P 7.2.1 Safe Torque Off Response

**Description:** Select the response of the drive to the activation of Safe Torque Off.

<b>Default Value:</b> 15 [Warning]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 9910
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
15	Warning
14	Fault

The Safe Torque Off (STO) function is a component in a safety control system. STO prevents the unit from generating the power required to rotate the motor. The iC7 drives are available with:

- Safe Torque Off (STO), as defined by EN IEC 61800-5-2.
- Stop category O, as defined in EN 60204-1.

**STO activation:** The STO function is activated by removing the voltages at the STO inputs of the drive. By connecting the frequency converter to external safety devices providing a safe delay, an installation for a Safe Stop 1 can be obtained. External safety devices must fulfill the required Cat.IPL or SIL when connected to STO inputs.

With default settings, the drive issues a fault, trips the unit and coasts the motor to a stop, when the STO function is activated. Manual restart is required. Use the STO function to stop the drive in situation, where a safety function is required. In normal operating mode when STO is not required, use the standard stop function instead.

### P 7.2.2 Safe Torque Off Output

**Description:** Select an output for signaling the activation of Safe Torque Off.

<b>Default Value:</b>	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 9911
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

Additional selections appear based on the hardware of the options connected to the drive and the available fieldbuses.

## 6.8.3.1 Terminating STO and resuming normal operation

### Procedure

1. Reapply 24 V DC supply to STO inputs.
2. Give a reset signal (via bus, digital I/O, or the control panel).

Set the STO function to automatic restart by setting the default value in *parameter 7.2.1 Safe Torque Off Reaction*. This means that an Automatic restart occurs. STO is terminated and normal operation is resumed, when the 24 V DC is applied to STO inputs. No reset signal is required.

## 6.9 Customization (Menu Index 8)

This parameter group contains parameters for customizing and adapting the behavior of the drive and user interface design.

## 6.9.1 Basic Settings (Menu Index 8.2)

### P 8.2.1 Date and Time

**Description:** Set the actual time and date. Format is YYYY-MM-DD and HH:MM:SS.

<b>Default Value:</b>	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 2800
<b>Unit:</b> -	<b>Data Type:</b> DATE_AND_TIME	<b>Access Type:</b> Read/Write

### P 8.2.2 Unit Selection

**Description:** Select the unit system used.

<b>Default Value:</b> SI	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2801
<b>Unit:</b> -	<b>Data Type:</b> USINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	SI (metric units)
1	USCS (United States customary units)

### P 8.2.3 Speed Unit

**Description:** Select the speed unit.

<b>Default Value:</b> 1 [RPM]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2813
<b>Unit:</b> -	<b>Data Type:</b> USINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Hz
1	RPM

## 6.9.2 Control Panel (Menu Index 8.3)

These parameters allow the customization of the Control Panel readout of the drive.

### 6.9.2.1 Readout Screen 1 (Menu Index 8.3.1)

#### P 8.3.1.1 Readout Field 1.1

**Description:** Select the parameter for readout field (screen 1 field 1).

<b>Default Value:</b> 0 [Automatic]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 300
<b>Unit:</b> -	<b>Data Type:</b> UDINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Automatic
9011	Motor Speed
9000	Motor Current
9010	Motor Shaft Speed
9009	Motor Torque
1708	Relative Motor Torque

Selection number	Selection name
9008	Motor Shaft Power
6075	Process Controller Output
6090	Feedback Value
1718	Speed Reference
6092	Setpoint Value
6151	Final Speed Reference
9007	Feedback Speed

## P 8.3.1.2 Readout Field 1.2

**Description:** Select the parameter for readout field (screen 1 field 2).

<b>Default Value:</b> 0 [None]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 301
<b>Unit:</b> -	<b>Data Type:</b> UDINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
9011	Motor Speed
9000	Motor Current
9010	Motor Shaft Speed
9009	Motor Torque
1708	Relative Motor Torque
9005	Motor Voltage
9008	Motor Shaft Power
674	Load Drooping Speed
666	Estimated Inertia
6075	Process Controller Output
6090	Feedback Value
1718	Speed Reference
6092	Setpoint Value
6151	Final Speed Reference
6153	Control Panel Speed Reference
6155	Local Torque Reference
9007	Feedback Speed
9044	DC-link Voltage
9041	Grid Frequency

Selection number	Selection name
9040	Line-To-Line Voltage (RMS)
9048	L1-L2 Line Voltage (RMS)
9049	L2-L3 Line Voltage (RMS)
9050	L3-L1 Line Voltage (RMS)
9047	Grid Voltage Imbalance

## P 8.3.1.3 Readout Field 1.3

**Description:** Select the parameter for readout field (screen 1 field 3).

<b>Default Value:</b> 0 [None]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 302
<b>Unit:</b> -	<b>Data Type:</b> UDINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
9011	Motor Speed
9000	Motor Current
9010	Motor Shaft Speed
9009	Motor Torque
1708	Relative Motor Torque
9005	Motor Voltage
9008	Motor Shaft Power
674	Load Drooping Speed
666	Estimated Inertia
6075	Process Controller Output
6090	Feedback Value
1718	Speed Reference
6092	Setpoint Value
6151	Final Speed Reference
6153	Control Panel Speed Reference
6155	Local Torque Reference
9007	Feedback Speed
9044	DC-link Voltage
9041	Grid Frequency
9040	Line-To-Line Voltage (RMS)
9048	L1-L2 Line Voltage (RMS)

Selection number	Selection name
9049	L2-L3 Line Voltage (RMS)
9050	L3-L1 Line Voltage (RMS)
9047	Grid Voltage Imbalance

## P 8.3.1.4 Readout Field 1.4

**Description:** Select the parameter for readout field (screen 1 field 4).

<b>Default Value:</b> 0 [None]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 303
<b>Unit:</b> -	<b>Data Type:</b> UDINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
9011	Motor Speed
9000	Motor Current
9010	Motor Shaft Speed
9009	Motor Torque
1708	Relative Motor Torque
9005	Motor Voltage
9008	Motor Shaft Power
674	Load Drooping Speed
666	Estimated Inertia
6075	Process Controller Output
6090	Feedback Value
1718	Speed Reference
6092	Setpoint Value
6151	Final Speed Reference
6153	Control Panel Speed Reference
6155	Local Torque Reference
9007	Feedback Speed
9044	DC-link Voltage
9041	Grid Frequency
9040	Line-To-Line Voltage (RMS)
9048	L1-L2 Line Voltage (RMS)

Selection number	Selection name
9049	L2-L3 Line Voltage (RMS)
9050	L3-L1 Line Voltage (RMS)
9047	Grid Voltage Imbalance

## P 8.3.1.5 Readout Field 1.5

**Description:** Select the parameter for readout field (screen 1 field 5).

<b>Default Value:</b> 0 [None]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 304
<b>Unit:</b> -	<b>Data Type:</b> UDINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
9011	Motor Speed
9000	Motor Current
9010	Motor Shaft Speed
9009	Motor Torque
1708	Relative Motor Torque
9005	Motor Voltage
9008	Motor Shaft Power
674	Load Drooping Speed
666	Estimated Inertia
6075	Process Controller Output
6090	Feedback Value
1718	Speed Reference
6092	Setpoint Value
6151	Final Speed Reference
6153	Control Panel Speed Reference
6155	Local Torque Reference
9007	Feedback Speed
9044	DC-link Voltage
9041	Grid Frequency
9040	Line-To-Line Voltage (RMS)
9048	L1-L2 Line Voltage (RMS)



Selection number	Selection name
9049	L2-L3 Line Voltage (RMS)
9050	L3-L1 Line Voltage (RMS)
9047	Grid Voltage Imbalance

### 6.9.2.2 Readout Screen 2 (Menu Index 8.3.2)

#### P 8.3.2.1 Readout Field 2.1

**Description:** Select the parameter for readout field (screen 2 field 1).

<b>Default Value:</b> 9010 [Motor Shaft Speed]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 310
<b>Unit:</b> -	<b>Data Type:</b> UDINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
9011	Motor Speed
9000	Motor Current
9010	Motor Shaft Speed
9009	Motor Torque
1708	Relative Motor Torque
9005	Motor Voltage
9008	Motor Shaft Power
674	Load Drooping Speed
666	Estimated Inertia
6075	Process Controller Output
6090	Feedback Value
1718	Speed Reference
6092	Setpoint Value
6151	Final Speed Reference
6153	Control Panel Speed Reference
6155	Local Torque Reference
9007	Feedback Speed
9044	DC-link Voltage
9041	Grid Frequency
9040	Line-To-Line Voltage (RMS)
9048	L1-L2 Line Voltage (RMS)

Selection number	Selection name
9049	L2-L3 Line Voltage (RMS)
9050	L3-L1 Line Voltage (RMS)
9047	Grid Voltage Imbalance

## P 8.3.2.2 Readout Field 2.2

**Description:** Select the parameter for readout field (screen 2 field 2).

<b>Default Value:</b> 9009 [Motor Torque]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 311
<b>Unit:</b> -	<b>Data Type:</b> UDINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
9011	Motor Speed
9000	Motor Current
9010	Motor Shaft Speed
9009	Motor Torque
1708	Relative Motor Torque
9005	Motor Voltage
9008	Motor Shaft Power
674	Load Drooping Speed
666	Estimated Inertia
6075	Process Controller Output
6090	Feedback Value
1718	Speed Reference
6092	Setpoint Value
6151	Final Speed Reference
6153	Control Panel Speed Reference
6155	Local Torque Reference
9007	Feedback Speed
9044	DC-link Voltage
9041	Grid Frequency
9040	Line-To-Line Voltage (RMS)
9048	L1-L2 Line Voltage (RMS)

Selection number	Selection name
9049	L2-L3 Line Voltage (RMS)
9050	L3-L1 Line Voltage (RMS)
9047	Grid Voltage Imbalance

## P 8.3.2.3 Readout Field 2.3

**Description:** Select the parameter for readout field (screen 2 field 3).

<b>Default Value:</b> 9008 [Motor Shaft Power]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 312
<b>Unit:</b> -	<b>Data Type:</b> UDINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
9011	Motor Speed
9000	Motor Current
9010	Motor Shaft Speed
9009	Motor Torque
1708	Relative Motor Torque
9005	Motor Voltage
9008	Motor Shaft Power
674	Load Drooping Speed
666	Estimated Inertia
6075	Process Controller Output
6090	Feedback Value
1718	Speed Reference
6092	Setpoint Value
6151	Final Speed Reference
6153	Control Panel Speed Reference
6155	Local Torque Reference
9007	Feedback Speed
9044	DC-link Voltage
9041	Grid Frequency
9040	Line-To-Line Voltage (RMS)
9048	L1-L2 Line Voltage (RMS)

Selection number	Selection name
9049	L2-L3 Line Voltage (RMS)
9050	L3-L1 Line Voltage (RMS)
9047	Grid Voltage Imbalance

## P 8.3.2.4 Readout Field 2.4

**Description:** Select the parameter for readout field (screen 2 field 4).

<b>Default Value:</b> 0 [None]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 313
<b>Unit:</b> -	<b>Data Type:</b> UDINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
9011	Motor Speed
9000	Motor Current
9010	Motor Shaft Speed
9009	Motor Torque
1708	Relative Motor Torque
9005	Motor Voltage
9008	Motor Shaft Power
674	Load Drooping Speed
666	Estimated Inertia
6075	Process Controller Output
6090	Feedback Value
1718	Speed Reference
6092	Setpoint Value
6151	Final Speed Reference
6153	Control Panel Speed Reference
6155	Local Torque Reference
9007	Feedback Speed
9044	DC-link Voltage
9041	Grid Frequency
9040	Line-To-Line Voltage (RMS)
9048	L1-L2 Line Voltage (RMS)

Selection number	Selection name
9049	L2-L3 Line Voltage (RMS)
9050	L3-L1 Line Voltage (RMS)
9047	Grid Voltage Imbalance

## P 8.3.2.5 Readout Field 2.5

**Description:** Select the parameter for readout field (screen 2 field 5).

<b>Default Value:</b> 0 [None]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 314
<b>Unit:</b> -	<b>Data Type:</b> UDINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
9011	Motor Speed
9000	Motor Current
9010	Motor Shaft Speed
9009	Motor Torque
1708	Relative Motor Torque
9005	Motor Voltage
9008	Motor Shaft Power
674	Load Drooping Speed
666	Estimated Inertia
6075	Process Controller Output
6090	Feedback Value
1718	Speed Reference
6092	Setpoint Value
6151	Final Speed Reference
6153	Control Panel Speed Reference
6155	Local Torque Reference
9007	Feedback Speed
9044	DC-link Voltage
9041	Grid Frequency
9040	Line-To-Line Voltage (RMS)
9048	L1-L2 Line Voltage (RMS)

Selection number	Selection name
9049	L2-L3 Line Voltage (RMS)
9050	L3-L1 Line Voltage (RMS)
9047	Grid Voltage Imbalance

## 6.10 I/O (Menu Index 9)

### 6.10.1 I/O Overview

*Parameter group 9* contains the parameters for the hardware configuration of the I/Os such as terminal modes, filtering of the electrical signals and signal ranges.

This Application Guide contains only the parameter descriptions for the Basic I/O. The parameter information for option boards such as the Encoder/Resolver Option OC7M can be found in the iC7 Functional Extensions Operating Guide.

### 6.10.2 Basic I/O

#### 6.10.2.1 I/O Status (Menu Index 9.3)

##### P 9.3.1 Digital Input Status

**Description:** Shows the digital input I/O word. Each bit represents the status of a digital input.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 1614
<b>Unit:</b> -	<b>Data Type:</b> WORD	<b>Access Type:</b> Read Only

The following table lists the meaning of the bits:

Bit	Description
00	DigIn13
01	DigIn14
02	DigIn15
03	DigIn16
04	DigIn17
05	DigIn18
06-15	Not used

##### P 9.3.2 Digital Output Status

**Description:** Shows the digital output I/O word. Each bit represents the status of a digital output.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 1615
<b>Unit:</b> -	<b>Data Type:</b> WORD	<b>Access Type:</b> Read Only

The following table lists the meaning of the bits:

Bit	Description
00-01	Not used
02	DigOut15
03	DigOut16
04-11	Not used

Bit	Description
12	Relay02
13	Relay05
14-15	Not used

### P 9.3.3 T31 Analog Output Value

**Description:** Shows the actual value of the terminal.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (0 — 20)	<b>Parameter Number:</b> 1613
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

### P 9.3.4 T33 Analog Input Value

**Description:** Shows the actual value of the terminal.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-20 — 20)	<b>Parameter Number:</b> 1611
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

### P 9.3.5 T34 Analog Input Value

**Description:** Shows the actual value of the terminal.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-20 — 20)	<b>Parameter Number:</b> 1612
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

### P 9.3.6 T34 Temperature Value

**Description:** Shows the measured temperature of the terminal.

<b>Default Value:</b> NA	<b>Parameter Type:</b> Range (-1000 — 1000)	<b>Parameter Number:</b> 1616
<b>Unit:</b> °C	<b>Data Type:</b> REAL	<b>Access Type:</b> Read Only

## 6.10.2.2 Digital Inputs/Outputs (Menu Index 9.4)

These parameters allow the setting of digital inputs and outputs on the Basic I/O board.

### 6.10.2.2.1 General Settings (Menu Index 9.4.1)

#### P 9.4.1.1 Digital Input Logic

**Description:** Set the operating logic for all digital inputs.

<b>Default Value:</b> 2 [PNP mode]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2261
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
1	NPN mode
2	PNP mode

### 6.10.2.2.2 Input T13 (Menu Index 9.4.2)

#### P 9.4.2.1 T13 Terminal Mode

**Description:** Select the mode for the terminal.

<b>Default Value:</b> 3 [Digital input]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2015
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Inactive
3	Digital input
4	Pulse input

#### P 9.4.2.2 T13 Signal Inversion

**Description:** Select whether the signal of the terminal is inverted.

<b>Default Value:</b> 0 [Non-Inverted]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2291
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Non-Inverted
1	Inverted

#### P 9.4.2.3 T13 Fast Debounce Filtering Time

**Description:** Set the fast debounce filtering time for the terminal.

<b>Default Value:</b> 0.00	<b>Parameter Type:</b> Range (0.00 — 63.50)	<b>Parameter Number:</b> 2285
<b>Unit:</b> $\mu$ s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 9.4.2.4 T13 Standard Debounce Filtering Time

**Description:** Set the standard debounce filtering time for the terminal.

<b>Default Value:</b> 5.00	<b>Parameter Type:</b> Range (0.00 — 127.00)	<b>Parameter Number:</b> 2024
<b>Unit:</b> ms	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 9.4.2.5 T13 Reaction Time

**Description:** Select the reaction time for the debounce filter.

<b>Default Value:</b> 0 [Standard reaction time (1ms tick)]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2025
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Standard reaction time (1ms tick)
1	Fast reaction time (0.5 $\mu$ s tick)

#### P 9.4.2.6 T13 Trigger Mode

**Description:** Select the trigger mode for the digital input.

<b>Default Value:</b> 0 [None]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2026
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.



Selection number	Selection name
0	None
1	Rising Edge
2	Falling Edge
3	Both Edges

#### P 9.4.2.7 T13 Pulse Min. Frequency

**Description:** Set the frequency representing 0% of the signal.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 100000)	<b>Parameter Number:</b> 2027
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 9.4.2.8 T13 Pulse Max. Frequency

**Description:** Set the frequency representing 100% of the signal.

<b>Default Value:</b> 100000	<b>Parameter Type:</b> Range (0 — 100000)	<b>Parameter Number:</b> 2028
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

### 6.10.2.2.3 Input T14 (Menu Index 9.4.3)

#### P 9.4.3.1 T14 Terminal Mode

**Description:** Select the mode for the terminal.

<b>Default Value:</b> 3 [Digital input]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2016
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Inactive
3	Digital input
4	Pulse input

#### P 9.4.3.2 T14 Signal Inversion

**Description:** Select whether the signal of the terminal is inverted.

<b>Default Value:</b> 0 [Non-Inverted]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2292
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Non-Inverted
1	Inverted

#### P 9.4.3.3 T14 Fast Debounce Filtering Time

**Description:** Set the fast debounce filtering time for the terminal.

<b>Default Value:</b> 0.00	<b>Parameter Type:</b> Range (0.00 — 63.50)	<b>Parameter Number:</b> 2286
<b>Unit:</b> µs	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 9.4.3.4 T14 Standard Debounce Filtering Time

**Description:** Set the standard debounce filtering time for the terminal.

<b>Default Value:</b> 5.00	<b>Parameter Type:</b> Range (0.00 — 127.00)	<b>Parameter Number:</b> 2029
<b>Unit:</b> ms	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 9.4.3.5 T14 Reaction Time

**Description:** Select the reaction time for the debounce filter.

<b>Default Value:</b> 0 [Standard reaction time (1ms tick)]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2030
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Standard reaction time (1ms tick)
1	Fast reaction time (0.5µs tick)

## P 9.4.3.6 T14 Trigger Mode

**Description:** Select the trigger mode for the digital input.

<b>Default Value:</b> 0 [None]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2031
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
1	Rising Edge
2	Falling Edge
3	Both Edges

## P 9.4.3.7 T14 Pulse Min. Frequency

**Description:** Set the frequency representing 0% of the signal.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 100000)	<b>Parameter Number:</b> 2032
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 9.4.3.8 T14 Pulse Max. Frequency

**Description:** Set the frequency representing 100% of the signal.

<b>Default Value:</b> 100000	<b>Parameter Type:</b> Range (0 — 100000)	<b>Parameter Number:</b> 2033
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## 6.10.2.2.4 Input/Output T15 (Menu Index 9.4.4)

## P 9.4.4.1 T15 Terminal Mode

**Description:** Select the mode for the terminal.

<b>Default Value:</b> 3 [Digital input]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2022
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Inactive
1	Digital Output
2	Pulse Output
3	Digital input
4	Pulse input

#### P 9.4.4.2 T15 Signal Inversion

**Description:** Select whether the signal of the terminal is inverted.

<b>Default Value:</b> 0 [Non-Inverted]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2295
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Non-Inverted
1	Inverted

#### P 9.4.4.3 T15 Fast Debounce Filtering Time

**Description:** Set the fast debounce filtering time for the terminal.

<b>Default Value:</b> 0.00	<b>Parameter Type:</b> Range (0.00 — 63.50)	<b>Parameter Number:</b> 2289
<b>Unit:</b> $\mu$ s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 9.4.4.4 T15 Standard Debounce Filtering Time

**Description:** Set the standard debounce filtering time for the terminal.

<b>Default Value:</b> 5.00	<b>Parameter Type:</b> Range (0.00 — 127.00)	<b>Parameter Number:</b> 2297
<b>Unit:</b> ms	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 9.4.4.5 T15 Reaction Time

**Description:** Select the reaction time for the debounce filter.

<b>Default Value:</b> 0 [Standard reaction time (1 ms tick)]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2299
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Standard reaction time (1 ms tick)
1	Fast reaction time (0.5 $\mu$ s tick)

#### P 9.4.4.6 T15 Trigger Mode

**Description:** Select the trigger mode for the digital input.

<b>Default Value:</b> 0 [None]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2044
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
1	Rising Edge
2	Falling Edge
3	Both Edges

## P 9.4.4.7 T15 Pulse Min. Frequency

**Description:** Set the frequency representing 0% of the signal.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 100000)	<b>Parameter Number:</b> 2045
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 9.4.4.8 T15 Pulse Max. Frequency

**Description:** Set the frequency representing 100% of the signal.

<b>Default Value:</b> 100000	<b>Parameter Type:</b> Range (0 — 100000)	<b>Parameter Number:</b> 2046
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 9.4.4.9 T15 Digital Output Logic

**Description:** Select the operating logic for the digital output.

<b>Default Value:</b> 0 [Tri state]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2047
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Tri state
1	Open collector sink (NPN)
2	Open collector source (PNP)
3	Push pull

## P 9.4.4.10 T15 Pulse Out Min. Frequency

**Description:** Set the frequency representing 0% of the signal.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 100000)	<b>Parameter Number:</b> 2048
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 9.4.4.11 T15 Pulse Out Max. Frequency

**Description:** Set the frequency representing 100% of the signal.

<b>Default Value:</b> 100000	<b>Parameter Type:</b> Range (0 — 100000)	<b>Parameter Number:</b> 2049
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## 6.10.2.2.5 Input/Output T16 (Menu Index 9.4.5)

## P 9.4.5.1 T16 Terminal Mode

**Description:** Select the mode for the terminal.

<b>Default Value:</b> 3 [Digital input]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2298
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Inactive
1	Digital Output
2	Pulse Output
3	Digital input
4	Pulse input

#### P 9.4.5.2 T16 Signal Inversion

**Description:** Select whether the signal of the terminal is inverted.

<b>Default Value:</b> 0 [Non-Inverted]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2296
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Non-Inverted
1	Inverted

#### P 9.4.5.3 T16 Fast Debounce Filtering Time

**Description:** Set the fast debounce filtering time for the terminal.

<b>Default Value:</b> 0.00	<b>Parameter Type:</b> Range (0.00 — 63.50)	<b>Parameter Number:</b> 2290
<b>Unit:</b> $\mu$ s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 9.4.5.4 T16 Standard Debounce Filtering Time

**Description:** Set the standard debounce filtering time for the terminal.

<b>Default Value:</b> 5.00	<b>Parameter Type:</b> Range (0.00 — 127.00)	<b>Parameter Number:</b> 2260
<b>Unit:</b> ms	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 9.4.5.5 T16 Reaction Time

**Description:** Select the reaction time for the debounce filter.

<b>Default Value:</b> 0 [Standard reaction time (1ms tick)]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2052
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Standard reaction time (1ms tick)
1	Fast reaction time (0.5 $\mu$ s tick)

#### P 9.4.5.6 T16 Trigger Mode

**Description:** Select the trigger mode for the digital input.

<b>Default Value:</b> 0 [None]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2053
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
1	Rising Edge
2	Falling Edge
3	Both Edges

## P 9.4.5.7 T16 Pulse Min. Frequency

**Description:** Set the frequency representing 0% of the signal.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 100000)	<b>Parameter Number:</b> 2054
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 9.4.5.8 T16 Pulse Max. Frequency

**Description:** Set the frequency representing 100% of the signal.

<b>Default Value:</b> 100000	<b>Parameter Type:</b> Range (0 — 100000)	<b>Parameter Number:</b> 2055
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 9.4.5.9 T16 Digital Output Type

**Description:** Select the operating logic for the digital output.

<b>Default Value:</b> 0 [Tri state]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2056
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Tri state
1	Open collector sink (NPN)
2	Open collector source (PNP)
3	Push pull

## P 9.4.5.10 T16 Pulse Out Min. Frequency

**Description:** Set the frequency representing 0% of the signal.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 100000)	<b>Parameter Number:</b> 2051
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 9.4.5.11 T16 Pulse Out Max. Frequency

**Description:** Set the frequency representing 100% of the signal.

<b>Default Value:</b> 100000	<b>Parameter Type:</b> Range (0 — 100000)	<b>Parameter Number:</b> 2050
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## 6.10.2.2.6 Input T17 (Menu Index 9.4.6)

## P 9.4.6.1 T17 Terminal Mode

**Description:** Select the mode for the terminal.

<b>Default Value:</b> 3 [Digital input]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2017
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Inactive
3	Digital input
4	Pulse input

#### P 9.4.6.2 T17 Signal Inversion

**Description:** Select whether the signal of the terminal is inverted.

<b>Default Value:</b> 0 [Non-Inverted]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2293
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Non-Inverted
1	Inverted

#### P 9.4.6.3 T17 Fast Debounce Filtering Time

**Description:** Set the fast debounce filtering time for the terminal.

<b>Default Value:</b> 0.00	<b>Parameter Type:</b> Range (0.00 — 63.50)	<b>Parameter Number:</b> 2287
<b>Unit:</b> $\mu$ s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 9.4.6.4 T17 Standard Debounce Filtering Time

**Description:** Set the standard debounce filtering time for the terminal.

<b>Default Value:</b> 5.00	<b>Parameter Type:</b> Range (0.00 — 127.00)	<b>Parameter Number:</b> 2034
<b>Unit:</b> ms	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 9.4.6.5 T17 Reaction Time

**Description:** Select the reaction time for the debounce filter.

<b>Default Value:</b> 0 [Standard reaction time (1ms tick)]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2035
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Standard reaction time (1ms tick)
1	Fast reaction time (0.5 $\mu$ s tick)

#### P 9.4.6.6 T17 Trigger Mode

**Description:** Select the trigger mode for the digital input.

<b>Default Value:</b> 0 [None]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2036
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
1	Rising Edge
2	Falling Edge
3	Both Edges

## P 9.4.6.7 T17 Pulse Min. Frequency

**Description:** Set the frequency representing 0% of the signal.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 100000)	<b>Parameter Number:</b> 2037
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 9.4.6.8 T17 Pulse Max. Frequency

**Description:** Set the frequency representing 100% of the signal.

<b>Default Value:</b> 100000	<b>Parameter Type:</b> Range (0 — 100000)	<b>Parameter Number:</b> 2038
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## 6.10.2.2.7 Input T18 (Menu Index 9.4.7)

## P 9.4.7.1 T18 Terminal Mode

**Description:** Select the mode for the terminal.

<b>Default Value:</b> 3 [Digital input]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2018
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Inactive
3	Digital input
4	Pulse input

## P 9.4.7.2 T18 Signal Inversion

**Description:** Select whether the signal of the terminal is inverted.

<b>Default Value:</b> 0 [Non-Inverted]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2294
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Non-Inverted
1	Inverted

## P 9.4.7.3 T18 Fast Debounce Filtering Time

**Description:** Set the fast debounce filtering time for the terminal.

<b>Default Value:</b> 0.00	<b>Parameter Type:</b> Range (0.00 — 63.50)	<b>Parameter Number:</b> 2288
<b>Unit:</b> $\mu$ s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write



## P 9.4.7.4 T18 Standard Debounce Filtering Time

**Description:** Set the standard debounce filtering time for the terminal.

<b>Default Value:</b> 5.00	<b>Parameter Type:</b> Range (0.00 — 127.00)	<b>Parameter Number:</b> 2039
<b>Unit:</b> ms	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 9.4.7.5 T18 Reaction Time

**Description:** Select the reaction time for the debounce filter.

<b>Default Value:</b> 0 [Standard reaction time (1ms tick)]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2040
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Standard reaction time (1ms tick)
1	Fast reaction time (0.5 $\mu$ s tick)

## P 9.4.7.6 T18 Trigger Mode

**Description:** Select the trigger mode for the digital input.

<b>Default Value:</b> 0 [None]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2041
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	None
1	Rising Edge
2	Falling Edge
3	Both Edges

## P 9.4.7.7 T18 Pulse Min. Frequency

**Description:** Set the frequency representing 0% of the signal.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (0 — 100000)	<b>Parameter Number:</b> 2042
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## P 9.4.7.8 T18 Pulse Max. Frequency

**Description:** Set the frequency representing 100% of the signal.

<b>Default Value:</b> 100000	<b>Parameter Type:</b> Range (0 — 100000)	<b>Parameter Number:</b> 2043
<b>Unit:</b> Hz	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

## 6.10.2.3 Analog Inputs/Outputs (Menu Index 9.5)

These parameters allow the setting of analog inputs and outputs on the Basic I/O board.

## 6.10.2.3.1 Output T31 (Menu Index 9.5.1)

## P 9.5.1.1 T31 Terminal Mode

**Description:** Select the mode for the terminal.

<b>Default Value:</b> 5 [Analog Output]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2019
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Inactive
5	Analog Output

#### P 9.5.1.2 T31 Terminal Type

**Description:** Select the type of the terminal. If voltage is selected, the unit is V. If current is selected, the unit is mA.

<b>Default Value:</b> 0 [Off]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2284
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Off
1	Voltage
2	Current

#### P 9.5.1.3 T31 Minimum Value

**Description:** Set the voltage or current representing 0% of the signal.

<b>Default Value:</b> 0.0	<b>Parameter Type:</b> Range (0 — 20.0)	<b>Parameter Number:</b> 2283
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 9.5.1.4 T31 Maximum Value

**Description:** Set the voltage or current representing 100% of the signal.

<b>Default Value:</b> 10.0	<b>Parameter Type:</b> Range (0 — 20.0)	<b>Parameter Number:</b> 2282
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

### 6.10.2.3.2 Input T33 (Menu Index 9.5.2)

#### P 9.5.2.1 T33 Terminal Mode

**Description:** Select the mode for the terminal.

<b>Default Value:</b> 6 [Analog Input]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2020
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Inactive
6	Analog Input

#### P 9.5.2.2 T33 Terminal Type

**Description:** Select the type of the terminal. If voltage is selected, the unit is V. If current is selected, the unit is mA.

<b>Default Value:</b> 1 [Voltage]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2273
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
1	Voltage
2	Current

#### P 9.5.2.3 T33 Minimum Value

**Description:** Set the voltage or current representing 0% of the signal.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (-20 — 20)	<b>Parameter Number:</b> 2272
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 9.5.2.4 T33 Maximum Value

**Description:** Set the voltage or current representing 100% of the signal.

<b>Default Value:</b> 10	<b>Parameter Type:</b> Range (-20 — 20)	<b>Parameter Number:</b> 2271
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 9.5.2.5 T33 Filter Time

**Description:** Set the filter time for the terminal.

<b>Default Value:</b> 0.00	<b>Parameter Type:</b> Range (0.00 — 60000.00)	<b>Parameter Number:</b> 2270
<b>Unit:</b> ms	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 9.5.2.6 T33 Live Zero Threshold Value

**Description:** Set the live zero threshold value for the terminal. The response to a live zero event is defined with parameter "5.2.15.2 Live Zero Response".

<b>Default Value:</b> -10	<b>Parameter Type:</b> Range (-20 — 20)	<b>Parameter Number:</b> 2274
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 9.5.2.7 T33 Live Zero Timeout Value

**Description:** Set the live zero timeout value for the terminal. The response to a live zero event is defined with parameter "5.2.15.2 Live Zero Response".

<b>Default Value:</b> 0.0	<b>Parameter Type:</b> Range (0.0 — 60.0)	<b>Parameter Number:</b> 2275
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

### 6.10.2.3.3 Input T34 (Menu Index 9.5.3)

#### P 9.5.3.1 T34 Terminal Mode

**Description:** Select the mode for the terminal.

<b>Default Value:</b> 6 [Analog Input]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2021
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Inactive
6	Analog Input
7	Temperature input

#### P 9.5.3.2 T34 Terminal Type

**Description:** Select the type of the terminal. If voltage is selected, the unit is V. If current is selected, the unit is mA.

<b>Default Value:</b> 1 [Voltage]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 2279
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
1	Voltage
2	Current

#### P 9.5.3.3 T34 Minimum Value

**Description:** Set the voltage or current representing 0% of the signal.

<b>Default Value:</b> 0	<b>Parameter Type:</b> Range (-20 — 20)	<b>Parameter Number:</b> 2278
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 9.5.3.4 T34 Maximum Value

**Description:** Set the voltage or current representing 100% of the signal.

<b>Default Value:</b> 10	<b>Parameter Type:</b> Range (-20 — 20)	<b>Parameter Number:</b> 2277
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 9.5.3.5 T34 Filter Time

**Description:** Set the filter time for the terminal.

<b>Default Value:</b> 0.00	<b>Parameter Type:</b> Range (0.00 — 60000.00)	<b>Parameter Number:</b> 2276
<b>Unit:</b> ms	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 9.5.3.6 T34 Live Zero Threshold Value

**Description:** Set the live zero threshold value for the terminal. The response to a live zero event is defined with parameter "5.2.15.2 Live Zero Response".

<b>Default Value:</b> -10	<b>Parameter Type:</b> Range (-20 — 20)	<b>Parameter Number:</b> 2280
<b>Unit:</b> -	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 9.5.3.7 T34 Live Zero Timeout Value

**Description:** Set the live zero timeout value for the terminal. The response to a live zero event is defined with parameter "5.2.15.2 Live Zero Response".

<b>Default Value:</b> 0.0	<b>Parameter Type:</b> Range (0.0 — 60.0)	<b>Parameter Number:</b> 2281
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 9.5.3.8 T34 Temperature Sensor Type

**Description:** Select which type of temperature sensor is connected to the terminal.

<b>Default Value:</b> 0 [No sensor]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1617
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	No sensor
4	Pt1000
5	Ni1000Tk5000
6	Ni1000Tk6180
7	KTY84-1x0
8	KTY84-151
9	KTY84-152
10	KTY81/82-1x0
11	KTY81/82-121
12	KTY81/82-122
13	KTY81/82-151
14	KTY81/82-152
15	KTY81/82-2x0
16	KTY81/82-221
17	KTY81/82-222
18	KTY81/82-251
19	KTY81/82-252

## 6.11 Connectivity (Menu Index 10)

This parameter group contains parameters for configuring the built-in and optional communications of the drive system.

### 6.11.1 Connectivity Overview

This section provides information about configuring and monitoring all types of communication interfaces as well as the communication and fieldbus protocols available. Following are the available interfaces:

- Communication interface X0
- Communication interface X1/X2

Following are the available network management protocol and fieldbus protocols:

- SNMP
- PROFINET
- MODBUS TCP
- EtherNet/IP

For more information refer to the related fieldbus guide.

### 6.11.2 Integrated Communication

### 6.11.2.1 Communication interfaces (Menu Index 10.2)

#### 6.11.2.1.1 Host Settings (Menu Index 10.2.1)

##### P 10.2.1.1 Fully Qualified Domain Name

**Description:** Fully Qualified Domain Name. Consists of a host name label and at least 1 higher-level domain separated by the symbol "." with up to 240 characters in total. Each label contains up to 63 characters and starts with a lowercase letter and ends with alphanumeric lowercase character and have as interior characters only alphanumeric lowercase characters and '-'.  
 Note: The host name label must not be empty.

<b>Default Value:</b> \*	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 7036
<b>Unit:</b> -	<b>Data Type:</b> STRING	<b>Access Type:</b> Read/Write

#### 6.11.2.1.2 Ethernet Interface X0 (Menu Index 10.2.2)

##### 6.11.2.1.2.1 IPv4 Settings

The Ethernet Interface X0 IPv4 settings view contains the following fields:

- Interface X0 MAC address
- IPv4 addressing method
- Requested IPv4 address
- Requested IPv4 SUBNET mask
- Requested IPv4 gateway address
- Enable ACD
- DNS server 1
- DNS server 2

##### 6.11.2.1.2.2 IPv4 Status

The Ethernet Interface X0 IPv4 status view contains the following fields:

- Interface X0 MAC address
- IPv4 addressing method
- Actual IPv4 address
- Actual IPv4 SUBNET mask
- Actual IPv4 gateway address
- DHCP server
- Actual DNS server 1
- Actual DNS server 2
- ACD activity

#### 6.11.2.1.3 Ethernet Interface X1/X2 Settings (Menu Index 10.2.3)

##### 6.11.2.1.3.1 IPv4 Settings

The Ethernet Interface X1/X2 IPv4 settings view contains the following fields:

- Interface X1 MAC address
- IPv4 addressing method
- Requested IPv4 address
- Requested IPv4 SUBNET mask
- Requested IPv4 gateway address
- Enable ACD
- DNS server 1
- DNS server 2

### 6.11.2.1.3.2 IPv4 Status

The Ethernet Interface X1/X2 IPv4 status view contains the following fields:

- Interface X1 MAC address
- IPv4 addressing method
- Actual IPv4 address
- Actual IPv4 SUBNET mask
- Actual IPv4 gateway address
- DHCP server
- Actual DNS server 1
- Actual DNS server 2
- ACD activity

### 6.11.2.1.4 Ethernet port X0 (Menu Index 10.2.4)

#### 6.11.2.1.4.1 X0 Settings (Menu Index 10.2.4.2)

P 10.2.4.2.5 Link configuration X0

**Description:** Select the configuration of the Ethernet link parameters.

<b>Default Value:</b> 0 [Auto negotiation]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 7047
<b>Unit:</b> -	<b>Data Type:</b> USINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Auto negotiation
1	10 Mbps full duplex
2	10 Mbps half duplex
3	100 Mbps full duplex
4	100 Mbps half duplex

### 6.11.2.1.5 Ethernet port X1 (Menu Index 10.2.5)

#### 6.11.2.1.5.1 X1 Settings (Menu Index 10.2.5.2)

P 10.2.5.2.5 Link Configuration X1

**Description:** Select the configuration of the Ethernet link parameters.

<b>Default Value:</b> 0 [Auto negotiation]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 7048
<b>Unit:</b> -	<b>Data Type:</b> USINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Auto negotiation
1	10 Mbps full duplex

Selection number	Selection name
2	10 Mbps half duplex
3	100 Mbps full duplex
4	100 Mbps half duplex

### 6.11.2.1.6 Ethernet port X2 (Menu Index 10.2.6)

#### 6.11.2.1.6.1 X2 Settings (Menu Index 10.2.6.2)

##### P 10.2.6.2.5 Link Configuration X2

**Description:** Select the configuration of the Ethernet link parameters.

<b>Default Value:</b> 0 [Auto negotiation]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 7049
<b>Unit:</b> -	<b>Data Type:</b> USINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Auto negotiation
1	10 Mbps full duplex
2	10 Mbps half duplex
3	100 Mbps full duplex
4	100 Mbps half duplex

### 6.11.2.2 Protocols (Menu Index 10.3)

#### 6.11.2.2.1 General Settings (Menu Index 10.3.1)

##### P 10.3.1.2 Fieldbus Profile

**Description:** Select the fieldbus profile. The selection affects the interpretation of the control word and status word.

<b>Default Value:</b> 101 [iC Speed Profile]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1301
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter

Selection number	Selection name
101	iC Speed Profile
201	PROFIdrive Standard Telegram 1

##### P 10.3.1.3 Fieldbus Fault Response

**Description:** Select the behavior when a fieldbus fault occurs.

<b>Default Value:</b> 1 [Info]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1303
<b>Unit:</b> -	<b>Data Type:</b> INT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter



Selection number	Selection name
1	Info
3	Warning
9	Fault, ramp to coast
10	Fault

#### P 10.3.1.4 No Fieldbus Connection Response

**Description:** Select the response in case there is no fieldbus connection.

<b>Default Value:</b> 1 [Info]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1327
<b>Unit:</b> -	<b>Data Type:</b> INT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter

Selection number	Selection name
1	Info
3	Warning
9	Fault, ramp to coast
10	Fault

#### P 10.3.1.6 Process Data Timeout Time

**Description:** Set the timeout time. If process data is not received within the time set, a process data timeout is triggered.

<b>Default Value:</b> 1	<b>Parameter Type:</b> Range (0 — 18000)	<b>Parameter Number:</b> 1340
<b>Unit:</b> s	<b>Data Type:</b> REAL	<b>Access Type:</b> Read/Write

#### P 10.3.1.12 Process Data Timeout Response

**Description:** Select the response to a process data timeout.

<b>Default Value:</b> 1 [Info]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 1341
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter

Selection number	Selection name
1	Info
3	Warning
5	Warning - Change Control Place
6	Warning - Change Control Place - Persistent
9	Fault, ramp to coast
10	Fault

#### P 10.3.1.13 Process Data Timeout Control Place

**Description:** Select the alternate control place to be used in case of fieldbus timeout. This is only valid in case of timeout warning or info.

<b>Default Value:</b> 1 [Local control]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 112
<b>Unit:</b> -	<b>Data Type:</b> UINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter

Selection number	Selection name
1	Local control
2	Fieldbus control
3	I/O control
4	Advanced control

### 6.11.2.2.2 PROFINET (Menu Index 10.3.2)

#### 6.11.2.2.2.1 Configuration (Menu Index 10.3.2.2)

##### P 10.3.2.2.1 Name of Station

**Description:** Set the name of station. The PROFINET device is identified by its name of station. Each name must be unique in the network.

<b>Default Value:</b>	<b>Parameter Type:</b> Range (\* — \*)	<b>Parameter Number:</b> 7080
<b>Unit:</b> -	<b>Data Type:</b> STRING	<b>Access Type:</b> Read/Write

#### 6.11.2.2.2.2 Diagnosis (Menu Index 10.3.2.3)

##### P 10.3.2.3.1 Diagnostic Fault

**Description:** Enables diagnostic fault. When disabled the device will not send any PROFINET diagnosis message with severity "Fault" when a fault is present on device.

<b>Default Value:</b> 1 [Enabled]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 7081
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Disabled
1	Enabled

##### P 10.3.2.3.2 Diagnostic Warning

**Description:** Enables diagnostic warning. When disabled the device will not send any PROFINET diagnosis message with severity "Maintenance required" when a warning is present on device.

<b>Default Value:</b> 1 [Enabled]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 7083
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Disabled
1	Enabled

### 6.11.2.2.3 Modbus TCP (Menu Index 10.3.3)

### 6.11.2.2.3.1 Configuration (Menu Index 10.3.3.2)

#### P 10.3.3.2.1 Persistent Storage

**Description:** Select if persistent storage is active for Modbus writes.

<b>Default Value:</b> 0 [Disabled]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 7061
<b>Unit:</b> -	<b>Data Type:</b> BOOL	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Disabled
1	Enabled

#### P 10.3.3.2.3 Byte Order

**Description:** Select the byte order.

<b>Default Value:</b> 0 [Big Endian]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 7062
<b>Unit:</b> -	<b>Data Type:</b> USINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Big Endian
1	Little Endian

#### P 10.3.3.2.4 Word Order

**Description:** Select the word order.

<b>Default Value:</b> 1 [Little Endian]	<b>Parameter Type:</b> Selection	<b>Parameter Number:</b> 7063
<b>Unit:</b> -	<b>Data Type:</b> USINT	<b>Access Type:</b> Read/Write

The following are the selections for the parameter.

Selection number	Selection name
0	Big Endian
1	Little Endian

## 7 Troubleshooting

### 7.1 Viewing Warnings

When a warning event occurs, the drive status indicators (halo and *WARN*) turn yellow. The drive remains operational and when the trigger for the warning is corrected, the indicators turn white.

To view the details of a warning, go to *parameter group 6.4.1 Active Events*.

To view the history of events for the drive, go to *parameter group 6.4.2 Event History*.




Illustration 70: Warnings

### 7.2 Viewing and Resetting Faults

When a fault occurs in the drive, the drive status indicators (halo and *FAULT*) turn red. The control panel display shows the name of the fault, and allows a direct reset.




Illustration 71: Fault Shown on Control Panel

#### Procedure

1. To view details about a fault and its cause, select the fault in the list shown on the control panel and click *[OK]*.

If the control panel display has changed, simultaneously press the left and right arrows on the control panel to return to *parameter group 6.4.1 Active Events*.




Illustration 72: View Active Faults

2. Resolve all triggers causing the fault.
3. Select *Reset all* and press *[OK]*.

### 7.3 Reading the Event Summary Table

#### Group number and number (columns 1-2)

Events in iC7 drives are characterized by 2 different identifiers: Group numbers and Individual numbers.

The group numbers for iC7 drives follow DRIVECOM industry standard error code specification. The specification originated with the Interbus communication profile. The [Interbus V3.0 base profile](#) was released on 2018-04-19. The [inverter specific profile](#) was released on 1997-12-15. The error code specification was adopted by CAN in Automation and ODVA and is used within their respective Drive Profile. The list of standardized error codes can be found within [IEC 61800-7-201](#)

Unlike individual numbers, the group numbers are not unique since multiple errors might be related to each other. An example is different ground faults which share the Group Number 0x2330.

### Display name and description (columns 3-4)

The columns are showing the name and a short description of the events. Few display names are marked with a \* which indicates that the event can be configured via a parameter.

### Type of event (columns 5-8)

The event summary table shows column names where I – Info, W – Warning, F – Fault, and PF – Protected Fault.

Following are the descriptions for these events:

- **Info:** The notification provides information to the user.
- **Warning:** The notification informs that an undesired event is happening. The drive can continue operation, but it might be with reduced performance and/or the drive might trip.
- **Fault (Trip):** An error notification informs that an undesired high-severity event occurred. The motor coasts without control from the drive. The error message and the error can be reset without power cycling the drive.
- **Protected Fault (Trip Lock):** An error notification informs that an undesired high-severity event happened. The motor coasts without control from the drive. The error message and the error can be reset after power cycling the drive

### Action of inverter and brake chopper (columns 9-10)

The columns are showing the possible action of the inverter (output of the drive) and the brake chopper, where C – Coast and RC – Ramp to Coast.

- **Inverter:**
  - RC: Output ramps to 0 before coasting.
  - C: Output coasts immediately.
- **Brake chopper:**
  - C: Output of the brake coasts immediately.

## 7.4 Events Summary for Industry Application Software

Following is the list of events that can occur in the Industry application software.

Table 33: Summary Table

Group number (hex)	Number (decimal)	Display name	Description	Type of event				Inverter and brake chopper action	
				I	W	F	PF	Inverter	Brake
0x21FF	4372	Current Injection Limit	The time limit for the short term current injection has been exceeded.		X	X		C	
0x2212	4374	DC-link Resonance	A resonance on the DC link with excessive RMS current values has been detected.		X	X		C	
0x2221	4384	Thermal Overload Rectifier	The rectifier is thermally overloaded. Mission profile is too demanding.		X	X		C	
0x2222	4373	DC-link Overcurrent	An overcurrent on the main DC-link capacitors has been detected.		X	X		C	
0x2310	5170	Current Limit Timeout	The drive has exceeded the allowed time in current limit.			X		C	
0x2311	4097	Inverter Overload	Thermal overload is detected in the inverter of the drive. Reduce the output load.		X	X		C	
0x2311	4368	Output Current High 0	The output current of the drive has exceeded its normal range at low speed. Shock load or too fast acceleration with high-inertia loads can cause this fault. Check that the motor size matches the drive and the		X	X		C	

Group number (hex)	Number (decimal)	Display name	Description	Type of event				Inverter and brake chopper action	
				I	W	F	PF	Inverter	Brake
			motor data is correct. Check that the motor shaft can be turned.						
0x2311	4369	Output Current High 1	The output current of the drive has exceeded its normal range. Shock load or too fast acceleration with high-inertia loads can cause this fault. Check that the motor size matches the drive and the motor data is correct. Check that the motor shaft can be turned.		X	X		C	
0x2311	4375	Excessive Current Limiting	The output current of the drive has exceeded the current limit multiple times. Check that the motor size matches the drive and the motor data is correct. Check that the motor shaft can be turned.		X	X		C	
0x2311	4377	Smart Derating Fault	A Smart Derating fault is detected. The load is too demanding for the current derating level. Lower the switching frequency if possible.		X	X		C	
0x2311	4380	Current Limit Setting Fault	The actual current limit setting is too high relative to the selected constant control frequency level. Reduce the control frequency setting or reduce the current limit setting.			X		C	C
0x2330	4352	Ground Fault 0	A high-impedance ground fault is detected on the output. Check the insulation of motor cable and motor.		X	X		C	
0x2330	4353	Ground Fault 1	A high-impedance ground fault is detected on the output. Check the insulation of motor cable and motor.		X	X		C	
0x2330	4354	Ground Fault 2	A low-impedance ground fault is detected on the output. Check the insulation of motor cable and motor.		X		X	C	
0x2330	4355	Ground Fault 21	A high or low-impedance ground fault is detected on the output. Check the insulation of motor cable and motor.		X		X	C	
0x2340	4356	Inverter Short Circuit	A short circuit at the inverter output is detected. Check the motor and motor cable.		X		X	C	
0x2340	4370	Output Current High 2	A critical output overcurrent has been detected. Check for short circuits on the output.		X		X	C	
0x2340	4649	Desat Gate Driver	The gate driver has detected desaturation condition.			X		C	C
0x23FD	4182	Motor Sync Loss	Motor Loss of Synchronization.		X				
0x23FE	4371	Current Imbalance	A current imbalance between paralleled power units has been detected.		X				
0x23FF	4175	Motor Disconnected	The motor is disconnected.		X	X		C	

Group number (hex)	Number (decimal)	Display name	Description	Type of event				Inverter and brake chopper action	
				I	W	F	PF	Inverter	Brake
0x23FF	4176	Missing Motor Phase	A missing motor phase is detected. Check motor, motor cables, and connections.		X	X		C	
0x3110	4164	Grid Voltage High	Grid voltage (RMS) above the normal operating range is detected.		X	X		C	C
0x3120	4165	Grid Voltage Low	A grid voltage (RMS) below the normal operating range is detected.		X	X		C	
0x3130	4160	Missing Grid Phase	A missing phase is detected on the grid side. Check the grid supply, cables, connections, and fuses.		X	X		C	
0x3140	4161	Grid Frequency Out of Range	A grid frequency outside the normal operating range is detected.		X	X		C	
0x31FD	4162	Grid Voltage Spikes	Excessive spikes on the grid voltage have been detected.		X	X		C	
0x31FE	4163	Grid Imbalance	A large imbalance of the grid voltages is detected. Check for uneven loads on the grid.		X	X		C	
0x31FF	4166	Grid Synchronization Error	The drive is unable to maintain the synchronization to the grid voltage.		X	X		C	
0x3211	4144	DC-link Voltage High 2	The voltage of the DC link is above the normal operating range. Can be caused by too fast motor braking or grid transients. Increase deceleration time, enable the overvoltage controller, use AC brake, or use a brake resistor while braking.		X	X		C	C
0x3212	4145	DC-link Voltage High 1	The voltage of the DC link is above the normal operating range and has reached a critical level. Can be caused by too fast motor braking or grid transients. Increase deceleration time, enable the overvoltage controller, use AC brake, or use a brake resistor while braking.		X	X		C	
0x3221	4146	DC-link Voltage Low	The DC-link voltage is below the normal operating range. Try to enable undervoltage protection to keep the drive running as long as possible.		X	X		C	C
0x32FE	4148	DC-link Imbalance	An imbalance across the DC-link capacitors is detected. The imbalance can be caused by a component fault of the DC link. If the fault remains after resetting the drive, service is required.		X	X		C	
0x32FE	4149	DC-link Short Circuit	An internal short circuit is detected in the DC link. Service is required.				X	C	C
0x32FE	4150	DC Capacitor Short Circuit	A short circuit in a DC-link capacitor is detected. Service is required.			X		C	C
0x32FE	4151	DC-link Short Circuit 2	A short circuit in the DC-link capacitor is detected. Service is required.	X			X	C	

Group number (hex)	Number (decimal)	Display name	Description	Type of event				Inverter and brake chopper action	
				I	W	F	PF	Inverter	Brake
0x32FF	4147	DC-link Voltage Ripple	Excessive voltage ripple has been detected on the main DC-link capacitors. This can be caused by an imbalance of the grid. Reduce the output power.		X	X		C	
0x4110	4099	Ambient Temp. High	The ambient temperature is too high. Check the temperature and cooling conditions. Lower the temperature or improve the cooling conditions.		X				
0x4210	4103	Inverter Temp. Limit	The temperature of the inverter heat sink is at the upper limit of the normal temperature range. Check cooling and heat sink conditions. Reduce the output current or ambient temperature. The drive may derate if the temperature is not lowered.		X				
0x4210	4104	Inverter Temp. High 1	The temperature of the inverter heat sink has exceeded the normal temperature level. Check cooling and heat sink conditions. Reduce the output current or ambient temperature.		X	X		C	C
0x4210	4105	Inverter Temp. High 2	The temperature of the inverter heat sink has reached a critical level. Check cooling and heat sink conditions. Reduce the output current to avoid a protected fault.		X	X		C	C
0x4210	4107	Brake Chopper Temp. Limit	The temperature of the brake chopper heat sink is at the upper limit of the normal temperature range. Check cooling and heat sink conditions. Reduce the generated regenerative power.		X				
0x4210	4108	Brake Chopper Temp. High 1	The temperature of the brake chopper heat sink has exceeded the normal temperature range. Check cooling and heat sink conditions. Reduce the generated regenerative power.		X	X		C	C
0x4210	4109	Brake Chopper Temp. High 2	The temperature of the brake chopper heat sink has reached a critical level. Check cooling and heat sink conditions. Reduce the generated regenerative power.		X	X		C	C
0x4210	4110	IGBT Temp. High	An inverter IGBT overtemperature has been detected. Reduce the ambient temperature, the output current and/or the switching frequency. Check the cooling and the condition of the heat sink.			X		C	C
0x4210	4113	Rectifier Temp. Limit	The temperature of the rectifier heat sink is at the upper limit of the normal temperature range. Check cooling and heat sink conditions. Reduce the output power (torque, speed) or the ambient temperature.		X				
0x4210	4114	Rectifier Temp. High 1	The temperature of the rectifier heat sink has exceeded the normal temperature range. Check cooling and heat sink conditions. Reduce the output power (torque, speed) or the ambient temperature.		X	X		C	C



Group number (hex)	Number (decimal)	Display name	Description	Type of event				Inverter and brake chopper action	
				I	W	F	PF	Inverter	Brake
0x4210	4115	Rectifier Temp. High 2	The temperature of the rectifier heat sink has reached a critical level. Check cooling and heat sink conditions. Reduce the output power (torque, speed) or the ambient temperature.		X	X		C	C
0x4210	4125	IGBT Temp. High	An inverter IGBT temperature has reached a critical value. Reduce the drive's output current if possible to avoid a protected fault.			X		C	C
0x4210	4200	Power Option Temp. High 1	The temperature of a power option has exceeded the normal temperature range. Check the cooling conditions. Reduce the load or the ambient temperature.		X	X		RC	C
0x4210	4201	Power Option Temp. High 2	The temperature of a power option has reached a critical level. Check the cooling conditions. Reduce the load or the ambient temperature.		X	X		RC	C
0x4210	4203	Power Option Temp. Limit	The temperature of a power option component is at the upper limit of the normal temperature. Check the cooling conditions. Reduce the load or the ambient temperature.		X				
0x4220	4102	Ambient Temp. Low	The drive is operated at a too low ambient temperature. Check the ambient temperature. Increase the ambient temperature or consider an external heater to increase the temperature around the drive.		X	X		C	C
0x4220	4106	Brake Chopper Temp. Low	The temperature of the brake chopper heat sink is too low. Check the ambient temperature. Increase the ambient temperature or consider an external heater to increase the temperature around the drive.		X	X		C	C
0x4220	4112	Rectifier Temp. Low	The temperature of the rectifier heat sink is too low. Check the ambient temperature. Increase the ambient temperature or consider an external heater to increase the temperature around the drive.		X	X		C	C
0x4220	4202	Power Option Temp. Low	The temperature of a power option component is too low. Check the ambient temperature. Increase the ambient temperature or consider an external heater to increase the temperature around the power option.		X	X		RC	C
0x4280	5132	Temp. Protection 1	Temperature protection 1 is triggered. The temperature has exceeded the configured value.		X	X		RC	
0x4280	5133	Temp. Protection 2	Temperature protection 2 is triggered. The temperature has exceeded the configured value.		X	X		RC	
0x4280	5134	Temp. Protection 3	Temperature protection 3 is triggered. The temperature has exceeded the configured value.		X	X		RC	
0x4280	5135	Temp. Protection 4	Temperature protection 4 is triggered. The temperature has exceeded the configured value.		X	X		RC	

Group number (hex)	Number (decimal)	Display name	Description	Type of event				Inverter and brake chopper action	
				I	W	F	PF	Inverter	Brake
0x4280	5136	Temp. Protection 5	Temperature protection 5 is triggered. The temperature has exceeded the configured value.		X	X		RC	
0x4280	5137	Temp. Protection 6	Temperature protection 6 is triggered. The temperature has exceeded the configured value.		X	X		RC	
0x4310	4117	Power Unit Temp. Limit	The internal air temperature of the drive is at the upper limit of the normal temperature range. Check cooling and heat sink conditions. Reduce the output power (torque, speed) or the ambient temperature.		X				
0x4310	4118	Power Unit Temp. High 1	The internal air temperature of the drive has exceeded its normal temperature range. Check cooling and heat sink conditions. Reduce the output power (torque, speed) or the ambient temperature.		X	X		C	C
0x4310	4119	Power Unit Temp. High 2	The internal air temperature of the drive has reached a critical value. Check cooling and heat sink conditions. Reduce the output power (torque, speed) or the ambient temperature.		X	X		C	C
0x4310	4121	Control Board Temp. Limit	The temperature of the control board is at the upper limit of the normal temperature range. Check cooling conditions and load of the control board. Reduce the load on the control board or the ambient temperature.		X				
0x4310	4122	Control Board Temp. High 1	The temperature of the control board has exceeded its normal temperature range. Check cooling conditions and load of the control board. Reduce the load on the control board or the ambient temperature.		X	X		C	C
0x4310	4123	Control Board Temp. High 2	The temperature of the control board has reached a critical level. Check cooling conditions and load of the control board. Reduce the load on the control board or the ambient temperature.		X	X		C	C
0x4320	4116	Power Unit Temp. Low	The internal air temperature of the drive is below the normal operating range. The drive is operated at a too low ambient temperature. Consider an external heater to avoid this warning or fault.		X	X		C	C
0x4320	4120	Control Board Temp. Low	The temperature of the control board is below the normal temperature range. The drive is operated at a too low ambient temperature. Check the ambient temperature. Increase the ambient temperature or consider an external heater to increase the temperature at the drive.		X	X		C	C
0x4380	5240	Cooling Monitor	The cooling signal is missing.		X	X		C	C
0x43FF	4124	Break Chopper Temperature Imbalance	There is a temperature imbalance between 1 or more brake chopper IGBT's.		X				

Group number (hex)	Number (decimal)	Display name	Description	Type of event				Inverter and brake chopper action	
				I	W	F	PF	Inverter	Brake
0x43FF	4126	IGBT Temperature Imbalance	There is a temperature imbalance between 1 or more IGBT's.		X				
0x43FF	4127	IGBT Temperature Imbalance	An excessive thermal imbalance between the IGBT modules has been detected. Check the condition of IGBT modules their connections the cooling and the driver boards.		X				
0x43FF	4131	Temperature Imbalance Brake IGBT	There is a temperature imbalance between 1 or more brake chopper IGBT's.		X	X		C	C
0x43FF	4132	IGBT temperature delta	There is a temperature imbalance between 1 or more IGBT's.		X	X		C	C
0x43FF	4204	Power Option Temp. Imbal. 1	The thermal imbalance between the power option components exceeds the normal operating range.		X	X		RC	C
0x43FF	4205	Power Option Temp. Imbal. 2	An excessive thermal imbalance between power option components has been detected.		X	X		RC	C
0x43FF	4206	Power Option Temp. Imbal. Limit	The thermal imbalance between the power option components is at the upper limit of the normal operating range.		X				
0x4480	5400	AHF High Temp. Derate	A too high temperature is detected in the connected AHF (Advanced Harmonic Filter). Output has been derated to 50%.			X			
0x4480	5401	AHF High Temp. Stop	A too high temperature has been detected in the connected AHF (Advanced Harmonic Filter). Operation of the drive has been stopped.			X		RC	
0x5112	4640	24V Supply Fault	The 24V supply is outside its normal operating range.				X	C	C
0x5114	4642	3.3V Supply Low	The voltage of the internal 3.3V supply is below its normal operating range.			X		C	C
0x5115	4643	28V Supply Low	The voltage of the internal 28V supply is below its normal operating range.			X		C	C
0x51FE	4644	Gate Driver Voltage Fault	The gate driver supply voltage is outside its normal operating range.				X	C	C
0x51FE	4653	Gate Driver Fault	A gate driver fault is detected or a link to the gate driver is broken.			X		C	C
0x51FF	4645	Power Board Supply Fault	A power supply fault on the power board has been detected.				X	C	C
0x51FF	4646	Power Supply Voltage	A power supply voltage is outside its normal operating range.				X	C	C

Group number (hex)	Number (decimal)	Display name	Description	Type of event				Inverter and brake chopper action	
				I	W	F	PF	Inverter	Brake
0x5210	4378	Current Sensor Fault	A defective current sensor or an error in the calibration of the current sensors has been detected.			X		C	C
0x5400	5173	Power Limit Timeout Regenerative	The drive has exceeded the allowed time in power limit			X		C	
0x5400	5174	Power Limit Timeout Motoring	The drive has exceeded the allowed time in power limit			X		C	
0x54EB	4641	24V Backup Mode	The drive is in 24V backup mode. The control section (including parameter configurations) and installed options are kept operational.	X					
0x54EC	4647	Function Disabled	The protection logic keeps the trip active until the configuration of the power unit protection levels is ready.			X		C	C
0x54ED	4128	Control Fan Failure	The control board cooling fan is not running at the commanded speed.		X				
0x54EE	4129	Main Fan Failure	The main cooling fan is not following its reference speed. Check the fan's wiring and whether its blocked or polluted. Replace the fan if necessary.		X				
0x54EE	4133	LCL Fan Speed Fault	LCL cooling fan not tracking commanded output.			X		C	C
0x54EF	4130	Internal Fan Failure	The internal fan is running below its reference speed. Check the fan's wiring and whether its blocked or polluted. Replace the fan if necessary.		X				
0x54F0	4628	STO Activated	The Safe Torque-Off (STO) is activated and an unintended restart is prevented until the STO-request has been reset.		X			C	
0x54F0	4629	STO Fault Ch. A	The Safe Torque-Off (STO) is activated due to a discrepancy fault: Channel A is not activated, while channel B is activated.			X		C	C
0x54F0	4630	STO Fault Ch. B	The Safe Torque-Off (STO) is activated due to a discrepancy fault: Channel B is not activated, while channel A is activated.			X		C	C
0x5530	4790	Control Data Error	A data error is detected in the control data database EEPROM.	X					
0x5530	4791	Invalid PUD	A data error has been detected in the power unit database EEPROM.			X		C	
0x6180	5260	Event Simulation	The event with the number 5260 is simulated.		X	X		C	C

Group number (hex)	Number (decimal)	Display name	Description	Type of event				Inverter and brake chopper action	
				I	W	F	PF	Inverter	Brake
0x6180	5264	Event Simulation SS2 Inst 1	Event simulation SS2 Instance 1.		X			C	C
0x6180	5265	Event Simulation SS2 Inst 2	Event simulation SS2 Instance 2.		X			C	C
0x6181	4980	A Digital Input terminal is unknown by system	A digital input terminal has been selected that is unknown by system. Maybe an option has been moved or removed.		X				
0x6181	4981	A Digital Output terminal is unknown by system	A digital output terminal has been selected that is unknown by system. Maybe an option has been moved or removed.		X				
0x6181	4982	An Analog Input terminal is unknown by system	An analog input terminal has been selected that is unknown by system. Maybe an option has been moved or removed.		X				
0x6181	4983	An Analog Output terminal is unknown by system	An analog output terminal has been selected that is unknown by system. Maybe an option has been moved or removed.		X				
0x6181	4984	A Digital Output occupied	A digital output is in use by an other function or fieldbus. If a Fieldbus has taken control over a terminal, it has priority over parameter selection		X				
0x6181	4985	An Analog Output occupied	An analog output is in use by an other function or fieldbus. If a Fieldbus has taken control over a terminal, it has priority over parameter selection		X				
0x61F4	4853	StartupOccurrence	This occurrence masks over various occurrences that might be active during startup, that we dont want to show the end user	X					
0x61F5	4854	Reset By Demand	Drive reset is requested by user, and will be performed shortly.	X				C	
0x61F6	4638	Drive to Drive Connection Lost	Drive to drive connection is lost.		X	X		C	C
0x61F7	4800	Low Storage Space	The available storage space for the file system is low.	X					
0x61F7	4801	Data Logger Storage	Volume restriction limits are preventing additional data logger capture files from being stored.		X				
0x61F7	4802	Event Logger Storage	Volume restriction limits are preventing additional event log capture files from being stored.		X				

Group number (hex)	Number (decimal)	Display name	Description	Type of event				Inverter and brake chopper action	
				I	W	F	PF	Inverter	Brake
0x61F8	4832	Node Discovery	Node discovery and configuration are in progress. The modulation is inhibited.	X				RC	C
0x61F8	4833	Node Commissioning	Nodes are being commissioned.		X			C	C
0x61F8	4834	Node Missing	A previously commissioned node is no longer available. The drive is waiting for the node to be available. If the node has been removed, recommission the drive.	X					
0x61F9	4855	Internal Fault	An internal fault has been detected. Cycle power, check the wiring if applicable, contact the service provider if the fault persists. Note the occurrence number for further troubleshooting directions.			X		RC	C
0x61F9	4856	Internal Fault	An internal fault has been detected (connection from controller). Cycle power, check the internal wiring, contact the service provider if the fault persists. Note the occurrence number for further troubleshooting directions.			X		C	C
0x61FA	4816	PLC Task Overrun	The high CPU load is inhibiting normal operation of the application (PLC task overrun).		X				
0x61FA	4817	PLC Runtime Error	The PLC runtime has stopped responding. The application has been halted.			X		C	C
0x61FB	4600	Option Communication Fault	A fault of the communication with an option has been detected. Cycle power, check that the option is properly installed, contact the Danfoss supplier or the service department if the fault persists. Note the occurrence number for further troubleshooting directions.			X		RC	C
0x61FB	4601	Internal Communication Fault	An internal communication fault has been detected. Cycle power, check the wiring if applicable, contact the service provider if the fault persists. Note the occurrence number for further troubleshooting directions.		X				
0x61FB	4602	Option Communication Fault	A fault of the communication with an option has been detected. Cycle power, check that the option is properly installed, contact the Danfoss supplier or the service department if the fault persists. Note the occurrence number for further troubleshooting directions.			X		C	C
0x61FB	4607	Internal Communication Fault	An internal communication fault has been detected. Cycle power, check the wiring if applicable, contact the Danfoss supplier or the service department if the fault persists. Note the occurrence number for further troubleshooting directions.			X		C	C

Group number (hex)	Number (decimal)	Display name	Description	Type of event				Inverter and brake chopper action	
				I	W	F	PF	Inverter	Brake
0x61FB	4631	Internal Communication Fault	An internal communication fault has been detected. Cycle power, check the wiring if applicable, contact the Danfoss supplier or the service department if the fault persists. Note the occurrence number for further troubleshooting directions.			X		RC	C
0x61FB	4632	Internal Communication Fault	An internal communication fault has been detected. Cycle power, check the wiring if applicable, contact the service provider if the fault persists. Note the occurrence number for further troubleshooting directions.		X				
0x61FC	4605	Internal Communication Fault	An internal communication fault has been detected. Cycle power, check the wiring if applicable, contact the service provider if the fault persists. Note the occurrence number for further troubleshooting directions.			X		C	C
0x61FC	4606	Internal Communication Fault	An internal communication fault has been detected. Cycle power, check the wiring if applicable, contact the Danfoss supplier or the service department if the fault persists. Note the occurrence number for further troubleshooting directions.			X		C	C
0x61FC	4639	High Speed Bus Sync Error	Internal error detected with high-speed bus connection to parallel control unit			X		C	C
0x61FC	4648	High Speed Bus Error	Internal error detected with high-speed bus connection to parallel control unit			X		C	C
0x61FC	4858	Internal Fault	An internal fault has been detected. The power system has not received the required reference for modulation. Cycle power, check the wiring if applicable, contact the Danfoss supplier or the service department if the fault persists. Note the occurrence number for further troubleshooting directions.		X	X		C	
0x61FC	4859	Internal Fault	An internal fault (connection from power system) has been detected. Cycle power, check the internal wiring, contact the service provider if the fault persists. Note the occurrence number for further troubleshooting directions.		X	X		C	
0x61FC	4860	Unexpected Time Adjust	An internal fault (unexpected time adjustment) has been detected. Cycle power, check the internal wiring, contact the service provider if the fault persists. Note the occurrence number for further troubleshooting directions.			X		C	C
0x61FC	4861	Synchronization Fault	An internal fault (time synchronization error between controller and power system) has been detected. Cycle power, check the internal wiring, contact the service provider if the fault persists. Note the occurrence number for further troubleshooting directions.			X		C	C

Group number (hex)	Number (decimal)	Display name	Description	Type of event				Inverter and brake chopper action	
				I	W	F	PF	Inverter	Brake
0x61FC	4862	PDS	Internal error detected with high-speed bus connection from controller.			X		C	C
0x61FC	4863	Internal Fault	An internal fault (connection with power system) has been detected. Cycle power, check the internal wiring, contact the service provider if the fault persists. Note the occurrence number for further troubleshooting directions.			X		C	C
0x61FD	4857	Software Update	The drive is currently performing an update of the software.	X					
0x61FF	4567	Restore Status	Provides information about the restore operation of a setting.	X					
0x6320	5301	Invalid Control Config.	An invalid control configuration is preventing operation.		X	X		C	
0x6320	5302	Start Blocked	Start of the motor is blocked. Check the Motor Ctrl. Ready Status Word for the cause.		X	X		C	
0x7080	5220	Brake Feedback Wrong State	Mechanical brake feedback is in a wrong state. Feedback state should reflect state of brake, except during opening or closing phases.		X				
0x7080	5221	Brake Priming Timeout	Brake priming has timed out. The drive could not produce the configured priming torque to open the brake safely.		X				
0x7080	5222	Brake Feedback Timeout	Brake feedback has timed out. The feedback signal is indicating that the mechanical brake has not opened or closed within the configured time.		X				
0x7110	5204	Brake Resistor Test Active	The Brake Resistor Test is active. Normal run of the drive is not possible.		X				
0x7110	5205	Brake Resistor Test Failed	The Brake Resistor Test was unsuccessful. Check the brake resistor and its connections.			X		C	C
0x7110	5206	Brake Resistor Test Successful	The test of the brake resistor is performed successfully.	X					
0x7111	4403	Brake Ch. Switch Shorted	A short circuit of the brake chopper switch has been detected, which can be dangerous. Disconnect power. Service is required.		X	X		C	
0x7113	4400	Brake Chopper Overload	A brake chopper overcurrent has been detected. Reduce the brake voltage level and check the rating of the brake resistor.		X		X	C	C
0x7113	4401	Brake Resistor Temp. High	The brake resistor temperature is too high. Check the rating of the brake resistor and cooling conditions. Reduce the generated regenerative power.		X	X		C	C



Group number (hex)	Number (decimal)	Display name	Description	Type of event				Inverter and brake chopper action	
				I	W	F	PF	Inverter	Brake
0x7113	4402	Brake Resistor Missing	The brake resistor or its connection is missing.		X	X		C	
0x7113	4404	Brake Failure	A brake failure is detected, further testing will clarify the failure source. Coast first to run the test.		X			C	
0x7120	4177	Motor Thermal Overload	A thermal overload of the motor has been detected. Check if the shaft torque is too high.		X	X		C	
0x7120	4178	Motor Speed High	The motor speed is above the normal operating range.		X	X		C	
0x7120	5200	AMA Active	The AMA (Automatic Motor Adaptation) is active. Normal run of the motor is not possible. Apply a start signal to run the AMA.		X				
0x7120	5201	AMA Motor Data	The motor data measurement of the AMA (Automatic Motor Adaptation) was unsuccessful.			X		C	C
0x7120	5202	AMA Motor Type	The motor type detection of the AMA (Automatic Motor Adaptation) was unsuccessful.			X		C	C
0x7120	5203	AMA Successful	The AMA (Automatic Motor Adaptation) has been performed successfully.	X					
0x7120	5300	Invalid Motor Data	Invalid motor data is preventing operation. Check the motor data settings.		X	X		C	
0x71FC	4179	AMA Current Low	The nominal current of the motor is too low for accurate results of automatic motor adaptation (AMA).		X				
0x71FD	4181	Low Motor Saliency For High Frequency Injection Mode	Motor saliency is too low for HF injection mode.		X	X		C	
0x71FE	4180	Rotor Angle Detection Error	Rotor angle detection has failed. This might be as the motor is not suited to the drive or the motor is missing.		X	X		C	
0x71FF	4379	CM Current High	An excessive common mode current has been detected in the LCL-filter.		X	X		C	
0x72FE	4417	Feedback Option Fault	The Feedback Option is indicating a fault condition.			X		C	C
0x7310	4418	Bad Speed Feedback	Speed Feedback value is not reliable.			X		C	
0x7580	5141	Control Panel Connection Lost	The connection to the control panel is lost. Control via control panel is released.						
0x7580	5142	PC Connection Lost	The connection to the PC tool is lost. PC control is released.						

Group number (hex)	Number (decimal)	Display name	Description	Type of event				Inverter and brake chopper action	
				I	W	F	PF	Inverter	Brake
0x75FC	4256	Address Conflict	The fieldbus has identified an Address Conflict on the network which made the device back off.		X				
0x75FC	4257	Ethernet Cable Fault	At link down a measurement is done to measure the distance to the far end of the cable, indicating where the fault has occurred. This warning occurs at distances > 4 m and Link State Change Down. Actual distance shown in detailed info.		X				
0x75FC	4258	Invalid Fieldbus Configuration	An issue due to an invalid configuration of the fieldbus connection has been detected. Features not supported by the device, mismatch between configured and actually available features or modules not available in the device. See additional detail info.	X					
0x75FC	4260	Redundant Controller Missing	One or more of the expected fieldbus controllers are missing.		X				
0x75FC	4261	Fieldbus Topology Mismatch	The current fieldbus topology does not match the topology provided at commissioning time.		X				
0x75FC	4263	Ethernet Link Status Changed	There has been detected a change of the Ethernet link status. Additional info has details about which port and state.	X					
0x75FC	4265	Ethernet Redundancy Error	Primary or backup physical paths has been detected missing.		X				
0x75FC	4266	X1 Cable Redundancy	Indicates that physical path from X1 interface to the controller is missing or wrongly configured.		X				
0x75FC	4267	X2 Cable Redundancy	Indicates that physical path from X2 interface to the controller is missing or wrongly configured.		X				
0x75FC	4268			X					
0x75FC	4269	Network Time Protocol	Information of Network Time Protocol server. See detailed info.	X					
0x75FC	4280	Controller Not in Run	Controller not in RUN state.	X					
0x75FC	4281	Interface Configuration Change	Interface configuration changed. See detailed info.	X					
0x75FD	4270			X					
0x75FD	4271			X					
0x75FD	4272			X					
0x75FD	4273	No EtherCAT Connection	No EtherCAT communication is currently established. Will happen during start-up until first connection is	X					

Group number (hex)	Number (decimal)	Display name	Description	Type of event				Inverter and brake chopper action	
				I	W	F	PF	Inverter	Brake
			established. Or if all connections has stopped (gracefully or disruptive)						
0x75FD	4282	No Modbus TCP Connection	No Modbus RTU communication is currently established. Occurs during start-up until first connection is established, or if all connections has stopped (gracefully or disruptive).	X					
0x75FE	4274				X				
0x75FE	4275				X				
0x75FE	4276				X				
0x75FE	4277	Loss of EtherCAT Connection	One or more of the fieldbus I/O connections has failed. This can happen when an established fieldbus I/O Connection has been disrupted by e.g cable break or powercut of PLC or other infrastructure components		X				
0x75FE	4283	Loss of Modbus RTU Connection	One or more of the fieldbus I/O connections has failed. This can happen when an established fieldbus I/O connection has been disrupted by for example cable break or powercut of PLC or other infrastructure components.		X				
0x75FF	4278	Primary Process Data Timeout	The fieldbus I/O data has not been updating any of the process data monitored by the primary process data monitor (Watchdog1). This can happen when the fieldbus has lost control or the current transferred I/O data is not valid.			X		C	C
0x75FF	4279	Secondary Process Data Timeout	The fieldbus I/O Data has not been updating any of the process data monitored by the secondary process data monitor (Watchdog2). This can happen when the fieldbus has lost control or the current transferred I/O data is not valid.			X		C	C
0x8100	5162	Alternate Control Place due to Fieldbus Timeout	Fieldbus process data timeout changed to alternate control place		X				
0x8331	5171	Torque Limit Timeout Motoring	The drive has exceeded the allowed time in torque limit.			X		C	
0x8331	5172	Torque Limit Timeout Regenerative	The drive has exceeded the allowed time in torque limit.			X		C	
0x8400	5210	Below Min. Speed	The Speed Monitor has detected that the speed is below the configured minimum speed.			X		C	C
0x8400	5211	Below Min. Speed	The Speed Monitor has detected that the speed is below the configured minimum speed.		X				

Group number (hex)	Number (decimal)	Display name	Description	Type of event				Inverter and brake chopper action	
				I	W	F	PF	Inverter	Brake
0x8400	5290	Speed Too High	The speed monitor has detected that the speed is above the configured maximum.			X		C	C
0x8400	5291	Speed Too High	The speed monitor has detected that the speed is above the configured maximum.		X				
0x8400	5292	Start Below Min. Speed	The start took too long. The speed has not reached the minimum speed within the time frame configured.			X		C	C
0x8611	4192	Position Following Error	The actual position is outside the allowed range of the position error window around a position demand value for longer than the position error delay.		X				
0x8612	4193	Position Limit	Motor position is outside the allowed range [Position-Min, PositionMax].		X	X		C	C
0x8612	4194	Position Command Rejected	Position command was rejected because of position software end limit.		X				
0x8612	4195	Hardware End Limit	The positioning controller detected that the drive is exceeding the hardware end Limits.		X	X		C	C
0x9080	5230	Lost Load Detected	Drive is not detecting any load on the motor shaft.						
0xF004	5270	Inertia Estimation Active	The drive is ready for performing the Inertia Estimation. A start command is required.		X				
0xF004	5271	Inertia Estimation Failed	The Inertia Estimation failed.			X		C	C
0xF004	5272	Inertia Estimation Successful	Inertia Estimation has been performed successfully.	X					
0xFF01	5123	External Exception 1	External Exception 1.			X		C	
0xFF01	5124	External Exception 2	External Exception 2.			X		C	
0xFFFF	4304	License Missing	A required license is missing.		X				
0xFFFF	4349	Authenticity Error	Files authenticity verification error occurred.			X		RC	C
0xFFFF	4350	Configuration Error	An invalid system configuration has been detected.		X	X		C	C
0xFFFF	4351	System Fault	A system fault has been detected. See additional information for details.			X		C	C
0xFFFF	4357	Firmware Crash	A firmware crash occurred and detailed information is provided.			X		C	C

\* indicates that the event's response can be configured using a parameter.

## Index

<b>A</b>	
Access Types.....	63
Application Software Structure.....	46
Automatic Motor Adaptation.....	10
Automation Energy Optimization.....	10
<b>B</b>	
Backup & Restore.....	41
Backup Data.....	42
Basic Functions.....	8
Basic setup of a Drive.....	51
<b>C</b>	
Control Panel.....	22
Control Panel Basic Configurations.....	24
Control Panel Display on Startup.....	24
Control Panel Elements.....	22
Control Panel Options.....	22
Control Panel Shortcuts.....	30
Controllers.....	9
<b>D</b>	
Data Types.....	62
Datalogger.....	36
<b>E</b>	
Event Summary.....	237
Events.....	236
<b>F</b>	
Faults.....	236
Functional Safety.....	203
<b>M</b>	
Mechanical Brake Control.....	176
Mobile apps.....	12
Motor and Motor Related Configurations.....	52
Motor Control Features.....	10
Motor Control Principle.....	10
Motor Types.....	10
MyDrive tools.....	12
MyDrive®.....	12
MyDrive® ecoSmart™.....	13
MyDrive® Harmonics.....	12
MyDrive® Insight.....	13
MyDrive® Select.....	12
<b>P</b>	
Parameter Group Navigation.....	27
Parameter Types.....	62
PC Control with MyDrive Insight.....	36
Process Control.....	165
Process Control Configuration.....	58
<b>R</b>	
Reading Parameter Tables).....	62
Readout Screens.....	25
Restore Data.....	43
<b>S</b>	
Set Intensity of Control Panel Display.....	26
Software tools.....	12
Speed Control Configuration.....	54
<b>T</b>	
Torque Control.....	158
Torque Control Configuration.....	56
<b>W</b>	
Warnings.....	236



**Danfoss A/S**  
Ulsnaes 1  
DK-6300 Graasten  
[vlt-drives.danfoss.com](http://vlt-drives.danfoss.com)

---

Danfoss can accept no responsibility for possible errors in catalogs, brochures, and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

---

