Λ



KIT TOP COVER ASSEMBLY

100054-3, 4, 6, 7, & 8.

Installation and servicing of Danfoss Turbocor® compressors by qualified and product trained personnel only. Follow these instructions and sound refrigeration/electrical/servicing practices relating to installation, commissioning, maintenance and service.				
Consult the appropriate	Never power compressor		Recover all refrigerant	
Danfoss Turbocor	without covers in place and	rated safety equipment when	from compressor in	
Compressors Inc. (DTC)	secured.		accordance with local	
Service Manual on		and/or components	codes and ensure pressure	
turbocor.danfoss.com for	Removing the mains input	energized with high voltage.	is fully vented before the	
detailed service instructions.	cover will expose you to a		removal of refrigerant	
	voltage hazard of up to 575V.	This equipment contains	containing components.	

Ensure the mains input power hazardous voltages that

death.

is off and locked out before

Before removing top cover, wait at least 20 minutes after isolating AC power to allow the high voltage capacitors to

removing cover.

discharge.

can cause serious injury or

1 - Introduction:

TOP COVER ASSEMBLY Removal and Installation Instructions.

Note: Care must be taken in removal and installation of the covers to prevent the screws from falling in to the power electronic compartment. Dropping cover screws can cause short circuit, energized components to explode, and damage to the power electronic parts of the compressor. Place the screws carefully after positioning the covers to minimize the risk of screws falling in to the power electronic areas.

2 - Suggested Tools:

The following tools are suggested:

Philips/torx screwdriver


3 - Removal Instructions:

- 1. Remove the mains input cover by releasing the four (4) screws and lift away the cover.
- 2. Release the nine (9) screws that secure the top cover and lift away the cover.


4 - Installation Instruction:



- 1. Ensure that no residue remains on the contact surfaces of top cover and casting sides.
- 2. Place the top cover and secure it with the nine (9) M5x15 screws according to the following sequence. Follow the sequence twice. The first time, only fasten screws half way down to allow for adjustments. Torque to 13 in.lb. on the second pass.



- 3. Ensure that no residue remains on the contact surfaces of the mains input cover and casting sides.
- 4. Place the new mains input cover and secure it with the four (4) M5x15 screws. Tighten according to the following sequence.



5. Follow the sequence twice. The first time, only fasten screws to half way down to allow for adjustment. Torque to 13 in.lb. on the second pass. Fasten the # 4 screw only once and use caution as to not overtighten this screw.

5 - Kit Contents

Kit numbers	Compressor models		
100054-3	KIT - COVER TOP ASSY (BLACK) EN/FR LABELS,		
	AVAILABLE TO ALL OEMS		
100054-4	KIT - COVER TOP ASSY (BLUE) DE LABELS, OEM		
	SPECIFIC		
100054-6	KIT - COVER TOP ASSY (GREEN) EN/FR LABELS		
100054-7	KIT – COVER TOP ASSEMBLY (BLUE – MOLDED)		
	EN/FR LABELS, OEM SPECIFIC		
100054-8	KIT – COVER TOP ASSEMBLY (GREEN – MOLDED)		
	DE LABELS, OEM SPECIFIC		

QTY	Part(s) Description	Picture(s)
1	COVER - TOP ASSEMBLY, BLUE/BLACK/GREEN	
9	SCREW, DOUBLE SEMS M5X15 TORX PAN HEAD	•••

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed.



All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.