

GE

# AF-60 LP™ Micro Drive

## Programming Guide



a product of  
**ecomagination**





---

**Contents**

<b>1 Safety</b>	<b>3</b>
1.1.1 High Voltage Warning	3
1.1.2 Safety Instructions	3
1.1.3 Software Version and Approvals	3
1.1.4 General Warning	3
1.1.5 IT Mains	4
1.1.6 Avoid unintended Start	4
1.1.8 Before Commencing Repair Work	4
<b>2 Introduction</b>	<b>5</b>
2.1.1 Drive Identification	5
2.1.2 AF-60 LP Micro Drive Model Number System Diagram	5
<b>3 Programming</b>	<b>7</b>
3.1 How to Program	7
3.1.1 Programming with DCT-10 Set-up Software	7
3.1.2 Programming with the Keypad	7
3.2 Status Menu	8
3.3 Quick Menu	8
3.4 Main Menu	9
<b>4 Parameter Descriptions</b>	<b>10</b>
4.1 Parameter Group 0: Operation/Display	10
4.2 Parameter Group 1: Load/Motor	13
4.3 Parameter Group 2: Brakes	18
4.4 Parameter Group 3: Reference/Ramps	20
4.5 Parameter Group 4: Limits/Warnings	24
4.6 Parameter Group 5: Digital In/Out	27
4.7 Parameter Group 6: Analog In/Out	31
4.7.3 6-1* Analog Input 1	31
4.8 Parameter Group 7: Controllers	35
4.9 Parameter Group 8: Communication	36
4.9.6 8-8* Bus communication diagnostics	38
4.10 Parameter Group 13: Logic Controller	39
4.10.1 13-** Programming Features	39
4.11 Parameter Group 14: Special Functions	44
4.12 Parameter Group 15: Drive Information	46
4.12.2 15-4* Drive Identification	46
4.13 Parameter Group 16: Data Readouts	47
5.1.1 Parameter Overview	49



5.2.1 Conversion Index	53
5.2.2 Change during operation	53
5.2.3 2-Set-up	53
5.2.4 Type	53
5.2.5 0-** Operation/Display	54
5.2.6 1-** Load/Motor	55
5.2.7 2-** Brakes	56
5.2.8 3-** Reference/Ramps	56
5.2.9 4-** Limits/Warnings	57
5.2.10 5-** Digital In/Out	57
5.2.11 6-** Analog In/Out	58
5.2.12 7-** Controllers	58
5.2.13 8-** Comm. and Options	59
5.2.14 13-** Logic Controller	60
5.2.15 14-** Special Functions	60
5.2.16 15-** Drive Information	61
5.2.17 16-** Data Readouts	62
<b>6 Troubleshooting</b>	<b>63</b>
6.1.1 Alarm, Warning and Extended Status Word	65
<b>Index</b>	<b>68</b>



# 1 Safety

## 1.1.1 High Voltage Warning

### **⚠ WARNING**

The voltage of the frequency converter is dangerous whenever it is connected to mains. Incorrect installation of the motor or frequency converter may cause damage to the equipment, serious injury or death. Consequently, it is essential to comply with the instructions in this manual as well as local and national rules and safety regulations.

## 1.1.2 Safety Instructions




### **CAUTION**

Before using functions directly or indirectly influencing personal safety (e.g. Fire Mode or other functions either forcing the motor to stop or attempting to keep it functioning) a thorough risk analysis and system test must be carried through. The system tests must include testing failure modes regarding the control signaling (analog and digital signals and serial communication).

- Make sure the frequency converter is properly connected to earth.
- Do not remove mains connections, motor connections or other power connections while the frequency converter is connected to power.
- Protect users against supply voltage.
- Protect the motor against overloading according to national and local regulations.
- The earth leakage current exceeds 3.5 mA.
- The [Off] key is not a safety switch. It does not disconnect the frequency converter from mains.

## 1.1.3 Software Version and Approvals

**Software Version  
Programming Guide  
AF-60 LP™ Micro Drive**

This Programming Guide can be used for all AF-60 LP™ Micro Drive frequency converters with software version 2.7X.  
The software version number can be read in *15-43 Software Version*.

Table 1.1

## 1.1.4 General Warning

### **⚠ WARNING**

#### **ELECTRICAL SHOCK HAZARD**

Touching the electrical parts may be fatal - even after the equipment has been disconnected from mains.

Also make sure that other voltage inputs have been disconnected (such as external DC bus power supplies). Be aware that there may be high voltage on the DC link even when the LEDs are turned off.

Before touching any potentially live parts of the frequency converter, wait at least 4 min for all sizes.

Shorter time is allowed only if indicated on the nameplate for the specific unit.

**CAUTION****Leakage Current**

The earth leakage current from the frequency converter exceeds 3.5 mA. According to IEC 61800-5-1 a reinforced Protective Earth connection must be ensured by means of a min. 10 mm<sup>2</sup> Cu or an additional PE wire - with the same cable cross section as the Mains wiring - must be terminated separately.

**Residual Current Device**

This product can cause a DC current in the protective conductor. Where a residual current device (RCD) is used for extra protection, only an RCD of Type B (time delayed) shall be used on the supply side of this product. Protective earthing of the frequency converter and the use of RCDs must always follow national and local regulations.

**CAUTION**

Motor overload protection is possible by setting *1-90 Motor Thermal Protection* to the value *Electronic overload trip*. For the North American market: Electronic overload functions provide class 20 motor overload protection, in accordance with NEC.

**WARNING**

Installation in high altitudes:

For altitudes above 2 km, please contact GE .

## 1.1.5 IT Mains

**CAUTION****IT Mains**

Installation on isolated mains source, i.e. IT mains.

Max. supply voltage allowed when connected to mains:  
440 V.


As an option, GE offers line filters for improved harmonics performance.

## 1.1.6 Avoid unintended Start

While the frequency converter is connected to mains, the motor can be started/stopped using digital commands, bus commands, references or via the drive Keypad.

- Disconnect the frequency converter from mains to avoid unintended start of any motors.
- To avoid unintended start, always press the [Off] key before changing parameters.

## 1.1.7 Disposal Instruction



Equipment containing electrical components must not be disposed of together with domestic waste.

It must be separately collected with electrical and electronic waste according to local and currently valid legislation.

Table 1.2

## 1.1.8 Before Commencing Repair Work

1. Disconnect AF-60 LP™ Micro Drive from mains (and external DC supply, if present).
2. Wait for 4 minutes (M1, M2 and M3) and 15 min (M4 and M5) for discharge of the DC-link.
3. Disconnect DC bus terminals and brake terminals (if present)
4. Remove motor cable



## 2 Introduction

### 2.1.1 Drive Identification

The nameplate sticker is located on the top of each frequency converter and shows the ratings, serial number, warnings catalog number, and other relevant data for each unit. See *Table 2.1* for details, how to read the type code string.



Illustration 2.1 This Example Shows the Nameplate Sticker

### 2.1.2 AF-60 LP Micro Drive Model Number System Diagram




Illustration 2.2



## 2.1.3 Warnings and Approvals

2

Symbols used in this Programming Guide.

### Symbols

The following symbols are used in this manual.



Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

### CAUTION

Indicates a situation that may result in equipment or property-damage-only accidents.

## 2.1.4 Abbreviations and Standards

Abbreviations:	Terms:	SI-units:	I-P units:
a	Acceleration	m/s <sup>2</sup>	ft/s <sup>2</sup>
AWG	American wire gauge		
Auto Tune	Automatic Motor Tuning		
°C	Celsius		
I	Current	A	Amp
I <sub>LIM</sub>	Current limit		
DCT	Drive Control Tool		
Joule	Energy	J=N·m	ft-lb, Btu
°F	Fahrenheit		
f	Frequency	Hz	Hz
kHz	Kilohertz	kHz	kHz
mA	Milliampere		
ms	Millisecond		
min	Minute		
M-TYPE	Motor Type Dependent		
Nm	Newton Metres		in-lbs
I <sub>M,N</sub>	Nominal motor current		
f <sub>M,N</sub>	Nominal motor frequency		
P <sub>M,N</sub>	Nominal motor power		
U <sub>M,N</sub>	Nominal motor voltage		
PELV	Protective Extra Low Voltage		
Watt	Power	W	Btu/hr, hp
Pascal	Pressure	Pa=N/m <sup>2</sup>	psi, psf, ft of water
I <sub>INV</sub>	Rated Drive Output Current		
RPM	Revolutions Per Minute		
SR	Size Related		
T	Temperature	C	F
t	Time	s	s,hr
T <sub>LIM</sub>	Torque limit		
U	Voltage	V	V

Table 2.1 Abbreviation and Standards table



### 3 Programming

#### 3.1 How to Program

##### 3.1.1 Programming with DCT-10 Set-up Software

The frequency converter can be programmed from a PC via RS-485 com-port by installing the DCT-10 Set-up Software.

This software can be downloaded from the GE Web site: [www.geelectrical.com/drives](http://www.geelectrical.com/drives)

##### 3.1.2 Programming with the Keypad

The keypad is divided into four functional groups:

1. Numeric display.
2. Menu key.
3. Navigation keys.
4. Operation keys and indicator lights (LEDs).

#### NOTE

Parameters should be changed in numerical order. Certain parameter values are affected by preceding changes.




Illustration 3.1 Keypad with Potentiometer

#### The display

Different information can be read from the display.

**Set-up number** shows the active set-up and the edit set-up. If the same set-up acts as both active and edit set-up, only that set-up number is shown (factory setting). When active and edit set-up differ, both numbers are shown in the display (Set-up 12). The number flashing, indicates the edit set-up.




Illustration 3.2 Indicating Set-up

The small digits to the left are the selected parameter number.




Illustration 3.3 Indicating Selected Parameter Number

The large digits in the middle of the display show the **value** of the selected parameter.




Illustration 3.4 Indicating Value of Selected Parameter

The right side of the display shows the **unit** of the selected parameter. This can be either Hz, A, V, kW, HP, %, s or RPM.




Illustration 3.5 Indicating Unit of Selected Parameter





**Motor direction** is shown to the bottom left of the display - indicated by a small arrow pointing either clockwise or counterclockwise.




Illustration 3.6 Indicating Motor Direction

Press the [Menu] key to select one of the following menus

### Status Menu

The Status Menu is either in *Readout Mode* or *Hand Mode*. In *Readout Mode* the value of the currently selected readout parameter is shown in the display.

In *Hand Mode* the local keypad reference is displayed.

### Quick Menu

Displays Quick Menu parameters and their settings. Parameters in the Quick Menu can be accessed and edited from here. Most applications can be run by setting the parameters in the Quick Menus.

### Main Menu

Displays Main Menu parameters and their settings. All parameters can be accessed and edited here.

### Indicator lights

- Green LED: The frequency converter is on.
- Yellow LED: Indicates a warning. See 6 *Troubleshooting*.
- Flashing red LED: Indicates an alarm. See 6 *Troubleshooting*.

### Navigation Keys

**[Back]:** For moving to the previous step or layer in the navigation structure.

**[▲] [▼]:** For maneuvering between parameter groups, parameters and within parameters.

**[OK]:** For selecting a parameter and for accepting changes to parameter settings.

Pressing [OK] for more than 1 s enters 'Adjust' mode. In 'Adjust' mode, it is possible to make fast adjustment by pressing [▲] [▼] combined with [OK].

Press [▲] [▼] to change value. Press [OK] to shift between digits quickly.

To exit 'Adjust' mode, press [OK] more than 1 s again with changes saving or press [Back] without changes saving.

### Operation Keys

A yellow light above the operation keys indicates the active key.

**[Hand ]:** Starts the motor and enables control of the frequency converter via the keypad.

**[Off/Reset]:** The motor stops except in alarm mode. In that case the motor will be reset.

**[Auto]:** The frequency converter is controlled either via control terminals or serial communication.

**[Potentiometer] Keypad:** The potentiometer works in two ways depending on the mode in which the frequency converter is running.

In *Auto Mode* the potentiometer acts as an extra programmable analog input.

In *Hand Mode* the potentiometer controls local reference.

## 3.2 Status Menu

After power up the Status Menu is active. Press [Menu] to toggle between Status, Quick Menu and Main Menu.

[▲] and [▼] toggles between the choices in each menu.

The display indicates the status mode with a small arrow above "Status".




Illustration 3.7 Indicating Status Mode

## 3.3 Quick Menu

The Quick Menu gives easy access to the most frequently used parameters.

1. To enter the Quick Menu, press [Menu] key until indicator in display is placed above *Quick Menu*.
2. Press [▲] [▼] to select either QM1 or QM2, then press [OK].
3. Press [▲] [▼] to browse through the parameters in the Quick Menu.
4. Press [OK] to select a parameter.
5. Press [▲] [▼] to change the value of a parameter setting.
6. Press [OK] to accept the change.
7. To exit, press either [Back] twice to enter *Status*, or press [Menu] once to enter *Main Menu*.




Illustration 3.8 Indicating Quick Menu Mode

### 3.4 Main Menu

The Main Menu gives access to all parameters.

1. To enter the Main Menu, press [Menu] key until indicator in display is placed above *Main Menu*.
2. Press [▲] [▼] to browse through the parameter groups.
3. Press [OK] to select a parameter group.
4. Press [▲] [▼] to browse through the parameters in the specific group.
5. Press [OK] to select the parameter.
6. Press [▲] [▼] to set/change the parameter value.
7. Press [OK] to accept the value.
8. To exit, press either [Back] twice to enter *Quick Menu*, or press [Menu] once to enter *Status*.




Illustration 3.9 Indicating Main Menu Mode



## 4 Parameter Descriptions

### 4.1 Parameter Group 0: Operation/Display

#### 0-03 Regional Settings

**Option:**                      **Function:**

		In order to meet the needs for different default settings in different parts of the world, <i>0-03 Regional Settings</i> , is implemented in the frequency converter. The selected setting influences the default setting of the motor nominal frequency.
[0]	International	Sets default of <i>1-23 Motor Frequency</i> , to 50 Hz, shows <i>1-20 Motor Power</i> in kW.
[1] *	US	Sets default of <i>1-23 Motor Frequency</i> , to 60 Hz, shows <i>1-20 Motor Power</i> in HP. <b>NOTE</b> This parameter cannot be changed while motor runs.

#### 0-04 Operating State at Power-up (Hand Mode)

**Option:**                      **Function:**

		This parameter controls whether or not the frequency converter start running the motor when powering up after a power down in Hand mode. <b>NOTE</b> If keypad with potentiometer is mounted, reference is set according to actual potentiometer value.
[0]	Resume	Frequency converter starts in same Hand or Off State as when powered off. Local reference is stored and used after power-up.
[1] *	Forced Stop, Ref=Old	Frequency converter powers up in Off State meaning that motor is stopped after power up. Local reference is stored and used after power-up.
[2]	Forced Stop, Ref=0	Frequency converter powers up in Off State meaning that motor is stopped after power up. Local reference is set to 0. Thus motor will not start running before local reference has been increased.

#### 4.1.1 0-1\* Set-up Handling

User-defined parameters and miscellaneous external inputs (eg. bus, keypad, analog/digital inputs, feedback, etc.) controls the functionality of the frequency converter.

A complete set of all parameters controlling the frequency converter is called a set-up. The frequency converter contains 2 set-ups, *Set-up 1* and *Set-up 2*.

Furthermore, a fixed set of factory settings can be copied into one or more set-ups.

Some of the advantages of having more than one set-up in the frequency converter are

- Run motor in one set-up (Active Set-up) while updating parameters in another set-up (Edit Set-up)
- Connect various motors (one at a time) to frequency converter. Motor data for various motors can be placed in different set-ups.
- Rapidly change settings of frequency converter and/or motor while motor is running (eg. ramp time or preset references) via bus or digital inputs.

The *Active Set-up* can be set as *Multi Set-up* where the active set-up is selected via input on a digital input terminal and/or via the bus control word.

#### NOTE

**Factory Set-up cannot be used as Active Set-up.**

#### 0-10 Active Set-up

**Option:**                      **Function:**

		<p><i>Active Set-up</i> controls the motor. Shifts between set-ups can only happen when</p> <ul style="list-style-type: none"> <li>• the motor is coasted</li> </ul> <p>OR</p> <ul style="list-style-type: none"> <li>• the set-ups between which the shift happens are linked to each other (see <i>0-12 Linked Set-ups</i>).</li> </ul> <p>If changing between set-ups that are not linked, the change will not happen before motor is coasted.</p> <p><b>NOTE</b> The motor is only considered stopped when it is coasted.</p>
--	--	---



**0-10 Active Set-up**

Option:	Function:
[1 ] * Set-up 1	Set-up 1 is active.
[2] Set-up 2	Set-up 2 is active.
[9] Multi Set-up	Select the active set-up via digital input and/or bus, see 5-1* <i>Digital Inputs</i> choice [23].

**0-11 Edit Set-up**

Option:	Function:
	The <i>Edit Set-up</i> is for updating parameters in the frequency converter from either keypad or bus. It can be identical or different from the <i>Active Set-up</i> . All set-ups can be edited during operation, independently of the active set-up.
[1 ] * Set-up 1	Update parameters in <i>Set-up 1</i> .
[2] Set-up 2	Update parameters in <i>Set-up 2</i> .
[9] Active Set-up	Update parameters in set-up selected as <i>Active Set-up</i> (see 0-10 <i>Active Set-up</i> ).

**0-12 Link Set-ups**

Option:	Function:
	The link ensures synchronizing of the “not changeable during operation” parameter values enabling shift from one set-up to another during operation. If the set-ups are not linked, a change between them is not possible while the motor is running. Thus the set-up change does not occur until the motor is coasted.
[0] Not linked	Leaves parameters unchanged in both set-ups and cannot be changed while motor runs.
[1 ] * Linked	Copy parameters “not changeable during operation” parameter values into presently selected <i>Edit Set-up</i> . <b>NOTE</b> This parameter cannot be changed while motor runs.

**0-31 Custom Readout Min Scale**

Range:	Function:
0.00 * [0.00–9999.00 ]	It is possible to create a customized readout related to the output frequency of the unit. The value entered in 0-31 <i>Custom Readout Min Scale</i> will be shown at 0 Hz. The readout can be shown in the keypad display when in Status Mode or it can be read in 16-09 <i>Custom Readout</i>

**0-32 Custom Readout Max Scale**

Range:	Function:
100.0* [0.00–9999.00]	It is possible to create a customized readout related to the output frequency of the unit. The value entered in 0-32 <i>Custom Readout Max Scale</i> will be shown at the frequency programmed in 4-14 <i>Motor Speed High Limit</i> . The readout can be shown in the keypad

**0-32 Custom Readout Max Scale**

Range:	Function:
	display when in Status Mode or it can be read in 16-09 <i>Custom Readout</i>

4.1.2 0-4\* Keypad

The frequency converter can operate in the following three modes: *Hand*, *Off* and *Auto*.

*Hand*: The frequency converter is locally operated and does not allow any remote control. By activating Hand a start signal is given.

*OFF*: The frequency converter stops with a normal stop ramp. When Off is chosen the frequency converter can only be started by pressing either Hand or Auto on the keypad.

*Auto*: In Auto-mode the frequency converter can be remote controlled (bus/digital).

**0-40 [Hand ] Key on Keypad**

Option:	Function:
[0] Disabled	[Hand] key has no function.
[1 ] * Enabled	[Hand] key is functional.

**0-41 [Off/Reset] Key on Keypad**

Option:	Function:
[0] Disable Off/Reset	[Off/Reset] key has no function.
[1 ] * Enable Off/Reset	Stop signal and reset of any faults.
[2] Enable Reset Only	Reset only. Stop (Off) function is disabled.

**0-42 [Auto] Key on Keypad**

Option:	Function:
[0] Disabled	[Auto] key has no function.
[1 ] * Enabled	[Auto] key is functional.

4.1.3 0-5\* Copy/Save

**0-50 Keypad Copy**

Option:	Function:
	The detachable keypad of the frequency converter can be used for storing setups, and thus for transferring data when moving parameter settings from one frequency converter to another. <b>NOTE</b> <i>Keypad Copy</i> can only be activated from the keypad and ONLY when the motor is coasted.
[1] All to keypad	Copy all setups from the frequency converter into the keypad.
[2] All from keypad	Copy all setups from keypad to frequency converter.
[3] Size independent from keypad	Copy non motor size dependent data from keypad to frequency converter.



## 0-51 Set-up Copy

Option:                      Function:

		Use this function to copy a set-up content into the <i>Edit Set-up</i> . In order to be able to make a set-up copy ensure that <ul style="list-style-type: none"> <li>the motor is coasted</li> <li>0-10 <i>Active Set-up, Active Set-up</i>, is set to either [1] <i>Set-up 1</i> or [2] <i>Set-up 2</i></li> </ul> <p><b>NOTE</b> The keyboard/parameter database are blocked while Set-up Copy is running.</p>
[0] *	No Copy	Copy function is inactive
[1]	Copy from Set-up 1	Copy from <i>Set-up 1</i> to edit set-up chosen in 0-11 <i>Edit Set-up</i> .
[2]	Copy from Set-up 2	Copy from <i>Set-up 2</i> to edit set-up chosen in 0-11 <i>Edit Set-up</i> .
[9]	Copy from Factory Set-up	Copy from Factory Settings to edit set-up chosen in 0-11 <i>Edit set-up</i> .

## 4.1.4 0-6\* Password

## 0-60 (Main) Menu Password

Range:                      Function:

		Use password for protection against unintended change of sensitive parameters, eg. motor parameters.
0 *	[0-999]	Enter the password for access to Main Menu via the [Main Menu] key. Select the number that should allow for changing other parameter values. 0 means there is no password.

**NOTE**

A password has affect on the keypad - not on the bus communication.

**NOTE**

Pressing [Menu], [OK] and [▼] will unlock the password. This will automatically enter the parameter editing screen in Quick Menu or Main Menu.

## 0-61 Access to Main/Quick Menu w/o Password

Option:                      Function:

[0] *	Full access	Select [0] <i>Full Access</i> to disable the password in 0-60 (Main) <i>Menu Password</i> .
[1]	Keypad: Read Only	Select [1] <i>Read Only</i> to block unauthorized editing of Main/Quick menu parameter.
[2]	keypad: No Access	Select [2] <i>No Access</i> to block unauthorized editing and viewing of Main/Quick menu parameter.



## 4.2 Parameter Group 1: Load/Motor

### 1-00 Configuration Mode

Option:	Function:
	Use this parameter for selecting the application control principle to be used when a Remote Reference is active. <b>NOTE</b> Changing this parameter will reset 3-00 Reference Range, 3-02 Minimum Reference and 3-03 Maximum Reference to their default values. <b>NOTE</b> This parameter cannot be adjusted while motor runs.
[0] * Speed Open Loop	For normal speed control (References).
[3] Process Closed Loop	Enables process closed loop control. See parameter group 7-3* Process PI Control for further information on PI-controller.

### 1-01 Motor Control Principle

Option:	Function:
[0] U/f	Is used for parallel connected motors and/or special motor applications. The U/f settings are set in 1-55 U/f Characteristic -U and 1-56 U/f Characteristic -F. <b>NOTE</b> When running U/f control slip- and load compensations are not included.
[1] * Advanced Vector Control	Normal running mode, including slip- and load compensations.

### 1-03 Torque Characteristics

Option:	Function:
	With more torque characteristics it is possible to run low energy consuming, as well as high torque applications.
[0] * Constant Torque	Motor shaft output provides constant torque under variable speed control.
[2] Energy Savings	This function automatically optimizes energy consumption in centrifugal pump and fan applications. See 14-41 Energy Savings Minimum Magnetisation.

### 1-05 Hand Mode Configuration

Option:	Function:
	This parameter is only relevant when 1-00 Configuration Mode is set to [3] Process Closed Loop. The parameter is used for determining the reference or setpoint handling when changing from Auto Mode to Hand Mode on the keypad.
[0] Speed Open Loop	In Hand Mode the drive always runs in Open Loop configuration regardless of setting in 1-00 Configuration Mode. Local potentiometer (if

### 1-05 Hand Mode Configuration

Option:	Function:
	present) or Arrow up/down determines output frequency limited by Motor Speed High/Low Limit (4-14 Motor Speed High Limit and 4-12 Motor Speed Low Limit).
[2] * As configuration in 1-00 Configuration Mode.	If 1-00 Configuration Mode is set to [1] Open Loop function is as described above. If 1-00 Configuration Mode is set to [3] Process Closed Loop changing from Auto mode to Hand mode results in a setpoint change via local potentiometer or Arrow up/down. The change is limited by Reference Max/Min (3-02 Minimum Reference and 3-03 Maximum Reference).

## 4.2.1 1-2\* Motor Data

Enter the correct motor nameplate data (power, voltage, frequency, current and speed).

Run Auto Tune, see 1-29 Auto Tune.

Factory settings for advanced motor data, parameter group 1-3\* Adv. Motor Data, are automatically calculated.

### NOTE

Parameters in parameter group 1-2\* Motor Data cannot be adjusted while motor runs.

### 1-20 Motor Power [kW]/[HP] (P<sub>m,n</sub>)

Option:	Function:
	Enter motor power from nameplate data. Two sizes down, one size up from nominal AF-60 LP™ rating.
[1] 0.09 kW/0.12 HP	
[2] 0.12 kW/0.16 HP	
[3] 0.18kW/0.25 HP	
[4] 0.25 kW/0.33 HP	
[5] 0.37kW/0.50 HP	
[6] 0.55 kW/0.75 HP	
[7] 0.75 kW/1.00 HP	
[8] 1.10 kW/1.50 HP	
[9] 1.50 kW/2.00 HP	
[10] 2.20 kW/3.00 HP	
[11] 3.00 kW/4.00 HP	
[12] 3.70 kW/5.00 HP	
[13] 4.00 kW/5.40 HP	
[14] 5.50 kW/7.50 HP	
[15] 7.50 kW/10.0 HP	
[16] 11.00 kW/15.00 HP	
[17] 15.00 kW/20.00 HP	
[18] 18.50 kW/25.00 HP	
[19] 22.00 kW/29.50 HP	
[20] 30.00 kW/40.00 HP	



**NOTE**

Changing this parameter affects parameters 1-22 Motor Voltage to 1-25 Motor Frequency, 1-30 Stator Resistance, 1-33 Stator Leakage Reactance and 1-35 Main Reactance.

**1-22 Motor Voltage (U<sub>m,n</sub>)**

Range:	Function:
230/400 V [50-999 V]	Enter motor voltage from nameplate data.

**1-23 Motor Frequency (f<sub>m,n</sub>)**

Range:	Function:
60 Hz* [20-400 Hz]	Enter motor frequency from nameplate data.

**1-24 Motor Current (I<sub>m,n</sub>)**

Range:	Function:
M-type dependent* [0.01-100.00 A]	Enter motor current from nameplate data.

**1-25 Motor Nominal Speed (n<sub>m,n</sub>)**

Range:	Function:
M-type Dependent* [100-9999 RPM]	Enter motor nominal speed from nameplate data.

**1-29 Auto Tune**

Option:	Function:
	Use Auto Tune to optimize motor performance. <b>NOTE</b> This parameter cannot be changed while motor runs.  <ol style="list-style-type: none"> <li>Stop the frequency converter - make sure motor is at standstill</li> <li>Choose [2] Enable Auto Tune</li> <li>Apply start signal - Via keypad: Press [Hand] - Or in Remote On mode: Apply start signal on terminal 18</li> </ol>
[0] * Off	Auto Tune function is disabled.
[2] Enable Auto Tune	Auto Tune function starts running. <b>NOTE</b> To gain optimum tuning of the frequency converter, run Auto Tune on a cold motor.

**4.2.2 1-3\* Adv. Motor Data**

Adjust advanced motor data using one of these methods:

- Run Auto Tune on cold motor. The frequency converter measures value from motor.
- Enter X<sub>1</sub> value manually. Obtain value from motor supplier.
- Use R<sub>s</sub>, X<sub>1</sub>, and X<sub>2</sub> default setting. The frequency converter establishes setting based on motor nameplate data.

**NOTE**

These parameters cannot be changed while the motor runs.




Illustration 4.1

**1-30 Stator Resistance (R<sub>s</sub>)**

Range:	Function:
Depending on motor data* [Ohm]	Set stator resistance value.

**1-33 Stator Leakage Reactance (X<sub>1</sub>)**

Range:	Function:
Depending on motor data* [Ohm]	Set stator leakage reactance of motor.

**1-35 Main Reactance (X<sub>2</sub>)**

Range:	Function:
Depending on motor data* [Ohm]	Set motor main reactance.

**4.2.3 1-5\* Load Independent Setting**

This parameter group is for setting the load independent motor settings.

**1-50 Motor Magnetization at Zero Speed**

Range:	Function:
	This parameter enables different thermal load on motor when running at low speed.
100 %* [0-300%]	Enter a percentage of rated magnetizing current. If setting is too low, motor shaft torque may be reduced.



**1-52 Min. Speed Normal Magnetizing [Hz]**

Range:	Function:
0.0 Hz* [0.0-10.0 Hz]	Use this parameter along with 1-50 Motor Magnetizing at Zero Speed. Set frequency required for normal magnetizing current. If frequency is set lower than motor slip frequency, 1-50 Motor Magnetizing at Zero Speed is inactive.




Illustration 4.2

**1-55 U/f Characteristic - U**

Range:	Function:
0.0 V* [0.0-999.9 V]	This parameter is an array parameter [0-5] and is only functional when 1-01 Motor Control Principle is set to [0] U/f. Enter voltage at each frequency point to manually form a U/f characteristic matching motor. Frequency points are defined in 1-56 U/f characteristics - F.

**1-56 U/f Characteristic - F**

Range:	Function:
0.0 Hz* [0.0-1000.0 Hz]	This parameter is an array parameter [0-5] and is only functional when 1-01 Motor Control Principle is set to [0] U/f. Enter frequency points to manually form a U/f characteristic matching motor. Voltage at each point is defined in 1-55 U/f Characteristic - U. Make a U/f characteristic based on 6 definable voltages and frequencies, see Illustration 4.3. Simplify U/f characteristics by merging 2 or more points (voltages and frequencies), respectively, are set equal.




Illustration 4.3 U/f Characteristics

**NOTE**

For 1-56 U/f characteristics - F the following applies [0] ≤ [1] ≤ [2] ≤ [3] ≤ [4] ≤ [5]

**4.2.4 1-6\* Load Dependent Setting**

Parameters for adjusting the load-dependent motor settings.

**1-60 Low Speed Load Compensation**

Range:	Function:
100 %* [0-199 %]	Use this parameter to gain optimum U/f characteristic when running at low speed. Enter percentage in relation to load when motor runs at low speed. Change-over point is automatically calculated based on motor size.




Illustration 4.4





**1-61 High Speed Load Compensation**

Range:		Function:
		Use this parameter to obtain optimum load compensation when running at high speed.
100 %*	[0-199 %]	Enter percentage to compensate in relation to load when motor runs at high speed. Change-over point is automatically calculated based on motor size.

**1-62 Slip Compensation**

Range:		Function:
100 %*	[-400-399 %]	<p>Compensation for load dependent motor slip.</p> <p>Slip compensation is calculated automatically based on rated motor speed, <math>n_{M,N}</math>.</p> <p>Example: if 1-62 Slip Compensation is set to 100% and the 4 pole 1800 RPM motor has an actual nameplate RPM of 1750 RPM, then 50 RPM is added to the output frequency by the drive.</p> <p><b>NOTE</b> This function is only active when 1-00 Configuration Mode, is set to [0] Speed Open Loop and when 1-01 Motor Control Principle, is set to [1] Advanced Vector Control</p>

**1-63 Slip Compensation Time**

Range:		Function:
0.10 s	[0.05-5.00 s]	<p>Enter slip compensation reaction speed. A high value results in slow reaction whereas a low value results in quick reaction.</p> <p>If low-frequency resonance problems arise, use longer time setting.</p>

4.2.5 1-7\* Start Adjustments

Considering the need for various start functions in different applications, it is possible to select a number of functions in this parameter group.

**1-71 Start Delay**

Range:		Function:
		<p>The start delay defines the time to pass from a start command is given until the motor starts accelerating.</p> <p>Setting start delay to 0.0 s disables 1-72 Start Function, when start command is given.</p>
0.0 s*	[0.0-10.0 s]	<p>Enter the time delay required before commencing acceleration.</p> <p>1-72 Start Function is active during Start delay time.</p>

**1-72 Start Function**

Option:	Function:
[0] DC Hold/Delay Time	Motor is energised with DC holding current (2-00 DC Hold Current) during start delay time.
[1] DC Brake/Delay Time	Motor is energised with DC braking current (2-01 DC Brake Current) during start delay time.
[2] * Coast/Delay Time	Drive is coasted during start delay time ( Driveoff).

**1-73 Start Mode**

Option:	Function:
	<p>The Start Mode parameter is used to catch a spinning motor after eg. mains drop-out.</p> <p><b>NOTE</b> This function is not suitable for hoisting applications.</p>
[0] * Disabled	Catch a spinning load disabled.
[1] Enabled	<p>Frequency converter enabled to catch spinning motor.</p> <p><b>NOTE</b> When flying start is enabled 1-71 Start Delay, and 1-72 Start Function, have no function.</p>

4.2.6 1-8\* Stop Adjustments

To meet the need for various stop functions in different application these parameters offer some special stop features for the motor.

**1-80 Function at Stop**

Option:	Function:
	<p>The selected function at stop is active in following situations:</p> <ul style="list-style-type: none"> <li>Stop command is given and output speed is ramped down to <i>Min. Speed for Function at Stop</i>.</li> <li>Start command is removed (standby), and output speed is ramped down to <i>Min. Speed for Function at Stop</i>.</li> <li>DC-brake command is given, and DC-brake time has passed</li> <li>While running and calculated output speed is below <i>Min. Speed for Function at Stop</i>.</li> </ul>
[0] * Coast	The drive is coasted.
[1] DC hold	The motor is energised with a DC current. See 2-00 DC Hold Current for more information.

**1-82 Min. Speed For Function at Stop [Hz]**

Range:	Function:	
0.0 Hz*	[0.0-20.0 Hz]	Set the speed at which to activate 1-80 Function at Stop.



### 4.2.7 1-9\* Motor Temperature

With an estimated motor temperature monitor the frequency converter is able to estimate motor temperature without having a thermistor mounted. It is thus possible to receive a warning or an alarm, if motor temperature exceeds upper operational limit.

#### 1-90 Motor Thermal Protection

Option:	Function:
	Using Electronic Overload the motor temperature is calculated based on frequency, speed and time. GE recommends using The Electronic Overload function, if a thermistor is not present. <b>NOTE</b> calculation is based on motor data from parameter group 1-2* Motor Data.
[0] *	No Protection Disables temperature monitoring.
[1]	Thermistor Warning A thermistor connected to either digital or analog input gives a warning if upper limit of motor temperature range is exceeded, (see 1-93 Thermistor Resource).
[2]	Thermistor Trip A thermistor connected to either digital or analog input gives an alarm and makes the frequency converter trip if upper limit of motor temperature range is exceeded, (see 1-93 Thermistor Resource).
[3]	Electronic Overload Warning If calculated upper limit of motor temperature range is exceeded, a warning occurs.
[4]	Electronic Overload Trip If 90% of calculated upper limit of motor temperature range is exceeded, an alarm occurs and the frequency converter trips.

#### NOTE

When the Electronic Overload function has been selected the drive will store the recorded temperature at power down and this temperature will resume at power up regardless of the elapsed time. Changing 1-90 Motor Thermal Protection back to [0] No Protection will reset the recorded temperature.

#### 1-93 Thermistor Resource

Option:	Function:
	Select the thermistor input terminal.
[0] *	None No thermistor is connected.
[1]	Analog Input 53 Connect thermistor to analog input terminal 53. <b>NOTE</b> Analog input 53 cannot be selected for other purposes when selected as thermistor resource.
[6]	Digital input 29 Connect thermistor to digital input terminal 29. While this input functions as thermistor input, it will not respond to the function chosen in

#### 1-93 Thermistor Resource

Option:	Function:									
	5-13 Digital Input 29. The value of 5-13 Digital Input 29 remains however unchanged in parameter database while function is inactive.									
	<table border="1"> <thead> <tr> <th>Input Digital/ Analog</th> <th>Supply Voltage</th> <th>Threshold Cut-out Values</th> </tr> </thead> <tbody> <tr> <td>Digital</td> <td>10 V</td> <td>&lt;800 Ω ⇒ 2.9 kohm</td> </tr> <tr> <td>Analog</td> <td>10 V</td> <td>&lt;800 Ω ⇒ 2.9 kohm</td> </tr> </tbody> </table>	Input Digital/ Analog	Supply Voltage	Threshold Cut-out Values	Digital	10 V	<800 Ω ⇒ 2.9 kohm	Analog	10 V	<800 Ω ⇒ 2.9 kohm
Input Digital/ Analog	Supply Voltage	Threshold Cut-out Values								
Digital	10 V	<800 Ω ⇒ 2.9 kohm								
Analog	10 V	<800 Ω ⇒ 2.9 kohm								
<b>Table 4.1</b>										



### 4.3 Parameter Group 2: Brakes

#### 4.3.1 2-\*\* Brakes

#### 4.3.2 2-0\* DC-Brake

The purpose of DC-brake function is to brake a rotating motor by applying DC-current to the motor.

#### 2-00 DC Hold Current

Range:	Function:
	This parameter either holds the motor (holding torque) or pre-heats the motor. The parameter is active if <i>DC Hold</i> has been selected in either <i>1-72 Start Function</i> or <i>1-80 Function at Stop</i> .
50%* [0-100%]	Enter a value for holding current as a percentage of the rated motor current set in <i>1-24 Motor Current</i> . 100% DC holding current corresponds to $I_{M,N}$ .

#### NOTE

Avoid 100% current too long as it may overheat the motor.

#### 2-01 DC Brake Current

Range:	Function:
50 %* [0-150%]	Set DC-current needed to brake rotating motor. Activate DC-brake in one of the four following ways: <ol style="list-style-type: none"> <li>DC-brake command, see <i>5-1* Digital Inputs</i> choice [5]</li> <li>DC Cut-in function, see <i>2-04 DC-Brake Cut-in Speed</i></li> <li>DC-brake selected as start function, see <i>1-72 Start Function</i></li> <li>DC-brake in connection with <i>Flying Start</i>, <i>1-73 Flying Start</i>.</li> </ol>

#### 2-02 DC-Braking Time

Range:	Function:
	DC-braking time defines the period during which <i>DC-brake current</i> is applied to the motor.
10.0 s* [0.0-60 s]	Set the time DC-braking current, set in <i>2-01 DC Brake Current</i> , must be applied.

#### NOTE

If DC-brake is activated as start function, DC-brake time is defined by *holding time*.

#### 2-04 DC-Brake Cut-in Speed

Range:	Function:
0.0 Hz* [0.0-400.0 Hz]	Set DC-brake cut-in speed to activate DC braking current, set in <i>2-01 DC Brake Current</i> , when ramping down. When set to 0 the function is off.

#### 4.3.3 2-1\* Brake Energy Function

Use the parameters in this group for selecting dynamic braking parameters.

#### 2-10 Brake Function

Option:	Function:
	<p><b>Resistor Brake:</b> The resistor brake limits voltage in the intermediate circuit when the motor acts as generator. Without brake resistor, the frequency converter eventually trips. The resistor brake consumes surplus energy resulting from motor braking. A frequency converter with brake, stops a motor faster than without a brake, which is used in many applications. Requires connection of external brake resistor. An alternative to the resistor brake is the AC brake.</p> <p><b>NOTE</b> Resistor brake is only functional in frequency converters with integrated dynamic brake. An external resistor must be connected.</p> <p><b>AC Brake:</b> The AC brake consumes surplus energy by creating power loss in the motor. It is important to keep in mind that an increase in power loss causes motor temperature to rise.</p>
[0] * Off	No brake function.
[1] Resistor Brake	Resistor brake is active.
[2] AC Brake	AC brake is active.

#### 2-11 Brake Resistor (Ohm)

Range:	Function:
5 Ω* [5-5000 Ω]	Set brake resistor value.

#### 2-16 AC Brake, Max Current

Range:	Function:
100.0%* [0.0-150.0%]	Enter max. permissible current for AC-braking to avoid overheating of motor. 100% equals motor current set in <i>1-24 Motor Current</i> .



**2-17 Over-Voltage Control**

Option:	Function:
	Use Over-voltage Control (OVC) to reduce the risk of the frequency converter tripping due to an over voltage on the DC link caused by generative power from the load. An over-voltage occurs eg. if the ramp down time is set too short compared to the actual load inertia.
[0] *	Disabled The OVC is not active/required.
[1]	Enabled, not at stop OVC is running unless a stop signal is active.
[2]	Enabled OVC is running, also when a stop signal is active.

**NOTE**

If Resistor Brake has been chosen in 2-10 Brake Function the OVC is not active even though enabled in this parameter.

**2-22 Activating Mechanical Brake**

Range:	Function:
	<p>If the motor is stopped using ramp, the mechanical brake is activated when motor speed is less than <i>Active Brake Speed</i>. Motor is ramped down to stop in the following situations:</p> <ul style="list-style-type: none"> <li>• A start command is removed (stand by)</li> <li>• A stop command is activated</li> <li>• Quick-stop is activated (Q-stop ramp is used)</li> </ul>
0 Hz*	[0-400 Hz] Select motor speed at which mechanical brake activates when ramping down. Mechanical brake automatically activates if frequency converter trips or reports an alarm.

4.3.4 2-2\* Mechanical Brake

For hoisting applications an electro-magnetic brake is required. The brake is controlled by a relay, which releases the brake when activated.

The brake activates if the frequency converter trips or a coast command is given. Furthermore, it activates when motor speed is ramped down below the speed set in 2-22 *Active Brake Speed*.

**2-20 Release Brake Current**

Range:	Function:
0.00 A*	[0.00-100 A] Select motor current at which mechanical brake releases.
	<div style="border: 1px solid black; padding: 5px; display: inline-block;"> <p><b>⚠ CAUTION</b></p> <p>If start delay time has passed, and motor current is below <i>Release brake current</i>, frequency converter trips.</p> </div>



### 4.4 Parameter Group 3: Reference/Ramps

#### 4.4.1 3-\*\* Reference/Ramps

Parameters for reference handling, definition of limitations, and configuration of the frequency converter's reaction to changes

#### 4.4.2 3-0\* Reference Limits

Parameters for setting the reference unit, limits and ranges.

##### 3-00 Reference Range

Option:	Function:
	Select the range of reference and feedback signals.
[0] * Min to Max	Reference setpoint ranges can have positive values only. Select this if running in Process Closed Loop.
[1] -Max to +Max	Ranges can have both positive and negative values. If potentiometer is used to adjust motor running in both direction, set reference range to -Max Reference to Max Reference by par.= [1] Choose hand on mode by keypad. Adjust the potentiometer to minimum, the motor can run in anti-clockwise with max speed. Then adjust the potentiometer to maximum, the motor will ramp down to 0 and run clockwise with max speed.

##### 3-02 Minimum Reference

Range:	Function:
0.00* [-4999-4999]	Enter value for minimum reference. The sum of all internal and external references are clamped (limited) to the minimum reference value, 3-02 <i>Minimum Reference</i> .

##### 3-03 Maximum Reference

Range:	Function:
50.00* [-4999-4999]	Enter value for Maximum Reference. The sum of all internal and external references are clamped (limited) to the maximum reference value, 3-03 <i>Maximum Reference</i> .

#### 4.4.3 3-1\* References

Parameters for setting up the reference sources. Select the preset references for the corresponding digital inputs in parameter group, 5-1\* *Digital Inputs*.

##### 3-10 Preset Reference

Option:	Function:																																				
	Each parameter set-up contains 8 preset references which are selectable via 3 digital inputs or bus.  <table border="1"> <thead> <tr> <th>[18] Bit2</th> <th>[17] Bit1</th> <th>[16] Bit0</th> <th>[16] Bit0</th> </tr> </thead> <tbody> <tr><td>0</td><td>0</td><td>0</td><td>0</td></tr> <tr><td>0</td><td>0</td><td>1</td><td>1</td></tr> <tr><td>0</td><td>1</td><td>0</td><td>2</td></tr> <tr><td>0</td><td>1</td><td>1</td><td>3</td></tr> <tr><td>1</td><td>0</td><td>0</td><td>4</td></tr> <tr><td>1</td><td>0</td><td>1</td><td>5</td></tr> <tr><td>1</td><td>1</td><td>0</td><td>6</td></tr> <tr><td>1</td><td>1</td><td>1</td><td>7</td></tr> </tbody> </table> <b>Table 4.2 Parameter Group 5-1* Digital Inputs Option [16], [17] and [18]</b>	[18] Bit2	[17] Bit1	[16] Bit0	[16] Bit0	0	0	0	0	0	0	1	1	0	1	0	2	0	1	1	3	1	0	0	4	1	0	1	5	1	1	0	6	1	1	1	7
[18] Bit2	[17] Bit1	[16] Bit0	[16] Bit0																																		
0	0	0	0																																		
0	0	1	1																																		
0	1	0	2																																		
0	1	1	3																																		
1	0	0	4																																		
1	0	1	5																																		
1	1	0	6																																		
1	1	1	7																																		
[0.00] * -100.00-100.00%	Enter the different preset references using array programming. Normally, 100% = value set in 3-03 <i>Maximum Reference</i> . However, there are exceptions if 3-00 <i>Reference Range</i> is set to [0] <i>Min - Max</i> . Example 1: 3-02 <i>Minimum Reference</i> is set to 20 and 3-03 <i>Maximum Reference</i> is set to 50. In this case 0%=0 and 100%=50. Example 2: 3-02 <i>Minimum Reference</i> is set to -70 and 3-03 <i>Maximum Reference</i> is set to 50. In this case 0%=0 and 100%=70.																																				

##### 3-11 Jog Speed [Hz]

Range:	Function:
5.0 Hz [0.0-400.0 Hz]	Jog speed is a fixed output speed and overrules the selected reference speed, see parameter group 5-1* <i>Digital Inputs</i> option [14]. If the motor is stopped while in jog mode, the jog signal acts as a start signal. Removing the jog signal makes the motor run according to the selected configuration.  Select speed to function as jog speed.



**3-12 Catch Up/Slow Down Value**

Range:	Function:
0% * [0-100%]	<p>The <i>Catch-up/Slowdown</i> function is activated by an input command (see 5-1* <i>Digital Inputs</i>, choice [28]/[29]). If the command is active, the Catch-up/Slowdown value (in %) is added to the reference function as follows:</p> $Reference = Reference + Reference \times \frac{Catchup\ Slowdown}{100}$ $Reference = Reference - Reference \times \frac{Catchup\ Slowdown}{100}$ <p>When the input command is inactivated, the reference returns to its original value ie. Reference=Reference + 0.</p>

**3-14 Preset Relative Reference**

Range:	Function:
0.00% [-100.00-100.00%]	<p>Define fixed value in % to be added to variable value defined in 3-18 <i>Relative Scaling Reference Source</i>. The sum of fixed and variable values (labeled Y in illustration below) is multiplied with actual reference (labeled X in illustration). This product is added to actual reference</p> $X + X \times \frac{Y}{100}$ <div style="text-align: center;"> <p><b>Illustration 4.5</b></p> </div>

**3-15 Reference 1 Source**

Option:	Function:
	3-15 <i>Reference 1 Source</i> , 3-16 <i>Reference 2 Source</i> and 3-17 <i>Reference 3 Source</i> define up to three different reference signals. The sum of these reference signals defines the actual reference.
[0]	No Function No reference signal is defined.
[1] *	Analog Input 53 Use signals from analog input 53 as reference, see parameter group 6-1* <i>Analog Input 1</i> .
[2]	Analog Input 60 Use signals from analog input 60 as reference, see parameter group 6-2* <i>Analog Input 2</i> .
[8]	Pulse input 33 Use signals from pulse input as reference, see parameter group 5-5* <i>Pulse Input</i> .
[11]	Local Bus Reference Use signals from local bus as reference, see parameter group 8-9* <i>Bus Feedback</i> .
[21]	Keypad Potentiometer Use signals from keypad potentiometer as reference, parameter group 6-8* <i>Keypad Potentiometer</i> .

**3-16 Reference 2 Source**

Option:	Function:
	See 3-15 <i>Reference 1 Source</i> for description.
[0]	No Function No reference signal is defined.
[1]	Analog Input 53 Use signals from analog input 53 as reference.
[2] *	Analog Input 60 Use signals from analog input 60 as reference.
[8]	Pulse input 33 Use signals from pulse input as reference, see parameter group 5-5* <i>Pulse Input</i> .
[11]	Local Bus Reference Use signals from local bus as reference.
[21]	Keypad Potentiometer Use signals from keypad potentiometer as reference.

**3-17 Reference 3 Source**

Option:	Function:
	See 3-15 <i>Reference 2 Source</i> for description.
[0]	No Function No reference signal is defined.
[1]	Analog Input 53 Use signals from analog input 53 as reference.
[2]	Analog Input 60 Use signals from analog input 60 as reference.
[8]	Pulse input 33 Use signals from pulse input as reference, see parameter group 5-5* <i>Pulse Input</i> .
[11] *	Local Bus Reference Use signals from local bus as reference.
[21]	Keypad Potentiometer Use signals from keypad potentiometer as reference.

**3-18 Relative Scaling Reference Source**

Option:	Function:
	Select the source for a variable value to be added to the fixed value defined in 3-14 <i>Preset Relative Reference</i> .
[0] *	No Function The function is disabled
[1]	Analog Input 53 Select analog input 53 as relative scaling reference source.
[2]	Analog Input 60 Select analog input 60 as relative scaling reference source.
[8]	Pulse Input 33 Select pulse input 33 as relative scaling reference source.
[11]	Local Bus Reference Select local bus ref. as relative scaling reference source.
[21]	Keypad Potentiometer Select keypad potentiometer as relative scaling reference source.



### 4.4.4 3-4\* Accel/Decel 1

A linear ramp is characterized by ramping up at a constant speed until the desired motor speed has been reached. Some overshoot may be experienced when reaching speed, which may cause speed jerks for a short while before stabilizing.

An S-ramp accelerates more smoothly thus compensating for jerks when the speed is reached.

See *Illustration 4.6* for a comparison of the two ramp types.




Illustration 4.6

#### Accel/Decel Time

Acceleration time from 0 to nominal motor frequency (1-23 Motor Frequency).

Ramp down: Deceleration time from nominal motor frequency (1-23 Motor Frequency) to 0.

#### Limitation

Too short of an Accel time can result in Torque limit warning (W12) and/or DC over voltage warning (W7). Ramping is stopped when the frequency converter has reached Torque limit motor mode (4-16 Torque Limit in Motor Mode).

Too short of a Decel time can result in Torque limit warning (W12) and/or DC over voltage warning (W7). Ramping is stopped when the frequency converter reaches the Torque limit generator mode (4-17 Torque Limit in Generator Mode) and/or the internal DC over voltage limit.

#### 3-40 Accel/Decel 1 Type

Option:	Function:
[0] * Linear	Constant acceleration/deceleration.
[2] S-ramp	Smooth jerk compensated acceleration/deceleration.

#### 3-41 Accel Time 1

Range:	Function:
Size related* [0.05-3600.00 s]	Enter accel time from 0 Hz to rated motor frequency ( $f_{M,N}$ ) set in 1-23 Motor Frequency.

#### 3-41 Accel Time 1

Range:	Function:
	Choose a accel time ensuring that torque limit is not exceeded, see 4-16 Torque Limit in Motor Mode.

#### 3-42 Decel Time 1

Range:	Function:
Size related* [0.05-3600.00 s]	Enter decel time from rated motor frequency ( $f_{M,N}$ ) in 1-23 Motor Frequency to 0 Hz. Choose a decel time that does not cause over-voltage in due to regenerative operation of motor. Furthermore, regenerative torque must not exceed limit set in 4-17 Torque Limit in Generator Mode.

### 4.4.5 3-5\* Accel/Decel 2

See parameter group 3-4\* Ramp 1 for a description of ramp types.

#### NOTE

Accel/Decel 2 - alternative ramp times:

Changing from Accel/Decel 1 to Accel/Decel 2 is done via the digital input. See 5-1\* Digital Inputs, option [34].

#### 3-50 Accel/Decel 2 Type

Option:	Function:
[0] * Linear	Constant acceleration/deceleration.
[2] S-ramp	Smooth jerk compensated acceleration/deceleration.

#### 3-51 Accel Time 2

Range:	Function:
Size related* [0.05-3600.00 s]	Enter accel time from 0 Hz to rated motor frequency ( $f_{M,N}$ ) set in 1-23 Motor Frequency. Choose a accel time ensuring that torque limit is not exceeded, see 4-16 Torque Limit in Motor Mode.

#### 3-52 Decel Time 2

Range:	Function:
Size related [0.05-3600.00 s]	Enter decel time from rated motor frequency ( $f_{M,N}$ ) in 1-23 Motor Frequency to 0 Hz. Choose a decel time that does not cause over-voltage in due to regenerative operation of motor. Furthermore, regenerative torque must not exceed limit set in 4-17 Torque Limit in Generator Mode.



#### 4.4.6 3-8\* OtherAccel/Decel Ramps

This section contains parameters for Jog and Quick Stop Ramps.

With a Jog Ramp it is possible to both ramp up and down whereas, it is only possible to ramp down with the Quick Stop Ramp.

##### 3-80 Jog Accel/Decel Time

Range:	Function:
Size related* [0.05-3600.00 s]	A linear ramp applicable when Jog is activated. See parameter group 5-1* <i>Digital Inputs</i> , option [14]. Accel time = Decel time. Jog Ramp time starts upon activation of a jog signal via a selected digital input or serial communication port.

##### 3-81 Quick Stop Decel Time

Range:	Function:
Size related* [0.05-3600.00 s]	A linear ramp applicable when Q-stop is activated. See parameter group 5-1* <i>Digital Inputs</i> , option [4].





## 4.5 Parameter Group 4: Limits/Warnings

### 4.5.1 4-\*\* Motor Limits

Parameter group for configuring limits and warning.

### 4.5.2 4-1\* Motor Limits

Use these parameters for defining the speed, torque and current working range for the motor.

4-10 Reverse Lock		
Option:	Function:	
		If terminals 96, 97 and 98 are connected to U, V and W respectively, the motor runs clockwise when seen from the front. <b>NOTE</b> <b>This parameter cannot be adjusted while the motor is running</b>
[0] *	Reverse Lock	The motor shaft rotates in forward direction. This setting prevents the motor from running in reverse direction. If 1-00 Configuration Mode is set to close loop control, 4-10 Motor Speed Direction will be automatically set to clockwise.
[1]	Reverse only	The motor shaft rotates in reverse direction. This setting prevents the motor from running in forward direction.
[2] *	Both	With this setting the motor can run in both directions. However, the output frequency is limited to the range: Motor Speed Low Limit (4-12 Motor Speed Low Limit) to Motor Speed High Limit (4-14 Motor Speed High Limit). If 1-00 Configuration Mode is set to open loop control, 4-10 Motor Speed Direction will be automatically set to both direction

4-12 Motor Speed Low Limit		
Range:	Function:	
0.0 Hz*	[0.0-400.0 Hz]	Set the <i>Minimum Motor Speed Limit</i> corresponding to the minimum output frequency of the motor shaft. <b>NOTE</b> <b>As the minimum output frequency is an absolute value, it cannot be deviated from.</b>

4-14 Motor Speed High Limit		
Range:	Function:	
65.0 Hz*	[0.0-400.0 Hz]	Set the <i>Maximum Motor Speed</i> corresponding to the maximum output frequency of the motor shaft. <b>NOTE</b> <b>As the maximum output frequency is an absolute value, it cannot be deviated from.</b>

4-16 Torque Limit in Motor Mode		
Range:	Function:	
150 %*	[0-400%]	Set the torque limit for motor operation. The setting is not automatically reset to default when changing settings in 1-00 Configuration Mode to 1-25 Load & Motor.

4-17 Torque Limit in Generator Mode		
Range:	Function:	
100 %*	[0-400%]	Set the torque limit for generator mode operation. The setting is not automatically reset to default when changing settings in 1-00 Configuration Mode to 1-25 Load & Motor.

### 4.5.3 4-4\* Adjustable Warnings 2

4-40 Warning Frequency Low		
Range:	Function:	
0.00 Hz*	[0.0 Hz- Depend on the value of 4-41 Warning Frequency High]	Use this parameter to set a lower limit for the frequency range. When the motor speed falls below this limit, the display reads SPEED LOW. Warning bit 10 is set in 16-94 Ext. Status Word. Output Relay can be configured to indicate this warning. Keypad warning light does not light when this parameter set limit is reached.

4-41 Warning Frequency High		
Range:	Function:	
400.0 Hz*	[Depend on the value of 4-40 Warning Frequency Low -400.0 Hz]	Use this parameter to set a higher limit for the frequency range. When the motor speed exceeds this limit, the display reads SPEED HIGH. Warning bit 9 is set in 16-94 Ext. Status Word. Output Relay can be configured to indicate this warning. Keypad warning light does not light when this parameter set limit is reached.

### 4.5.4 4-5\* Adjustable Warnings

Parameter group containing adjustable warning limits for current, speed, reference and feedback.

4-50 Warning Current Low		
Range:	Function:	
		Use this parameter to set a lower limit for the current range. If current drops below the set limit, warning bit 8 is set in 16-94 Ext. Status Word.



**4-50 Warning Current Low**

Range:		Function:
		Output Relay can be configured to indicate this warning. keypad warning light does not light when this parameter's set limit is reached.
0.00 A*	[0.00-26.00 A]	Set value for low current limit.

**4-51 Warning Current High**

Range:		Function:
		Use this parameter to set an upper limit for the current range. If current exceeds the set limit, warning bit 7 is set in <i>16-94 Ext. Status Word</i> . Output Relay can be configured to indicate this warning. keypad warning light does not light when this parameter's set limit is reached.
26.00 A*	[0.00-26.00 A]	Set upper current limit.

**4-54 Warning Reference Low**

Range:		Function:
-4999.000*	[-4999.000- Depend on the value of 4-55 <i>Warning Reference High</i> ]	Use this parameter to set a lower limit for the reference range. When the actual reference falls below this limit, the display reads Reference Low. Warning bit 20 is set in <i>16-94 Ext. Status Word</i> . Output Relay can be configured to indicate this warning. Keypad warning light does not light when this parameter set limit is reached.

**4-55 Warning Reference High**

Range:		Function:
4999.000*	[Depend on the value of 4-54 <i>Warning Reference Low</i> - 4999.000]	Use this parameter to set a higher limit for the reference range. When the actual reference exceeds this limit, the display reads Reference High. Warning bit 19 is set in <i>16-94 Ext. Status Word</i> . Output Relay can be configured to indicate this warning. Keypad warning light does not light when this parameter set limit is reached.

**4-56 Warning Feedback Low**

Range:		Function:
-4999.000*	[-4999.000- Depend on the value of 4-57 <i>Warning Feedback High</i> ]	Use this parameter to set a lower limit for the feedback range. When the feedback falls below this limit, the display reads Feedback Low. Warning bit 6 is set in <i>16-94 Ext. Status Word</i> . Output Relay can be configured to

**4-56 Warning Feedback Low**

Range:		Function:
		indicate this warning. Keypad warning light does not light when this parameter set limit is reached.

**4-57 Warning Feedback High**

Range:		Function:
4999.000*	[Depend on the value of 4-56 <i>Warning Feedback Low</i> -4999.000]	Use this parameter to set a higher limit for the feedback range. When the feedback exceeds this limit, the display reads Feedback High. Warning bit 5 is set in <i>16-94 Ext. Status Word</i> . Output Relay can be configured to indicate this warning. Keypad warning light does not light when this parameter set limit is reached.

**4-58 Missing Motor Phase Function**

Option:		Function:
		A missing motor phase causes the motor torque to drop. This monitor may be disabled for special purposes (eg. small motors running pure U/f mode), but as there is a risk of overheating the motor, GE strongly recommends that the function is On. A missing motor phase causes the frequency converter to trip and report an alarm. <b>NOTE</b> <b>This parameter cannot be changed while motor runs.</b>
[0]	Off	Function is disabled.
[1] *	On	Function is enabled.

4.5.5 4-6\* Jump Frequencies

In some applications mechanical resonance may occur. Avoid resonance points by creating a Jump frequency. The frequency converter ramps through the Jump frequency area thereby passing mechanical resonance points quickly.

**4-61 Jump Frequency From [Hz]**

Range:		Function:
0.0 Hz*	[0.0-400.0 Hz]	Enter either the lower or upper limit of the speeds to be avoided. It does not matter whether Jump From or Jump To is the upper or lower limit, however the Jump Frequency function is disabled if the two parameters are set to the same value.



4-63 Jump Frequency To [Hz]

Array [2]

Range:

Function:

0.0 Hz*	[0.0-400.0 Hz]	Enter either the upper or lower limit of the speed area to be avoided. Make sure to enter the <b>opposite</b> limit of that in 4-61 <i>Jump Frequency From [Hz]</i> .
---------	----------------	--



## 4.6 Parameter Group 5: Digital In/Out

### 4.6.1 5-\*\* Digital In/Out

The following describes all digital input command functions and signals.

### 4.6.2 5-1\* Digital Inputs

Parameters for configuring the functions for the input terminals.

The digital inputs are used for selecting various functions in the frequency converter. All digital inputs can be set to the following:

[0]	No Operation	The frequency converter will not react to signals transmitted to the terminal.
[1]	Reset	Reset the frequency converter after a Trip/Alarm. Not all alarms can be reset.
[2]	Coast Inverse	Coasting stop, inverted input (NC). The frequency converter leaves the motor in free mode.
[3]	Coast and reset inv.	Reset and coasting stop inverted input (NC). The frequency converter resets and leaves the motor in free mode.
[4]	Quick stop inverse	Inverted input (NC). Generates a stop in accordance with the quick-stop ramp time set in 3-81 <i>Quick Stop Ramp Time</i> . When motor stops, shaft is in free mode.
[5]	DC-brake inv.	Inverted input for DC braking (NC). Stops motor by energizing it with DC current for a certain time period, see 2-01 <i>DC Brake Current</i> . Function is only active when value in 2-02 <i>DC-Braking Time</i> is different from 0.
[6]	Stop inv.	Stop inverted function. Generates stop function when selected terminal goes from logical level "1" to "0". Stop is performed according to selected ramp time.
[8]	Start	Select start for a start/stop command. 1 = Start, 0 = stop.
[9]	Latched start	Motor starts if a pulse is applied for min. 2 ms. Motor stops when Stop inverse is activated.
[10]	Reversing	Change direction of motor shaft rotation. Reversing signal only changes direction of rotation; it does not activate start function. Select [2] <i>Both directions</i> in 4.10 <i>Motor Speed Direction</i> . 0 = normal, 1 = reversing.
[11]	Start reversing	Use for start/stop and for reversing at the same time. Signals on start [8] are not allowed at the same time. 0 = stop, 1 = start reversing.
[12]	Enable start forward	Use if motor shaft must rotate clockwise at start.

[13]	Enable start reverse	Use if motor shaft must rotate counter-clockwise at start.
[14]	Jog	Use for activating jog speed. See 3-11 <i>Jog Speed</i> .
[16]	Preset reference bit 0	Preset reference bit 0, 1 and 2 enables a choice between one of the eight preset references according to below.
[17]	Preset reference bit 1	Same as preset reference bit 0 [16], see 3-10 <i>Preset Reference</i> .
[18]	Preset reference bit 2	Same as preset reference bit 0 [16].
[19]	Freeze reference	Freeze actual reference. The frozen reference is now the point of enable/condition for Speed up and Speed down to be used. If Speed up/down is used, speed change always follows ramp 2 (3-51 <i>Ramp2 Ramp-up Time</i> and 3-52 <i>Ramp2 Ramp-down Time</i> ) in the range 3-02 <i>Minimum Reference</i> - 3-03 <i>Maximum Reference</i> .
[20]	Freeze output	Freeze the actual motor frequency (Hz). The frozen motor frequency is now the point of enable/condition for Speed up and Speed down to be used. If Speed up/down is used, the speed change always follows ramp 2 in the range 4-12 <i>Motor Speed Low Limit</i> - 4-14 <i>Motor Speed High Limit</i> . <b>NOTE</b> When freeze output is active, the frequency converter cannot be stopped via a low [8] <i>Start</i> signal. Stop the frequency converter via a terminal programmed for Coasting Inverse [2] or Coast and reset, inverse [3].
[21]	Speed up	Select Speed up and Speed down if digital control of the up/down speed is desired (motor potentiometer). Activate this function by selecting either Freeze reference or Freeze output. When Speed-up is activated for less than 400 ms. the resulting reference will be increased by 0.1%. If Speed-up is activated for more than 400 ms. the resulting reference will ramp according to ramp 2 in 3-51 <i>Ramp2 Ramp-up Time</i> .
[22]	Speed down	Same as Speed-up [21].
[23]	Setup select bit 0	Set 0-10 <i>Active set-up</i> to Multi set-up. Logic 0 = set up 1, Logic 1 = Set up 2.
[26]	Precise stop inverse (only terminal 33)	Prolong the stop signal to give a precise stop independent of scan time. The function is available for terminal 33 only.
[27]	Start, precise stop (only terminal 33)	As [26], but including Start.



[28]	Catch up	Select Catch up/Slow down to increase or reduce the resulting reference value by the percentage set in 3-12 <i>Catch Up/Slow Down Value</i>
[29]	Slow down	Same as Catch up [28]
[32]	Pulse input (only terminal 33)	Select Pulse input when using a pulse sequence as either reference or feedback. Scaling is done in parameter group 5-5* <i>Pulse Input</i>
[34]	Ramp bit 0	Logic 0=Ramp1, see parameter group 3-4* <i>Ramp1</i> Logic 1=Ramp2, see parameter group 3-5* <i>Ramp2</i> .
[60]	Counter A (up)	Input for counter A.
[61]	Counter A (down)	Input for counter A.
[62]	Reset counter A	Input for reset of counter A.
[63]	Counter B (up)	Input for counter B.
[64]	Counter B (down)	Input for counter B.
[65]	Reset counter B	Input for reset of counter B.

5-10 Terminal 18 Digital Input

**Option:**    **Function:**

[8] *	Start	Select function from available digital input range. See parameter group 5-1* <i>Digital Inputs</i> for choices.
-------	-------	---

5-11 Terminal 19 Digital Input

**Option:**    **Function:**

[10] *	Reversing	Select function from available digital input range. See parameter group 5-1* <i>Digital Inputs</i> for choices.
--------	-----------	---

5-12 Terminal 27 Digital Input

**Option:**    **Function:**

[1] *	Reset	Select function from available digital input range. See parameter group 5-1* <i>Digital Inputs</i> * for choices.
-------	-------	---

5-13 Terminal 29 Digital Input

**Option:**    **Function:**

[14] *	Jog	Select function from available digital input range. See parameter group 5-1* <i>Digital Inputs</i> for choices.
--------	-----	---

5-15 Terminal 33 Digital Input

**Option:**    **Function:**

[16] *	Preset bit 0	Select function from available digital input range. See parameter group 5-1* <i>Digital Inputs</i> for choices.
--------	--------------	---

4.6.3 5-3\* Digital Outputs

5-34 On delay, Terminal 42 Digital Output

**Range:**    **Function:**

0.01 s*	[0.00-600.00 s]	
---------	-----------------	--

5-35 Off delay, Terminal 42 Digital Output

**Range:**    **Function:**

0.01 s*	[0.00-600.00 s]	
---------	-----------------	--

4.6.4 5-4\* Relays

Parameter group for configuring timing and output functions for relays.

[0]	No Operation	Default for all digital and relay outputs.
[1]	Control Ready	Control board receives supply voltage.
[2]	Drive Ready	Frequency converter is ready for operation and applies supply signal on control board.
[3]	Drive Ready, Remote	Frequency converter is ready for operation in Auto mode.
[4]	Enable/No Warning	Frequency converter is ready for operation. No start or stop command is given. No warnings are present.
[5]	Drive Running	Motor is running.
[6]	Running/No Warning	Motor runs, and no warning are present.
[7]	Run in Range/No Warning	Motor runs within programmed current ranges, see 4-50 <i>Warning Current Low</i> and 4-51 <i>Warning Current High</i> . No warnings are present.
[8]	Run on ref/No Warning	Motor runs at reference speed.
[9]	Alarm	An alarm activates output.
[10]	Alarm on Warning	An alarm or warning activates output.
[12]	Out of Current Range	Motor current is outside range set in 4-50 <i>Warning Current Low</i> and 4-51 <i>Warning Current High</i> .
[13]	Below Current, low	Motor current is lower than set in 4-50 <i>Warning Current Low</i> .
[14]	Above Current, high	Motor current is higher than set in 4-51 <i>Warning Current High</i> .
[16]	Below Frequency, low	Motor speed is lower than set in 4-40 <i>Warning Frequency Low</i> .
[17]	Above Frequency, high	Motor speed is higher than set in 4-41 <i>Warning Frequency High</i> .
[19]	Below Feedback, low	Feedback is lower than set in 4-56 <i>Warning Feedback Low</i> .
[20]	Above Feedback, high	Feedback is higher than set in 4-57 <i>Warning Feedback High</i> .
[21]	Thermal Warning	Thermal warning is present when temperature exceeds limit in motor, frequency converter, brake resistor or thermistor.



[22]	Ready, No Thermal Warning	Frequency converter is ready for operation and no over-temperature warning is present.
[23]	Remote Ready, No Thermal Warning	Frequency converter is ready for operation in Auto mode, and no over-temperature warning is present.
[24]	Ready, Voltage OK	Frequency converter is ready for operation and mains voltage is within specified voltage range.
[25]	Reverse	Motor runs/is ready to run clockwise when logic = 0 and counter clockwise when logic = 1. Output changes as soon as reversing signal is applied.
[26]	Bus OK	Active communication (no time-out) via serial communication port.
[28]	Brake, No Warn	Brake is active, and no warnings are present.
[29]	Brake Ready/No Fault	Brake is ready for operation, and no faults are present.
[30]	Brake Fault (IGBT)	Protects frequency converter if fault on brake modules is present. Use relay to cut out main voltage from frequency converter.
[32]	Mech. Brake Control	Enables control of external mechanical brake, see parameter group 2-2* <i>Mechanical Brake</i> .
[36]	Control Word Bit 11	Bit 11 in control word controls relay.
[41]	Below Reference, low	Reference is lower than set in 4-54 <i>Warning Reference Low</i> .
[42]	Above Reference, high	Reference is higher than set in 4-55 <i>Warning Reference High</i> .
[51]	Local Reference Active	
[52]	Remote Reference Active	
[53]	No Alarm	
[54]	Start Cmd Active	
[55]	Running Reverse	
[56]	Drive in Hand Mode	
[57]	Drive in Auto Mode	
[60]	Comparator 0	See parameter group 13-1* <i>Comparators</i> . If comparator 0 is evaluated as TRUE, output goes high. Otherwise, it is low.
[61]	Comparator 1	See parameter group 13-1* <i>Comparators</i> . If comparator 1 is evaluated as TRUE, output goes high. Otherwise, it is low.
[62]	Comparator 2	See parameter group 13-1* <i>Comparators</i> . If comparator 2 is evaluated as TRUE, output goes high. Otherwise, it is low.

[63]	Comparator 3	See parameter group 13-1* <i>Comparators</i> . If comparator 3 is evaluated as TRUE, output goes high. Otherwise, it is low.
[70]	Logic Rule 0	See parameter group 13-4* <i>Logic Rules</i> . If Logic Rule 1 is evaluated as TRUE, output goes high. Otherwise, it is low.
[71]	Logic Rule 1	See parameter group 13-4* <i>Logic Rules</i> . If Logic Rule 2 is evaluated as TRUE, output goes high. Otherwise, it is low.
[72]	Logic Rule 2	See parameter group 13-4* <i>Logic Rules</i> . If Logic Rule 3 is evaluated as TRUE, output goes high. Otherwise, it is low.
[73]	Logic Rule 3	See parameter group 13-4* <i>Logic Rules</i> . If Logic Rule 3 is evaluated as TRUE, output goes high. Otherwise, it is low.
[81]	Logic Controller Digital Output B	See 13-52 <i>Logic Controller Action</i> . When Logic Controller Action [39] <i>Set dig. out. A high</i> is executed, input goes high. When Smart Logic Action [33] <i>Set dig. out. A low</i> is executed, input goes low.

5-40 Function Relay

**Option:**                      **Function:**

[0] *	No Operation	Select function from available relay output range.
-------	--------------	--

5-41 On delay, Relay

**Option:**                      **Function:**

[0.01 s] *	[0.00-600.00 s]	Enter the delay of the relay cut-in time. If the Selected Event condition changes before the On delay timer expires, the relay output is unaffected. The function to control the relay see 5-40 <i>Function Relay</i> .
------------	-----------------	---

5-42 Off delay, Relay

**Option:**                      **Function:**

[0.01 s] *	[0.00-600.00 s]	Enter the delay of the relay cut-off time. If the Selected Event condition changes before the off delay timer expires, the relay output is unaffected. The function to control the relay see 5-40 <i>Function Relay</i> .
------------	-----------------	---

4.6.5 5-5\* Pulse Input

Set 5-15 *Terminal 33 Digital Input* to choice [32] *pulse input*. Now terminal 33 handles a pulse input in the range from Low frequency, 5-55 *Terminal 33 Low Frequency*, to 5-56 *Terminal 33 High Frequency*. Scale frequency input via 5-57 *Terminal 33 Low Ref./Feedb. Value* and 5-58 *Terminal 33 High Ref./Feedb. Value*.



5-55 Terminal 33 Low Frequency

**Range:**                      **Function:**

20 Hz*	[20-4999 Hz]	Enter low frequency corresponding to low motor shaft speed (i.e. low reference value) in 5-57 Terminal 33 Low Ref./Feedb. Value.
--------	--------------	--

5-56 Terminal 33 High Frequency

**Range:**                      **Function:**

5000 Hz*	[21-5000 Hz]	Enter high frequency corresponding to high motor shaft speed (i.e. high reference value) in 5-58 Terminal 33 High Ref./Feedb. Value.
----------	--------------	--

5-57 Terminal 33 Low Ref./Feedb. Value

**Range:**                      **Function:**

0.000*	[-4999-4999]	Set reference/feedback value corresponding to low pulse frequency value set in 5-55 Terminal 33 Low Frequency.
--------	--------------	--

5-58 Terminal 33 High Ref./Feedb. Value

**Range:**                      **Function:**

50.000*	[-4999-4999]	Set reference/feedback value corresponding to high pulse frequency value set in 5-56 Terminal 33 High Frequency.
---------	--------------	--



### 4.7 Parameter Group 6: Analog In/Out

#### 4.7.1 6-\*\* Analog In/Out

Parameter group for configuring analog inputs and outputs.

#### 4.7.2 6-0\* Analog I/O Mode

Parameter group for setting up the analog I/O configuration.

#### 6-00 Live Zero Timeout Time

Range:	Function:
10 s* [1-99 s]	The Live Zero function is used for monitoring the signal on an analog input. If the signal disappears, a <i>Live Zero</i> warning is reported. Set delay time before <i>Live Zero Timeout Function</i> is applied (6-01 <i>Live Zero Timeout Time</i> ). If the signal reappears during the set delay, timer will be reset. When live zero is detected, the frequency converter freezes output frequency and starts <i>Live Zero Timeout</i> timer.

#### 6-01 Live Zero Timeout Function

Option:	Function:
[0] * Off	Function is disabled.
[1] Freeze output	Output frequency remains at value it had when live zero was detected.
[2] Stop	Frequency converter decels down to 0 Hz. Remove live zero error condition before restarting frequency converter.
[3] Jogging	Frequency converter accels to jog speed, see 3-11 <i>Jog Speed</i> .
[4] Max Speed	Frequency converter accels to Motor Speed High Limit, see 4-14 <i>Motor Speed High Limit</i> .
[5] Stop and Trip	Frequency converter decels down to 0 Hz and then trips. Remove live zero condition and activate reset before restarting the frequency converter.

#### 4.7.3 6-1\* Analog Input 1

Parameters for configuring scaling and limits for analog input 1 (terminal 53).

### NOTE

Micro switch 4 in position U:  
6-10 Terminal 53 Low Voltage and 6-11 Terminal 53 High Voltage are active.

Micro switch 4 in position I:  
6-12 Terminal 53 Low Current and 6-13 Terminal 53 High Current are active.




Illustration 4.7




Illustration 4.8

#### 6-10 Terminal 53 Low Voltage

Range:	Function:
0.07 V* [0.00-9.90 V]	This scaling value should correspond to minimum reference value set in 6-14 Terminal 53 Low Ref./Feedb. Value. See also 4.4 Parameter Group 3: Reference/Ramps. Enter low voltage value.

### CAUTION

The value must be set to min. 1 V in order to activate the Live Zero Timeout function in 6-01 *Live Zero Timeout Function*.





**6-11 Terminal 53 High Voltage**

Range:	Function:
	This scaling value should correspond to maximum reference value set in 6-15 Terminal 53 High Ref./Feedb. Value.
10.0 V* [0.10-10.00 V]	Enter high voltage value.

**6-12 Terminal 53 Low Current**

Range:	Function:
	This reference signal should correspond to minimum reference value set in 6-14 Terminal 53 Low Ref./Feedb. Value.
0.14 mA* [0.00-19.90 mA]	Enter low current value.

**CAUTION**

The value must be set to min. 2 mA in order to activate the Live Zero Timeout function in 6-01 Live Zero Timeout Function.

**6-13 Terminal 53 High Current**

Range:	Function:
	This reference signal should correspond to the maximum reference value set in 6-15 Terminal 53 High Ref./Feedb. Value.
20.00 mA* [0.10-20.00 mA]	Enter high current value.

**6-14 Terminal 53 Low Ref./Feedb. Value**

Range:	Function:
	The scaling value corresponding to the low voltage/low current set in 6-10 Terminal 53 Low Voltage and 6-12 Terminal 53 Low Current.
0.000* [-4999-4999]	Enter analog input scaling value.

**6-15 Terminal 53 High Ref./Feedb. Value**

Range:	Function:
	The scaling value corresponding to the high voltage/high current set in 6-11 Terminal 53 High Voltage and 6-13 Terminal 53 High Current.
50.000* [-4999.000-4999.000]	Enter analog input scaling value.

**6-16 Terminal 53 Filter Time Constant**

Range:	Function:
	A first-order digital low pass filter time constant for suppressing electrical noise in terminal 53. A high time constant value improves dampening but also increases time delay through the filter.
0.01 s* [0.01-10.00 s]	Enter time constant.

**6-19 Terminal 53 Mode**

Option:	Function:
	Select the input to be present on terminal 53.
	<b>CAUTION</b> 6-19 Terminal 53 Mode MUST be set according to Micro switch 4 setting.
[0] * Voltage Mode	
[1] Current Mode	

4.7.4 6-2\* Analog Input 2

Parameters for configuring scaling and limits for analog input 2, terminal 60.

**6-22 Terminal 60 Low Current**

Range:	Function:
	This reference signal should correspond to minimum reference value set in 6-24 Terminal 60 Low Ref./Feedb. Value.
0.14 mA* [0.00-19.90 mA]	Enter low current value.

**CAUTION**

The value must be set to min. 2 mA in order to activate the Live Zero Timeout function in 6-01 Live Zero Timeout Time.

**6-23 Terminal 60 High Current**

Range:	Function:
	This reference signal should correspond to the high current value set in 6-25 Terminal 60 High Ref./Feedb. Value.
20.00 mA* [0.10-20.00 mA]	Enter high current value.

**6-24 Terminal 60 Low Ref./Feedb. Value**

Range:	Function:
	The scaling value corresponding to the low current set in 6-22 Terminal 60 Low Current.
0.000* [-4999-4999]	Enter analog input scaling value.

**6-25 Terminal 60 High Ref./Feedb. Value**

Range:	Function:
	The scaling value corresponding to the high current set in 6-23 Terminal 60 High Current.
50.00* [-4999-4999]	Enter analog input scaling value.



**6-26 Terminal 60 Filter Time Constant**

Range:		Function:
0.01 s*	[0.01-10.00 s]	Enter time constant.

A first-order digital low pass filter time constant for suppressing electrical noise in terminal 60. A high time constant value improves dampening, but also increases time delay through the filter.

**NOTE**  
This parameter cannot be changed while motor runs.

**4.7.5 6-8\* Keypad Potentiometer**

The keypad potentiometer can be selected either as Reference Resource or Relative Reference Resource.

**NOTE**

In Hand mode the keypad potentiometer functions as local reference.

**6-80 Keypad Potmeter Enable**

Option:	Function:
[0]	Disabled
[1] *	Enable

If keypad Potmeter is disabled, [▲] [▼] can adjust local reference, and Potmeter value does not give any reference in Auto/Hand mode.

**6-81 Keypad Potentiometer Low Ref. Value**

Range:		Function:
0.000*	[-4999-4999]	Enter low reference value.
		The scaling value corresponding to 0.
		The reference value corresponding to potentiometer turned fully counter-clockwise (0 degrees).

**6-82 Keypad Potentiometer High Ref. Value**

Range:		Function:
50.00*	[-4999-4999]	Enter high reference value.
		The scaling value corresponding to the maximum reference feedback value set in 3-03 Maximum Reference.
		The reference value corresponding to potentiometer turned fully clockwise (200 degrees).

**4.7.6 6-9\* Analog Output**

These parameters are for configuring the analog outputs of the frequency converter.

**6-90 Terminal 42 Mode**

Option:	Function:
[0] *	0-20 mA
[1]	4-20 mA
[2]	Digital output

Range for analog outputs is 0-20 mA  
Range for analog outputs is 4-20 mA  
Functions as slow reacting digital output. Set value to either 0 mA (off) or 20 mA (on), see 6-92 Terminal 42 Digital Output.

**6-91 Terminal 42 Analog Output**

Option:	Function:
[0] *	No Operation
[10]	Output Frequency [0-100 Hz]
[11]	Reference (REF min-max)
[12]	Feedback (FB min-max)
[13]	Motor Current (0-I <sub>max</sub> )
[16]	Power (0-P <sub>nom</sub> )
[19]	DC Link Voltage (0-1000 V)
[20]	Bus Reference [0.0% -100.0%]

Select the function for terminal 42 as an analog output.

3-02 Minimum Reference to 3-03 Minimum Reference.

16-37 Inv. Max. Current is I<sub>max</sub>.

1-20 Motor Power is P<sub>nom</sub> (motor).

The analog output will follow the reference value set on the RS-485 bus.

**6-92 Terminal 42 Digital Output**

Option:	Function:
[0] *	No Operation
[80]	Logic Controller Digital Output A

See parameter group 5-4\* Relays, for choices and descriptions.

See 13-52 Logic Controller Action. When Logic Controller Action [38] Set dig. out. A high is executed, input goes high. When Smart Logic Action [32] Set dig. out. A low is executed, input goes low.

**6-93 Terminal 42 Output Min. Scale**

Range:	Function:
0.00%	[0.00-200.0%]

Scale minimum output of selected analog signal at terminal 42 as percentage of maximum signal value. E.g. if 0 mA (or 0 Hz) is desired at 25% of maximum output value, program 25%. Scaling values up to 100% can never be higher than corresponding setting in 6-94 Terminal 42 Output Min. Scale.




Illustration 4.9

6-94 Terminal 42 Output Max. Scale

Range:

Function:

<p>100.00%*</p>	<p>[0.00-200.00%]</p>	<p>Scale maximum output of selected analog signal at terminal 42. Set value to maximum value of current signal output. Scale output to give a current lower than 20 mA at full scale; or 20 mA at an output below 100% of maximum signal value.</p> <p>If 20 mA is the desired output current at a value between 0-100% of the full-scale output, program percentage value in the parameter, i.e. 50% = 20 mA. If a current between 4 and 20 mA is desired at maximum output (100%), calculate percentage value as follows:</p> $\frac{20 \text{ mA}}{\text{desired maximum current}} \times 100 \%$ <p>i.e.</p> $10 \text{ mA} = \frac{20}{10} \times 100 = 200 \%$
-----------------	-----------------------	--



## 4.8 Parameter Group 7: Controllers

### 4.8.1 7-\*\* Controllers

Parameters group for configuring application controls.

### 4.8.2 7-2\* Process Ctrl. Feedback

Select feedback sources and handling for Process PI Control.

#### NOTE

Set 3-15 Reference 1 Source to [0] No Function in order to use Analog Input as a feedback signal. In order to use analog input as a feedback resource, do not use the same resource as reference resource in 3-15, 3-16 and 3-17.

#### 7-20 Process CL Feedback Resources

Option:	Function:
	Select input to function as feedback signal.
[0] *	No Function
[1]	Analog Input 53
[2]	Analog Input 60
[8]	Pulse Input 33
[11]	Local Bus Ref.

### 4.8.3 7-3\* Process PI Control

#### 7-30 Process PI Normal/Inverse Control

Option:	Function:
[0] *	Normal Feedback larger than setpoint result in a speed reduction. Feedback less than setpoint result in a speed increase.
[1]	Inverse Feedback larger than setpoint result in a speed increase. Feedback less than setpoint result in a speed reduction.

#### 7-31 Process PI Anti Windup

Option:	Function:
[0]	Disable Regulation of a given error will continue even when the output frequency cannot be increased/ decreased.
[1] *	Enable PI-controller ceases from regulating a given error when the output frequency cannot be increased/ decreased.

#### 7-32 Process PI Start Speed

Range:	Function:
0.0 Hz*	[0.0-200.0 Hz] Until the set motor speed has been reached the frequency converter operates in Open Loop mode.

#### 7-33 Process PI Proportional Gain

Option:	Function:
[0.01] *	0.00-10.00 Enter the value for the P proportional gain, i.e. the multiplication factor of the error between the set point and the feedback signal. <b>NOTE</b> 0.00 = Off.

#### 7-34 Process PI Integral Time

Range:	Function:
9999.00 s*	[0.10-9999.00 s] The integrator provides an increasing gain at a constant error between the set point and the feedback signal. The integral time is the time needed by the integrator to reach the same gain as the proportional gain.

#### 7-38 Process Feed Forward Factor

Range:	Function:
0%*	[0-400%] The FF factor sends a part of the reference signal around the PI controller which then only affects part of the control signal. By activating the FF factor less overshoot and high dynamics are gained when changing the setpoint. This parameter is always active when 1-00 Configuration Mode is set to [3] Process.

#### 7-39 On Reference Bandwidth

Range:	Function:
5%	[0-200%] Enter the value for the On Reference Bandwidth. The PI control error is the difference between setpoint and feedback and when this is less than the value set in this parameter the On Reference is active.



## 4.9 Parameter Group 8: Communication

### 4.9.1 8-\*\* Communication

Parameter group for configuring communication.

### 4.9.2 8-0\* General Settings

Use this parameter group for configuring the general settings for communication.

#### 8-01 Control Site

Option:	Function:
[0] * Digital and Control Word	Use both digital input and control word as control.
[1] Digital Only	Use digital input as control.
[2] Control Word Only	Use control word only as control. <b>NOTE</b> The setting in this parameter overrules settings in 8-50 Coasting Select to 8-56 Preset Reference Select.

#### 8-02 Control Word Source

Option:	Function:
[0] None	Function is inactive
[1] * Drive RS-485	Monitoring control word source is done via serial communication port RS-485.

#### 8-03 Control Word Timeout Time

Range:	Function:
1.0 s* [0.1-6500 s]	Enter time to pass before control word timeout function (8-04 Control Word Timeout Function) must be carried out.

#### 8-04 Control Word Timeout Function

Option:	Function:
[0] * Off	Select the action to be taken in case of a timeout. No function.
[1] Freeze Output	Freeze output until communication resumes.
[2] Stop	Stop with auto restart when communication resumes.
[3] Jogging	Run motor at jog frequency until communication resumes.
[4] Max. Speed	Run motor at max. frequency until communication resumes.
[5] Stop and Trip	Stop motor, then reset frequency converter in order to restart either via keypad or digital input.

#### 8-06 Reset Control Word Timeout

Option:	Function:
[0] * No Function	Resetting the control word timeout will remove any timeout function. Control word timeout is not reset.
[1] Do Reset	Control word timeout is reset, and parameter goes into [0] No Function state.

### 4.9.3 8-3\* GE Drive Port Settings

Parameters for configuring the GE Drive Port.

#### 8-30 Protocol

Option:	Function:
[0] * GE Drive Protocol	Select the protocol to be used. Note that changing protocol will not be effective until after powering off the frequency converter.
[2] Modbus RTU	

#### 8-31 Address

Range:	Function:
1* [1 - Protocol-dependent]	Select the address for the bus. Drive-bus range is 1-126. Modbus range is 1-247.

#### 8-32 Drive Port Baud Rate

Option:	Function:
[0] 2400 Baud	Select baud rate for Drive Port. <b>NOTE</b> Changing baud rate will be effective after responding to any ongoing bus-requests.
[1] 4800 Baud	
[2] * 9600 Baud	When choosing GE Drive Protocol in 8-30
[3] * 19200 Baud	When choosing Modbus in 8-30
[4] 38400 Baud	

#### 8-33 Drive Port Parity

Option:	Function:
[0] * Even Parity (1 stopbit)	This parameter only affects Modbus as Drive bus always has even parity.
[1] Odd parity	
[2] No Parity (1 stopbit)	Select this for Modbus RTU
[3] No Parity (2 stopbit)	

#### 8-35 Minimum Response Delay

Range:	Function:
0.010 s* [0.001-0.500 s]	Specify minimum delay time between receiving a request and transmitting a response.



**8-36 Max Response Delay**

Range:	Function:
5.000 s* [0.010-10.00 s]	Specify maximum permissible delay time between transmitting a request and receiving a response. Exceeding this time delay causes control word timeout.

4.9.4 8-4\* Drive MC Protocol Set

**8-43 Drive Port PCD Read Configuration**

Array [16]

Option:	Function:
[0] *	None
[1]	1500 Operation Hours
[2]	1501 Running Hours
[3]	1502 kWh Counter
[4]	1600 Control Word
[5]	1601 Reference [Unit]
[6]	1602 Reference %
[7]	1603 Status Word
[8]	1605 Main Actual Value [%]
[9]	1609 Custom Readout
[10]	1610 Power [kW]
[11]	1611 Power [hp]
[12]	1612 Motor Voltage
[13]	1613 Frequency
[14]	1614 Motor Current
[15]	1615 Frequency [%]
[16]	1618 Motor Thermal
[17]	1630 DC Link Voltage
[18]	1634 Heatsink Temp.
[19]	1635 Inverter Thermal
[20]	1638 Logic Controller State
[21]	1650 External Reference
[22]	1651 Pulse Reference
[23]	1652 Feedback [Unit]
[24]	1660 Digital Input 18,19,27,33
[25]	1661 Digital Input 29
[26]	1662 Analog Input 53(V)
[27]	1663 Analog Input 53(mA)
[28]	1664 Analog Input 60
[29]	1665 Analog Output 42 [mA]
[30]	1668 Freq. Input 33 [Hz]
[31]	1671 Relay Output [bin]
[32]	1672 Counter A
[33]	1673 Counter B
[34]	1690 Alarm Word
[35]	1692 Warning Word
[36]	1694 Ext. Status Word
	Select the parameters to be assigned to PCD's of telegrams. The number of available PCDs depends on

**8-43 Drive Port PCD Read Configuration**

Array [16]

Option:	Function:
	the telegrams. This table is not for [0] array and [1] array . For these two arrays, index 1 is fixed to [7] and index 2 is fixed to [8]. These two arrays cannot be changed by end user.

4.9.5 8-5\* Digital/Bus

Parameters for configuring control word Digital/Bus merging.

**NOTE**

Parameters are only active when 8-01 Control Site, is set to [0] Digital and control word.

**8-50 Coasting Select**

Option:	Function:
	Select control of coasting function via digital input and/or bus.
[0]	Digital Input Activation via a digital input.
[1]	Bus Activation via serial communication port.
[2]	LogicAnd Activation via serial communication port and a digital input.
[3] *	LogicOr Activation via serial communication port or a digital input.

**8-51 Quick Stop Select**

Option:	Function:
	Select control of quick stop function via digital input and/or bus.
[0]	Digital Input Activation via a digital input.
[1]	Bus Activation via serial communication port.
[2]	LogicAnd Activation via serial communication port and a digital input.
[3] *	LogicOr Activation via serial communication port or a digital input.

**8-52 DC Brake Select**

Option:	Function:
	Select control of DC brake via digital input and/or bus.
[0]	Digital Input Activation via a digital input.
[1]	Bus Activation via serial communication port.
[2]	LogicAnd Activation via serial communication port and a digital input.
[3] *	LogicOr Activation via serial communication port or a digital input.



**8-53 Start Select**

Option:	Function:
	Select control of start function via digital input and/or bus.
[0]	Digital Input Activation via a digital input.
[1]	Bus Activation via serial communication port.
[2]	LogicAnd Activation via serial communication port and a digital input.
[3] *	LogicOr Activation via serial communication port or a digital input.

**8-54 Reversing Select**

Option:	Function:
	Select control of reversing function via digital input and/or bus.
[0]	Digital Input Activation via a digital input.
[1]	Bus Activation via serial communication port.
[2]	LogicAnd Activation via serial communication port and a digital input.
[3] *	LogicOr Activation via serial communication port or a digital input.

**8-55 Set-up Select**

Option:	Function:
	Select control of set-up selection via digital input and/or bus.
[0]	Digital Input Activation via a digital input.
[1]	Bus Activation via serial communication port.
[2]	LogicAnd Activation via serial communication port and a digital input.
[3] *	LogicOr Activation via serial communication port or a digital input.

**8-56 Preset Reference Select**

Option:	Function:
	Select control of Preset Reference selection via digital input and/or bus.
[0]	Digital Input Activation via a digital input.
[1]	Bus Activation via serial communication port.
[2]	LogicAnd Activation via serial communication port and a digital input.
[3] *	LogicOr Activation via serial communication port or a digital input.

4.9.6 8-8\* Bus communication diagnostics

These parameters are used for monitoring the Bus communication via the Port.

**8-80 Bus Message Count**

Range:	Function:
0 N/A* [0-0 N/A]	This parameter shows the number of valid telegrams detected on the bus.

**8-81 Bus Error Count**

Range:	Function:
0 N/A* [0-0 N/A]	This parameter shows the number of telegrams with faults (e.g. CRC fault), detected on the bus.

**8-82 Slave Messages Rcvd**

Range:	Function:
0 N/A* [0-0 N/A]	This parameter shows the number of valid telegrams addressed to the slave, sent by the frequency converter.

**8-83 Slave Error Count**

Range:	Function:
0 N/A* [0-0 N/A]	This parameter shows the number of error telegrams, which could be executed by the frequency converter.

4.9.7 8-9\* Bus Feedback

Parameter for configuring bus feedback.

**8-94 Bus Feedback 1**

Range:	Function:
0* [0x8000-0x7FFF]	Bus feedback is delivered via Drive or Modbus by writing the feedback value into this parameter.



## 4.10 Parameter Group 13: Logic Controller

### 4.10.1 13-\*\* Programming Features

Logic Controller is a sequence of user-defined actions (13-52 *Logic Controller Action* [X]) executed by the Logic Controller when the associated user-defined event (13-51 *Logic Controller Event* [X]) is set to *True*.

Events and actions are linked in pairs, meaning that when an event is true, the linked action is carried out. After this the next event is evaluated and its belonging action carried out and so on. Only one event is evaluated at the time.

If an event is evaluated as *False*, the Logic Controller takes no action during the scan interval and no other events are evaluated.

It is possible to program from 1 to 20 events and actions. When the last event/action has been executed, the sequence starts again from event/action [0].

The drawing shows an example with three events/actions:




Illustration 4.10

#### Starting and stopping the Logic Controller

Start the Logic Controller by selecting [1] *On* in 13-00 *Logic Controller Mode*. The Logic Controller starts evaluating Event 0, and if this is evaluated as *TRUE*, the Logic Controller continues its cycle.

The Logic Controller stops when the *Stop Event*, 13-02 *Stop Event*, is *TRUE*. The Logic Controller can also be stopped by selecting [0] *Off* in 13-00 *Logic Controller Mode*.

To reset all Logic Controller parameters select [1] *Reset Logic Controller* in 13-03 *Reset Logic Controller* and start programming from scratch.

### 4.10.2 13-0\* Logic Controller Settings

Use Logic Controller settings to activate, deactivate and reset the Logic Controller.

#### 13-00 Logic Controller Mode

Option:	Function:
[0] *	Off Function is disabled.
[1]	On Logic Controller is active.

#### 13-01 Start Event

Option:	Function:
	Select input to activate Logic Controller.
[0]	False Enters <i>False</i> in logic rule.
[1]	True Enters <i>True</i> in logic rule.
[2]	Running See parameter group 5-4* <i>Relays</i> [5] for description.
[3]	InRange See parameter group 5-4* <i>Relays</i> [7] for description.
[4]	OnReference See parameter group 5-4* <i>Relays</i> [8] for description.
[7]	Out of Current Range See parameter group 5-4* <i>Relays</i> [12] for description.
[8]	BelowLow See parameter group 5-4* <i>Relays</i> [13] for description.
[9]	AboveHigh See parameter group 5-4* <i>Relays</i> [14] for description.
[16]	ThermalWarning See parameter group 5-4* <i>Relays</i> [21] for description.
[17]	MainsOutOfRange Mains voltage is outside the specified voltage range.
[18]	Reversing See parameter group 5-4* <i>Relays</i> [25] for description.
[19]	Warning A warning is active.
[20]	Alarm_Trip A trip alarm is active.
[21]	Alarm_TripLock A trip lock alarm is active.
[22]	Comparator 0 Use result of comparator 0 in logic rule.
[23]	Comparator 1 Use result of comparator 1 in logic rule.
[24]	Comparator 2 Use result of comparator 2 in logic rule.
[25]	Comparator 3 Use result of comparator 3 in logic rule.
[26]	LogicRule 0 Use result of logic rule 0 in logic rule.
[27]	LogicRule 1 Use result of logic rule 1 in logic rule.
[28]	LogicRule 2 Use result of logic rule 2 in logic rule.
[29]	LogicRule 3 Use result of logic rule 3 in logic rule.
[33]	DigitalInput_18 Use value of DI 18 in logic rule.
[34]	DigitalInput_19 Use value of DI 19 in logic rule.
[35]	DigitalInput_27 Use value of DI 27 in logic rule.





**13-01 Start Event**

Option:	Function:
[36] DigitalInput_29	Use value of DI 29 in logic rule.
[38] DigitalInput_33	
[39] * StartCommand	This event is <i>True</i> , if frequency converter is started by any means (digital input or other).
[40] DriveStopped	This event is <i>True</i> , if frequency converter is stopped or coasted by any means (digital input or other).

**13-02 Stop Event**

Option:	Function:
	Select input to activate Logic Controller.
[0] False	Enters <i>False</i> in logic rule.
[1] True	Enters <i>True</i> in logic rule.
[2] Running	See parameter group 5-4* Relays [5] for description.
[3] InRange	See parameter group 5-4* Relays [7] for description.
[4] OnReference	See parameter group 5-4* Relays [8] for description.
[7] Out of Current Range	See parameter group 5-4* Relays [12] for description.
[8] BelowLow	See parameter group 5-4* Relays [13] for description.
[9] AboveHigh	See parameter group 5-4* Relays [14] for description.
[16] ThermalWarning	See parameter group 5-4* Relays [21] for description.
[17] MainsOutOfRange	Mains voltage is outside the specified voltage range.
[18] Reversing	See parameter group 5-4* Relays [25] for description.
[19] Warning	A warning is active.
[20] Alarm_Trip	A trip alarm is active.
[21] Alarm_TripLock	A trip lock alarm is active.
[22] Comparator 0	Use result of comparator 0 in logic rule.
[23] Comparator 1	Use result of comparator 1 in logic rule.
[24] Comparator 2	Use result of comparator 2 in logic rule.
[25] Comparator 3	Use result of comparator 3 in logic rule.
[26] LogicRule 0	Use result of logic rule 0 in logic rule.
[27] LogicRule 1	Use result of logic rule 1 in logic rule.
[28] LogicRule 2	Use result of logic rule 2 in logic rule.
[29] LogicRule 3	Use result of logic rule 3 in logic rule.
[30] LC Timeout0	Use result of timer 0 in logic rule.

**13-02 Stop Event**

Option:	Function:
[31] LC Timeout1	Use result of timer 1 in logic rule.
[32] LC Timeout2	Use result of timer 2 in logic rule.
[33] DigitalInput_18	Use value of DI 18 in logic rule.
[34] DigitalInput_19	Use value of DI 19 in logic rule.
[35] DigitalInput_27	Use value of DI 27 in logic rule.
[36] DigitalInput_29	Use value of DI 29 in logic rule.
[38] DigitalInput_33	
[39] StartCommand	This event is <i>True</i> , if frequency converter is started by any means (digital input or other).
[40] * DriveStopped	This event is <i>True</i> , if frequency converter is stopped or coasted by any means (digital input or other).

**13-03 Reset Logic Controller**

Option:	Function:
[0] * Do Not Reset	Retains all settings programmed in parameter group 13.
[1] Reset Logic Controller	Reset all group 13 parameters to default settings.

4.10.3 13-04 Comparators

Comparators are used for comparing continuous variables (i.e. output frequency, output current, analog input etc.) to fixed preset values.




Illustration 4.11

In addition, there are digital values that will be compared to fixed time values. See explanation in 13-10 *Comparator Operand*. Comparators are evaluated once in each scan interval. Use the result (TRUE or FALSE) directly. All parameters in this parameter group are array parameters with index 0 to 5. Select index 0 to program Comparator 0, select index 1 to program Comparator 1, and so on.

**13-10 Comparator Operand**

Array [4]

Option:	Function:
	Select variable to be monitored by comparator.
[0] * Disabled	Comparator is disabled.
[1] Reference	Resulting remote reference (not local) as a percentage.



**13-10 Comparator Operand**

Array [4]

Option:	Function:
[2] Feedback	Feedback in [Hz].
[3] MotorSpeed	Motor speed in Hz.
[4] MotorCurrent	Motor current in [A].
[6] MotorPower	Motor power in either [kW] or [hp].
[7] MotorVoltage	Motor voltage in [V].
[8] DCLinkVoltage	DC-link voltage in [V].
[12] AnalogInput53	Expressed as actual value.
[13] AnalogInput60	Expressed as actual value.
[18] PulseInput33	Expressed as actual value.
[20] AlarmNumber	Shows number of the alarm.
[30] CounterA	Number of counts.
[31] CounterB	Number of counts.

**13-11 Comparator Operator**

Array [4]

Option:	Function:
[0]	Less Than < Result of evaluation is <i>True</i> if variable selected in <i>13-10 Comparator Operand</i> is smaller than fixed value in <i>13-12 Comparator Value</i> . Result is <i>False</i> if variable selected in <i>13-10 Comparator Operand</i> is greater than fixed value in <i>13-12 Comparator Value</i> .
[1] *	Approximately equals ≈ Result of evaluation is <i>True</i> if variable selected in <i>13-10 Comparator Operand</i> is approximately equal to fixed value in <i>13-12 Comparator Value</i> .
[2]	Greater Than > Inverse logic of option [0].

**13-12 Comparator Value**

Array [4]

Range:	Function:
0.0* [-9999-9999]	Enter "trigger level" for variable monitored by this comparator.

4.10.4 13-2\* Timers

Use the timer results to define an event (*13-51 Logic Controller Action*) or as boolean input in a logic rule (*13-40 Logic Rule Boolean 1*, *13-42 Logic Rule Boolean 2* or *13-44 Logic Rule Boolean 3*).

When timer value has elapsed timer changes state from *False* to *True*.

**13-20 Logic Controller Controller Timer**

Array [3]

Range:	Function:
0.0 s* [0.0-3600 s]	Enter value to define duration of the <i>False</i> output from programmed timer. A timer is only <i>False</i> if it is started by an action and until the given timer value has elapsed.

4.10.5 13-4\* Logic Rules

Combine up to three boolean inputs (*TRUE/FALSE* inputs) from timers, comtors, digital inputs, status bits and events using the logical operators *AND*, *OR*, and *NOT*. Select boolean inputs for the calculation in *13-40 Logic Rule Boolean 1*, *13-42 Logic Rule Boolean 2* and *13-44 Logic Rule Boolean 3*. Define the operators used to logically combine the selected inputs in *13-41 Logic Rule Operator 1* and *13-43 Logic Rule Operator 2*.




Illustration 4.12

**Priority of calculation**

The results of *13-40 Logic Rule Boolean 1*, *13-41 Logic Rule Operator 1* and *13-42 Logic Rule Boolean 2* are calculated first. The outcome (*TRUE/FALSE*) of this calculation is combined with the settings of *13-43 Logic Rule Operator 2* and *13-44 Logic Rule Boolean 3*, yielding the final result (*TRUE/FALSE*) of the logic rule.

**13-40 Logic Rule Boolean 1**

Array [4]

Option:	Function:
[0] *	False Enters <i>False</i> in logic rule.
[1]	True Enters <i>True</i> in logic rule.
[2]	Running See parameter group <i>5-4* Relays</i> [5] for description.
[3]	InRange See parameter group <i>5-4* Relays</i> [7] for description.
[4]	OnReference See parameter group <i>5-4* Relays</i> [8] for description.
[7]	Out of Current Range See parameter group <i>5-4* Relays</i> [12] for description.
[8]	BelowLow See parameter group <i>5-4* Relays</i> [13] for description.



**13-40 Logic Rule Boolean 1**

Array [4]

**Option:**                      **Function:**

[9]	AboveHigh	See parameter group 5-4* Relays [14] for description.
[16]	ThermalWarning	See parameter group 5-4* Relays [21] for description.
[17]	MainsOutOfRange	Mains voltage is outside the specified voltage range.
[18]	Reversing	See parameter group 5-4* Relays [25] for description.
[19]	Warning	A warning is active.
[20]	Alarm_Trip	A trip alarm is active.
[21]	Alarm_TripLock	A trip lock alarm is active.
[22]	Comparator 0	Use result of comparator 0 in logic rule.
[23]	Comparator 1	Use result of comparator 1 in logic rule.
[24]	Comparator 2	Use result of comparator 2 in logic rule.
[25]	Comparator 3	Use result of comparator 3 in logic rule.
[26]	LogicRule 0	Use result of logic rule 0 in logic rule.
[27]	LogicRule 1	Use result of logic rule 1 in logic rule.
[28]	LogicRule 2	Use result of logic rule 2 in logic rule.
[29]	LogicRule 3	Use result of logic rule 3 in logic rule.
[30]	LC Timeout0	Use result of timer 0 in logic rule.
[31]	LC Timeout1	Use result of timer 1 in logic rule.
[32]	LC Timeout2	Use result of timer 2 in logic rule.
[33]	DigitalInput_18	Use value of DI 18 in logic rule.
[34]	DigitalInput_19	Use value of DI 19 in logic rule.
[35]	DigitalInput_27	Use value of DI 27 in logic rule.
[36]	DigitalInput_29	Use value of DI 29 in logic rule.
[38]	DigitalInput_33	Use value of DI 33 in logic rule.
[39]	StartCommand	This event is <i>True</i> , if frequency converter is started by any means (digital input or other).
[40]	DriveStopped	This event is <i>True</i> , if frequency converter is stopped or coasted by any means (digital input or other).

**13-41 Logic Rule Operator 1**

Array [4]

**Option:**                      **Function:**

		Select first logical operator to use on boolean inputs from 13-40 Logic Rule Boolean 1 and 13-42 Logic Rule Boolean 2.
[0] *	Disabled	Ignores 13-42 Logic Rule Boolean 2, 13-43 Logic Rule Operator 2 and 13-44 Logic Rule Boolean 3.
[1]	And	Evaluates expression [13-40] AND [13-42].
[2]	Or	Evaluates expression [13-40] OR [13-42].
[3]	And not	Evaluates expression [13-40] AND NOT [13-42].
[4]	Or not	Evaluates expression [13-40] OR NOT [13-42].
[5]	Not and	Evaluates expression NOT [13-40] and [13-42].

**13-41 Logic Rule Operator 1**

Array [4]

**Option:**                      **Function:**

[6]	Not or	Evaluates expression NOT [13-40] OR [13-42].
[7]	Not and not	Evaluates expression NOT [13-40] AND NOT [13-42].
[8]	Not or not	Evaluates expression NOT [13-40] OR NOT [13-42].

**13-42 Logic Rule Boolean 2**

Array [4]

**Option:**                      **Function:**

		Select second boolean input for selected logic rule. See 13-40 Logic Rule Boolean 1 for choices and descriptions.
--	--	---

**13-43 Logic Rule Operator 2**

Array [4]

**Option:**                      **Function:**

		Select second logical operator to use on boolean inputs calculated in 13-40 Logic Rule Boolean 1, 13-41 Logic Rule Operator 1, and 13-42 Logic Rule Boolean 2 and the boolean input from 13-42 Logic Rule Boolean 2.
[0] *	Disabled	Ignores 13-44 Logic Rule Boolean 3.
[1]	And	Evaluates expression [13-40/13-42] AND [13-44].
[2]	Or	Evaluates expression [13-40/13-42] OR [13-44].
[3]	And not	Evaluates expression [13-40/13-42] AND NOT [13-44].
[4]	Or not	Evaluates expression [13-40/13-42] OR NOT [13-44].
[5]	Not and	Evaluates expression NOT [13-40/13-42] and [13-44].
[6]	Not or	Evaluates expression NOT [13-40/13-42] OR [13-44].
[7]	Not and not	Evaluates expression NOT [13-40/13-42] AND NOT [13-44].
[8]	Not or not	Evaluates expression NOT [13-40/13-42] OR NOT [13-44].

**13-44 Logic Rule Boolean 3**

Array [4]

**Option:**                      **Function:**

		Select third boolean input for selected logic rule. See 13-40 Logic Rule Boolean 1 for choices and descriptions.
--	--	--



### 4.10.6 13-5\* States

#### 13-51 Logic Controller Event

Array [20]

**Option: Function:**

	Select boolean input to define Logic Controller Event. See 13-40 <i>Logic Rule Boolean 1</i> for choices and descriptions.
--	--

#### 13-52 LC Controller Action

Array [20]

**Option: Function:**

Option:	Function:
	Select action corresponding to LC event. Actions are executed when corresponding event (13-51 <i>Logic Controller Event</i> ) is evaluated as <i>True</i> .
[0] *	Disabled Function is disabled.
[1]	No Action No action is taken.
[2]	Select Set-up1 Changes active set-up to Set-up 1.
[3]	Select Set-up2 Changes active set-up to Set-up 2.
[10]	SelectPresetRef0 Selects preset reference 0
[11]	SelectPresetRef1 Selects preset reference 1
[12]	SelectPresetRef2 Selects preset reference 2
[13]	SelectPresetRef3 Selects preset reference 3
[14]	SelectPresetRef4 Selects preset reference 4
[15]	SelectPresetRef5 Selects preset reference 5
[16]	SelectPresetRef6 Selects preset reference 6
[17]	SelectPresetRef7 Selects preset reference 7
[18]	SelectRamp1 Selects ramp 1
[19]	SelectRamp2 Selects ramp 2
[22]	Run Issues start command to frequency converter.
[23]	RunReverse Issues start reverse command to frequency converter.
[24]	Stop Issues stop command to frequency converter.
[25]	Qstop Issues quick stop command to frequency converter.
[26]	DCstop Issues DC stop command to frequency converter.
[27]	Coast frequency converter coasts immediately. All stop commands including coast command stop the Logic Controller.
[28]	Freeze Output Freezes output frequency.
[29]	StartTimer0 Starts timer 0.
[30]	StartTimer1 Starts timer 1
[31]	StartTimer2 Starts timer 2
[32]	SetDO42Low Set Digital output 42 low.
[33]	SetRelayLow Set Relay low.
[38]	SetDO42High Set Digital output 42 high.
[39]	SetRelayHigh Set Relay high.
[60]	ResetCounterA Resets counter A to 0.
[61]	ResetCounterB Resets counter B to 0.



### 4.11 Parameter Group 14: Special Functions

#### 4.11.1 14-\*\* Special Functions

Parameter group for configuring special frequency converter functions.

#### 4.11.2 14-0\* Carrier Frequency

##### 14-01 Motor Noise (Carrier Frequency)

Option:	Function:
	Select the carrier frequency in order to minimize e.g. acoustic noise and power loss or maximizing efficiency.
[0]	2 KHz
[1] *	4 KHz
[2]	8 KHz
[4]	16 KHz

#### NOTE

For 18.5 kW and 22 kW frequency converter, the option [4] is not available.

##### 14-03 Overmodulation

Option:	Function:
	This feature allows more accurate speed control near and over nominal speed (50/60 Hz). Another advantage with overmodulation is the ability of staying at a constant speed even though main is dropping.
[0]	Off Disables the overmodulation function to avoid torque ripple on the motor shaft.
[1] *	On Connects the overmodulation function to obtain an output voltage up to 15% greater than mains voltage.

#### 4.11.3 14-1\* Mains Monitoring

This parameter group supplies functions for handling imbalance on mains.

##### 14-12 Functions at Mains Imbalance

Option:	Function:
	Operation under severe mains imbalance conditions reduces drive lift time. Select function to take place when severe mains imbalance is detected.
[0] *	Trip Frequency converter trips.
[1]	Warning Frequency converter issues a warning.
[2]	Disabled No action taken.

Parameters for configuring auto reset handling, special trip handling and control card self test or restore.

##### 14-20 Reset Mode

Option:	Function:
	Select reset function after tripping. Once reset, the frequency converter can be restarted.
[0] *	Manual Reset Perform reset via [Reset] or digital inputs.
[1]	AutoReset 1 Performs one automatic reset after tripping.
[2]	AutoReset 2 Performs two automatic resets after tripping.
[3]	AutoReset 3 Performs three automatic resets after tripping.
[4]	AutoReset 4 Performs four automatic resets after tripping.
[5]	AutoReset 5 Performs five automatic resets after tripping.
[6]	AutoReset 6 Performs six automatic resets after tripping.
[7]	AutoReset 7 Performs seven automatic resets after tripping.
[8]	AutoReset 8 Performs eight automatic resets after tripping.
[9]	AutoReset 9 Performs nine automatic resets after tripping.
[10]	AutoReset 10 Performs ten automatic resets after tripping.
[11]	AutoReset 15 Performs fifteen automatic resets after tripping.
[12]	AutoReset 20 Performs twenty automatic resets after tripping.
[13]	Infinite auto reset Performs an infinite number of automatic resets after tripping.
[14]	Reset at power-up Trip-lock alarm can be reset at power up. <b>CAUTION</b> Motor may start without warning.

##### 14-21 Automatic Restart Time

Range:	Function:
10 s* [0-600 s]	Enter time interval from trip to start of automatic reset function. This parameter is active when 14-20 Reset Mode, is set to [1] to [13] Automatic Reset.

##### 14-22 Operation Mode

Option:	Function:
	Use this parameter for specifying normal operation or to initialize all parameters, except 15-03 Power Ups, 15-04 Over Temps and 15-05 Over Volts.
[0] *	Normal Operation Frequency converter runs normal operation.
[2]	Restore Factory Settings Resets all parameters to default settings, except for 15-03 Power Ups, 15-04 Over Temps and 15-05 Over Volts. Frequency converter resets during next power-up.



**14-22 Operation Mode**

Option:	Function:
	14-22 Operation Mode also reverts to default setting [0] Normal Operation.

**14-26 Action at Inverter Fault**

Option:	Function:
[0]	Trip When the frequency converter detects an over-voltage, it will trip immediately. <b>NOTE</b> It is recommended to choose [0] Trip in hoisting applications.
[1] *	Warning When the frequency converter detects an over-voltage, it will give warning immediately. After protection filter, it will trip. <b>NOTE</b> It is recommended to disable <i>protection mode</i> in hoisting applications.

4.11.4 15-4\* Drive Identification

Parameters containing read only information about the hardware and software configuration of the frequency converter.

**14-41 Energy Savings Minimum Magnetization**

Range:	Function:
66%* [40-75%]	Enter the minimum allowable magnetization for energy savings. Selecting a low value reduces energy loss in the motor, but may also reduce resistance to sudden load changes.



### 4.12 Parameter Group 15: Drive Information

Parameter group containing information on operating data, hardware configuration, software version, etc.

#### 15-00 Operating Time

Range:		Function:
0 days*	[0-65535 days]	View how many days the frequency converter has been powered up. The value is saved at power off and cannot be reset.

#### 15-01 Running Hours

Range:		Function:
0*	[0- 2147483647]	View running hours of motor. The value is saved at power off and can be reset in <i>15-07 Reset Running Hours Counter</i> .

#### 15-02 kWh Counter

Range:		Function:
0	[0-65535]	View power consumption in kWh as a mean value over one hour. Reset counter in <i>15-06 Reset kWh Counter</i> .

#### 15-03 Power Ups

Range:		Function:
0	[0-2147483647]	View number of times frequency converter has been powered up. Counter cannot be reset.

#### 15-04 Over Temps

Range:		Function:
0	[0-65535]	View number of times frequency converter has tripped due to over temperature. Counter cannot be reset.

#### 15-05 Over Volts

Range:		Function:
0*	[0-65535]	View number of times frequency converter has tripped due to over voltage. Counter cannot be reset.

#### 15-06 Reset kWh Counter

Option:	Function:	
[0] *	Do Not Reset	Counter is not reset.
[1]	Reset Counter	Counter is reset.

#### 15-07 Reset Running Hours Counter

Option:	Function:	
[0] *	Do Not Reset	Counter is not reset.
[1]	Reset Counter	Counter is reset.

### 4.12.1 15-3\* Fault Log

This parameter group contains a fault log showing reasons for the ten latest trips.

#### 15-30 Fault Log: Error Code

Range:		Function:
0	[0-255]	View error code and look it up in <i>GE AF-60 LP Micro Quick Guide</i> .

### 4.12.2 15-4\* Drive Identification

Parameters containing read only information about the hardware and software configuration of the frequency converter.

#### 15-40 Drive Type

Option:	Function:	
		View Drive type.

#### 15-41 Power Section

Option:	Function:	
		View power section of frequency converter.

#### 15-42 Voltage

Option:	Function:	
		View voltage of frequency converter.

#### 15-43 Software Version

Option:	Function:	
		View software version of frequency converter.

#### 15-46 Frequency Converter Ordering No

Option:	Function:	
		View ordering number for re-ordering frequency converter in its original configuration.

#### 15-48 Keypad ID No

Option:	Function:	
		View keypad ID number.

#### 15-51 Frequency Converter Serial Number

Option:	Function:	
		View frequency converter serial number.



### 4.13 Parameter Group 16: Data Readouts

#### 16-00 Control Word

Range:		Function:
0*	[0-65535]	View latest valid control word sent to frequency converter via serial communication port.

#### 16-01 Reference [Unit]

Range:		Function:
0.000*	[-4999.000-4999.000]	View total remote reference. Total reference is sum of pulse, analog, preset, keypad potentiometer, local bus and freeze reference.

#### 16-02 Reference %

Range:		Function:
0.0*	[-200.0-200.0%]	View total remote reference in percent. Total reference is sum of pulse, analog, preset, keypad potentiometer, local bus and freeze reference.

#### 16-03 Status Word

Range:		Function:
0*	[0-65535]	View status word sent to frequency converter via serial communication port.

#### 16-05 Main Actual Value %

Range:		Function:
0.00*	[-100.00-100.00%]	View two-byte word sent with status word to bus Master reporting main actual value.

#### 16-09 Custom Readout

Range:		Function:
0.00*	[0.00-9999.00%]	Customized readout based on the settings of 0-31 Custom Readout Min Scale, 0-32 Custom Readout Max Scale and 4-14 Motor Speed High Limit

#### 4.13.1 16-1\* Motor Status

#### 16-10 Power [kW]

Range:		Function:
0 kW*	[0-99 kW]	View output power in kW.

#### 16-11 Power [hp]

Range:		Function:
0 hp	[0-99 hp]	View output power in hp.

#### 16-12 Motor Voltage

Range:		Function:
0.0*	[0.0-999.9 V]	View motor phase voltage.

#### 16-13 Frequency

Range:		Function:
0.0 Hz*	[0.0-400.0 Hz]	View output frequency in Hz.

#### 16-14 Motor Current

Range:		Function:
0.00 A*	[0.00-655 A]	View motor phase current.

#### 16-15 Frequency [%]

Range:		Function:
0.00*	[-100.00-100.00%]	View a two-byte word reporting actual motor frequency as a percentage of 4-14 Motor Speed High Limit

#### 16-18 Motor Thermal

Range:		Function:
0%*	[0-100%]	View calculated thermal motor load as percentage of estimated thermal motor load.

#### 4.13.2 16-3\* Drive Status

#### 16-30 DC Link Voltage

Range:		Function:
0 V*	[0-10000 V]	View DC-link voltage.

#### 16-34 Heat Sink Temp.

Range:		Function:
0*	[0-255°C]	View heat sink temperature of frequency converter.

#### 16-35 Drive Thermal

Range:		Function:
0%*	[0-100%]	View calculated thermal load on frequency converter in relation to estimated thermal load on frequency converter.

#### 16-36 Drive Nom. Current

Range:		Function:
0.00 A*	[0.01-655A]	View continuous nominal drive current.

#### 16-37 Drive Max. Current

Range:		Function:
0.00 A*	[0.1-655A]	View intermittent maximum drive current (150%).

#### 16-38 Logic Controller State

Range:		Function:
0*	[0-255]	View number of active Logic state.

#### 4.13.3 16-5\* Ref. & Feedb.

#### 16-50 External Reference

Range:		Function:
0.0%*	[-200.0-200.0%]	View sum of all external references in percent.



**16-51 Pulse Reference****Range:**                      **Function:**

0.0 %*	[-200.0-200.0%]	View actual pulse input converted to a reference in percent.
--------	-----------------	--

**16-52 Feedback****Range:**                      **Function:**

0.000*	[-4999.000-4999.000]	View analog or pulse feedback in Hz.
--------	----------------------	--------------------------------------

## 4.13.4 16-6\* Inputs and Outputs

**16-60 Digital Input 18, 19, 27, 33****Range:**                      **Function:**

0*	[0-1111]	View signal states from active digital inputs.
----	----------	--

**16-61 Digital Input 29****Range:**                      **Function:**

0*	[0-1]	View signal state on digital input 29.
----	-------	--

**16-62 Analog Input 53 (volt)****Range:**                      **Function:**

0.00*	[0.00-10.00 V]	View input voltage on analog input terminal.
-------	----------------	--

**16-63 Analog Input 53 (current)****Range:**                      **Function:**

0.00*	[0.00-20.00 mA]	View input current on analog input terminal.
-------	-----------------	--

**16-64 Analog Input 60****Range:**                      **Function:**

0.00*	[0.00-20.00 mA]	View actual value at input 60 either as reference or protection value.
-------	-----------------	--

**16-65 Analog Output 42 [mA]****Range:**                      **Function:**

0.00 mA*	[0.00-20.00 mA]	View output current on analog output 42.
----------	-----------------	--

**16-68 Pulse Input****Range:**                      **Function:**

20 Hz*	[20-5000 Hz]	View input frequency on pulse input terminal.
--------	--------------	---

**16-71 Relay Output [bin]****Range:**                      **Function:**

0*	[0-1]	View relay setting.
----	-------	---------------------

**16-72 Counter A****Range:**                      **Function:**

0*	[-32768-32767]	View present value of Counter A.
----	----------------	----------------------------------

**16-73 Counter B****Range:**                      **Function:**

0*	[-32768-32767]	View present value of Counter B.
----	----------------	----------------------------------

## 4.13.5 16-8\* GE Drive Port

Parameter for viewing references from GE Drive Port.

**16-86 GE Drive Port REF 1****Range:**                      **Function:**

0*	[0x8000-0x7FFF]	View currently received reference from GE Drive Port.
----	-----------------	---

## 4.13.6 16-9\* Diagnosis Read-Outs

**16-90 Alarm Word****Range:**                      **Function:**

0*	[0-0xFFFFFFFF]	Via alarm word sent via serial communication port in hex code.
----	----------------	--

**16-92 Warning Word****Range:**                      **Function:**

0*	[0-0xFFFFFFFF]	View warning word sent via serial communication port in hex code.
----	----------------	---

**16-94 Ext. Status Word****Range:**                      **Function:**

0*	[0-0xFFFFFFFF]	View extended warning word sent via serial communication port in hex code.
----	----------------	--



5.1.1 Parameter Overview

Parameter Overview			
<p><b>0-** Operation/Display</b></p> <p><b>0-0/ Basic Settings</b></p> <p><b>0-03 Regional Settings</b></p> <p>[0] International</p> <p>*[1] US</p> <p><b>0-04 Oper. State at Power-up (Hand)</b></p> <p>[0] Resume</p> <p>[1] Forced stop, ref=f"old</p> <p>[2] Forced stop, re=0</p> <p><b>0-1* Set-up Handling</b></p> <p><b>0-10 Active Set-up</b></p> <p>*[1] Setup 1</p> <p>[2] Setup 2</p> <p>[9] Multi Setup</p> <p><b>0-11 Edit Set-up</b></p> <p>*[1] Setup 1</p> <p>[2] Setup 2</p> <p>[9] Active Setup</p> <p><b>0-12 Link Setups</b></p> <p>[0] Not Linked</p> <p>*[20] Linked</p> <p><b>0-31 Custom Readout Min Scale</b></p> <p>0.00-9999.00</p> <p>*0.00</p> <p><b>0-32 Custom Readout Max Scale</b></p> <p>0.00-9999.00</p> <p>*100.0</p> <p><b>0-4* Keypad</b></p> <p><b>0-40 [Hand] Key on Keypad</b></p> <p>[0] Disabled</p> <p>*[1] Enabled</p> <p><b>0-41 [Off / Reset] Key on Keypad</b></p> <p>[0] Disable All</p> <p>*[1] Enable All</p> <p>[2] Enable Reset Only</p> <p><b>0-42 [Auto] Key on Keypad</b></p> <p>[0] Disabled</p> <p>*[1] Enabled</p> <p><b>0-5* Copy/Save</b></p> <p><b>0-50 Keypad Copy</b></p> <p>*[0] No copy</p> <p>[1] All to keypad</p> <p>[2] All from keypad</p> <p>[3] Size indep. from keypad</p> <p><b>0-51 Set-up Copy</b></p> <p>*[0] No copy</p> <p>[1] Copy from setup 1</p> <p>[2] Copy from setup 2</p> <p>[9] Copy from Factory setup</p> <p><b>0-6* Password</b></p>	<p><b>0-60 (Main) Menu Password</b></p> <p>0-999 *0</p> <p><b>0-61 Access to Main/Quick Menu w/o Password</b></p> <p>*[0] Full access</p> <p>[1] Keypad: Read Only</p> <p>[2] Keypad: No Access</p> <p><b>1-** Load/Motor</b></p> <p><b>1-0* General Settings</b></p> <p><b>1-00 Configuration Mode</b></p> <p>*[0] Speed open loop</p> <p>[3] Process</p> <p><b>1-01 Motor Control Principle</b></p> <p>[0] U/f</p> <p>*[1] Adv.Vector Control</p> <p><b>1-03 Torque Characteristics</b></p> <p>*[0] Constant torque</p> <p>[2] Energy Saving</p> <p><b>1-05 Local Mode Configuration</b></p> <p>[0] Speed Open Loop</p> <p>*[2] As config in par. 1-00</p> <p><b>1-2* Motor Data</b></p> <p><b>1-20 Motor Power [kW] [HP]</b></p> <p>[1] 0.09 kW/0.12 HP</p> <p>[2] 0.12 kW/0.16 HP</p> <p>[3] 0.18 kW/0.25 HP</p> <p>[4] 0.25 kW/0.33 HP</p> <p>[5] 0.37 kW/0.50 HP</p> <p>[6] 0.55 kW/0.75 HP</p> <p>[7] 0.75 kW/1.00 HP</p> <p>[8] 1.10 kW/1.50 HP</p> <p>[9] 1.50 kW/2.00 HP</p> <p>[10] 2.20 kW/3.00 HP</p> <p>[11] 3.00 kW/4.00 HP</p> <p>[12] 3.70 kW/5.00 HP</p> <p>[13] 4.00 kW/5.40 HP</p> <p>[14] 5.50 kW/7.50 HP</p> <p>[15] 7.50 kW/10.00 HP</p> <p>[16] 11.00 kW/15.00 HP</p> <p>[17] 15.00 kW/20.00 HP</p> <p>[18] 18.50 kW/25.00 HP</p> <p>[19] 22.00 kW/29.50 HP</p> <p>[20] 30.00 kW/40.00 HP</p> <p><b>1-22 Motor Voltage</b></p> <p>50-999 V * 230-400 V</p> <p><b>1-23 Motor Frequency</b></p> <p>20-400 Hz *60 Hz</p> <p><b>1-24 Motor Current</b></p> <p>0.01-100.00 A *Motortype dep.</p> <p><b>1-25 Motor Nominal Speed</b></p> <p>100-9999 rpm * Motortype dep.</p>	<p><b>1-29 Auto Tune</b></p> <p>*[0] Off</p> <p>[2] EnableAuto Tune</p> <p><b>1-3* Adv. Motor Data</b></p> <p><b>1-30 Stator Resistance (Rs)</b></p> <p>[Ohm] * Dep. on motor data</p> <p><b>1-33 Stator Leakage Reactance (X1)</b></p> <p>[Ohm] * Dep. on motor data</p> <p><b>1-35 Main Reactance (Xh)</b></p> <p>[Ohm] * Dep. on motor data</p> <p><b>1-5* Load Indep. Setting</b></p> <p><b>1-50 Motor Magnetisation at 0 Speed</b></p> <p>0-300% *100%</p> <p><b>1-52 Min Speed Norm. Magnet. [Hz]</b></p> <p>0.0-10.0 Hz *0.0 Hz</p> <p><b>1-55 U/f Characteristic - U</b></p> <p>0-999.9 V</p> <p><b>1-56 U/f Characteristic - F</b></p> <p>0-400 Hz</p> <p><b>1-6* Load Depen. Setting</b></p> <p><b>1-60 Low Speed Load Compensation</b></p> <p>0-199% Load CompensationLoad Compensation *100%</p> <p><b>1-61 High Speed Load Compensation</b></p> <p>0-199% *100%</p> <p><b>1-62 Slip Compensation</b></p> <p>-400-399% *100%</p> <p><b>1-63 Slip Compensation Time Constant</b></p> <p>0.05-5.00 s *0.10 s</p> <p><b>1-7* Start Adjustments</b></p> <p><b>1-71 Holding Time</b></p> <p>0.0-10.0 s * 0.0 s</p> <p><b>1-72 Start Function</b></p> <p>[0] DC hold/delay time</p> <p>[1] DC brake/delay time</p> <p>*[2] Coast/delay time</p> <p><b>1-73 Start Mode</b></p> <p>*[0] Disabled</p> <p>[1] Enable - Catch Spinning Load</p> <p><b>1-8* Stop Adjustments</b></p> <p><b>1-80 Function at Stop</b></p> <p>*[0] Coast</p> <p>[1] DC hold</p>	<p><b>1-82 Min Speed for Funct. at Stop [Hz]</b></p> <p>0.0-20.0 Hz *0.0 Hz</p> <p><b>1-9* Motor Temperature</b></p> <p><b>1-90 Motor Thermal Protection</b></p> <p>*[0] No protection</p> <p>[1] Thermistor warning</p> <p>[2] Thermistor trip</p> <p>[3] Electronic Overload warning</p> <p>[4] Electronic Overload trip</p> <p><b>1-93 Thermistor Resource</b></p> <p>*[0] None</p> <p>[1] Analog input 53</p> <p>[6] Digital input 29</p> <p><b>2-** Brakes</b></p> <p><b>2-0* DC-Brake</b></p> <p><b>2-00 DC Hold Current</b></p> <p>0-150% *50%</p> <p><b>2-01 DC Brake Current</b></p> <p>0-150% *50%</p> <p><b>2-02 DC Braking Time</b></p> <p>0.0-60.0 s *10.0 s</p> <p><b>2-04 DC Brake Cut In Speed</b></p> <p>0.0-400.0 Hz * 0.0 Hz</p> <p><b>2-1* Brake Energy Funct.</b></p> <p><b>2-10 Brake Function</b></p> <p>*[0] Off</p> <p>[1] Resistor brake</p> <p>[2] AC brake</p> <p><b>2-11 Brake Resistor (ohm)</b></p> <p>5-5000 *5</p> <p><b>2-16 AC Brake, Max current</b></p> <p>0-150% *100%</p> <p><b>2-17 Over-voltage Control</b></p> <p>*[0] Disabled</p> <p>[1] Enabled (not at stop)</p> <p>[2] Enabled</p> <p><b>2-2* Mechanical Brake</b></p> <p><b>2-20 Release Brake Current</b></p> <p>0.00-100.0 A *0.00 A</p> <p><b>2-22 Activate Brake Speed [Hz]</b></p> <p>0.0-400.0 Hz * 0.0 Hz</p> <p><b>3-** Reference / Ramps</b></p> <p><b>3-0* Reference Limits</b></p> <p><b>3-00 Reference Range</b></p> <p>*[0] Min to Max</p> <p>[1] -Max to+Max</p> <p><b>3-02 Minimum Reference</b></p> <p>-4999-4999 *0.000</p> <p><b>3-03 Maximum Reference</b></p> <p>-4999-4999 *50.00</p>

Table 5.1



<p><b>3-1* References</b></p> <p><b>3-10 Preset Reference</b> -100.0-100.0% *0.00%</p> <p><b>3-11 Jog Speed [Hz]</b> 0.0-400.0 Hz *5.0 Hz</p> <p><b>3-12 Catch up/slow Down Value</b> 0.00-100.0% *0.00%</p> <p><b>3-14 Preset Relative Reference</b> -100.0-100.0% *0.00%</p> <p><b>3-15 Reference Resource 1</b> [0] No function *[1] Analog Input 53 [2] Analog input 60 [8] Pulse input 33 [11] Local bus ref [21] Keypad Potentiometer</p> <p><b>3-16 Reference Resource 2</b> [0] No function [1] Analog Input 53 *[2] Analog input 60 [8] Pulse input 33 *[11] Local bus ref [21] Keypad Potentiometer</p> <p><b>3-17 Reference Resource 3</b> [0] No function [1] Analog Input 53 [2] Analog input 60 [8] Pulse input 33 *[11] Local bus ref [21] Keypad Potentiometer</p> <p><b>3-18 Relative Scaling Ref. Resource</b> *[0] No function [1] Analog Input 53 [2] Analog input 60 [8] Pulse input 33 [11] Local bus ref [21] Keypad Potentiometer</p> <p><b>3-4* Accel/Decel 1</b></p> <p><b>3-40 Accel/Decel 1 Pattern</b> *[0] Linear [2] S-Shape</p> <p><b>3-41 Accel Time 1</b> 0.05-3600 s *3.00 s (10.00 s<sup>1)</sup>)</p> <p><b>3-42 Decel Time 1</b> 0.05-3600 s *3.00 s (10.00 s<sup>1)</sup>)</p> <p><b>3-5* Accel/Decel 2</b></p> <p><b>3-50 Accel/Decel 2 Pattern</b> *[0] Linear [2] S-Shape</p> <p><b>3-51 Accel Time 2</b> 0.05-3600 s *3.00 s (10.00 s<sup>1)</sup>)</p>	<p><b>3-52 Decel Time 2</b> 0.05-3600 s *3.00 s (10.00 s<sup>1)</sup>)</p> <p><b>3-8* Other Ramps</b></p> <p><b>3-80 Jog Accel and Decel Time</b> 0.05-3600 s *3.00 s (10.00 s<sup>1)</sup>)</p> <p><b>3-81 Quick Stop Decel Time</b> 0.05-3600 s *3.00 s(10.00 s<sup>1)</sup>)</p> <p><b>4-** Limits/Warnings</b></p> <p><b>4-1* Motor Limits</b></p> <p><b>4-10 Reverse Lock</b> [0] Reverse Lock if Par. 1-00 is set to [3] [1] Reverse *[2] Both if Par. 1-00 is set to [0]</p> <p><b>4-12 Motor Speed Low Limit [Hz]</b> 0.0-400.0 Hz * 0.0 Hz</p> <p><b>4-14 Motor Speed High Limit [Hz]</b> 0.1-400.0 Hz *65.0 Hz</p> <p><b>4-16 Torque Limit Motor Mode</b> 0-400% *150%</p> <p><b>4-17 Torque Limit Generator Mode</b> 0-400% *100%</p> <p><b>4-4* Adj. Warnings 2</b></p> <p><b>4-40 Warning Frequency Low</b> 0.00-Value of 4-41 Hz *0.0 Hz</p> <p><b>4-41 Warning Frequency High</b> Value of 4-40-400.0 Hz *400.0 Hz</p> <p><b>4-5* Adj. Warnings</b></p> <p><b>4-50 Warning Current Low</b> 0.00-100.00 A *0.00 A</p> <p><b>4-51 Warning Current High</b> 0.00-100.00 A *100.00 A</p> <p><b>4-54 Warning Reference Low</b> -4999.000-Value of 4-55 *-4999.000</p> <p><b>4-55 Warning Reference High</b> Value of 4-54-4999.000 *4999.000</p> <p><b>4-56 Warning Feedback Low</b> -4999.000-Value of 4-57 *-4999.000</p> <p><b>4-57 Warning Feedback High</b> Value of 4-56-4999.000 *4999.000</p> <p><b>4-58 Missing Motor Phase Function</b> [0] Off *[1] On</p> <p><b>4-6* Jump Frequencies</b></p> <p><b>4-61 Jump Frequency From [Hz]</b> 0.0-400.0 Hz * 0.0 Hz</p> <p><b>4-63 Jump FrequencyTo [Hz]</b> 0.0-400.0 Hz * 0.0 Hz</p>	<p><b>5-1* Digital Inputs</b></p> <p><b>5-10 Terminal 18 Digital Input</b> [0] No function [1] Reset [2] Coast inverse [3] Coast and reset inv. [4] Quick stop inverse [5] DC-brake inv. [6] Stop inv *[8] Start [9] Latched start [10] Reversing [11] Start reversing [12] Enable start forward [13] Enable start reverse [14] Jog [16-18] Preset ref bit 0-2 [19] Freeze reference [20] Freeze output [21] Speed up [22] Speed down [23] Setup select bit 0 [28] Catch up [29] Slow down [34] Ramp bit 0 [60] Counter A (up) [61] Counter A (down) [62] Reset counter A [63] Counter B (up) [64] Counter B (down) [65] ResetCounter B</p> <p><b>5-11 Terminal 19 Digital Input</b> See par. 5-10. *[10] Reversing</p> <p><b>5-12 Terminal 27 Digital Input</b> See par. 5-10. * [1] Reset</p> <p><b>5-13 Terminal 29 Digital Input</b> See par. 5-10. * [14] Jog</p> <p><b>5-15 Terminal 33 Digital Input</b> See par. 5-10. * [16] Preset ref bit 0 [26] Precise Stop Inverse [27] Start, Precise Stop [32] Pulse Input</p> <p><b>5-3* Digital Outputs</b></p> <p><b>5-34 On Delay, Terminal 42 Digital Output</b> 0.00-600.00 s *0.01 s</p> <p><b>5-35 Off Delay, Terminal 42 Digital Output</b> 0.00-600.00 s *0.01 s</p> <p><b>5-4* Relays</b></p>	<p><b>5-40 Function Relay</b> *[0] No operation [1] Control ready [2] Drive ready [3] Drive ready, Remote [4] Enable/No warning [5] Drive running [6] Running/No warning [7] Run in range/No warning [8] Run on ref/No warning [9] Alarm [10] Alarm or warning [12] Out of current range [13] Below current, low [14] Above current, high [16] Below frequency, low [17] Above frequency, high [19] Below feedback, low [20] Above feedback, high [21] Thermal warning [22] Ready, No thermal warning [23] Remote ready, No thermal warning [24] Ready, Voltage ok [25] Reverse [26] Bus ok [28] Brake,NoWarn [29] Brake ready/NoFault [30] BrakeFault (IGBT) [32] Mech.brake control [36] Control word bit 11 [41] Below reference, low [42] Above reference, high [51] Local ref. active [52] Remote ref. active [53] No alarm [54] Start cmd active [55] Running reverse [56] Drive in hand mode [57] Drive in auto mode [60-63] Comparator 0-3 [70-73] Logic rule 0-3 [81] Logic Controller digital output B</p> <p><b>5-41 On Delay, Relay</b> 0.00-600.00 s *0.01 s</p> <p><b>5-42 Off Delay, Relay</b> 0.00-600.00 s *0.01 s</p> <p><b>5-5* Pulse Input</b></p> <p><b>5-55 Terminal 33 Low Frequency</b> 20-4999 Hz * 20 Hz</p>
<p><sup>1)</sup> M4 and M5 only</p>			

Table 5.2



<p><b>5-56 Terminal 33 High Frequency</b> 21-5000 Hz *5000 Hz -4999-4999 *0.000 <b>5-58 Term. 33 High Ref./Feedb. Value</b> -4999-4999 *50.0006-** <i>Analog In/Out</i> <b>6-** Analog In/Out</b> <b>6-0* Analog I/O Mode</b> <b>6-00 Live Zero Timeout Time</b> 1-99 s *10 s <b>6-01 Live Zero TimeoutFunction</b> *[0] Off [1] Freeze output [2] Stop [3] Jogging [4] Max speed [5] Stop and trip <b>6-1* Analog Input 1</b> <b>6-10 Terminal 53 Low Voltage</b> 0.00-9.99 V *0.07 V <b>6-11 Terminal 53 High Voltage</b> 0.01-10.00 V *10.00 V <b>6-12 Terminal 53 Low Current</b> 0.00-19.99 mA *0.14 mA <b>6-13 Terminal 53 High Current</b> 0.01-20.00 mA *20.00 mA <b>6-14 Term. 53 Low Ref./Feedb. Value</b> -4999-4999 *0.000 <b>6-15 Term. 53 High Ref./Feedb. Value</b> -4999-4999 *50.000 <b>6-16 Terminal 53 Filter Time Constant</b> 0.01-10.00 s *0.01 s <b>6-19 Terminal 53 mode</b> *[0] Voltage mode [1] Current mode <b>6-2* Analog Input 2</b> <b>6-22 Terminal 60 Low Current</b> 0.00-19.99 mA *0.14 mA <b>6-23 Terminal 60 High Current</b> 0.01-20.00 mA *20.00 mA <b>6-24 Term. 60 Low Ref./Feedb. Value</b> -4999-4999 *0.000 <b>6-25 Term. 60 High Ref./Feedb. Value</b> -4999-4999 *50.00 <b>6-26 Terminal 60 Filter Time Constant</b> 0.01-10.00 s *0.01 s <b>6-8* Keypad potentiometer</b> <b>6-80 Keypad Keypad Potmeter Enable</b> [0] Disabled [1] * Enable</p>	<p><b>6-81 keypad potm. Low Reference</b> -4999-4999 *0.000 <b>6-82 Keypad potm. High Reference</b> -4999-4999 *50.00 <b>6-9* Analog Output xx</b> <b>6-90 Terminal 42 Mode</b> *[0] 0-20 mA [1] 4-20 mA [2] Digital Output <b>6-91 Terminal 42 Analog Output</b> *[0] No operation [10] Output Frequency [11] Reference [12] Feedback [13] Motor Current [16] Power [20] Bus Reference <b>6-92 Terminal 42 Digital Output</b> See par. 5-40 *[0] No Operation [80] Logic Controller Digital Output A <b>6-93 Terminal 42 Output Min Scale</b> 0.00-200.0% *0.00% <b>6-94 Terminal 42 Output Max Scale</b> 0.00-200.0% *100.0% <b>7-** Controllers</b> <b>7-2* Process Ctrl. Feedb</b> <b>7-20 Process CL Feedback 1 Resource</b> *[0] NoFunction [1] Analog Input 53 [2] Analog input 60 [8] PulseInput33 [11] LocalBusRef <b>7-3* Process PI Ctrl. 7-30 Process PI Normal/Inverse Ctrl</b> *[0] Normal [1] Inverse <b>7-31 Process PI Anti Windup</b> [0] Disable *[1] Enable <b>7-32 Process PI Start Speed</b> 0.0-200.0 Hz *0.0 Hz <b>7-33 Process PI Proportional Gain</b> 0.00-10.00 *0.01 <b>7-34 Process PI Integral Time</b> 0.10-9999 s *9999 s <b>7-38 Process PI Feed Forward Factor</b> 0-400% *0% <b>7-39 On Reference Bandwidth</b> 0-200% *5%</p>	<p><b>8-** Comm. and Options</b> <b>8-0* General Settings</b> <b>8-01 Control Site</b> *[0] Digital and ControlWord [1] Digital only [2] ControlWord only <b>8-02 Control Word Source</b> [0] None *[1] GE Drive RS485 <b>8-03 Control Word Timeout Time</b> 0.1-6500 s *1.0 s <b>8-04 Control Word Timeout Function</b> *[0] Off [1] Freeze Output [2] Stop [3] Jogging [4] Max. Speed [5] Stop and trip <b>8-06 Reset Control Word Timeout</b> *[0] No Function [1] Do reset <b>8-3* GE Drive Port Settings</b> <b>8-30 Protocol</b> *[0] GE Drive [2] Modbus RTU <b>8-31 Address</b> 1-247 *1 <b>8-32 GE Drive Port Baud Rate</b> [0] 2400 Baud [1] 4800 Baud *[2] 9600 Baud For choosing GE Drive in 8-30 *[3] 19200 Baud For choosing GE Drive in 8-30 *[4] 38400 Baud <b>8-33 GE Drive Port Parity</b> *[0] Even Parity, 1 Stop Bit [1] Odd Parity, 1 Stop Bit [2] No Parity, 1 Stop Bit [3] No Parity, 2 Stop Bits <b>8-35 Minimum Response Delay</b> 0.001-0.5 *0.010 s <b>8-36 Max Response Delay</b> 0.100-10.00 s *5.000 s <b>8-4* Drive MC protocol set</b> <b>8-43 Drive Port PCD Read Configuration</b> *[0] None Expressionlimit [1] [1500] Operation Hours [2] [1501] Running Hours [3] [1502] kWh Counter [4] [1600] Control Word [5] [1601] Reference [Unit]</p>	<p>[6] [1602] Reference % [7] [1603] Status Word [8] [1605] Main Actual Value [%] [9] [1609] Custom Readout [10] [1610] Power [kW] [11] [1611] Power [hp] [12] [1612] Motor Voltage [13] [1613] Frequency [14] [1614] Motor Current [15] [1615] Frequency [%] [16] [1618] Motor Thermal [17] [1630] DC Link Voltage [18] [1634] Heatsink Temp. [19] [1635] Inverter Thermal [20] [1638] SL Controller State [21] [1650] External Reference [22] [1651] Pulse Reference [23] [1652] Feedback [Unit] [24] [1660] Digital Input 18,19,27,33 [25] [1661] Digital Input 29 [26] [1662] Analog Input 53(V) [27] [1663] Analog Input 53(mA) [28] [1664] Analog Input 60 [29] [1665] Analog Output 42 [mA] [30] [1668] Freq. Input 33 [Hz] [31] [1671] Relay Output [bin] [32] [1672] Counter A [33] [1673] Counter[34] [1690] Alarm Word [34] [1690] Alarm Word [35] [1692] Warning Word [36] [1694] Ext. Status Word <b>8-5* Digital/Bus</b> <b>8-50 Coasting Select</b> [0] DigitalInput [1] Bus [2] LogicAnd *[3] LogicOr <b>8-51 Quick Stop Select</b> See par. 8-50 * [3] LogicOr <b>8-52 DC Brake Select</b> See par. 8-50 * [3] LogicOr <b>8-53 Start Select</b> See par. 8-50 * [3] LogicOr <b>8-54 Reversing Select</b> See par. 8-50 * [3] LogicOr <b>8-55 Set-up Select</b> See par. 8-50 * [3] LogicOr <b>8-56 Preset Reference Select</b> See par. 8-50 * [3] LogicOr <b>8-8X Bus communication Diagnostics</b> <b>8-80 Bus Message Count</b> 0-0 N/A *0 N/A <b>8-81 Bus Error Count</b> 0-0 N/A *0 N/A</p>
--	--	--	---

Table 5.3



Parameter Lists

AF-60 LP™ Micro Drive Programming Guide

5

<p><b>8-82 Slave Messages Rcvd</b> 0-0 N/A *0 N/A</p> <p><b>8-83 Slave Error Count</b> 0-0 N/A *0 N/A</p> <p><b>8-9* Bus Jog / Feedback</b></p> <p><b>8-94 Bus feedback 1</b> 0x8000-0x7FFF *0</p> <p><b>13-** Controller Logic</b></p> <p><b>13-0* Logic Controller Settings</b></p> <p><b>13-00 Logic Controller Mode</b> *[0] Off [1] On</p> <p><b>13-01 Start Event</b> [0] False [1] True [2] Running [3] InRange [4] OnReference [7] OutOfCurrentRange [8] BelowLow [9] AboveHigh [16] ThermalWarning [17] MainOutOfRange [18] Reversing [19] Warning [20] Alarm_Trip [21] Alarm_TripLock [22-25] Comparator 0-3 [26-29] LogicRule0-3 [33] DigitalInput_18 [34] DigitalInput_19 [35] DigitalInput_27 [36] DigitalInput_29 [38] DigitalInput_33 *[39] StartCommand [40] DriveStopped</p> <p><b>13-02 Stop Event</b> See par. 13-01 * [40] DriveStopped</p> <p><b>13-03 Reset Logic Controller</b> *[0] Do not reset [1] Reset Logic Controller</p> <p><b>13-1* Comparators</b></p> <p><b>13-10 Comparator Operand</b> *[0] Disabled [1] Reference [2] Feedback [3] MotorSpeed [4] MotorCurrent [6] MotorPower [7] MotorVoltage [8] DCLinkVoltage [12] AnalogInput53 [13] AnalogInput60 [18] PulseInput33 [20] AlarmNumber</p>	<p>[30] CounterA [31] CounterB</p> <p><b>13-11 Comparator Operator</b> [0] Less Than *[1] Approximately equals [2] Greater Than</p> <p><b>13-12 Comparator Value</b> -9999-9999 *0.0</p> <p><b>13-2* Timers</b></p> <p><b>13-20 LC Controller Timer</b> 0.0-3600 s *0.0 s</p> <p><b>13-4* Logic Rules</b></p> <p><b>13-40 Logic Rule Boolean 1</b> See par. 13-01 * [0] False [30]-[32] LC Time-out 0-2</p> <p><b>13-41 Logic Rule Operator 1</b> *[0] Disabled [1] And [2] Or [3] And not [4] Or not [5] Not and [6] Not or [7] Not and not [8] Not or not</p> <p><b>13-42 Logic Rule Boolean 2</b> See par. 13-40</p> <p><b>13-43 Logic Rule Operator 2</b> See par. 13-41 * [0] Disabled</p> <p><b>13-44 Logic Rule Boolean 3</b> See par. 13-40</p> <p><b>13-5* States</b></p> <p><b>13-51 LC Controller Event</b> See par. 13-40</p> <p><b>13-52 LC Controller Action</b> *[0] Disabled [1] NoAction [2] SelectSetup1 [3] SelectSetup2 [10-17] SelectPresetRef0-7 [18] Select Accel/Decel 1. [19] Select Accel/Decel 2. [22] Run [23] RunReverse [24] Stop [25] Qstop [26] DCstop [27] Coast [28] FreezeOutput [29] StartTimer0 [30] StartTimer1 [31] StartTimer2 et Digital Output B High [32] Set Digital Output A Low [33] Set Digital Output B Low</p>	<p>[38] Set Digital Output A High [39] Set Digital Output B High [60] ResetCounterA [61] ResetCounterB</p> <p><b>14-** Special Functions</b></p> <p><b>14-0*Carrier Frequency</b></p> <p><b>14-01 Motor Noise (Carrier Frequency)</b> [0] 2 kHz *[1] 4 kHz [2] 8 kHz [4] 16 kHz not available for M5</p> <p><b>14-03 Overmodulation</b> [0] Off *[1] On</p> <p><b>14-1* Mains monitoring</b></p> <p><b>14-12 Function at mains imbalance</b> *[0] Trip [1] Warning [2] Disabled</p> <p><b>14-2* Trip Reset</b></p> <p><b>14-20 Reset Mode</b> *[0] Manual reset [1-9] AutoReset 1-9 [10] AutoReset 10 [11] AutoReset 15 [12] AutoReset 20 [13] Infinite auto reset [14] Reset at power up</p> <p><b>14-21 Automatic Restart Time</b> 0-600 s * 10 s</p> <p><b>14-22 Restore Factory Settings</b> *[0] Normal Operation [2] Restore Factory Settings</p> <p><b>14-26 Action At Drive Fault</b> *[0] Trip [1] Warning</p> <p><b>14-4* Energy Savings</b></p> <p><b>14-41 Energy Savings Minimum Magnetisation</b> 40-75% *66%</p> <p><b>15-** Drive Information 15-0*</b></p> <p><b>Operating Data</b></p> <p><b>15-00 Operating Days</b></p> <p><b>15-01 Running Hours</b></p> <p><b>15-02 kWh Counter</b></p> <p><b>15-03 Power Ups</b></p> <p><b>15-04 Over Temps</b></p> <p><b>15-05 Over Volts</b></p> <p><b>15-06 Reset kWh Counter</b> *[0] Do not reset [1] Reset counter</p> <p><b>15-07 Reset Running Hours Counter</b> *[0] Do not reset [1] Reset counter</p>	<p><b>15-3* Fault Log</b></p> <p><b>15-30 Fault Log: Error Code</b></p> <p><b>15-4* Drive Identification</b></p> <p><b>15-40 GE Drive Type</b></p> <p><b>15-41 Power Section</b></p> <p><b>15-42 Voltage</b></p> <p><b>15-43 Software Version</b></p> <p><b>15-46 Frequency Converter Order. No</b></p> <p><b>15-48 Keypad Id No</b></p> <p><b>15-51 Frequency Converter Serial No</b></p> <p><b>16-** Data Readouts</b></p> <p><b>16-0* General Status</b></p> <p><b>16-00 Control Word</b> 0-0xFFFF</p> <p><b>16-01 Reference [Unit]</b> -4999-4999</p> <p><b>16-02 Reference %</b> -200.0-200.0 %</p> <p><b>16-03 Status Word</b> 0-0xFFFF</p> <p><b>16-05 Main Actual Value [%]</b> -200.0-200.0 %</p> <p><b>16-09 Custom Readout</b> Dep. on par. 0-31, 0-32 and 4-14</p> <p><b>16-1* Motor Status</b></p> <p><b>16-10 Power [kW]</b></p> <p><b>16-11 Power [hp]</b></p> <p><b>16-12 Motor Voltage [V]</b></p> <p><b>16-13 Frequency [Hz]</b></p> <p><b>16-14 Motor Current [A]</b></p> <p><b>16-15 Frequency [%]</b></p> <p><b>16-18 Motor Thermal [%]</b></p> <p><b>16-3* Drive Status</b></p> <p><b>16-30 DC Link Voltage</b></p> <p><b>16-34 Heatsink Temp.</b></p> <p><b>16-35 Inverter Thermal</b></p> <p><b>16-36 Drive Nominal current</b></p> <p><b>16-37 Drive Maximum Current</b></p> <p><b>16-38 Logic Controller State</b></p> <p><b>16-5* Ref. / Feedb.</b></p> <p><b>16-50 External Reference</b></p> <p><b>16-51 Pulse Reference</b></p> <p><b>16-52 Feedback [Unit]</b></p> <p><b>16-6* Inputs/Outputs</b></p> <p><b>16-60 Digital Input 18,19,27,33</b> 0-1111</p> <p><b>16-61 Digital Input 29</b> 0-1</p> <p><b>16-62 Analog Input 53 (volt)</b></p> <p><b>16-63 Analog Input 53 (current)</b></p> <p><b>16-64 Analog Input 60</b></p> <p><b>16-65 Analog Output 42 [mA]</b></p> <p><b>16-68 Pulse Input [Hz]</b></p> <p><b>16-71 Relay Output [bin]</b></p> <p><b>16-72 Counter A</b></p>
--	---	---	---

Table 5.4



Parameter Lists AF-60 LP™ Micro Drive Programming Guide

<b>16-73 Counter B</b> <b>16-8* Fieldbus/GE Drive Port</b> <b>16-86 GE Drive Port REF 1</b> 0x8000-0x7FFFF <b>16-9* Diagnosis Readouts</b>	<b>16-90 Alarm Word</b> 0-0XFFFFFFF <b>16-92 Warning Word</b> 0-0XFFFFFFF <b>16-94 Ext. Status Word</b> 0-0XFFFFFFF	<b>18-** Extended Motor Data</b> <b>18-8* Motor Resistors</b> <b>18-80 Stator Resistance (High resolution)</b> 0.000-99.990 ohm *0.000 ohm	<b>18-81 Stator Leakage Reactance (High resolution)</b> 0.000-99.990 ohm *0.000 ohm
--	--	---	--

Table 5.5

### 5.2.1 Conversion Index

The various attributes of each parameter are displayed in the section *Factory Settings*. Parameter values are transferred as whole numbers only. Conversion factors are therefore used to transfer decimals according to *Table 5.6*.

Example:

Conversion index	Conversion factor
2	10
1	100
0	1
-1	0.1
-2	0.01
-3	0.001
-4	0.0001
-5	0.00001

Table 5.6 Conversion Table

### 5.2.2 Change during operation

“TRUE” means that the parameter can be changed while the frequency converter is in operation and “FALSE” means that the frequency converter must be stopped before a change can be made.

### 5.2.4 Type

Data Type	Description	Type
2	Integer 8	Int8
3	Integer 16	Int16
4	Integer 32	Int32
5	Unsigned 8	UInt8
6	Unsigned 16	UInt16
7	Unsigned 32	UInt32
9	Visible string	VisibleString

Table 5.7

*1-24 Motor Current* has a conversion index of -2 (i.e. conversion factor of 0.01 according to *Table 5.6*). To set the parameter to 2.25 A, transfer the value 225 via Modbus. The Conversion Factor of 0.01 means that the value transferred is multiplied by 0.01 in the frequency converter. The value 225 transferred on the bus is thus perceived as 2.25 A in the frequency converter.



5.2.5 0-\*\* Operation/Display

5

Parameter Number	Parameter Description	Default Value	2 Setup	Change During Operation	Conversion Index	Type
0-03	Regional Settings	[1] US	1 set-up	FALSE	-	UInt8
0-04	Operating State at Power-up (Hand)	[1] Forced stop ref=old	All set-ups	TRUE	-	UInt8
0-10	Active Set-up	[1] Set-up 1	1 set-up	TRUE	-	UInt8
0-11	Edit Set-up	[1] Set-up 1	1 set-up	TRUE	-	UInt8
0-12	Link Setups	[20] Linked	All set-ups	FALSE	-	UInt8
0-31	Custom Readout Min Scale	0	1 set-up	TRUE	-2	Int32
0-32	Custom Readout Max Scale	0	1 set-up	TRUE	-2	Int32
0-40	[Hand ] Key on keypad	[1] Enabled	All set-ups	TRUE	-	UInt8
0-41	[Off / Reset] Key on keypad	[1] Enable All	All set-ups	TRUE	-	UInt8
0-42	[Auto ] Key on keypad	[1] Enabled	All set-ups	TRUE	-	UInt8
0-50	Keypad Copy	[0] No copy	1 set-up	FALSE	-	UInt8
0-51	Set-up Copy	[0] No copy	1 set-up	FALSE	-	UInt8
0-60	Main Menu Password	0	1 set-up	TRUE	0	UInt16
0-61	Access to Main/Quick menu w/o Password	0	1 set-up	TRUE	-	UInt8

Table 5.8



5.2.6 1-\*\* Load/Motor

Parameter Number	Parameter Description	Default Value	2 Setup	Change During Operation	Conversion Index	Type
1-00	Configuration Mode	[0] Speed open loop	All set-ups	TRUE	-	Uint8
1-01	Motor Control Principle	[1] Adv. Vector Control	All set-ups	FALSE	-	Uint8
1-03	Torque Characteristics	[0] Constant torque	All set-ups	TRUE	-	Uint8
1-05	Hand Mode Configuration	[2] As mode 1-00 Configuration Mode	All set-ups	TRUE	-	Uint8
1-20	Motor Power		All set-ups	FALSE	-	Uint8
1-22	Motor Voltage		All set-ups	FALSE	0	Uint16
1-23	Motor Frequency		All set-ups	FALSE	0	Uint16
1-24	Motor Current		All set-ups	FALSE	-2	Uint16
1-25	Motor Nominal Speed		All set-ups	FALSE	0	Uint16
1-29	Auto Tune	[0] Off	1 set-up	FALSE	-	Uint8
1-30	Stator Resistance (Rs)		All set-ups	FALSE	-2	Uint16
1-33	Stator Leakage Reactance (X1)		All set-ups	FALSE	-2	Uint32
1-35	Main Reactance (Xh)		All set-ups	FALSE	-2	Uint32
1-50	Motor Magnetisation at Zero Speed	100%	All set-ups	TRUE	0	Uint16
1-52	Min Speed Normal Magnetising [Hz]	0 Hz	All set-ups	TRUE	-1	Uint16
1-55	U/f Characteristic-U		All set-ups	TRUE	0	Uint16
1-56	U/f Characteristic-F		All set-ups	TRUE	0	Uint16
1-60	Low Speed Load Compensation	100%	All set-ups	TRUE	0	Uint16
1-61	High Speed Load Compensation	100%	All set-ups	TRUE	0	Uint16
1-62	Slip Compensation	100%	All set-ups	TRUE	0	Int16
1-63	Slip Compensation Time Constant	0.1 s	All set-ups	TRUE	-2	Uint16
1-71	Holding Time	0 s	All set-ups	TRUE	-1	Uint8
1-72	Start Function	[2] Coast/delay time	All set-ups	TRUE	-	Uint8
1-73	Start Mode	[0] Disabled	All set-ups	FALSE	-	Uint8
1-80	Function at Stop	[0] Coast	All set-ups	TRUE	-	Uint8
1-82	Min Speed for Function at Stop [Hz]	0 Hz	All set-ups	TRUE	-1	Uint16
1-90	Motor Thermal Protection	[0] No protection	All set-ups	TRUE	-	Uint8
1-93	Thermistor Resource	[0] None	All set-ups	FALSE	-	Uint8

Table 5.9





5.2.7 2-\*\* Brakes

5

Parameter Number	Parameter Description	Default Value	2 Setup	Change During Operation	Conversion Index	Type
2-00	DC Hold Current	50%	All set-ups	TRUE	0	Uint16
2-01	DC Brake Current	50%	All set-ups	TRUE	0	Uint16
2-02	DC Braking Time	10 s	All set-ups	TRUE	-1	Uint16
2-04	DC Brake Cut In Speed	0 Hz	All set-ups	TRUE	-1	Uint16
2-10	Brake Function	[0] Off	All set-ups	TRUE	-	Uint8
2-11	Brake Resistor (Ω)		All set-ups	TRUE	0	Uint16
2-16	AC Brake, Max current	100%	All set-ups	TRUE	0	Uint16
2-17	Over-voltage Control	[0] Disabled	All set-ups	TRUE	-	Uint8
2-20	Release Brake Current	0 A	All set-ups	TRUE	-2	Uint32
2-22	Activate Brake Speed [Hz]	0 Hz	All set-ups	TRUE	-1	Uint16

Table 5.10

5.2.8 3-\*\* Reference/Ramps

Parameter Number	Parameter Description	Default Value	2 Setup	Change During Operation	Conversion Index	Type
3-00	Reference Range	[0] Min to Max	All set-ups	TRUE	-	Uint8
3-02	Minimum Reference	0	All set-ups	TRUE	-3	Int32
3-03	Maximum Reference	50	All set-ups	TRUE	-3	Int32
3-10	Preset Reference	0%	All set-ups	TRUE	-2	Int16
3-11	Jog Speed [Hz]	5 Hz	All set-ups	TRUE	-1	Uint16
3-12	Catch up/slow Down Value	0%	All set-ups	TRUE	-2	Int16
3-14	Preset Relative Reference	0%	All set-ups	TRUE	-2	Int16
3-15	Reference Resource 1	[1] Analog in 53	All set-ups	TRUE	-	Uint8
3-16	Reference Resource 2	[2] Analog in 60	All set-ups	TRUE	-	Uint8
3-17	Reference Resource 3	[11] Local bus reference	All set-ups	TRUE	-	Uint8
3-18	Relative Scaling Reference Resource	[0] No function	All set-ups	TRUE	-	Uint8
3-40	Accel/Decel 1 Pattern	[0] Linear	All set-ups	TRUE	-	Uint8
3-41	Accel Time 1	3 s	All set-ups	TRUE	-2	Uint32
3-42	Decel Time 1	3 s	All set-ups	TRUE	-2	Uint32
3-50	Accel/Decel 2 Pattern	[0] Linear	All set-ups	TRUE	-	Uint8
3-51	Accel Time 2	3 s	All set-ups	TRUE	-2	Uint32
3-52	Decel Time 2	3 s	All set-ups	TRUE	-2	Uint32
3-80	Jog Accel/Decel Time	3 s	All set-ups	TRUE	-2	Uint32
3-81	Quick Stop Ramp Time	3 s	1 set-up	TRUE	-2	Uint32

Table 5.11



5.2.9 4-\*\* Limits/Warnings

Parameter Number	Parameter Description	Default Value	2 Setup	Change During Operation	Conversion Index	Type
4-10	Reverse Lock	[2] Both directions	All set-ups	FALSE	-	Uint8
4-12	Motor Speed Low Limit [Hz]	0 Hz	All set-ups	FALSE	-1	Uint16
4-14	Motor Speed High Limit [Hz]	65 Hz	All set-ups	FALSE	-1	Uint16
4-16	Torque Limit Motor Mode	150%	All set-ups	TRUE	0	Uint16
4-17	Torque Limit Generator Mode	100%	All set-ups	TRUE	0	Uint16
4-40	Warning Frequency Low	0Hz	All set-ups	TRUE	-1	Uint16
4-41	Warning Frequency High	400Hz	All set-ups	TRUE	-1	Uint16
4-50	Warning Current Low	0 A	All set-ups	TRUE	-2	Uint32
4-51	Warning Current High	26 A	All set-ups	TRUE	-2	Uint32
4-54	Warning Reference Low	-4999	All set-ups	TRUE	-3	Int32
4-55	Warning Reference High	4999	All set-ups	TRUE	-3	Int32
4-56	Warning Feedback Low	-4999	All set-ups	TRUE	-3	Int32
4-57	Warning Feedback High	4999	All set-ups	TRUE	-3	Int32
4-58	Missing Motor Phase Function	[1] On	All set-ups	FALSE	-	Uint8
4-61	Jump Frequency From [Hz]	0 Hz	All set-ups	TRUE	-1	Uint16
4-63	Jump Frequency To [Hz]	0 Hz	All set-ups	TRUE	-1	Uint16

Table 5.12

5.2.10 5-\*\* Digital In/Out

Parameter Number	Parameter Description	Default Value	2 Setup	Change During Operation	Conversion Index	Type
5-10	Terminal 18 Digital Input	[8] Start	All set-ups	TRUE	-	Uint8
5-11	Terminal 19 Digital Input	[10] Reversing	All set-ups	TRUE	-	Uint8
5-12	Terminal 27 Digital Input	[1] Reset	All set-ups	TRUE	-	Uint8
5-13	Terminal 29 Digital Input	[14] Jog	All set-ups	TRUE	-	Uint8
5-15	Terminal 33 Digital Input	[16] Preset ref bit 0	All set-ups	TRUE	-	Uint8
5-34	On Delay, Terminal 42 Digital Output	0.01s	All set-ups	TRUE	-2-	Uint16
5-35	Off Delay, Terminal 42 Digital Output	0.01s	All set-ups	TRUE	-2	Uint16
5-40	Function Relay	[0] No operation	All set-ups	TRUE	-	Uint8
5-41	On Delay, Relay	0.01s	All set-ups	TRUE	-2	Uint16
5-42	Off Delay, Relay	0.01s	All set-ups	TRUE	-2	Uint16
5-55	Terminal 33 Low Frequency	20 Hz	All set-ups	TRUE	0	Uint16
5-56	Terminal 33 High Frequency	5000 Hz	All set-ups	TRUE	0	Uint16
5-57	Terminal 33 Low Ref./Feedb. Value	0	All set-ups	TRUE	-3	Int32
5-58	Terminal 33 High Ref./Feedb. Value	50	All set-ups	TRUE	-3	Int32

Table 5.13



5.2.11 6-\*\* Analog In/Out

5

Parameter Number	Parameter Description	Default Value	2 Setup	Change During Operation	Conversion Index	Type
6-00	Live Zero Timeout Time	10 s	All set-ups	TRUE	0	Uint8
6-01	Live Zero TimeoutFunction	[0] Off	All set-ups	TRUE	-	Uint8
6-10	Terminal 53 Low Voltage	0.07 V	All set-ups	TRUE	-2	Uint16
6-11	Terminal 53 High Voltage	10 V	All set-ups	TRUE	-2	Uint16
6-12	Terminal 53 Low Current	0.14 mA	All set-ups	TRUE	-2	Uint16
6-13	Terminal 53 High Current	20 mA	All set-ups	TRUE	-2	Uint16
6-14	Terminal 53 Low Ref./Feedb. Value	0	All set-ups	TRUE	-3	Int32
6-15	Terminal 53 High Ref./Feedb. Value	50	All set-ups	TRUE	-3	Int32
6-16	Terminal 53 Filter Time Constant	0.01 s	All set-ups	TRUE	-2	Uint16
6-19	Terminal 53 mode	[0] Voltage mode	1 set-up	TRUE	-	Uint8
6-22	Terminal 60 Low Current	0.14 mA	All set-ups	TRUE	-2	Uint16
6-23	Terminal 60 High Current	20 mA	All set-ups	TRUE	-2	Uint16
6-24	Terminal 60 Low Ref./Feedb. Value	0	All set-ups	TRUE	-3	Int32
6-25	Terminal 60 High Ref./Feedb. Value	50	All set-ups	TRUE	-3	Int32
6-26	Terminal 60 Filter Time Constant	0.01 s	All set-ups	TRUE	-2	Uint16
6-80	Keypad Potmeter Enable	1	1 set-up	FALSE	-	Uint8
6-81	Keypad potentiometer Low Ref.	0	All set-ups	TRUE	-3	Int32
6-82	Keypad potentiometer High Ref.	50	All set-ups	TRUE	-3	Int32
6-90	Terminal 42 Mode	[0] 0-20 mA	All set-ups	TRUE	-	Uint8
6-91	Terminal 42 Analog Output	[0] No operation	All set-ups	TRUE	-	Uint8
6-92	Terminal 42 Digital Output	[0] No operation	All set-ups	TRUE	-	Uint8
6-93	Terminal 42 Output Min Scale	0%	All set-ups	TRUE	-2	Uint16
6-94	Terminal 42 Output Max Scale	100%	All set-ups	TRUE	-2	Uint16

Table 5.14

5.2.12 7-\*\* Controllers

Parameter Number	Parameter Description	Default Value	2 Setup	Change During Operation	Conversion Index	Type
7-20	Process CL Feedback 1 Resource	[0] No function	All set-ups	TRUE	-	Uint8
7-30	Process PI Normal/ Inverse Control	[0] Normal	All set-ups	TRUE	-	Uint8
7-31	Process PI Anti Windup	[1] Enabled	All set-ups	TRUE	-	Uint8
7-32	Process PI Start Speed	0 Hz	All set-ups	TRUE	-1	Uint16
7-33	Process PI Proportional Gain	0.01	All set-ups	TRUE	-2	Uint16
7-34	Process PI Integral Time	9999 s	All set-ups	TRUE	-2	Uint32
7-38	Process PI Feed Forward Factor	0%	All set-ups	TRUE	0	Uint16
7-39	On Reference Bandwidth	5%	All set-ups	TRUE	0	Uint8

Table 5.15



5.2.13 8-\*\* Comm. and Options

Parameter Number	Parameter Description	Default Value	2 Setup	Change During Operation	Conversion Index	Type
8-01	Control Site	[0] Digital and ctrl.word	All set-ups	TRUE	-	UInt8
8-02	Control Word Source	[1] GE Drive RS485	All set-ups	TRUE	-	UInt8
8-03	Control Word Timeout Time	1 s	1 set-up	TRUE	-1	UInt16
8-04	Control Word Timeout Function	[0] Off	1 set-up	TRUE	-	UInt8
8-06	Reset Control Word Timeout	[0] No function	1 set-up	TRUE	-	UInt8
8-30	Protocol	[0] GE Drive	1 set-up	TRUE	0	UInt8
8-31	Address	1	1 set-up	TRUE	0	UInt8
8-32	GE Drive Port Baud Rate	[2] 9600 Baud	1 set-up	TRUE	-	UInt8
8-33	GE Drive Port Parity	[0] Even Parity 1 Stop Bit	1 set-up	TRUE	-	UInt8
8-35	Minimum Response Delay	0.01 s	1 set-up	TRUE	-3	UInt16
8-36	Max Response Delay	5 s	1 set-up	TRUE	-3	UInt16
8-43	Drive Port PCD Read Configuration	0	1 set-up	TRUE	-	UInt8
8-50	Coasting Select	[3] Logic OR	All set-ups	TRUE	-	UInt8
8-51	Quick Stop Select	[3] Logic OR	All set-ups	TRUE	-	UInt8
8-52	DC Brake Select	[3] Logic OR	All set-ups	TRUE	-	UInt8
8-53	Start Select	[3] Logic OR	All set-ups	TRUE	-	UInt8
8-54	Reversing Select	[3] Logic OR	All set-ups	TRUE	-	UInt8
8-55	Set-up Select	[3] Logic OR	All set-ups	TRUE	-	UInt8
8-56	Preset Reference Select	[3] Logic OR	All set-ups	TRUE	-	UInt8
8-94	Bus feedback 1	0	All set-ups	TRUE	0	Int16

Table 5.16



5.2.14 13-\*\* Logic Controller

5

Parameter Number	Parameter Description	Default Value	2 Setup	Change During Operation	Conversion Index	Type
13-00	Logic Controller Mode	[0] Off	1 set-up	TRUE	-	UInt8
13-01	Start Event	[39] Start command	1 set-up	TRUE	-	UInt8
13-02	Stop Event	[40] Drive stopped	1 set-up	TRUE	-	UInt8
13-03	Reset Logic Controller	[0] Do not reset	1 set-up	TRUE	-	UInt8
13-10	Comparator Operand	[0] Disabled	1 set-up	TRUE	-	UInt8
13-11	Comparator Operator	[1] ApproxEqual	1 set-up	TRUE	-	UInt8
13-12	Comparator Value	0	1 set-up	TRUE	-1	Int32
13-20	Logic Controller Controller Timer	0 s	1 set-up	TRUE	-1	UInt32
13-40	Logic Rule Boolean 1	[0] False	1 set-up	TRUE	-	UInt8
13-41	Logic Rule Operator 1	[0] Disabled	1 set-up	TRUE	-	UInt8
13-42	Logic Rule Boolean 2	[0] False	1 set-up	TRUE	-	UInt8
13-43	Logic Rule Operator 2	[0] Disabled	1 set-up	TRUE	-	UInt8
13-44	Logic Rule Boolean 3	[0] False	1 set-up	TRUE	-	UInt8
13-51	Logic Controller Event	[0] False	1 set-up	TRUE	-	UInt8
13-52	Logic Controller Action	[0] Disabled	1 set-up	TRUE	-	UInt8

Table 5.17

5.2.15 14-\*\* Special Functions

Parameter Number	Parameter Description	Default Value	2 Setup	Change During Operation	Conversion Index	Type
14-01	Motor Noise (Carrier Freq.)	[1] 4.0 kHz	All set-ups	TRUE	-	UInt8
14-03	Overmodulation	[1] On	All set-ups	FALSE	-	UInt8
14-12	Function at Mains Imbalance	[0] Trip	All set-ups	TRUE	-	UInt8
14-20	Reset Mode	[0] Manual reset	All set-ups	TRUE	-	UInt8
14-21	Automatic Restart Time	10 s	All set-ups	TRUE	0	UInt16
14-22	Restore Factory Settings	[0] Normal operation	1 set-up	TRUE	-	UInt8
14-26	Action At Inverter Fault	[0] Trip	All set-ups	TRUE	-	UInt8
14-41	Energy Savings Minimum Magnetisation	66 %	All set-ups	TRUE	0	UInt8

Table 5.18



## 5.2.16 15-\*\* Drive Information

Parameter Number	Parameter Description	Default Value	2 Setup	Change During Operation	Conversion Index	Type
15-00	Operating Time	0	1 set-up	TRUE	0	UInt32
15-01	Running Hours	0	1 set-up	TRUE	0	UInt32
15-02	kWh Counter	0	1 set-up	TRUE	0	UInt32
15-03	Power Up's	0	1 set-up	TRUE	0	UInt32
15-04	Over Temp's	0	1 set-up	TRUE	0	UInt16
15-05	Over Volt's	0	1 set-up	TRUE	0	UInt16
15-06	Reset kWh Counter	[0] Do not reset	1 set-up	TRUE	-	UInt8
15-07	Reset Running Hours Counter	[0] Do not reset	1 set-up	TRUE	-	UInt8
15-30	Fault Log: Error Code	0	1 set-up	TRUE	0	UInt8
15-40	GE Drive Type		1 set-up	FALSE	0	VisibleString
15-41	Power Section		1 set-up	FALSE	0	VisibleString
15-42	Voltage		1 set-up	FALSE	0	VisibleString
15-43	SW ID Control Card		1 set-up	FALSE	0	VisibleString
	Frequency Converter Ordering					
15-46	No		1 set-up	FALSE	0	VisibleString
15-48	Keypad Id No		1 set-up	FALSE	0	VisibleString
	Frequency Converter Serial					
15-51	Number		1 set-up	FALSE	0	VisibleString

Table 5.19



5.2.17 16-\*\* Data Readouts

5

Parameter Number	Parameter Description	Default Value	2 Setup	Change During Operation	Conversion Index	Type
16-00	Control Word	0	1 set-up	TRUE	0	Uint16
16-01	Reference [Unit]	0	1 set-up	TRUE	-3	Int32
16-02	Reference %	0	1 set-up	TRUE	-1	Int16
16-03	Status Word	0	1 set-up	TRUE	0	Uint16
16-05	Main Actual Value [%]	0	1 set-up	TRUE	-2	Int16
16-09	Custom Readout	0	1 set-up	TRUE	-2	Int32
16-10	Power [kW]	0	1 set-up	TRUE	-3	Uint16
16-11	Power [hp]	0	1 set-up	TRUE	-3	Uint16
16-12	Motor Voltage	0	1 set-up	TRUE	0	Uint16
16-13	Frequency	0	1 set-up	TRUE	-1	Uint16
16-14	Motor Current	0	1 set-up	TRUE	-2	Uint16
16-15	Frequency [%]	0	1 set-up	TRUE	-1	Uint16
16-18	Motor Thermal	0	1 set-up	TRUE	0	Uint8
16-30	DC Link Voltage	0	1 set-up	TRUE	0	Uint16
16-34	Heatsink Temp.	0	1 set-up	TRUE	0	Uint8
16-35	Inverter Thermal	0	1 set-up	TRUE	0	Uint8
16-36	Inv. Nom. Current	0	1 set-up	TRUE	-2	Uint16
16-37	Inv. Max. Current	0	1 set-up	TRUE	-2	Uint16
16-38	Logic Controller State	0	1 set-up	TRUE	0	Uint8
16-50	External Reference	0	1 set-up	TRUE	-1	Int16
16-51	Pulse Reference	0	1 set-up	TRUE	-1	Int16
16-52	Feedback [Unit]	0	1 set-up	TRUE	-3	Int32
16-60	Digital input 18,19,27,33	0	1 set-up	TRUE	0	Uint16
16-61	Digital input 29	0	1 set-up	TRUE	0	Uint8
16-62	Analog Input 53 (V)	0	1 set-up	TRUE	-2	Uint16
16-63	Analog Input 53 (mA)	0	1 set-up	TRUE	-2	Uint16
16-64	Analog Input 60	0	1 set-up	TRUE	-2	Uint16
16-65	Analog Output 42 [mA]	0	1 set-up	TRUE	-2	Uint16
16-68	Pulse input 33	20	1 set-up	TRUE	0	Uint16
16-71	Relay Output [bin]	0	1 set-up	TRUE	0	Uint8
16-72	Counter A	0	1 set-up	TRUE	0	Int16
16-73	Counter B	0	1 set-up	TRUE	0	Int16
16-86	GE Drive Port REF 1	0	1 set-up	TRUE	0	Int16
16-90	Alarm Word	0	1 set-up	TRUE	0	Uint32
16-92	Warning Word	0	1 set-up	TRUE	0	Uint32
16-94	Ext. Status Word	0	1 set-up	TRUE	0	Uint32

Table 5.20



## 6 Troubleshooting

A warning or an alarm is signalled by the relevant LED on the front of the frequency converter and indicated by a code on the display.

A warning remains active until its cause is no longer present. Under certain circumstances operation of the motor may still be continued. Warning messages may be critical, but are not necessarily so.

In the event of an alarm, the frequency converter will have tripped. Alarms must be reset to restart operation once their cause has been rectified.

**This may be done in four ways:**

1. By pressing [Reset].
2. Via a digital input with the "Reset" function.
3. Via serial communication.

### NOTE

After a manual reset press [Reset], [Auto] or [Hand] to restart the motor.

If an alarm cannot be reset, the reason may be that its cause has not been rectified, or the alarm is trip-locked (see also *Table 6.1*).

### CAUTION

Alarms that are trip-locked offer additional protection, means that the mains supply must be switched off before the alarm can be reset. After being switched back on, the frequency converter is no longer blocked and may be reset as described above once the cause has been rectified.

Alarms that are not trip-locked can also be reset using the automatic reset function in *14-20 Reset Mode* (Warning: automatic wake-up is possible!)

If a warning and alarm is marked against a code in the *Table 6.1*, this means that either a warning occurs before an alarm, or it can be specified whether it is a warning or an alarm that is to be displayed for a given fault.

This is possible, for instance, in *1-90 Motor Thermal Protection*. After an alarm or trip, the motor carries on coasting, and the alarm and warning flash on the frequency converter. Once the problem has been rectified, only the alarm continues flashing.



No.	Description	Warning	Alarm	Trip Lock	Error	Parameter Reference
2	Live zero error	(X)	(X)			6-01
4	Mains phase loss	(X)	(X)	(X)		14-12
7	DC over voltage	X	X			
8	DC under voltage	X	X			
9	Inverter overloaded	X	X			
10	Motor overload temperature	(X)	(X)			1-90
11	Motor thermistor over temperature	(X)	(X)			1-90
12	Torque limit	(X)				4-16, 4-17
13	Over Current	X	X	X		
14	Earth fault	X	X	X		
16	Short Circuit		X	X		
17	Control word timeout	(X)	(X)			8-04
25	Brake resistor short-circuited		X	X		
27	Brake chopper short-circuited		X	X		
28	Brake Check		X			
29	Power board over temp		X	X		
30	Motor phase U missing		(X)	(X)		4-58
31	Motor phase V missing		(X)	(X)		4-58
32	Motor phase W missing		(X)	(X)		4-58
38	Internal fault		X	X		
44	Earth fault 2		X	X		
47	Control Voltage Fault		X	X		





No.	Description	Warning	Alarm	Trip Lock	Error	Parameter Reference
51	Auto tune check $U_{nom}$ and $I_{nom}$		X			
52	Auto tune low $I_{nom}$		X			
53	Auto tune motor too big		X			
54	Auto tune motor too small		X			
55	Auto tune Parameter out of range		X			
59	Current limit	X				
63	Mechanical Brake Low		X			
80	Drive Initialized to Default Value		X			
84	The connection between drive and keypad is lost				X	
85	Button disabled				X	
86	Copy fail				X	
87	Keypad data invalid				X	
88	Keypad data not compatible				X	
89	Parameter read only				X	
90	Parameter database busy				X	
91	Parameter value is not valid in this mode				X	
92	Parameter value exceeds the min/max limits				X	

**Table 6.1 Alarm/Warning Code List**

(X) Dependent on parameter

A trip is the action when an alarm has appeared. The trip will coast the motor and can be reset by pressing [Reset] or make a reset by a digital input (parameter group 5-1\* [1]). The original event that caused an alarm cannot damage the frequency converter or cause dangerous conditions. A trip lock is an action when an alarm occurs, which may cause damage to frequency converter or connected parts. A trip lock situation can only be reset by a power cycling.

LED indication	
Warning	yellow
Alarm	flashing red

**Table 6.2**

The alarm words, warning words and extended status words can be read out via serial bus or optional fieldbus for diagnosis. See also *16-90 Alarm Word*, *16-92 Warning Word* and *16-94 Ext. Status Word*.



### 6.1.1 Alarm, Warning and Extended Status Word

			Par. 16-90	Par. 16-92	Par. 16-94
Bit	Hex	Dec	AlarmWord	WarningWord	ExtendedStatusWord
0	1	1	Brake check		Ramping
1	2	2	Pwr.card temp	Pwr.card temp	Auto tune running
2	4	4	Earth Fault		Start CW/CCW
3	8	8			Slow down
4	10	16	Ctrl.word TO	Ctrl.word TO	Catch up
5	20	32	Over Current	Over Current	Above Feedback High
6	40	64		Torque limit	Below Feedback Low
7	80	128	Motor Thermistor Over	Motor Thermistor Over	Output current high
8	100	256	Electronic Overload Over	Electronic Overload Over	Output current low
9	200	512	Inverter overload	Inverter overload	Above Frequency High
10	400	1024	DC under volt	DC under volt	Below Frequency Low
11	800	2048	DC over volt	DC over volt	
12	1000	4096	Short Circuit		
13	2000	8192			Braking
14	4000	16384	Mains ph. loss	Mains ph. loss	
15	8000	32768	"Auto Tune Not OK"		OVC active
16	10000	65536	Live zero error	Live zero error	AC brake
17	20000	131072	Internal fault		
18	40000	262144			
19	80000	524288	U phase loss		Above Reference High
20	100000	1048576	V phase loss		Below Reference Low
21	200000	2097152	W phase loss		Local Ref./Remote Ref.
22	400000	4194304			
23	800000	8388608	Control Voltage Fault		
24	1000000	16777216			
25	2000000	33554432		Current limit	
26	4000000	67108864	Brake resistor short-circuit		
27	8000000	134217728	Brake IGBT short-circuit		
28	10000000	268435456	M4/M5: Earth Fault (Desat)	MotorPhaseMissing	
29	20000000	536870912	Drive restored		
30	40000000	1073741824		Undefined	
31	80000000	2147483648	Mech. brake low		DatabaseBusy



Table 6.3

The alarm words, warning words and extended status words can be read out via serial bus for diagnose. See also 16-94 Ext. Status Word.

**WARNING/ALARM 2, Live zero error**

Signal on terminal 53 or 60 is less than 50% of value set in 6-10 Terminal 53 Low Voltage, 6-12 Terminal 53 Low Current and 6-22 Terminal 60 Low Current.

**WARNING/ALARM 4, Mains phase loss**

A phase is missing on the supply side, or the mains voltage imbalance is too high. This message also appears for a fault in the input rectifier on the frequency converter.

**Troubleshooting:** Check the supply voltage and supply currents to the frequency converter. The fault may be caused by mains distortions. Installing GE Line Filter may rectify this problem.

**WARNING/ALARM 7, DC overvoltage**

If the intermediate circuit voltage exceeds the limit, the frequency converter trips after a time.

**Troubleshooting**

- Connect a brake resistor
- Extend the ramp time
- Change the ramp type
- Activate the functions in 2-10 Brake Function
- Increase 14-26 Trip Delay at Inverter Fault

The fault may be caused by mains distortions. Installing GE Line Filter may rectify this problem.

**WARNING/ALARM 8, DC under voltage**

If the intermediate circuit voltage (DC link) drops below the under voltage limit, the frequency converter checks if a 24 V DC backup supply is connected. If no 24 V DC backup supply is connected, the frequency converter trips after a fixed time delay. The time delay varies with unit size.

**Troubleshooting**

Check that the supply voltage matches the frequency converter voltage.

Perform input voltage test.

Perform soft charge circuit test.

**WARNING/ALARM 9, Inverter overload**

The frequency converter is about to cut out because of an overload (too high current for too long). The counter for electronic, thermal inverter protection issues a warning at 98% and trips at 100%, while giving an alarm. The frequency converter *cannot* be reset until the counter is below 90%.

The fault is that the frequency converter has run with more than 100% overload for too long.

**Troubleshooting**

Compare the output current shown on the keypad with the frequency converter rated current.

Compare the output current shown on the keypad with measured motor current.

Display the Thermal Drive Load on the keypad and monitor the value. When running above the frequency converter continuous current rating, the counter increases. When running below the frequency converter continuous current rating, the counter decreases.

**WARNING/ALARM 10, Motor overload temperature**

According to the electronic thermal protection, the motor is too hot. Select whether the frequency converter gives a warning or an alarm when the counter reaches 100% in *1-90 Motor Thermal Protection*. The fault occurs when the motor is overloaded by more than 100% for too long.

**Troubleshooting**

Check for motor overheating.

Check if the motor is mechanically overloaded

Check that the motor current set in *1-24 Motor Current* is correct.

Ensure that Motor data in parameters 1-20 through 1-25 are set correctly.

Running Auto tune in 1-29 Auto Tune. The inverter peak current limit (approx. 200% of the rated current) is exceeded. The warning will last approx. 8-12 s, then the frequency converter trips and issues an alarm. Turn off the frequency converter and check if the motor shaft can be turned and if the motor size matches the

frequency converter. If extended mechanical brake control is selected, trip can be reset externally. may tune the frequency converter to the motor more accurately and reduce thermal loading.

**WARNING/ALARM 11, Motor thermistor over temp**

The thermistor might be disconnected. Select whether the frequency converter gives a warning or an alarm in *1-90 Motor Thermal Protection*.

**Troubleshooting**

Check for motor overheating.

Check if the motor is mechanically overloaded.

**WARNING/ALARM 13, Over current**

The inverter peak current limit (approx. 200% of the rated current) is exceeded. The warning will last approx. 8-12 s, then the frequency converter trips and issues an alarm. Turn off the frequency converter and check if the motor shaft can be turned and if the motor size matches the frequency converter. If extended mechanical brake control is selected, trip can be reset externally.

**Troubleshooting:**

Remove power and check if the motor shaft can be turned.

Check that the motor size matches the frequency converter.

Check parameters 1-20 through 1-25. for correct motor data.

**ALARM 14, Earth (ground) fault**

There is current from the output phases to earth, either in the cable between the frequency converter and the motor or in the motor itself.

**Troubleshooting:**

Remove power to the frequency converter and repair the earth fault.

Check for earth faults in the motor by measuring the resistance to ground of the motor leads and the motor with a megohmmeter.

**ALARM 16, Short circuit**

There is short-circuiting in the motor or motor wiring.

Remove power to the frequency converter and repair the short circuit.

**WARNING/ALARM 17, Control word timeout**

There is no communication to the frequency converter. The warning is only active when *8-04 Control Word Timeout Function* is NOT set to OFF.

If *8-04 Control Word Timeout Function* is set to *Stop and Trip*, a warning appears and the frequency converter ramps down until it trips, while giving an alarm. *8-03 Control Timeout Time* could possibly be increased.

**Troubleshooting:**

Check connections on the serial communication cable.

Increase *8-03 Control Word Timeout Time*

Check the operation of the communication equipment.

Verify a proper installation based on EMC requirements.

**ALARM 29, Heatsink temp**

The maximum temperature of the heatsink has been exceeded. The temperature fault will not reset until the temperature falls below a defined heatsink temperature. The trip and reset points are different based on the frequency converter power size.

**Troubleshooting**

Check for the following conditions.

Ambient temperature too high.

Motor cable too long.

Incorrect airflow clearance above and below the frequency converter.

Blocked airflow around the frequency converter.

Damaged heatsink fan.

Dirty heatsink.

**ALARM 30, Motor phase U missing**

Motor phase U between the frequency converter and the motor is missing.

Remove power from the frequency converter and check motor phase U.

**ALARM 31, Motor phase V missing**

Motor phase V between the frequency converter and the motor is missing.

Remove power from the frequency converter and check motor phase V.

**ALARM 32, Motor phase W missing**

Motor phase W between the frequency converter and the motor is missing.

Remove power from the frequency converter and check motor phase W.

**ALARM 38, Internal fault****Troubleshooting**

Cycle power

Check that the option is properly installed

Check for loose or missing wiring

It may be necessary to contact the local GE supplier or service department. Note the code number for further troubleshooting directions.

**WARNING 47, 24 V supply low**

The 24 V DC is measured on the control card. The external 24 V DC backup power supply may be overloaded, otherwise contact the GE supplier.

**ALARM 51, Auto tune check  $U_{nom}$  and  $I_{nom}$** 

The settings for motor voltage, motor current, and motor power are wrong. Check the settings in parameters 1-20 to 1-25.

**ALARM 55, Auto Tune parameter out of range**

The parameter values of the motor are outside of the acceptable range. Auto tune does not run.

**ALARM 63, Mechanical brake low**

The actual motor current has not exceeded the "release brake" current within the "Start delay" time window.

**ALARM 80, Drive restored to default value**

Parameter settings are restored to factory settings after a manual reset. Reset the unit to clear the alarm.

**ALARM 84, The connection between drive and Keypad is lost**

Try to reassemble the keypad gently.

**ALARM 85, Button disabled**

See parameter group *0-4\* Keypad*

**ALARM 86, Copy fail**

An error occurred while copying from frequency converter to keypad or vice versa.

**ALARM 87, Keypad data invalid**

Occurs when copying from keypad if the keypad contains erroneous data - or if no data was uploaded to the keypad.

**ALARM 88, Keypad data not compatible**

Occurs when copying from keypad if data are moved between frequency converters with major differences in software versions.

**WARNING 89, Parameter read only**

Occurs when trying to write to a read-only parameter.

**ALARM 90, Parameter database busy**

Keypad and RS-485 connection are trying to update parameters simultaneously.

**ALARM 91, Parameter value is not valid in this mode**

Occurs when trying to write an illegal value to a parameter.

**ALARM 92, Parameter value exceeds the min/max limits**

Occurs when trying to set a value outside the range. Parameter can only be changed when the motor is stopped. Err. A wrong password was entered, occurs when using a wrong password for changing a password-protected parameter.



## Index

<b>A</b>	
Abbreviations And Standards.....	6
Active Set-up.....	7, 43, 27, 10, 12, 49, 54
Alarm, Warning And Extended Status Word.....	65
Alarm/Warning Code List.....	64
Alarms And Warnings.....	63
Analog In/Out.....	58
<b>B</b>	
<b>Brake</b>	
Resistor.....	18, 28, 56
Resistor (ohm).....	49
Brakes.....	56
<b>C</b>	
Comm. And Options.....	59
Controllers.....	58
Conversion Index.....	53
Current Rating.....	66
<b>D</b>	
Data Readouts.....	62
DC-brake.....	16, 18, 27
DC-Brake.....	49
Digital In/Out.....	57
Display.....	7
Disposal Instruction.....	4
<b>Drive</b>	
Identification.....	45, 46
Information.....	61
<b>E</b>	
Earth Leakage Current.....	3, 4
Edit Set-up.....	7, 10, 11, 12, 49, 54
Electronic Waste.....	4
EMC.....	67
<b>H</b>	
Hand Mode.....	33, 10, 13, 29, 55
<b>I</b>	
Indicator Lights.....	8
Isolated Mains Source.....	4
IT Mains.....	4
<b>L</b>	
Leakage Current.....	4
Limits/Warnings.....	57
<b>Load</b>	
Compensation.....	15, 49, 55
Compensations.....	13
Load/Motor.....	55
<b>M</b>	
Main Menu.....	8, 9
Maximum Reference.....	20
Minimum Reference.....	20
<b>Motor</b>	
Current.....	67, 14
Data.....	66
Direction.....	8
Frequency.....	14
Nominal Speed.....	14
Overload Protection.....	4
Phase.....	47, 25, 49, 57
Power.....	67, 13
Status.....	47
Temperature.....	17, 18, 49
Voltage.....	14
<b>N</b>	
Navigation Keys.....	8
Not Changeable During Operation.....	11
<b>O</b>	
Operation Keys.....	8
Operation/Display.....	54
Output Current.....	66
Over-voltage Control.....	19, 49, 56
<b>P</b>	
Parameter Number.....	7
<b>Q</b>	
Quick Menu.....	8
<b>R</b>	
Rated Magnetizing Current.....	14
Readout Mode.....	8
Reference/Ramps.....	56
Reset.....	66, 67
Residual Current Device.....	4
<b>S</b>	
Serial Communication.....	8, 23, 29, 36, 37, 38, 47, 48



---

**Index** **AF-60 LP™ Micro Drive Programming Guide**

---

**Set-up Number**..... 7  
**Short Circuit**..... 66  
**Slip Compensation**..... 16, 49, 55  
**Smart Logic**..... 60  
**Special Functions**..... 44, 60  
**Status Menu**..... 8  
**Symbols**..... 6

**T**

**Thermal Load**..... 14, 47  
**Thermistor**  
    Thermistor..... 17, 66, 49  
    Resource..... 55  
**Troubleshooting**..... 63  
**Type Code String**..... 5

**U**

**Unit**..... 7

**V**

**Value**..... 7

Industrial Solutions (formerly Power Protection), a division of GE Energy, is a first class European supplier of low and medium voltage products including wiring devices, residential and industrial electrical distribution components, automation products, enclosures and switchboards. Demand for the company's products comes from wholesalers, installers, panelboard builders, contractors, OEMs and utilities worldwide.

  
[www.ge.com/ex/industrialsolutions](http://www.ge.com/ex/industrialsolutions)

**Belgium**

GE Industrial Belgium  
Nieuwevaart 51  
B-9000 Gent  
Tel. +32 (0)9 265 21 11

**Finland**

GE Energy Industrial Solutions  
Kuortaneenkatu 2  
FI-00510 Helsinki  
Tel. +358 (0)10 394 3760

**France**

GE Energy Industrial Solutions  
Paris Nord 2  
13, rue de la Perdrix  
F-95958 Roissy CDG Cédex  
Tel. +33 (0)800 912 816

**Germany**

GE Energy Industrial Solutions  
Vor den Siebenburgen 2  
D-50676 Köln  
Tel. +49 (0)221 16539 - 0

**Hungary**

GE Hungary Kft.  
Váci ut 81-83.  
H-1139 Budapest  
Tel. +36 1 447 6050

**Italy**

GE Energy Industrial Solutions  
Centro Direzionale Colleoni  
Via Paracelso 16  
Palazzo Andromeda B1  
I-20041 Agrate Brianza (MB)  
Tel. +39 2 61 773 1

**Netherlands**

GE Energy Industrial Solutions  
Parallelweg 10  
NI-7482 CA Haaksbergen  
Tel. +31 (0)53 573 03 03

**Poland**

GE Power Controls  
Ul. Odrowaza 15  
03-310 Warszawa  
Tel. +48 22 519 76 00

**Portugal**

GE Energy Industrial Solutions  
Rua Camilo Castelo Branco, 805  
Apartado 2770  
4401-601 Vila Nova de Gaia  
Tel. +351 22 374 60 00

**Russia**

GE Energy Industrial Solutions  
27/8, Elektrozavodskaya street  
Moscow, 107023  
Tel. +7 495 937 11 11

**South Africa**

GE Energy Industrial Solutions  
Unit 4, 130 Gazelle Avenue  
Corporate Park Midrand 1685  
P.O. Box 76672 Wendywood 2144  
Tel. +27 11 238 3000

**Spain**

GE Energy Industrial Solutions  
P.I. Clot del Tufau, s/n  
E-08295 Sant Vicenç de Castellet  
Tel. +34 900 993 625

**United Arab Emirates**

GE Energy Industrial Solutions  
1101, City Tower 2, Sheikh Zayed Road  
P.O. Box 11549, Dubai  
Tel. +971 43131202

**United Kingdom**

GE Energy Industrial Solutions  
Houghton Centre  
Salthouse Road  
Blackmills  
Northampton  
NN4 7EX  
Tel. +44 (0)800 587 1239

**United States of America**

GE Energy Industrial Solutions  
41 Woodford Avenue  
Plainville, CT 06062



GE imagination at work

132R0041



\* M G Q 2 J 2 Q 2 \*