



Quick Guide

VLT[®] AutomationDrive FC 360



Contents

1 Introduction	3
1.1 Purpose of the Manual	3
1.2 Additional Resources	3
1.3 Document and Software Version	3
1.4 Approvals and Certifications	3
1.5 Disposal	3
1.6 Product Overview	3
1.6.1 Enclosure Types and Power Ratings	4
1.6.2 Exploded Views	5
2 Safety	7
2.1 Safety Symbols	7
2.2 Qualified Personnel	7
2.3 Safety Precautions	7
3 Quick Start	9
3.1 Identification and Variants	9
3.2 Hand On/Auto On Mode	10
3.3 Application Selections	10
3.4 Jumper Terminal 12 and 27	14
3.5 Automatic Motor Adaptation (AMA)	14
4 Installation	15
4.1 Mechanical Installation	15
4.2 Electrical Installation	16
4.2.1 General Requirements	18
4.2.2 Grounding Requirements	18
4.2.2.1 Leakage Current (>3.5 mA)	18
4.2.3 Mains, Motor, and Ground Connections	19
4.2.4 Control Wiring	20
4.3 Serial Communication	22
5 Local Control Panel and Programming	23
5.1 Local Control Panel (LCP)	23
5.1.1 Introduction	23
5.1.2 Numerical Local Control Panel LCP 21	23
5.1.3 Local Control Panel LCP 102	24
5.1.4 The Right-key Function on LCP 21	25
5.2 Main Menu	25
5.3 Quick Menu	27

5.4 PM Motor Setup	29
5.5 Profibus	30
5.6 Parameter List	31
6 Application Examples	37
7 Diagnostics and Troubleshooting	40
7.1 Warning and Alarm Types	40
7.2 Warning and Alarm Displays	40
7.3 Warning and Alarm Code List	41
7.4 Error Code List	43
7.5 Troubleshooting	43
8 Specifications	45
8.1 Mains Supply 3x380–480 V AC	45
8.2 General Technical Data	47
8.3 Fuses	51
8.3.1 Introduction	51
8.3.2 CE Compliance	51
8.4 Connection Tightening Torques	52
Index	53

1 Introduction

1.1 Purpose of the Manual

The quick guide provides information for safe installation and commissioning of the frequency converter.

The quick guide is intended for use by qualified personnel. Read and follow the quick guide to use the frequency converter safely and professionally, and pay particular attention to the safety instructions and general warnings. Keep this quick guide available with the frequency converter at all times.

VLT® is a registered trademark.

1.2 Additional Resources

Other resources are available to understand advanced frequency converter functions and programming.

- The *Programming Guide* provides greater detail on working with parameters.
- The *Design Guide* provides detailed capabilities and functionality to design motor control systems.
- Optional equipment is available that may change some of the procedures described. Be sure to see the instructions supplied with those options for specific requirements.

Contact the local Danfoss supplier or go to www.danfoss.com/fc360 for downloads.

1.3 Document and Software Version

The Quick Guide is regularly reviewed and updated. All suggestions for improvement are welcome.


Edition	Remarks	Software version
MG06A5xx	Replaces MG06A4xx	1.3x

1.4 Approvals and Certifications



Illustration 1.1 Approval

1.5 Disposal



Do not dispose of equipment containing electrical components together with domestic waste. Collect it separately in accordance with local and currently valid legislation.

1.6 Product Overview

A frequency converter is an electronic motor controller that converts AC mains input into a variable AC waveform output. The frequency and voltage of the output are regulated to control the motor speed or torque. The frequency converter can vary the speed of the motor in response to system feedback, such as changing temperature or pressure for controlling fan, compressor, or pump motors. The frequency converter can also regulate the motor by responding to remote commands from external controllers.


In addition, the frequency converter monitors the system and motor status, issues warnings or alarms for fault conditions, starts and stops the motor, optimises energy efficiency, and offers many more control, monitoring, and efficiency functions. Operation and monitoring functions are available as status indications to an outside control system or serial communication network.

1.6.1 Enclosure Types and Power Ratings

Enclosure type 380–480 V	J1	J2	J3	J4	J5	J6	J7
Power size [kW]	0.37–2.2	3.0–5.5	7.5	11–15	18.5–22	30–45	55–75
Dimensions [mm]							
Height A	210	272.5	272.5	317.5	410	515	550
Width B	75	90	115	133	150	233	308
Depth C (with option B)	168 (173)	168 (173)	168 (173)	245 (250)	245 (250)	241	323
Mounting holes							
a	198	260	260	297.5	390	495	521
b	60	70	90	105	120	200	270
Mounting screw	M4	M5	M5	M6	M6	M8	M8

Table 1.1 Enclosure Types, Power Ratings and Dimensions


1.6.2 Exploded Views



1308C439.10

1	NLCP (accessory)	10	2-Pole Relay 2 (0.37–7.5 kW), pluggable 3-Pole Relay 2 (11–22 kW), pluggable
2	Control cassette	11	Mains terminals
3	RFI switch (screw M3x12 only)	12	Cable strain relief (0.37–2.2 kW: accessory)
4	Removable fan assembly	13	Pluggable RS-485 terminal
5	Grounding clamp (accessory)	14	Fixed I/O terminals
6	Shielded cable grounding clamp and strain relief (accessory)	15	Fixed I/O terminals
7	Motor terminal (U V W) and brake and load sharing terminals	16	Terminal cover
8	PE ground	17	Option-B (MCB102/103 accessories)
9	3-Pole relay 1		

Illustration 1.2 Exploded View, J1-J5 (0.37–22 kW), IP20



1	J7 frequency converter	10	I/O cable clamps
2	Removable fan assembly	11	Terminal cover
3	M5 screw X4 (for fan assembly)	12	Motor terminals
4	NLCP (accessory)	13	Load sharing terminals
5	Option B (MCB 102/103 accessories)	14	Removable plugger (for load sharing terminal)
6	I/O terminals	15	Shielded cable grounding clamps
7	I/O terminals	16	Mains terminals
8	Pluggable RS-485 terminals	17	Decoupling plate (accessory)
9	Relay terminal 1&2, fixed	18	M4 screw X3 (for decoupling plate)

Illustration 1.3 Exploded View, J7 (55 kW, 75 kW), IP20

2 Safety

2.1 Safety Symbols

The following symbols are used in this document:

⚠ WARNING

Indicates a potentially hazardous situation that could result in death or serious injury.

⚠ CAUTION

Indicates a potentially hazardous situation that could result in minor or moderate injury. It can also be used to alert against unsafe practices.

NOTICE

Indicates important information, including situations that can result in damage to equipment or property.

2.2 Qualified Personnel

Correct and reliable transport, storage, installation, operation, and maintenance are required for the trouble-free and safe operation of the frequency converter. Only qualified personnel are allowed to install or operate this equipment.

Qualified personnel are defined as trained staff, who are authorised to install, commission, and maintain equipment, systems, and circuits in accordance with pertinent laws and regulations. Additionally, the personnel must be familiar with the instructions and safety measures described in this manual.

2.3 Safety Precautions

⚠ WARNING

HIGH VOLTAGE

Frequency converters contain high voltage when connected to AC mains input, DC power supply, or load sharing. Failure to perform installation, start-up, and maintenance by qualified personnel can result in death or serious injury.

- Installation, start-up, and maintenance must be performed by qualified personnel only.

⚠ WARNING

UNINTENDED START

When the frequency converter is connected to AC mains, DC power supply, or load sharing, the motor may start at any time. Unintended start during programming, service, or repair work can result in death, serious injury, or property damage. The motor can start by means of an external switch, a serial bus command, an input reference signal from the LCP or LOP, via remote operation using MCT 10 software, or after a cleared fault condition.

To prevent unintended motor start:

- Disconnect the frequency converter from mains.
- Press [Off/Reset] on the LCP before programming parameters.
- The frequency converter, motor, and any driven equipment must be fully wired and assembled when the frequency converter is connected to AC mains, DC power supply, or load sharing.

⚠ WARNING

DISCHARGE TIME

The frequency converter contains DC-link capacitors, which can remain charged even when the frequency converter is not powered. Failure to wait the specified time after power has been removed before performing service or repair work, could result in death or serious injury.

1. Stop the motor.
2. Disconnect AC mains, permanent magnet type motors, and remote DC-link power supplies, including battery back-ups, UPS, and DC-link connections to other frequency converters.
3. Wait for the capacitors to discharge fully, before performing any service or repair work. The duration of waiting time is specified in *Table 2.1*.

Voltage [V]	Minimum waiting time (minutes)	
	4	15
380–480	0.37–7.5 kW	11–75 kW
High voltage may be present even when the warning LEDs are off!		

Table 2.1 Discharge Time

⚠ WARNING**LEAKAGE CURRENT HAZARD**

Leakage currents exceed 3.5 mA. Failure to ground the frequency converter properly can result in death or serious injury.

- Ensure the correct grounding of the equipment by a certified electrical installer.

⚠ WARNING**EQUIPMENT HAZARD**

Contact with rotating shafts and electrical equipment can result in death or serious injury.

- Ensure that only trained and qualified personnel perform installation, start up, and maintenance.
- Ensure that electrical work conforms to national and local electrical codes.
- Follow the procedures in this manual.

NOTICE**HIGH ALTITUDES**

For installation at altitudes above 2000 m, contact Danfoss regarding PELV.

⚠ CAUTION**INTERNAL FAILURE HAZARD**

An internal failure in the frequency converter can result in serious injury, when the frequency converter is not properly closed.

- Ensure that all safety covers are in place and securely fastened before applying power.

NOTICE**Use on Isolated Mains**

For details about the use of the frequency converter on isolated mains, refer to section *RFI Switch* in the *Design Guide*.

Follow the recommendations regarding the installation on IT-mains. Use relevant monitoring devices for IT-mains to avoid damage.


3 Quick Start

⚠ WARNING

Improper use could result in death, serious injury, equipment, or property damage. Before installing or using the equipment, carefully read *chapter 2 Safety* and *chapter 4 Installation*.

3.1 Identification and Variants

Confirm that the equipment matches the requirements and ordering information by checking power size, voltage and overload data on the nameplate of the frequency converter.



130BC435.11

1	Type code
2	Ordering number
3	Specifications

Illustration 3.1 Nameplate 1 and 2

1-6: Product Name	
7: Overload	H: Heavy Duty Q: Normal Duty ¹⁾
8-10: Power Size	0.37–75 kW e.g. K37: 0.37 kW ²⁾ 1K1: 1.1 kW 11K: 11 kW etc.
11-12: Voltage Class	T4: 380–480 V three phases
13-15: IP Class	E20: IP20
16-17: RFI	H2: C3 Class
18: Brake chopper	X: No B: Built-in ³⁾
19: LCP	X: No
20: PCB Coating	C: 3C3
21: Mains terminals	D: Load sharing
29-30: Embedded Fieldbus	AX: No A0: Profibus AL: ProfiNet ⁴⁾

Table 3.1 Type Code: Selection of Different Features and Options

For options and accessories, refer to the section *Options and Accessories in Design Guide*.

- 1) Only 11–75 kW for normal duty variants. Profibus and ProfiNet unavailable for normal duty.
- 2) For all power sizes, see chapter 8.1.1 *Mains Supply 3x380–480 V AC*
- 3) 0.37–22 kW with built-in brake chopper. 30–75 kW with external brake chopper only.
- 4) Not available yet.

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
F	C	-	3	6	0	H				T	4	E	2	0	H	2	X	X	C	D	X	X	S	X	X	X	X	A	X	B	X
						Q											B											A	0		
																												A	L		

130BC437.10

Illustration 3.2 Type Code String

3.2 Hand On/Auto On Mode

After installation (see *chapter 4 Installation*), there are 2 simple ways to start up the frequency converter: Hand On and Auto On mode. At the first power-up, it is in Auto On mode.




Illustration 3.3 Location of Hand On, Off/Reset and Auto On Keys on the NLCP

- Press [Hand On] to provide a local start command to the frequency converter. Press [▲] and [▼] to increase and decrease speed.
- Press [Off/Reset] to stop the frequency converter.
- Press [Auto On] to control the frequency converter either via control terminals or serial communication.

CAUTION

Since the frequency converter is in Auto On mode at first power-up, the frequency converter may start the motor directly.

NOTICE

5-12 Terminal 27 Digital Input has coast inverse as default setting. Connect terminals 12 and 27 to test Hand On/Auto On running.

For LCP operation, see *chapter 5 Local Control Panel and Programming*.

3.3 Application Selections

Use the selections for quick application set-up of the most common applications by setting 0-16 Application Selection. When necessary, the selections can be modified for individual needs. All selections are for Auto On mode.

NOTICE

When an application is selected, relevant parameters are automatically set. Customer specific configuration of all parameters based on specific requirements is still possible.

CAUTION

If any of the applications below are selected, relay 1 is set to [Running] and relay 2 is set to [Alarm]

Application																																													
Pumps, fans, compressors																																													
Description																																													
For applications where a value (e.g. pressure, temperature) must be kept at a desired level by sensor feedback																																													
<table border="1"> <tr> <td>FC 360</td> <td></td> </tr> <tr> <td>+24V</td> <td>12</td> </tr> <tr> <td>DI1</td> <td>18</td> </tr> <tr> <td>DI2</td> <td>19</td> </tr> <tr> <td>DI3</td> <td>27</td> </tr> <tr> <td>DI4</td> <td>29</td> </tr> <tr> <td>DI5</td> <td>32</td> </tr> <tr> <td>DI6</td> <td>33</td> </tr> <tr> <td>DI7</td> <td>31</td> </tr> <tr> <td>COM</td> <td>20</td> </tr> <tr> <td>+10V</td> <td>50</td> </tr> <tr> <td>AI1</td> <td>53</td> </tr> <tr> <td>AI2</td> <td>54</td> </tr> <tr> <td>COM</td> <td>55</td> </tr> <tr> <td>AO1</td> <td>45</td> </tr> <tr> <td>AO2</td> <td>42</td> </tr> <tr> <td></td> <td>1</td> </tr> <tr> <td>R1</td> <td>2</td> </tr> <tr> <td></td> <td>3</td> </tr> <tr> <td></td> <td>4</td> </tr> <tr> <td>R2</td> <td>5</td> </tr> <tr> <td></td> <td>6</td> </tr> </table>	FC 360		+24V	12	DI1	18	DI2	19	DI3	27	DI4	29	DI5	32	DI6	33	DI7	31	COM	20	+10V	50	AI1	53	AI2	54	COM	55	AO1	45	AO2	42		1	R1	2		3		4	R2	5		6	
FC 360																																													
+24V	12																																												
DI1	18																																												
DI2	19																																												
DI3	27																																												
DI4	29																																												
DI5	32																																												
DI6	33																																												
DI7	31																																												
COM	20																																												
+10V	50																																												
AI1	53																																												
AI2	54																																												
COM	55																																												
AO1	45																																												
AO2	42																																												
	1																																												
R1	2																																												
	3																																												
	4																																												
R2	5																																												
	6																																												
Parameter settings																																													
Parameter	Option/value																																												
1-00 Configuration Mode	[3] Process Closed Loop																																												
1-03 Torque Characteristics	[1] Variable Torque																																												
3-00 Reference Range	[0] Min- Max																																												
3-15 Reference 1 Source	[0] No Function																																												
4-12 Motor Speed Low Limit [Hz]	30.0 Hz																																												
4-14 Motor Speed High Limit [Hz]	50.0 Hz																																												
5-10 Terminal 18 Digital Input	[8] Start																																												

5-12 Terminal 27 Digital Input	[2] Coast Inverse
5-14 Terminal 32 Digital Input	[14] Jog
5-40 Function Relay (Relay 1 Selection)	[5] Running
5-40 Function Relay (Relay 2 Selection)	[9] Alarm
6-22 Terminal 54 Low Current	4.0 mA
6-23 Terminal 54 High Current	20.0 mA
6-29 Terminal 54 mode	[0] Current Mode
6-70 Terminal 45 Mode	[0] 0–20 mA
6-71 Terminal 45 Analog Output	[100] Output frequency
6-90 Terminal 42 Mode	[0] 0–20 mA
6-91 Terminal 42 Analog Output	[103] Motor Current
7-20 Process CL Feedback 1 Resource	[2] Analog input 54

Table 3.2 Process Closed Loop

Application
Local/remote

Description
For applications where the speed reference can be switched between local potentiometer and remote current signal

Parameter settings	Set-up 1	Set-up 2
0-10 Active Set-up	[9] Multi Set-up	[9] Multi Set-up
0-12 Link Setups	[20] Linked	[20] Linked
1-00 Configuration Mode	[0] Speed Open Loop	[0] Speed Open Loop
3-00 Reference Range	[0] Min–Max	[0] Min–Max
3-15 Reference 1 Source	[1] AI 53	[2] AI 54
3-16 Reference 2 Source		
4-12 Motor Speed Low Limit [Hz]	25.0 Hz	25.0 Hz

4-14 Motor Speed High Limit [Hz]	50.0 Hz	50.0 Hz
5-10 (DI 18 Selection)0-10 Active Set-up	[8] Start	[8] Start
5-10 Terminal 18 Digital Input	[2] Coast Inverse	[2] Coast Inverse
5-14 Terminal 32 Digital Input	[23] Set-up select	[23] Set-up select
5-40 Function Relay (Relay 1 Selection)	[5] Running	[5] Running
5-40 Function Relay (Relay 2 Selection)	[9] Alarm	[9] Alarm
6-10 Terminal 53 Low Voltage	0.07 V	
6-11 Terminal 53 High Voltage	10 V	
6-19 Terminal 53 mode	[1] Voltage Mode	
6-22 Terminal 54 Low Current		4.0 mA
6-23 Terminal 54 High Current		20.0 mA
6-29 Terminal 54 mode		[0] Current Mode
6-70 Terminal 45 Mode	[0] 0–20 mA	[0] 0–20 mA
6-71 Terminal 45 Analog Output	[100] Output frequency	[100] Output frequency
6-90 Terminal 42 Mode	[0] 0–20 mA	[0] 0–20 mA
6-91 Terminal 42 Analog Output	[103] Motor Current	[103] Motor Current

Table 3.3 Local/Remote

Application	
Conveyors, extruders	
Description	
For running at a stable speed by a voltage reference signal.	
Parameter settings	
Parameter	Option/value
1-00 Configuration Mode	[0] Speed Open Loop
3-00 Reference Range	[0] Min-Max
3-15 Reference 1 Source	[1] AI 53
4-12 Motor Speed Low Limit [Hz]	25.0 Hz
4-14 Motor Speed High Limit [Hz]	50.0 Hz
5-10 Terminal 18 Digital Input	[8] Start
5-12 Terminal 27 Digital Input	[2] Coast Inverse
5-40 Function Relay (Relay 1 Selection)	[5] Running
5-40 Function Relay (Relay 2 Selection)	[9] Alarm
6-10 Terminal 53 Low Voltage	0.07 V
6-11 Terminal 53 High Voltage	10 V
6-19 Terminal 53 mode	[1] Voltage Mode
6-70 Terminal 45 Mode	[0] 0–20 mA
6-71 Terminal 45 Analog Output	[100] Output frequency
6-90 Terminal 42 Mode	[0] 0–20 mA
6-91 Terminal 42 Analog Output	[103] Motor Current

Table 3.4 Speed Open Loop

Application	
Machine tools, texturizers	
Description	
For precise speed applications with 24 V encoder feedback	
Parameter settings	
Parameter	Option/value
1-00 Configuration Mode	[1] Speed Close Loop
3-00 Reference Range	[0] Min-Max
3-15 Reference 1 Source	[1] AI 53
3-16 Reference 2 Source	[11] Local Bus Ref
4-12 Motor Speed Low Limit [Hz]	20.0 Hz
4-14 Motor Speed High Limit [Hz]	50.0 Hz
5-10 Terminal 18 Digital Input	[8] Start
5-12 Terminal 27 Digital Input	[2] Coast Inverse
5-14 Terminal 32 Digital Input	[82] Encoder input B
5-15 Terminal 33 Digital Input	[81] Encoder input A
5-40 Function Relay (Relay 1 Selection)	[5] Running
5-40 Function Relay (Relay 2 Selection)	[9] Alarm
6-10 Terminal 53 Low Voltage	0.07 V
6-11 Terminal 53 High Voltage	10 V
6-19 Terminal 53 mode	[1] Voltage Mode
6-70 Terminal 45 Mode	[0] 0–20 mA
6-71 Terminal 45 Analog Output	[100] Output frequency
6-90 Terminal 42 Mode	[0] 0–20 mA
6-91 Terminal 42 Analog Output	[103] Motor Current
7-00 Speed PID Feedback Source	[1] 24 V encoder

Table 3.5 Speed Close Loop

Application	
Industrial washing machines, conveyors	
Description	
For applications with 8 different speeds by digital input. By using another digital input, 16 speeds are possible.	
Parameter settings	
Parameter	Option/value
1-00 Configuration Mode	[0] Speed Open Loop
3-00 Reference Range	[0] Min-Max
3-15 Reference 1 Source	[0] No Function
4-14 Motor Speed High Limit [Hz]	50.0 Hz
5-10 Terminal 18 Digital Input	[8] Start
5-12 Terminal 27 Digital Input	[2] Coast Inverse
5-13 Terminal 29 Digital Input	[16] Preset ref bit 0
5-14 Terminal 32 Digital Input	[17] Preset ref bit 1
5-15 Terminal 33 Digital Input	[18] Preset ref bit 2
6-70 Terminal 45 Mode	[0] 0-20 mA
6-71 Terminal 45 Analog Output	[100] Output frequency
6-90 Terminal 42 Mode	[0] 0-20 mA
6-91 Terminal 42 Analog Output	[103] Motor Current

Table 3.6 Multi-speed

Application	
One Gear Drive (OGD)	
Description	
For applications that use OGD. For example, conveyors in food and beverage industries.	
Parameter settings	
Parameter	Option/value
1-00 Configuration Mode	[0] Open Loop
1-01 Motor Control Principle	[1] VVC+
1-08 Motor Control Bandwidth	high
1-10 Motor Construction	[1] PM, non-salient SPM
1-14 Damping Gain	120
1-15 Low Speed Filter Time Const.	0.175
1-16 High Speed Filter Time Const.	0.175
1-17 Voltage filter time const.	0.035
1-24 Motor Current	7.2
1-25 Motor Nominal Speed	3000
1-26 Motor Cont. Rated Torque	12.6
1-29 Automatic Motor Adaptation (AMA)	[0] Off
1-30 Stator Resistance (Rs)	0.5
1-37 d-axis Inductance (Ld)	5
1-39 Motor Poles	10
1-40 Back EMF at 1000 RPM	120
1-42 Motor Cable Length	50 m
1-66 Min. Current at Low Speed	50
1-73 Flying Start	[2] Enable always
2-06 Parking Current	80
2-07 Parking Time	0.5
2-10 Brake Function	[0] Off
3-03 Maximum Reference	250 Hz
4-14 Motor Speed High Limit [Hz]	250 Hz

4-16 Torque Limit Motor Mode	160
4-18 Current Limit	160
5-10 Terminal 18 Digital Input	[8] Start
5-11 Terminal 19 Digital Input	[0] No operation
5-12 Terminal 27 Digital Input	[2] Coast inverse
5-13 Terminal 29 Digital Input	[0] No operation
5-14 Terminal 32 Digital Input	[0] No operation
5-15 Terminal 33 Digital Input	[0] No operation
5-16 Terminal 31 Digital Input	[0] No operation
6-10 Terminal 53 Low Voltage	4.0 mA
6-11 Terminal 53 High Voltage	20.0 mA
6-14 Terminal 53 Low Ref./Feedb. Value	0
6-15 Terminal 53 High Ref./Feedb. Value	250
6-19 Terminal 53 mode	[0] Current Mode
14-01 Switching Frequency	10.0 kHz
14-07 Dead Time Compensation Level	65
14-64 Dead Time Compensation Zero Current Level	[0] Disabled
14-65 Speed Derate Dead Time Compensation	250
14-51 DC-Link Voltage Compensation	[0] Off
30-20 High Starting Torque Time [s]	0
30-21 High Starting Torque Current [%]	100
30-22 Locked Rotor Protection	[0] Off
30-23 Locked Rotor Detection Time [s]	1

Table 3.7 One Gear Drive (OGD)

NOTICE

For further examples, refer to *chapter 6 Application Examples*.

3.4 Jumper Terminal 12 and 27

When using factory default programming values, jumper wire may be required between terminal 12 and terminal 27 for the frequency converter to operate.

- Digital input terminal 27 is designed to receive a 24 V DC external interlock command. In many applications, the user wires an external interlock device to terminal 27.
- When no interlock device is used, wire a jumper between control terminal 12 and terminal 27. This provides internal 24 V signal on terminal 27.
- No signal present prevents the unit from operating.

3.5 Automatic Motor Adaptation (AMA)

Automatic motor adaptation (AMA)

It is highly recommended to run AMA because it measures the electrical characteristics of the motor to optimise compatibility between the frequency converter and the motor under VVC⁺ mode.

- The frequency converter builds a mathematical model of the motor for regulating output motor current, thus enhancing motor performance.
- Some motors may be unable to run the complete version of the test. In that case, select *Enable reduced AMA*.
- If warnings or alarms occur, see *chapter 7.3 Warning and Alarm Code List*.
- Run this procedure on a cold motor for best results.

To run AMA using the numeric LCP (NLCP)

1. By default parameter setting, connect terminals 12 and 27 before running AMA.
2. Enter the main menu.
3. Go to parameter group 1-** *Load and Motor*.
4. Press [OK].
5. Set motor parameters using nameplate data for parameter group 1-2* *Motor Data*.
6. Set motor cable length in 1-42 *Motor Cable Length*.
7. Go to 1-29 *Automatic Motor Adaptation (AMA)*.
8. Press [OK].
9. Select [1] *Enable complete AMA*.
10. Press [OK].
11. The test runs automatically and indicates when it is complete.

Depending on the power size, the AMA takes 3 to 10 minutes to complete.

NOTICE

AMA function in FC 360 does not cause the motor to run and it does not harm the motor.

4 Installation

4.1 Mechanical Installation

Select the best possible operation site by considering:

- Ambient operating temperature.
- Installation method.
- Cooling.
- Position of the frequency converter.
- Cable routing.
- Power source supplying correct voltage and necessary current.
- Motor current rating within the maximum current from the frequency converter.
- Correct rating of external fuses and circuit breakers.

Cooling and Mounting:

- Top and bottom clearance for air cooling must be provided, see *Table 4.1* for clearance requirements
- Consider derating for temperatures starting from 45 °C and elevation 1000 m above sea level. See *Design Guide* for details on derating.

Enclosure	J1-J5	J6/J7
Clearance above and below the unit [mm]	100	200

Table 4.1 Minimum Airflow Clearance Requirements

- Mount the unit vertically
- IP20 units allow side-by-side installation
- Improper mounting can result in overheating and reduced performance
- Use the slotted mounting holes on the unit for wall mounting, when provided
- See *chapter 8.4 Connection Tightening Torques* for proper tightening specifications.

4.2 Electrical Installation

This section describes how to wire the frequency converter.

4





Illustration 4.1 Basic Wiring Schematic Drawing

A=Analog, D=Digital

- 1) Built-in brake chopper available from 0.37–22 kW
- 2) Relay 2 is 2-pole for J1–J3 and 3-pole for J4–J7. Relay 2 of J4–J7 with terminals 4, 5 and 6 has the same NO/NC logic as Relay 1. Relay are pluggable in J1–J5, and fixed in J6–J7.
- 3) Dual DC choke in 30–75 kW (J6–J7)
- 4) Switch S801 (bus terminal) can be used to enable termination on the RS-485 port (terminals 68 and 69).
- 5) No BR for 30–75 kW (J6–J7)



1	PLC	6	Minimum 200 mm (7.9 inch) between control cables, motor and mains
2	Frequency converter	7	Motor, 3-phase and PE
3	Output contactor (generally not recommended)	8	Mains, 3-phase and reinforced PE
4	Grounding rail (PE)	9	Control wiring
5	Cable shielding (stripped)	10	Equalising minimum 16 mm ² (0.025 inch)

Illustration 4.2 Typical Electrical Connection

4.2.1 General Requirements

⚠ WARNING

EQUIPMENT HAZARD!

Rotating shafts and electrical equipment can be hazardous. Extreme care should be taken to protect against electrical hazards when applying power to the unit. All electrical work must conform to national and local electrical codes and installation, start up, and maintenance should only be performed by trained and qualified personnel. Failure to follow these guidelines could result in death or serious injury.

CAUTION

WIRING ISOLATION!

Run input power, motor wiring and control wiring in 3 separate metallic conduits or use separated shielded cable for high frequency noise isolation. Failure to isolate power, motor and control wiring could result in less than optimum frequency converter and associated equipment performance.

Run motor cables from multiple frequency converters separately. Induced voltage from output motor cables run together can charge equipment capacitors even with the equipment turned off and locked out.

- An electronically activated function within the frequency converter provides overload protection for the motor. The overload provides Class 20 motor protection. See *chapter 7.1 Warning and Alarm Types* for details on the trip function.

Wire Type and Ratings

- All wiring must comply with local and national regulations regarding cross-section and ambient temperature requirements.
- Danfoss recommends that all power connections be made with a minimum 75 °C rated copper wire.
- See *chapter 8 Specifications* for recommended wire sizes.

4.2.2 Grounding Requirements

⚠ WARNING

GROUNDING HAZARD!

For operator safety, it is important to ground the frequency converter properly by a certified electrical installer in accordance with national and local electrical codes as well as instructions contained within this document. Ground currents are higher than 3.5 mA. Failure to ground the frequency converter properly could result in death or serious injury.

- Proper protective grounding for equipment with ground currents higher than 3.5 mA must be established, see *chapter 4.2.2.1 Leakage Current (>3.5 mA)*.
- A dedicated ground wire is required for input power, motor power, and control wiring.
- Use the clamps provided with the equipment for proper ground connections.
- Do not ground one frequency converter to another in a “daisy chain” fashion (see *Illustration 4.3*).
- Keep the ground wire connections as short as possible.
- Using high-strand wire to reduce electrical noise is recommended.
- Follow motor manufacturer wiring requirements.




Illustration 4.3 Grounding Principle

4.2.2.1 Leakage Current (>3.5 mA)

Follow national and local codes regarding protective earthing of equipment with a leakage current > 3.5 mA. The earth leakage current depends on various system configurations including RFI filtering, screened motor cables, and frequency converter power.

EN/IEC61800-5-1 (Power Drive System Product Standard) requires special care if the leakage current exceeds 3.5 mA. Grounding must be reinforced in one of the following ways:

- Ground wire of at least 10 mm² (copper wire)
- 2 separate ground wires both complying with the dimensioning rules

See EN 60364-5-54 § 543.7 for further information.

Using RCDs

Where residual current devices (RCDs), also known as ground leakage circuit breakers (ELCBs), are used, comply with the following:

- Use RCDs of type B only, which are capable of detecting AC and DC currents
- Use RCDs with an inrush delay to prevent faults due to transient earth currents
- Dimension RCDs according to the system configuration and environmental considerations

4.2.3 Mains, Motor, and Ground Connections

⚠ WARNING

INDUCED VOLTAGE!

Run output motor cables from multiple frequency converters separately. Induced voltage from output motor cables run together can charge equipment capacitors even when the equipment is turned off and locked out. Failure to run output motor cables separately could result in death or serious injury.

Grounding clamps are provided for motor wiring (see *Illustration 4.4*).

- Do not install power factor correction capacitors between the frequency converter and the motor
- Do not wire a starting or pole-changing device between the frequency converter and the motor
- Follow motor manufacturer wiring requirements
- All frequency converters may be used with an isolated input source as well as with ground reference power lines. When supplied from an isolated mains source (IT mains or floating delta) or TT/TN-S mains with a grounded leg (grounded delta), set *14-50 RFI Filter* to OFF (enclosure types J6–J7) or remove the RFI screw (enclosure types J1–J5). When off, the internal RFI filter capacitors are isolated to avoid damage to the intermediate circuit and to reduce earth capacity currents in accordance with IEC 61800-3.
- Do not install a switch between the frequency converter and the motor in IT mains.




Illustration 4.4 Mains, Motor and Ground Connections for Enclosure Type J1-J5




Illustration 4.5 Mains, Motor, and Ground Connections for Enclosure Type J7

Illustration 4.4 displays mains input, motor, and grounding for enclosure types J1–J5. *Illustration 4.5* displays mains

input, motor, and grounding for enclosure type J7. Actual configurations vary with unit types and optional equipment.

4.2.4 Control Wiring

Access

- Remove the cover plate with a screwdriver. See *Illustration 4.6*.




Illustration 4.6 Control Wiring Access for J1-J7 Enclosures

Control Terminal Types

Illustration 4.7 shows the frequency converter control terminals. Terminal functions and default settings are summarised in *Table 4.2*.




Illustration 4.7 Control Terminal Locations

See *chapter 8.2 General Technical Data* for terminal ratings details.

Terminal	Parameter	Default setting	Description
Digital I/O, Pulse I/O, Encoder			
12	-	+24 V DC	24 V DC supply voltage. Maximum output current is 100 mA for all 24 V loads.
18	5-10	[8] Start	Digital inputs.
19	5-11	[10] Reversing	
31	5-16	[0] No operation	Digital input
32	5-14	[0] No operation	Digital input, 24 V encoder. Terminal 33 can be used for pulse input.
33	5-15	[0] No operation	
27	5-12 5-30	DI [2] Coast inverse DO [0] No operation	Selectable for either digital input, digital output or pulse output. Default setting is digital input.
29	5-13 5-31	DI [14] Jog DO [0] No operation	Terminal 29 can be used for pulse input.
20	-		Common for digital inputs and 0 V potential for 24 V supply.
Analog inputs/outputs			
42	6-91	[0] No operation	Programmable analog output. The analog signal is 0-20 mA or 4-20 mA at a maximum of 500 Ω. Can also be configured as digital outputs
45	6-71	[0] No operation	
50	-	+10 V DC	10 V DC analog supply voltage. 15 mA maximum commonly used for potentiometer or thermistor.
53	6-1*	Reference	Analog input. Selectable for voltage or current.
54	6-2*	Feedback	
55	-		Common for analog input

Terminal	Parameter	Default setting	Description
Serial communication			
61	-		Integrated RC-Filter for cable screen. ONLY for connecting the screen when experiencing EMC problems.
68 (+)	8-3*		RS-485 interface. A control card switch is provided for termination resistance.
69 (-)	8-3*		
Relays			
01, 02, 03	5-40 [0]	[0] No operation	Form C relay output. These relays are in various locations depending upon the frequency converter configuration and size. Usable for AC or DC voltage and resistive or inductive loads.
04, 05, 06	5-40 [1]	[0] No operation	RO2 in J1-J3 enclosure is 2-pole, only terminals 04 and 05 are available

Table 4.2 Terminal Descriptions

Control terminal functions


Frequency converter functions are commanded by receiving control input signals.

- Programme each terminal for the function it supports in the parameters associated with that terminal. See Table 4.2 for terminals and associated parameters.
- Confirm that the control terminal is programmed for the correct function. See chapter 5 Local Control Panel and Programming for details on accessing parameters and programming.
- The default terminal programming initiates frequency converter functioning in a typical operational mode.

Using screened control cables

The preferred method in most cases is to secure control and serial communication cables with screening clamps provided at both ends to ensure best possible high frequency cable contact.

If the ground potential between the frequency converter and the PLC is different, electric noise may occur that disturbs the entire system. Solve this problem by fitting an equalising cable as close as possible to the control cable. Minimum cable cross section: 16 mm².



1	Minimum 16 mm ²
2	Equalising cable

Illustration 4.8 Screening Clamps at Both Ends

50/60 Hz ground loops

With very long control cables, ground loops may occur. To eliminate ground loops, connect one end of the screen-to-ground with a 100 nF capacitor (keeping leads short).





Illustration 4.9 Connection with a 100 nF Capacitor

Avoid EMC noise on serial communication


This terminal is connected to ground via an internal RC link. Use twisted-pair cables to reduce interference between conductors. The recommended method is shown in Illustration 4.10.



1	Minimum 16 mm ²
2	Equalising cable

Illustration 4.10 Twisted-pair Cables

Alternatively, the connection to terminal 61 can be omitted.



1	Minimum 16 mm ²
2	Equalising cable

Illustration 4.11 Twisted-pair Cables without Terminal 61

4.3 Serial Communication

Connect RS-485 serial communication wiring to terminals (+)68 and (-)69.

- Screened serial communication cable is recommended
- See *chapter 4.2.2 Grounding Requirements* for proper grounding




Illustration 4.12 Serial Communication Wiring Diagram

For basic serial communication set-up, select the following:

1. Protocol type in *8-30 Protocol*.
 2. Frequency converter address in *8-31 Address*.
 3. Baud rate in *8-32 Baud Rate*.
- Two communication protocols are internal to the frequency converter. Follow motor manufacturer wiring requirements.
 - Danfoss FC
 - Modbus RTU
 - Functions can be programmed remotely using the protocol software and RS-485 connection or in parameter group *8-** Communications and Options*
 - Selecting a specific communication protocol changes various default parameter settings to match that protocol's specifications along with making additional protocol-specific parameters available

13088489.10

5 Local Control Panel and Programming

5.1 Local Control Panel (LCP)

5.1.1 Introduction

FC 360 supports numerical local control panel (LCP 21), graphic local control panel (LCP 102), and blind cover. This chapter describes the operations with LCP 21 and LCP 102, as well as how to program with LCP 21. For details about how to program with LCP 102, see the *Programming Guide*.

NOTICE

The frequency converter can also be programmed from the MCT-10 Set-up software on PC via RS-485 com-port. This software can be ordered using code number 130B1000 or downloaded from the Danfoss website: www.danfoss.com/BusinessAreas/DrivesSolutions/software-download

5.1.2 Numerical Local Control Panel LCP 21

The Numerical Local Control Panel (LCP 21) is divided into 4 functional sections.

- A. Numeric display
- B. Menu key
- C. Navigation keys and indicator lights (LEDs)
- D. Operation keys and indicator lights (LEDs)




Illustration 5.1 View of the LCP 21

A. Numeric display

The LCD-display is back-lit with 1 numeric line. All data is displayed in the LCP.

1	Set-up number shows the active set-up and the edit set-up. If the same set-up acts as both active and edit set-up, only that set-up number is shown (factory setting). When active and edit set-up differ, both numbers are shown in the display (Set-up 12). The number flashing indicates the edit set-up.
2	Parameter number.
3	Parameter value.
4	Motor direction is shown in the bottom left of the display, indicated by a small arrow pointing either clockwise or counterclockwise.
5	The triangle indicates whether the LCP is in status, quick menu or main menu.

Table 5.1 Legend to Illustration 5.1, Section A



Illustration 5.2 Display Information

B. Menu key

Press [Menu] to select between status, quick menu or main menu.

C. Navigation keys and indicator lights (LEDs)

6	Green LED/On: Control section is working.
7	Yellow LED/Warn.: Indicates a warning.
8	Flashing Red LED/Alarm: Indicates an alarm.
9	[Back]: For moving to the previous step or layer in the navigation structure
10	Arrows [▲] [▼]: For maneuvering between parameter groups, parameters and within parameters or increasing/decreasing parameter values. Arrows can also be used for setting local reference.
11	[OK]: For selecting a parameter and for accepting changes to parameter settings
12	[▶]: For moving from left to right within the parameter value to change each digit individually.

Table 5.2 Legend to Illustration 5.1, Section C

D. Operation keys and indicator lights (LEDs)

13	[Hand On]: Starts the motor and enables control of the frequency converter via the LCP. NOTICE 5-12 Terminal 27 Digital Input has coast inverse as the default setting. This means that [Hand On] does not start the motor if there is no 24 V to terminal 27.
14	[Off/Reset]: Stops the motor (off). If in alarm mode, the alarm is reset.
15	[Auto On]: Frequency converter is controlled either via control terminals or serial communication.


Table 5.3 Legend to Illustration 5.1, Section D

WARNING

The [Off/Reset] key is not a safety switch. It does not disconnect the frequency converter from mains.

5.1.3 Local Control Panel LCP 102

FC 360 supports Local Control Panel LCP 102, see Illustration 5.3.



130BC362.10

Illustration 5.3 Local Control Panel LCP 102

- a. Display area
- b. Menu keys for changing the display to show status, programming, or error message history.

- c. Navigation keys for programming functions, moving the display cursor, and speed control in local operation. Also included are the status indicator lights.
- d. Operational mode keys and reset.

NOTICE


The [Info] button does not function when LCP 102 is connected to FC 360.

Functions

- English and Chinese display
- Status messages
- Quick menu for easy commissioning
- Parameter setting and explanation of parameter function
- Parameter adjustment
- Full parameter back-up and copy function
- Alarm logging
- Hand-operated start/stop, or automatic mode option
- Reset function

Mounting

Use the graphical LCP adapter and a cable to connect the LCP 102 to the FC 360, as shown in Illustration 5.4.



130BD532.10

Illustration 5.4 Graphical LCP Adapter and Connecting Cable

5.1.4 The Right-key Function on LCP 21

Press [▶] to edit any of the 4 digits on the display individually. When pressing [▶] once, the cursor moves to the first digit and the digit starts flashing as shown in *Illustration 5.5*. Press the [▲] [▼] to change the value. Pressing [▶] does not change the value of the digits or move the decimal point.




Illustration 5.5 Right-key Function

[▶] can also be used for moving between parameter groups. When in main menu, press [▶] to move to the first parameter in the next parameter group (e.g. move from 0-03 Regional Settings [0] International to 1-00 Configuration Mode [0] Open loop).

5.2 Main Menu

The main menu gives access to all parameters.

1. To enter the main menu, press [Menu] until indicator in display is placed above main menu.
2. [▲] [▼]: Browse through the parameter groups.
3. Press [OK] to select a parameter group.
4. [▲] [▼]: Browse through the parameters in the specific group.
5. Press [OK] to select the parameter.
6. [▶] and [▲] [▼]: Set/change the parameter value.
7. Press [OK] to accept the value.

8. To exit, press either [Back] twice (or 3 times for array parameters) to enter main menu, or press [Menu] once to enter status.

See *Illustration 5.6*, *Illustration 5.7*, and *Illustration 5.8* for the principles of changing the value of continuous, enumerated and array parameters respectively. The actions in the illustrations are described in *Table 5.4*, *Table 5.5*, and *Table 5.6*.




Illustration 5.6 Main Menu Interactions - Continuous Parameters

1	[OK]: The first parameter in the group is shown.
2	Press [▼] repeatedly to move down to the desired parameter.
3	Press [OK] to start editing.
4	[▶]: First digit flashing (can be edited).
5	[▶]: Second digit flashing (can be edited).
6	[▶]: Third digit flashing (can be edited).
7	[▼]: Decreases the parameter value, the decimal point changes automatically
8	[▲]: Increases the parameter value.
9	[Back]: Cancel changes, return to 2) [OK]: Accept changes, return to 2)
10	[▲][▼]: Select parameter within the group.
11	[Back]: Removes the value and shows the parameter group.
12	[▲][▼]: Select group.

Table 5.4 Changing Values in Continuous Parameters

For enumerated parameters, the interaction is similar but the parameter value is shown in brackets, because of the LCP 21 digits limitation (4 large digits) and the enum can be greater than 99. When the enum value is greater than 99, the LCP 21 can only display the first part of the bracket.




Illustration 5.7 Main Menu Interactions - Enumerated Parameters

1	[OK]: The first parameter in the group is shown.
2	Press [OK] to start editing.
3	[▲][▼]: Change parameter value (flashing).
4	Press [Back] to cancel changes or [OK] to accept changes (return to screen 2).
5	[▲][▼]: Select a parameter within the group.
6	[Back]: Removes the value and shows the parameter group.
7	[▲][▼]: Select a group.

Table 5.5 Changing Values in Enumerated Parameters

Array parameters function as follows:




Illustration 5.8 Main Menu Interactions - Array Parameters

1	[OK]: Shows parameter numbers and the value in the first index.
2	[OK]: Index can be selected.
3	[▲][▼]: Select index.
4	[OK]: Value can be edited.
5	[▲][▼]: Change parameter value (flashing).
6	[Back]: Cancels changes [OK]: Accepts changes
7	[Back]: Cancels editing index, a new parameter can be selected.
8	[▲][▼]: Select parameter within the group.
9	[Back]: Removes parameter index value and shows the parameter group.
10	[▲][▼]: Select group.

Table 5.6 Changing Values in Array Parameters

5.3 Quick Menu

The quick menu gives easy access to the most frequently used parameters.

1. To enter the quick menu, press [Menu] until the indicator in display is placed above *Quick Menu*.
2. Press [▲] [▼] to select either QM1 or QM2, then press [OK].
3. Press [▲] [▼] to browse through the parameters in the quick menu.
4. Press [OK] to select a parameter.
5. Press [▲] [▼] to change the value of a parameter setting.
6. Press [OK] to accept the change.
7. To exit, press either [Back] twice (or 3 times if in QM2 and QM3) to enter *Status*, or press [Menu] once to enter main menu.

130BC445.12




Illustration 5.9 Quick Menu Structure

5.4 PM Motor Setup

Initial Programming Steps

1. Select [1] PM, non salient SPM in 1-10 Motor Construction to activate PM motor operation.
2. Select [0] Open Loop in 1-00 Configuration Mode.

NOTICE

Encoder feedback is not supported for PM motors.

Programming motor data

After selecting PM motor in 1-10 Motor Construction, the PM motor-related parameters in parameter groups 1-2* Motor Data, 1-3* Adv. Motor Data and 1-4* are active. The information can be found on the motor nameplate and in the motor data sheet.

The following parameters must be programmed in the listed order

1. 1-24 Motor Current
2. 1-26 Motor Cont. Rated Torque
3. 1-25 Motor Nominal Speed
4. 1-39 Motor Poles
5. 1-30 Stator Resistance (Rs)
Enter line to common stator winding resistance (Rs). If only line-line data is available, divide the line-line value by 2 to achieve the line to common (starpoint) value.
It is also possible to measure the value with an ohmmeter, which also takes the resistance of the cable into account. Divide the measured value by 2 and enter the result.
6. 1-37 d-axis Inductance (Ld)
Enter line to common direct axis inductance of the PM motor.
If only line-line data is available, divide the line-line value with 2 to achieve the line-common (starpoint) value.
It is also possible to measure the value with an inductance meter, which also takes the inductance of the cable into account. Divide the measured value by 2 and enter the result.
7. 1-40 Back EMF at 1000 RPM
Enter line-to-line back EMF of PM Motor at 1000 RPM mechanical speed (RMS value). Back EMF is the voltage generated by a PM motor when no frequency converter is connected and the shaft is turned externally. Back EMF is normally specified for nominal motor speed or for 1000 RPM measured between 2 lines. If the value is not available for a motor speed of 1000 RPM, calculate the correct value as follows: For example, if back EMF at 1800 RPM is 320 V, the back EMF at 1000 RPM is:

Back EMF=(Voltage/
RPM)*1000=(320/1800)*1000=178.
Program this value for 1-40 Back EMF at 1000 RPM.

Test Motor Operation

1. Start the motor at low speed (100 to 200 RPM). If the motor does not turn, check installation, general programming and motor data.

Parking

This function is the recommended choice for applications where the motor is rotating at slow speed e.g. windmilling in fan applications. 2-06 Parking Current and 2-07 Parking Time are adjustable. Increase the factory setting of these parameters for applications with high inertia.

Start the motor at nominal speed. In case the application does not run well, check the VVC+ PM settings. Table 5.7 shows recommendations in different applications.

Application	Settings
Low inertia applications $I_{Load}/I_{Motor} < 5$	<ul style="list-style-type: none"> • Increase the value for 1-17 Voltage filter time const. by factor 5 to 10 • Reduce the value for 1-14 Damping Gain • Reduce the value (<100%) for 1-66 Min. Current at Low Speed
Low inertia applications $50 > I_{Load}/I_{Motor} > 5$	Keep calculated values
High inertia applications $I_{Load}/I_{Motor} > 50$	Increase the values for 1-14 Damping Gain, 1-15 Low Speed Filter Time Const. and 1-16 High Speed Filter Time Const.
High load at low speed <30% (rated speed)	1-17 Voltage filter time const. should be increased 1-66 Min. Current at Low Speed should be increased (>100% for longer time can overheat the motor)

Table 5.7 Recommendations in Different Applications

If the motor starts oscillating at a certain speed, increase 1-14 Damping Gain. Increase the value in small steps.

Starting torque can be adjusted in 1-66 Min. Current at Low Speed. 100% provides nominal torque as starting torque.

5.5 Profibus


FC 360 frequency converters support profibus. The profibus module is integrated in the control cassette with profibus. If profibus is needed,

- Order a new frequency converter on which the control cassette with profibus is pre-installed;
- Order a control cassette with profibus to replace the standard control cassette on an existing frequency converter. In this case, upgrade the firmware with MCT-10 Set-up software.

5

In both cases, ensure that *15-43 Software Version* is higher than 1.20.

Illustration 5.10 shows the front panel of a control cassette with profibus.



130BD650.10

1	Termination resistor switch
2	Profibus address selector

Illustration 5.10 Front Panel of a Control Cassette with Profibus

The functions of the LEDs and switches on the front panel are introduced in *Table 5.8*.

LED/Switch	Description
NS2	Not used for profibus
NS1	Indicates the network status when communicating with the profibus master. When this light shows constant green, data exchange between the master and the frequency converter is active.
MS	Indicates the module status, which is acyclic DP V1 communication from either a profibus master class 1 (PLC) or a master class 2 (MCT 10, FDT tool). When this light shows constant green, then DP V1 communication from master classes 1 and 2 is active.
COM	Communication status for RS-485. Not used for profibus.
Termination resistor switch	When the switch is turned on, the termination resistor is in effect.
Profibus address selector	Use the switches in the selector to set the profibus address. The address change comes into effect at the next power-up. WARNING Switch off the power supply before changing the switches.

Table 5.8 Functions of LEDs and Switches

The profibus decoupling kit contains parts that are required for profibus to work. Mount the kit before using profibus. *Illustration 5.11* and *Illustration 5.12* show how to mount the decoupling kit.




Illustration 5.11 Fasten the Plate with Screws




Illustration 5.12 Push the 5-pin Connector into Place

5.6 Parameter List

5.6.1 Parameter List - Main Menu Structure

Parameter ID	Parameter Name / Description	Parameter Value / Range	Parameter Unit / Notes	Parameter Function / Action	Parameter Reference / Notes
0-0*	Operation / Display				
0-01	Basic Settings				>Local bus reference<
0-02	Language				>Bus PCD<
0-03	Regional Settings				Reference 2 Source
0-04	Operating State at Power-up				Reference 3 Source
0-06	GridType				Relative Scaling Reference Resource
[10]	>380-440V/50Hz/IT-grid<				Ramp 1
[11]	>380-440V/50Hz/Delta<				Ramp 1 Type
[12]	>380-440V/50Hz<				>Linear<
[20]	>440-480V/50Hz/IT-grid<				>S-ramp Const Time<
[21]	>440-480V/50Hz/Delta<				Ramp 1 Ramp Up Time
[22]	>440-480V/50Hz<				>0.05-3600 s< * Size related
[110]	>380-440V/60Hz/IT-grid<				Ramp 1 Ramp Down Time
[111]	>380-440V/60Hz/Delta<				>0.05-3600 s< * Size related
[112]	>380-440V/60Hz<				Ramp 1 Ramp Down Time
[120]	>440-480V/60Hz/IT-grid<				>0.05-3600 s< * Size related
[121]	>440-480V/60Hz/Delta<				Ramp 1 Ramp Down Time
[122]	>440-480V/60Hz<				>0.05-3600 s< * Size related
0-07	Auto DC Braking				Ramp 2
0-10	Set-up Operations				Ramp 2 Type
[10]	Active Set-up				Ramp 2 Ramp Up Time
[11]	>Set-up 1<				Ramp 2 Ramp Down Time
[2]	>Set-up 2<				Ramp 2 Ramp Down Time
[9]	>Multi Set-up<				Ramp 3
0-11	Programming Set-up				Ramp 3 Type
0-12	Link Setups				Ramp 3 Ramp up Time
0-14	Readout: Edit Set-ups / Channel				Ramp 3 Ramp down Time
0-16	Application Selection				Ramp 4
[10]	None				Ramp 4 Type
[1]	>Process Close Loop<				Ramp 4 Ramp up Time
[2]	>Local/Remote<				Ramp 4 Ramp Down Time
[3]	>Speed Open Loop<				Other Ramps
[4]	>Speed Close Loop<				Jog Ramp Time
[5]	>Multi Speed<				Quick Stop Ramp Time
0-2*	LCP Display				Digital Potentiometer
0-20	Display Line 1.1 Small				Step Size
0-21	Display Line 1.2 Small				Power Restore
0-22	Display Line 1.3 Small				Maximum Limit
0-23	Display Line 2 Large				Minimum Limit
0-24	Display Line 3 Large				Ramp Delay
0-3*	LCP Custom Readout				Limits / Warnings
0-30	Custom Readout Unit				4-1* Motor Limits
0-31	Custom Readout Min Value				4-10 Motor Speed Direction
0-32	Custom Readout Max Value				[0] >Clockwise<
0-37	Display Text 1				[2] >Both directions<
0-38	Display Text 2				4-12 Motor Speed Low Limit [Hz]
0-39	Display Text 3				4-14 Motor Speed High Limit [Hz]
0-4*	LCP keypad				4-16 Torque Limit Motor Mode
0-40	[Hand on] Key on LCP				4-17 Torque Limit Generator Mode
0-42	[Auto on] Key on LCP				Current Limit
0-44	[Off/Reset] Key on LCP				4-19 Max Output Frequency
0-5*	Copy/Save				Limit Factors
0-50	LCP Copy				4-20 Torque Limit Factor Source
[1]	>No copy<				4-21 Speed Limit Factor Source
[11]	>All to LCP<				4-22 Break Away Boost
[2]	>All from LCP<				4-3* Motor Fb Monitor
[3]	>Size indep. from LCP<				4-30 Motor Feedback Loss Function
0-51	Set-up Copy				4-31 Motor Feedback Speed Error
[0]	>No copy				4-32 Motor Feedback Loss Timeout
[1]	>Copy from setup 1<				Adj. Warnings 2
[2]	>Copy from setup 2<				4-40 Warning Freq. Low
[9]	>Copy from Factory setup<				4-41 Warning Freq. High
0-6*	Password				4-42 Adjustable Temperature Warning
0-60	Main Menu Password				4-50 Warning Current Low
1-*	Load and Motor				
1-0*	General Settings				
1-00	Configuration Mode				
[0]	>Open Loop<				DC-Brake
[1]	>Speed closed loop<				2-0* DC Hold/Motor Preheat Current
[2]	>Torque closed loop<				2-01 DC Brake Current
[3]	>Process closed loop<				2-02 DC Braking Time
[4]	>Torque open loop<				2-04 DC Brake Cut in Speed
[6]	>Surface Winder<				2-06 Parking Current
[7]	>Extended PID Speed OL<				2-07 Parking Time
1-01	Motor Control Principle				Brake Energy Funct.
[0]	>U/F<				2-10 Brake Function
[1]	>VVC+<				>Off<
1-03	Torque Characteristics				>Resistor brake<
[0]	>Constant torque<				>AC brake<
[1]	>Variable Torque<				2-11 Brake Resistor (ohm)
[2]	>Auto Energy Optim. CT<				2-12 Brake Power Limit (kW)
1-06	Clockwise Direction				2-14 Brake voltage reduce
1-08	Motor Control Bandwidth				2-16 AC Brake, Max current
1-1*	Motor Selection				2-17 Over-voltage Control
1-10	Motor Construction				>Disabled<
1-14	Damping Gain				[1] >Enabled (not at stop)<
1-15	Low Speed Filter Time Const.				[2] >Enabled<
1-16	High Speed Filter Time Const.				>Over-voltage Gain
1-17	Voltage filter time const.				Mechanical Brake
1-2*	Motor Data				2-20 Release Brake Current
1-20	Motor Power				2-22 Activate Brake Speed [Hz]
[2]	>0.12 kW - 0.16 hp<				3-*** Reference / Ramps
[3]	>0.18 kW - 0.25 hp<				3-0* Reference Limits
[4]	>0.25 kW - 0.33 hp<				3-00 Reference Range
[5]	>0.37 kW - 0.5 hp<				[2] >Min - Max<
[6]	>0.55 kW - 0.75 hp<				[1] >Max - +Max<
[7]	>0.75 kW - 1 hp<				3-01 Reference/Feedback Unit
[8]	>1.1 kW - 1 hp<				3-02 Minimum Reference
[9]	>1.5 kW - 2 hp<				3-03 Maximum Reference
[10]	>2.2 kW - 3 hp<				3-04 Reference Function
[11]	>3 kW - 4 hp<				[0] >Sum<
[12]	>3.7 kW - 5 hp<				>External/Preset<
[13]	>4 kW - 5.4 hp<				3-1* References
[14]	>5.5 kW - 7.5 hp<				3-10 Preset Reference
[15]	>7.5 kW - 10 hp<				3-11 Jog Speed [Hz]
[16]	>11 kW - 15 hp<				3-12 Catch up/slow Down Value
[17]	>15 kW - 20 hp<				3-14 Preset Relative Reference
[18]	>18.5 kW - 25 hp<				[0] >No function<
[19]	>22 kW - 30 hp<				[1] >Analog input 53<
[20]	>30 kW - 40 hp<				[2] >Analog input 54<
[21]	>37 kW - 50 hp<				[7] >Frequency input 29<
[22]	>45 kW - 60 hp<				[8] >Frequency input 33<

4-51	Warning Current High	[156]	>HW Limit Negative<	[40]	>Out of ref range<	[11]	>At torque limit<	[179]	Position Mech Brake
4-54	Warning Reference Low	[157]	>Pos. Quick Stop<	[41]	>Below reference, low<	[12]	>Out of current range<	[193]	>Sleep Mode<
4-55	Warning Reference High	[160]	>Go To Target Pos<	[42]	>Above ref, high<	[13]	>Below current, low<	[194]	>Broken Belt Function<
4-56	Warning Feedback Low	[162]	>Pos. ldx Bit0<	[43]	>Extended PID Limit<	[14]	>Above current, high<	5-41	On Delay, Relay
4-57	Warning Feedback High	[163]	>Pos. ldx Bit1<	[45]	>Bus ctrl.<	[15]	>Out of frequency range<	5-42	Off Delay, Relay
4-58	Missing Motor Phase Function	[164]	>Pos. ldx Bit2<	[46]	>Bus control, timeout: On<	[16]	>Below frequency, low<	5-5* Pulse Input	
4-6*	Speed Bypass	[165]	Core diameter source	[47]	>Bus control, timeout: Off<	[17]	>Above frequency, high<	5-50	Term. 29 Low Frequency
4-61	Bypass Speed From [Hz]	[166]	New diameter select	[55]	>Pulse output <	[18]	>Out of feedb. range<	5-51	Term. 29 High Frequency
4-63	Bypass Speed To [Hz]	[167]	Reset diameter	[56]	>Heat sink cleaning warning, high<	[19]	>Below feedback, low<	5-52	Term. 29 Low Ref./Feedb. Value
5-0*	Digital I/O mode	[168]	Winder jog forward	[61]	>Comparator 0<	[20]	>Above feedback, high<	5-53	Term. 33 High Ref./Feedb. Value
5-00	Digital I/O Mode	[170]	Winder jog reverse	[62]	>Comparator 1<	[21]	>Thermal warning<	5-55	Term. 33 Low Frequency
[1]	>NPN<	[169]	Tension on	[63]	>Comparator 2<	[22]	>Ready, no thermal warning<	5-56	Term. 33 High Frequency
5-01	Terminal 27 Mode	5-11	Terminal 19 Digital Input	[64]	>Comparator 3<	[23]	>Remote/ready/no TW<	5-57	Term. 33 Low Ref./Feedb. Value
5-02	Terminal 29 Mode	5-12	Terminal 27 Digital Input	[65]	>Comparator 4<	[24]	>Reverse<	5-6* Pulse Output	
5-1*	Digital Inputs	[32]	Pulse time based	[70]	>Comparator 5<	[25]	>Bus OK<	5-60	Terminal 27 Pulse Output Variable
5-10	Terminal 18 Digital Input	[82]	Terminal 32 Digital Input	[71]	>Logic rule 0<	[26]	>Torque limit & stop<	*[0]	>No operation<
[0]	>No operation<	5-15	Encoder input B	[72]	>Logic rule 1<	[27]	>Brake, no brake warning<	[45]	>Bus ctrl.<
[1]	>Reset<	5-16	Terminal 33 Digital Input	[73]	>Logic rule 2<	[28]	>Brake ready, no fault<	[48]	>Bus ctrl., timeout<
[2]	>Coast inverse<	[32]	Pulse time based	[74]	>Logic rule 3<	[29]	>Brake fault (IGBT)<	[100]	>Output frequency<
[3]	>Coast and reset inv<	[81]	Encoder input A	[75]	>Logic rule 4<	[30]	>Relay 123<	[101]	>Reference<
[4]	>Quick stop inverse<	5-3* Digital Outputs	Terminal 31 Digital Input	[80]	>Logic rule 5<	[31]	>Mech brake ctrl<	[102]	>Process Feedback<
[5]	>DC-brake inverse<	5-30	Terminal 27 Digital Output	[82]	>SL digital output A<	[32]	>Control word bit 11<	[103]	>Motor Current<
[6]	>Stop inverse<	*[0]	>No operation<	[83]	>SL digital output B<	[36]	>Control word bit 12<	[104]	>Torque rel to limit<
*[8]	>Start<	[1]	>Control Ready<	[91]	>SL digital output C<	[37]	>Out of ref range<	[105]	>Torg relate to rated<
[9]	>Latched start<	[2]	>Drive ready<	[160]	>Encoder emulate output A<	[40]	>Below reference, low<	[106]	>Power<
[10]	>Reversing<	[3]	>Drive rdy/rem ctrl<	[161]	>No alarm<	[42]	>Above ref, high<	[107]	>Speed<
[11]	>Start reversing<	[4]	>Stand-by/no warning<	[165]	>Running reverse <	[45]	>Bus ctrl.<	[109]	>Max Out Freq<
[12]	>Enable start forward<	[5]	>Running<	[166]	>Local ref active <	[46]	>Bus control, timeout: On<	5-62	Pulse Output Max Freq 27
[13]	>Enable start reverse<	[6]	>Run in range/no warn<	[167]	>Remote ref active<	[47]	>Bus control, timeout: Off<	5-63	Terminal 29 Pulse Output Variable
[14]	>Jog<	[7]	>Run on ref/no warn<	[168]	>Start command activ<	[56]	>Heat sink cleaning warning, high<	5-65	Pulse Output Max Freq 29
[15]	>Preset reference on<	[8]	>Run on ref/no warn<	[169]	>Drive in hand mode<	[60]	>Comparator 0<	5-7* 24V Encoder Input	
[16]	>Preset ref bit 0<	[9]	>Alarm<	[170]	>Drive in auto mode<	[61]	>Comparator 1<	5-70	Term 32/33 Pulses Per Revolution
[17]	>Preset ref bit 1<	[10]	>Alarm or warning<	[171]	>Homing Completed<	[62]	>Comparator 2<	5-71	Term 32/33 Encoder Direction
[18]	>Preset ref bit 2<	[11]	>At torque limit<	[172]	>Target Position Reached<	[63]	>Comparator 3<	5-9* Bus Controlled	
[19]	>Freeze reference<	[12]	>Out of current range<	[173]	>Position Control Fault<	[64]	>Comparator 4<	5-90	Digital & Relay Bus Control
[20]	>Freeze output<	[13]	>Below current, low<	[174]	End of roll	[65]	>Comparator 5<	5-93	Pulse Out 27 Bus Control
[21]	>Speed up<	[14]	>Above frequency, high<	[175]	TLD indicator	[70]	>Logic rule 0<	5-94	Pulse Out 27 Timeout Preset
[22]	>Speed down<	[15]	>Out of frequency range<	[176]	Running on tension	[71]	>Logic rule 1<	5-95	Pulse Out 29 Bus Control
[23]	>Set-up select bit 0<	[16]	>Below frequency, low<	[179]	Ready to run	[72]	>Logic rule 2<	5-96	Pulse Out 29 Timeout Preset
[26]	>Precise stop inverse<	[17]	>Above frequency, high<	[193]	Position Mech Brake	[73]	>Logic rule 3<	6-** Analog In/Out	
[28]	>Catch up<	[18]	>Out of feedb. range<	[194]	>Sleep Mode<	[74]	>Logic rule 4<	6-0* Analog I/O Mode	
[29]	>Slow down<	[19]	>Below feedback, low<	5-31	>Broken Belt Function<	[75]	>Logic rule 5<	6-00	Live Zero Timeout Time
[34]	>Ramp bit 0<	[20]	>Above feedback, high<	5-34	Terminal 29 Digital Output	[80]	>SL digital output A<	6-01	Live Zero Timeout Function
[35]	>Ramp bit 1<	[21]	>Thermal warnings<	5-35	On Delay, Digital Output	[81]	>SL digital output B<	*[0]	>Off<
[51]	>External interlock<	[22]	>Ready, no thermal warning<	5-4* Relays	Off Delay, Digital Output	[82]	>SL digital output C<	[1]	>Freeze output<
[60]	>Counter A (up)<	[23]	>Remote/ready/no TW<	5-40	Function Relay	[83]	>SL digital output D<	[2]	>Stop<
[61]	>Counter A (down)<	[24]	>Ready, no over/under voltage<	[0]	>No operation<	[160]	>No alarm<	[3]	>Jogging<
[62]	>Reset Counter A<	[25]	>Reverse<	[1]	>Control Ready<	[161]	>Running reverse <	[4]	>Max. speed<
[63]	>Counter B (up)<	[26]	>Bus OK<	[2]	>Drive ready<	[165]	>Local ref active <	[5]	>Stop and trip<
[64]	>Counter B (down)<	[27]	>Torque limit & stop<	[3]	>Drive rdy/rem ctrl<	[166]	>Remote ref active<	6-1* Analog Input 53	
[65]	>Reset Counter B<	[28]	>Brake, no brake warning<	[4]	>Stand-by/no warning<	[167]	>Start command activ<	6-10	Terminal 53 Low Voltage
[72]	>PID error inverse<	[29]	>Brake ready, no fault<	[5]	>Running<	[168]	>Drive in hand mode<	>0-10 V< *0.07 V	
[73]	>PID reset 1 part<	[30]	>Brake fault (IGBT)<	[6]	>Run in range/no warn<	[169]	>Drive in auto mode<	>0-10 V< *10 V	
[74]	>PID enable<	[31]	>Relay 123<	[7]	>Run on ref/no warn<	[170]	>Homing Completed<	6-11	Terminal 53 High Voltage
[150]	>Go To Home<	[32]	>Mech brake ctrl<	[8]	>Run on range/no warn<	[171]	>Target Position Reached<	6-12	Terminal 53 Low Current
[151]	>Home Ref. Switch<	[36]	>Control word bit 11<	[8]	>Alarm<	[172]	>Position Control Fault<	>0-20 mA< *4 mA	
[155]	>HW Limit Positive<	[37]	>Control word bit 12<	[9]	>Alarm or warning<	[175]	Running on tension	6-13	Terminal 53 High Current
				[10]	>Alarm or warning<	[176]	Ready to run	>0-20 mA< *20 mA	

6-14	Terminal 53 Low Ref./Feedb. Value	>0.000-1.000< *0.015	7-5*	Adv. Process PID II	8-8*	FC Port Diagnostics	12-1*	Ethernet Link Parameters
6-15	Terminal 53 High Ref./Feedb. Value	Speed PID Integral Time	7-50	Process PID Extended PID	8-80	Bus Message Count	12-10	Link Status
6-16	Terminal 53 Filter Time Constant	>2.0-20000.0 ms< *8.0 ms	7-51	Process PID Feed Fwd Gain	8-81	Bus Error Count	12-11	Link Duration
6-19	Terminal 53 mode	Speed PID Differentiation Time	7-52	Process PID Feed Fwd Ramp up	8-82	Slave Messages Rcvd	12-12	Auto Negotiation
[0]	>Current mode<	>0.0-200.0 ms< *300 ms	7-53	Process PID Feed Fwd Ramp down	8-83	Slave Error Count	12-13	Link Speed
*[1]	>Voltage mode<	Speed PID Diff. Gain Limit	7-56	Process PID Ref. Filter Time	8-84	Slave Messages Sent	12-14	Link Duplex
6-2*	Analog Input 54	>1.0-20.0< *5.0	7-57	Process PID Fb. Filter Time	8-85	Slave Timeout Errors	12-8*	Other Ethernet Services
6-20	Terminal 54 Low Voltage	Speed PID Lowpass Filter Time	7-6*	Feedback Conversion	8-88	Reset FC port Diagnostics	12-80	FTP Server
6-21	Terminal 54 High Voltage	>1.0-100.0 ms< *10.0 ms	7-60	Feedback 1 Conversion	8-9*	Bus Feedback	12-81	HTTP Server
6-22	Terminal 54 Low Current	Speed PID Feedback Gear Ratio	[*0]	>Linear<	8-90	Bus Jog 1 Speed	12-82	SMTP Service
6-23	Terminal 54 High Current	Speed PID Feed Forward Factor	[1]	>Square root<	8-91	Bus Jog 2 Speed	12-89	Transparent Socket Channel Port
6-24	Terminal 54 Low Ref./Feedb. Value	Torque PID Ctrl.	7-62	Feedback 2 Conversion	9-9*	PROFIDrive	12-9*	Advanced Ethernet Services
6-25	Terminal 54 High Ref./Feedb. Value	Torque PID Proportional Gain	8-0*	Common and Options	9-00	Setpoint	12-90	Cable Diagnostics
6-26	Terminal 54 Filter Time Constant	Torque PID Integration Time	8-0*	General Settings	9-07	Actual Value	12-91	Auto Cross Over
6-29	Terminal 54 mode	Process Ctrl. Feedb	8-01	Control Site	9-15	PCD Write Configuration	12-92	IGMP Snooping
[0]	>Current mode<	>No function<	8-02	Control Source	9-16	PCD Read Configuration	12-93	Cable Error Length
*[1]	>Voltage mode<	>No function<	8-03	Control Timeout	9-18	Node Address	12-94	Broadcast Storm Filter
6-7*	Analog/Digital Output 45	[1] >Analog input 53<	8-04	Control Timeout Function	9-19	Drive Unit System Number	12-96	Port Config
6-70	Terminal 45 Mode	[2] >Analog input 54<	8-07	Diagnosis Trigger	9-22	Telegram Selection	12-98	Interface Counters
[0]	>0-20 mA<	[3] >Frequency input 29<	8-1	Ctrl. Word Settings	9-23	Parameters for Signals	12-99	Media Counters
[1]	>4-20 mA<	[4] >Frequency input 33<	8-10	Control Word Profile	9-27	Parameter Edit	13-0*	Smart Logic
[2]	>Digital Output<	7-22 Process CL Feedback 2 Resource	8-14	Configurable Control Word CTW	9-28	Process Control	13-0*	SLC Settings
6-71	Terminal 45 Analog Output	7-3* Process PID Ctrl.	8-19	Product Code	9-44	Fault Message Counter	13-00	SL Controller Mode
[0]	>No operation<	7-30 Process PID Normal/ Inverse Control	8-3	FC Port Settings	9-45	Fault Code	*[0]	>Off<
[100]	>Output frequency<	>Normal<	8-30	Protocol	9-47	Fault Number	[1]	>On<
[101]	>Reference<	[1] >Inverses<	[*0]	>FC<	9-52	Fault Situation Counter	13-01	Start Event
[102]	>Process Feedback<	7-31 Process PID Anti Windup	[2]	>Modbus RTU<	9-53	Profibus Warning Word	[0]	>False<
[103]	>Motor Current<	[0] >Off<	8-31	Address	9-63	Actual Baud Rate	[1]	>True<
[104]	>Torque rel to limit<	*[1] >On<	8-32	Baud Rate	9-64	Device Identification	[2]	>Running<
[105]	>Torq relate to rated<	7-32 Process PID Start Speed	[0]	>2400 Baud<	9-65	Profile Number	[3]	>In range<
[106]	>Power<	>0 - 6000 rpm< *0 rpm	[1]	>4800 Baud<	9-67	Control Word 1	[4]	>On reference<
[107]	>Speed<	Process PID Proportional Gain	[2]	>9600 Baud<	9-68	Status Word 1	[7]	>Out of current range<
[111]	>Speed Feedback<	>0.00 - 10.00< *0.01	[3]	>19200 Baud<	9-70	Programming Set-up	[8]	>Below 1 low<
[113]	PID Clamped Output	7-33 Process PID Integral Time	[4]	>38400 Baud<	9-71	Profibus Save Data Values	[9]	>Above 1 high<
[139]	>Bus Control<	7-34 Process PID Differentiation Time	[5]	>57600 Baud<	9-72	ProfibusDriveReset	[16]	>Thermal warning<
6-72	Terminal 45 Digital Output	>0.10-9999.00 s< *9999.00 s	[6]	>76800 Baud<	9-75	DO Identification	[17]	>Mains out of range<
6-73	Terminal 45 Output Min Scale	>0.00-20.00 s< *0.00 s	[7]	>115200 Baud<	9-80	Defined Parameters (1)	[18]	>Reversing<
6-74	Terminal 45 Output Max Scale	7-35 Process PID Diff. Gain Limit	8-33	Parity / Stop Bits	9-81	Defined Parameters (2)	[19]	>Warning<
6-76	Terminal 45 Output Bus Control	7-38 Process PID Feed Forward Factor	[*0]	>Even Parity, 1 Stop Bit<	9-82	Defined Parameters (3)	[20]	>Alarm (trip)<
6-9*	Analog/Digital Output 42	>0-200%< *0%	[1]	>Odd Parity, 1 Stop Bit<	9-83	Defined Parameters (4)	[21]	>Alarm (trip lock)<
6-90	Terminal 42 Mode	7-39 On Reference Bandwidth	[2]	>No Parity, 1 Stop Bit<	9-84	Defined Parameters (5)	[22]	>Comparator 0<
6-91	Terminal 42 Analog Output	7-4* Adv. Process PID I	[3]	>No Parity, 2 Stop Bits<	9-90	Changed Parameters (1)	[23]	>Comparator 1<
6-92	Terminal 42 Digital Output	7-40 Process PID I-part Reset	8-35	Minimum Response Delay	9-91	Changed Parameters (2)	[24]	>Comparator 2<
6-93	Terminal 42 Output Min Scale	7-41 Process PID Output Neg. Clamp	8-36	Maximum Response Delay	9-92	Changed Parameters (3)	[25]	>Comparator 3<
6-94	Terminal 42 Output Max Scale	7-42 Process PID Output Pos. Clamp	8-37	Maximum Inter-char delay	9-93	Changed Parameters (4)	[26]	>Logic rule 0<
6-96	Terminal 42 Output Bus Control	7-43 Process PID Gain Scale at Min. Ref.	8-4*	FC MC protocol set	9-94	Changed Parameters (5)	[27]	>Logic rule 1<
6-98	Drive Type	7-44 Process PID Gain Scale at Max. Ref.	8-43	PCD Read Configuration	9-99	Profibus Revision Counter	[28]	>Logic rule 2<
7-0*	Speed PID Ctrl.	7-45 Process PID Feed Fwd Resource	8-5*	Digital/Bus	12-0*	Ethernet	[29]	>Logic rule 3<
7-00	Speed PID Feedback Source	*[0] >No function<	8-50	Coasting Select	12-00*	IP Settings	[33]	>Digital input DI18<
[1]	>24V encoder<	[1] >Analog input 53<	8-51	Quick Stop Select	12-00	IP Address Assignment	[34]	>Digital input DI19<
[2]	>MCB 102<	[2] >Analog input 54<	8-52	DC Brake Select	12-01	IP Address	[35]	>Digital input DI27<
[3]	>MCB 103<	[7] >Frequency input 29<	8-53	Start Select	12-02	Subnet Mask	[36]	>Digital input DI29<
[6]	>Analog input 53<	[8] >Frequency input 33<	8-54	Reversing Select	12-03	Default Gateway	*[39]	>Start command<
[7]	>Analog input 54<	[11] >Local bus reference<	8-55	Set-up Select	12-04	DHCP Server	[40]	>Drive stopped<
[8]	>Frequency input 29<	[32] >Bus PCD<	8-56	Preset Reference Select	12-05	Lease Expires	[42]	>Auto Reset Trip<
[9]	>Frequency input 33<	7-46 Process PID Feed Fwd Normal/ Inv. Ctrl.	8-57	Profidrive OFF2 Select	12-06	Name Servers	[50]	>Comparator 4<
*[20]	>None<	7-48 PCD Feed Forward	8-58	Profidrive OFF3 Select	12-07	Domain Name	[51]	>Comparator 5<
7-02	Speed PID Proportional Gain	7-49 Process PID Output Normal/ Inv. Ctrl.	8-7*	BACnet	12-08	Host Name	[60]	>Logic rule 4<
			8-79	Protocol Firmware Version	12-09	Physical Address	[61]	>Logic rule 5<

183]	>Broken Belt<	14-2* Reset Functions	14-64	Dead Time Compensation Level	16-14	Motor current	17-59	Resolver Interface
13-02	Stop Event	14-20	Reset Mode	14-65	Speed Derate	16-15	Frequency [%]	17-6* Monitoring and App.
[0]	>Off<	>Manual reset<	14-65	Speed Derate Dead Time Compensation	16-16	Torque [Nm]	18-9	Data Readouts 2
[1]	>On<	>Automatic reset x 1<	14-8* Options	14-8* Options	16-18	Motor Thermal	18-9*	PID Readouts
13-03	Reset SLC	>Automatic reset x 2<	14-89	Option Detection	16-22	Torque [%]	18-90	Process PID Error
[0]	>Do not reset SLC<	>Automatic reset x 3<	14-9	Option Detection	16-3*	Drive Status	18-91	Process PID Output
[1]	>Reset SLC<	>Automatic reset x 4<	14-90	Option Detection	16-30	DC Link Voltage	18-92	Process PID Clamped Output
13-1*	Comparators	>Automatic reset x 5<	15-5*	Drive Information	16-33	Brake Energy /2 min	18-93	Process PID Gain Scaled Output
13-10	Comparator Operand	>Automatic reset x 6<	15-61	Option SW Version	16-34	Heatsink Temp.	22-2*	Appl. Functions
13-11	Comparator Operator	>Automatic reset x 7<	15-62	Option Ordering No	16-35	Inverter Thermal	22-4* Sleep Mode	
13-12	Comparator Value	>Automatic reset x 8<	15-63	Option Serial No	16-36	Inv. Nom. Current	22-40	Minimum Run Time
13-2*	Timers	>Automatic reset x 9<	15-63	Option Serial No	16-37	Inv. Max. Current	22-41	Minimum Sleep Time
13-20	SL Controller Timer	>Automatic reset x 10<	15-71	Option in Slot A	16-38	SL Controller State	22-43	Wake-Up Speed [Hz]
13-4*	Logic Rules	>Automatic reset x 15<	15-71	Option in Slot A	16-39	Control Card Temp.	22-44	Wake-Up Ref/FB Diff
13-40	Logic Rule Boolean 1	>Automatic reset x 20<	15-0*	Operating Data	16-5*	Ref. & Feedb.	22-45	Setpoint Boost
13-41	Logic Rule Operator 1	>Infinite auto reset<	15-00	External Reference	16-50	External Reference	22-46	Maximum Boost Time
13-42	Logic Rule Boolean 2	>Reset at power-up<	15-01	Running Hours	16-52	Feedback[Unit]	22-47	Sleep Speed [Hz]
13-43	Logic Rule Operator 2	Automatic Restart Time	15-02	kWh Counter	16-57	Feedback [RPM]	22-6*	Broken Belt Detection
13-44	Logic Rule Boolean 3	>0-600 s < *10 s	15-03	Power Up's	16-6*	Inputs & Outputs	22-60	Broken Belt Function
13-5*	States	>Normal operation <	15-04	Over Temp's	16-60	Digital Input	22-61	Broken Belt Torque
13-51	SL Controller Event	>Initialisation<	15-05	Over Volt's	16-61	Terminal 53 Setting	22-62	Broken Belt Delay
13-52	SL Controller Action	Trip Delay at Current Limit	15-06	Reset kWh Counter	16-62	Analog Input 53	30-2*	Adv. Start Adjust
14-0*	Special Functions	Trip Delay at Torque Limit	15-07	Reset Running Hours Counter	16-63	Terminal 54 Setting	30-20	High Starting Torque Time [s]
14-01	Switching Frequency	>Trip<	15-3*	Alarm Log	16-64	Analog Input AI54	30-21	High Starting Torque Current [%]
[1]	>Ran3<	>Warning or trip after warning<	15-31	InternalFault/Reason	16-66	Digital Output	30-22	Locked Rotor Protection
[2]	>2.0 kHz<	>Production Settings	15-4*	Drive Identification	16-67	Pulse Input 29[Hz]	30-23	Locked Rotor Detection Time [s]
[3]	>3.0 kHz<	Service Code	15-41	FC Type	16-68	Pulse Input 33 [Hz]	32-11	User Unit Numerator
[4]	>4.0 kHz<	Current Limit Ctrl.	15-42	Voltage	16-69	Pulse Output 27 [Hz]	32-12	User Unit Denominator
*[5]	>5.0 kHz<	Current Lim Ctrl, Proportional Gain	15-43	Software Version	16-70	Pulse Output 29 [Hz]	32-67	Max. Tolerated Position Error
[6]	>6.0 kHz<	Current Lim Ctrl, Integration Time	15-44	Ordered TypeCode	16-71	Relay Output	32-69	PID Sample Time
[7]	>8.0 kHz<	Current Lim Ctrl, Filter Time	15-45	Actual Typecode String	16-72	Counter A	32-80	Maximum Allowed Velocity
[8]	>10.0 kHz<	Energy Optimising	15-46	Drive Ordering No	16-73	Counter B	32-81	Motion Ctrl Quick Stop Ramp
[9]	>12.0kHz<	VT Level	15-48	LCP Id No	16-8*	Fieldbus & FC Port	33-00	Force Home
[10]	>16.0kHz<	AEO Minimum Magnetisation	15-49	SW ID Control Card	16-80	Fieldbus CTW 1	33-01	Home Offset
14-03	Overmodulation	>40-75% < *66%	15-50	SW ID Power Card	16-82	Fieldbus REF 1	33-02	Home Ramp Time
[0]	>Off<	Environment	15-51	Drive Serial Number	16-84	Comm. Option STW	33-03	Homing Velocity
*[1]	>On<	14-50	RFI Filter	15-52	Power Card Serial Number	16-86	FC Port CTW 1	Home Type
14-07	Dead Time Compensation Level	14-51	DC-Link Voltage Compensation	15-6*	Option Ident	16-9*	Diagnosis Readouts	Negative Software Limit
14-08	Damping Gain Factor	14-52	Fan Control	15-60	Option Mounted	16-90	Alarm Word	Positive Software Limit
14-09	Dead Time Bias Current Level	*[5]	>Constant-on mode<	15-92	Defined Parameters	16-91	Alarm Word 2	Negative Software Limit Active
14-1*	Mains On/Off	[6]	>Constant-off mode<	15-97	Application Type	16-92	Warning Word	Positive Software Limit Active
14-10	Mains Failure	[7]	>On-when-inverter-is-on-else-off Mode<	15-98	Drive Identification	16-93	Warning Word 2	Target Position Window
*[0]	>No function<	[8]	>Variable-speed mode<	15-99	Parameter Metadata	16-94	Ext. Status Word	Motion Control Data Readouts
[1]	>Ctrl. ramp-down<	14-55	Output Filter	16-0*	Data Readouts	16-95	Ext. Status Word 2	PCD 1 Write For Application
[2]	>Ctrl. ramp-down, trip<	14-6*	Auto Derate	16-00	Control Word	17-5*	Feedback Options	PCD 2 Write For Application
[3]	>Coasting<	14-63	Min Switch Frequency	16-01	Reference [Unit]	17-60	Feedback Direction	PCD 3 Write For Application
[4]	>Kinetic back-up<	[2]	>2.0 kHz<	16-02	Reference [%]	17-61	Feedback Signal Monitoring	PCD 4 Write For Application
[5]	>Kinetic back-up, trips<	[3]	>3.0 kHz<	16-03	Status Word	17-1*	Inc. Enc. Interfac	PCD 5 Write For Application
[6]	>Alarm<	[4]	>4.0 kHz<	16-05	Main Actual Value [%]	17-10	Signal Type	PCD 6 Write For Application
[7]	>Kin. back-up, trip w. recovery<	[5]	>5.0 kHz<	16-09	Custom Readout	17-11	Resolution (PPR)	PCD 7 Write For Application
14-11	Mains Voltage at Mains Fault	[6]	>6.0 kHz<	16-10	Power [kW]	17-5*	Resolver Interface	PCD 8 Write For Application
14-12	Function at Mains Imbalance	[7]	>8.0 kHz<	16-11	Power [hp]	17-50	Poles	PCD 9 Write For Application
*[0]	>Trip<	[8]	>10.0 kHz<	16-12	Motor Voltage	17-51	Input Voltage	PCD 10 Write For Application
[1]	>Warning<	[9]	>12.0 kHz<	16-13	Frequency	17-52	Input Frequency	PCD 1 Read For Application
[2]	>Disabled<	[10]	>16.0 kHz<	16-13	Frequency	17-53	Transformation Ratio	PCD 2 Read For Application
[3]	>Derate<					17-56	Encoder Sim. Resolution	PCD 3 Read For Application
14-15	Kin. Backup Trip Recovery Level							

33-24	PCD 4 Read For Application
33-25	PCD 5 Read For Application
33-26	PCD 6 Read For Application
33-27	PCD 7 Read For Application
33-28	PCD 8 Read For Application
33-29	PCD 9 Read For Application
33-30	PCD 10 Read For Application
34-56	Track Error
37-*	Application Settings
37-0*	Application Mode
37-00	Application Mode
37-2*	Central Winder
37-20	Winder Mode Selection
37-21	Tension Set Point
37-22	Taper Set Point
37-23	Partial Roll Diameter Value
37-24	Core1 Diameter
37-25	Core2 Diameter
37-26	Winder Jog Speed
37-27	TLD Low Limit
37-28	TLD High Limit
37-29	TLD Timer
37-30	TLDOnDelay
37-31	Diameter Limit Detector
37-32	Initial Diameter Measurement
37-33	Diameter Measurement Input
37-34	Reading at Core
37-35	Reading at Full Roll
37-36	Tension Set Point Input
37-37	Taper Set Point Input
37-38	Tension Feedback Input
37-39	Tension Feedback Type
37-40	Central Winder Cmd Src
37-41	Diameter Change Rate
37-42	Tapered Tension Change Rate
37-43	Diameter Calculator Min Speed
37-44	Line Acceleration Feed Forward
37-45	Line Speed Source
37-46	Winder Speed Match Scale
37-47	Tension PID Profile
37-48	Tension PID Proportional Gain
37-49	Tension PID Derivate Time
37-50	Tension PID Integral Time
37-51	Tension PID Out Limit
37-52	Tension PID Der Gain Limit
37-53	Tension PID Anti Windup
37-54	Winder Jog Reverse
37-55	Winder Jog Forward
37-56	New Diameter Select
37-57	Tension On/Off
37-58	Core Select
37-59	Diameter Reset

6 Application Examples

The examples in this section are intended as a quick reference for common functionalities.

		Parameters	
FC		Function	Setting
+24 V	12	1-29 Automatic Motor Adaptation (AMA)	[1] Enable complete AMA
D IN	18		
D IN	19	5-12 Terminal 27 Digital Input	[2]* Coast inverse
COM	20		
D IN	27	* = Default value	
D IN	29	Notes/comments: Parameter group 1-2* Motor Data must be set according to motor	
D IN	32	NOTICE	
D IN	33	If terminal 12 and 27 are not connected, set 5-12 to [0]	
D IN	31		
+10 V	50		
A IN	53		
A IN	54		
COM	55		
A OUT	42		
A OUT	45		

Table 6.1 AMA with T27 Connected

		Parameters	
FC		Function	Setting
+24 V	12	6-10 Terminal 53 Low Voltage	0.07 V*
D IN	18		
D IN	19	6-11 Terminal 53 High Voltage	10 V*
COM	20		
D IN	27	6-14 Terminal 53 Low Ref./Feedb. Value	0
D IN	29		
D IN	32	6-15 Terminal 53 High Ref./Feedb. Value	1500
D IN	33		
D IN	31	6-19 Terminal 53 mode	[1] Voltage
+10 V	50		
A IN	53	* = Default value	
A IN	54	Notes/comments:	
COM	55		
A OUT	42		
A OUT	45		

Table 6.2 Analog Speed Reference (Voltage)

		Parameters	
FC		Function	Setting
+24 V	12	6-12 Terminal 53 Low Current	4 mA*
D IN	18		
D IN	19	6-13 Terminal 53 High Current	20 mA*
COM	20		
D IN	27	6-14 Terminal 53 Low Ref./Feedb. Value	0
D IN	29		
D IN	32	6-15 Terminal 53 High Ref./Feedb. Value	1500
D IN	33		
D IN	31	6-19 Terminal 53 mode	[0] current
+10 V	50		
A IN	53	* = Default value	
A IN	54	Notes/comments:	
COM	55		
A OUT	42		
A OUT	45		

Table 6.3 Analog Speed Reference (Current)

		Parameters	
FC		Function	Setting
+24 V	12	5-10 Terminal 18 Digital Input	[8] Start
D IN	18		
D IN	19	5-11 Terminal 19 Digital Input	[10] Reversing*
COM	20		
D IN	27	5-12 Terminal 27 Digital Input	[0] No operation
D IN	29		
D IN	32	5-14 Terminal 32 Digital Input	[16] Preset ref bit 0
D IN	33		
D IN	31	5-15 Terminal 33 Digital Input	[17] Preset ref bit 1
+10 V	50		
A IN	53	3-10 Preset Reference	
A IN	54	Preset ref. 0 25%	
COM	55	Preset ref. 1 50%	
A OUT	42	Preset ref. 2 75%	
A OUT	45	Preset ref. 3 100%	
		* = Default value	
		Notes/comments:	

Table 6.4 Start/Stop with Reversing and 4 Preset Speeds

		Parameters	
FC		Function	Setting
+24 V	12	5-11 Terminal 19 Digital Input	[1] Reset
D IN	18	* = Default value	
D IN	19	Notes/comments:	
COM	20		
D IN	27		
D IN	29		
D IN	32		
D IN	33		
D IN	31		
+10 V	50		
A IN	53		
A IN	54		
COM	55		
A OUT	42		
A OUT	45		

Table 6.5 External Alarm Reset

		Parameters	
FC		Function	Setting
+24 V	12	6-10 Terminal 53 Low Voltage	0.07 V*
D IN	18	6-11 Terminal 53 High Voltage	10 V*
D IN	19	6-14 Terminal 53 Low Ref./Feedb. Value	0
COM	20	6-15 Terminal 53 High Ref./Feedb. Value	1500
D IN	27	6-19 Terminal 53 mode	[1] voltage
D IN	29	* = Default value	
D IN	32	Notes/comments:	
D IN	33		
D IN	31		
+10 V	50		
A IN	53		
A IN	54		
COM	55		
A OUT	42		
A OUT	45		

Table 6.6 Speed Reference (Using a Manual Potentiometer)

		Parameters	
FC		Function	Setting
+24 V	12	4-30 Motor Feedback Loss Function	[1] Warning
D IN	18	4-31 Motor Feedback Speed Error	100
D IN	19	4-32 Motor Feedback Loss Timeout	5 s
COM	20	7-00 Speed PID Feedback Source	[2] MCB 102
D IN	27	17-11 Resolution (PPR)	1024*
D IN	29	13-00 SL Controller Mode	[1] On
D IN	32	13-01 Start Event	[19] Warning
D IN	33	13-02 Stop Event	[44] Reset key
D IN	31	13-10 Comparato r Operand	[21] Warning no.
+10 V	50	13-11 Comparato r Operator	[1] ~*
A IN	53	13-12 Comparato r Value	90
A IN	54	13-51 SL Controller Event	[22] Comparator 0
COM	55	13-52 SL Controller Action	[32] Set digital out A low
A OUT	42	5-40 Function Relay	[80] SL digital output A
A OUT	45	* = Default value	
		Notes/comments:	
		If the limit in the feedback monitor is exceeded, warning 90 is issued. The SLC monitors warning 90 and in the case that warning 90 becomes TRUE then relay 1 is triggered. External equipment may then indicate that service may be required. If the feedback error goes below the limit again within 5 s, the frequency converter continues and the warning disappears. But Relay 1 is still triggered until pressing [Off/Reset].	

Table 6.7 Using SLC to Set a Relay

		Parameters	
		Function	Setting
		5-10 Terminal 18 Digital Input	[8] Start*
		5-12 Terminal 27 Digital Input	[19] Freeze Reference
		5-13 Terminal 29 Digital Input	[21] Speed Up
		5-14 Terminal 32 Digital Input	[22] Speed Down
		* = Default value	
		Notes/comments:	

Table 6.8 Speed Up/Down

		Parameters	
		Function	Setting
		1-90 Motor Thermal Protection	[2] Thermistor trip
		1-93 Thermistor Source	[1] Analog input 53
		6-19 Terminal 53 mode	[1] Voltage
		* = Default value	
		Notes/comments:	
		If only a warning is desired, 1-90 Motor Thermal Protection should be set to [1] Thermistor warning.	

Table 6.9 Motor Thermistor




Illustration 6.1 Speed Up/Down

CAUTION

Thermistors must use reinforced or double insulation to meet PELV insulation requirements.

7 Diagnostics and Troubleshooting

7.1 Warning and Alarm Types

Warning/ alarm type	Description
Warning	A warning indicates an abnormal operating condition that may lead to an alarm. A warning stops when the abnormal condition is removed.
Alarm	An alarm indicates a fault that requires immediate attention. It is always accompanied by a trip or trip lock. The frequency converter must be reset after an alarm. Reset the frequency converter in any of 4 ways: <ul style="list-style-type: none"> • Press [Reset] • Digital reset input command • Serial communication reset input command • Auto reset

Trip

A trip is an action by the frequency converter to suspend operation to prevent damages to the frequency converter and other equipment. When a trip occurs, the motor coasts to a stop. The frequency converter logic continues to operate and monitor the frequency converter status. After the fault condition is remedied, the frequency converter is ready for a reset.

Trip Lock

A trip lock is an action by the frequency converter to suspend operation to prevent damages to the frequency converter and other equipment. When a trip lock occurs, the motor coasts to a stop. The frequency converter logic continues to operate and monitor the frequency converter status. The frequency converter starts a trip lock only when serious faults occur that can damage the frequency converter or other equipments. After the faults are fixed, the input power must be cycled before the reset of the frequency converter.

7.2 Warning and Alarm Displays




Illustration 7.1 Warning and Alarm Displays

An alarm or trip-lock alarm flashes in the display along with the alarm number.




Illustration 7.2 Alarm/Trip Lock Alarm

In addition to the text and alarm code on the frequency converter display, there are 3 status indicator lights. The warning indicator light becomes yellow during an alarm. The alarm indicator light becomes red and flashing during an alarm.




Illustration 7.3 Status Indicator Lights

7.3 Warning and Alarm Code List

An (X) marked in *Table 7.1* means that action occurs. A warning precedes an alarm.

No.	Description	Warning	Alarm	Trip lock	Cause
2	Live zero error	X	X		Signal on terminal 53 or 54 is less than 50% of value set in <i>6-10 Terminal 53 Low Voltage</i> , <i>6-12 Terminal 53 Low Current</i> , <i>6-20 Terminal 54 Low Voltage</i> and <i>6-22 Terminal 54 Low Current</i> .
3	No motor	X			No motor has been connected to the output of the frequency converter.
4	Mains phase loss ¹⁾	X	X	X	Missing phase on supply side, or too high voltage imbalance. Check supply voltage.
7	DC over voltage ¹⁾	X	X		Intermediate circuit voltage exceeds limit.
8	DC under voltage ¹⁾	X	X		Intermediate circuit voltage drops below "voltage warning low" limit.
9	Inverter overloaded	X	X		More than 100% load for too long.
10	Motor ETR over temperature	X	X		Motor is too hot due to more than 100% load for too long.
11	Motor thermistor over temperature	X	X		Thermistor or thermistor connection is disconnected.
12	Torque limit	X	X		Torque exceeds value set in either <i>4-16 Torque Limit Motor Mode</i> or <i>4-17 Torque Limit Generator Mode</i> .
13	Overcurrent	X	X	X	Inverter peak current limit is exceeded.
14	Ground fault	X	X	X	Discharge from output phases to ground.
16	Short circuit		X	X	Short-circuit in motor or on motor terminals.
17	Control word timeout	X	X		No communication to frequency converter.
25	Brake resistor short-circuited	X	X	X	Brake resistor is short-circuited, thus brake function is disconnected.
26	Brake overload	X	X		The power transmitted to the brake resistor over the last 120 s. exceeds the limit. Possible corrections: Decrease brake energy via lower speed or longer ramp time.
27	Brake IGBT/Brake chopper short-circuited	X	X	X	Brake transistor is short-circuited, thus brake function is disconnected.
28	Brake check	X	X		Brake resistor is not connected/working.
30	U phase loss		X	X	Motor phase U is missing. Check the phase.
31	V phase loss		X	X	Motor phase V is missing. Check the phase.
32	W phase loss		X	X	Motor phase W is missing. Check the phase.
34	Fieldbus fault	X	X		Profibus communication issues have occurred.
35	Option fault		X		Field bus or option B detects internal errors.
36	Mains failure	X	X		This warning/alarm is only active if the supply voltage to the frequency converter is lost and <i>14-10 Mains Failure</i> is NOT set to [0] No Function.
38	Internal fault		X	X	Contact the local Danfoss supplier.
40	Overload T27	X			Check the load connected to terminal 27 or remove short-circuit connection.
41	Overload T29	X			Check the load connected to terminal 29 or remove short-circuit connection.
46	Gate drive voltage fault		X	X	
47	24 V supply low	X	X	X	24 V DC may be overloaded.
51	AMA check U_{nom} and I_{nom}		X		Wrong setting for motor voltage and/or motor current.
52	AMA low I_{nom}		X		Motor current is too low. Check settings.
53	AMA big motor		X		The motor is too big for the AMA to operate.

No.	Description	Warning	Alarm	Trip lock	Cause
54	AMA small motor		X		The motor is too small for the AMA to operate.
55	AMA parameter range		X		The parameter values of the motor are outside of the acceptable range. AMA will not run.
56	AMA interrupt		X		The user has interrupted the AMA.
57	AMA timeout		X		
58	AMA internal		X		Contact Danfoss.
59	Current limit	X	X		Frequency converter overload.
61	Encoder loss	X	X		
63	Mechanical brake low		X		Actual motor current has not exceeded "release brake" current within "start delay" time window.
65	Control card temp	X	X	X	The cut-out temperature of the control card is 80 °C.
67	Option change		X		A new option is detected or a mounted option is removed.
69	Power card temp	X	X	X	
80	Drive initialised to default value		X		All parameter settings are initialised to default settings.
87	Auto DC braking	X			Occurs in IT mains when the frequency converter coasts and V DC is higher than 830 V. Energy on DC link is consumed by the motor. This function can be enabled/disabled in 0-07 Auto DC Braking.
88	Option detection		X	X	Option is removed successfully.
90	Feedback monitor	X	X		Feedback fault is detected by option B.
95	Broken belt	X	X		
101	Flow/pressure information missing		X	X	
120	Position control fault		X		
250	New spare part		X	X	
251	New type code		X	X	
252	Tension limit		X		
nw run	Not while running				Parameter can only be changed when the motor is stopped.
Err.	A wrong password was entered				Occurs when using a wrong password for changing a password-protected parameter.

Table 7.1 Warnings and Alarms Code List

1) These faults may be caused by mains distortions. Installing a Danfoss line filter may rectify this problem.

The alarm words, warning words and extended status words can be read out via serial bus or optional fieldbus for diagnosis.

7.4 Error Code List

LCP-related errors are displayed in the format of **Err XX**, where XX indicates the error number.

Error number	Description
84	The connection between frequency converter and LCP is lost.
85	One of the LCP keys has been disabled via parameters in parameter group <i>0-4* LCP Keypad</i> .
86	Data copy failure: Occurs when data is copied from frequency converter to LCP, or from LCP to frequency converter (<i>0-50 LCP Copy</i>).
87	Invalid LCP data: Occurs when data is being copied from LCP to frequency converter (<i>0-50 LCP Copy</i>).
88	LCP data incompatible: Occurs when data is being copied from LCP to frequency converter (<i>0-50 LCP Copy</i>), typically because data is moved between frequency converters that have major software differences.
89	An operation is issued via LCP to write a value to a parameter that is read-only.
90	LCP, serial communication, or field bus communication attempt to update the same parameters at the same time.

Table 7.2 Error Code List

7.5 Troubleshooting

Symptom	Possible cause	Test	Solution
Motor not running	LCP stop	Check if [Off] has been pressed.	Press [Auto On] or [Hand On] (depending on operation mode) to run the motor.
	Missing start signal (standby)	Check <i>5-10 Terminal 18 Digital Input</i> for correct setting for terminal 18 (use default setting).	Apply a valid start signal to start the motor.
	Motor coast signal active (coasting)	Check <i>5-12 Terminal 27 Digital Input</i> . for correct setting for terminal 27 (use default setting).	Apply 24 V on terminal 27 or program this terminal to <i>No operation</i> .
	Wrong reference signal source	Check the following: <ul style="list-style-type: none"> The reference signal is local, remote or bus reference? Preset reference is active? Terminal connection is correct? The scaling of terminals is correct? The reference signal is available? 	Program correct settings. Set preset reference active in parameter group <i>3-1* References</i> . Check for correct wiring. Check scaling of terminals. Check reference signal.
Motor is running in the wrong direction	Motor rotation limit	Check that <i>4-10 Motor Speed Direction</i> is programmed correctly.	Program correct settings.
	Active reversing signal	Check if a reversing command is programmed for the terminal in parameter group <i>5-1* Digital inputs</i> .	Deactivate reversing signal.
	Wrong motor phase connection	Change <i>1-06 Clockwise Direction</i>	
Motor is not reaching maximum speed	Frequency limits are set incorrectly	Check output limits in <i>4-14 Motor Speed High Limit [Hz]</i> and <i>4-19 Max Output Frequency</i>	Program correct limits.
	Reference input signal not scaled correctly	Check reference input signal scaling in <i>6-** Analog I/O mode</i> and parameter group <i>3-1* References</i> .	Program correct settings.

Symptom	Possible cause	Test	Solution
Motor speed is unstable	Possible incorrect parameter settings	Check the settings of all motor parameters, including all motor compensation settings. For closed loop operation, check PID settings.	Check settings in parameter group 6-** <i>Analog I/O mode</i> .
Motor runs roughly	Possible over-magnetisation	Check for incorrect motor settings in all motor parameters.	Check motor settings in parameter groups 1-2* <i>Motor data</i> , 1-3* <i>Adv motor data</i> , and 1-5* <i>Load indep. setting</i> .
Motor will not brake	Possible incorrect settings in the brake parameters. Possible too short ramp-down times.	Check brake parameters. Check ramp time settings.	Check parameter group 2-0* <i>DC brake</i> and 3-0* <i>Reference limits</i> .
Open power fuses or circuit breaker trip	Phase to phase short	Motor or panel has a short phase to phase. Check motor and panel phase for shorts.	Eliminate any shorts detected.
	Motor overload	Motor is overloaded for the application.	Perform the startup test and verify motor current is within specifications. If motor current is exceeding nameplate full load current, the motor may run only with reduced load. Review the specifications for the application.
	Loose connections	Perform pre-startup check for loose connections.	Tighten loose connections.
Mains current imbalance greater than 3%	Problem with mains power (See <i>Alarm 4 Mains phase loss</i> description)	Rotate input power leads into the frequency converter 1 position: A to B, B to C, C to A.	If the imbalanced leg follows the wire, it is a power problem. Check mains power supply.
	Problem with the frequency converter unit	Rotate input power leads into the frequency converter 1 position: A to B, B to C, C to A.	If the imbalanced leg stays on same input terminal, it is a problem with the unit. Contact the supplier.
Motor current imbalance greater than 3%	Problem with motor or motor wiring	Rotate output motor leads 1 position: U to V, V to W, W to U.	If the imbalanced leg follows the wire, the problem is in the motor or motor wiring. Check motor and motor wiring.
	Problem with the frequency converter unit	Rotate output motor leads one position: U to V, V to W, W to U.	If the imbalanced leg stays on same output terminal, it is a problem with the unit. Contact the supplier.
Acoustic noise or vibration (e.g. a fan blade is making noise or vibrations at certain frequencies)	Resonances, e.g. in the motor/fan system	Bypass critical frequencies by using parameters in parameter group 4-6* <i>Speed Bypass</i> .	Check if noise and/or vibration have been reduced to an acceptable limit.
		Turn off over-modulation in 14-03 <i>Overmodulation</i> .	
		Increase resonance dampening in 1-64 <i>Resonance Dampening</i> .	

Table 7.3 Troubleshooting

8 Specifications

8.1 Mains Supply 3x380–480 V AC

Frequency converter typical shaft output [kW]	HK37 0.37	HK55 0.55	HK75 0.75	H1K1 1.1	H1K5 1.5	H2K2 2.2	H3K0 3	H4K0 4	H5K5 5.5	H7K5 7.5
Enclosure IP20	J1	J1	J1	J1	J1	J1	J2	J2	J2	J3
Output current										
Shaft output [kW]	0.37	0.55	0.75	1.1	1.5	2.2	3	4	5.5	7.5
Continuous (3x380–440 V) [A]	1.2	1.7	2.2	3	3.7	5.3	7.2	9	12	15.5
Continuous (3x441–480 V) [A]	1.1	1.6	2.1	2.8	3.4	4.8	6.3	8.2	11	14
Intermittent (60 s overload) [A]	1.9	2.7	3.5	4.8	5.9	8.5	11.5	14.4	19.2	24.8
Continuous kVA (400 V AC) [kVA]	0.84	1.18	1.53	2.08	2.57	3.68	4.99	6.24	8.32	10.74
Continuous kVA (480 V AC) [kVA]	0.9	1.3	1.7	2.5	2.8	4.0	5.2	6.8	9.1	11.6
Maximum input current										
Continuous (3x380–440 V) [A]	1.2	1.6	2.1	2.6	3.5	4.7	6.3	8.3	11.2	15.1
Continuous (3x441–480 V) [A]	1.0	1.2	1.8	2.0	2.9	3.9	4.3	6.8	9.4	12.6
Intermittent (60 s overload) [A]	1.9	2.6	3.4	4.2	5.6	7.5	10.1	13.3	17.9	24.2
Additional specifications										
Maximum cable cross section (mains, motor, brake and load sharing) [mm ² /AWG] ²⁾	4 mm ²									
Estimated power loss at rated maximum load [W] ³⁾	20.88	25.16	30.01	40.01	52.91	73.97	94.81	115.5	157.54	192.83
Weight, enclosure IP20	2.3	2.3	2.3	2.3	2.3	2.5	3.6	3.6	3.6	4.1
Efficiency [%] ⁴⁾	96.2	97.0	97.2	97.4	97.4	97.6	97.5	97.6	97.7	98.0

8

Table 8.1 Mains Supply 3x380–480 V AC - Heavy Duty¹⁾

Frequency converter typical shaft output [kW]	H11K 11	H15K 15	H18K 18.5	H22K 22	H30K 30	H37K 37	H45K 45	H55K 55	H75K 75	
IP20	J4	J4	J5	J5	J6	J6	J6	J7	J7	
Output current										
Continuous (3x380–440 V) [A]	23	31	37	42.5	61	73	90	106	147	
Continuous (3x441–480 V) [A]	21	27	34	40	52	65	77	96	124	
Intermittent (60 s overload) [A]	34.5	46.5	55.5	63.8	91.5	109.5	135	159	220.5	
Continuous kVA (400 V AC) [kVA]	15.94	21.48	25.64	29.45	42.3	50.6	62.4	73.4	101.8	
Continuous kVA (480 V AC) [kVA]	17.5	22.4	28.3	33.3	43.2	54.0	64.0	79.8	103.1	
Maximum input current										
Continuous (3x380–440 V) [A]	22.1	29.9	35.2	41.5	57	70.3	84.2	102.9	140.3	
Continuous (3x441–480 V) [A]	18.4	24.7	29.3	34.6	49.3	60.8	72.7	88.8	121.1	
Intermittent (60 s overload) [A]	33.2	44.9	52.8	62.3	85.5	105.5	126.3	154.4	210.5	
Additional specifications										
Maximum cable size (mains, motor, brake) [mm ² /AWG] ²⁾	16 mm ²			50 mm ²				85 mm ²		
Estimated power loss at rated maximum load [W] ³⁾	289.53	393.36	402.83	467.52	630	848	1175	1250	1507	
Weight enclosure IP20 [kg]	9.4	9.5	12.3	12.5	22.4	22.5	22.6	37.3	38.7	
Efficiency [%] ⁴⁾	97.8	97.8	98.1	97.9	98.1	98.0	97.7	98.0	98.2	

Table 8.2 Mains Supply 3x380–480 V AC - Heavy Duty¹⁾

Frequency converter typical shaft output [kW]	Q11K	Q15K	Q18K	Q22K	Q30K	Q37K	Q45K	Q55K	Q75K
IP20	J4	J4	J5	J5	J6	J6	J6	J7	J7
Output current									
Continuous (3x380–440 V) [A]	23	31	37	42.5	61	73	90	106	147
Continuous (3x441–480 V) [A]	21	27	34	40	52	65	77	96	124
Intermittent (60 s overload) [A]	25.3	34.1	40.7	46.8	67.1	80.3	99	116.6	161.7
Continuous kVA (400 V AC) [kVA]	15.94	21.48	25.64	29.45	42.3	50.6	62.4	73.4	101.8
Continuous kVA (480 V AC) [kVA]	17.5	22.4	28.3	33.3	43.2	54.0	64.0	79.8	103.1
Maximum input current									
Continuous (3x380–440 V) [A]	22.1	29.9	35.2	41.5	57	70.3	84.2	102.9	140.3
Continuous (3x441–480 V) [A]	18.4	24.7	29.3	34.6	49.3	60.8	72.7	88.8	121.1
Intermittent (60 s overload) [A]	24.3	32.9	38.7	45.7	62.7	77.3	92.6	113.2	154.3
Additional specifications									
Maximum cable size (mains, motor, brake) [mm ² /AWG] ²⁾	16 mm ²			50 mm ²				85 mm ²	
Estimated power loss at rated maximum load [W] ³⁾	289.53	393.36	402.83	467.52	630	848	1175	1250	1507
Weight enclosure IP20 [kg]	9.4	9.5	12.3	12.5	22.4	22.5	22.6	37.3	38.7
Efficiency [%] ⁴⁾	97.8	97.8	98.1	97.9	98.1	98.0	97.7	98.0	98.2

Table 8.3 Mains Supply 3x380–480 V AC - Normal Duty¹⁾

1) Heavy duty=150–160% current during 60 s, Normal duty=110% current during 60 s.

2) American Wire Gauge.

3) The typical power loss is at nominal load conditions and expected to be within $\pm 15\%$ (tolerance relates to variety in voltage and cable conditions).

Values are based on a typical motor efficiency (IE2/IE3 border line). Motors with lower efficiency add to the power loss in the frequency converter and motors with high efficiency reduce power loss.

Applies for dimensioning of frequency converter cooling. If the switching frequency is higher than the default setting, the power losses may rise. LCP and typical control card power consumptions are included. Further options and customer load may add up to 30 W to the losses. (Though typical only 4 W extra for a fully loaded control card, or field bus, or options for slot B).

For power loss data according to EN 50598-2, refer to www.danfoss.com/vlteneregyefficiency

4) Measured using 5 m screened motor cables at rated load and rated frequency for enclosure types J1–J5, and using 33 m screened motor cables at rated load and rated frequency for enclosure types J6 and J7. For energy efficiency class, see chapter 8.2.1 Ambient Conditions. For part load losses, see www.danfoss.com/vlteneregyefficiency.

8.2 General Technical Data

Mains supply (L1, L2, L3)

Supply terminals	L1, L2, L3
Supply voltage	380-480 V: -15% (-25%) ¹⁾ to +10%

1) The frequency converter can run at -25% input voltage with reduced performance. The maximum output power of the frequency converter is 75% in case of -25% input voltage and 85% in case of -15% input voltage.

Full torque cannot be expected at mains voltage lower than 10% below the frequency converter's lowest rated supply voltage.

Supply frequency	50/60 Hz \pm 5%
Maximum imbalance temporary between mains phases	3.0 % of rated supply voltage
True power factor (λ)	\geq 0.9 nominal at rated load
Displacement power factor (cos ϕ)	near unity ($>$ 0.98)
Switching on input supply L1, L2, L3 (power-ups) \leq 7.5 kW	maximum 2 times/minute
Switching on input supply L1, L2, L3 (power-ups) 11-75 kW	maximum 1 time/minute

The unit is suitable for use on a circuit capable of delivering not more than 100,000 RMS symmetrical Amperes, 480 V maximum.

Motor output (U, V, W)

Output voltage	0-100% of supply voltage
Output frequency	0-500 Hz
Output frequency in VVC ⁺ Mode	0-200 Hz
Switching on output	Unlimited
Ramp times	0.05-3600 s

Torque characteristics

Starting torque (constant torque)	maximum 160% for 60 s ¹⁾
Overload torque (constant torque)	maximum 160% for 60 s ¹⁾
Starting torque (variable torque)	maximum 110% for 60 s ¹⁾
Overload torque (variable torque)	maximum 110% for 60 s
Starting current	maximum 200% for 1 s
Torque rise time in VVC ⁺ (independent of f_{sw})	10 ms

1) Percentage relates to the nominal torque.

2) The torque response time depends on application and load, but, as a general rule, the torque step from 0 to reference is 4-5 x torque rise time.

Cable lengths and cross sections¹⁾

Maximum motor cable length, screened	50 m
Maximum motor cable length, unscreened	0.37-22 kW: 75 m, 30-75 kW: 100 m
Maximum cross section to control terminals, flexible/rigid wire	2.5 mm ² /14 AWG
Minimum cross section to control terminals	0.55 mm ² / 30 AWG

1) For power cables, see Table 8.1 to Table 8.3.

Digital inputs

Programmable digital inputs	7
Terminal number	18, 19, 27 ¹⁾ , 29 ¹⁾ , 32, 33, 31
Logic	PNP or NPN
Voltage level	0-24 V DC
Voltage level, logic '0' PNP	< 5 V DC
Voltage level, logic '1' PNP	> 10 V DC
Voltage level, logic '0' NPN	> 19 V DC
Voltage level, logic '1' NPN	< 14 V DC
Maximum voltage on input	28 V DC
Pulse frequency range	4 Hz-32 kHz
(Duty cycle) minimum pulse width	4.5 ms
Input resistance, R_i	approximately 4 k Ω

1) Terminals 27 and 29 can also be programmed as output.

Analog inputs

Number of analog inputs	2
Terminal number	53, 54
Modes	Voltage or current
Mode select	software
Voltage level	0–10 V
Input resistance, R_i	approximately 10 k Ω
Maximum voltage	-15 to +20 V
Current level	0/4 to 20 mA (scaleable)
Input resistance, R_i	approximately 200 Ω
Maximum current	30 mA
Resolution for analog inputs	11 bit
Accuracy of analog inputs	Maximum error 0.5% of full scale
Bandwidth	100 Hz

The analog inputs are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.




Illustration 8.1 Analog Inputs

Pulse inputs

Programmable pulse inputs	2
Terminal number pulse	29, 33
Maximum frequency at terminal, 29, 33	32 kHz (Push-pull driven)
Maximum frequency at terminal, 29, 33	5 kHz (open collector)
Minimum frequency at terminal 29, 33	4 Hz
Voltage level	see section on digital input
Maximum voltage on input	28 V DC
Input resistance, R_i	approximately 4 k Ω
Pulse input accuracy (0.1–1 kHz)	Maximum error: 0.1% of full scale
Pulse input accuracy (1–32 kHz)	Maximum error: 0.05% of full scale

Analog outputs

Number of programmable analog outputs	2
Terminal number	45, 42
Current range at analog output	0/4–20 mA
Maximum resistor load to common at analog output	500 Ω
Accuracy on analog output	Maximum error: 0.8 % of full scale
Resolution on analog output	10 bit

The analog output is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Control card, RS-485 serial communication

Terminal number	68 (P,TX+, RX+), 69 (N,TX-, RX-)
Terminal number 61	Common for terminals 68 and 69

The RS-485 serial communication circuit is functionally seated from other central circuits and galvanically isolated from the supply voltage (PELV).

Digital outputs

Programmable digital/pulse outputs	2
Terminal number	27, 29 ¹⁾
Voltage level at digital/frequency output	0–24 V
Maximum output current (sink or source)	40 mA
Maximum load at frequency output	1 k Ω
Maximum capacitive load at frequency output	10 nF
Minimum output frequency at frequency output	4 Hz
Maximum output frequency at frequency output	32 kHz
Accuracy of frequency output	Maximum error: 0.1 % of full scale
Resolution of frequency output	10 bit

1) Terminal 27 and 29 can also be programmed as input.

The digital output is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Control card, 24 V DC output

Terminal number	12
Maximum load	100 mA

The 24 V DC supply is galvanically isolated from the supply voltage (PELV), but has the same potential as the analog and digital inputs and outputs.

Relay outputs

Programmable relay outputs	2
Relay 01 and 02	01–03 (NC), 01–02 (NO), 04–06 (NC), 04–05 (NO)
Maximum terminal load (AC-1) ¹⁾ on 01–02/04–05 (NO) (Resistive load)	250 V AC, 3 A
Maximum terminal load (AC-15) ¹⁾ on 01–02/04–05 (NO) (Inductive load @ $\cos\phi$ 0.4)	250 V AC, 0.2 A
Maximum terminal load (DC-1) ¹⁾ on 01–02/04–05 (NO) (Resistive load)	30 V DC, 2 A
Maximum terminal load (DC-13) ¹⁾ on 01–02/04–05 (NO) (Inductive load)	24 V DC, 0.1 A
Maximum terminal load (AC-1) ¹⁾ on 01–03/04–06 (NC) (Resistive load)	250 V AC, 3 A
Maximum terminal load (AC-15) ¹⁾ on 01–03/04–06 (NC) (Inductive load @ $\cos\phi$ 0.4)	250 V AC, 0.2 A
Maximum terminal load (DC-1) ¹⁾ on 01–03/04–06 (NC) (Resistive load)	30 V DC, 2 A
Minimum terminal load on 01–03 (NC), 01–02 (NO)	24 V DC 10 mA, 24 V AC 20 mA

1) IEC 60947 t 4 and 5

The relay contacts are galvanically isolated from the rest of the circuit by reinforced isolation.

Control card, +10 V DC output

Terminal number	50
Output voltage	10.5 V \pm 0.5 V
Maximum load	15 mA

The 10 V DC supply is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Control characteristics

Resolution of output frequency at 0–500 Hz	\pm 0.003 Hz
System response time (terminals 18, 19, 27, 29, 32, 33)	\leq 2 ms
Speed control range (open loop)	1:100 of synchronous speed
Speed accuracy (open loop)	\pm 0.5% of nominal speed
Speed accuracy (close loop)	\pm 0.1% of nominal speed

All control characteristics are based on a 4-pole asynchronous motor.

Ambient Conditions

Enclosure types J1–J7	IP20
Vibration test, all enclosure types	1.0 g
Relative humidity	5–95% (IEC 721-3-3; Class 3K3 (non-condensing) during operation
Aggressive environment (IEC 60068-2-43) H ₂ S test	class Kd
Test method according to IEC 60068-2-43 H ₂ S (10 days)	
Ambient temperature (at 60 AVM switching mode)	
- with derating	maximum 55 °C ¹⁾
- at full continuous output current with some power size	maximum 50 °C ¹⁾
- at full continuous output current	maximum 45 °C ¹⁾
Minimum ambient temperature during full-scale operation	0 °C
Minimum ambient temperature at reduced performance	- 10 °C
Temperature during storage/transport	-25 to +65/70 °C
Maximum altitude above sea level without derating	1000 m
Maximum altitude above sea level with derating	3000 m
EMC standards, emission	EN 61800-3, EN 61000-3-2, EN 61000-3-3, EN 61000-3-11, EN 61000-3-12, EN 61000-6-3/4, EN 55011, IEC 61800-3 EN 61800-3, EN 61000-6-1/2, EN 61000-4-2,
EMC standards, immunity	EN 61000-4-3, EN 61000-4-4, EN 61000-4-5, EN 61000-4-6
Energy efficiency class ²⁾	IE2

1) For details about derating for high ambient temperature, refer to the *Design Guide*.

2) Determined according to EN50598-2 at:

- Rated load
- 90% rated frequency
- Switching frequency factory setting
- Switching pattern factory setting

Control card performance

Scan interval	1 ms
---------------	------

Protection and features

- Electronic thermal motor protection against overload.
- Temperature monitoring of the heatsink ensures that the frequency converter trips if the temperature reaches a predefined level. An overload temperature cannot be reset until the temperature of the heatsink is below the temperature limit. For details of these limits and level, refer to the *Design Guide*.
- The frequency converter is protected against short-circuits on motor terminals U, V, W.
- If a mains phase is missing, the frequency converter trips or issues a warning (depending on the load and parameter setting).
- Monitoring of the intermediate circuit voltage ensures that the frequency converter trips if the intermediate circuit voltage is too low or too high.
- The frequency converter is protected against earth faults on motor terminals U, V, W.

8.3 Fuses

8.3.1 Introduction

Use fuses and/or circuit breakers on the supply side to protect service personnel and equipment from injuries and damage in case of component breakdown inside the frequency converter (first fault).

⚠ WARNING

Personnel and property must be protected in case of internal component breakdown in the frequency converter.

Branch circuit protection

All branch circuits in an installation, switch gear, machines etc. must be protected against short circuit and overcurrent according to national/international regulations.

NOTICE

The recommendations do not cover branch circuit protection for UL.

Table 8.4 lists the recommended fuses that have been tested.

If fuses are selected according to recommendations, possible damages on the frequency converter can be limited to inside the unit.

⚠ WARNING

Malfunction or failing to follow the recommendation may result in personnel risk and damage to the frequency converter and other equipment.

8.3.2 CE Compliance

NOTICE

Using fuses or circuit breakers is mandatory to ensure compliance with IEC 60364 for CE.

Danfoss recommends using the fuses in Table 8.4 on a circuit capable of delivering 100,000 A_{rms} (symmetrical), 380–480 V depending on the frequency converter voltage rating. With the proper fusing, the frequency converter short circuit current rating (SCCR) is 100,000 A_{rms}.

Enclosure type	Power [kW]	CE compliance fuse
J1	0.37–1.1	gG-10
	1.5	
	2.2	
J2	3.0	gG-25
	4.0	
	5.5	
J3	7.5	gG-32
J4	11–15	gG-50
J5	18.5	gG-80
	22	
J6	30	gG-125
	37	
	45	
J7	55	aR-250
	75	

Table 8.4 CE Fuse, 380–480 V, Enclosure Types J1–J7

8.4 Connection Tightening Torques

Make sure to use the right torques when tightening all electrical connections. Too low or too high torque results in a bad electrical connection. Use a torque wrench to ensure correct torques are applied.

Enclosure type	Power [kW]	Torque [Nm]					
		Mains	Motor	DC connection	Brake	Ground	Relay
J1	0.37–2.2	0.8	0.8	0.8	0.8	3	0.5
J2	3.0–5.5	0.8	0.8	0.8	0.8	3	0.5
J3	7.5	0.8	0.8	0.8	0.8	3	0.5
J4	11–15	1.2	1.2	1.2	1.2	1.6	0.5
J5	18.5–22	1.2	1.2	1.2	1.2	1.6	0.5
J6	30–45	3.5	3.5	3.5	-	2.5	0.5
J7	55	12	12	12	-	2.5	0.5
J7	75	14	14	14	-	2.5	0.5

Table 8.5 Tightening Torques

Index

A

AC waveform..... 3
 AMA with T27 connected..... 37
 Ambient condition..... 50
 Analog input..... 48
 Analog output..... 48
 Application example..... 37
 Approval..... 3
 Automatic motor adaptation..... 14

B

Branch circuit protection..... 51

C

Cable length..... 47
 Clearance requirement..... 15
 Control cable..... 21
 Control card performance..... 50
 Control card, 24 V DC output..... 49
 Control card, RS-485 serial communication..... 48
 Control characteristic..... 49
 Control system..... 3
 Control terminal..... 42
 Control wiring..... 18
 Cross section..... 47

D

Derating..... 15, 50
 Digital input..... 14, 47
 Digital output..... 49
 Discharge time..... 7

E

Electrical noise..... 18
 EMC..... 50
 Energy efficiency..... 45, 46
 Energy efficiency class..... 50
 External controller..... 3
 External interlock..... 14

F

Floating delta..... 19
 Fuse..... 51

G

Ground connection..... 18
 Ground loop..... 21
 Ground wire..... 18, 19
 Grounded delta..... 19
 Grounding..... 18, 20

H

High altitude..... 8
 High voltage..... 7

I

IEC 61800-3..... 19, 50
 Induced voltage..... 18
 Input power..... 18
 Input signal..... 21
 Installation..... 15
 Isolated mains..... 19

L

Leakage current..... 8, 18
 Load sharing..... 7

M

Main menu..... 25
 Mains supply (L1, L2, L3)..... 47
 Mains supply data..... 45
 Menu key..... 23
 Motor cable..... 18, 19
 Motor current..... 14
 Motor Data..... 14
 Motor output..... 47
 Motor power..... 18
 Motor protection..... 18, 50
 Motor status..... 3
 Motor wiring..... 18, 19
 Multiple frequency converter..... 19

N

Navigation key..... 23
 Noise isolation..... 18
 Numeric display..... 23

O

Open loop..... 49

Operation key..... 23
 Optional equipment..... 3, 20
 Output current..... 49
 Overload protection..... 18

P

PELV..... 8, 39, 49
 Power connection..... 18
 Power factor..... 19
 Profibus..... 30
 Programming..... 14
 Protection and feature..... 50
 Pulse input..... 48

Q

Qualified personnel..... 7
 Quick menu..... 27

R

RCD..... 19
 Relay output..... 49
 Remote command..... 3
 Reset..... 40, 50
 RFI filter..... 19

S

Safety..... 8
 Screened control cable..... 21
 Serial bus..... 42
 Serial communication..... 3, 21, 22, 40
 Shielded cable..... 18
 Specification..... 15, 22, 45
 Speed reference..... 37
 Supply voltage..... 48
 System feedback..... 3

T

Technical Data..... 47
 Terminal programming..... 21
 Terminal tightening torque..... 52
 Thermistor..... 39
 Torque characteristic..... 47
 Trip function..... 18
 Troubleshooting..... 40

U

Unintended start..... 7

V

Voltage level..... 47

W

Warning and alarm list..... 42
 Wire size..... 18



www.danfoss.com/fc360

.....
Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.
.....

Danfoss A/S
Ulsnaes 1
DK-6300 Graasten
www.danfoss.com/drives

