



Instruction Manual

VLT[®] Midi Drive FC 280



Contents

1 Introduction	3
1.1 Purpose of the Manual	3
1.2 Additional Resources	3
1.3 Document and Software Version	3
1.4 Product Overview	3
1.5 Approvals and Certifications	4
1.6 Disposal	4
2 Safety	5
2.1 Safety Symbols	5
2.2 Qualified Personnel	5
2.3 Safety Precautions	5
3 Mechanical Installation	7
3.1 Unpacking	7
3.2 Installation Environment	7
3.3 Mounting	7
4 Electrical Installation	10
4.1 Safety Instructions	10
4.2 EMC-compliant Installation	10
4.3 Grounding	10
4.4 Wiring Schematic	12
4.5 Access	14
4.6 Motor Connection	14
4.7 AC Line Input Connection	15
4.8 Control Wiring	15
4.9 Installation Checklist	19
5 Commissioning	20
5.1 Safety Instructions	20
5.2 Applying Power	20
5.3 Local Control Panel Operation	20
5.4 Basic Programming	28
5.5 Checking Motor Rotation	30
5.6 Checking Encoder Rotation	30
5.7 Local Control Test	30
5.8 System Start-up	31
5.9 STO Commissioning	31

6 Safe Torque Off (STO)	32
6.1 Safety Precautions for STO	33
6.2 Safe Torque Off Installation	33
6.3 STO Commissioning	34
6.4 Maintenance and Service for STO	35
6.5 STO Technical Data	37
7 Application Examples	38
8 Maintenance, Diagnostics and Troubleshooting	42
8.1 Maintenance and Service	42
8.2 Warning and Alarm Types	42
8.3 Warning and Alarm Display	42
8.4 List of Warnings and Alarms	44
8.5 Troubleshooting	46
9 Specifications	48
9.1 Electrical Data	48
9.2 Line Power Supply (3-phase)	50
9.3 Motor Output and Motor Data	50
9.4 Ambient Conditions	50
9.5 Cable Specifications	51
9.6 Control Input/Output and Control Data	51
9.7 Connection Tightening Torques	54
9.8 Fuses and Circuit Breakers	54
9.9 Enclosure Sizes, Power Ratings and Dimensions	55
10 Appendix	56
10.1 Symbols, Abbreviations and Conventions	56
10.2 Parameter Menu Structure	56
Index	62

1 Introduction

1.1 Purpose of the Manual

This instruction manual provides information for safe installation and commissioning of the VLT® Midi Drive FC 280 adjustable frequency drive.

This instruction manual is intended for use by qualified personnel.

To use the adjustable frequency drive safely and professionally, read and follow the instruction manual. Pay particular attention to the safety instructions and general warnings. Always keep this instruction manual with the adjustable frequency drive.

VLT® is a registered trademark.

1.2 Additional Resources

Resources available to understand advanced adjustable frequency drive functions and programming:

- VLT® Midi Drive FC 280 Design Guide.
- VLT® Midi Drive FC 280 Programming Guide.

Supplementary publications and manuals are available from Danfoss. See vlt-drives.danfoss.com/Support/Technical-Documentation/ for listings.

1.3 Document and Software Version

This manual is regularly reviewed and updated. All suggestions for improvement are welcome. *Table 1.1* shows the document version and the corresponding software version.

Edition	Remarks	Software version
MG07A1	The first edition of this manual	1.0

Table 1.1 Document and Software Version

1.4 Product Overview

1.4.1 Intended Use

The adjustable frequency drive is an electronic motor controller intended for:

- Regulation of motor speed in response to system feedback or to remote commands from external controllers. A power drive system consists of the

adjustable frequency drive, the motor and equipment driven by the motor.

- System and motor status surveillance.

The adjustable frequency drive can also be used for motor protection.

Depending on configuration, the adjustable frequency drive can be used in standalone applications or form part of a larger appliance or installation.

The adjustable frequency drive is allowed for use in residential, industrial and commercial environments in accordance with local laws and standards.

NOTICE!

In a residential environment, this product can cause radio interference, in which case supplementary mitigation measures can be required.

Foreseeable misuse

Do not use the adjustable frequency drive in applications which are non-compliant with specified operating conditions and environments. Ensure compliance with the conditions specified in *chapter 9 Specifications*.

1.4.2 Block Diagram of the Adjustable Frequency Drive

Figure 1.1 is a block diagram of the internal components of the adjustable frequency drive. See *Table 1.2* for their functions.




Figure 1.1 Adjustable Frequency Drive Block Diagram

Area	Component	Functions
1	Line power input	<ul style="list-style-type: none"> AC line power supply to the adjustable frequency drive.
2	Rectifier	<ul style="list-style-type: none"> The rectifier bridge converts the AC input to DC current to supply inverter power.
3	DC bus	<ul style="list-style-type: none"> Intermediate DC bus circuit handles the DC current.
4	DC reactor	<ul style="list-style-type: none"> Filters the intermediate DC circuit current. Provides line transient protection. Reduces the root mean square (RMS) current. Raises the power factor reflected back to the line. Reduces harmonics on the AC input.
5	Capacitor bank	<ul style="list-style-type: none"> Stores the DC power. Provides ride-through protection for short power losses.
6	Inverter	<ul style="list-style-type: none"> Converts the DC into a controlled PWM AC waveform for a controlled variable output to the motor.
7	Output to motor	<ul style="list-style-type: none"> Regulated 3-phase output power to the motor.
8	Control circuitry	<ul style="list-style-type: none"> Input power, internal processing, output and motor current are monitored to provide efficient operation and control. User interface and external commands are monitored and performed. Status output and control can be provided.

Table 1.2 Legend to Figure 1.1

1.4.3 Enclosure Sizes and Power Ratings

For enclosure sizes and power ratings of the adjustable frequency drives, refer to *chapter 9.9 Enclosure Sizes, Power Ratings and Dimensions*.

1.4.4 Safe Torque Off (STO)

The VLT® Midi Drive FC 280 adjustable frequency drive supports Safe Torque Off (STO). See *chapter 9.9 Enclosure Sizes, Power Ratings and Dimensions* for details about the installation, commissioning, maintenance and technical data of STO.

1.5 Approvals and Certifications




For compliance with the European Agreement concerning International Carriage of Dangerous Goods by Inland Waterways (ADN), refer to *ADN-compliant Installation* in the VLT® Midi Drive FC 280 *Design Guide*.

Applied standards and compliance for STO

Use of STO on terminals 37 and 38 requires that the user satisfies all provisions for safety including relevant laws, regulations and guidelines. The integrated STO function complies with the following standards:

- IEC/EN 61508: 2010 SIL 2
- IEC/EN 61800-5-2: 2007 SIL2
- IEC/EN 62061: 2012 SILCL of SIL2
- EN ISO 13849-1: 2008 Category 3 PL d

1.6 Disposal



2 Safety

2.1 Safety Symbols

The following symbols are used in this document:

⚠ WARNING

Indicates a potentially hazardous situation that could result in death or serious injury.

⚠ CAUTION

Indicates a potentially hazardous situation that could result in minor or moderate injury. It can also be used to alert against unsafe practices.

NOTICE!

Indicates important information, including situations that can result in damage to equipment or property.

2.2 Qualified Personnel

Correct and reliable transport, storage, installation, operation and maintenance are required for the trouble-free and safe operation of the frequency converter. Only qualified personnel are allowed to install or operate this equipment.

Qualified personnel are defined as trained staff who are authorized to install, commission and maintain equipment, systems and circuits in accordance with pertinent laws and regulations. Also, personnel must be familiar with the instructions and safety measures described in this guide.

2.3 Safety Precautions

⚠ WARNING

HIGH VOLTAGE

Frequency converters contain high voltage when connected to AC mains input, DC supply or load sharing. Failure to perform installation, start-up and maintenance by qualified personnel can result in death or serious injury.

- Only qualified personnel must perform installation, start-up and maintenance.

⚠ WARNING

UNINTENDED START

When the frequency converter is connected to AC mains, DC supply or load sharing, the motor may start at any time. Unintended start during programming, service or repair work can result in death, serious injury or property damage. The motor can start with an external switch, a serial communication bus command, an input reference signal from the LCP, via remote operation using MCT 10 Set-up Software or after a cleared fault condition.

To prevent unintended motor start:

- Disconnect the adjustable frequency drive from line power.
- Press [Off/Reset] on the LCP before programming parameters.
- Completely wire and assemble the frequency converter, motor and any driven equipment before connecting the frequency converter to AC mains, DC supply or load sharing.

⚠ WARNING

DISCHARGE TIME

The adjustable frequency drive contains DC link capacitors that can remain charged even when the adjustable frequency drive is not powered. High voltage can be present even when the warning LED indicator lights are off. Failure to wait the specified time after power has been removed before performing service or repair work can result in death or serious injury.

- Stop the motor.
- Disconnect AC line power and remote DC link supplies, including battery backups, UPS and DC link connections to other adjustable frequency drives.
- Disconnect or lock PM motor.
- Wait for the capacitors to discharge fully. The minimum waiting time is specified in *Table 2.1*.
- Before performing any service or repair work, use an appropriate voltage measuring device to make sure that the capacitors are fully discharged.

Voltage [V]	Power range [kW (hp)]	Minimum waiting time (minutes)
200-240	0.37-3.7 (0.5-5)	4
380-480	0.37-7.5 (0.5-10)	4
	11-22 (15-30)	15

Table 2.1 Discharge Time

⚠ WARNING

LEAKAGE CURRENT HAZARD

Leakage currents exceed 3.5 mA. Failure to ground the adjustable frequency drive properly can result in death or serious injury.

- Ensure the correct grounding of the equipment by a certified electrical installer.

⚠ WARNING

EQUIPMENT HAZARD

Contact with rotating shafts and electrical equipment can result in death or serious injury.

- Ensure that only trained and qualified personnel perform installation, start-up and maintenance.
- Ensure that electrical work conforms to national and local electrical codes.
- Follow the procedures in this manual.

⚠ CAUTION

INTERNAL FAILURE HAZARD

An internal failure in the adjustable frequency drive can result in serious injury when the adjustable frequency drive is not properly closed.

- Ensure that all safety covers are in place and securely fastened before applying power.

3 Mechanical Installation

3.1 Unpacking

3.1.1 Items Supplied

Items supplied may vary according to product configuration.

- Make sure the items supplied and the information on the nameplate correspond to the order confirmation.
- Check the packaging and the adjustable frequency drive visually for damage caused by inappropriate handling during shipment. File any claim for damage with the carrier. Retain damaged parts for clarification.

NOTICE!

Do not remove the nameplate from the adjustable frequency drive (loss of warranty).

3.1.2 Storage

Ensure that requirements for storage are fulfilled. Refer to *chapter 9.4 Ambient Conditions* for further details.

3.2 Installation Environment

NOTICE!

In environments with airborne liquids, particles or corrosive gases, ensure that the IP/Type rating of the equipment matches the installation environment. Failure to meet requirements for ambient conditions can reduce lifetime of the adjustable frequency drive. Ensure that requirements for air humidity, temperature and altitude are met.

Vibration and shock

The adjustable frequency drive complies with requirements for units mounted on the walls and floors of production premises, as well as in panels bolted to walls or floors.

For detailed ambient conditions specifications, refer to *chapter 9.4 Ambient Conditions*.

3.3 Mounting

NOTICE!

Improper mounting can result in overheating and reduced performance.

Cooling

- Ensure 100 mm (4 in) of top and bottom clearance for air cooling.

Lifting

- To determine a safe lifting method, check the weight of the unit, see *chapter 9.9 Enclosure Sizes, Power Ratings and Dimensions*.
- Ensure that the lifting device is suitable for the task.
- If necessary, plan for a hoist, crane or forklift with the appropriate rating to move the unit.
- For lifting, use hoist rings on the unit, when provided.



1	Type code
2	Order number
3	Power rating
4	Input voltage, frequency and current (at low/high voltages)
5	Output voltage, frequency and current (at low/high voltages)
6	Enclosure type and IP rating
7	Disposal
8	CE mark
9	Serial number
10	Functional safety
11	Rated ambient temperature
12	Discharge time (Warning)

Figure 3.1 Product Nameplate (Example)

3

Mounting

To adapt to the mounting holes of FC 280, contact the local Danfoss supplier to order a separate backplate.

To mount the adjustable frequency drive:

1. Ensure that the strength of the mounting location supports the unit weight. The adjustable frequency drive allows side-by-side installation.
2. Locate the unit as close to the motor as possible. Keep the motor cables as short as possible.
3. Mount the unit vertically to a solid flat surface or to the optional backplate to provide cooling airflow.
4. When provided, use the slotted mounting holes on the unit for wall mounting.




Figure 3.2 Top and Bottom Mounting Holes (See chapter 9.9 Enclosure Sizes, Power Ratings and Dimensions)

3.3.1 Side-by-side Installation

Side-by-side installation

All FC 280 units can be installed side-by-side in vertical or horizontal position. The units do not require extra ventilation on the side.




Figure 3.3 Side-by-side Installation

CAUTION

RISK OF OVERHEATING

If IP21 solution is used, mounting the units side-by-side could lead to overheating and unit damages.

- Avoid mounting the units side-by-side if IP21 solution is used.

3.3.2 Bus Decoupling Kit

The bus decoupling kit ensures mechanical fixation and electrical shielding of cables for the following control cassette variants:

- Control cassette with PROFIBUS.
- Control cassette with PROFINET.
- Control cassette with CANopen.
- Control cassette with Ethernet.

Each bus decoupling kit contains one horizontal decoupling plate and one vertical decoupling plate. Mounting the vertical decoupling plate is optional. The vertical decoupling plate provides better mechanical support for PROFINET and Ethernet connectors and cables.

3.3.3 Mounting

To mount the bus decoupling kit:


1. Place the horizontal decoupling plate on the control cassette that is mounted on the adjustable frequency drive, and fasten the plate

using two screws, as shown in *Figure 3.4*.
Tightening torque 0.7–1.0 Nm.

2. Optional: Mount the vertical decoupling plate as follows:
 - 2a Remove the two mechanical springs and two metal clamps from the horizontal plate.
 - 2b Mount the mechanical springs and metal clamps on the vertical plate.
 - 2c Fasten the plate with two screws, as shown in *Figure 3.5*. Tightening torque 0.7–1.0 Nm.


NOTICE!

If the IP21 top cover is used, do not mount the vertical decoupling plate because its height affects the proper installation of the IP21 top cover.



1	Mechanical springs
2	Metal clamps
3	Screws

Figure 3.4 Fasten the Horizontal Decoupling Plate with Screws



1	Vertical decoupling plate
2	Screws

Figure 3.5 Fasten the Vertical Decoupling Plate with Screws

Both *Figure 3.4* and *Figure 3.5* show PROFINET sockets. The actual sockets are based on the type of the control cassette mounted on the adjustable frequency drive.

3. Push the PROFIBUS/PROFINET/CANopen/Ethernet cable connectors into the sockets in the control cassette.
4.
 - 4a Place the PROFIBUS/CANopen cables between the spring-loaded metal clamps to establish mechanical fixation and electrical contact between the shielded sections of the cables and the clamps.
 - 4b Place the PROFINET/Ethernet cables between the spring-loaded metal clamps to establish mechanical fixation between the cables and the clamps.

4 Electrical Installation

4.1 Safety Instructions

See *chapter 2 Safety* for general safety instructions.

⚠ WARNING

INDUCED VOLTAGE

Induced voltage from output motor cables of different adjustable frequency drives that run together can charge equipment capacitors, even when the equipment is turned off and locked out. Failure to run output motor cables separately or use shielded cables or metal conduits could result in death or serious injury.

- Run output motor cables separately.
- Use shielded cables or metal conduits.
- Lock out all the adjustable frequency drives simultaneously.

⚠ WARNING

SHOCK HAZARD

The adjustable frequency drive can cause a DC current in the PE conductor and hence result in death or serious injury.

- When a residual current-operated protective device (RCD) is used for protection against electrical shock, only an RCD of Type B is permitted on the supply side.

Failure to follow the recommendation means that the RCD cannot provide the intended protection.

NOTICE!

The adjustable frequency drive is supplied with Class 20 motor overload protection.

Overcurrent protection

- Extra protective equipment, such as short circuit protection or motor thermal protection between adjustable frequency drive and motor, is required for applications with multiple motors.
- Input fusing is required to provide short circuit and overcurrent protection. If fuses are not factory-supplied, the installer must provide them. See maximum fuse ratings in *chapter 9.8 Fuses and Circuit Breakers*.

Wire type and ratings

- All wiring must comply with local and national regulations regarding cross-section and ambient temperature requirements.
- Power connection wire recommendation: minimum 75 °C (167 °F)-rated copper wire.

See *chapter 9.5 Cable Specifications* for recommended wire sizes and types.

4.2 EMC-compliant Installation

To obtain an EMC-compliant installation, follow the instructions provided in *chapter 4.3 Grounding*, *chapter 4.4 Wiring Schematic*, *chapter 4.6 Motor Connection*, and *chapter 4.8 Control Wiring*.

4.3 Grounding

⚠ WARNING

LEAKAGE CURRENT HAZARD

Leakage currents exceed 3.5 mA. Failure to ground the adjustable frequency drive properly could result in death or serious injury.

- Ensure the correct grounding of the equipment by a certified electrical installer.

For electrical safety

- Ground the adjustable frequency drive in accordance with applicable standards and directives.
- Use a dedicated ground wire for input power, motor power and control wiring.
- Do not ground one adjustable frequency drive to another in a daisy chain fashion (see *Figure 4.1*).
- Keep the ground wire connections as short as possible.
- Follow the motor manufacturer wiring requirements.
- Minimum cable cross-section: 10 mm² (7 AWG) (or 2 rated ground wires terminated separately).




Figure 4.1 Grounding Principle

For EMC-compliant installation

- Establish electrical contact between the cable shield and the adjustable frequency drive enclosure by using metal cable connectors or by using the clamps provided on the equipment (see chapter 4.6 Motor Connection).
- Use high-strand wire to reduce electrical interference.
- Do not use pigtails.

NOTICE!

POTENTIAL EQUALIZATION

Risk of electrical interference, when the ground potential between the adjustable frequency drive and the control system is different. Install equalizing cables between the system components. Recommended cable cross-section: 16 mm² (5 AWG).

4.4 Wiring Schematic

This section describes how to wire the adjustable frequency drive.

4




Figure 4.2 Basic Wiring Schematic Drawing

A=Analog, D=Digital


* Built-in brake chopper is only available on 3-phase units.

** Terminal 53 can also be used as digital input.

*** Switch S801 (bus terminal) can be used to enable termination on the RS485 port (terminals 68 and 69).

**** Refer to chapter 6 Safe Torque Off (STO) for the correct STO wiring.

130BD391.11



4

1	PLC	6	Minimum 200 mm (7.9 in) between control cables, motor and line power.
2	Adjustable frequency drive	7	Motor, 3-phase and PE
3	Output contactor (generally not recommended)	8	Line power, single-phase, 3-phase and reinforced PE
4	Grounding rail (PE)	9	Control wiring
5	Cable shielding (stripped)	10	Equalizing minimum 16 mm ² (6 AWG)

Figure 4.3 Typical Electrical Connection

4.5 Access

- Remove the cover plate with a screwdriver. See *Figure 4.4*.




Figure 4.4 Control Wiring Access

4.6 Motor Connection

⚠ WARNING

INDUCED VOLTAGE

Induced voltage from output motor cables that run together can charge equipment capacitors, even when the equipment are turned off and locked out. Failure to run output motor cables separately or use shielded cables or metal conduits could result in death or serious injury.

- Run output motor cables separately.
- Use shielded cables or metal conduits
- Comply with local and national electrical codes for cable sizes. For maximum cable sizes, see *chapter 9.1 Electrical Data*.
- Follow the motor manufacturer wiring requirements.
- Motor wiring knockouts or access panels are provided at the base of IP21 (NEMA1/12) units.
- Do not wire a starting or pole-changing device (for example, Dahlander motor or slip ring induction motor) between the adjustable frequency drive and the motor.

Procedure

- Strip a section of the outer cable insulation.
- Position the stripped cable under the cable clamp to establish mechanical fixation and electrical contact between the cable shield and ground.

- Connect the ground cable to the nearest grounding terminal in accordance with the grounding instructions provided in *chapter 4.3 Grounding*. See *Figure 4.5*.
- Connect the 3-phase motor wiring to terminals 96 (U), 97 (V) and 98 (W) as shown in *Figure 4.5*.
- Tighten the terminals in accordance with the information provided in *chapter 9.7 Connection Tightening Torques*.





Figure 4.5 Motor Connection

The line power, motor and grounding connection for single-phase and 3-phase adjustable frequency drives are shown in *Figure 4.6* and *Figure 4.7* respectively. Actual configurations vary with unit types and optional equipment.



130BE232.11


Figure 4.6 Line power, Motor and Grounding Connection for Single-phase Units

4.7 AC Line Input Connection

- Size the wiring based on the input current of the adjustable frequency drive. For maximum wire sizes, see *chapter 9.1 Electrical Data*.
- Comply with local and national electrical codes for cable sizes.

Procedure

1. Connect the AC input power cables to terminals N and L for single-phase units (see *Figure 4.6*) or to terminals L1, L2 and L3 for 3-phase units (see *Figure 4.7*).
2. Depending on the configuration of the equipment, connect the input power to the line power input terminals or the input disconnect.
3. Ground the cable in accordance with the grounding instructions in *chapter 4.3 Grounding*.
4. When supplied from an isolated line power source (IT line power or floating delta) or TT/TN-S line power with a grounded leg (grounded delta), ensure that the RFI filter screw is removed to avoid damage to the intermediate circuit and reduce ground capacity currents in accordance with IEC 61800-3.




130BE231.11

Figure 4.7 Line power, Motor and Grounding Connection for 3-phase Units

4.8 Control Wiring

4.8.1 Control Terminal Types

Figure 4.8 shows the removable adjustable frequency drive connectors. Terminal functions and default settings are summarized in *Table 4.1* and *Table 4.2*.



130BE212.10

Figure 4.8 Control Terminal Locations




Figure 4.9 Terminal Numbers

4

See chapter 9.6 Control Input/Output and Control Data for terminal ratings details.

Terminal	Parameter	Default setting	Description
Digital I/O, Pulse I/O, Encoder			
12, 13	-	+24 V DC	24 V DC supply voltage. Maximum output current is 100 mA for all 24 V loads.
18	Parameter 5-10 Terminal 18 Digital Input	[8] Start	Digital inputs.
19	Parameter 5-11 Terminal 19 Digital Input	[10] Reversing	
27	Parameter 5-12 Terminal 27 Digital Input parameter 5-30 Terminal 27 Digital Output	DI [2] Coast inverse DO [0] No operation	
29	Parameter 5-13 Terminal 29 Digital Input	[14] Jog	Digital input.
32	Parameter 5-14 Terminal 32 Digital Input	[0] No operation	Digital input, 24 V encoder. Terminal 33 can be used for pulse input.
33	Parameter 5-15 Terminal 33 Digital Input	[16] Preset ref bit 0	
37, 38	-	STO	Functional safety inputs.
Analog inputs/outputs			

Terminal	Parameter	Default setting	Description
42	Parameter 6-91 Terminal 42 Analog Output	[0] No operation	Programmable analog output. The analog signal is 0–20 mA or 4–20 mA at a maximum of 500 Ω. Can also be configured as digital outputs.
50	-	+10 V DC	10 V DC analog supply voltage. 15 mA maximum commonly used for potentiometer or thermistor.
53	6-1* parameter group	-	Analog input. Only voltage mode is supported. It can also be used as digital input.
54	6-2* parameter group	-	Analog input. Selectable between voltage or current mode.
55	-	-	Common for analog input.

Table 4.1 Terminal Descriptions - Digital Inputs/Outputs, Analog Input/Outputs

Terminal	Parameter	Default setting	Description
Serial communication			
61	-	-	Integrated RC filter for cable shield. ONLY for connecting the shield when experiencing EMC problems.
68 (+)	8-3* parameter group	-	RS485 interface. A control card switch is provided for termination resistance.
69 (-)	8-3* parameter group	-	
Relays			

Terminal	Parameter	Default setting	Description
01, 02, 03	5-40	[9] Alarm	Form C relay output. These relays are in various locations depending upon the adjustable frequency drive configuration and size. Usable for AC or DC voltage and resistive or inductive loads.

Table 4.2 Terminal Descriptions - Serial Communication

4.8.2 Wiring to Control Terminals

Control terminal connectors can be unplugged from the adjustable frequency drive for ease of installation, as shown in *Figure 4.8*.

For details about STO wiring, refer to *chapter 6 Safe Torque Off (STO)*.

NOTICE!

Keep control cables as short as possible and separate them from high power cables to minimize interference.

1. Loosen the screws for the terminals.
2. Insert sleeved control cables into the slots.
3. Fasten the screws for the terminals.
4. Ensure that the contact is firmly established and not loose. Loose control wiring can be the source of equipment faults or less than optimal operation.

See *chapter 9.5 Cable Specifications* for control terminal cable sizes and *chapter 7 Application Examples* for typical control cable connections.

4.8.3 Enabling Motor Operation (Terminal 27)

A jumper wire is required between terminal 12 (or 13) and terminal 27 for the adjustable frequency drive to operate when using factory default programming values.

- Digital input terminal 27 is designed to receive 24 V DC external interlock command.
- When no interlock device is used, wire a jumper between control terminal 12 (recommended) or 13 to terminal 27. The jumper provides an internal 24 V signal on terminal 27.
- Only for GLCP: When the status line at the bottom of the LCP reads *AUTO REMOTE COAST*, it indicates that the unit is ready to operate but is missing an input signal on terminal 27.

NOTICE!

UNABLE TO START

The adjustable frequency drive cannot operate without a signal on terminal 27, unless terminal 27 is reprogrammed.

4.8.4 Mechanical Brake Control

In hoisting/lowering applications, it is necessary to control an electro-mechanical brake.

- Control the brake using any relay output or digital output (terminal 27).
- Keep the output closed (voltage-free) as long as the adjustable frequency drive is unable to keep the motor at standstill, for example, due to the load being too heavy.
- Select [32] *Mechanical brake control* in parameter group 5-4* *Relays* for applications with an electro-mechanical brake.
- The brake is released when the motor current exceeds the preset value in *parameter 2-20 Release Brake Current*.
- The brake is engaged when the output frequency is less than the frequency set in *parameter 2-22 Activate Brake Speed [Hz]*, and only if the adjustable frequency drive carries out a stop command.

If the adjustable frequency drive is in alarm mode or in an overvoltage situation, the mechanical brake immediately closes.

The adjustable frequency drive is not a safety device. It is the responsibility of the system designer to integrate safety devices according to relevant national crane/lift regulations.




Figure 4.10 Connecting the Mechanical Brake to the Adjustable Frequency Drive

For basic serial communication set-up, select the following:

1. Protocol type in *parameter 8-30 Protocol*.
 2. Adjustable frequency drive address in *parameter 8-31 Address*.
 3. Baud rate in *parameter 8-32 Baud Rate*.
- Two communication protocols are internal to the adjustable frequency drive. Follow the motor manufacturer wiring requirements.
 - Danfoss FC
 - Modbus RTU
 - Functions can be programmed remotely using the protocol software and RS-485 connection or in parameter group 8-** *Communications and Options*.
 - Selecting a specific communication protocol changes various default parameter settings to match the specifications of the protocol, and makes extra protocol-specific parameters available.

4.8.5 RS-485 Serial Communication

Connect RS-485 serial communication wiring to terminals (+)68 and (-)69.

- Shielded serial communication cable is recommended.
- See *chapter 4.3 Grounding* for proper grounding.




Figure 4.11 Serial Communication Wiring Diagram

4.9 Installation Checklist

Before completing installation of the unit, inspect the entire installation as detailed in *Table 4.3*. Check and mark the items when completed.

Inspect for	Description	<input checked="" type="checkbox"/>
Auxiliary equipment	<ul style="list-style-type: none"> Look for auxiliary equipment, switches, disconnects or input fuses/circuit breakers, which may reside on the input power side of the frequency converter or output side to the motor. Ensure that they are ready for full-speed operation. Check the function and installation of any sensors used for feedback to the adjustable frequency drive. Remove any power factor correction capacitors on the motor(s). Adjust any power factor correction capacitors on the line power side and ensure that they are dampened. 	
Cable routing	<ul style="list-style-type: none"> Ensure that the motor wiring and control wiring are separated, screened or in 3 separate metallic conduits for high-frequency interference isolation. 	
Control wiring	<ul style="list-style-type: none"> Check for broken or damaged wires and loose connections. Check that the control wiring is isolated from power and motor wiring for noise immunity. Check the voltage source of the signals, if necessary. <p>The use of shielded cable or twisted pair is recommended. Ensure that the shield is terminated correctly.</p>	
Cooling clearance	<ul style="list-style-type: none"> Ensure that the top and bottom clearance is adequate to ensure proper air flow for cooling, see <i>chapter 3.3 Mounting</i>. 	
Ambient conditions	<ul style="list-style-type: none"> Check that requirements for ambient conditions are met. 	
Fusing and circuit breakers	<ul style="list-style-type: none"> Check for proper fusing or circuit breakers. Check that all fuses are inserted firmly and are in operational condition and that all circuit breakers are in the open position. 	
Grounding	<ul style="list-style-type: none"> Check for sufficient ground connections and ensure that they are tight and free of oxidation. Do not ground to conduit or mount the back panel to a metal surface. 	
Input and output power wiring	<ul style="list-style-type: none"> Check for loose connections. Check that the motor and line cables are in separate conduit or separated shielded cables. 	
Panel interior	<ul style="list-style-type: none"> Inspect that the unit interior is free of dirt, metal chips, moisture and corrosion. Check that the unit is mounted on an unpainted, metal surface. 	
Switches	<ul style="list-style-type: none"> Ensure that all switch and disconnect settings are in the proper positions. 	
Vibration	<ul style="list-style-type: none"> Check that the unit is mounted solidly or that shock mounts are used, as necessary. Check for an unusual amount of vibration. 	

Table 4.3 Installation Check List

CAUTION

POTENTIAL HAZARD IN THE EVENT OF INTERNAL FAILURE

Risk of personal injury if the adjustable frequency drive is not properly closed.

- Before applying power, ensure that all safety covers are in place and securely fastened.

5 Commissioning

5.1 Safety Instructions

See *chapter 2 Safety* for general safety instructions.

⚠ WARNING

HIGH VOLTAGE

Adjustable frequency drives contain high voltage when connected to AC line power. Failure to perform installation, start-up and maintenance by qualified personnel could result in death or serious injury.

- Installation, start-up and maintenance must be performed by qualified personnel only.

Before applying power:

1. Close the cover properly.
2. Check that all cable connectors are firmly tightened.
3. Ensure that input power to the unit is off and locked out. Do not rely on the adjustable frequency drive disconnect switches for input power isolation.
4. Verify that there is no voltage on input terminals L1 (91), L2 (92) and L3 (93), phase-to-phase and phase-to-ground.
5. Verify that there is no voltage on output terminals 96 (U), 97 (V) and 98 (W), phase-to-phase and phase-to-ground.
6. Confirm continuity of the motor by measuring Ω values on U–V (96–97), V–W (97–98) and W–U (98–96).
7. Check for proper grounding of the adjustable frequency drive as well as the motor.
8. Inspect the adjustable frequency drive for loose connections on the terminals.
9. Confirm that the supply voltage matches the voltage of the adjustable frequency drive and the motor.

5.2 Applying Power

Apply power to the adjustable frequency drive using the following steps:

1. Confirm that the input voltage is balanced within 3%. If not, correct the input voltage imbalance before proceeding. Repeat this procedure after the voltage correction.
2. Ensure that any optional equipment wiring matches the installation application.
3. Ensure that all operator devices are in the OFF position. Panel doors must be closed and covers securely fastened.
4. Apply power to the unit. Do not start the adjustable frequency drive now. For units with a disconnect switch, turn it to the ON position to apply power to the adjustable frequency drive.

5.3 Local Control Panel Operation

The adjustable frequency drive supports numerical local control panel (LCP) graphic local control panel (GLCP) and blind cover. This chapter describes the operations with LCP and GLCP.

NOTICE!

The adjustable frequency drive can also be programmed from the MCT 10 Set-up Software on PC via RS485 communication port. This software can be ordered using code number 130B1000 or downloaded from the Danfoss website: www.danfoss.com/BusinessAreas/DrivesSolutions/softwaredownload.

5.3.1 Local Control Panel (LCP)

The numerical local control panel (LCP) is divided into four functional sections.

- A. Numeric display.
- B. Menu key.
- C. Navigation keys and LEDs.
- D. Operation keys and LEDs.




Figure 5.1 View of the LCP

A. Numeric display

The LCD display is backlit with one numeric line. All data is displayed in the LCP.

1	The set-up number shows the active set-up and the edit set-up. If the same set-up acts as both the active and edit set-up, only that set-up number is shown (factory setting). When active and edit set-up differ, both numbers are shown in the display (for example, set-up 12). The number flashing indicates the edit set-up.
2	Parameter number.
3	Parameter value.
4	Motor direction is shown in the bottom left of the display. A small arrow indicates the direction, either clockwise or counter-clockwise.
5	The triangle indicates whether the LCP is in Status, Quick Menu or Main Menu.

Table 5.1 Legend to Figure 5.1, Section A




Figure 5.2 Display Information

B. Menu key

Press [Menu] to select between Status, Quick Menu or Main Menu.

C. Navigation keys and LEDs

Key	Function
9 [Back]	For moving to the previous step or layer in the navigation structure.
1 0 Arrows [▲] [▼]	For switching between parameter groups, parameters and within parameters or increasing/decreasing parameter values. Arrows can also be used for setting local reference.
1 1 [OK]	Press to access parameter groups or to enable a selection.
1 2 [▶]	For moving from left to right within the parameter value to change each digit individually.

Table 5.2 Legend to Figure 5.1, Navigation Keys

	Indicator	Light	Function
6	On	Green	The ON light activates when the frequency converter receives power from the mains voltage, a DC bus terminal or an external 24 V supply.
7	Warn.	Yellow	When warning conditions are met, the yellow WARN light comes on and text appears in the display area identifying the problem.
8	Alarm	Red	A fault condition causes the red alarm light to flash and an alarm text is displayed.

Table 5.3 Legend to Figure 5.1, Indicator Lights (LEDs)

D. Operation keys and LEDs

Key	Function
13 Hand On	Starts the adjustable frequency drive in local control. <ul style="list-style-type: none"> An external stop signal by control input or serial communication overrides the local hand on.
14 Off/Reset	Stops the motor but does not remove power to the adjustable frequency drive or resets the adjustable frequency drive manually after a fault has been cleared.
15 Auto On	Puts the system in remote operational mode. <ul style="list-style-type: none"> Responds to an external start command by control terminals or serial communication.

Table 5.4 Legend to Figure 5.1, Section D

⚠ WARNING**ELECTRICAL HAZARD**

Even after pressing the [Off/Reset] key, voltage is present at the terminals of the adjustable frequency drive. Operating the [Off/Reset] key does not disconnect the adjustable frequency drive from line power. Touching live parts can result in death or serious injury.

- Do not touch any live parts.

5.3.2 The Right Key Function on LCP

Press [▶] to edit any of the four digits on the display individually. When pressing [▶] once, the cursor moves to the first digit and the digit starts flashing as shown in *Figure 5.3*. Press the [▲] [▼] to change the value. Pressing [▶] does not change the value of the digits or move the decimal point.




Figure 5.3 Right Key Function

[▶] can also be used for moving between parameter groups. When in Main Menu, press [▶] to move to the first parameter in the next parameter group (for example, move from *parameter 0-03 Regional Settings [0] International* to *parameter 1-00 Configuration Mode [0] Open-loop*).

NOTICE!

During start-up, the LCP shows the message *INITIALIZING*. When this message is no longer shown, the adjustable frequency drive is ready for operation. Adding or removing options can extend the duration of start-up.

5.3.3 Quick Menu on LCP

The *Quick Menu* gives easy access to the most frequently used parameters.

1. To enter *Quick Menu*, press [Menu] until the indicator in display is placed above *Quick Menu*.
2. Press [▲] [▼] to select either QM1 or QM2, then press [OK].
3. Press [▲] [▼] to browse through the parameters in *Quick Menu*.
4. Press [OK] to select a parameter.
5. Press [▲] [▼] to change the value of a parameter setting.
6. Press [OK] to accept the change.
7. To exit, press either [Back] twice (or three times if in QM2 and QM3) to enter *Status*, or press [Menu] once to enter *Main Menu*.

130BC445.12




Figure 5.4 Quick Menu Structure

5.3.4 Main Menu on LCP

The *Main Menu* gives access to all parameters.

1. To enter *Main Menu*, press [Menu] until the indicator in the display is placed above *Main Menu*.
2. [▲] [▼]: Browse through the parameter groups.
3. Press [OK] to select a parameter group.
4. [▲] [▼]: Browse through the parameters in the specific group.
5. Press [OK] to select the parameter.
6. [▶] and [▲] [▼]: Set/change the parameter value.
7. Press [OK] to accept the value.
8. To exit, press either [Back] twice (or three times for array parameters) to enter *Main Menu*, or press [Menu] once to enter *Status*.

See *Figure 5.5*, *Figure 5.6* and *Figure 5.7* for the principles of changing the value of continuous, enumerated and array parameters, respectively. The actions in the figures are described in *Table 5.5*, *Table 5.6* and *Table 5.7*.




Figure 5.5 Main Menu Interactions - Continuous Parameters

1	[OK]: The first parameter in the group is shown.
2	Press [▼] repeatedly to move down to the parameter.
3	Press [OK] to start editing.
4	[▶]: First digit flashing (can be edited).
5	[▶]: Second digit flashing (can be edited).
6	[▶]: Third digit flashing (can be edited).
7	[▼]: Decreases the parameter value, the decimal point changes automatically.
8	[▲]: Increases the parameter value.
9	[Back]: Cancel changes, return to 2. [OK]: Accept changes, return to 2.
10	[▲][▼]: Select parameter within the group.
11	[Back]: Removes the value and shows the parameter group.
12	[▲][▼]: Select group.

Table 5.5 Changing Values in Continuous Parameters

For enumerated parameters, the interaction is similar but the parameter value is shown in brackets because of the digits limitation (four large digits) on LCP, and the enum can be greater than 99. When the enum value is greater than 99, the LCP can only show the first part of the bracket.




Figure 5.6 Main Menu Interactions - Enumerated Parameters

1	[OK]: The first parameter in the group is shown.
2	Press [OK] to start editing.
3	[▲][▼]: Change parameter value (flashing).
4	Press [Back] to cancel changes or [OK] to accept changes (return to screen 2).
5	[▲][▼]: Select a parameter within the group.
6	[Back]: Removes the value and shows the parameter group.
7	[▲][▼]: Select a group.

Table 5.6 Changing Values in Enumerated Parameters

Array parameters function as follows:




Figure 5.7 Main Menu Interactions - Array Parameters

1	[OK]: Shows parameter numbers and the value in the first index.
2	[OK]: Index can be selected.
3	[▲][▼]: Select index.
4	[OK]: Value can be edited.
5	[▲][▼]: Change parameter value (flashing).
6	[Back]: Cancels changes. [OK]: Accepts changes.
7	[Back]: Cancels editing index, a new parameter can be selected.
8	[▲][▼]: Select parameter within the group.
9	[Back]: Removes parameter index value and shows the parameter group.
10	[▲][▼]: Select group.

Table 5.7 Changing Values in Array Parameters

5.3.5 GLCP Layout

The GLCP is divided into four functional groups (see Figure 5.8).

- A. Display area
- B. Display menu keys
- C. Navigation keys and LEDs
- D. Operation keys and reset




Figure 5.8 Graphic Local Control Panel (GLCP)

A. Display area

The display area is activated when the frequency converter receives power from the mains voltage, a DC bus terminal or an external 24 V DC supply.

The information displayed on the LCP can be customized for user application. Select options in the *Quick Menu Q3-13 Display Settings*.

Display	Parameter number	Default setting
1	0-20	[1602] Reference [%]
2	0-21	[1614] Motor Current
3	0-22	[1610] Power [kW]
4	0-23	[1613] Frequency
5	0-24	[1502] kWh Counter

Table 5.8 Legend to Figure 5.8, Display Area

B. Display menu keys

Menu keys are used for menu access for parameter set-up, toggling through status display modes during normal operation and viewing fault log data.

	Key	Function
6	Status	Shows operational information.
7	Quick Menu	Allows access to programming parameters for initial set-up instructions and many detailed application instructions.
8	Main Menu	Allows access to all programming parameters.
9	Alarm Log	Displays a list of current warnings, the last 10 alarms and the maintenance log.

Table 5.9 Legend to Figure 5.8, Display Menu Keys

C. Navigation keys and LEDs

Navigation keys are used for programming functions and moving the display cursor. The navigation keys also provide speed control in local operation. There are also three adjustable frequency drive status indicator lights in this area.

	Key	Function
10	Back	Reverts to the previous step or list in the menu structure.
11	Cancel	Cancels the last change or command as long as the display mode has not changed.
12	Info	Press for a definition of the function being displayed.
13	Navigation Keys	Use the four navigation keys to move between items in the menu.
14	OK	Press to access parameter groups or to enable a selection.

Table 5.10 Legend to Figure 5.8, Navigation Keys

	Indicator	Light	Function
15	On	Green	The ON light activates when the frequency converter receives power from the mains voltage, a DC bus terminal or an external 24 V supply.
16	Warn.	Yellow	When warning conditions are met, the yellow WARN light turns on and text appears in the display area identifying the problem.
17	Alarm	Red	A fault condition causes the red alarm light to flash and an alarm text is displayed.

Table 5.11 Legend to Figure 5.8, Indicator Lights (LEDs)

D. Operation keys and reset

Operation keys are located at the bottom of the LCP.

	Key	Function
18	Hand On	Starts the adjustable frequency drive in local control. <ul style="list-style-type: none"> An external stop signal by control input or serial communication overrides the local hand on.
19	Off	Stops the motor but does not remove power to the adjustable frequency drive.
20	Auto On	Puts the system in remote operational mode. <ul style="list-style-type: none"> Responds to an external start command by control terminals or serial communication.
21	Reset	Resets the adjustable frequency drive manually after a fault has been cleared.

Table 5.12 Legend to Figure 5.8, Operation Keys and Reset

NOTICE!

To adjust the display contrast, press [Status] and the [▲]/[▼] keys.

5.3.6 Parameter Settings

Establishing the correct programming for applications often requires setting functions in several related parameters. Details for parameters are provided in chapter 10.2 Parameter Menu Structure.

Programming data is stored internally in the adjustable frequency drive.

- For backup, upload data into the LCP memory.
- To download data to another adjustable frequency drive, connect the LCP to that unit and download the stored settings.
- Restoring factory default settings does not change data stored in the LCP memory.

5.3.7 Changing Parameter Settings with GLCP

Access and change parameter settings from the Quick Menu or from the Main Menu. The Quick Menu only gives access to a limited number of parameters.

- Press [Quick Menu] or [Main Menu] on the LCP.
- Press [▲] [▼] to browse through the parameter groups, press [OK] to select a parameter group.
- Press [▲] [▼] to browse through the parameters, press [OK] to select a parameter.

- Press [▲] [▼] to change the value of a parameter setting.
- Press [◀] [▶] to shift digit when a decimal parameter is in the editing state.
- Press [OK] to accept the change.
- Press either [Back] twice to enter Status, or press [Main Menu] once to enter the Main Menu.

View changes

Quick Menu Q5 - Changes Made lists all parameters changed from default settings.

- The list only shows parameters, which have been changed in the current edit set-up.
- Parameters, which have been reset to default values, are not listed.
- The message *Empty* indicates that no parameters have been changed.

5.3.8 Uploading/Downloading Data to/from the GLCP

- Press [Off] to stop the motor before uploading or downloading data.
- Press [Main Menu] parameter 0-50 LCP Copy and press [OK].
- Select [1] All to LCP to upload data to the LCP or select [2] All from LCP to download data from the LCP.
- Press [OK]. A progress bar shows the uploading or downloading progress.
- Press [Hand On] or [Auto On] to return to normal operation.

5.3.9 Restoring Default Settings with GLCP

NOTICE!

Risk of losing programming, motor data, localization and monitoring records by restoration of default settings. To provide a backup, upload data to the LCP before initialization.

Restoring the default parameter settings is done by initialization of the adjustable frequency drive. Initialization is carried out through parameter 14-22 Operation Mode (recommended) or manually. Initialization does not reset the settings for parameter 1-06 Clockwise Direction.

- Initialization using parameter 14-22 Operation Mode does not reset adjustable frequency drive

settings, such as operating hours, serial communication selections, fault log, alarm log and other monitoring functions.

- Manual initialization erases all motor, programming, localization and monitoring data and restores factory default settings.

Recommended initialization procedure via parameter 14-22 Operation Mode

1. Press [Main Menu] twice to access parameters.
2. Scroll to *parameter 14-22 Operation Mode* and press [OK].
3. Scroll to [2] *Initialization* and press [OK].
4. Remove power to the unit and wait for the display to turn off.
5. Apply power to the unit.

Default parameter settings are restored during start-up. This may take slightly longer than normal.

6. Alarm 80 is displayed.
7. Press [Reset] to return to operation mode.

Manual initialization procedure

1. Remove power to the unit and wait for the display to turn off.
2. Press and hold [Status], [Main Menu] and [OK] at the same time while applying power to the unit (approximately 5 s or until audible click and fan starts).

Factory default parameter settings are restored during start-up. This may take slightly longer than normal.

Manual initialization does not reset the following adjustable frequency drive information:

- *Parameter 15-00 Operating hours*
- *Parameter 15-03 Power Up's*
- *Parameter 15-04 Over Temp's*
- *Parameter 15-05 Over Volt's*

5.4 Basic Programming

5.4.1 Asynchronous Motor Set-up

Enter the following motor data. The information can be found on the motor nameplate.

1. *Parameter 1-20 Motor Power [kW].*
2. *Parameter 1-22 Motor Voltage.*
3. *Parameter 1-23 Motor Frequency.*

4. *Parameter 1-24 Motor Current.*
5. *Parameter 1-25 Motor Nominal Speed.*

For optimum performance in VVC⁺ mode, extra motor data is required to set up the following parameters. The data is found in the motor datasheet (this data is typically not available on the motor nameplate). Run a complete AMA using *parameter 1-29 Automatic Motor Adaptation (AMA) [1] Enable Complete AMA* or enter the parameters manually.

1. *Parameter 1-30 Stator Resistance (Rs).*
2. *Parameter 1-31 Rotor Resistance (Rr).*
3. *Parameter 1-33 Stator Leakage Reactance (X1).*
4. *Parameter 1-35 Main Reactance (Xh).*

Application-specific adjustment when running VVC⁺

VVC⁺ is the most robust control mode. In most situations, it provides optimum performance without further adjustments. Run a complete AMA for best performance.

5.4.2 PM Motor Set-up in VVC⁺

Initial programming steps

1. Set *parameter 1-10 Motor Construction* to the following options to activate PM motor operation:
 - [1] *PM, non-salient SPM*
 - [2] *PM, salient IPM, non Sat*
 - [3] *PM, salient IPM, Sat*
2. Select [0] *Open-loop* in *parameter 1-00 Configuration Mode*.

NOTICE!

Encoder feedback is not supported for PM motors.

Programming motor data

After selecting PM motor in *parameter 1-10 Motor Construction*, the PM motor-related parameters in parameter groups *1-2* Motor Data*, *1-3* Addl. Motor Data* and *1-4* Adv. Motor Data II* are active.

The information can be found on the motor nameplate and in the motor data sheet.

Programme the following parameters in the listed order.

1. *Parameter 1-24 Motor Current.*
2. *Parameter 1-26 Motor Cont. Rated Torque.*
3. *Parameter 1-25 Motor Nominal Speed.*
4. *Parameter 1-39 Motor Poles.*
5. *Parameter 1-30 Stator Resistance (Rs).*

Enter line to common stator winding resistance (Rs). If only line-line data is available, divide the line-line value by 2 to achieve the line to common (starpoint) value.
It is also possible to measure the value with an ohmmeter, which also takes the resistance of the cable into account. Divide the measured value by 2 and enter the result.

6. **Parameter 1-37 d-axis Inductance (Ld).**
Enter line to common direct axis inductance of the PM motor.
If only line-line data is available, divide the line-line value with 2 to achieve the line-common (starpoint) value.
It is also possible to measure the value with an inductance meter, which also takes the inductance of the cable into account. Divide the measured value by 2 and enter the result.
7. **Parameter 1-40 Back EMF at 1000 RPM.**
Enter line-to-line back EMF of PM motor at 1000 RPM mechanical speed (RMS value). Back EMF is the voltage generated by a PM motor when no adjustable frequency drive is connected and the shaft is turned externally. Back EMF is normally specified for nominal motor speed or for 1000 RPM measured between two lines. If the value is not available for a motor speed of 1000 RPM, calculate the correct value as follows: For example, if back EMF at 1800 RPM is 320 V, the back EMF at 1000 RPM is:
Back EMF=(Voltage/RPM)x1000=(320/1800)x1000=178.
Program this value for *parameter 1-40 Back EMF at 1000 RPM*.

Test motor operation

1. Start the motor at low speed (100–200 RPM). If the motor does not turn, check installation, general programming and motor data.

Parking

This function is the recommended choice for applications where the motor is rotating at slow speed (for example, windmilling in fan applications). *Parameter 2-06 Parking Current* and *parameter 2-07 Parking Time* are adjustable. Increase the factory setting of these parameters for applications with high inertia.

Start the motor at nominal speed. If the application does not run well, check the VVC+ PM settings. *Table 5.13* shows recommendations in different applications.

Application	Settings
Low inertia applications $I_{Load}/I_{Motor} < 5$	<ul style="list-style-type: none"> • Increase the value for <i>parameter 1-17 Voltage filter time const.</i> by factor 5–10. • Reduce the value for <i>parameter 1-14 Damping Gain</i>. • Reduce the value (<100%) for <i>parameter 1-66 Min. Current at Low Speed</i>.
Medium inertia applications $5 > I_{Load}/I_{Motor} > 5$	Keep calculated values.
High inertia applications $I_{Load}/I_{Motor} > 50$	Increase the values for <i>parameter 1-14 Damping Gain</i> , <i>parameter 1-15 Low Speed Filter Time Const.</i> and <i>parameter 1-16 High Speed Filter Time Const.</i>
High load at low speed <30% (rated speed)	Increase the value for <i>parameter 1-17 Voltage filter time const.</i> Increase the value for <i>parameter 1-66 Min. Current at Low Speed</i> (>100% for longer time can overheat the motor).

Table 5.13 Recommendations for Different Applications

If the motor starts oscillating at a certain speed, increase *parameter 1-14 Damping Gain*. Increase the value in small steps.

Starting torque can be adjusted in *parameter 1-66 Min. Current at Low Speed*. 100% provides nominal torque as starting torque.

5.4.3 Automatic Motor Adaptation (AMA)

Automatic motor adaptation (AMA)

It is highly recommended to run AMA, because it measures the electrical characteristics of the motor to optimize compatibility between the adjustable frequency drive and the motor under VVC+ mode.

- The adjustable frequency drive builds a mathematical model of the motor for regulating output motor current, thus enhancing motor performance.
- Some motors may be unable to run the complete version of the test. In that case, select [2] *Enable reduced AMA* in *parameter 1-29 Automatic Motor Adaption (AMA)*.
- If warnings or alarms occur, see *chapter 8.4 List of Warnings and Alarms*.

- Run this procedure on a cold motor for best results.

To run AMA using the LCP

1. By default parameter setting, connect terminals 12 and 27 before running AMA.
2. Enter the *Main Menu*.
3. Go to parameter group 1-** *Load and Motor*.
4. Press [OK].
5. Set motor parameters using nameplate data for parameter group 1-2* *Motor Data*.
6. Set motor cable length in *parameter 1-42 Motor Cable Length*.
7. Go to *parameter 1-29 Automatic Motor Adaptation (AMA)*.
8. Press [OK].
9. Select [1] *Enable complete AMA*.
10. Press [OK].
11. The test runs automatically and indicates when it is complete.

Depending on the power size, the AMA takes 3 to 10 minutes to complete.

NOTICE!

The AMA function does not cause the motor to run and it does not harm the motor.

5.5 Checking Motor Rotation

Before running the adjustable frequency drive, check the motor rotation.

1. Press [Hand On].
2. Press [▲] for positive speed reference.
3. Check that the speed displayed is positive.
4. Verify that the wiring between the adjustable frequency drive and the motor is correct.
5. Verify that the motor running direction matches the setting in *parameter 1-06 Clockwise Direction*.
 - When *parameter 1-06 Clockwise Direction* is set to [0] *Normal* (default clockwise):

- a. Verify that the motor turns clockwise.
- b. Verify that the LCP direction arrow is clockwise.

- When *parameter 1-06 Clockwise Direction* is set to [1] *Inverse* (counter-clockwise):

- a. Verify that the motor turns counter-clockwise.
- b. Verify that the LCP direction arrow is counter-clockwise.

5.6 Checking Encoder Rotation

Only check encoder rotation if encoder feedback is used.

1. Select [0] *Open-loop* in *parameter 1-00 Configuration Mode*.
2. Select [1] *24 V encoder* in *parameter 7-00 Speed PID Feedback Source*.
3. Press [Hand On].
4. Press [▲] for positive speed reference (*parameter 1-06 Clockwise Direction* at [0] *Normal*).
5. Check in *parameter 16-57 Feedback [RPM]* that the feedback is positive.

NOTICE!

NEGATIVE FEEDBACK

If the feedback is negative, the encoder connection is wrong. Use *parameter 5-71 Term 32/33 Encoder Direction* to inverse the direction or reverse the encoder cables.

5.7 Local Control Test

1. Press [Hand On] to provide a local start command to the adjustable frequency drive.
2. Accelerate the adjustable frequency drive by pressing [▲] to full speed. Moving the cursor left of the decimal point provides quicker input changes.
3. Note any acceleration problems.
4. Press [Off]. Note any deceleration problems.

If acceleration or deceleration problems occur, see *chapter 8.5 Troubleshooting*. See *chapter 8.2 Warning and Alarm Types* for resetting the adjustable frequency drive after a trip.

5.8 System Start-up

The procedure in this section requires user-wiring and application programming to be completed. The following procedure is recommended after application set-up is completed.

1. Press [Auto On].
2. Apply an external run command.
3. Adjust the speed reference throughout the speed range.
4. Remove the external run command.
5. Check the sound and vibration levels of the motor to ensure that the system is working as intended.

If warnings or alarms occur, see *chapter 8.2 Warning and Alarm Types* for resetting the adjustable frequency drive after a trip.

5.9 STO Commissioning

Refer to *chapter 6 Safe Torque Off (STO)* for the correct installation and commissioning of STO.

6 Safe Torque Off (STO)

The Safe Torque Off (STO) function is a component in a safety control system. STO prevents the unit from generating the energy that is required to rotate the motor, thus ensuring safety in emergency situations.

The STO function is designed and approved suitable for the requirements of:

- IEC/EN 61508: 2010 SIL 2
- IEC/EN 61800-5-2: 2007 SIL2
- IEC/EN 62061: 2012 SILCL of SIL2
- EN ISO 13849-1: 2008 Category 3 PL d

To achieve the desired level of operational safety, select and apply the components in the safety control system appropriately. Before using STO, carry out a thorough risk analysis on the installation to determine whether the STO function and safety levels are appropriate and sufficient.

The STO function in the adjustable frequency drive is controlled via control terminals 37 and 38. When STO is activated, the power supply on the high side and low side of the IGBT gate driving circuits are cut off. *Figure 6.1* shows the STO architecture. *Table 6.1* shows STO statuses based on whether terminals 37 and 38 are energized.




Figure 6.1 STO Architecture

Terminal 37	Terminal 38	Torque	Warning or alarm
Energized ¹⁾	Energized	Yes ²⁾	No warnings or alarms.
De-energized ³⁾	De-energized	No	Warning/alarm 68: Safe Stop.
De-energized	Energized	No	Alarm 188: STO Function Fault.
Energized	De-energized	No	Alarm 188: STO Function Fault.

Table 6.1 STO Status

- 1) Voltage range is 24 V \pm 5 V, with terminal 55 as the reference terminal.
- 2) Torque is present only when the adjustable frequency drive is operating.
- 3) Open circuit, or the voltage within the range of 0 V \pm 1.5 V, with terminal 55 as the reference terminal.

Test pulse filtering

For safety devices that generate test pulses on the STO control lines, if the pulse signals stay at low level (≤ 1.8 V) for no longer than 5 ms, they are ignored, as shown in *Figure 6.2*.




Figure 6.2 Test Pulse Filtering

Asynchronous input tolerance

The input signals at the two terminals are not always synchronous. If the discrepancy between the two signals is longer than 12 ms, the STO fault alarm (*alarm 188, STO Function Fault*) occurs.

Valid signals

To activate STO, the two signals must be both at low level for at least 80 ms. To terminate STO, the two signals must be both at high level for at least 20 ms. Refer to

chapter 9.6 Control Input/Output and Control Data for the voltage levels and input current of STO terminals.

6.1 Safety Precautions for STO

Qualified personnel

Only qualified personnel are allowed to install or operate this equipment.

Qualified personnel are defined as trained staff who are authorized to install, commission and maintain equipment, systems and circuits in accordance with pertinent laws and regulations. Additionally, the personnel must be familiar with the instructions and safety measures described in this manual.

NOTICE!

After installation of STO, perform a commissioning test as specified in chapter 6.3.3 STO Commissioning Test. A passed commissioning test is mandatory after first installation and after each change to the safety installation.

⚠ WARNING

RISK OF ELECTRICAL SHOCK

The STO function does NOT isolate AC line voltage to the adjustable frequency drive or auxiliary circuits and therefore does not provide electrical safety. Failure to isolate the AC line voltage supply from the unit and wait the time specified could result in death or serious injury.

- Perform work on electrical parts of the adjustable frequency drive or the motor only after isolating the AC line voltage supply and waiting the time specified in chapter 2.3.1 Discharge Time.

NOTICE!

When designing the machine application, consider the timing and distance for a coast to stop (STO). For more information regarding stop categories, refer to EN 60204-1.

6.2 Safe Torque Off Installation

For motor connection, AC line input connection and control wiring, follow the instructions for safe installation in chapter 4 Electrical Installation.

Enable the integrated STO as follows:

1. Remove the jumper between control terminals 12 (24 V), 37 and 38. Cutting or breaking the jumper is not sufficient to avoid short-circuiting. See the jumper in Figure 6.3.




Figure 6.3 Jumper between Terminal 12 (24 V), 37 and 38

2. Connect a dual-channel safety device (for example, safety PLC, light curtain, safety relay or emergency stop button) to terminals 37 and 38 to form a safety application. The device must comply with the desired safety level based on the hazard assessment. Figure 6.4 shows the wiring schematic of STO applications where the adjustable frequency drive and the safety device are in the same cabinet. Figure 6.5 shows the wiring schematic of STO applications where external supply is used.

NOTICE!

The STO signal must be PELV supplied.




Figure 6.4 STO Wiring in 1 Cabinet, Adjustable Frequency Drive Provides the Supply Voltage




Figure 6.5 STO Wiring, External Supply

3. Complete the wiring according to the instructions in *chapter 4 Electrical Installation*, and:
 - Eliminate short circuit risks.
 - Ensure that the STO cables are shielded if they are longer than 20 m (65 ft).
 - Connect the safety device directly to terminals 37 and 38.

6.3 STO Commissioning

6.3.1 Activation of Safe Torque Off

To activate the STO function, remove the voltage at terminals 37 and 38 of the adjustable frequency drive.

When STO is activated, the adjustable frequency drive issues *alarm 68, Safe Stop* or *warning 68, Safe Stop*, trips the unit and coasts the motor to stop. Use the STO function to stop the adjustable frequency drive in emergency stop

situations. In normal operating mode when STO is not required, use the standard stop function instead.

NOTICE!

If STO is activated while the adjustable frequency drive issues warning 8 or alarm 8 (DC undervoltage), the adjustable frequency drive skips the *alarm 68, Safe Stop*, but the STO operation is not affected.

6.3.2 Deactivation of Safe Torque Off

Follow the instructions in *Table 6.2* to deactivate the STO function and resume normal operation based on the restart mode of the STO function.

WARNING

RISK OF INJURY OR DEATH

Reapplying 24 V DC supply to either terminal 37 or 38 terminates the SIL2 STO state, potentially starting the motor. Unexpected motor start may cause personal injuries or death.

- Ensure that all safety measures are taken before reapplying 24 V DC supply to terminals 37 and 38.

Restart mode	Steps to deactivate STO and resume normal operation	Restart mode configuration
Manual restart	<ol style="list-style-type: none"> 1. Reapply 24 V DC supply to terminals 37 and 38. 2. Initiate a reset signal (via serial communication bus, digital I/O or [Reset]/[Off Reset] key on the LCP). 	Default setting. <i>Parameter 5-19 Terminal 37/38 SAFE STOP=[1] Safe Stop Alarm</i>
Automatic restart	Reapply 24 V DC supply to terminals 37 and 38.	<i>Parameter 5-19 Terminal 37/38 SAFE STOP= [3] Safe Stop Warning.</i>

Table 6.2 STO Deactivation

6.3.3 STO Commissioning Test

After installation and before first operation, perform a commissioning test of the installation using STO. Perform the test again after each modification of the installation or application involving the STO.

NOTICE!

A successful commissioning test of the STO function is required after the initial installation and after each subsequent change to the installation.

To perform a commissioning test:

- Follow the instructions in *chapter 6.3.4 Test for STO Applications in Manual Restart Mode* if STO is set to manual restart mode.
- Follow the instructions in *chapter 6.3.5 Test for STO Applications in Automatic Restart Mode* if STO is set to automatic restart mode.

6.3.4 Test for STO Applications in Manual Restart Mode

For applications where *parameter 5-19 Terminal 37/38 SAFE STOP* is set to the default value [1] *Safe Stop Alarm*, conduct the commissioning test as follows.

1. Set *parameter 5-40 Function Relay* to [190] *Safe Function active*.
2. Remove the 24 V DC voltage supply to terminals 37 and 38 using the safety device while the adjustable frequency drive drives the motor (that is, the line power supply is not interrupted).
3. Verify that:
 - 3a The motor coasts. It may take a long time for the motor to stop.
 - 3b The customer relay activates (if connected).
 - 3c If the LCP is mounted, *alarm 68, Safe Stop* shows on the LCP. If the LCP is not mounted, *alarm 68, Safe Stop* is logged in *parameter 15-30 Alarm Log: Error Code*.
4. Reapply 24 V DC to terminals 37 and 38.
5. Ensure that the motor remains in the coasted state, and the customer relay (if connected) remains activated.
6. Send reset signal (via serial communication bus, digital I/O or [Reset]/[Off Reset] key on the LCP).
7. Ensure that the motor becomes operational and runs within the original speed range.

The commissioning test is successfully completed when all the above steps are passed.

6.3.5 Test for STO Applications in Automatic Restart Mode

For applications where *parameter 5-19 Terminal 37/38 SAFE STOP* is set to [3] *Safe Stop Warning*, conduct the commissioning test as follows:

1. Remove the 24 V DC voltage supply to terminals 37 and 38 by the safety device while the adjustable frequency drive drives the motor (that is, the line power supply is not interrupted).
2. Verify that:
 - 2a The motor coasts. Note that it may take a long time for the motor to stop.
 - 2b The customer relay activates (if connected).
 - 2c *Warning 68, Safe Stop W68* shows on the LCP if the LCP is mounted.
 - 2d If the LCP is not mounted, *Warning 68, Safe Stop W68* is logged in *parameter 15-30 Alarm Log: Error Code*.
3. Reapply 24 V DC to terminals 37 and 38.
4. Ensure that the motor becomes operational and runs within the original speed range.

The commissioning test is successfully completed when all the above steps are passed.

NOTICE!

See the warning on the restart behavior in *chapter 6.1 Safety Precautions for STO*.

6.4 Maintenance and Service for STO

- The user is responsible for security measures.
- The adjustable frequency drive parameters can be protected with password.

The functional test consists of two parts:

- Basic functional test.
- Diagnostic functional test.

When all the steps are completed successfully, the functional test is successful.

Basic functional test

If the STO function has not been used for one year, conduct a basic functional test to detect any failure or malfunction of STO.

1. Ensure that *parameter 5-19 Terminal 37/38 SAFE STOP* is set to **[1] Safe Stop Alarm*.
2. Remove the 24 V DC voltage supply for terminals 37 and 38.
3. Check if the LCP displays *alarm 68, Safe Stop*.
4. Verify that the adjustable frequency drive trips the unit.
5. Verify that the motor is coasting and stops completely.
6. Initiate a start signal (via serial communication bus, digital I/O or the LCP), and verify that the motor does not start.
7. Reconnect the 24 V DC voltage supply to terminals 37 and 38.
8. Verify that the motor is not started automatically and restarts only by giving a reset signal (via serial communication bus, digital I/O or [Reset]/ [Off Reset] key on the LCP).

Diagnostic functional test

1. Verify that *warning 68 Safe Stop* and *alarm 68 Safe Stop* do not occur when 24 V supply is connected to terminals 37 and 38.
2. Remove the 24 V supply for terminal 37, and verify that the LCP displays *alarm 188, STO Function Fault* if the LCP is mounted. If the LCP is not mounted, verify that *alarm 188, STO Function Fault* is logged in *parameter 15-30 Alarm Log: Error Code*.
3. Reapply 24 V supply to terminal 37, and verify that resetting the alarm is successful.
4. Remove the 24 V supply for terminal 38 and verify that the LCP displays *alarm 188 STO Function Fault* if the LCP is mounted. If the LCP is not mounted, verify that *alarm 188, STO Function Fault* is logged in *parameter 15-30 Alarm Log: Error Code*.
5. Reapply 24 V supply to terminal 38 and verify that resetting the alarm is successful.

6.5 STO Technical Data

The Failure Modes, Effects and Diagnostic Analysis (FMEDA) is performed based on the following assumptions:

- FC 280 takes 10% of the total failure budget for an SIL2 safety loop.
- Failure rates are based on the Siemens SN29500 database.
- Failure rates are constant; wear-out mechanisms are not included.
- For each channel, the safety-related components are considered to be of type A with a hardware fault tolerance of 0.
- The stress levels are average for an industrial environment and the working temperature of components is up to 85 °C (185 °F).
- A safe error (for example, output in safe state) is repaired within 8 hours.
- No torque output is the safe state.

Safety standards	Safety of Machinery	ISO 13849-1, IEC 62061
	Functional Safety	IEC 61508
Safety function	Safe Torque Off	IEC 61800-5-2
Safety performance	ISO 13849-1	
	Category	Cat. 3
	Diagnostic Coverage (DC)	60% (Low)
	Mean Time to Dangerous Failure (MTTFd)	2400 years (High)
	Performance Level	PL d
	IEC 61508/IEC 61800-5-2/IEC 62061	
	Safety Integrity Level	SIL2
	Probability of Dangerous Failure per Hour (PFH) (High Demand Mode)	7.54E-9 (1/h)
	Probability of Dangerous Failure on Demand (PFD _{avg} for PTI = 20 years) (Low Demand Mode)	6.05E-4
	Safe Failure Fraction (SFF)	> 84%
	Hardware Fault Tolerance (HFT)	1 (Type A, 1oo2D)
	Proof Test Interval ²⁾	20 Years
	Common Cause Failure (CCF)	$\beta = 5\%$; $\beta_D = 5\%$
	Diagnostic Test Interval (DTI)	160 ms
Systematic Capability	SC 2	
Reaction time ¹⁾	Input to output response time	Enclosure sizes K1–K3: Maximum 50 ms Enclosure sizes K4 and K5: Maximum 30 ms

Table 6.3 Technical Data for STO

1) Reaction time is the amount of time from an input signal condition that triggers the STO until the torque is off on the motor.

2) For the way to perform proof test, please refer to chapter 6.4 Maintenance and Service for STO.

7 Application Examples

The examples in this section are intended as a quick reference for common applications.

- Parameter settings are the regional default values unless otherwise indicated (selected in *parameter 0-03 Regional Settings*).
- Parameters associated with the terminals and their settings are shown next to the drawings.
- Required switch settings for analog terminals 53 or 54 are also shown.

NOTICE!

When the STO feature is not used, a jumper wire is required between terminals 12, 37 and 38 for the adjustable frequency drive to operate with factory default programming values.

7

7.1.1 AMA

		Parameters	
		Function	Setting
		Parameter 1-29 Automatic Motor Adaptation (AMA)	[1] Enable complete AMA
		Parameter 5-12 Terminal 27 Digital Input	*[2] Coast inverse
		*=Default value	
		Notes/comments: Set parameter group 1-2* Motor Data according to motor specifications.	
		NOTICE! If terminal 12 and 27 are not connected, set parameter 5-12 Terminal 27 Digital Input to [0] No operation.	

Table 7.1 AMA with T27 Connected

7.1.2 Speed

		Parameters	
		Function	Setting
		Parameter 6-10 Terminal 53 Low Voltage	0.07 V*
		Parameter 6-11 Terminal 53 High Voltage	10 V*
		Parameter 6-14 Terminal 53 Low Ref./Feedb. Value	0
		Parameter 6-15 Terminal 53 High Ref./Feedb. Value	50
		Parameter 6-19 Terminal 53 mode	[1] Voltage mode
		*=Default value	
		Notes/comments:	

Table 7.2 Analog Speed Reference (Voltage)

		Parameters	
		Function	Setting
	130BE205.11	Parameter 6-12 Terminal 53 Low Current	4 mA*
		Parameter 6-13 Terminal 53 High Current	20 mA*
		Parameter 6-14 Terminal 53 Low Ref./Feedb. Value	0
		Parameter 6-15 Terminal 53 High Ref./Feedb. Value	50
		Parameter 6-19 Terminal 53 mode	[0] current mode
		*=Default value	
		Notes/comments:	

Table 7.3 Analog Speed Reference (Current)

		Parameters	
		Function	Setting
	130BE208.11	Parameter 6-10 Terminal 53 Low Voltage	0.07 V*
		Parameter 6-11 Terminal 53 High Voltage	10 V*
		Parameter 6-14 Terminal 53 Low Ref./Feedb. Value	0
		Parameter 6-15 Terminal 53 High Ref./Feedb. Value	50
		Parameter 6-19 Terminal 53 mode	[1] voltage mode
		*=Default value	
		Notes/comments:	

Table 7.4 Speed Reference (Using a Manual Potentiometer)

		Parameters	
		Function	Setting
	130BE209.11	Parameter 5-10 Terminal 18 Digital Input	*[8] Start
		Parameter 5-12 Terminal 27 Digital Input	[19] Freeze Reference
		Parameter 5-13 Terminal 29 Digital Input	[21] Speed Up
		Parameter 5-14 Terminal 32 Digital Input	[22] Slow
		*=Default value	
		Notes/comments:	

Table 7.5 Speed Up/Slow




Figure 7.1 Speed Up/Slow

7.1.3 Start/Stop

		Parameters	
		Function	Setting
		Parameter 5-10 Terminal 18 Digital Input	[8] Start
		Parameter 5-11 Terminal 19 Digital Input	*[10] Reversing
		Parameter 5-12 Terminal 27 Digital Input	[0] No operation
		Parameter 5-14 Terminal 32 Digital Input	[16] Preset ref bit 0
		Parameter 5-15 Terminal 33 Digital Input	[17] Preset ref bit 1
		Parameter 3-10 Preset Reference	Preset ref. 0 25% Preset ref. 1 50% Preset ref. 2 75% Preset ref. 3 100%
		* = Default value	
		Notes/comments:	

Table 7.6 Start/Stop with Reversing and Four Preset Speeds

7.1.4 External Alarm Reset

		Parameters	
		Function	Setting
		Parameter 5-11 Terminal 19 Digital Input	[1] Reset
		*=Default value	
		Notes/comments:	

Table 7.7 External Alarm Reset

7.1.5 Motor Thermistor

NOTICE!

To meet PELV insulation requirements, use reinforced or double insulation on the thermistors.

		Parameters	
		Function	Setting
		Parameter 1-90 Motor Thermal Protection	[2] Thermistor trip
		Parameter 1-93 T Thermistor Source	[1] Analog input 53
		Parameter 6-19 T Terminal 53 mode	[1] Voltage
		* = Default value	
		Notes/comments:	
		If only a warning is needed, set parameter 1-90 Motor Thermal Protection to [1] Thermistor warning.	

Table 7.8 Motor Thermistor

7.1.6 SLC

		Parameters	
		Function	Setting
		Parameter 4-30 Motor Feedback Loss Function	[1] Warning
		Parameter 4-31 Motor Feedback Speed Error	50
		Parameter 4-32 Motor Feedback Loss Timeout	5 s
		Parameter 7-00 S peed PID Feedback Source	[1] 24V encoder
		Parameter 5-70 T erm 32/33 Pulses Per Revolution	1024*
		Parameter 13-00 SL Controller Mode	[1] On
		Parameter 13-01 Start Event	[19] Warning
		Parameter 13-02 Stop Event	[44] Reset key
		Parameter 13-10 Comparator Operand	[21] Warning no.
		Parameter 13-11 Comparator Operator	*[1] ≈
		Parameter 13-12 Comparator Value	61
		Parameter 13-51 SL Controller Event	[22] Comparator 0
		Parameter 13-52 SL Controller Action	[32] Set digital out A low
		Parameter 5-40 F unction Relay	[80] SL digital output A
		* = Default value	
		Notes/comments: If the limit in the feedback monitor is exceeded, <i>warning 61 feedback monitor</i> is issued. The SLC monitors <i>warning 61 feedback monitor</i> . If <i>warning 61 feedback monitor</i> becomes true, relay 1 is triggered. External equipment could indicate that service is required. If the feedback error goes below the limit again within 5 s, the adjustable frequency drive continues and the warning disappears. But relay 1 persists until [Off/Reset] is pressed.	

Table 7.9 Using SLC to Set a Relay

8 Maintenance, Diagnostics and Troubleshooting

8.1 Maintenance and Service

Under normal operating conditions and load profiles, the adjustable frequency drive is maintenance-free throughout its designed lifetime. To prevent breakdown, danger and damage, examine the frequency converter at regular intervals depending on the operating conditions. Replace worn or damaged parts with original spare parts or standard parts. For service and support, contact the local Danfoss supplier.

⚠ WARNING

UNINTENDED START

When the frequency converter is connected to AC mains, DC supply or load sharing, the motor may start at any time. Unintended start during programming, service or repair work can result in death, serious injury or property damage. The motor can start with an external switch, a serial communication bus command, an input reference signal from the LCP, via remote operation using MCT 10 Set-up Software or after a cleared fault condition.

To prevent unintended motor start:

- Disconnect the adjustable frequency drive from line power.
- Press [Off/Reset] on the LCP before programming parameters.
- Completely wire and assemble the frequency converter, motor and any driven equipment before connecting the frequency converter to AC mains, DC supply or load sharing.

8.2 Warning and Alarm Types

Warning/ alarm type	Description
Warning	A warning indicates an abnormal operating condition that leads to an alarm. A warning stops when the abnormal condition is removed.
Alarm	An alarm indicates a fault that requires immediate attention. The fault always triggers a trip or trip lock. Reset the adjustable frequency drive after an alarm. Reset the adjustable frequency drive in any of four ways: <ul style="list-style-type: none"> • Press [Reset]/[Off/Reset]. • Digital reset input command. • Serial communication reset input command. • Auto reset.

Trip

When tripping, the adjustable frequency drive suspends operation to prevent damage to the adjustable frequency drive and other equipment. When a trip occurs, the motor coasts to a stop. The adjustable frequency drive logic continues to operate and monitor the adjustable frequency drive status. After the fault condition is remedied, the adjustable frequency drive is ready for a reset.

Trip lock

When trip locking, the adjustable frequency drive suspends operation to prevent damage to the adjustable frequency drive and other equipment. When a trip lock occurs, the motor coasts to a stop. The adjustable frequency drive logic continues to operate and monitor the adjustable frequency drive status. The adjustable frequency drive starts a trip lock only when serious faults occur that can damage the adjustable frequency drive or other equipment. After the faults are fixed, cycle the input power before resetting the adjustable frequency drive.

8.3 Warning and Alarm Display




Figure 8.1 Warning Display

An alarm or trip-lock alarm shows in the display along with the alarm number.




Figure 8.2 Alarm/Trip Lock Alarm

In addition to the text and alarm code on the adjustable frequency drive display, there are three status indicator lights. The warning indicator light is yellow during a warning. The alarm indicator light is red and flashing during an alarm.




Figure 8.3 Status Indicator Lights

8.4 List of Warnings and Alarms

An (X) marked in *Table 8.1* indicates that the warning or alarm has occurred.

No.	Description	Warning	Alarm	Trip lock	Cause
2	Live zero error	X	X	-	Signal on terminal 53 or 54 is less than 50% of value set in <i>parameter 6-10 Terminal 53 Low Voltage</i> , <i>parameter 6-20 Terminal 54 Low Voltage</i> and <i>parameter 6-22 Terminal 54 Low Current</i> .
3	No motor	X	-	-	No motor has been connected to the output of the adjustable frequency drive.
4	Mains phase loss ¹⁾	X	X	X	Missing phase on supply side, or the voltage imbalance is too high. Check the supply voltage.
7	DC overvoltage ¹⁾	X	X	-	DC link voltage exceeds limit.
8	DC undervoltage ¹⁾	X	X	-	DC link voltage drops below the voltage warning low limit.
9	Inverter overloaded	X	X	-	More than 100% load for too long.
10	Motor ETR overtemperature	X	X	-	Motor is too hot due to more than 100% load for too long.
11	Motor thermistor overtemperature	X	X	-	Thermistor or thermistor connection is disconnected, or the motor is too hot.
12	Torque limit	X	X	-	Torque exceeds value set in either <i>parameter 4-16 Torque Limit Motor Mode</i> or <i>parameter 4-17 Torque Limit Generator Mode</i> .
13	Overcurrent	X	X	X	Inverter peak current limit is exceeded. If this alarm occurs on power-up, check whether power cables are mistakenly connected to the motor terminals.
14	Ground fault	X	X	X	Discharge from output phases to ground.
16	Short circuit		X	X	Short circuit in motor or on motor terminals.
17	Control word timeout	X	X		No communication to the adjustable frequency drive.
25	Brake resistor short-circuited	-	X	X	Brake resistor is short circuited, thus the brake function is disconnected.
26	Brake overload	X	X	-	The power transmitted to the brake resistor over the last 120 s exceeds the limit. Possible corrections: Decrease brake energy via lower speed or longer ramp time.
27	Brake IGBT/Brake chopper short circuited	-	X	X	Brake transistor is short-circuited, thus the brake function is disconnected.
28	Brake check	-	X		Brake resistor is not connected/working.
30	U phase loss	-	X	X	Motor phase U is missing. Check the phase.
31	V phase loss	-	X	X	Motor phase V is missing. Check the phase.
32	W phase loss	-	X	X	Motor phase W is missing. Check the phase.
34	Fieldbus fault	X	X	-	PROFIBUS communication issues have occurred.
35	Option fault	-	X	-	Serial communication bus detects internal errors.
36	Mains failure	X	X	-	This warning/alarm is only active if the supply voltage to the adjustable frequency drive is less than the value set in <i>parameter 14-11 Mains Voltage at Mains Fault</i> , and <i>parameter 14-10 Mains Failure</i> is NOT set to [0] No Function.
38	Internal fault	-	X	X	Contact the local Danfoss supplier.
40	Overload T27	X	-	-	Check the load connected to terminal 27 or remove short circuit connection.

No.	Description	Warning	Alarm	Trip lock	Cause
41	Overload T29	-	-	-	Check the load connected to terminal 29 or remove short circuit connection.
46	Gate drive voltage fault		X	X	
47	24 V supply low	X	X	X	24 V DC may be overloaded.
51	AMA check U_{nom} and I_{nom}	-	X	-	Wrong setting for motor voltage and/or motor current.
52	AMA low I_{nom}	-	X	-	Motor current is too low. Check the settings.
53	AMA big motor	-	X	-	The power size of the motor is too large for the AMA to operate.
54	AMA small motor	-	X	-	The power size of the motor is too small for the AMA to operate.
55	AMA parameter range	-	X	-	The parameter values of the motor are outside of the acceptable range. AMA does not run.
56	AMA interrupt	-	X	-	The AMA is interrupted.
57	AMA timeout	-	X	-	
58	AMA internal	-	X	-	Contact Danfoss.
59	Current limit	X	X	-	Adjustable frequency drive overload.
61	Encoder loss	X	X	-	
63	Mechanical brake low	-	X	-	Actual motor current has not exceeded release brake current within start delay time window.
65	Control card temp	X	X	X	The cut-out temperature of the control card is 80 °C (176 °F).
67	Option change	-	X	-	A new option is detected or a mounted option is removed.
68	Safe Stop	X	X	-	STO is activated. If STO is in manual restart mode (default), to resume normal operation, apply 24 V DC to terminals 37 and 38 and initiate a reset signal (via serial communication bus, digital I/O or [Reset]/[Off Reset] key). If STO is in automatic restart mode, applying 24 V DC to terminals 37 and 38 automatically resumes the adjustable frequency drive to normal operation. Refer to <i>chapter 6.3 STO Commissioning</i> for more details.
69	Power card temp	X	X	X	
80	Drive initialized to default value		X		All parameter settings are initialized to default settings.
87	Auto DC braking	X	-	-	Occurs in IT line power when the adjustable frequency drive coasts and the DC voltage is higher than 830 V for 400 V units, and 425 V for 200 V units. Energy on DC link is consumed by the motor. This function can be enabled/disabled in <i>parameter 0-07 Auto DC Braking</i> .
88	Option detection	-	X	X	The option is removed successfully.
95	Broken belt	X	X	-	
120	Position control fault	-	X	-	
188	STO internal fault	-	X	-	24 V DC supply is connected to only one of the 2 STO terminals (37 and 38), or a failure in STO channels is detected. Make sure that both terminals are connected to 24 V DC supply, and the discrepancy between the signals at the two terminals is less than 12 ms. If the fault still occurs, contact the local Danfoss supplier.
nw run	Not while running	-	-	-	Parameter can only be changed when the motor is stopped.

No.	Description	Warning	Alarm	Trip lock	Cause
Err.	An incorrect password was entered	-	-	-	Occurs when using an incorrect password for changing a password-protected parameter.

Table 8.1 Warnings and Alarms Code List

1) These faults may be caused by line power distortions. Installing a Danfoss line filter may rectify this problem.

For diagnosis, read out the alarm words, warning words, and extended status words.

8.5 Troubleshooting

8

Symptom	Possible cause	Test	Solution
Motor not running	LCP stop	Check if [Off] has been pressed.	Press [Auto On] or [Hand On] (depending on operating mode) to run the motor.
	Missing start signal (standby)	Check <i>parameter 5-10 Terminal 18 Digital Input</i> for correct setting for terminal 18 (use default setting).	Apply a valid start signal to start the motor.
	Motor coast signal active (coasting)	Check <i>parameter 5-12 Terminal 27 Digital Input</i> for correct setting for terminal 27 (use default setting).	Apply 24 V on terminal 27 or program this terminal to [0] <i>No operation..</i>
	Wrong reference signal source	Check the following: <ul style="list-style-type: none"> The reference signal is local, remote or bus reference? Preset reference is active? Terminal connection is correct? The scaling of terminals is correct? The reference signal is available? 	Program correct settings. Set preset reference active in parameter group 3-1* <i>References</i> . Check for correct wiring. Check scaling of terminals. Check reference signal.
Motor is running in the wrong direction.	Motor rotation limit	Check that <i>parameter 4-10 Motor Speed Direction</i> is programmed correctly.	Program correct settings.
	Active reversing signal	Check if a reversing command is programmed for the terminal in parameter group 5-1* <i>Digital inputs</i> .	Deactivate reversing signal.
	Wrong motor phase connection	Change <i>parameter 1-06 Clockwise Direction</i> .	
Motor is not reaching maximum speed	Frequency limits are set incorrectly	Check output limits in <i>parameter 4-14 Motor Speed High Limit [Hz]</i> and <i>parameter 4-19 Max Output Frequency</i> .	Program correct limits.
	Reference input signal not scaled correctly	Check reference input signal scaling in 6-** <i>Analog I/O mode</i> and parameter group 3-1* <i>References</i> .	Program correct settings.
Motor speed is unstable	Possible incorrect parameter settings	Check the settings of all motor parameters, including all motor compensation settings. For closed-loop operation, check PID settings.	Check settings in parameter group 6-** <i>Analog I/O mode</i> .
Motor runs roughly.	Possible overmagnetization	Check for incorrect motor settings in all motor parameters.	Check motor settings in parameter groups 1-2* <i>Motor data</i> , 1-3* <i>Adv motor data</i> and 1-5* <i>Load indep. setting</i> .

Symptom	Possible cause	Test	Solution
Motor does not brake	Possible incorrect settings in the brake parameters. Possible too short ramp-down times.	Check brake parameters. Check ramp time settings.	Check parameter group 2-0* <i>DC brake</i> and 3-0* <i>Reference limits</i> .
Open power fuses or circuit breaker trip	Phase-to-phase short	Motor or panel has a short phase-to-phase. Check motor and panel phase for shorts.	Eliminate any shorts detected.
	Motor overload	Motor is overloaded for the application.	Perform the start-up test and verify that motor current is within specifications. If motor current is exceeding nameplate full load current, the motor may run only with reduced load. Review the specifications for the application.
	Loose connections	Perform pre-start-up check for loose connections.	Tighten loose connections.
Line power current imbalance greater than 3%	Problem with line power (See <i>Alarm 4, Mains phase loss</i> description)	Rotate input power leads into the adjustable frequency drive one position: A to B, B to C, C to A.	If the imbalanced leg follows the wire, it is a power problem. Check line power supply.
	Problem with the adjustable frequency drive unit	Rotate input power leads into the adjustable frequency drive one position: A to B, B to C, C to A.	If the imbalanced leg stays on same input terminal, it is a problem with the unit. Contact the supplier.
Motor current imbalance greater than 3%	Problem with motor or motor wiring	Rotate output motor leads one position: U to V, V to W, W to U.	If the imbalanced leg follows the wire, the problem is in the motor or motor wiring. Check motor and motor wiring.
	Problem with the adjustable frequency drive unit	Rotate output motor leads one position: U to V, V to W, W to U.	If the imbalanced leg stays on same output terminal, it is a problem with the unit. Contact the supplier.
Acoustic noise or vibration (for example, a fan blade is making noise or vibrations at certain frequencies)	Resonances, for example, in the motor/fan system	Bypass critical frequencies by using parameters in parameter group 4-6* <i>Speed Bypass</i> .	Check if noise and/or vibration have been reduced to an acceptable limit.
		Turn off overmodulation in <i>parameter 14-03 Overmodulation</i> .	
		Increase resonance damping in <i>parameter 1-64 Resonance Dampening</i> .	

Table 8.2 Troubleshooting

9 Specifications

9.1 Electrical Data

Adjustable frequency driver typical shaft output [kW] (hp)	HK37 0.37 (0.5)	HK55 0.55 (0.75)	HK75 0.75 (1.0)	H1K1 1.1 (1.5)	H1K5 1.5 (2.0)	H2K2 2.2 (3.0)	H3K0 3 (4)
Enclosure IP20	K1	K1	K1	K1	K1	K1	K2
Output current							
Shaft output [kW] (hp)	0.37 (0.5)	0.55 (0.75)	0.75 (1.0)	1.1 (1.5)	1.5 (2.0)	2.2 (3.0)	3 (4)
Continuous (3x380–440 V) [A]	1.2	1.7	2.2	3	3.7	5.3	7.2
Continuous (3x441–480 V) [A]	1.1	1.6	2.1	2.8	3.4	4.8	6.3
Intermittent (60 s overload) [A]	1.9	2.7	3.5	4.8	5.9	8.5	11.5
Continuous kVA (400 V AC) [kVA]	0.84	1.18	1.53	2.08	2.57	3.68	4.99
Continuous kVA (480 V AC) [kVA]	0.9	1.3	1.7	2.5	2.8	4.0	5.2
Maximum input current							
Continuous (3x380–440 V) [A]	1.2	1.6	2.1	2.6	3.5	4.7	6.3
Continuous (3x441–480 V) [A]	1.0	1.2	1.8	2.0	2.9	3.9	4.3
Intermittent (60 s overload) [A]	1.9	2.6	3.4	4.2	5.6	7.5	10.1
Additional specifications							
Maximum cable cross-section (line power, motor, brake and load sharing) [mm ² (AWG)]	4(12)						
Estimated power loss at rated maximum load [W] ¹⁾	20.88	25.16	30.01	40.01	52.91	73.97	94.81
Weight, enclosure IP20 [kW] (hp)	2.3 (5.1)	2.3 (5.1)	2.3 (5.1)	2.3 (5.1)	2.3 (5.1)	2.5 (5.5)	3.6 (7.94)
Efficiency [%] ²⁾	96.2	97.0	97.2	97.4	97.4	97.6	97.5

Table 9.1 Line Power Supply 3x380–480 V AC

Adjustable frequency driver typical shaft output [kW] (hp)	H4K0 4 (5)	H5K5 5.5 (7.5)	H7K5 7.5 (10)	H11K 11 (15)	H15K 15 (20)	H18K 18.5 (25)	H22K 22 (30)
IP20	K2	K2	K3	K4	K4	K5	K5
Output current							
Shaft output [kW] (hp)	4 (5)	5.5 (7.5)	7.5 (10)	11 (15)	15 (20)	18.5 (25)	22 (30)
Continuous (3x380–440 V) [A]	9	12	15.5	23	31	37	42.5
Continuous (3x441–480 V) [A]	8.2	11	14	21	27	34	40
Intermittent (60 s overload) [A]	14.4	19.2	24.8	34.5	46.5	55.5	63.8
Continuous kVA (400 V AC) [kVA]	6.24	8.32	10.74	15.94	21.48	25.64	29.45
Continuous kVA (480 V AC) [kVA]	6.8	9.1	11.6	17.5	22.4	28.3	33.3
Maximum input current							
Continuous (3x380–440 V) [A]	8.3	11.2	15.1	22.1	29.9	35.2	41.5
Continuous (3x441–480 V) [A]	6.8	9.4	12.6	18.4	24.7	29.3	34.6
Intermittent (60 s overload) [A]	13.3	17.9	24.2	33.2	44.9	52.8	62.3
Additional specifications							
Maximum cable size (line power, motor, brake) [mm ² (AWG)]	4(12)			16(6)			
Estimated power loss at rated maximum load [W] ¹⁾	115.5	157.54	192.83	289.53	393.36	402.83	467.52
Weight enclosure IP20 [kg] (hp)	3.6 (7.94)	3.6 (7.94)	4.1 (9.04)	9.4 (20.7)	9.5 (20.94)	12.3 (27.12)	12.5 (27.6)
Efficiency [%] ²⁾	97.6	97.7	98.0	97.8	97.8	98.1	97.9

Table 9.2 Line Power Supply 3x380–480 V AC

1) The typical power loss is at nominal load conditions and expected to be within $\pm 15\%$ (tolerance relates to variances in voltage and cable conditions).

Values are based on a typical motor efficiency (IE2/IE3 border line). Motors with lower efficiency add to the power loss in the adjustable frequency drive and motors with high efficiency reduce power loss.

Applies for dimensioning of adjustable frequency drive cooling. If the switching frequency is higher than the default setting, the power losses may rise. LCP and typical control card power consumptions are included. Further options and customer load may add up to 30 W to the losses (though typical only 4 W extra for a fully loaded control card or serial communication bus).

For power loss data according to EN 50598-2, refer to www.danfoss.com/vltenergyefficiency.

2) Measured using 50 m (165 ft) shielded motor cables at rated load and rated frequency. For energy efficiency class, see chapter 9.4 Ambient Conditions. For part load losses, see www.danfoss.com/vltenergyefficiency.

9.2 Line Power Supply (3-phase)

Line power supply (L1, L2, L3)

Supply terminals L1, L2, L3

Supply voltage 380–480 V: -15% (-25%)¹⁾ to +10%

1) The adjustable frequency drive can run at -25% input voltage with reduced performance. The maximum output power of the adjustable frequency drive is 75% if input voltage is -25% and 85% if input voltage is -15%.

Full torque cannot be expected at AC line voltage lower than 10% below the lowest rated supply voltage of the adjustable frequency drive.

Supply frequency 50/60 Hz ±5%

Maximum imbalance temporary between line phases 3.0% of rated supply voltage

True power factor (λ) ≥0.9 nominal at rated load

Displacement power factor ($\cos \phi$) near unity (>0.98)

Switching on input supply L1, L2, L3 (power-ups) ≤7.5 kW (10 hp) Maximum two times/minute

Switching on input supply L1, L2, L3 (power-ups) 11–22 kW (15–30 hp) Maximum one time/minute

The unit is suitable for use on a circuit capable of delivering less than 5000 RMS symmetrical Amperes, 480 V maximum.

9.3 Motor Output and Motor Data

Motor output (U, V, W)

Output voltage 0–100% of supply voltage

Output frequency 0–500 Hz

Output frequency in VVC⁺ Mode 0–200 Hz

Switching on output Unlimited

Ramp time 0.05–3600 s

Torque characteristics

Starting torque (constant torque) Maximum 160% for 60 s¹⁾

Overload torque (constant torque) Maximum 160% for 60 s¹⁾

Starting torque (variable torque) Maximum 110% for 60 s¹⁾

Overload torque (variable torque) Maximum 110% for 60 s

Starting current Maximum 200% for 1 s

Torque rise time in VVC⁺ (independent of f_{sw}) Maximum 50 ms

1) Percentage relates to the nominal torque.

9.4 Ambient Conditions

Ambient Conditions

IP class IP20

Vibration test, all enclosure sizes 1.0 g

Relative humidity 5–95% (IEC 721-3-3; Class 3K3 (non-condensing) during operation

Ambient temperature (at DPWM switching mode)

- with derating maximum 55°C (131 °F)¹⁾

- at full continuous output current with some power size maximum 50 °C (122 °F)

- at full continuous output current maximum 45 °C (113 °F)

Minimum ambient temperature during full-scale operation 0 °C (32 °F)

Minimum ambient temperature at reduced performance -10 °C (14 °F)

Temperature during storage/transport -25 to +65/70 °C (-13 to + 149/158 °F)

Maximum altitude above sea level without derating 1000 m (3300 ft)

Maximum altitude above sea level with derating 3000 m (10000 ft)

EMC standards, emission EN 61800-3, EN 61000-3-2, EN 61000-3-3, EN 61000-3-11,

EMC standards, immunity	EN 61000-3-12, EN 61000-6-3/4, EN 55011, IEC 61800-3 EN 61800-3, EN 61000-6-1/2, EN 61000-4-2, EN 61000-4-3 EN 61000-4-4, EN 61000-4-5, EN 61000-4-6, EN 61326-3-1
Energy efficiency class ²⁾	IE2

1) Refer to *Special Conditions in the Design Guide* for:

- Derating for high ambient temperature.
- Derating for high altitude.

2) Determined according to EN50598-2 at:

- Rated load
- 90% rated frequency
- Switching frequency factory setting
- Switching pattern factory setting

9.5 Cable Specifications

Cable lengths and cross-sections¹⁾

Maximum motor cable length, shielded	50 m (165 ft)
Maximum motor cable length, non-shielded	75 m (250 ft)
Maximum cross-section to control terminals, flexible/rigid wire	2.5 mm ² /14 AWG
Minimum cross-section to control terminals	0.55 mm ² /30 AWG
Maximum STO input cable length, unshielded	20 m (65 ft)

1) For power cables, see Table 9.1 to Table 9.2.

9.6 Control Input/Output and Control Data

Digital inputs

Terminal number	18, 19, 27 ¹⁾ , 29, 32, 33
Logic	PNP or NPN
Voltage level	0–24 V DC
Voltage level, logic 0 PNP	<5 V DC
Voltage level, logic 1 PNP	>10 V DC
Voltage level, logic 0 NPN	>19 V DC
Voltage level, logic 1 NPN	<14 V DC
Maximum voltage on input	28 V DC
Pulse frequency ranges	4–32 kHz
(Duty cycle) minimum pulse width	4.5 ms
Input resistance, R _i	Approximately 4 kΩ

1) Terminals 27 can also be programmed as output.

STO inputs¹⁾

Terminal number	37, 38
Voltage level	0–30 V DC
Voltage level, low	<1.8 V DC
Voltage level, high	>20 V DC
Maximum voltage on input	30 V DC
Minimum input current (each pin)	6 mA

1) Refer to chapter 6 *Safe Torque Off (STO)* for more details about STO inputs.

Analog inputs

Number of analog inputs	2
Terminal number	53 ¹⁾ , 54
Modes	Voltage or current
Mode select	Software
Voltage level	0–10 V
Input resistance, R _i	approximately 10 kΩ
Maximum voltage	-15 V to +20 V
Current level	0/4 to 20 mA (scaleable)
Input resistance, R _i	approximately 200 Ω
Maximum current	30 mA
Resolution for analog inputs	11 bit
Accuracy of analog inputs	Maximum error 0.5% of full scale
Bandwidth	100 Hz

The analog inputs are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

1) Terminal 53 supports only voltage mode and can also be used as digital input.




Figure 9.1 Analog Inputs

Pulse inputs

Programmable pulse inputs	2
Terminal number pulse	29, 33
Maximum frequency at terminal 29, 33	32 kHz (push-pull driven)
Maximum frequency at terminal 29, 33	5 kHz (open collector)
Minimum frequency at terminal 29, 33	4 Hz
Voltage level	See the section on digital input.
Maximum voltage on input	28 V DC
Input resistance, R _i	Approximately 4 kΩ
Pulse input accuracy (0.1–1 kHz)	Maximum error: 0.1% of full scale
Pulse input accuracy (1–32 kHz)	Maximum error: 0.05% of full scale

Digital outputs

Programmable digital/pulse outputs	1
Terminal number	27
Voltage level at digital/frequency output	0–24 V
Maximum output current (sink or source)	40 mA
Maximum load at frequency output	1 kΩ
Maximum capacitive load at frequency output	10 nF
Minimum output frequency at frequency output	4 Hz
Maximum output frequency at frequency output	32 kHz
Accuracy of frequency output	Maximum error: 0.1% of full scale
Resolution of frequency output	10 bit

1) Terminal 27 can also be programmed as input.

The digital output is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Analog outputs

Number of programmable analog outputs	1
Terminal number	42
Current range at analog output	0/4–20 mA
Maximum resistor load to common at analog output	500 Ω
Accuracy on analog output	Maximum error: 0.8% of full scale
Resolution on analog output	10 bit

The analog output is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Control card, 24 V DC output

Terminal number	12, 13
Maximum load	100 mA

The 24 V DC supply is galvanically isolated from the supply voltage (PELV), but has the same potential as the analog and digital inputs and outputs.

Control card, +10 V DC output

Terminal number	50
Output voltage	10.5 V ±0.5 V
Maximum load	15 mA

The 10 V DC supply is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Control card, RS485 serial communication

Terminal number	68 (PTX+, RX+), 69 (NTX-, RX-)
Terminal number 61	Common for terminals 68 and 69

The RS485 serial communication circuit is galvanically isolated from the supply voltage (PELV).

Relay outputs

Programmable relay outputs	1
Relay 01	01–03 (NC), 01–02 (NO)
Maximum terminal load (AC-1) ¹⁾ on 01–02 (NO) (Resistive load)	250 V AC, 3 A
Maximum terminal load (AC-15) ¹⁾ on 01–02 (NO) (Inductive load @ cosφ 0.4)	250 V AC, 0.2 A
Maximum terminal load (DC-1) ¹⁾ on 01–02 (NO) (Resistive load)	30 V DC, 2 A
Maximum terminal load (DC-13) ¹⁾ on 01–02 (NO) (Inductive load)	24 V DC, 0.1 A
Maximum terminal load (AC-1) ¹⁾ on 01–03 (NC) (Resistive load)	250 V AC, 3 A
Maximum terminal load (AC-15) ¹⁾ on 01–03 (NC) (Inductive load @ cosφ 0.4)	250 V AC, 0.2 A
Maximum terminal load (DC-1) ¹⁾ on 01–03 (NC) (Resistive load)	30 V DC, 2 A
Minimum terminal load on 01–03 (NC), 01–02 (NO)	24 V DC 10 mA, 24 V AC 20 mA

¹⁾ IEC 60947 parts 4 and 5

The relay contacts are galvanically isolated from the rest of the circuit by reinforced isolation.

Control card performance

Scan interval	1 ms
---------------	------

Control characteristics

Resolution of output frequency at 0–500 Hz	±0.003 Hz
System response time (terminals 18, 19, 27, 29, 32 and 33)	≤2 ms
Speed control range (open-loop)	1:100 of synchronous speed
Speed accuracy (open-loop)	±0.5% of nominal speed
Speed accuracy (closed-loop)	±0.1% of nominal speed

All control characteristics are based on a 4-pole asynchronous motor.

9.7 Connection Tightening Torques

Make sure to use the right torques when tightening all electrical connections. Too low or too high torque may cause electrical connection problems. Use a torque wrench to ensure that correct torques are applied.

Enclosure type	Power [kW] (hp)	Torque [Nm]					
		Line power	Motor	DC connection	Brake	Ground	Control/Relay
K1	0.37–2.2 (0.5–3)	0.8	0.8	0.8	0.8	3	0.5
K2	3.0–5.5 (4–7.5)	0.8	0.8	0.8	0.8	3	0.5
K3	7.5 (10)	0.8	0.8	0.8	0.8	3	0.5
K4	11–15 (15–20)	1.2	1.2	1.2	1.2	1.6	0.5
K5	18.5–22 (25–30)	1.2	1.2	1.2	1.2	1.6	0.5

Table 9.3 Tightening Torques

9.8 Fuses and Circuit Breakers

Use fuses and/or circuit breakers on the supply side to protect service personnel and equipment from injuries and damage in case of component breakdown inside the adjustable frequency drive (first fault).

9

Branch circuit protection

All branch circuits in an installation (including switch gear and machines) must be protected against short circuit and overcurrent according to national/international regulations.

NOTICE!

The recommendations do not cover branch circuit protection for UL.

Table 9.4 lists the recommended fuses and circuit breakers that have been tested.

⚠ WARNING

PERSONAL INJURY AND EQUIPMENT DAMAGE RISK

Malfunction or failing to follow the recommendations may result in personal risk and damage to the adjustable frequency drive and other equipment.

- Select fuses according to recommendations. Possible damage can be limited to be inside the adjustable frequency drive.

NOTICE!

Using fuses and/or circuit breakers is mandatory to ensure compliance with IEC 60364 for CE.

Danfoss recommends using the fuses and circuit breakers in Table 9.4 on a circuit capable of delivering 5000 A_{rms} (symmetrical) 380–480 V depending on the adjustable frequency drive voltage rating. With the proper fuses and/or circuit breakers, the adjustable frequency drive short circuit current rating (SCCR) is 5000 A_{rms}.

Enclosure size	Power [kW] (hp)	CE compliance fuse	LVD circuit breaker
K1	0.37–2.2 (0.5–3)	gG-10	PKZM0-16
K2	3.0–5.5 (4–7.5)	gG-25	PKZM0-20
K3	7.5 (10)	gG-32	PKZM0-25
K4	11–15 (15–20)	gG-50	
K5	18.5–22 (25–30)	gG-80	

Table 9.4 CE Fuse, 380–480 V

9.9 Enclosure Sizes, Power Ratings and Dimensions

See Figure 3.2 for the dimensions, and the top and bottom mounting holes.

Power Size [kW (hp)]	Enclosure size	K1						K2			K3	K4		K5	
		0.37 (0.5)	0.55 (0.75)	0.75 (1.0)	1.1 (1.5)	1.5 (2.0)		2.2 (3.0)			–	–	–		
Power Size [kW (hp)]	Single-phase 200–240 V	0.37 (0.5)	0.55 (0.75)	0.75 (1.0)	1.1 (1.5)	1.5 (2.0)		2.2 (3.0)			–	–	–		
	3-phase 200–240 V	0.37 (0.5)	0.55 (0.75)	0.75 (1.0)	1.1 (1.5)	1.5 (2.0)		2.2 (3.0)			3.7 (5)	–	–		
	3-phase 380–480 V	0.37 (0.5)	0.55 (0.75)	0.75 (1.0)	1.1 (1.5)	1.5 (2.0)	2.2 (3.0)	3 (4)	4 (5)	5.5 (7.5)	7.5 (10)	11 (15)	15 (20)	18.5 (25)	22 (30)
Dimensions [mm] (in)	Height A	210 (8.27)						272.5 (10.73)			272.5 (10.73)	317.5 (12.5)		410 (16.14)	
	Width B	75 (2.95)						90 (3.54)			115 (4.53)	133 (5.24)		150 (5.91)	
	Depth C	168 (6.61)						168 (6.61)			168 (6.61)	245 (9.65)		245 (9.65)	
Mounting holes	a	198 (7.8)						260 (10.24)			260 (10.24)	297.5 (11.71)		390 (15.35)	
	b	60 (2.36)						70 (2.76)			90 (3.54)	105 (4.13)		120 (4.72)	
	c	5 (0.2)						6.4 (0.25)			6.5 (0.26)	8 (0.315)		7.8 (0.307)	
	d	9 (0.35)						11 (0.43)			11 (0.43)	12.4 (0.488)		12.6 (0.496)	
	e	4.5 (0.177)						5.5 (0.22)			5.5 (0.22)	6.8 (0.27)		7 (0.28)	
	f	7.3 (0.287)						8.1 (0.319)			9.2 (0.362)	11 (0.43)		11.2 (0.44)	

Table 9.5 Enclosure Sizes, Power Ratings and Dimensions

10 Appendix

10.1 Symbols, Abbreviations and Conventions

°C	Degrees celsius
AC	Alternating current
AEO	Automatic energy optimization
AWG	American wire gauge
AMA	Automatic motor adaptation
DC	Direct current
EMC	Electromagnetic compatibility
ETR	Electronic thermal relay
$f_{M,N}$	Nominal motor frequency
FC	Adjustable frequency drive
I_{INV}	Rated inverter output current
I_{LIM}	Current limit
$I_{M,N}$	Nominal motor current
$I_{VLT,MAX}$	Maximum output current
$I_{VLT,N}$	Rated output current supplied by the adjustable frequency drive
IP	Ingress protection
LCP	Local control panel
MCT	Motion control tool
n_s	Synchronous motor speed
$P_{M,N}$	Nominal motor power
PELV	Protective extra low voltage
PCB	Printed circuit board
PM Motor	Permanent magnet motor
PWM	Pulse width modulation
RPM	Revolutions per minute
STO	Safe torque off
T_{LIM}	Torque limit
$U_{M,N}$	Nominal motor voltage

Table 10.1 Symbols and Abbreviations

Conventions

- All dimensions are in (in [mm]).
- An asterisk (*) indicates the default option of a parameter.
- Numbered lists indicate procedures.
- Bullet lists indicate other information.
- Italicized text indicates:
 - Cross reference
 - Link
 - Parameter name

10.2 Parameter Menu Structure

0-51	Operation/Display	*[0]	>No copy	[2]	[4]	[1]	>Sine Ramp<
0-0*	Basic Settings	[1]	>Copy from setup 1<	1-30	1-93	[2]	>Sine 2 Ramp<
0-01	Language	[2]	>Copy from setup 2<	1-31	2-0*	3-41	Ramp 1 Ramp Up Time
0-03	Regional Settings	[9]	>Copy from Factory setup<	1-33	2-0*	3-42	>0.05-3600 s< * Size related
0-04	Operating State at Power-up	0-6*	Password	1-35	2-01	3-42	Ramp 1 Ramp Down Time
0-06	GridType	0-60	Main Menu Password	1-37	2-02	3-5*	>0.05-3600 s< * Size related
[10]	>380-440V/50Hz/IT-grid<	1-0*	Load and Motor General Settings	1-38	2-04	3-5*	Ramp 2 Type
[11]	>380-440V/50Hz/Delta<	1-00	Configuration Mode	1-39	2-06	3-51	Ramp 2 Ramp Up Time
[12]	>380-440V/50Hz<	[0]	>Open Loop<	1-40	2-07	3-52	Ramp 2 Ramp Down Time
[20]	>440-480V/50Hz/IT-grid<	[1]	>Speed closed loop<	1-41	2-1*	3-6*	Ramp 3
[21]	>440-480V/50Hz/Delta<	[1]	>Torque closed loop<	1-42	2-10	3-60	Ramp 3 Type
[22]	>440-480V/50Hz<	[2]	>Process closed loop<	1-43	*[0]	3-61	Ramp 3 Ramp up Time
[110]	>380-440V/60Hz/IT-grid<	[3]	>Torque open loop<	1-44	[1]	3-62	Ramp 3 Ramp down Time
[111]	>380-440V/60Hz/Delta<	[4]	>Surface Winder<	1-50	[2]	3-7*	Ramp 4
[112]	>380-440V/60Hz<	[6]	>Extended PID Speed OL<	1-52	2-11	3-70	Ramp 4 Type
[120]	>440-480V/60Hz/IT-grid<	[7]	Motor Control Principle	1-55	2-12	3-71	Ramp 4 Ramp up Time
[121]	>440-480V/60Hz/Delta<	[1]	>VVC<	1-56	2-14	3-72	Ramp 4 Ramp Down Time
[122]	>440-480V/60Hz<	[0]	>Uf<	1-60	2-16	3-8*	Other Ramps
0-07	Auto DC Braking	*[1]	Torque Characteristics	1-61	2-17	3-80	Jog Ramp Time
0-1*	Set-up Operations	*[0]	>Constant torque<	1-62	*[0]	3-81	Quick Stop Ramp Time
0-10	Active Set-up	[1]	>Variable Torque<	1-63	[1]	3-9*	Digital Potentiometer
*[1]	>Set-up 1<	[2]	>Auto Energy Optim. CT<	1-64	[2]	3-90	Step Size
[2]	>Set-up 2<	[1]	Clockwise Direction	1-65	2-19	3-92	Power Restore
[9]	>Multi Set-up<	0-11	Motor Control Bandwidth	1-66	2-20	3-93	Maximum Limit
0-11	Programming Set-up	1-08	Motor Selection	1-67	2-22	3-94	Minimum Limit
0-12	Link Setups	1-1*	Motor Construction	1-71	3-0*	3-95	Ramp Delay
0-13	Readout: Edit Set-ups / Channel	1-10	Damping Gain	1-72	3-0*	3-96	Maximum Limit Switch Reference
0-14	Readout: Selection	1-14	Low Speed Filter Time Const.	1-73	3-0*	4-1*	Limits / Warnings
*[0]	None	1-15	High Speed Filter Time Const.	[0]	*[0]	4-10	Motor Speed Direction
[1]	>Simple Process Close Loop<	1-16	Voltage filter time const.	[1]	[1]	[0]	>Clockwise<
[2]	>Local/Remote<	1-17	Motor Data	[2]	3-01	*[2]	>Both directions<
[3]	>Speed Open Loop<	1-20	Motor Power	[3]	3-02	4-12	Motor Speed Low Limit [Hz]
[4]	>Simple Speed Close Loop<	[2]	>0.12 kW - 0.16 hp<	[4]	3-03	4-14	Motor Speed High Limit [Hz]
[5]	>Multi Speed<	[3]	>0.18 kW - 0.25 hp<	[5]	3-04	4-16	Torque Limit Motor Mode
[6]	>OGD Function<	[4]	>0.25 kW - 0.33 hp<	[6]	[1]	4-18	Current Limit
0-2*	LCP Display	[5]	>0.37 kW - 0.5 hp<	[7]	3-1*	4-19	Max Output Frequency
0-20	Display Line 1.1 Small	[6]	>0.55 kW - 0.75 hp<	[8]	3-10	4-2*	Limit Factors
0-21	Display Line 1.2 Small	[7]	>1.1 kW - 1.5 hp<	[9]	3-11	4-20	Torque Limit Factor Source
0-22	Display Line 1.3 Small	[8]	>1.5 kW - 2 hp<	[10]	3-12	4-21	Speed Limit Factor Source
0-23	Display Line 2 Large	[9]	>2.2 kW - 3 hp<	[11]	3-13	4-22	Break Away Boost
0-24	Display Line 3 Large	[10]	>3 kW - 4 hp<	[12]	3-14	4-3*	Motor Fb Monitor
0-3*	LCP Custom Readout	[11]	>3.7 kW - 5 hp<	[13]	3-15	4-31	Motor Feedback Loss Function
0-30	Custom Readout Min Value	[12]	>4 kW - 5.4 hp<	[14]	[0]	4-32	Motor Feedback Speed Error
0-31	Custom Readout Max Value	[13]	>5.5 kW - 7.5 hp<	[15]	*[1]	4-32	Motor Feedback Loss Timeout
0-32	Custom Readout Text 1	[14]	>7.5 kW - 10 hp<	[16]	[2]	4-4*	Adj. Warnings 2
0-33	Display Text 1	[15]	>11 kW - 15 hp<	[17]	[7]	4-40	Warning Freq. Low
0-38	Display Text 2	[16]	>15 kW - 20 hp<	[18]	[8]	4-41	Warning Freq. High
0-39	Display Text 3	[17]	>18.5 kW - 25 hp<	[19]	[20]	4-5*	Adj. Warnings
0-40	[Hand on] Key on LCP	[18]	>22 Motor Voltage	[20]	[32]	4-50	Warning Current Low
0-42	[Off/Reset] Key on LCP	[19]	Motor Frequency	[21]	3-16	4-51	Warning Current High
0-44	[Off/Reset] Key on LCP	[22]	Motor Current	[22]	3-17	4-54	Warning Reference Low
0-5*	Copy/Save	1-23	Motor Nominal Speed	[23]	3-18	4-55	Warning Reference High
0-50	LCP Copy	1-24	Motor Cont. Rated Torque	[24]	3-4*	4-56	Warning Feedback Low
*[0]	>No copy<	1-25	Automatic Motor Adaption (AMA)	[25]	*[0]	4-57	Warning Feedback High
[1]	>All to LCP<	1-26	>Off<	[26]	[10]	4-58	Missing Motor Phase Function
[2]	>All from LCP<	*[0]	>Enable Complete AMA<	[27]			
[3]	>Size indep. from LCP<	[1]					
0-51	Set-up Copy	[1]					

4-6*	Speed Bypass	[155]	>HW Limit Positive Inv<	[41]	>Below reference, low<	[15]	>Out of frequency range<	5-42	Off Delay, Relay
4-61	Bypass Speed From [Hz]	[156]	>HW Limit Negative Inv<	[42]	>Above ref, high<	[16]	>Below frequency, low<	5-5*	Pulse Input
4-63	Bypass Speed To [Hz]	[157]	>Pos. Quick Stop Inv<	[43]	>Extended PID Limit<	[17]	>Above frequency, high<	5-50	Term. 29 Low Frequency
5-5**	Digital In/Out	[160]	>Go To Target Pos<	[45]	>Bus ctrl.<	[18]	>Out of feedb. range<	5-51	Term. 29 High Frequency
5-0*	Digital I/O mode	[162]	>Pos. Idx Bit0<	[46]	>Bus control, timeout: On<	[19]	>Below feedback, low<	5-52	Term. 29 Low Ref./Feedb. Value
5-00	Digital I/O Mode	[163]	>Pos. Idx Bit1<	[47]	>Bus control, timeout: Off<	[20]	>Above feedback, high<	5-53	Term. 29 High Ref./Feedb. Value
*[0]	>PNP<	[164]	>Pos. Idx Bit2<	[55]	>Pulse output <	[21]	>Thermal warning<	5-55	Term. 33 Low Frequency
[1]	>NPN<	[171]	>Limit switch ccw inverse<	[56]	>Heat sink cleaning warning, high<	[22]	>Ready, no thermal warning<	5-56	Term. 33 High Frequency
5-01	Terminal 27 Mode	[172]	>Limit switch cw inverse<	[60]	>Comparator 0<	[23]	>Remote,ready,no TW<	5-57	Term. 33 Low Ref./Feedb. Value
5-02	Terminal 29 Mode	5-11	Terminal 19 Digital Input	[61]	>Comparator 1<	[24]	>Ready, no over/under voltage<	5-58	Term. 33 High Ref./Feedb. Value
5-1*	Digital Inputs	5-12	Terminal 27 Digital Input	[62]	>Comparator 2<	[25]	>Reverse<	5-6*	Pulse Output
5-10	Terminal 18 Digital Input	5-13	Terminal 29 Digital Input	[63]	>Comparator 3<	[26]	>Bus OK<	5-60	Terminal 27 Pulse Output Variable
[0]	>No operation<	[32]	Pulse time based	[64]	>Comparator 4<	[27]	>Torque limit & stop<	*[0]	>No operation<
[1]	>Reset<	5-14	Terminal 32 Digital Input	[65]	>Comparator 5<	[28]	>Brake ready, no brake warning<	[45]	>Bus ctrl.<
[2]	>Coast inverse<	[82]	Encoder input B	[70]	>Logic rule 0<	[29]	>Brake ready, no fault<	[48]	>8Bus ctrl, timeout<
[3]	>Coast and reset inv<	5-15	Terminal 33 Digital Input	[71]	>Logic rule 1<	[30]	>Brake fault (IGBT)<	[100]	>Output frequency<
[4]	>Quick stop inverse<	[32]	Pulse time based	[72]	>Logic rule 2<	[31]	>Relay 123<	[101]	>Reference<
[5]	>DC-brake inverse<	[81]	Encoder input A	[73]	>Logic rule 3<	[32]	>Mech brake ctrl.<	[102]	>Process Feedback<
[6]	>Stop inverse<	5-19	Terminal 37/38 SAFE STOP	[74]	>Logic rule 4<	[36]	>Control word bit 11<	[103]	>Motor Current<
*[8]	>Start<	*[0]	>Safe Stop Alarm<	[75]	>Logic rule 5<	[37]	>Control word bit 12<	[104]	>Torque rel to limit<
[9]	>Latched start<	[1]	>Safe Stop Warning<	[80]	>SL digital output A<	[40]	>Out of ref range<	[105]	>Torq relate to rated<
[10]	>Reversing<	5-3*	Digital Outputs	[81]	>SL digital output B<	[41]	>Below reference, low<	[106]	>Power<
[11]	>Start reversing<	5-30	Terminal 27 Digital Output	[82]	>SL digital output C<	[42]	>Above ref, high<	[107]	>Speed<
[12]	>Enable start forward<	*[0]	>No operation<	[83]	>SL digital output D<	[45]	>Bus ctrl.<	[109]	>Max Out Freq<
[13]	>Enable start reverse<	[1]	>Control Ready<	[91]	>Encoder emulate output A<	[46]	>Bus control, timeout: On<	[113]	>Ext. Closed Loop 1<
[14]	>Jog<	[2]	>Drive ready<	[160]	>No alarm<	[47]	>Bus control, timeout: Off<	5-62	Pulse Output Max Freq 27
[15]	>Preset reference on<	[3]	>Drive rdy/rem ctrl.<	[161]	>Running reverse <	[56]	>Heat sink cleaning warning, high<	5-7*	24V Encoder Input
[16]	>Preset ref bit 0<	[4]	>Stand-by/no warning<	[165]	>Local ref active <	[60]	>Comparator 0<	5-70	Term 32/33 Pulses Per Revolution
[17]	>Preset ref bit 1<	[5]	>Running<	[166]	>Remote ref active<	[61]	>Comparator 1<	5-71	Term 32/33 Encoder Direction
[18]	>Preset ref bit 2<	[6]	>Running/no warning<	[167]	>Start command active<	[62]	>Comparator 2<	5-9*	Bus Controlled
[19]	>Freeze reference<	[7]	>Run in range/no warn<	[168]	>Drive in hand mode<	[63]	>Comparator 3<	5-90	Digital & Relay Bus Control
[20]	>Freeze output<	[8]	>Run on ref/no warn<	[169]	>Drive in auto mode<	[64]	>Comparator 4<	5-93	Pulse Out 27 Bus Control
[21]	>Speed up<	[9]	>Alarm<	[170]	>Homing Completed<	[65]	>Comparator 5<	5-94	Pulse Out 27 Timeout Preset
[22]	>Speed down<	[10]	>Alarm or warning<	[171]	>Target Position Reached<	[70]	>Logic rule 0<	6-2**	Analog In/Out
[23]	>Set-up select bit 0<	[11]	>At torque limit<	[172]	>Position Control Fault<	[71]	>Logic rule 1<	6-0*	Analog I/O Mode
[24]	>Set-up select bit 1<	[12]	>Out of current range<	[173]	>Position Mech Brake<	[72]	>Logic rule 2<	6-00	Live Zero Timeout Time
[26]	>Precise stop inverse<	[13]	>Below current, low<	[190]	>Safe Function active <	[73]	>Logic rule 3<	6-01	Live Zero Timeout Function
[28]	>Catch up<	[14]	>Above current, high<	[193]	>Sleep Mode<	[74]	>Logic rule 4<	*[0]	>Off<
[29]	>Slow down<	[15]	>Out of frequency range<	[194]	>Broken Belt Function<	[75]	>Logic rule 5<	[1]	>Freeze output<
[34]	>Ramp bit 0<	[16]	>Below frequency, low<	[239]	STO function fault	[80]	>SL digital output A<	[2]	>Stop<
[35]	>Ramp bit 1<	[17]	>Above frequency, high<	5-34	On Delay, Digital Output	[81]	>SL digital output B<	[3]	>Jogging<
[40]	>Latched precise start<	[18]	>Out of feedb. range<	5-35	Off Delay, Digital Output	[82]	>SL digital output C<	[4]	>Max. speed<
[51]	>External Interlock<	[19]	>Below feedback, low<	5-4*	Relays	[83]	>SL digital output D<	[5]	>Stop and trip<
[55]	>DigiPot increase<	[20]	>Above feedback, high<	5-40	Function Relay	[160]	>No alarm<	6-1*	Analog Input 53
[56]	>DigiPot decrease<	[21]	>Thermal warning<	[0]	>No operation<	[161]	>Running reverse <	6-10	Terminal 53 Low Voltage
[57]	>DigiPot clear<	[22]	>Ready, no thermal warning<	[1]	>Control Ready<	[165]	>Local ref active <	>0-10 V<	*0.07 V
[58]	>DigiPot Hoist<	[23]	>Remote,ready,no TW<	[2]	>Drive ready<	[166]	>Remote ref active<	Terminal 53 High Voltage	
[60]	>Counter A (up)<	[24]	>Ready, no over/under voltage<	[3]	>Drive rdy/rem ctrl.<	[167]	>Start command active<	>0-10 V<	*10 V
[61]	>Counter A (down)<	[25]	>Reverse<	[4]	>Stand-by/no warning<	[168]	>Drive in hand mode<	Terminal 53 Low Ref./Feedb. Value	
[62]	>Reset Counter A<	[26]	>Bus OK<	[5]	>Running<	[169]	>Drive in auto mode<	Terminal 53 High Ref./Feedb. Value	
[63]	>Counter B (up)<	[27]	>Torque limit & stop<	[6]	>Running/no warning<	[170]	>Homing Completed<	Terminal 53 Filter Time Constant	
[64]	>Counter B (down)<	[28]	>Brake ready, no brake warning<	[7]	>Run in range/no warn<	[171]	>Target Position Reached<	Terminal 53 Digital Input	
[65]	>Reset Counter B<	[29]	>Brake ready, no fault<	[8]	>Run on ref/no warn<	[172]	>Position Control Fault<	Terminal 53 mode	
[72]	>PID error inverse<	[30]	>Brake fault (IGBT)<	[9]	>Alarm<	[173]	>Position Mech Brake<	*[1]	>Voltage mode<
[73]	>PID reset l part<	[31]	>Relay 123<	[10]	>Alarm or warning<	[190]	>Safe Function active <	[6]	>Digital input<
[74]	>PID enable<	[32]	>Mech brake ctrl.<	[11]	>At torque limit<	[193]	>Sleep Mode<	6-2*	Analog Input 54
[150]	>Go To Home<	[36]	>Control word bit 11<	[12]	>Out of current range<	[194]	>Broken Belt Function<	6-20	Terminal 54 Low Voltage
[151]	>Home Ref. Switch<	[40]	>Control word bit 12<	[13]	>Below current, low<	[239]	STO function fault	6-21	Terminal 54 High Voltage
			>Out of ref range<	[14]	>Above current, high<	5-41	On Delay, Relay	6-22	Terminal 54 Low Current

[0]	>Ran3<	[0]	InternalFaultReason	16-64	Analog Input A154	30-2*	Adv. Start Adjust
[1]	>Ran5<	[1]	Drive Identification	16-65	Analog Output 42 [mA]	30-20	High Starting Torque Time [s]
[2]	>Ran20<	[2]	15-4* FC Type	16-66	Digital Output	30-21	High Starting Torque Current [%]
[3]	>3.0 kHz<	[3]	15-41 Power Section	16-67	Pulse Input 29[Hz]	30-22	Locked Rotor Protection
[4]	>4.0 kHz<	[4]	15-42 Voltage	16-68	Pulse Output 27 [Hz]	30-23	Locked Rotor Detection Time [s]
[5]	>5.0 kHz<	[5]	15-43 Software Version	16-69	Pulse Output 33 [Hz]	32-** Motion Control Basic Settings	
[6]	>6.0 kHz<	[6]	15-44 Ordered TypeCode	16-71	Relay Output	32-11	User Unit Denominator
[7]	>8.0 kHz<	[7]	15-45 Actual Typecode String	16-72	Counter A	32-12	User Unit Numerator
[8]	>10.0 kHz<	[8]	15-46 Drive Ordering No	16-73	Counter B	32-67	Max. Tolerated Position Error
[9]	>12.0kHz<	[9]	15-48 LCP Id No	16-74	Prec. Stop Counter	32-80	Maximum Allowed Velocity
[10]	>16.0kHz<	[10]	15-49 SW ID Control Card	16-8* Fieldbus & FC Port	32-81	Motion Ctrl Quick Stop Ramp	
14-03	Overmodulation		15-50 SW ID Power Card	16-80	Fieldbus CTW. 1	33-** Motion Control Adv. Settings	
[0]	>Off<		15-51 Drive Serial Number	16-82	Fieldbus REF 1	33-00	Homming Mode
[1]	>On<		15-53 Power Card Serial Number	16-84	Comm. Option STW	33-01	Home Offset
[2]	>Kinetic back-up<		15-6* Option Ident	16-85	FC Port CTW 1	33-02	Home Ramp Time
[3]	>Kinetic back-up, trip<		15-60 Option Mounted	16-86	FC Port REF 1	33-03	Homming Velocity
[4]	>Kinetic back-up, trip w recovery<		15-9* Parameter Info	16-9* Diagnosis Readouts	33-04	Home Behaviour	
[5]	>Alarm<		15-92 Defined Parameters	16-90	Alarm Word	33-41	Negative Software Limit
[6]	>Alam<		15-97 Application Type	16-91	Alarm Word 2	33-42	Positive Software Limit
[7]	>Kin. back-up, trip w recovery<		15-98 Drive Identification	16-92	Warning Word	33-43	Negative Software Limit Active
14-11	Mains Voltage at Mains Fault		15-99 Parameter Metadata	16-93	Warning Word 2	33-44	Positive Software Limit Active
14-12	Function at Mains Imbalance		16-** Data Readouts	16-94	Ext. Status Word	33-47	Target Position Window
[0]	>Trip<		16-00 Control Status	16-95	Ext. Status Word 2	34-** Motion Control Data Readouts	
[1]	>Warning<		16-01 Reference [Unit]	16-97	Alarm Word 3	34-0*	PCD Write Par.
[2]	>Disabled<		16-02 Reference [%]	18-** Data Readouts 2		34-01	PCD 1 Write For Application
[3]	>Derate<		16-03 Status Word	18-9* PID Readouts		34-02	PCD 2 Write For Application
14-15	Kin. Backup Trip Recovery Level		16-05 Main Actual Value [%]	18-90	Process PID Error	34-03	PCD 3 Write For Application
14-2*	Reset Functions		16-09 Custom Readout	18-91	Process PID Output	34-04	PCD 4 Write For Application
[0]	>Manual reset<		16-10 Motor Status	18-92	Process PID Clamped Output	34-05	PCD 5 Write For Application
[1]	>Automatic reset x 1<		16-11 Power [hp]	18-93	Process PID Gain Scaled Output	34-06	PCD 6 Write For Application
[2]	>Automatic reset x 2<		16-12 Motor Voltage	21-** Ext. Closed Loop		34-07	PCD 7 Write For Application
[3]	>Automatic reset x 3<		16-13 Frequency	21-1* Ext. CL 1 Ref./Fb.		34-08	PCD 8 Write For Application
[4]	>Automatic reset x 4<		16-14 Motor current	21-11	Ext. 1 Minimum Reference	34-09	PCD 9 Write For Application
[5]	>Automatic reset x 5<		16-15 Frequency [%]	21-12	Ext. 1 Maximum Reference	34-10	PCD 10 Write For Application
[6]	>Automatic reset x 6<		16-16 Torque [Nm]	21-13	Ext. 1 Reference Source	34-2* PCD Read Par.	
[7]	>Automatic reset x 7<		16-18 Motor Thermal	21-14	Ext. 1 Feedback Source	34-21	PCD 1 Read For Application
[8]	>Automatic reset x 8<		16-20 Motor Angle	21-15	Ext. 1 Setpoint	34-22	PCD 2 Read For Application
[9]	>Automatic reset x 9<		16-22 Torque [%]	21-17	Ext. 1 Reference [Unit]	34-23	PCD 3 Read For Application
[10]	>Automatic reset x 10<		16-3* Drive Status	21-18	Ext. 1 Feedback [Unit]	33-24	PCD 4 Read For Application
[11]	>Automatic reset x 15<		16-30 DC Link Voltage	21-19	Ext. 1 Output [%]	33-25	PCD 5 Read For Application
[12]	>Automatic reset x 20<		16-33 Brake Energy /2 min	21-20	Ext. 1 Normal/Inverse Control	33-26	PCD 6 Read For Application
[13]	>Infinite auto reset<		16-34 Heatsink Temp.	21-21	Ext. 1 Proportional Gain	33-27	PCD 7 Read For Application
14-21	Automatic Restart Time		16-35 Inverter Thermal	21-22	Ext. 1 Integral Time	33-28	PCD 8 Read For Application
[0]	>Operation Mode		16-37 Inv. Nom. Current	21-23	Ext. 1 Differentiation Time	33-29	PCD 9 Read For Application
[2]	>Normal operation<		16-38 SL Controller State	21-24	Ext. 1 Dif. Gain Limit	34-5*	Process Data
14-24	Trip Delay at Current Limit		16-5* Ref. & Feeds.	22-4* Sleep Mode		34-50	Actual Position
14-25	Trip Delay at Torque Limit		16-50 External Reference	22-40	Minimum Run Time	34-56	Track Error
14-27	Action At Inverter Fault		16-52 Feedback[Unit]	22-41	Minimum Sleep Time	37-** Application Settings	
			16-53 Digit Pot Reference	22-43	Wake-Up Speed [Hz]	37-0* ApplicationMode	
			16-57 Feedback [RPM]	22-44	Wake-Up Ref./FB Diff	37-00	Application Mode
			16-60 Digital Input	22-45	Setpoint Boost	[1]	>Drive mode<
			16-61 Terminal 53 Setting	22-46	Maximum Boost Time	[1]	>Position Control<
			16-62 Analog Input 53	22-6* Broken Belt Detection		37-1*	Position Control
			16-63 Terminal 54 Setting	22-60	Broken Belt Function	[0]	>24V Encoder<
				22-61	Broken Belt Torque	37-02	Pos. Target
				22-62	Broken Belt Delay	37-03	Pos. Type
				30-**	Special Features	37-04	Pos. Velocity

37-05 Pos. Ramp Up Time
 37-06 Pos. Ramp Down Time
 37-07 Pos. Auto Brake Ctrl
 [0] >Disable<
 *[1] >Enable<
 37-08 Pos. Hold Delay
 37-09 Pos. Coast Delay
 37-10 Pos. Brake Delay
 37-11 Pos. Brake Wear Limit
 37-12 Pos. PID Anti Windup
 [0] >Disable<
 *[1] >Enable<
 37-13 Pos. PID Output Clamp
 37-14 Pos. Ctrl. Source
 *[0] >DI<
 [1] >FieldBus <
 37-15 Pos. Direction Block
 *[0] No Blocking
 [1] >Block Reverse<
 [2] >Block Forward<
 37-17 Pos. Ctrl Fault Behaviour
 *[0] >Ramp Down & Brake <
 [1] >Brake Directly<
 37-18 Pos. Ctrl Fault Reason
 37-19 Pos. New Index
 >0-255*0
 <

Index

A

Abbreviation..... 56

AC input..... 4, 15

AC line power..... 4, 15

AC waveform..... 4

Additional resource..... 3

Alarm log..... 26

AMA with T27 connected..... 38

Ambient condition..... 50

Analog input..... 52

Approval and certification..... 4

Auto on..... 27, 31

Automatic motor adaptation..... 29

Auxiliary equipment..... 19

B

Backplate..... 8

Branch circuit protection..... 54

C

Cable length..... 51

Cable routing..... 19

Cable size..... 14

Circuit breaker..... 19

Clearance requirement..... 7

Conduct..... 19

Control

- Characteristic..... 53
- Terminal..... 27, 46
- Wiring..... 10, 17, 19

Control card

- +10 V DC output..... 53
- Performance..... 53
- RS485 serial communication..... 53

Convention..... 56

Cooling..... 7

Cooling clearance..... 19

Cross-section..... 51

Customer relay..... 35

D

DC current..... 4

Default setting..... 27

Derating..... 50

Digital input..... 17

Digital output..... 52

Discharge time..... 5

Disconnect switch..... 20

Disposal instructions..... 4

E

Electrical interference..... 11

EMC..... 50

EMC-compliant installation..... 10

Encoder rotation..... 30

Energy efficiency..... 48, 49

Energy efficiency class..... 51

External command..... 4

External controller..... 3

F

Fault log..... 26

Feedback..... 19

Floating delta..... 15

Fuse..... 10, 19, 54

G

Ground connection..... 19

Ground wire..... 10

Grounded delta..... 15

Grounding..... 14, 15, 19, 20

H

Hand on..... 27

High voltage..... 5, 20

I

IEC 61800-3..... 15, 51

Initialization

- Manual procedure..... 28
- Procedure..... 28

Input

- Current..... 15
- Power..... 4, 10, 15, 19, 20
- Terminal..... 15, 20

Input power wiring..... 19

Input voltage..... 20

Index	Instruction Manual
Inputs	Output current..... 52
Digital input..... 51	Output power wiring..... 19
Pulse input..... 52	Outputs
Installation..... 19	Analog output..... 53
Installation environment..... 7	Overcurrent protection..... 10
Intended use..... 3	
Interference isolation..... 19	P
Isolated main..... 15	PELV..... 40, 53
	Potential equalization..... 11
J	Power connection..... 10
Jumper..... 17	Power factor..... 4, 19
	Programming..... 17, 26, 27
L	
Leakage current..... 6, 10	Q
Lifting..... 7	Qualified personnel..... 5
Line power	Quick menu..... 22, 26
Supply (L1, L2, L3)..... 50	
Supply data..... 48	R
Voltage..... 26	Recycling..... 4
Load sharing..... 5	Reference..... 26
Local control..... 27	Relay output..... 53
	Remote command..... 3
M	Reset..... 25, 27, 28, 42
Main menu..... 24, 26	RFI filter..... 15
Maintenance..... 42	Run command..... 31
Mechanical brake control..... 17	
Menu key..... 21, 25, 26	S
Menu structure..... 26	Safety..... 6
Motor	Serial communication..... 18, 27, 42
Cable..... 14	Service..... 42
Current..... 4, 26, 29	Set-up..... 31
Data..... 28, 30	Shielded cable..... 19
output..... 50	Shock..... 7
Power..... 10, 26	Side-by-side installation..... 8
Protection..... 3	SIL2..... 4
Rotation..... 30	SILCL of SIL2..... 4
Status..... 3	Specification..... 18
Mounting..... 8, 19	Speed reference..... 31, 38
	Standard and compliance for STO..... 4
N	Start-up..... 28
Nameplate..... 7	
Navigation key..... 21, 25, 26	
Numeric display..... 21	
O	
Open-loop..... 53	
Operation key..... 21, 25	
Optional equipment..... 20	

STO	
Activation.....	34
Automatic restart.....	34, 35
Commissioning test.....	35
Deactivation.....	34
Maintenance.....	35
Manual restart.....	34, 35
Technical data.....	37
Storage.....	7
Supply voltage.....	20, 53
Symbol.....	56
System feedback.....	3
T	
Terminal tightening torque.....	54
Terminals	
Output terminal.....	20
Thermistor.....	40
Torque	
characteristic.....	50
Transient protection.....	4
U	
Unintended start.....	5, 42
V	
Vibration.....	7
Voltage level.....	51
W	
Warning and alarm list.....	46
Wire size.....	10



Danfoss Drives

4401 N. Bell School Rd.
Loves Park IL 61111 USA
Phone: 1-800-432-6367
1-815-639-8600
Fax: 1-815-639-8000
www.danfossdrives.com

Danfoss Drives

8800 W. Bradley Rd.
Milwaukee, WI 53224 USA
Phone: 1-800-621-8806
1-414-355-8800
Fax: 1-414-355-6117
www.danfossdrives.com

.....
Danfoss shall not be responsible for any errors in catalogs, brochures or other printed material. Danfoss reserves the right to alter its products at any time without notice, provided that alterations to products already on order shall not require material changes in specifications previously agreed upon by Danfoss and the Purchaser. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.
.....

Danfoss A/S
Ulsnaes 1
DK-6300 Graasten
vlt-drives.danfoss.com

