




# Service Guide

## VLT<sup>®</sup> Soft Starter MCD 500





## Contents

<b>1 Introduction</b>	<b>3</b>
1.1 Purpose of the Manual	3
1.2 Additional Resources	3
1.3 Document Version	3
<b>2 Safety</b>	<b>4</b>
<b>3 Troubleshooting</b>	<b>6</b>
3.1 Functional Tests	6
3.1.1 Testing the MCD 500 with a Small Motor	6
3.1.2 Power Circuit Test	6
3.1.3 Start Performance Test	7
3.1.4 Run Performance Test	7
3.1.5 Bypass Contactor Test	7
3.1.6 Control Input Test	8
3.1.7 After Repair Tests	8
3.2 Trip Messages	8
3.3 General Faults	13
<b>4 Service Instructions</b>	<b>16</b>
4.1 Enclosure Sizes	16
4.1.1 MCD5-0021B ~ MCD5-0053B (G1B)	17
4.1.2 MCD5-0068B ~ MCD5-0105B (G1B)	18
4.1.3 MCD5-0131B ~ MCD5-0215B (G2B)	19
4.1.4 MCD5-0245B ~ MCD5-0396B (G3B)	20
4.1.5 MCD5-0245C (G3C)	21
4.1.6 MCD5-0469B ~ MCD5-0961B (G4B)	22
4.1.7 MCD5-0360C ~ MCD5-0927C (G4C)	23
4.1.8 MCD5-1200C ~ MCD5-1600C (G5C)	24
4.2 Identifying the Soft Starter Version	25
<b>5 Spare Parts</b>	<b>26</b>
5.1 Main Control PCB	26
5.2 Model PCB	27
5.3 Backplane PCB	28
5.4 Bypass Driver PCB	29
5.5 SCRs and SCR Connections	30
5.6 Power Assemblies (SCR Power Assemblies)	31
5.7 Snubber Assemblies	32
5.8 Fans	33

5.9 Current Transformers	34
5.10 Bypass Contactors	35
5.11 Plastic Components	36
5.11.1 Complete Plastic Components	38
5.12 Control Panel LCP 501 Upgrade Kit	39
5.13 Busbars	40
5.14 Other Spare Parts	42
<b>6 Avoiding Damage</b>	<b>43</b>
6.1 SCRs	43
6.1.1 Typical Causes of SCR Damage	43
6.1.2 Protecting SCRs	43
6.1.3 Semiconductor Fuses	43
6.1.4 Main Contactors	43
6.2 Output Relays	43
6.2.1 Using the Soft Starter to Switch a Contactor	43
6.3 Control Input	44
<b>7 Appendix</b>	<b>45</b>
7.1 Bolts and Tightening Torques	45
7.1.1 Input/Output Busbars to SCRs	45
7.1.2 SCRs to Heat Sink	45
7.1.3 Bypass Contactor Connections	46
7.1.4 Current Transformer Busbar Assembly	46
7.2 Minimum and Maximum Current Settings	46
7.3 Symbols, Abbreviations, and Conventions	47
<b>Index</b>	<b>48</b>



# 1 Introduction

## 1.1 Purpose of the Manual

The purpose of this guide is to provide detailed technical information and instructions to enable an authorized technician to identify faults and perform repairs on the VLT® Soft Starter MCD 500.

The service guide includes the following information:

- Troubleshooting and test instructions.
- Exploded views of the different models.
- Spare part lists with ordering numbers.

## 1.2 Additional Resources

Other resources are available to understand advanced soft starter operation.

- The *Operating Guide* provides detailed information for the installation and start-up of the soft starter.
- The *Design Guide* entails all technical information about the soft starter and customer design and applications.
- Optional equipment is available that can change some of the information described in these publications. Be sure to consult the instructions supplied with the options for specific requirements.

Supplementary publications and manuals are available from Danfoss. See [drives.danfoss.com/downloads/portal/#/](https://drives.danfoss.com/downloads/portal/#/) for listings.

## 1.3 Document Version

This guide is regularly reviewed and updated. All suggestions for improvement are welcome. *Table 1.1* shows the document version.

Edition	Remarks
MG17L8	Introductory chapter added. Ordering number for current transformers for models 0021B ~ 0105B changed.

Table 1.1 Document Version

## 2 Safety

The following symbols are used in this guide:

### **⚠️ WARNING**

Indicates a potentially hazardous situation that could result in death or serious injury.

### **⚠️ CAUTION**

Indicates a potentially hazardous situation that could result in minor or moderate injury. It can also be used to alert against unsafe practices.

### **NOTICE**

Indicates important information, including situations that can result in damage to equipment or property.

#### 2.1.1 Qualified Personnel

Correct and reliable transport, storage, installation, operation, and maintenance are required for the trouble-free and safe operation of the soft starter. Only qualified personnel are allowed to install or operate this equipment.

Qualified personnel is defined as trained staff, who are authorized to install, commission, and maintain equipment, systems, and circuits in accordance with pertinent laws and regulations. Additionally, the personnel must be familiar with the instructions and safety measures described in this manual.

### **⚠️ WARNING**

#### **ELECTRICAL SHOCK HAZARD**

VLT® Soft Starter MCD 500 contains dangerous voltages when connected to mains voltage. Only a qualified electrician should carry out the electrical installation. Improper installation of the motor or the soft starter can cause death, serious injury, or equipment failure. Follow the guidelines in this manual and local electrical safety codes.

Models MCD5-0360C ~ MCD5-1600C:

Treat the busbar and heat sink as live parts whenever the unit has mains voltage connected (including when the soft starter is tripped or waiting for a command).

### **⚠️ WARNING**

#### **PROPER GROUNDING**

Disconnect the soft starter from mains voltage before carrying out repair work.

It is the responsibility of the person installing the soft starter to provide proper grounding and branch circuit protection according to local electrical safety codes. Do not connect power factor correction capacitors to the output of the VLT® Soft Starter MCD 500. If static power factor correction is employed, it must be connected to the supply side of the soft starter.

### **⚠️ WARNING**

#### **IMMEDIATE START**

In auto-on mode, the motor can be controlled remotely (via remote inputs) while the soft starter is connected to mains.

MCD5-0021B ~ MCD5-0961B:

Transportation, mechanical shock, or rough handling may cause the bypass contactor to latch into the On state.

To prevent the motor from starting immediately on first commissioning or operation after transportation:

- Always ensure that the control supply is applied before the power.
- Applying control supply before power ensures that the contactor state is initialized.

### **⚠️ WARNING**

#### **UNINTENDED START**

When the soft starter is connected to AC mains, DC supply, or load sharing, the motor can start at any time. Unintended start during programming, service, or repair work can result in death, serious injury, or property damage. The motor can start with an external switch, a fieldbus command, an input reference signal from the LCP or LOP, via remote operation using MCD PC Software, or after a cleared fault condition.

To prevent unintended motor start:

- Press [Off]/[Reset] on the LCP before programming parameters.
- Disconnect the soft starter from mains.
- Completely wire and assemble the soft starter, motor, and any driven equipment before connecting the soft starter to AC mains, DC supply, or load sharing.

**⚠ WARNING****SAFETY OF PERSONNEL**

The soft starter is not a safety device and does not provide electrical isolation or disconnection from the supply.

- If isolation is required, the soft starter must be installed with a main contactor.
- Do not rely on the start and stop functions for safety of personnel. Faults occurring in the mains supply, the motor connection, or the electronics of the soft starter can cause unintended motor starts or stops.
- If faults occur in the electronics of the soft starter, a stopped motor may start. A temporary fault in the supply mains or loss of motor connection can also cause a stopped motor to start.

To provide safety of personnel and equipment, control the isolation device through an external safety system.

**NOTICE**

Before changing any parameter settings, save the current parameter to a file using MCD PC Software or the *Save User Set* function.

**NOTICE**

Use the *autostart* feature with caution. Read all the notes related to *autostart* before operation.

The examples and diagrams in this manual are included solely for illustrative purposes. The information contained in this manual is subject to change at any time and without prior notice. Responsibility or liability is never accepted for direct, indirect, or consequential damage resulting from the use or application of this equipment.

## 3 Troubleshooting

### 3

When a protection condition is detected, the VLT® Soft Starter MCD 500 writes this condition to the event log and may also trip or issue a warning. The soft starter response depends on the protection action settings (*parameter group 16 Protection Actions*).

Some protection responses cannot be adjusted. Usually, external events (for example phase loss) or a fault within the soft starter cause these trips. These trips do not have associated parameters and cannot be set to *Warn* or *Log*.

If the soft starter trips:

1. Identify and clear the condition that triggered the trip.
2. Reset the soft starter.
3. Restart the soft starter.

To reset the soft starter, press [Reset] or activate the *Reset remote* input.

If the soft starter has issued a warning, it resets itself when the cause of the warning has been resolved.

### 3.1 Functional Tests

Use the tests described in this section to identify the cause of problems with the soft starter.

#### 3.1.1 Testing the MCD 500 with a Small Motor

The VLT® Soft Starter MCD 500 can be connected to a small motor for testing. During this test, the control input and relay output protection settings of the soft starter can be tested. This test mode is not suitable for testing soft starting or soft stopping performance.

#### **NOTICE**

When testing the soft starter with a small motor, ensure that *parameter 1-1 Motor Full Load Current* is set to the minimum allowable value.

The FLC of the test motor must be at least 2% of the soft starter minimum FLC (see *chapter 7.2.1 Minimum and Maximum Current Settings*).

#### 3.1.2 Power Circuit Test

This procedure tests the soft starter power circuit, including:

- SCR.
- Interface PCB.
- Main control PCB.

Use a 500 V DC insulation tester on the 200 Ω scale or a standard multimeter (voltmeter).

1. Isolate the soft starter from the incoming mains supply and remove the control voltage.
2. Disconnect the motor cables and any external bypass contactor cables from the soft starter.
3. Allow the soft starter to cool to room ambient temperature.
4. Using a meter, check the resistance across each phase of the soft starter in both directions.
  - 4a L1 to T1.
  - 4b T1 to L1.
  - 4c L2 to T2.
  - 4d T2 to L2.
  - 4e L3 to T3.
  - 4f T3 to L3.
5. If any reading is less than 200 Ω, the SCR or internal bypass relay has failed short circuit and must be replaced.
6. To prevent a repeated SCR failure, investigate the cause of the SCR damage.

#### **NOTICE**

Events that damage SCRs often damage the backplane PCB as well, although the main control PCB is undamaged.

1. Replace the damaged SCRs and backplane PCB.
2. Check for correct operation before replacing the main control PCB.

External influences that almost always cause SCR damage.

- If the MOVs and/or surrounding circuitry on the backplane PCB show signs of physical damage, the most likely cause is overvoltage.
- If the MOVs and/or surrounding circuitry on the backplane PCB do not show signs of physical damage, the most likely cause is overcurrent.

See *chapter 5.5.1 SCRs and SCR Connection* for information on typical causes of SCR damage.

### 3.1.3 Start Performance Test

This procedure tests that the soft starter operates correctly during start-up.

1. Connect the soft starter to mains voltage, control voltage, and to a motor.
2. Set *parameter 1-1 Motor FLC* to match the full load current of the motor.
3. Set *parameter 1-3 Start mode* to *Constant current*.
4. Set *parameter 1-4 Current limit* to a level which supplies sufficient start current to enable the connected motor to accelerate to full speed.
  - 4a Calculate the expected start current by multiplying *parameter 1-1 Motor FLC* by *parameter 1-4 Current limit*.
  - 4b If the secondary parameter set is being tested, multiply *parameter 7-1 Motor FLC-2* by *parameter 7-4 Current limit-2*.
5. Initiate a start and measure the actual start current. To measure the actual start current, view the phase current display or use a clip-on ammeter.

If the measured current is equal to the actual start current on all 3 phases, the soft starter performs correctly.

#### **NOTICE**

During start mode, the *On* LED on the LCP flashes.

### 3.1.4 Run Performance Test

This procedure tests for correct operation of the soft starter during run mode.

This test is performed using an AC voltmeter.

1. Measure the voltage across each phase (L1–T1, L2–T2, L3–T3). This result should be close to the nominal mains voltage (phase voltage for in-line connection and mains voltage for inside delta connection).
  - 1a If the voltage is 0, the SCR on that phase may have failed.
  - 1b If the voltage is not equivalent to the nominal mains voltage, the bypass contactor may be damaged and should be replaced (internally bypassed models only).
2. Command the soft starter to start. When the soft starter starts, measure the voltage across each phase.

- 2a For units which are not bypassed, the voltage should drop to less than 2 V AC just before the soft starter reaches run mode.
- 2b For units with internal bypass contactors, the voltage should be less than 0.5 V AC when the soft starter reaches run mode.
- 2c If the voltage remains near nominal voltage, the SCR does not fire correctly. Check the connections between the main control PCB and the SCRs.

If the voltage starts near nominal mains voltage and then drops to less than 2 V AC just before reaching run mode, the soft starter operates correctly. Thus, the soft starter is not the cause of the starting problem.

### 3.1.5 Bypass Contactor Test

This procedure tests the operation of the internal bypass contactors. Use this test if the soft starter trips with:

- Bypass failure.
- Time overcurrent.
- Heat sink overtemperature.

This test is performed using an AC voltmeter.

1. Measure the voltage across each phase (L1–T1, L2–T2, L3–T3). This result should be close to the nominal mains voltage (phase voltage for in-line connection and mains voltage for inside delta connection).
  - 1a If the voltage is 0, replace the bypass contactor.
2. Command the soft starter to start. When the *Run* LED stops flashing, the bypass contactor closes with an audible sound.
  - 2a If the bypass contactors do not close, the bypass contactor, main control PCB, model PCB, or bypass driver PCB (G2B) is faulty. Alternatively, there is a faulty connection between these components.
3. When the soft starter runs, measure the voltage across each phase. This result should be <0.5 V AC.
4. Command the soft starter to stop and listen for the bypass contactor to open.

- 4a If the soft starter is configured for soft stop, the bypass contactor opens when the *Run* LED starts flashing.
- 4b If the soft starter is not configured for soft stop, the bypass contactor closes when the *Run* LED turns off.

**NOTICE**

The bypass contactors used in the G1B enclosure size are latching. The soft starter control circuits are designed to open the bypass contactors even when losing control voltage. However, it is still possible that the bypass contactor is closed when there is no control supply to the soft starter. The bypass contactors open when control voltage is applied.

3.1.6 Control Input Test

This procedure tests the condition of the soft starter control inputs. This test is performed using a wire link.

1. Disconnect all external wiring from the soft starter control inputs.
2. Control voltage must still be connected to the soft starter.
3. Navigate to the soft starter digital I/O view.
4. Connect a wire link between each input.

**Test results**

- If the corresponding LED lights up and the shown status of the input changes, the input operates correctly.
- If the LED does not light up or the shown status does not change, the main control PCB is damaged.

3.2 Trip Messages

Table 3.1 lists the protection mechanisms in the soft starter and the probable cause of the trip. Some of these protection mechanisms can be adjusted using *parameter group 2 Protection* and *parameter group 16 Protection Action*. Other settings are built-in system protections and cannot be set or adjusted.

Display	Possible cause/suggested solution
Awaiting data	The LCP does not receive data from the control PCB. Check the cable connection and the fitting of the display on the soft starter.
Battery/clock	A verification error has occurred on the real-time clock, or the back-up battery voltage is low. If the battery is low and the power is off, date/time settings are lost. Reprogram the date and time. Related parameter: <ul style="list-style-type: none"> <li>• <i>Parameter 16-12 Battery Clock</i>.</li> </ul>
Controller	Name selected for a programmable input. Refer to <i>Input A trip</i> .

3.1.7 After Repair Tests

**NOTICE**

The servicing technician is responsible for ensuring that all electrical safety tests have been completed in accordance with local regulations.

To test that the soft starter functions correctly after reassembly:

1. Apply control power only to the soft starter.
2. Ensure that the welcome screen shows the correct firmware version.
3. Perform a *Run simulation* test using both the LCP and remote switches.
4. Connect mains supply and motor. Test that the soft starter functions as expected.

To test the soft starter operation with a small motor (that is a motor with a current rating much lower than that of the soft starter):

1. Use the *Tools* menu to load the *Factory Default* parameter file for the soft starter.
2. Disable *parameter 2-4 Undercurrent Trip*.
3. Connect a small motor to the motor terminals of the soft starter. Test that the soft starter functions as expected.

**NOTICE**

Ensure that *parameter 2-4 Undercurrent Trip* is reset to its default value after conducting tests.

Display	Possible cause/suggested solution
Current imbalance	<p>Problems with the motor, the environment, or the installation can cause current imbalance, such as:</p> <ul style="list-style-type: none"> <li>• An imbalance in the incoming mains voltage.</li> <li>• A problem with the motor windings.</li> <li>• A light load on the motor.</li> <li>• A phase loss on mains terminals L1, L2, or L3 during run mode.</li> </ul> <p>An SCR that has failed open circuit. A failed SCR can only be diagnosed accurately by replacing the SCR and checking the soft starter performance.</p> <p>Related parameters:</p> <ul style="list-style-type: none"> <li>• <i>Parameter 2-2 Current Imbalance.</i></li> <li>• <i>Parameter 2-3 Current Imbalance Delay.</i></li> <li>• <i>Parameter 16-2 Current Imbalance.</i></li> </ul>
Current read err lx	<p>Where X is 1, 2, or 3.</p> <p>Internal fault (PCB fault). The output from the current transformer circuit is not close enough to 0 when the SCRs are turned off. Contact the local Danfoss supplier for advice.</p> <p>This trip is not adjustable.</p> <p>Related parameters: None.</p>
Excess start time	<p>Excess start time trip can occur under the following conditions:</p> <ul style="list-style-type: none"> <li>• <i>Parameter 1-1 Motor FLC</i> is not appropriate for the motor.</li> <li>• <i>Parameter 1-4 Current Limit</i> has been set too low.</li> <li>• <i>Parameter 1-6 Start Ramp Time</i> has been set higher than the setting in <i>parameter 1-9 Excess Start Time Setting</i>.</li> <li>• <i>Parameter 1-6 Start Ramp Time</i> is set too short for a high inertia load when using adaptive control.</li> </ul> <p>Related parameters:</p> <ul style="list-style-type: none"> <li>• <i>Parameter 1-1 Motor FLC.</i></li> <li>• <i>Parameter 1-4 Current Limit.</i></li> <li>• <i>Parameter 1-6 Start Ramp Time.</i></li> <li>• <i>Parameter 1-9 Excess Start Time.</i></li> <li>• <i>Parameter 7-1 Motor FLC-2.</i></li> <li>• <i>Parameter 7-4 Current Limit-2.</i></li> <li>• <i>Parameter 7-6 Start Ramp-2.</i></li> <li>• <i>Parameter 7-9 Excess Strt Time-2.</i></li> <li>• <i>Parameter 16-7 Excess Start Time.</i></li> </ul>
Firing fail px	<p>Where X is phase 1, 2, or 3.</p> <p>The SCR did not fire as expected. Check for faulty SCRs and internal wiring faults.</p> <p>This trip is not adjustable.</p> <p>Related parameters: None.</p>
FLC too high	<p>The soft starter can support higher motor full load current values when connected to the motor using inside delta configuration rather than in-line connection. If the soft starter is connected in-line, but the programmed setting for <i>parameter 1-1 Motor FLC</i> exceeds the in-line maximum, the soft starter trips at start (see <i>chapter 7.2.1 Minimum and Maximum Current Settings</i>).</p> <p>If the soft starter is connected to the motor using inside delta configuration, check that the soft starter detects the connection correctly. Contact the local Danfoss supplier for advice.</p> <p>Related parameters:</p> <ul style="list-style-type: none"> <li>• <i>Parameter 1-1 Motor FLC.</i></li> <li>• <i>Parameter 7-1 Motor FLC-2.</i></li> </ul>

Display	Possible cause/suggested solution
Frequency	<p>The mains frequency is outside of the specified range.</p> <p>Check for other equipment in the area that could be affecting the mains supply, particularly frequency converters and switch mode power supplies (SMPS).</p> <p>If the soft starter is connected to a generator-set supply, the generator may be too small or could have a speed control problem.</p> <p>Related parameters:</p> <ul style="list-style-type: none"> <li>• <i>Parameter 2-8 Frequency Check.</i></li> <li>• <i>Parameter 2-9 Frequency Variation.</i></li> <li>• <i>Parameter 2-10 Frequency Delay.</i></li> <li>• <i>Parameter 16-5 Frequency.</i></li> </ul>
Heat sink overtemp	<p>Check that cooling fans are operating. If mounted in an enclosure, check if ventilation is adequate. Fans operate during start, run, and for 10 minutes after the soft starter exits the stop state.</p> <p><b>NOTICE</b></p> <p><b>Models MCD5-0021B ~ MCD4-0053B and MCD5-0141B do not have a cooling fan. Models with fans operate the cooling fans from a start until 10 minutes after a stop.</b></p> <p>Related parameters:</p> <ul style="list-style-type: none"> <li>• <i>Parameter 16-6 Heat sink Overtemp.</i></li> </ul>
High level	Name selected for a programmable input. Refer to <i>Input A trip</i> .
High pressure	Name selected for a programmable input. Refer to <i>Input A trip</i> .
Input A trip	<p>The programmable input is set to a trip function and has activated. Resolve the trigger condition.</p> <p>Related parameters:</p> <ul style="list-style-type: none"> <li>• <i>Parameter 3-3 Input A Function.</i></li> <li>• <i>Parameter 3-4 Input A Name.</i></li> <li>• <i>Parameter 3-5 Input A Trip.</i></li> <li>• <i>Parameter 3-6 Input A Trip Delay.</i></li> <li>• <i>Parameter 3-7 Input A Initial Delay.</i></li> <li>• <i>Parameter 16-8 Input A Trip.</i></li> </ul>
Instantaneous overcurrent	<p>There has been a sharp rise in motor current, probably caused by a locked rotor condition (shear pin) while running. Check for a jammed load.</p> <p>Related parameters:</p> <ul style="list-style-type: none"> <li>• <i>Parameter 2-6 Instantaneous Overcurrent.</i></li> <li>• <i>Parameter 2-7 Instantaneous Overcurrent Delay.</i></li> <li>• <i>Parameter 16-4 Inst Overcurrent.</i></li> </ul>
Internal fault X	<p>The soft starter has tripped on an internal fault. Contact the local Danfoss supplier with the fault code (X).</p> <p>Related parameters: None.</p>
L1 phase loss L2 phase loss L3 phase loss	<p>During prestart, check that the soft starter has detected a phase loss as indicated.</p> <p>In run state, the soft starter has detected that the current on the affected phase has dropped below 3.3% of the programmed motor FLC for more than 1 s. This current drop indicates that either the incoming phase or connection to the motor has been lost.</p> <p>For the soft starter and the motor, check:</p> <ul style="list-style-type: none"> <li>• The supply connections.</li> <li>• The input connections.</li> <li>• The output connections.</li> </ul> <p>A failed SCR can also cause phase loss, particularly an SCR that has failed open circuit. A failed SCR can only be diagnosed accurately by replacing the SCR and checking the soft starter performance.</p> <p>Related parameters: None.</p>



Display	Possible cause/suggested solution
L1-T1 shorted L2-T2 shorted L3-T3 shorted	During prestart checks, the soft starter has detected a short-circuited SCR or a short circuit within the bypass contactor as indicated. Related parameters: None.
Low control volts	The soft starter has detected a drop in the control voltage. <ul style="list-style-type: none"> <li>Check the external control supply (terminals A4, A5, A6) and reset the soft starter.</li> </ul> If the external control supply is stable: <ul style="list-style-type: none"> <li>Check if the 24 V supply on the main control PCB is faulty; or</li> <li>Check if the bypass driver PCB is faulty (internally bypassed models only).</li> </ul> This protection is not active in ready state. Related parameters: <ul style="list-style-type: none"> <li><i>Parameter 16-13 Low Control Volts.</i></li> </ul>
Low level	Name selected for a programmable input. Refer to <i>Input A trip</i> .
Low pressure	Name selected for a programmable input. Refer to <i>Input A trip</i> .
Motor overload/ Motor 2 overload	The motor has reached its maximum thermal capacity. The following can cause overload: <ul style="list-style-type: none"> <li>The soft starter protection settings do not match the motor thermal capacity.</li> <li>Excessive starts per hour.</li> <li>Excessive throughput.</li> <li>Damage to the motor windings.</li> </ul> Resolve the cause of the overload and allow the motor to cool. Related parameters: <ul style="list-style-type: none"> <li><i>Parameter 1-1 Motor FLC.</i></li> <li><i>Parameter 1-2 Locked Rotor Time.</i></li> <li><i>Parameter 1-3 Start Mode.</i></li> <li><i>Parameter 1-4 Current Limit.</i></li> <li><i>Parameter 7-1 Motor FLC-2.</i></li> <li><i>Parameter 7-2 Locked Rotor Time-2.</i></li> <li><i>Parameter 7-3 Start Mode-2.</i></li> <li><i>Parameter 7-4 Current Limit-2.</i></li> <li><i>Parameter 16-1 Motor Overload.</i></li> </ul>
Motor connection tx	Where X is 1, 2, or 3. The motor is not connected correctly to the soft starter for in-line or inside delta use. <ul style="list-style-type: none"> <li>Check individual motor connections to the soft starter for power circuit continuity.</li> <li>Check connections at the motor terminal box.</li> </ul> This trip is not adjustable. Related parameters: <ul style="list-style-type: none"> <li><i>Parameter 15-7 Motor Connection.</i></li> </ul>

Display	Possible cause/suggested solution
Motor thermistor	<p>The motor thermistor input has been enabled and:</p> <ul style="list-style-type: none"> <li>• The resistance at the thermistor input has exceeded 3.6 kΩ for more than 1 s.</li> <li>• The motor winding has overheated. Identify the cause of the overheating and allow the motor to cool before restarting.</li> <li>• The motor thermistor input has been opened.</li> </ul> <p><b>NOTICE</b> If a valid motor thermistor is no longer used, fit a 1.2 kΩ resistor across terminals 05 and 06.</p> <p>Related parameters:</p> <ul style="list-style-type: none"> <li>• <i>Parameter 16-9 Motor Thermistor.</i></li> </ul>
Network communication (between module and network)	<p>The network master has sent a trip command to the soft starter, or there could be a network communication problem.</p> <p>Check the network for causes of communication inactivity.</p> <p>Related parameters:</p> <ul style="list-style-type: none"> <li>• <i>Parameter 16-11 Network/Comms.</i></li> </ul>
No flow	Name selected for a programmable input. Refer to <i>Input A trip</i> .
Not ready	Check if the soft starter disable function is active. If <i>parameter 3-3 Input A Function</i> is set to <i>Starter disable</i> and there is an open circuit on terminals 11 and 16, the soft starter does not start.
Parameter out of range	<ul style="list-style-type: none"> <li>• A parameter value is outside the valid range.</li> </ul> <p>The soft starter loads the default value for all affected parameters. To go to the first invalid parameter and adjust the setting, press [Main Menu].</p> <p>Related parameters: None.</p>
Phase sequence	<p>The phase sequence on the soft starter mains terminals (L1, L2, L3) is not valid.</p> <p>Check the phase sequence on L1, L2, and L3, and ensure that the setting in <i>parameter 2-1 Phase Sequence</i> is suitable for the installation.</p> <p>Related parameters:</p> <ul style="list-style-type: none"> <li>• <i>Parameter 2-1 Phase Sequence.</i></li> </ul>
PLC	Name selected for a programmable input. Refer to <i>Input A trip</i> .
Power loss	<p>The soft starter is not receiving mains supply on 1 or more phases when a start command is given. Check that the main contactor closes when a start command is given and remains closed until the end of a soft stop.</p> <p>If testing the soft starter with a small motor, it must draw at least 2% of its minimum FLC setting on each phase.</p> <p>Related parameters: None.</p>
Pump fault	Name selected for a programmable input. Refer to <i>Input A trip</i> .
Starter/communication (between module and soft starter)	<ul style="list-style-type: none"> <li>• There is a problem with the connection between the soft starter and the optional communications module. Remove and reinstall the module. If the problem persists, contact the local distributor.</li> <li>• There is an internal communication error within the soft starter. Contact the local distributor.</li> </ul> <p>Related parameters:</p> <ul style="list-style-type: none"> <li>• <i>Parameter 16-10 Starter/Comms.</i></li> </ul>
Starter disable	Name selected for a programmable input. Refer to <i>Input A trip</i> .
Thermistor cct (thermistor circuit)	<p>The thermistor input has been enabled and:</p> <ul style="list-style-type: none"> <li>• The resistance at the input has dropped below 20 Ω (the cold resistance of most thermistors is above this value) or</li> <li>• A short circuit has occurred. Check and resolve this condition.</li> </ul> <p>Check that a PT100 (RTD) is not connected to terminals 05 and 06.</p> <p>Related parameters: None.</p>

Display	Possible cause/suggested solution
Time - overcurrent	The soft starter is internally bypassed and has drawn high current during running. (The 10 A protection curve trip has been reached, or the motor current has risen to 600% of the motor FLC setting.) Related parameters: None.
Undercurrent	The motor has experienced a sharp drop in current, caused by loss of load. Causes can include broken components (shafts, belts, or couplings) or a pump running dry. Related parameters: <ul style="list-style-type: none"> <li>• <i>Parameter 2-4 Undercurrent.</i></li> <li>• <i>Parameter 2-5 Undercurrent Delay.</i></li> <li>• <i>Parameter 16-3 Undercurrent.</i></li> </ul>
Unsupported option (function not available in inside delta)	The selected function is not available (for example jog is not supported in inside delta configuration). Related parameters: None.
Vibration	Name selected for a programmable input. Refer to <i>Input A trip</i> .
VZC fails px	Where X is 1, 2, or 3. Internal fault (PCB fault). Contact the local Danfoss supplier for advice. This trip is not adjustable. Related parameters: None.

Table 3.1 Trip Messages

### 3.3 General Faults

Table 3.2 describes situations where the soft starter does not operate as expected but neither trips nor issues a warning.

Symptom	Probable cause
The soft starter is not ready.	Check input A (11, 16). Check if the soft starter is disabled via a programmable input. If <i>parameter 3-3 Input A Function</i> is set to <i>Starter disable</i> , and there is an open circuit on the corresponding input, the soft starter does not start.
The soft starter does not respond to the [Hand On] and [Reset] keys.	Check if the soft starter is in auto-on mode. When the soft starter is in auto-on mode, the hand-on LED on the soft starter is off. Press [Auto On] once to change to local control.
The soft starter does not respond to commands from the control inputs.	<ul style="list-style-type: none"> <li>• The soft starter is waiting for the restart delay to elapse. <i>Parameter 2-11 Restart delay</i> controls the length of the restart delay.</li> <li>• The motor may be too hot to allow a start. If <i>parameter 2-12 Motor temperature check</i> is set to <i>Check</i>, the soft starter only allows a start when it calculates that the motor has sufficient thermal capacity to complete the start successfully. Wait for the motor to cool before attempting another start.</li> <li>• Check if the soft starter is disabled via a programmable input. If <i>parameter 3-3 Input A Function</i> is set to <i>Starter disable</i>, and there is an open circuit on terminals 11 and 16, the soft starter does not start. If there is no further need to disable the soft starter, close the circuit on the input.</li> </ul> <p><b>NOTICE</b> <i>Parameter 3-1 Local/remote controls when the [Auto On] is enabled.</i></p>

Symptom	Probable cause
The soft starter does not respond to a start command from either the local or remote controls.	<ul style="list-style-type: none"> <li>The soft starter may be waiting for the restart delay to elapse. <i>Parameter 2-11 Restart delay</i> controls the length of the restart delay.</li> <li>The motor may be too hot to allow a start. If <i>parameter 2-12 Motor temperature check</i> is set to <i>Check</i>, the soft starter only allows a start when it calculates that the motor has sufficient thermal capacity to complete the start successfully.</li> <li>Check if the soft starter is disabled via a programmable input. If <i>parameter 3-3 Input A function</i> is set to <i>Starter disable</i>, and there is an open circuit on terminals 11 and 16, the soft starter does not start. If there is no further need to disable the soft starter, close the circuit on the input.</li> </ul> <p><b>NOTICE</b>  <i>Parameter 3-1 Local/remote controls when [Auto On] is enabled.</i></p>
The soft starter does not control the motor correctly during start.	<ul style="list-style-type: none"> <li>Start performance may be unstable when using a low motor FLC setting (<i>parameter 1-1 Motor FLC</i>). This can affect use on a small test motor with full load current of 5–50 A.</li> <li>Install power factor correction (PFC) capacitors on the supply side of the soft starter. To control a dedicated PFC capacitor contactor, connect the contactor to run relay terminals.</li> </ul>
Motor does not reach full speed.	<ul style="list-style-type: none"> <li>If the start current is too low, the motor does not produce enough torque to accelerate to full speed. The soft starter may trip on excess start time.</li> </ul> <p><b>NOTICE</b>  <b>Make sure that the motor starting parameters are appropriate for the application and that the intended motor starting profile is used. If <i>parameter 3-3 Input A Function</i> is set to <i>Motor Set Select</i>, check that the corresponding input is in the expected state.</b></p> <ul style="list-style-type: none"> <li>Check if the load is jammed. Check the load for severe overloading or a locked rotor situation.</li> </ul>
Erratic motor operation.	<ul style="list-style-type: none"> <li>The SCRs in the soft starter require at least 5 A of current to latch. If testing the soft starter on a motor with full load current less than 5 A, the SCRs may not latch correctly.</li> </ul>
Erratic and noisy motor operation.	If the soft starter is connected to the motor using inside delta configuration, the soft starter may not be detecting the connection correctly. Contact the local Danfoss supplier for advice.
Soft stop ends too quickly.	<ul style="list-style-type: none"> <li>The soft stop settings may not be appropriate for the motor and load. Review the settings of: <ul style="list-style-type: none"> <li>- <i>Parameter 1-10 Stop Mode.</i></li> <li>- <i>Parameter 1-11 Stop Time.</i></li> <li>- <i>Parameter 7-10 Stop Mode-2.</i></li> <li>- <i>Parameter 7-11 Stop Time-2.</i></li> </ul> </li> <li>If the motor is lightly loaded, soft stop has limited effect.</li> </ul>
Adaptive control, DC brake, and jog functions not working.	<ul style="list-style-type: none"> <li>These features are only available with in-line installation. If the soft starter is installed inside delta, these features do not operate.</li> </ul>
A reset does not occur after an auto-reset when using a remote 2-wire control.	<ul style="list-style-type: none"> <li>Remove and reapply the remote 2-wire start signal for a restart.</li> </ul>
Remote start/stop command overrides autostart/stop settings when using remote 2-wire control.	<ul style="list-style-type: none"> <li>Only use autostart/stop in auto-on mode with 3-wire or 4-wire control.</li> </ul>

Symptom	Probable cause
After selecting adaptive control, the motor used an ordinary start and/or the 2 <sup>nd</sup> start was different from the 1 <sup>st</sup> start.	<ul style="list-style-type: none"> <li>The 1<sup>st</sup> adaptive control start is <i>Current limit</i>. The soft starter then learns from the motor characteristics. Subsequent starts use adaptive control.</li> </ul>
Non-resettable <i>Thermistor Cct</i> trip, when there is a link between thermistor inputs 05 and 06, or when the motor thermistor connected between 05 and 06 is permanently removed.	<ul style="list-style-type: none"> <li>The thermistor input is enabled once a link is fitted and short-circuit protection has activated.</li> </ul> <p>Remove the link, then load the default parameter set. This disables the thermistor input and clears the trip.</p> <p>Place a 1.2 kΩ resistor across the thermistor input.</p> <p>Turn thermistor protection to <i>Log only</i> (<i>parameter 16-9 Motor Thermistor</i>).</p>
Parameter settings cannot be stored.	<ul style="list-style-type: none"> <li>Make sure to save the new value by pressing [OK] after adjusting a parameter setting. If pressing [Back], the change is not saved.</li> <li>Check that the adjustment lock (<i>parameter 15-2 Adjustment Lock</i>) is set to <i>Read/Write</i>. If the adjustment lock is on, settings can be viewed, but not changed. Knowing the security access code is necessary to change the adjustment lock setting.</li> <li>The EEPROM may be faulty on the main control PCB. A faulty EEPROM also trips the soft starter, and the LCP shows the message <i>Par. Out of Range</i>. Contact the local Danfoss supplier for advice.</li> </ul>
The LCP shows message <i>Awaiting data</i> .	The LCP does not receive data from the control PCB. Check the cable connection.

Table 3.2 General Fault Messages

## 4 Service Instructions

### 4.1 Enclosure Sizes


The physical layout and spare parts for VLT® Soft Starter MCD 500 vary according to the size of the soft starter. MCD 500 soft starters can be grouped into 5 classes (enclosure sizes) as follows:

**4**

Class	MCD 500 models
G1B	MCD5-0021B MCD5-0037B MCD5-0043B MCD5-0053B MCD5-0068B MCD5-0084B MCD5-0089B MCD5-0105B
G2B	MCD5-0131B MCD5-0141B MCD5-0195B MCD5-0215B
G3B	MCD5-0245B MCD5-0331B MCD5-0396B
G4B	MCD5-0469B MCD5-0525B MCD5-0632B MCD5-0744B MCD5-0826B MCD5-0961B
G3C	MCD5-0245C
G4C	MCD5-0360C MCD5-0380C MCD5-0428C MCD5-0595C MCD5-0619C MCD5-0790C MCD5-0927C
G5C	MCD5-1200C MCD5-1410C MCD5-1600C

Table 4.1 MCD 500 Enclosure Sizes

4.1.1 MCD5-0021B ~ MCD5-0053B (G1B)




177HA536.10

1	Cover	7	Current transformers
2	Cable guide	8	Mounting posts
3	Main plastic	9	Backplane PCB
4	Terminal blocks	10	SCRs
5	LCP and main control PCB	11	Side plastic
6	Model PCB		

Illustration 4.1 Exploded View of MCD5-0021B ~ MCD5-0053B (G1B)

4.1.2 MCD5-0068B ~ MCD5-0105B (G1B)

4




177HA537.10

1	Cover	8	Mounting posts
2	Cable guide	9	Bypass contactors
3	Main plastic	10	Backplane PCB
4	Terminal blocks	11	SCRs
5	LCP and main control PCB	12	Side plastic
6	Model PCB	13	Fan
7	Current transformers		

Illustration 4.2 Exploded View of MCD5-0068B ~ MCD5-0105B (G1B)



4.1.3 MCD5-0131B ~ MCD5-0215B (G2B)




1	Cover	8	Model PCB
2	Main plastic	9	Current transformers
3	Cable guide	10	Bypass contactors
4	Terminal blocks	11	SCRs
5	LCP and main control PCB	12	Main body
6	Bypass Driver PCB	13	Fan and bracket
7	Support plastic		

Illustration 4.3 Exploded View of MCD5-0131B ~ MCD5-0215B (G2B)

4.1.4 MCD5-0245B ~ MCD5-0396B (G3B)

4




177HA661.10

1	Cover	6	Snubber assembly	11	Main chassis (see notice)
2	Main plastic	7	Current transformers	12	SCRs
3	LCP and main control PCB	8	Fan assembly	13	Heat sink
4	Bypass driver PCB	9	Support plastic		
5	Bypass contactors	10	Model PCB		

Illustration 4.4 Exploded View of MCD5-0245B ~ MCD5-0396B (G3B)

**NOTICE**


When refitting the main chassis of G3B units, ensure that the insulator card is bent upwards as shown in *Illustration 4.5*.



177HA667.10

Illustration 4.5 MCD 500 G3B Insulator Card

4.1.5 MCD5-0245C (G3C)




177HA539.10

1	Cover	7	Support plastic
2	Cable guide	8	Model PCB
3	Main plastic	9	Current transformers
4	Terminal blocks	10	SCRs
5	LCP and main control PCB	11	Main body
6	Fan assembly		

Illustration 4.6 Exploded View of MCD5-0245C (G3C)

4.1.6 MCD5-0469B ~ MCD5-0961B (G4B)


4



1	Cover	6	Bypass driver PCB
2	Main plastic	7	Snubber assembly
3	LCP and main control PCB	8	Fan assembly
4	Wiring loom (wiring harness)	9	Main chassis
5	Phase arm (SCR phase module)		

Illustration 4.7 Exploded View of MCD5-0469B ~ MCD5-0961B (G4B)

4.1.7 MCD5-0360C ~ MCD5-0927C (G4C)




4

1	Cover	8	Snubber assembly
2	Main plastic	9	Module mount and spacer plastic
3	Cable guide	10	Power assembly (SCR power assembly)
4	Support plastic	11	Fan assembly
5	Model PCB	12	Current transformer assembly
6	Module mount and spacer plastic	13	Main body
7	Magnetic bypass plate (models 0595C ~ 0927C)		

Illustration 4.8 Exploded View of MCD5-0360C ~ MCD5-0927C (G4C)

4.1.8 MCD5-1200C ~ MCD5-1600C (G5C)

4




1	Cover	8	Snubber assembly
2	Main plastic	9	Magnetic bypass plate
3	Cable guide	10	Power assembly (SCR power assembly)
4	LCP and main control PCB	11	Fan assembly
5	Bypass driver PCB	12	Current transformer assembly
6	Support plastic	13	Main body
7	Model PCB		

Illustration 4.9 Exploded View of MCD5-1200C ~ MCD5-1600C (G5C)

## 4.2 Identifying the Soft Starter Version

The soft starter version is the last 2 digits of the first part of the serial number on the nameplate.



1	Version number
---	----------------

Illustration 4.10 Nameplate

## 5 Spare Parts

### **NOTICE**

Unless otherwise indicated, spare part kits contain only 1 of each item. All images in this section are indicative.

### 5.1 Main Control PCB

Each soft starter requires 1 main control PCB.

5

### **NOTICE**

Kits 175G56\*\* do not support the control panel LCP 501 and are only used with MCD 500 units version 09 or earlier.  
Kits 175G57\*\* are fully backwards compatible.

Model	CV1		CV2	
	T5	T7	T5	T7
MCD5-0021B				
MCD5-0037B				
MCD5-0043B				
MCD5-0053B	175G5603	175G5604	175G5601	175G5602
MCD5-0068B	175G5703	175G5704	175G5701	175G5702
MCD5-0084B				
MCD5-0089B				
MCD5-0105B				
MCD5-0131B				
MCD5-0141B				
MCD5-0195B				
MCD5-0215B				
MCD5-0245B				
MCD5-0331B				
MCD5-0396B				
MCD5-0469B				
MCD5-0525B				
MCD5-0632B				
MCD5-0744B				
MCD5-0826B	175G5607	175G5608	175G5605	175G5606
MCD5-0961B	175G5707	175G5708	175G5705	175G5706
MCD5-0245C				
MCD5-0360C				
MCD5-0380C				
MCD5-0428C				
MCD5-0595C				
MCD5-0619C				
MCD5-0790C				
MCD5-0927C				
MCD5-1200C				
MCD5-1410C				
MCD5-1600C				

Table 5.1 Ordering Numbers for Main Control PCB





177HA558.10

Illustration 5.1 Main Control PCB Ordering Numbers 175G5601–175G5604 and 175G5701–175G5704



177HA559.10


Illustration 5.2 Main Control PCB Ordering Numbers 175G5605–175G5608 and 175G5705–175G5708

## 5.2 Model PCB

Each soft starter requires 1 model PCB.


Model	Ordering number
MCD5-0021B	175G5609
MCD5-0037B	175G5610
MCD5-0043B	175G5611
MCD5-0053B	175G5612
MCD5-0068B	175G5613
MCD5-0084B	175G5614
MCD5-0089B	175G5615
MCD5-0105B	175G5616
MCD5-0131B	175G5617
MCD5-0141B	175G5618
MCD5-0195B	175G5619
MCD5-0215B	175G5620
MCD5-0245B	175G5710
MCD5-0331B	175G5711
MCD5-0396B	175G5712
MCD5-0469B	175G5713
MCD5-0525B	175G5714
MCD5-0632B	175G5715
MCD5-0744B	175G5716
MCD5-0826B	175G5717
MCD5-0961B	175G5718
MCD5-0245C	175G5621
MCD5-0360C	175G5622
MCD5-0380C	175G5623
MCD5-0428C	175G5624
MCD5-0595C	175G5625
MCD5-0619C	175G5626
MCD5-0790C	175G5627
MCD5-0927C	175G5628
MCD5-1200C	175G5629
MCD5-1410C	175G5630
MCD5-1600C	175G5631

Table 5.2 Ordering Numbers for Model PCB




177HA560.10

Illustration 5.3 Model PCB Ordering Numbers 175G5609–175G5612



177HA561.10

Illustration 5.4 Model PCB Ordering Numbers 175G5613–175G5616



177HA562.10


Illustration 5.5 Model PCB Ordering Numbers 175G5617–175G5718

### 5.3 Backplane PCB

Models MCD5-0021B ~ MCD5-0105B require 1 backplane PCB.

Model	Ordering number
MCD5-0021B	175G5632
MCD5-0037B	
MCD5-0043B	
MCD5-0053B	
MCD5-0068B	
MCD5-0084B	
MCD5-0089B	
MCD5-0105B	
MCD5-0131B	Not required
MCD5-0141B	
MCD5-0195B	
MCD5-0215B	
MCD5-0245B	
MCD5-0331B	
MCD5-0396B	
MCD5-0469B	
MCD5-0525B	
MCD5-0632B	
MCD5-0744B	
MCD5-0826B	
MCD5-0961B	
MCD5-0245C	
MCD5-0360C	
MCD5-0380C	
MCD5-0428C	
MCD5-0595C	
MCD5-0619C	
MCD5-0790C	
MCD5-0927C	
MCD5-1200C	
MCD5-1410C	
MCD5-1600C	

Table 5.3 Ordering Numbers for Backplane PCB



177HA563.10

Illustration 5.6 Backplane PCB Ordering Number 175G5632


### 5.4 Bypass Driver PCB

Models MCD5-0131B ~ MCD5-0215B require 1 bypass driver PCB.

Model	Ordering number
MCD5-0021B	Not required
MCD5-0037B	
MCD5-0043B	
MCD5-0053B	
MCD5-0068B	
MCD5-0084B	
MCD5-0089B	
MCD5-0105B	
MCD5-0131B	
MCD5-0141B	
MCD5-0195B	
MCD5-0215B	175G5719
MCD5-0245B	
MCD5-0331B	
MCD5-0396B	
MCD5-0469B	
MCD5-0525B	175G5720
MCD5-0632B	
MCD5-0744B	
MCD5-0826B	
MCD5-0961B	Not required
MCD5-0245C	
MCD5-0360C	
MCD5-0380C	
MCD5-0428C	
MCD5-0595C	
MCD5-0619C	
MCD5-0790C	
MCD5-0927C	
MCD5-1200C	
MCD5-1410C	
MCD5-1600C	


Table 5.4 Ordering Numbers for Bypass Driver PCB

1) Bypass contactor upgrade: Refer to Product Note PN04 MCD 500 Bypass Contactor Upgrade for more information.




177HA564.10

Illustration 5.7 Bypass Driver PCB Ordering Number 175G5633



177HA595.10

Illustration 5.8 Bypass Driver PCB Ordering Number 175G5698



177HA659.10

Illustration 5.9 Bypass Driver PCB Ordering Numbers 175G5719, 175G5720

5.5 SCRs and SCR Connections

Models MCD5-0021B ~ MCD5-0396B use SCRs. Each soft starter requires 3 SCRs.

Model	Ordering number
MCD5-0021B	175G5119
MCD5-0037B	175G5120
MCD5-0043B	175G5121
MCD5-0053B	175G5122
MCD5-0068B	
MCD5-0084B	175G5123
MCD5-0089B	175G5124
MCD5-0105B	175G5634
MCD5-0131B	
MCD5-0141B	
MCD5-0195B	175G5126
MCD5-0215B	175G5127
MCD5-0245B	
MCD5-0245C	
MCD5-0331B	175G5721
MCD5-0396B	

Table 5.5 Ordering Numbers for SCRs




Illustration 5.10 SCRs Ordering Numbers 175G5119–175G5122




Illustration 5.11 SCRs Ordering Numbers 175G5123, 175G5124, 175G5634



Illustration 5.12 SCRs Ordering Numbers 175G5635, 175G5126, 175G5127

**NOTICE**

Spare part kits can include either Semikron or Eupec SCRs. These SCRs are fully interchangeable in MCD 500 units and can be mixed within the same soft starter.

**NOTICE**

SCR firing loom connections may be different from different manufacturers. Ensure that the wiring of connections matches the SCR type.

Connect the firing looms according to *Illustration 5.14* to *Illustration 5.22*.



Illustration 5.13 SCRs for Models 0021 ~ 0068




Illustration 5.14 Connection Diagram for Models 0021 ~ 0068




Illustration 5.15 Semikron SCR for Models 0084 ~ 0131




Illustration 5.16 Eupec SCR for Models 0084 ~ 0131




Illustration 5.17 Connection Diagram for Models 0084 ~ 0131




Illustration 5.18 Semikron SCR for Models 0141 ~ 0245




Illustration 5.19 Eupec SCR for Models 0141 ~ 0245




Illustration 5.20 Connection Diagram for Models 0141 ~ 0245



Illustration 5.21 SCR for Models 0331 ~ 0396




Illustration 5.22 Connection Diagram for Models 0331 ~ 0396

## 5.6 Power Assemblies (SCR Power Assemblies)

Models MCD5-0632B ~ MCD5-0961B use phase arms (SCR phase modules). Each soft starter requires 3 phase arms.

Model	Ordering number
MCD5-0469B	175G5722
MCD5-0525B	175G5723
MCD5-0632B	175G5724
MCD5-0744B	175G5725
MCD5-0826B	175G5726
MCD5-0961B	175G5727

Table 5.6 Ordering Numbers for Phase Arms (SCR Phase Modules)

Models MCD5-0360C ~ MCD5-1600C use power assemblies. Each soft starter requires 2 power assemblies.

Model	Ordering number
MCD5-0360C	175G5636
MCD5-0380C	175G5637
MCD5-0428C	175G5638
MCD5-0595C	175G5639
MCD5-0619C	175G5640
MCD5-0790C	175G5641
MCD5-0927C	175G5642
MCD5-1200C	175G5643
MCD5-1410C	175G5644
MCD5-1600C	175G5645

Table 5.7 Ordering Numbers for Power Assemblies



Illustration 5.23 Power Assemblies Ordering Numbers 175G5636–175G5642



5



Illustration 5.24 Power Assemblies Ordering Numbers  
175G5643–175G5645




Illustration 5.25 Power Assemblies Ordering Numbers  
175G5722–175G5727

### 5.7 Snubber Assemblies

Models MCD5-0245B ~ MCD5-0961B and T7 (AC input) models MCD5-0360C ~ MCD5-1600C use snubber assemblies. Each soft starter requires 3 snubber assemblies.

Each snubber kit includes 3 snubber assemblies.

Model	Ordering numbers
MCD5-0245B	175G5728
MCD5-0331B	
MCD5-0396B	
MCD5-0469B	175G5729
MCD5-0525B	
MCD5-0632B	
MCD5-0744B	
MCD5-0826B	
MCD5-0961B	175G5699
MCD5-0360C	
MCD5-0380C	
MCD5-0428C	
MCD5-0595C	
MCD5-0619C	
MCD5-0790C	
MCD5-0927C	
MCD5-1200C	175G5700
MCD5-1410C	
MCD5-1600C	

Table 5.8 Ordering Numbers for Snubber Assemblies




Illustration 5.26 Snubber Assemblies Ordering Number  
175G5728




Illustration 5.27 Snubber Assemblies Ordering Number 175G5729



Illustration 5.28 Snubber Assemblies Ordering Number 175G5699




Illustration 5.29 Snubber Assemblies Ordering Number 175G5700

### 5.8 Fans

Certain models include a fan. The number of fans required differs between units and is shown in Table 5.9.

Model	Part number	Quantity
MCD5-0021B	Not required	-
MCD5-0037B		
MCD5-0043B		
MCD5-0053B		
MCD5-0068B	175G5646	-
MCD5-0084B		
MCD5-0089B		
MCD5-0105B		
MCD5-0131B		
MCD5-0141B		
MCD5-0141B	Not required	-
MCD5-0195B	175G5646	1
MCD5-0215B		
MCD5-0245B	175G5647	3
MCD5-0331B		
MCD5-0396B		
MCD5-0469B		
MCD5-0525B		
MCD5-0632B		
MCD5-0744B		
MCD5-0826B		
MCD5-0961B		
MCD5-0245C		
MCD5-0360C		
MCD5-0380C		
MCD5-0428C		
MCD5-0595C		
MCD5-0619C	175G5648	2
MCD5-0790C		
MCD5-0927C		
MCD5-1200C	175G5648	3
MCD5-1410C		
MCD5-1600C		

Table 5.9 Ordering Numbers for Fans

5



177HA552.10

Illustration 5.30 Fan Ordering Numbers 175G5646, 175G5647



177HA553.10

Illustration 5.31 Fan Ordering Number 175G5648

### 5.9 Current Transformers

Each soft starter requires 3 current transformers.

Model	Ordering number
MCD5-0021B	175G5649
MCD5-0037B	
MCD5-0043B	
MCD5-0053B	
MCD5-0068B	
MCD5-0084B	
MCD5-0089B	
MCD5-0105B	
MCD5-0131B	175G9048
MCD5-0141B	
MCD5-0195B	
MCD5-0215B	
MCD5-0245B	
MCD5-0331B	
MCD5-0396B	1)
MCD5-0469B	
MCD5-0525B	
MCD5-0632B	
MCD5-0744B	
MCD5-0826B	175G9048
MCD5-0961B	
MCD5-0245C	
MCD5-0360C	
MCD5-0380C	
MCD5-0428C	
MCD5-0595C	
MCD5-0619C	
MCD5-0790C	
MCD5-0927C	
MCD5-1200C	175G5652
MCD5-1410C	
MCD5-1600C	
MCD5-1600C	175G5653
MCD5-0595C	175G5654
MCD5-0619C	175G5654
MCD5-0790C	175G5655
MCD5-0927C	175G5656
MCD5-1200C	175G5657
MCD5-1410C	175G5658
MCD5-1600C	175G5659

Table 5.10 Ordering Numbers for Current Transformers

1) The current transformers for models MCD5-0469B ~ MCD5-0961B are included in the phase arm.



177HA554.10

Illustration 5.32 Current Transformers Ordering Numbers 175G9048





Illustration 5.33 Current Transformers Ordering Numbers  
175G5649



Illustration 5.34 Current Transformers Ordering Numbers  
175G5652-175G5659

### 5.10 Bypass Contactors

Some models are internally bypassed. The bypass contactor for models MCD5-0021B ~ MCD5-0053B is included in the model PCB. The bypass contactors for models MCD5-0632B ~ MCD5-0961B are included in the phase arm. Each soft starter requires 3 bypass contactors.

Model	Ordering number
MCD5-0021B	Not required
MCD5-0037B	
MCD5-0043B	
MCD5-0053B	
MCD5-0068B	175G5660
MCD5-0084B	
MCD5-0089B	
MCD5-0105B	
MCD5-0131B	175G5661 (version 02 or earlier) 175G5697 (version 03 and later) <sup>1)</sup>
MCD5-0141B	
MCD5-0195B	
MCD5-0215B	
MCD5-0245B	175G0121
MCD5-0331B	175G0122
MCD5-0396B	
MCD5-0469B	
MCD5-0525B	
MCD5-0245C	Not required
MCD5-0360C	
MCD5-0380C	
MCD5-0428C	
MCD5-0595C	
MCD5-0619C	
MCD5-0790C	
MCD5-0927C	
MCD5-1200C	
MCD5-1410C	
MCD5-1600C	

Table 5.11 Ordering Numbers for Bypass Contactors

1) Bypass contactor upgrade. 175G5697 supersedes 175G5661. For more information, refer to Product Note PN04 MCD 500 Bypass Contactor Upgrade and PN15 MCD500 G2 Bypass Contactor Service Spares.




Illustration 5.35 Bypass Contactors Ordering Number  
175G5660

5



177HA55

Illustration 5.36 Bypass Contactors Ordering Numbers 175G5661 and 175G5697



177HA683.10

Illustration 5.37 Bypass Contactors Ordering Numbers 175G0121 and 175G0122

### 5.11 Plastic Components

The following body plastic components are available for VLT® Soft Starter MCD 500.

Model	Cover	Main plastic component	Cable guide	Mounting posts
MCD5-0021B	175G5667	175G5671	175G5669	175G5670 (set of 3)
MCD5-0037B				
MCD5-0043B				
MCD5-0053B				
MCD5-0068B				
MCD5-0084B				
MCD5-0089B				
MCD5-0105B				
MCD5-0131B	175G5668	175G5672		Not required
MCD5-0141B				
MCD5-0195B				
MCD5-0215B				
MCD5-0245B				
MCD5-0331B				
MCD5-0396B				
MCD5-0469B				
MCD5-0525B				
MCD5-0632B				
MCD5-0744B				
MCD5-0826B				
MCD5-0961B				
MCD5-0245C				
MCD5-0360C				
MCD5-0380C				
MCD5-0428C				
MCD5-0595C				
MCD5-0619C				
MCD5-0790C				
MCD5-0927C				
MCD5-1200C				
MCD5-1410C				
MCD5-1600C				

Table 5.12 Ordering Numbers for Plastic Components



177HA566.10

Illustration 5.38 Plastic Components Ordering Numbers  
175G5667 and 175G5668



Illustration 5.41 Plastic Components Ordering Number  
175G5670

5



177HA571.11

Illustration 5.39 Plastic Components Ordering Numbers  
175G5671 and 175G5672



177HA568.10

Illustration 5.40 Plastic Components Ordering Number  
175G5669

### 5.11.1 Complete Plastic Components

The complete plastic components kit contains the following items:

- 175G5673:
  - 175G5667
  - 175G5671
  - 175G5669
  - 175G5670
  - Side plastic
  - Plastic base
- 175G5674:
  - 175G5668
  - 175G5672
  - 175G5669
  - Support plastic
- 175G5675:
  - 175G5672
  - 175G5669
  - Support plastic

Model	Complete plastic component kits
MCD5-0021B	175G5673
MCD5-0037B	
MCD5-0043B	
MCD5-0053B	
MCD5-0068B	
MCD5-0084B	
MCD5-0089B	
MCD5-0105B	
MCD5-0131B	175G5674
MCD5-0141B	
MCD5-0195B	
MCD5-0215B	
MCD5-0245B	
MCD5-0331B	
MCD5-0396B	
MCD5-0469B	
MCD5-0525B	
MCD5-0632B	
MCD5-0744B	175G5675
MCD5-0826B	
MCD5-0961B	
MCD5-0245C	
MCD5-0360C	
MCD5-0380C	
MCD5-0428C	
MCD5-0595C	
MCD5-0619C	
MCD5-0790C	
MCD5-0927C	
MCD5-1200C	
MCD5-1410C	
MCD5-1600C	

Table 5.13 Ordering Numbers for Complete Plastic Component Kits

### 5.12 Control Panel LCP 501 Upgrade Kit

A remote mountable LCP, control panel LCP 501, is available for use with VLT® Soft Starter MCD 500. An upgrade kit containing new body plastics is required to use control panel LCP 501 with MCD 500 units of version 09 or earlier.

**NOTICE**

A new main control PCB is also required to support the control panel LCP 501. See *chapter 5.1 Main Control PCB* for details.



177HA566.10

Illustration 5.42 LCP 501 Upgrade Kit Ordering Number 175G0096

Model	Upgrade kit	Control panel LCP 501
MCD5-0021B	175G0097	175G0096
MCD5-0037B		
MCD5-0043B		
MCD5-0053B		
MCD5-0068B		
MCD5-0084B		
MCD5-0089B		
MCD5-0105B		
MCD5-0131B	175G0098	
MCD5-0141B		
MCD5-0195B		
MCD5-0215B		
MCD5-0245B	-	-
MCD5-0331B		
MCD5-0396B		
MCD5-0469B		
MCD5-0525B		
MCD5-0632B		
MCD5-0744B		
MCD5-0826B		
MCD5-0961B	175G0098	175G0096
MCD5-0245C		
MCD5-0360C		
MCD5-0380C		
MCD5-0428C		
MCD5-0595C		
MCD5-0619C		
MCD5-0790C		
MCD5-0927C		
MCD5-1200C		
MCD5-1410C		
MCD5-1600C		



177HA571.11

Illustration 5.43 LCP 501 Upgrade Kit Ordering Numbers 175G0097 and 175G0098

Table 5.14 Ordering Numbers for Control Panel LCP 501 Upgrade Kit


5.13 Busbars

Each soft starter requires a total of 6 busbars (3 inputs and 3 outputs). Each kit contains 3 busbars (unless otherwise stated) and fixing accessories if applicable.

5

Model	Input	Output
MCD5-0021B	175G5677	175G5678
MCD5-0037B		
MCD5-0043B		
MCD5-0053B		
MCD5-0068B	175G5679	175G5680
MCD5-0084B	175G5681	174G5682
MCD5-0089B		
MCD5-0105B		
MCD5-0131B	175G5696	175G5683
MCD5-0141B	175G5684	175G5685
MCD5-0195B		
MCD5-0215B		
MCD5-0245B		
MCD5-0331B		
MCD5-0396B	Available on request	Available on request
MCD5-0469B		
MCD5-0525B		
MCD5-0632B		
MCD5-0744B		
MCD5-0826B		
MCD5-0961B		
MCD5-0245C	175G5686	175G5687 (set of 6)
MCD5-0360C	175G5688	175G5689
MCD5-0380C		
MCD5-0428C		
MCD5-0595C		
MCD5-0619C		
MCD5-0790C		
MCD5-0927C	175G5690	175G5691
MCD5-1200C	175G5692	175G5693
MCD5-1410C		
MCD5-1600C	175G5694	175G5695

Table 5.15 Ordering Numbers for Busbars



177HA573.10

Illustration 5.44 Busbar Ordering Number 175G5677



Illustration 5.45 Busbar Ordering Numbers 175G5679 and 175G5681



177HA573.10

Illustration 5.46 Busbar Ordering Numbers 175G5678, 175G5680, and 175G5682





Illustration 5.47 Busbar Ordering Numbers 175G5696 and 175G5684



Illustration 5.48 Busbar Ordering Numbers 175G5683 and 175G5685



177HA578.10

Illustration 5.49 Busbar Ordering Number 175G5686



177HA579.10

Illustration 5.50 Busbar Ordering Number 175G5687



Illustration 5.51 Busbar Ordering Numbers 175G5688, 175G5690, 175G5692, and 175G5694



Illustration 5.52 Busbar Ordering Numbers 175G5689, 175G5691, 175G5693, and 175G5695

5.14 Other Spare Parts

The spare parts in Table 5.16 are also available.

5

Model	Cage clamps	Connector plugs
MCD5-0021B	175G5666 (set of 3)	175G5676 (set of 3)
MCD5-0037B		
MCD5-0043B		
MCD5-0053B		
MCD5-0068B		
MCD5-0084B		
MCD5-0089B		
MCD5-0105B		
MCD5-0131B		
MCD5-0141B		
MCD5-0195B		
MCD5-0215B		
MCD5-0245B		
MCD5-0331B		
MCD5-0396B		
MCD5-0469B		
MCD5-0525B		
MCD5-0632B		
MCD5-0744B		
MCD5-0826B		
MCD5-0961B		
MCD5-0245C		
MCD5-0360C		
MCD5-0380C		
MCD5-0428C		
MCD5-0595C		
MCD5-0619C		
MCD5-0790C		
MCD5-0927C		
MCD5-1200C		
MCD5-1410C		
MCD5-1600C		



177HA565.10

Illustration 5.53 Other Spare Parts Ordering Number 175G5666



177HA572.10



Illustration 5.54 Other Spare Parts Ordering Number 175G5676

Table 5.16 Ordering Numbers for Other Spare Parts



## 6 Avoiding Damage

### 6.1 SCRs

#### 6.1.1 Typical Causes of SCR Damage

Generally, overcurrent, overvoltage, or overtemperature cause SCR damage. To prevent damage, check that the soft starter has been installed properly. Common causes of SCR problems include:

##### Overcurrent

- Cable fault on soft starter output.
- Motor fault.
- Start current and/or start time exceed the soft starter rating.
- Starts per hour exceed the soft starter rating.

##### Overvoltage

- Supply transient or surge.
- Lightning strike (direct or indirect) on supply.
- Motor fault.
- Loose connection in power circuit, before or after the soft starter.
- Power factor correction connected to the output of the soft starter.
- Overcorrected bulk power factor correction on a lightly loaded system causing severe ringing voltages.

##### Overtemperature

- Blocked heat sinks or restricted ventilation.
- Inadequate ventilation.
- Excessive ambient temperatures.
- Bypass relay fails to close during running (internally bypassed starters only).

#### 6.1.2 Protecting SCRs

Modern SCRs are rugged and reliable. However, the risk of SCR damage can be reduced by using semiconductor fuses and/or a main contactor.

#### 6.1.3 Semiconductor Fuses

Semiconductor fuses reduce the potential for SCR damage caused by short circuits on the output of the soft starter.

Protection systems such as circuit breakers or HRC fuses do not operate quickly enough to protect SCRs from short circuits.

#### 6.1.4 Main Contactors

SCRs are most vulnerable to overvoltage damage when voltage is applied to their input terminal while they are off. In this condition, the SCR blocks the full mains voltage. Using a main contactor to remove voltage from the SCR input when the soft starter is off eliminates the risk of SCR damage due to overvoltage.

### 6.2 Output Relays

VLT® Soft Starter MCD 500 has 3 programmable output relays. These relays are often used to control external contactors.

The electronic contactor coils used in many contactors have a high initial inrush current. If the contactor coil is switched directly, the internal relays of the soft starter can be damaged.


#### 6.2.1 Using the Soft Starter to Switch a Contactor

Before using the soft starter output relay to switch an electronic contactor coil, consult the contactor manufacturer. Some contactor manufacturers (for example Klockner-Moeller) state that PCB mount relays cannot be used for direct switching of their electronic contactor coils.

If this is case, there are 2 solutions:

- Use the output relay to control a slave relay. This slave relay can then be used to switch the electronic contactor coil circuit directly.


6



1	Soft starter output relay
2	Slave relay coil
3	Contactor coil

Illustration 6.1 Relay Controlling a Slave Relay

- If the contactor has a volt-free electronic input (low voltage/low current), the output relay can be wired directly into this input for contactor control.



1	Soft starter output relay
2	Contactor coil

Illustration 6.2 Output Relay Directly Wired to a Volt-free Electronic Input

### 6.3 Control Input

Operate VLT® Soft Starter MCD 500 with external 2-wire or 3-wire control signals. Configure and wire external switches into control input terminals 17 and 25.

- External switches operating the control inputs must be rated for the control voltage being used and a continuous current of 100 mA.
- Incorrect configuration and wiring of the external contacts/switches to the control input terminals can cause damage.
- If long cable runs are used, wiring must be twisted pair or shielded cable and must be separated from AC power cables by at least 300 mm (984.2 ft).

## 7 Appendix

### 7.1 Bolts and Tightening Torques

When assembling soft starter components, tighten each bolt using a calibrated torque driver set to the appropriate assembly torque. *Table 7.1 to Table 7.5* indicate the different types of bolts and bolt tightening torques for each assembly.

#### 7.1.1 Input/Output Busbars to SCRs

Model	Bolt size	Torque (Nm)
MCD5-0021B MCD5-0037B MCD5-0043B MCD5-0053B MCD5-0068B MCD5-0084B MCD5-0089B MCD5-0105B	M5x12	4
MCD5-0084B MCD5-0089B MCD5-0105B	M6x16	4
MCD5-0131B	M6x16	5
MCD5-0141B MCD5-0195B MCD5-0215B MCD5-0245B	M8x20	9
MCD5-0331B MCD5-0396B	M10x20	12
MCD5-0469B MCD5-0525B MCD5-0632B MCD5-0744B MCD5-0826B MCD5-0961B	M8x25	20
MCD5-0245C	M8x20	8
MCD5-0360C MCD5-0380C MCD5-0428C MCD5-0595C MCD5-0619C MCD5-0790C MCD5-0927C	M8x16	12
MCD5-1200C MCD5-1410C MCD5-1600C	M10x35	20

Table 7.1 Tightening Torque Busbars to SCRs

#### 7.1.2 SCRs to Heat Sink

Model	Bolt size	Torque (Nm)
MCD5-0021B MCD5-0037B MCD5-0043B MCD5-0053B MCD5-0068B MCD5-0084B MCD5-0089B MCD5-0105B MCD5-0131B MCD5-0141B MCD5-0195B	M5x16	5
MCD5-0215B MCD5-0245B	M5x20	5
MCD5-0331B MCD5-0396B	M6x30	5
MCD5-0469B MCD5-0525B MCD5-0632B MCD5-0744B MCD5-0826B MCD5-0961B	Not required	Not required
MCD5-0245C	M5x20	4
MCD5-0360C MCD5-0380C MCD5-0428C MCD5-0595C MCD5-0619C MCD5-0790C MCD5-0927C MCD5-1200C MCD5-1410C MCD5-1600C	Not required	Not required

Table 7.2 Tightening Torque SCRs to Heat Sink

### 7.1.3 Bypass Contactor Connections

Model	Bolt size	Torque (Nm)
MCD5-0021B MCD5-0037B MCD5-0043B MCD5-0053B	M5x12	4
MCD5-0068B MCD5-0084B MCD5-0089B MCD5-0105B	M6x12	4
MCD5-0131B MCD5-0141B	M5x12	4
MCD5-0195B MCD5-0215B MCD5-0245B	M8x20	8
MCD5-0331B MCD5-0396B	M10x30	20
MCD5-0469B MCD5-0525B	M10x25	20
MCD5-0632B MCD5-0744B MCD5-0826B MCD5-0961B	Not required	Not required
MCD5-0245C MCD5-0360C MCD5-0380C MCD5-0428C MCD5-0595C MCD5-0619C MCD5-0790C MCD5-0927C MCD5-1200C MCD5-1410C MCD5-1600C	M8x20	8
	Not required	Not required

Table 7.3 Tightening Torques Bypass Contactor Connections

### 7.1.4 Current Transformer Busbar Assembly

Model	Bolt size	Torque (Nm)
MCD5-0245C	M6x16	4

Table 7.4 Tightening Torques Current Transformer Busbar Assembly

7

## 7.2 Minimum and Maximum Current Settings

The minimum and maximum full load current settings depend on the soft starter model:

Model	In-line connection		Inside delta connection	
	Minimum [A]	Maximum [A]	Minimum [A]	Maximum [A]
MCD5-0021B	5	23	5	34
MCD5-0037B	9	43	9	64
MCD5-0043B	10	50	10	75
MCD5-0053B	11	53	11	79
MCD5-0068B	15	76	15	114
MCD5-0084B	19	97	19	145
MCD5-0089B	20	100	20	150
MCD5-0105B	21	105	21	157
MCD5-0131B	29	145	29	217
MCD5-0141B	34	170	34	255
MCD5-0195B	40	200	40	300
MCD5-0215B	44	220	44	330

Model	In-line connection		Inside delta connection	
	Minimum [A]	Maximum [A]	Minimum [A]	Maximum [A]
MCD5-0245B	51	255	51	382
MCD5-0245C	51	255	51	382
MCD5-0331B	70	350	70	525
MCD5-0360C	72	360	72	540
MCD5-0380C	76	380	76	570
MCD5-0396B	85	425	85	638
MCD5-0428C	86	430	86	645
MCD5-0469B	100	500	100	750
MCD5-0525B	116	580	116	870
MCD5-0595C	124	620	124	930
MCD5-0619C	130	650	130	975
MCD5-0632B	140	700	140	1050
MCD5-0790C	158	790	158	1185
MCD5-0744B	164	820	164	1230
MCD5-0826B	184	920	184	1380
MCD5-0927C	186	930	186	1395
MCD5-0961B	200	1000	200	1500
MCD5-1200C	240	1200	240	1800
MCD5-1410C	282	1410	282	2115
MCD5-1600C	320	1600	320	2400

Table 7.5 Minimum and Maximum Current Settings

### 7.3 Symbols, Abbreviations, and Conventions

AC	Alternating current
DC	Direct current
FLC	Full load current
LCP	Local control panel
MOV	Metal oxide varistor
PCB	Printed circuit board
PFC	Power factor correction
SCR	Silicon-controlled rectifier

Table 7.6 Symbols and Abbreviations

#### Conventions

Numbered lists indicate procedures.

Bullet lists indicate other information.

Italicized text indicates:

- Cross-reference.
- Link.
- Parameter name.

All dimensions in drawings are in [mm].

## Index

<b>A</b>	
Abbreviations.....	47
Access code.....	15
Assembly torque.....	45
Auto-on mode.....	4, 14
<b>B</b>	
Bolts.....	45
Brake	
DC brake.....	14
Starter disable.....	12, 13
Busbar.....	4, 40
<b>C</b>	
Capacitors	
Power factor correction capacitor.....	4, 14
Connection diagram for SCRs.....	30, 31
Connections	
In-line connection.....	9, 11
Inside delta.....	11
Inside delta connection.....	9, 14
Motor connection.....	11
Contactors	
Bypass contactor.....	4, 9, 11
Main contactor.....	5, 12
Control input.....	44
Conventions.....	47
Current imbalance.....	9
Current settings.....	46
<b>D</b>	
Delay.....	13
<b>E</b>	
Enclosure size.....	16
Event log.....	6
Excess start time.....	9
Exploded views	
G1B.....	17, 18
G2B.....	19
G3B.....	20
G3C.....	21
G4B.....	22
G4C.....	23
G5C.....	24
<b>F</b>	
Features	
Adaptive control.....	9, 14, 15
DC brake.....	14
In-line connection.....	9, 11
In-line installation.....	14
Inside delta.....	11
Inside delta connection.....	9, 14
Inside delta installation.....	14
Jog.....	13, 14
Starter disable.....	12, 13
FLC.....	9, 13, 14, 47
see also <i>Full load current</i>	
Frame size.....	16
see also <i>Enclosure size</i>	
Full load current.....	9, 13, 14, 47
see also <i>FLC</i>	
<b>G</b>	
General fault messages.....	15
<b>H</b>	
Heat sink.....	4, 10, 43
<b>I</b>	
Input A trip.....	8, 10, 11, 12, 13
Inputs	
Input A.....	10, 12, 13, 14
Programmable input.....	8, 10, 12, 13
Remote.....	4, 6
Installation	
In-line installation.....	14
Inside delta installation.....	14
<b>L</b>	
LCP.....	8, 15, 47
see also <i>Local control panel</i>	
Local control.....	13
Local control panel.....	8, 15, 47
see also <i>LCP</i>	
<b>M</b>	
Main contactor.....	43
Main menu.....	12
Models	
Internally bypassed.....	11, 13
Motor	
connection.....	5, 11
temperature.....	13
windings.....	9, 11
Overload.....	11
Thermal capacity.....	11, 13
Thermistor.....	12, 15

**N**

Nameplate..... 25  
 Network communication..... 12

**O**

Ordering numbers

Backplane PCB..... 28  
 Busbar..... 40, 41  
 Bypass contactor..... 35  
 Bypass driver PCB..... 29  
 Complete plastic components kit..... 38  
 Control panel LCP 501 upgrade kit..... 39  
 Current transformer..... 34  
 Fan..... 33  
 Main control PCB..... 26  
 Model PCB..... 27  
 Other spare parts..... 42  
 Phase arm..... 31  
 Plastic..... 36  
 Power assembly..... 31  
 SCR phase module..... 31  
 SCR power assembly..... 31  
 SCRs and SCR Connection..... 30  
 Snubber assembly..... 32

Output relay..... 43

Overcurrent..... 10, 13

Overvoltage..... 6, 43

**P**

Power factor..... 14

Power factor correction..... 47

Power loss..... 12

Protection settings..... 11

**Q**

Qualified personnel..... 4

**R**

Remote control..... 13

Restart delay..... 13

**S**

Safety

Instructions..... 4

SCR damage..... 43

SCR firing loom..... 30

SCR, connection diagram..... 30, 31

Semiconductor fuse..... 43

Spare part..... 16, 26

Spare parts

Backplane PCB..... 28  
 Busbar..... 40, 41  
 Bypass contactor..... 35  
 Bypass driver PCB..... 29  
 Complete plastic components kit..... 38  
 Control panel LCP 501 upgrade kit..... 39  
 Current transformer..... 34  
 Eupec SCRs..... 30  
 Fan..... 33  
 Main control PCB..... 26  
 Model PCB..... 27  
 Other spare parts..... 42  
 Phase arm..... 31  
 Plastic..... 36  
 Power assembly..... 31  
 SCR phase module..... 31  
 SCR power assembly..... 31  
 SCRs and SCR Connection..... 30  
 Semikron SCRs..... 30  
 Snubber assembly..... 32

Start modes

Adaptive control..... 9, 14, 15  
 Jog..... 13, 14

Starting profile..... 14

Stop modes

DC brake..... 14  
 Starter disable..... 12, 13

Stop time..... 14

Supply..... 4, 5, 10, 11, 12, 14

Symbols..... 47

**T**

Terminals

A4..... 11  
 A5..... 11  
 A6..... 11  
 Relay terminal..... 14  
 Terminal 05..... 12  
 Terminal 06..... 12  
 Terminal 11..... 12, 13  
 Terminal 16..... 12, 13  
 Terminal 17..... 44  
 Terminal 25..... 44

Tightening torque..... 45

Trip messages..... 13

**U**

Undercurrent..... 13

Unintended start..... 4



.....  
Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.  
.....

Danfoss A/S  
Ulsnaes 1  
DK-6300 Graasten  
vlt-drives.danfoss.com

