

MAKING MODERN LIVING POSSIBLE



# Quick Guide

## VLT® Compressor Drive CDS 803



[www.danfoss.com/drives](http://www.danfoss.com/drives)

**VLT**®  
THE REAL DRIVE



**Contents**

<b>1 Quick Guide</b>	2
1.1 Safety	2
1.1.1 Warnings	2
1.1.2 Safety Instructions	2
1.2 Introduction	2
1.2.1 Available Literature	2
1.2.2 Approvals	3
1.2.3 IT Mains	3
1.2.4 Avoid Unintended Start	3
1.2.5 Disposal Instruction	3
1.3 Installation	3
1.3.1 Before Starting Repair Work	3
1.3.2 Enclosure Types	3
1.3.3 Side-by-Side Installation	4
1.3.4 Dimensions	4
1.3.6 Connecting to Mains and Compressor	5
1.3.7 Fuses	7
1.3.8 EMC-Correct Electrical Installation	8
1.3.9 Control Terminals	9
1.4 Programming	11
1.4.2 The Start-up Wizard	12
1.4.3 Main Menu Structure	21
1.5 Acoustic Noise or Vibration	23
1.6 Warnings and Alarms	23
1.7 General Specifications	24
1.7.1 Mains Supply 3x200-240 V AC	24
1.7.2 Mains Supply 3x380-480 V AC	25
1.8 Special Conditions	29
1.8.1 Derating for Ambient Temperature and Switching Frequency	29
1.8.2 Derating for Low Air Pressure	29
1.9 Options for VLT® Compressor Drive CDS 803	29

# 1 Quick Guide

## 1.1 Safety

### 1.1.1 Warnings

#### **WARNING**

##### High Voltage Warning

The voltage of the frequency converter is dangerous whenever it is connected to mains. Incorrect installation of the compressor or frequency converter may cause damage to the equipment, serious injury or death. Consequently, it is essential to comply with the instructions in this manual as well as local and national rules and safety regulations.

#### **WARNING**

##### DISCHARGE TIME!

Frequency converters contain DC-link capacitors that can remain charged even when the frequency converter is not powered. To avoid electrical hazards, disconnect AC mains, any permanent magnet type compressors, and any remote DC-link power supplies, including battery back-ups, UPS, and DC-link connections to other frequency converters. Wait for the capacitors to fully discharge before performing any service or repair work. The waiting time is listed in the *Discharge Time* table. Failure to wait the specified time after power has been removed before doing service or repair could result in death or serious injury.

Voltage [V]	Cooling capacity [TR]	Minimum waiting time (min)
3x200	4-6.5	15
3x400	4-5	4
3x400	6.5	15

Table 1.1 Discharge Time

#### **CAUTION**

##### Leakage Current

The ground leakage current from the frequency converter exceeds 3.5 mA. According to IEC 61800-5-1 a reinforced Protective Earth connection must be ensured with a min. 10 mm<sup>2</sup> Cu or an additional PE wire - with the same cable cross-section as the mains wiring - must be terminated separately.

##### Residual Current Device

This product can cause a DC current in the protective conductor. Where a residual current device (RCD) is used for extra protection, only an RCD of Type B (time delayed) shall be used on the supply side of this product. See also *Danfoss Application Note on RCD, MN90G*.

Protective earthing of the frequency converter and the use of RCDs must always follow national and local regulations.

#### **WARNING**

##### Installation at High Altitudes

For altitudes above 2000 m, contact Danfoss regarding PELV.

## 1.1.2 Safety Instructions

- Make sure the frequency converter is properly connected to ground.
- Do not remove mains connections, compressor connections or other power connections while the frequency converter is connected to power.
- Protect users against supply voltage.
- Protect the compressor against overloading according to national and local regulations.
- The ground leakage current exceeds 3.5 mA.
- The [Off/Reset] key is not a safety switch. It does not disconnect the frequency converter from mains.

## 1.2 Introduction

### 1.2.1 Available Literature

This Quick Guide contains basic information necessary for installing and running the frequency converter. Supplementary publications and manuals are available from Danfoss. See [www.danfoss.com/BusinessAreas/DrivesSolutions/ Documentations/VLT+Technical+Documentation.htm](http://www.danfoss.com/BusinessAreas/DrivesSolutions/Documentations/VLT+Technical+Documentation.htm) for listings.

## 1.2.2 Approvals

Certification		IP20
EC Declaration of Conformity		✓
UL Listed		✓
C-tick		✓

Table 1.2 Approvals

The frequency converter complies with UL508C thermal memory retention requirements. For more information, refer to the section *Motor Thermal Protection* in the product specific *design guide*.


## 1.2.3 IT Mains

### CAUTION

#### IT Mains

Installation on isolated mains source, that is, IT mains.  
Max. supply voltage allowed when connected to mains:  
440 V (3x380-480 V units).

Open the RFI switch by removing the screw on the side of the frequency converter when at IT grid.



1 RFI switch

Illustration 1.1 IP20

### CAUTION

If reinserted, only use M3x12 screw.

## 1.2.4 Avoid Unintended Start

While the frequency converter is connected to mains, the compressor can be started/stopped using digital commands, bus commands, references or via the LCP.

- Disconnect the frequency converter from mains whenever personal safety considerations make it necessary to avoid unintended start of any compressors.
- To avoid unintended start, always press [Off/Reset] before changing parameters.

## 1.2.5 Disposal Instruction



Equipment containing electrical components must not be disposed of together with domestic waste.

It must be separately collected with electrical and electronic waste according to local and currently valid legislation.

## 1.3 Installation

### 1.3.1 Before Starting Repair Work

1. Disconnect from mains (and external DC supply, if present).
2. Wait as stated in *Table 1.1* for discharge of the DC-link.
3. Remove compressor cable.

### 1.3.2 Enclosure Types

Cooling capacity	400 V IP20
Enclosure	
4 TR/VZH028	H3
5 TR/VZH035	H3
6.5 TR/VZH044	H4

Table 1.3 H3-H4, 400 V

Cooling capacity	200 V IP20
Enclosure	
4 TR/VZH028	H4
5 TR/VZH035	H4
6.5 TR/VZH044	H5

Table 1.4 H4-H5, 200 V

### 1.3.3 Side-by-Side Installation

The frequency converter can be mounted side-by-side and requires the clearance above and below for cooling.

Frame	IP class	Clearance above/below [mm/inch]
H3	IP20	100/4
H4	IP20	100/4
H5	IP20	100/4

Table 1.5 Clearance

#### NOTICE

With IP21/Nema Type1 option kit mounted, a distance of 50 mm between the units is required.

### 1.3.4 Dimensions

#### NOTICE

The illustration in *Table 1.6* is with LCP, but all dimensions are the same without LCP.



Enclosure		Height [mm]			Width [mm]		Depth [mm]	Mounting hole [mm]			Max. Weight
Frame	IP Class	A	A <sup>1)</sup>	a	B	b	C	d	e	f	kg
H3	IP20	255	329	240	100	74	206	11	5.5	8.1	4.5
H4	IP20	296	359	275	135	105	241	12.6	7	8.4	7.9
H5	IP20	334	402	314	150	120	255	12.6	7	8.5	9.5

Table 1.6 Dimensions

1) Including decoupling plate

The dimensions are only for the physical units, but when installing in an application it is necessary to add space for free air passage both above and below the units. The amount of space for free air passage is listed in *Table 1.5*.

### 1.3.5 Electrical Installation in General

All cabling must comply with national and local regulations on cable cross-sections and ambient temperature. Copper conductors required, (75 °C) recommended.

Enclosure		Torque [Nm]					
Frame	IP class	Line	Compressor connection	DC connection	Control terminals	Ground	Relay
H3	IP20	1.4	0.8	0.8	0.5	0.8	0.5
H4	IP20	1.2	1.2	1.2	0.5	0.8	0.5
H5	IP20	1.2	1.2	1.2	0.5	0.8	0.5

Table 1.7 Enclosure H3-H5

### 1.3.6 Connecting to Mains and Compressor


The frequency converter is designed to operate Danfoss VZH Compressors. For maximum cross-section on wires see chapter 1.7 General Specifications.

- Use a shielded/armored compressor cable to comply with EMC emission specifications, and connect this cable to both the decoupling plate and the compressor metal.
  - Keep compressor cable as short as possible to reduce the noise level and leakage currents.
  - For further details on mounting of the decoupling plate, see *VLT® Compressor Drive CDS 803 Decoupling Plate Installation Instructions*.
  - Also see *EMC-Correct Installation in the VLT® Compressor Drive CDS 803 Design Guide*.
1. Mount the ground wires to ground terminal.
  2. Connect compressor to terminals U, V and W, see Table 1.8.

U	T1
V	T2
W	T3

Table 1.8 Connection of Compressor to Terminals

3. Mount mains supply to terminals L1, L2 and L3 and tighten.




13BB634.10

1	Line
2	Ground
3	Compressor
4	Relays


Illustration 1.2 H3-H5 Frame

IP20 200-240 V 4-6.5 tons


IP20 380-480 V 4-6.5 tons




**Illustration 1.3** Mount the 2 screws in the mounting plate, slide it into place and tighten fully.



**Illustration 1.5** When mounting cables, first mount and tighten ground cable.



**Illustration 1.4** H3-H5 Frame



**Illustration 1.6** Mount mains plug and tighten wires.




Illustration 1.7 Tighten support bracket on mains wires.

### 1.3.7 Fuses

#### Branch circuit protection

To protect the installation against electrical and fire hazard, all branch circuits in an installation, switch gear, machines etc., must be short-circuit and overcurrent protected according to national and local regulations.

#### Short circuit protection

Danfoss recommends using the fuses listed in *Table 1.9* to protect service personnel or equipment in case of an internal failure in the unit or short-circuit on DC-link. The frequency converter provides full short circuit protection in case of a short-circuit on the compressor.

#### Overcurrent protection

Provide overload protection to avoid overheating of the cables in the installation. Overcurrent protection must always be carried out according to local and national regulations. Circuit breakers and fuses must be designed for protection in a circuit capable of supplying a maximum of 100,000 A<sub>rms</sub> (symmetrical), 480 V maximum.

#### UL/Non UL compliance

Use the fuses listed in *Table 1.9* to ensure compliance with UL or IEC 61800-5-1.

#### **NOTICE**

In the event of malfunction, failure to follow the protection recommendation may result in damage to the frequency converter.

	Fuse				
	UL				Non UL
	Bussmann	Bussmann	Bussmann	Bussmann	Max fuse
CDS 803	Type RK5	Type RK1	Type J	Type T	Type G
3x200-240 V IP20					
4 TR/VZH028	FRS-R-50	KTN-R50	JKS-50	JJN-50	50
5 TR/VZH035	FRS-R-50	KTN-R50	JKS-50	JJN-50	50
6.5 TR/VZH044	FRS-R-80	KTN-R80	JKS-80	JJN-80	65
3x380-480 V IP20					
4 TR/VZH028	FRS-R-25	KTS-R25	JKS-25	JJS-25	25
5 TR/VZH035	FRS-R-25	KTS-R25	JKS-25	JJS-25	25
6.5 TR/VZH044	FRS-R-50	KTS-R50	JKS-50	JJS-50	50

Table 1.9 Fuses

### 1.3.8 EMC-Correct Electrical Installation

General points to be observed to ensure EMC-correct electrical installation.

- Use only screened/armoured motor cables and screened/armoured control cables.
- Connect the screen to ground at both ends.
- Avoid installation with twisted screen ends (pigtails), since this ruins the screening effect at high frequencies. Use the cable clamps provided instead.
- Ensure the same potential between frequency converter and ground potential of PLC.
- Use starwashers and galvanically conductive installation plates.





Illustration 1.8 EMC-correct Electrical Installation

### 1.3.9 Control Terminals



**Illustration 1.9 Location of Control Terminals**

1. Place a screwdriver behind the terminal cover to activate the snap.
2. Tilt the screwdriver outwards to open the cover.

### Control terminals

To make the compressor run:

1. Apply start signal on terminal 18
2. Connect terminals 12, 27 and terminal 53, 54 or 55

BUS TER.  
OFF  ON

61 68 69  
COMM.GND  
P N

18	19	27	29	42	45	50	53	54
DIGI IN	DIGI IN	DIGI IN	DIGI IN					

10V OUT  
0/4-20mA A OUT / DIG OUT

10V/20mA IN	10V/20mA IN	0/4-20mA A OUT / DIG OUT

12 20 55  
+24V  
GND

**Illustration 1.10 Control Terminals**

Set the functions of digital input 18, 19 and 27 in *5-00 Digital Input Mode* (PNP is default value). Set the function of digital input 29 in *5-03 Digital Input 29 Mode* (PNP is default value).

## 1.3.10 Electrical Overview




Illustration 1.11 Basic Wiring Schematic Drawing

## 1.4 Programming

### 1.4.1 Local Control Panel (LCP)

#### **NOTICE**

LCP is NOT supported in SW 1.0X!

The LCP is divided into 4 functional sections.

- A. Display
- B. Menu key
- C. Navigation keys and indicator lights (LEDs)
- D. Operation keys and indicator lights (LEDs)




Illustration 1.12 Local Control Panel (LCP)

#### A. Display

The LCD-display is back-lit with 2 alphanumeric lines. All data is displayed on the LCP.

Information can be read from the display.

1	Parameter number and name.
2	Parameter value.
3	Set-up number shows the active set-up and the edit set-up. If the same set-up acts as both active and edit set-up, only that set-up number is shown (factory setting). When active and edit set-ups differ, both numbers are shown in the display (set-up 12). The number flashing, indicates the edit set-up.
4	Compressor direction is shown to the bottom left of the display – indicated by a small arrow pointing either clockwise or counterclockwise.
5	The triangle indicates if the LCP is in Status, Quick Menu or Main Menu.

Table 1.10 Legend to Illustration 1.12

#### B. Menu key

Press [Menu] to select between Status, Quick Menu or Main Menu.

#### C. Navigation keys and indicator lights (LEDs)

6	Com LED: Flashes when bus communication is communicating.
7	Green LED/On: Control section is working.
8	Yellow LED/Warn.: Indicates a warning.
9	Flashing Red LED/Alarm: Indicates an alarm.
10	[Back]: For moving to the previous step or layer in the navigation structure
11	[▲] [▼] [►]: For maneuvering between parameter groups, parameters and within parameters. Can also be used for setting local reference.
12	[OK]: For selecting a parameter and for accepting changes to parameter settings

Table 1.11 Legend to Illustration 1.12


#### D. Operation keys and indicator lights (LEDs)

13	[Hand On]: Starts the compressor and enables control of the frequency converter via the LCP.  <b>NOTICE</b> Terminal 27 Digital Input (5-12 Terminal 27 Digital Input) has stop inverse as default setting. This means that [Hand On] does not start the compressor if there is no 24 V to terminal 27. Connect terminal 12 to terminal 27.
14	[Off/Reset]: Stops the compressor (Off). If in alarm mode, the alarm is reset.
15	[Auto On]: Frequency converter is controlled either via control terminals or serial communication.

Table 1.12 Legend to Illustration 1.12


## 1.4.2 The Start-up Wizard

The built-in wizard menu guides the installer through the set-up of the frequency converter in a clear and structured manner to set-up an open loop application. An open loop application is here an application with a start signal, analog reference (voltage or current) and optionally also relay signals (but no feed back signal from the process applied).




**Illustration 1.13 Open Loop Application**

The wizard is initially be shown after power-up until any parameter has been changed. The wizard can always be accessed again through the Quick Menu. Press [OK] to start the wizard. Press [Back] to return to the status screen.



**Illustration 1.14 Start-up/Quit Wizard**


At power up the user is asked to choose the preferred language.




Power Up Screen



The next screen will be the Wizard screen.




Wizard Screen



Status Screen

The Wizard can always be reentered via the Quick Menu!

... the CDS 803 Wizard starts



**The Start-up Wizard for open loop applications**

Parameter	Option	Default	Function
0-01 Language	[0] English [1] Deutsch [2] Francais [3] Dansk [4] Spanish [5] Italiano [28] Bras.port	[0] English	Select the language for the display.
0-06 GridType	[0] 200-240 V/50 Hz/IT-grid [1] 200-240 V/50 Hz/Delta [2] 200-240 V/50 Hz [10] 380-440 V/50 Hz/IT-grid [11] 380-440 V/50 Hz/Delta [12] 380-440 V/50 Hz [20] 440-480 V/50 Hz/IT-grid [21] 440-480 V/50 Hz/Delta [22] 440-480 V/50 Hz [30] 525-600 V/50 Hz/IT-grid [31] 525-600 V/50 Hz/Delta [32] 525-600 V/50 Hz [100] 200-240 V/60 Hz/IT-grid [101] 200-240 V/60 Hz/Delta [102] 200-240 V/60 Hz [110] 380-440 V/60 Hz/IT-grid [111] 380-440 V/60 Hz/Delta [112] 380-440 V/60 Hz [120] 440-480 V/60 Hz/IT-grid [121] 440-480 V/60 Hz/Delta [122] 440-480 V/60 Hz [130] 525-600 V/60 Hz/IT-grid [131] 525-600 V/60 Hz/Delta [132] 525-600 V/60 Hz	Size related	Select operating mode for restart upon reconnection of the frequency converter to mains voltage after power down.
0-60 Main Menu Password	0-999	0	Define the password for access to the LCP.
1-13 Compressor Selection	[24] VZH028-R410A [25] VZH035-R410A [26] VZH044-R410A	Size related	Select the used compressor.
3-03 Maximum Reference	0-200 Hz	200 Hz	The maximum reference is the lowest obtainable by summing all references.
3-15 Reference 1 Source	[0] No function [1] Analog in 53 [2] Analog in 54 [7] Pulse input 29 [11] Local bus reference	[1] Analog in 53	Select the input to be used for the reference signal.
3-41 Ramp 1 Ramp Up Time	0.05-3600.0 s	30.00 s	Ramp-up time from 0 to 1-25 Motor Nominal Speed.
3-42 Ramp 1 Ramp Down Time	0.05-3600.0 s	30.00 s	Ramp down time from rated motor speed to 0.

Parameter	Option	Default	Function
5-12 Terminal 27 Digital Input	[0] No operation [1] Reset [2] Coast inverse [3] Coast and reset inverse [4] Quick stop inverse [5] DC-brake inverse [6] Stop inverse [7] External Interlock [8] Start [9] Latched start [10] Reversing [11] Start reversing [14] Jog [16] Preset ref bit 0 [17] Preset ref bit 1 [18] Preset ref bit 2 [19] Freeze reference [20] Speed up [22] Speed down [23] Set-up select bit 0 [34] Ramp bit 0 [52] Run permissive [53] Hand start [54] Auto start [60] Counter A (up) [61] Counter A (down) [62] Reset Counter A [63] Counter B (up) [64] Counter B (down) [65] Reset Counter B	[6] Stop inverse	Select the input function for terminal 27.
5-40 Function Relay [0] Function relay	See 5-40 Function Relay	Alarm	Select the function to control output relay 1.
5-40 Function Relay [1] Function relay	See 5-40 Function Relay	Drive running	Select the function to control output relay 2.
6-10 Terminal 53 Low Voltage	0-10 V	0.07 V	Enter the voltage that corresponds to the low reference value.
6-11 Terminal 53 High Voltage	0-10 V	10 V	Enter the voltage that corresponds to the high reference value.
8-01 Control Site	[0] Digital and ctrl.word [1] Digital only [2] Controlword only	[0] Digital and ctrl. word	Select if digital, bus, or a combination of both should control the frequency converter.
8-30 Protocol	[0] FC [2] Modbus RTU	[0] FC	Select the protocol for the integrated RS-485 port.
8-32 Baud Rate	[0] 2400 Baud [1] 4800 Baud *[2] 9600 Baud [3] 19200 Baud [4] 38400 Baud [5] 57600 Baud [6] 76800 Baud [7] 115200 Baud	9600	Select the baud rate for the RS-485 port.

Table 1.13 Open Loop Applications Set-up

**The Start-up Wizard for compressor functions**

1	28-00 Short Cycle Protection <input checked="" type="checkbox"/> Enabled
2	28-01 Interval between Starts 300 s
3	28-02 Minimum Run Time 60 s
4	28-10 Oil Return Management <input checked="" type="checkbox"/> On
5	28-11 Low Speed Running Time 20 min
6	28-13 Boost Duration 60 s

130BD874.11

**Illustration 1.16 Compressor Function Wizard****Compressor function wizard**

Parameter	Option	Default	Function
28-00 Short Cycle Protection	[0] Disabled [1] Enabled	[1] Enabled	Select if short cycle protection is to be used.
28-01 Interval between Starts	0-3600 s	300 s	Enter the minimum allowed time between starts.
28-02 Minimum Run Time	10-3600 s	60 s	Enter the minimum allowed time to run before stop.
28-10 Oil Return Management	[0] Off [1] On	[1] On	Select if Oil Return Management is to be used.
28-11 Low Speed Running Time	1-1400 min	20 min	Enter the low speed running time.
28-13 Boost Duration	10-3600 s	60 s	Enter the boost duration for the oil return.

**Table 1.14 Compressor Function**

**The Start-up Wizard for compressor closed loop applications**

1	0-01 Language [0] English
2	0-06 Grid Type [Size related]
3	0-60 Main Menu Password [0]
4	1-00 Configuration Mode [0] Open loop
5	1-13 Compressor Selection [Size related]
6	3-02 Minimum Reference [0] Hz
7	3-03 Maximum Reference [200] Hz
8	3-10 Preset Reference [0%]
9	3-15 Reference 1 Source [1] Analog in 53
10	3-41 Ramp 1 Ramp Up Time [30.00] s
11	3-42 Ramp 1 Ramp Down Time [30.00] s
12	5-12 Terminal 27 Digital Input [0] Stop inverse
13	5-40 Function Relay 1 Alarm
14	5-40 Function Relay 2 Drive running
15	6-10/12 Terminal 53 Low Voltage [0003] s
16	6-11 Terminal 53 High Voltage [10] V
17	6-14 Terminal 53 Low Ref./Feedb. [30]
18	6-15 Terminal 53 High Ref./Feedb. [200]
19	6-22 Terminal 54 Low Voltage [0.07] V
20	6-23 Terminal 54 High Voltage [10.00] V
21	6-24 Terminal 54 Low Ref./Feedb. [0]
22	6-25 Terminal 54 High Ref./Feedb. [50.000]
23	20-00 Feedback 1 Source [0] No function
24	20-81 Normal/Inverse Control [0] Normal
25	8-01 Control Site [0] Digital and ctrl.word
26	8-30 Protocol [0] FC
27	8-32 Baud Rate [9600]

130BD875.11

**Illustration 1.17 Closed Loop Wizard**

## Closed loop wizard

Parameter	Option	Default	Function
0-01 Language	[0] English [1] Deutsch [2] Francais [3] Dansk [4] Spanish [5] Italiano [28] Bras.port	0	Select the language for the display.
0-06 GridType	[0] 200-240 V/50 Hz/IT-grid [1] 200-240 V/50 Hz/Delta [2] 200-240 V/50 Hz [10] 380-440 V/50 Hz/IT-grid [11] 380-440 V/50 Hz/Delta [12] 380-440 V/50 Hz [20] 440-480 V/50 Hz/IT-grid [21] 440-480 V/50 Hz/Delta [22] 440-480 V/50 Hz [30] 525-600 V/50 Hz/IT-grid [31] 525-600 V/50 Hz/Delta [32] 525-600 V/50 Hz [100] 200-240 V/60 Hz/IT-grid [101] 200-240 V/60 Hz/Delta [102] 200-240 V/60 Hz [110] 380-440 V/60 Hz/IT-grid [111] 380-440 V/60 Hz/Delta [112] 380-440 V/60 Hz [120] 440-480 V/60 Hz/IT-grid [121] 440-480 V/60 Hz/Delta [122] 440-480 V/60 Hz [130] 525-600 V/60 Hz/IT-grid [131] 525-600 V/60 Hz/Delta [132] 525-600 V/60 Hz	Size related	Select the operating mode for restart upon reconnection of the frequency converter to mains voltage after power down.
0-60 Main Menu Password	0-999	0	Define the password for access to the LCP.
1-00 Configuration Mode	[0] Open loop [3] Closed loop	[0] Open loop	Select closed loop.
1-13 Compressor Selection	[24] VZH028 [25] VZH035 [26] VZH044	Size related	Select the used compressor.
3-02 Minimum Reference	-4999.0 - 200 Hz	0 Hz	The minimum reference is the lowest value obtainable by summing all references.
3-03 Maximum Reference	0 - 200 Hz	200 Hz	The maximum reference is the highest obtainable by summing all references
3-10 Preset Reference	-100 - 100 %	0 %	Setup a fix set point n preset reference [0].
3-15 Reference 1 Source	[0] No function [1] Analog in 53 [2] Analog in 54 [7] Pulse input 29 [11] Local bus reference	[1] Analog in 53	Select the input to be used for the reference signal.
3-41 Ramp 1 Ramp Up Time	0.05-3600.0 s	30.00 s	Ramp up time from 0 to 1-25 Motor Nominal Speed.
3-42 Ramp 1 Ramp Down Time	0.05-3600.0 s	30.00 s	Ramp-down time from rated motor speed to 0.

Parameter	Option	Default	Function
5-12 Terminal 27 Digital Input	[0] No operation [1] Reset [2] Coast inverse [3] Coast and reset inverse [4] Quick stop inverse [5] DC-brake inverse [6] Stop inverse [7] External Interlock [8] Start [9] Latched start [10] Reversing [11] Start reversing [14] Jog [16] Preset ref bit 0 [17] Preset ref bit 1 [18] Preset ref bit 2 [19] Freeze reference [20] Speed up [22] Speed down [23] Set-up select bit 0 [34] Ramp bit 0 [52] Run permissive [53] Hand start [54] Auto start [60] Counter A (up) [61] Counter A (down) [62] Reset Counter A [63] Counter B (up) [64] Counter B (down) [65] Reset Counter B	[6] Stop inverse	Select the input function for terminal 27.
5-40 Function Relay [0] Function relay	See 5-40 Function Relay	Alarm	Select the function to control output relay 1.
5-40 Function Relay [1] Function relay	See 5-40 Function Relay	Drive running	Select the function to control output relay 2.
6-10 Terminal 53 Low Voltage	0-10 V	0.07 V	Enter the voltage that corresponds to the low reference value.
6-11 Terminal 53 High Voltage	0-10 V	10 V	Enter the voltage that corresponds to the high reference value.
6-14 Terminal 53 Low Ref./Feedb. Value	-4999 - 4999	30	Enter the reference value that corresponds to the voltage set in 6-10 Terminal 53 Low Voltage.
6-15 Terminal 53 High Ref./Feedb. Value	-4999 - 4999	200	Enter the reference value that corresponds to the voltage set in 6-11 Terminal 53 High Voltage.
6-22 Terminal 54 Low Current	0.00-20.00 mA	4.00 mA	Enter the current that corresponds to the low reference value.
6-23 Terminal 54 High Current	0-10 V	10 V	Enter the current that corresponds to the high reference value.
6-24 Terminal 54 Low Ref./Feedb. Value	-0.00-20.00 mA	20.00 mA	Enter the reference value that corresponds to the current set in 6-20 Terminal 54 Low Voltage.
6-25 Terminal 54 High Ref./Feedb. Value	-4999 - 4999	Size related	Enter the reference value that corresponds to the current set in 6-21 Terminal 54 High Voltage.
8-01 Control Site	[0] Digital and ctrl.word [1] Digital only [2] Controlword only	0	Select if digital, bus, or a combination of both should control the frequency converter.

Parameter	Option	Default	Function
8-30 Protocol	[0] FC [2] Modbus RTU	0	Select the protocol for the integrated RS-485 port.
8-32 Baud Rate	[0] 2400 Baud [1] 4800 Baud [2] 9600 Baud [3] 19200 Baud [4] 38400 Baud [5] 57600 Baud [6] 76800 Baud [7] 115200 Baud	[2] 9600 Baud	Select the baud rate for the RS-485 port.
20-00 Feedback 1 Source	[0] No function [1] Analog Input 53 [2] Analog Input 54 [3] Pulse input 29 [100] Bus Feedback 1 [101] Bus Feedback 2	[0] No function	Select which input will be used as the source of the feedback signal.
20-81 PI Normal/ Inverse Control	[0] Normal [1] Inverse	[0] Normal	Select how the feedback should be calculated

Table 1.15 Closed Loop Applications Set-up

**Changes made**

*Changes Made* lists all parameters changed from default settings.

- The list shows only parameters which have been changed in the current edit-setup.
- Parameters which have been reset to default values are not listed.
- The message *Empty* indicates that no parameters have been changed.

**To change parameter settings**

1. Press [Menu] key to enter the Quick Menu until indicator in display is placed above Quick Menu.
2. Press [ $\blacktriangle$ ] [ $\triangledown$ ] to select wizard, closed loop set-up, compressor set-up or changes made, then press [OK].
3. Press [ $\blacktriangle$ ] [ $\triangledown$ ] to browse through the parameters in the Quick Menu.
4. Press [OK] to select a parameter.
5. Press [ $\blacktriangle$ ] [ $\triangledown$ ] to change the value of a parameter setting.
6. Press [OK] to accept the change.
7. Press either [Back] twice to enter Status, or press [Menu] once to enter Main Menu.

**The Main Menu accesses all parameters**

1. Press [Menu] until indicator in display is placed above Main Menu.
2. Press [ $\blacktriangle$ ] [ $\triangledown$ ] to browse through the parameter groups.
3. Press [Ok] to select a parameter group.
4. Press [ $\blacktriangle$ ] [ $\triangledown$ ] to browse through the parameters in the specific group.
5. Press [Ok] to select the parameter.
6. Press [ $\blacktriangle$ ] [ $\triangledown$ ] to set/change the parameter value.

**Quick Guide****Quick Guide**

<b>1.4.3 Main Menu Structure</b>	4-19 Max Output Frequency	6-29 Terminal 54 mode	13-11 Comparator Operator	15-59 File name
	4-4* <b>Adj. Warnings 2</b>	6-7* <b>Analog/Digital Output 45</b>	13-12 Comparator Value	15-9* <b>Parameter Info</b>
	4-40 Warning Freq. Low	6-70 Terminal 45 Mode	13-2* <b>Timers</b>	15-92 Defined Parameters
	4-41 Warning Freq. High	6-71 Terminal 45 Analog Output	13-20 SL Controller Timer	15-97 Drive Identification Type
<b>0-** Operation / Display</b>	<b>4-5* Adj. Warnings</b>	6-72 Terminal 45 Digital Output	<b>13-4* Logic Rules</b>	<b>16-** Data Readouts</b>
<b>0-0* Basic Settings</b>	4-50 Warning Current Low	6-73 Terminal 45 Output Min Scale	13-40 Logic Rule Boolean 1	<b>16-0* General Status</b>
0-01 Language	4-51 Warning Current High	6-74 Terminal 45 Output Max Scale	13-41 Logic Rule Operator 1	16-00 Control Word
0-03 Regional Settings	4-54 Warning Reference Low	6-75 Terminal 45 Output Bus Control	13-42 Logic Rule Boolean 2	16-01 Reference [Unit]
0-04 Operating State at Power-up	4-55 Warning Reference High	6-76 Terminal 45 Output	13-43 Logic Rule Operator 2	16-02 Reference [%]
0-06 GridType	4-56 Warning Feedback Low	6-77 Terminal 42 Mode	13-44 Logic Rule Boolean 3	16-03 Status Word
0-07 Auto DC Braking	4-57 Warning Feedback High	6-91 Terminal 42 Analog Output	<b>13-5* States</b>	16-05 Main Actual Value [%]
<b>0-1* Set-up Operations</b>	4-58 Missing Motor Phase Function	6-92 Terminal 42 Digital Output	13-51 SL Controller Event	16-09 Custom Readout
0-10 Active Set-up	<b>4-6* Speed Bypass</b>	6-93 Terminal 42 Output Min Scale	13-52 SL Controller Action	<b>16-1* Motor Status</b>
0-11 Programming Set-up	4-61 Bypass Speed From [Hz]	6-94 Terminal 42 Output Max Scale		16-10 Power [kW]
0-12 Link Setups	4-63 Bypass Speed To [Hz]	6-95 Terminal 42 Output Bus Control	<b>14-0* Inverter Switching</b>	16-11 Power [hp]
<b>0-3* LCP Custom Readout</b>	4-64 Semi-Auto Bypass Set-up	<b>8-** Comm. and Options</b>	14-01 Switching Frequency	16-12 Motor Voltage
0-30 Custom Readout Unit	<b>5-** Digital In/Out</b>	<b>8-0* General Settings</b>	14-03 Overmodulation	16-13 Frequency
0-31 Custom Readout Min Value	<b>5-0* Digital I/O mode</b>	8-01 Control Site	14-12 Function at Mains Imbalance	16-14 Motor current
0-32 Custom Readout Max Value	5-00 Digital Input Mode	8-02 Control Source	<b>14-2* Reset Functions</b>	16-15 Frequency [%]
<b>0-4* LCP Keypad</b>	<b>5-1* Digital Inputs</b>	8-03 Control Timeout Time	14-01 Remote Mode	16-16 Torque [Nm]
0-40 [Hand on] Key on LCP	5-10 Terminal 18 Digital Input	8-04 Control Timeout Function	14-21 Automatic Restart Time	16-18 Motor Thermal
0-42 [Auto on] Key on LCP	5-11 Terminal 19 Digital Input	<b>8-3* FC Port Settings</b>	14-22 Operation Mode	16-22 Torque [%]
0-44 [Off/Reset] Key on LCP	5-12 Terminal 27 Digital Input	8-30 Protocol	14-23 Typicode Setting	<b>16-3* Drive Status</b>
<b>0-5* Copy/Save</b>	5-13 Terminal 29 Digital Input	8-31 Address	14-29 Service Code	16-30 DC Link Voltage
0-50 LCP Copy	<b>5-3* Digital Outputs</b>	8-32 Baud Rate	14-30 On Delay, Digital Output	16-34 Heatsink Temp.
0-51 Set-up Copy	5-34 On Delay, Digital Output	8-33 Priority / Stop Bits	14-31 Off Delay, Digital Output	16-35 Inverter Thermal
<b>0-6* Password</b>	5-35 Off Delay, Digital Output	8-35 Minimum Response Delay	14-40 RFI Filter	16-36 Inv. Nom. Current
0-60 Main Menu Password	<b>5-4* Relays</b>	8-36 Maximum Response Delay	<b>14-6* Auto Degrade</b>	16-37 Inv. Max. Current
<b>1-** Load and Motor</b>	5-41 Function Relay	8-37 Maximum Inter-chan delay	14-65 Auto Degrade Dead Time Compensation	16-38 SL Controller State
1-1* Motor Selection	5-41 On Delay, Relay	<b>8-4* FC MC protocol set</b>	<b>14-9* Fault Settings</b>	<b>16-5* Ref. &amp; Feedb.</b>
1-10 Motor Construction	5-42 Off Delay, Relay	8-42 PCD Write Configuration	14-90 Fault Level	16-50 External Reference
1-13 Compressor Selection	<b>5-5* Pulse Input</b>	8-43 PCD Read Configuration	<b>15-** Drive Information</b>	16-52 Feedback [Unit]
<b>1-9* Motor Temperature</b>	Term. 29 Low Frequency	<b>8-5* Digital/Bus</b>	15-0* Operating Data	16-54 Feedback 1 [Unit]
1-90 Motor Thermal Protection	5-51 Term. 29 High Frequency	8-50 Coasting Select	15-01 Running Hours	16-55 Feedback 2 [Unit]
1-93 Thermistor Source	5-51 Term. 29 High Ref./Feedb. Value	8-51 Quick Stop Select	15-02 Power Up's	<b>16-** Inputs &amp; Outputs</b>
<b>3-** Reference Ramps</b>	5-52 Term. 29 Low Ref./Feedb. Value	8-52 DC Brake Select	15-03 Power Up's	16-56 Digital Input
3-0* Reference Limits	5-53 Term. 29 High Ref./Feedb. Value	8-53 Start Select	15-04 Over Temp's	16-60 Digital Output
3-02 Minimum Reference	<b>5-9* Bus Controlled</b>	8-54 Reversing Select	15-05 Over Volts	16-61 Terminal 53 Setting
3-03 Maximum Reference	5-90 Digital & Relay Bus Control	8-55 Set-up Select	15-06 Reset kWh Counter	16-62 Analog Input AI53
<b>3-1* References</b>	<b>6-** Analog In/Out</b>	8-56 Preset Reference Select	15-07 Reset Running Hours Counter	16-63 Terminal 54 Setting
3-10 Preset Reference	6-00 Live Zero Timeout Time	<b>8-8* FC Port Diagnostics</b>	15-08 Number of Starts	16-64 Analog Input AI54
3-11 Jog Speed [Hz]	6-01 Live Zero Timeout Function	8-80 Bus Message Count	15-09 Number of Auto Resets	16-65 Analog Output AO42 [mA]
3-14 Preset Relative Reference	<b>6-1* Analog Input 53</b>	8-81 Bus Error Count	<b>15-3* Alarm Log</b>	16-66 Digital Output
3-15 Reference 1 Source	6-10 Terminal 53 Low Voltage	8-82 Slave Messages Rcvd	15-40 Pulse Input #29 [Hz]	16-67 Pulse Input
3-16 Reference 2 Source	6-11 Terminal 53 High Voltage	8-83 Slave Error Count	15-41 Power Section	16-68 Fieldbus & FC Port
3-17 Reference 3 Source	6-12 Terminal 53 Low Current	8-84 Slave Messages Sent	15-42 Voltage	16-69 FC Port REF 1
<b>3-4* Ramp 1</b>	6-13 Terminal 53 High Current	8-85 Slave Timeout Errors	15-43 Software Version	16-70 Diagnosis Readouts
3-41 Ramp 1 Ramp Up Time	6-14 Terminal 53 Low Ref./Feedb. Value	8-88 Reset FC port Diagnostics	15-44 Ordered Type-Code	16-90 Alarm Word
3-42 Ramp 1 Ramp Down Time	6-15 Terminal 53 High Ref./Feedb. Value	<b>8-9* Bus Jog / Feedback</b>	15-45 Actual Typecode String	16-91 Alarm Word 2
<b>3-5* Ramp 2</b>	6-16 Terminal 53 Filter Time Constant	8-94 Bus Feedback 1	15-46 Drive Ordering No	16-92 Warning Word
3-51 Ramp 2 Ramp Up Time	6-19 Terminal 53 mode	8-95 Bus Feedback 2	15-48 LCID No	16-93 Warning Word 2
3-52 Ramp 2 Ramp Down Time	<b>6-2* Analog Input 54</b>	<b>13-** Smart Logic</b>	15-49 SW ID Control Card	16-94 Ext. Status Word
<b>3-8* Other Ramps</b>	6-20 Terminal 54 Low Voltage	<b>13-0* SLC Settings</b>	15-50 SW ID Power Card	16-95 Ext. Status Word 2
3-81 Quick Stop Ramp Time	6-21 Terminal 54 High Voltage	13-00 SL Controller Mode	15-51 Drive Serial Number	16-96 Power Card Serial Number
<b>4-** Limits / Warnings</b>	6-22 Terminal 54 Low Current	13-01 Start Event	15-52 Power Card	16-97 Power Card Serial Number
4-14 Motor Speed High Limit [Hz]	6-23 Terminal 54 High Current	13-03 Reset SLC	15-53 Power Operand	16-98 Power Card Serial Number
4-18 Current Limit	6-24 Terminal 54 Low Ref./Feedb. Value	13-10 Comparator Operand		
	6-25 Terminal 54 High Ref./Feedb. Value			
	6-26 Terminal 54 Filter Time Constant			

<b>20-** Drive Closed Loop</b>	
20-0*	Feedback
20-00	Feedback 1 Source
20-01	Feedback 1 Conversion
20-03	Feedback 2 Source
20-04	Feedback 2 Conversion
20-2*	<b>Feedback/Setpoint</b>
20-20	Feedback Function
20-20	Feedback Function
20-8*	<b>PI Basic Settings</b>
20-81	PI Normal/ Inverse Control
20-83	PI Start Speed [Hz]
20-84	On Reference Bandwidth
20-9*	<b>PI Controller</b>
20-91	PI Anti Windup
20-93	PI Proportional Gain
20-94	PI Integral Time
20-97	PI Feed Forward Factor
<b>28-** Compressor Functions</b>	
<b>28-0* Short Cycle Protection</b>	
28-00	Short Cycle Protection
28-01	Interval between Starts
28-02	Minimum Run Time
<b>28-1* Oil Return Management</b>	
28-10	Oil Return Management
28-11	Low Speed Running Time
28-13	Boost Duration
28-15	ORM Min Speed Limit [Hz]
28-17	ORM Boost Speed [Hz]
<b>28-4* Anti-reverse Protection at Stop</b>	
28-40	Reverse Protection Control
<b>28-6* Compressor Readouts</b>	
28-60	RPS

## 1.5 Acoustic Noise or Vibration

If the compressor is making noise or vibrations at certain frequencies, try the following:

- Speed Bypass, parameter group 4-6\* *Speed Bypass*

## 1.6 Warnings and Alarms

Fault number	Alarm/Warning Bit Number	Fault text	Warning	Alarm	Trip locked	Cause of problem
2	16	Live zero error	X	X		Signal on terminal 53 or 54 is less than 50% of the value set in 6-10 <i>Terminal 53 Low Voltage</i> , 6-12 <i>Terminal 53 Low Current</i> , 6-20 <i>Terminal 54 Low Voltage</i> or 6-22 <i>Terminal 54 Low Current</i> . See also parameter group 6-0* <i>Analog I/O Mode</i> .
4	14	Mains ph. loss	X	X	X	Missing phase on the supply side or too high voltage imbalance. Check the supply voltage. See 14-12 <i>Function at Mains Imbalance</i> .
7	11	DC over volt	X	X		Intermediate circuit voltage exceeds limit.
8	10	DC under volt	X	X		Intermediate circuit voltage drops below "voltage warning low" limit.
9	9	Inverter overload	X	X		More than 100% load for too long.
10	8	Motor ETR over	X	X		The motor is too hot due to more than 100% load for too long. See 1-90 <i>Motor Thermal Protection</i>
11	7	Motor th over	X	X		The thermistor or the thermistor connection is disconnected. See 1-90 <i>Motor Thermal Protection</i> .
13	5	Over Current	X	X	X	Inverter peak current limit is exceeded.
14	2	Earth Fault		X	X	Discharge from output phases to ground.
16	12	Short Circuit		X	X	Short-circuit in the compressor or on the compressor terminals.
17	4	Ctrl. word TO	X	X		No communication to the frequency converter. See parameter group 8-0* <i>General Settings</i> .
18		Start failed		X		The speed has not been able to exceed 1-78 <i>Compressor Start Min Speed [Hz]</i> during start within the allowed time.
30	19	U phase loss		X	X	Motor phase U is missing. Check the phase. See 4-58 <i>Missing Motor Phase Function</i> .
31	20	V phase loss		X	X	Motor phase V is missing. Check the phase. See 4-58 <i>Missing Motor Phase Function</i> .
32	21	W phase loss		X	X	Motor phase W is missing. Check the phase. See 4-58 <i>Missing Motor Phase Function</i> .
38	17	Internal fault		X	X	Contact the local Danfoss supplier.
44	28	Earth Fault		X	X	Discharge from output phases to ground, using the value of 15-31 <i>Alarm Log Value</i> if possible.
47	23	Control Voltage Fault	X	X	X	24 V DC may be overloaded.
48	25	VDD1 supply low		X	X	Control voltage low. Contact the local Danfoss supplier
49				X		The speed is below the specified limit in 1-87 <i>Compressor Min. Speed for Trip [Hz]</i> .
58		AMA internal	X	X		Contact the local Danfoss supplier.
59	25	Current limit	X			The current is higher than the value in 4-18 <i>Current Limit</i> .
60	44	External Interlock		X		External interlock has been activated. To resume normal operation, apply 24 V DC to the terminal programmed for external interlock and reset the frequency converter (via serial communication, digital I/O, or by pressing [Off/Reset]).

Quick Guide		Quick Guide				
Fault number	Alarm/Warning Bit Number	Fault text	Warning	Alarm	Trip locked	Cause of problem
69	1	Pwr. Card Temp	X	X	X	The temperature sensor on the power card is either too hot or too cold.
79		Illegal power section configuration	X	X		Internal fault. Contact the local Danfoss supplier.
80	29	Drive initialised		X		All parameter settings are initialised to default settings.
87	47	Auto DC Braking	X			The frequency converter is auto DC braking
126		Motor Rotating		X		High back-emf voltage. Stop the rotor of the PM motor.
250		New sparepart		X	X	The power or switch mode power supply has been exchanged. (Only on 400 V 30-90 kW units). Contact the local Danfoss supplier
251		New Typecode		X	X	The frequency converter has a new type code (Only on 400 V 30-90 kW units). Contact the local Danfoss supplier.

Table 1.16 Warnings and Alarms

## 1.7 General Specifications

### 1.7.1 Mains Supply 3x200-240 V AC

Frequency converter	4 TR/VZH028	5 TR/VZH035	6.5 TR/VZH044
Typical shaft output [kW]	6.0	7.5	10
IP20 enclosure protection	H4	H4	H5
Maximum cable size in terminals (mains, compressor) [mm <sup>2</sup> /AWG]	16/6	16/6	16/6
Output current			
Continuous (3x200-240 V) [A]	20.7	25.9	33.7
Intermittent (3x200-240 V) [A]	-	-	37.1
Maximum input current			
Continuous 3x200-240 V) [A]	23.0	28.3	37.0
Intermittent (3x200-240 V) [A]	-	-	41.5
Maximum mains fuses, see Table 1.9			
Estimated power loss [W], Best case/typical <sup>1)</sup>	182/ 204	229/ 268	369/ 386
Weight enclosure protection P20 [kg]	7.9	7.9	9.5
Efficiency [%], best case/ typical <sup>1)</sup>	97.3/ 97.0	98.5/ 97.1	97.2/ 97.1

Table 1.17 3x200-240 V AC

1) At rated load conditions

## 1.7.2 Mains Supply 3x380-480 V AC

Frequency converter	4 TR/VZH028	5 TR/VZH035	6.5 TR/VZH044
Typical shaft output [kW]	6.0	7.5	10
IP20 enclosure protection	H3	H3	H4
Maximum cable size in terminals (mains, compressor) [mm <sup>2</sup> /AWG]	4/10	4/10	16/6
<b>Output current</b>			
Continuous (3x380-440 V) [A]	11.6	14.3	16.4
Intermittent (3x380-440 V) [A]			18.0
Continuous (3x440-480 V) [A]	9.8	12.3	15.5
Intermittent (3x440-480 V) [A]			17.0
<b>Maximum input current</b>			
Continuous (3x380-440 V) [A]	12.7	15.5	18.0
Intermittent (3x380-440 V) [A]			19.8
Continuous (3x440-480 V) [A]	10.8	13.5	17.0
Intermittent (3x440-480 V) [A]			18.7
<b>Maximum mains fuses</b>			
Estimated power loss [W], best case/typical <sup>1)</sup>	104/131	159/198	248/274
Weight enclosure protection IP20 [kg]	4.3	4.5	7.9
Efficiency [%], best case/typical <sup>1)</sup>	98.4/98.0	98.2/97.8	98.1/97.9

Table 1.18 3x380-480 V AC

1) At rated load conditions

### 1.7.3 EMC Test Results

The following test results have been obtained using a system with a frequency converter, a screened control cable, a control box with potentiometer, as well as a compressor screened cable.

RFI Filter Type	Conduct emission. Maximum shielded cable length [m]						Radiated emission			
	Industrial environment			Housing, trades and light industries		Industrial environment		Housing, trades and light industries		
	EN 55011 Class A2	EN 55011 Class A1		EN 55011 Class B		EN 55011 Class A1		EN 55011 Class B		
	Without external filter	With external filter	Without external filter	With external filter	Without external filter	With external filter	Without external filter	With external filter	Without external filter	With external filter
<b>H4 RFI filter (Class A1)</b>										
CDS 803 IP20			25	50		20	Yes	Yes		No

**Table 1.19 Test Results**

### 1.7.4 General Specifications

#### Protection and features

- Electronic thermal compressor protection against overload.
- Temperature monitoring of the heat sink ensures that the frequency converter trips in case of overtemperature.
- The frequency converter is protected against short-circuits between compressor terminals U, V, W.
- When a compressor phase is missing, the frequency converter trips and issues an alarm.
- When a mains phase is missing, the frequency converter trips or issues a warning (depending on the load).
- Monitoring of the intermediate circuit voltage ensures that the frequency converter trips, when the intermediate circuit voltage is too low or too high.
- The frequency converter is protected against ground faults on compressor terminals U, V, W.

#### Mains supply (L1, L2, L3)

Supply voltage	200-240 V ±10%
Supply voltage	380-480 V ±10%
Supply frequency	50/60 Hz
Maximum imbalance temporary between mains phases	3.0% of rated supply voltage
True power factor ( $\lambda$ )	≥0.9 nominal at rated load
Displacement power factor ( $\cos\phi$ ) near unity	(>0.98)
Switching on the input supply L1, L2, L3 (power-ups)	Maximum 2 times/min.
Environment according to EN 60664-1	Overvoltage category III/pollution degree 2
The unit is suitable for use on a circuit capable of delivering not more than 100000 RMS symmetrical Amperes, 240/480 V maximum.	

#### Compressor output (U, V, W)

Output voltage	0-100% of supply voltage
Output frequency	0-200 Hz (VVC <sup>+</sup> ), 0-400 Hz (u/f)
Switching on output	Unlimited
Ramp times	0.05-3600 s

## Cable lengths and cross-sections

Maximum compressor cable length, screened/armoured (EMC correct installation)	See chapter 1.7.3 EMC Test Results
Maximum compressor cable length, unscreened/unarmoured	50 m
Maximum cross-section to compressor, mains <sup>1)</sup>	
Cross-section DC terminals for filter feedback on enclosure size H1-H3, I2, I3, I4	4 mm <sup>2</sup> /11 AWG
Cross-section DC terminals for filter feedback on enclosure size H4-H5	16 mm <sup>2</sup> /6 AWG
Maximum cross-section to control terminals, rigid wire	2.5 mm <sup>2</sup> /14 AWG
Maximum cross-section to control terminals, flexible cable	2.5 mm <sup>2</sup> /14 AWG
Minimum cross-section to control terminals	0.05 mm <sup>2</sup> /30 AWG

1) See chapter 1.7.2 Mains Supply 3x380-480 V AC for more information

## Digital inputs

Programmable digital inputs	4
Terminal number	18, 19, 27, 29
Logic	PNP or NPN
Voltage level	0-24 V DC
Voltage level, logic 0 PNP	<5 V DC
Voltage level, logic 1 PNP	>10 V DC
Voltage level, logic 0 NPN	>19 V DC
Voltage level, logic 1 NPN	<14 V DC
Maximum voltage on input	28 V DC
Input resistance, R <sub>i</sub>	Approx. 4 kΩ
Digital input 29 as thermistor input	Fault: >2.9 kΩ and no fault: <800 Ω
Digital input 29 as Pulse input	Maximum frequency 32 kHz push-pull-driven & 5 kHz (O.C.)

## Analog inputs

Number of analog inputs	2
Terminal number	53, 54
Terminal 53 mode	Parameter 6-19: 1=voltage, 0=current
Terminal 54 mode	Parameter 6-29: 1=voltage, 0=current
Voltage level	0-10 V
Input resistance, R <sub>i</sub>	approx. 10 kΩ
Maximum voltage	20 V
Current level	0/4 to 20 mA (scalable)
Input resistance, R <sub>i</sub>	<500 Ω
Maximum current	29 mA

## Analog output

Number of programmable analog outputs	2
Terminal number	42, 45 <sup>1)</sup>
Current range at analog output	0/4-20 mA
Maximum load to common at analog output	500 Ω
Maximum voltage at analog output	17 V
Accuracy on analog output	Maximum error: 0.4% of full scale
Resolution on analog output	10 bit

1) Terminal 42 and 45 can also be programmed as digital outputs.

## Digital output

Number of digital outputs	2
Terminal number	42, 45 <sup>1)</sup>
Voltage level at digital output	17 V
Maximum output current at digital output	20 mA
Maximum load at digital output	1 kΩ

1) Terminals 42 and 45 can also be programmed as analog output.

## Quick Guide

## Quick Guide

1

Control card, RS-485 serial communication

Terminal number	68 (P, TX+, RX+), 69 (N, TX-, RX-)
Terminal number	61 common for terminals 68 and 69

Control card, 24 V DC output

Terminal number	12
Maximum load	80 mA

Relay output

Programmable relay output	2
Relay 01 and 02	01-03 (NC), 01-02 (NO), 04-06 (NC), 04-05 (NO)
Maximum terminal load (AC-1) <sup>1)</sup> on 01-02/04-05 (NO) (Resistive load)	250 V AC, 3 A
Maximum terminal load (AC-15) <sup>1)</sup> on 01-02/04-05 (NO) (Inductive load @ cosφ 0.4)	250 V AC, 0.2 A
Maximum terminal load (DC-1) <sup>1)</sup> on 01-02/04-05 (NO) (Resistive load)	30 V DC, 2 A
Maximum terminal load (DC-13) <sup>1)</sup> on 01-02/04-05 (NO) (Inductive load)	24 V DC, 0.1 A
Maximum terminal load (AC-1) <sup>1)</sup> on 01-03/04-06 (NC) (Resistive load)	250 V AC, 3 A
Maximum terminal load (AC-15) <sup>1)</sup> on 01-03/04-06 (NC) (Inductive load @ cosφ 0.4)	250 V AC, 0.2 A
Maximum terminal load (AC-15) <sup>1)</sup> on 01-03/04-06 (NC) (Inductive load @ cosφ 0.4)	30 V DC, 2 A
Maximum terminal load (DC-1) <sup>1)</sup> on 01-03/04-06 (NC) (Resistive load)	Minimum terminal load on 01-03 (NC), 01-02 (NO) 24 V DC 10 mA, 24 V AC 20 mA
Environment according to EN 60664-1	Overvoltage category III/pollution degree 2

1) IEC 60947 parts 4 and 5.

Control card, 10 V DC output<sup>1)</sup>

Terminal number	50
Output voltage	10.5 V ±0.5 V
Maximum load	25 mA

1) All inputs, outputs, circuits, DC supplies and relay contacts are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Surroundings

Enclosure	IP20
Enclosure kit available	IP21, TYPE 1
Vibration test	1.0 g
Maximum relative humidity	5%-95% (IEC 60721-3-3; Class 3K3 (non-condensing) during operation
Aggressive environment (IEC 60721-3-3), coated (standard)	Class 3C3
Test method according to IEC 60068-2-43 H2S (10 days)	
Ambient temperature	50 °C

Derating for high ambient temperature, see chapter 1.8 Special Conditions.

Minimum ambient temperature during full-scale operation	0 °C
Minimum ambient temperature at reduced performance	-20 °C
Temperature during storage/transport	-30 to +65/70 °C
Maximum altitude above sea level without derating	1000 m
Maximum altitude above sea level with derating	3000 m
Derating for high altitude, see chapter 1.8 Special Conditions	
Safety standards	EN/IEC 61800-5-1, UL 508C
EMC standards, Emission	EN 61800-3, EN 61000-6-3/4, EN 55011, IEC 61800-3
EMC standards,	EN 61800-3, EN 61000-3-12, EN 61000-6-1/2, EN 61000-4-2, EN 61000-4-3, EN 61000-4-4, EN
Immunity	61000-4-5, EN 61000-4-6

## 1.8 Special Conditions

### 1.8.1 Derating for Ambient Temperature and Switching Frequency

The ambient temperature measured over 24 hours should be at least 5 °C lower than the maximum ambient temperature. If the frequency converter is operated at high ambient temperature, the continuous output current should be decreased. For derating curves, see *VLT® Compressor Drive CDS 803 Design Guide*.

### 1.8.2 Derating for Low Air Pressure

The cooling capability of air is decreased at low air pressure. For altitudes above 2000 m, contact Danfoss regarding PELV. Below 1000 m altitude no derating is necessary, but above 1000 m the ambient temperature or the maximum output current should be decreased. Decrease the output by 1% per 100 m altitude above 1000 m or reduce the maximum ambient temperature by 1°C per 200 m.

## 1.9 Options for VLT® Compressor Drive CDS 803

For options, see the *VLT® Compressor Drive CDS 803 Design Guide*.



[www.danfoss.com/drives](http://www.danfoss.com/drives)

.....  
Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequent changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.  
.....

Danfoss A/S  
Ulsnaes 1  
DK-6300 Graasten  
[www.danfoss.com/drives](http://www.danfoss.com/drives)

