



Design Guide

VLT[®] Compressor Drive CDS 803



Contents

| | |
|--|-----------|
| 1 Introduction | 5 |
| 1.1 Purpose of the Manual | 5 |
| 1.2 Document and Software Version | 5 |
| 1.3 Safety Symbols | 5 |
| 1.4 Abbreviations | 5 |
| 1.5 Additional Resources | 6 |
| 1.6 Definitions | 6 |
| 1.7 Power Factor | 8 |
| 2 Product Overview | 9 |
| 2.1 Safety | 9 |
| 2.2 CE Labeling | 10 |
| 2.3 Air Humidity | 11 |
| 2.4 Aggressive Environments | 11 |
| 2.5 Vibration and Shock | 11 |
| 2.6 Control Structures | 12 |
| 2.6.1 Control Structure Open Loop | 12 |
| 2.6.2 Local (Hand On) and Remote (Auto On) Control | 12 |
| 2.6.3 Control Structure Closed Loop | 13 |
| 2.6.4 Feedback Conversion | 13 |
| 2.6.5 Reference Handling | 14 |
| 2.6.6 Closed Loop Set-up Wizard | 15 |
| 2.6.7 Tuning the Drive Closed Loop Controller | 18 |
| 2.6.8 Manual PI Adjustment | 18 |
| 2.7 General Aspects of EMC | 19 |
| 2.7.2 Emission Requirements | 20 |
| 2.8 Galvanic Isolation (PELV) | 22 |
| 2.9 Earth Leakage Current | 23 |
| 2.10 Extreme Running Conditions | 23 |
| 3 Selection | 24 |
| 3.1 Options and Accessories | 24 |
| 3.1.1 Local Control Panel (LCP) | 24 |
| 3.1.2 Mounting of LCP in Panel Front | 24 |
| 3.1.3 IP21/TYPE 1 Enclosure Kit | 25 |
| 3.1.4 Decoupling Plate | 26 |
| 4 How to Order | 27 |
| 4.1 Configuration | 27 |
| 4.2 Ordering Numbers | 28 |

| | |
|--|----|
| 5 How to Install | 29 |
| 5.1 Mechanical Dimensions | 29 |
| 5.1.1 Side-by-Side Installation | 29 |
| 5.1.2 Frequency Converter Dimensions | 30 |
| 5.1.3 Shipping Dimensions | 32 |
| 5.2 Electrical Data | 33 |
| 5.2.3 Connecting to Mains and Compressor | 34 |
| 5.2.4 Fuses | 36 |
| 5.2.6 Control Terminals | 39 |
| 6 How to Programme | 40 |
| 6.1 Programming with MCT 10 Set-up Software | 40 |
| 6.2 Local Control Panel (LCP) | 40 |
| 6.3 Menus | 41 |
| 6.3.1 Status Menu | 41 |
| 6.3.2 Quick Menu | 41 |
| 6.3.3 The Start-up Wizard | 41 |
| 6.3.4 Main Menu | 49 |
| 6.4 Quick Transfer of Parameter Settings between Multiple Frequency Converters | 50 |
| 6.5 Read-out and Programming of Indexed Parameters | 50 |
| 6.6 Initialise the Frequency Converter to Default Settings in two Ways | 50 |
| 7 RS-485 Installation and Set-up | 51 |
| 7.1 RS-485 | 51 |
| 7.1.1 Overview | 51 |
| 7.1.2 Network Connection | 52 |
| 7.1.3 Frequency Converter Hardware Set-up | 52 |
| 7.1.4 Parameter Settings for Modbus Communication | 52 |
| 7.1.5 EMC Precautions | 53 |
| 7.2 FC Protocol Overview | 53 |
| 7.2.1 FC Protocol Overview | 53 |
| 7.3 Network Configuration | 54 |
| 7.4 FC Protocol Message Framing Structure | 54 |
| 7.4.2 Telegram Structure | 54 |
| 7.4.4 Frequency Converter Address (ADR) | 54 |
| 7.4.5 Data Control Byte (BCC) | 54 |
| 7.4.7 The PKE Field | 56 |
| 7.4.8 Parameter Number (PNU) | 56 |
| 7.4.9 Index (IND) | 56 |
| 7.4.10 Parameter Value (PWE) | 57 |

| | |
|---|-----------|
| 7.4.11 Data Types Supported by the Frequency Converter | 57 |
| 7.4.12 Conversion | 57 |
| 7.5 Examples | 57 |
| 7.6 Modbus RTU Overview | 58 |
| 7.6.1 Assumptions | 58 |
| 7.6.2 What the User Should Already Know | 58 |
| 7.6.3 Modbus RTU Overview | 58 |
| 7.6.4 Frequency Converter with Modbus RTU | 59 |
| 7.7 Network Configuration | 59 |
| 7.8 Modbus RTU Message Framing Structure | 59 |
| 7.8.1 Frequency Converter with Modbus RTU | 59 |
| 7.8.2 Modbus RTU Message Structure | 59 |
| 7.8.3 Start/Stop Field | 60 |
| 7.8.4 Address Field | 60 |
| 7.8.5 Function Field | 60 |
| 7.8.6 Data Field | 60 |
| 7.8.7 CRC Check Field | 60 |
| 7.8.8 Coil Register Addressing | 60 |
| 7.8.9 How to Control the Frequency Converter | 62 |
| 7.8.10 Function Codes Supported by Modbus RTU | 62 |
| 7.8.11 Modbus Exception Codes | 63 |
| 7.9 How to Access Parameters | 63 |
| 7.9.1 Parameter Handling | 63 |
| 7.9.2 Storage of Data | 63 |
| 7.10 Examples | 64 |
| 7.10.1 Read Coil Status (01 hex) | 64 |
| 7.10.2 Force/Write Single Coil (05 hex) | 64 |
| 7.10.3 Force/Write Multiple Coils (0F hex) | 64 |
| 7.10.4 Read Holding Registers (03 hex) | 65 |
| 7.10.5 Preset Single Register (06 hex) | 65 |
| 7.10.6 Preset Multiple Registers (10 hex) | 66 |
| 7.11 Danfoss FC Control Profile | 66 |
| 7.11.1 Control Word According to FC Profile (8-10 Protocol = FC profile) | 66 |
| 7.11.2 Status Word According to FC Profile (STW) (8-30 Protocol = FC profile) | 68 |
| 7.11.3 Bus Speed Reference Value | 69 |
| 8 General Specifications | 70 |
| 8.1 Mains Supply Specifications | 70 |
| 8.1.1 Mains Supply 3x200-240 V AC | 70 |
| 8.1.2 Mains Supply 3x380-480 V AC | 71 |
| 8.2 General Specifications | 72 |

| | |
|---|-----------|
| 8.2.1 Digital Inputs | 73 |
| 8.2.2 Analog Inputs | 73 |
| 8.2.3 Analog Output | 73 |
| 8.2.4 Digital Output | 73 |
| 8.2.5 Control Card, RS-485 Serial Communication | 73 |
| 8.2.6 Control Card, 24 V DC Output | 74 |
| 8.2.7 Relay Output | 74 |
| 8.2.8 Control Card, 10 V DC Output ¹⁾ | 74 |
| 8.3 Acoustic Noise or Vibration | 75 |
| 8.4 Derating according to Ambient Temperature and Switching Frequency | 76 |
| Index | 77 |

1 Introduction

1.1 Purpose of the Manual

This design guide is intended for project and systems engineers, design consultants, and application and product specialists. Technical information is provided to understand the capabilities of the frequency converter for integration into motor control and monitoring systems. Details concerning operation, requirements, and recommendations for system integration are described. Information is provided for input power characteristics, output for motor control, and ambient operating conditions for the converter.

Also included are safety features, fault condition monitoring, operational status reporting, serial communication capabilities, and programmable options and features. Design details such as site requirements, cables, fuses, control wiring, the size and weight of units, and other critical information necessary to plan for system integration is also provided.

Reviewing the detailed product information in the design stage will enable developing a well-conceived system with optimal functionality and efficiency.

VLT® is a registered trademark

1.2 Document and Software Version

This manual is regularly reviewed and updated. All suggestions for improvement are welcome. *Table 1.1* shows the document version and the corresponding software version.

| Edition | Remarks | Software version |
|----------|---------|------------------|
| MG18N1xx | | 1.00 |

Table 1.1 Document and Software Version

1.3 Safety Symbols

The following symbols are used in this document:



Indicates a potentially hazardous situation that could result in death or serious injury.



Indicates a potentially hazardous situation that could result in minor or moderate injury. It can also be used to alert against unsafe practices.

NOTICE

Indicates important information, including situations that can result in damage to equipment or property.

1.4 Abbreviations

| | |
|--|---------------|
| Alternating current | AC |
| American wire gauge | AWG |
| Ampere/AMP | A |
| Automatic Motor Adaptation | AMA |
| Current limit | I_{LIM} |
| Degrees Celsius | °C |
| Direct current | DC |
| Electro Magnetic Compatibility | EMC |
| Electronic Thermal Relay | ETR |
| Frequency Converter | FC |
| Gram | g |
| Hertz | Hz |
| Kilohertz | kHz |
| Local Control Panel | LCP |
| Meter | m |
| Millihenry Inductance | mH |
| Milliamper | mA |
| Millisecond | ms |
| Minute | min |
| Motion Control Tool | MCT |
| Nanofarad | nF |
| Newton Meters | Nm |
| Nominal motor current | $I_{M,N}$ |
| Nominal motor frequency | $f_{M,N}$ |
| Nominal motor power | $P_{M,N}$ |
| Nominal motor voltage | $U_{M,N}$ |
| Protective Extra Low Voltage | PELV |
| Printed Circuit Board | PCB |
| Rated Inverter Output Current | I_{INV} |
| Revolutions Per Minute | RPM |
| Regenerative terminals | Regen |
| Second | s |
| Synchronous Motor Speed | n_s |
| Torque limit | T_{LIM} |
| Volts | V |
| The maximum output current | $I_{VLT,MAX}$ |
| The rated output current supplied by the frequency converter | $I_{VLT,N}$ |

Table 1.2 Abbreviations

1.5 Additional Resources

- *VLT® Compressor Drive CDS 803 Quick Guide*
- *VLT® Compressor Drive CDS 803 Programming Guide* provides information on how to programme and includes complete parameter descriptions.
- *VLT® Compressor Drive CDS 803 Design Guide* entails all technical information about the frequency converter and customer design and applications.
- *MCT 10 Set-up Software* enables the user to configure the frequency converter from a Windows™ based PC environment.

Danfoss technical literature is available in print from your local Danfoss Sales Office or at: www.danfoss.com/BusinessAreas/DrivesSolutions/Documentations/Technical+Documentation.htm

1.6 Definitions

Frequency Converter

$I_{VLT,MAX}$

The maximum output current.

$I_{VLT,N}$

The rated output current supplied by the frequency converter.

$U_{VLT, MAX}$

The maximum output voltage.

Input

| | | |
|--|---------|--|
| The connected compressor can start and stop with LCP and the digital inputs. Functions are divided into 2 groups. Functions in group 1 have higher priority than functions in group 2. | Group 1 | Reset, Coasting stop, Reset and Coasting stop, Quick-stop, DC braking, Stop and the [Off] key. |
| | Group 2 | Start, Pulse start, Reversing, Start reversing, Jog and Freeze output |

Table 1.3 Control Commands

Compressor

f_{JOG}

The motor frequency when the jog function is activated (via digital terminals).

f_M

The motor frequency.

f_{MAX}

The maximum compressor frequency.

f_{MIN}

The minimum compressor frequency.

$f_{M,N}$

The rated motor frequency (nameplate data).

I_M

The motor current.

$I_{M,N}$

The rated motor current (nameplate data).

$n_{M,N}$

The rated motor speed (nameplate data).

$P_{M,N}$

The rated motor power (nameplate data).

U_M

The instantaneous motor voltage.

$U_{M,N}$

The rated motor voltage (nameplate data).

Break-away torque




Illustration 1.1 Break-away Torque

η_{VLT}

The efficiency of the frequency converter is defined as the ratio between the power output and the power input.

Start-disable command

A stop command belonging to the group 1 control commands, see *Table 1.3*.

Stop command

See Control commands.

References

Analog reference

A signal transmitted to the analog inputs 53 or 54, can be voltage or current.

Bus reference

A signal transmitted to the serial communication port (FC port).

Preset reference

A defined preset reference to be set from -100% to +100% of the reference range. Selection of 8 preset references via the digital terminals.

Ref_{MAX}

Determines the relationship between the reference input at 100% full scale value (typically 10 V, 20 mA) and the resulting reference. The maximum reference value set in *3-03 Maximum Reference*.

Ref_{MIN}

Determines the relationship between the reference input at 0% value (typically 0 V, 0 mA, 4 mA) and the resulting reference. The minimum reference value set in *3-02 Minimum Reference*.

Miscellaneous**Analog inputs**

The analog inputs are used for controlling various functions of the frequency converter.

There are 2 types of analog inputs:

Current input, 0-20 mA and 4-20 mA

Voltage input, 0-10 V DC.

Analog outputs

The analog outputs can supply a signal of 0-20 mA, 4-20 mA, or a digital signal.

Automatic Motor Adaptation, AMA

AMA algorithm determines the electrical parameters for the connected compressor at standstill.

Digital inputs

The digital inputs can be used for controlling various functions of the frequency converter.

Digital outputs

The frequency converter features 2 Solid State outputs that can supply a 24 V DC (max. 40 mA) signal.

Relay outputs

The frequency converter features 2 programmable Relay Outputs.

ETR

Electronic Thermal Relay is a thermal load calculation based on present load and time. Its purpose is to estimate the compressor temperature.

Initialising

If initialising is carried out (*14-22 Operation Mode*), the programmable parameters of the frequency converter return to their default settings.

Initialising; *14-22 Operation Mode* does not initialise communication parameters.

Intermittent duty cycle

An intermittent duty rating refers to a sequence of duty cycles. Each cycle consists of an on-load and an off-load period. The operation can be either periodic duty or non-periodic duty.

LCP

The Local Control Panel (LCP) makes up a complete interface for control and programming of the frequency converter. The control panel is detachable and can be installed up to 3 m from the frequency converter, i.e. in a front panel by means of the installation kit option.

lsb

Least significant bit.

MCM

Short for Mille Circular Mil, an American measuring unit for cable cross-section. 1 MCM \equiv 0.5067 mm².

msb

Most significant bit.

On-line/Off-line parameters

Changes to on-line parameters are activated immediately after the data value is changed. Press [OK] to activate off-line parameters.

PI controller

The PI controller maintains the desired speed, pressure, temperature, etc. by adjusting the output frequency to match the varying load.

RCD

Residual Current Device.

Set-up

Parameter settings in 2 set-ups can be saved. Change between the 2 parameter set-ups and edit one set-up, while another set-up is active.

Slip compensation

The frequency converter compensates for the compressor slip by giving the frequency a supplement that follows the measured compressor load keeping the compressor speed almost constant.

Smart Logic Control (SLC)

The SLC is a sequence of user defined actions executed when the associated user defined events are evaluated as true by the SLC.

Thermistor

A temperature-dependent resistor placed where the temperature is to be monitored (frequency converter or compressor).

Trip

A state entered in fault situations, e.g. if the frequency converter is subject to an over-temperature or when the frequency converter is protecting the compressor, process or mechanism. Restart is prevented until the cause of the fault has disappeared and the trip state is cancelled by activating reset or, in some cases, by being programmed to reset automatically. Trip may not be used for personal safety.

Trip locked

A state entered in fault situations when the frequency converter is protecting itself and requiring physical intervention, for example, if the frequency converter is subject to a short circuit on the output. A locked trip can only be cancelled by cutting off mains, removing the cause of the fault, and reconnecting the frequency converter. Restart is prevented until the trip state is cancelled by activating reset or, in some cases, by being programmed to reset automatically. Trip locked may not be used for personal safety.

VT characteristics

Variable torque characteristics used for pumps and fans.

VVC⁺

If compared with standard voltage/frequency ratio control, Voltage Vector Control (VVC⁺) improves the dynamics and the stability, both when the speed reference is changed and in relation to the load torque.

1.7 Power Factor

The power factor is the relation between I_1 and I_{RMS} .

$$\text{Power factor} = \frac{\sqrt{3} \times U \times I_1 \times \text{COS}\phi}{\sqrt{3} \times U \times I_{RMS}}$$

The power factor for 3-phase control:

$$= \frac{I_1 \times \text{COS}\phi}{I_{RMS}} = \frac{I_1}{I_{RMS}} \text{ since } \text{COS}\phi = 1$$

The power factor indicates to which extent the frequency converter imposes a load on the mains supply.

The lower the power factor, the higher the I_{RMS} for the same kW performance.

$$I_{RMS} = \sqrt{I_1^2 + I_5^2 + I_7^2 + \dots + I_n^2}$$

In addition, a high power factor indicates that the different harmonic currents are low.

The frequency converters built-in DC coils produce a high power factor, which minimizes the imposed load on the mains supply.

2 Product Overview

2.1 Safety

2.1.1 Safety Precautions

Safety Regulations

1. Disconnect the frequency converter from mains, if repair work is to be carried out. Check that the mains supply has been disconnected and that the necessary time has passed before removing compressor and mains plugs.
2. The [Off/Reset] key does not disconnect the equipment from mains and is thus not to be used as a safety switch.
3. Correct protective earthing of the equipment must be established, the user must be protected against supply voltage, and the compressor must be protected against overload in accordance with applicable national and local regulations.
4. The earth leakage currents are higher than 3.5 mA.
5. Protection against motor overload is set by *1-90 Motor Thermal Protection*. If this function is desired, set *1-90 Motor Thermal Protection* to data value [4], [6], [8], [10] *ETR trip* or data value [3], [5], [7], [9] *ETR warning*.
Note: The function is initialised at 1.16 x rated motor current and rated motor frequency. For the North American market: The ETR functions provide class 20 motor overload protection in accordance with NEC.
6. Do not remove the plugs for the compressor and mains supply while the frequency converter is connected to mains. Check that the mains supply has been disconnected and that the necessary time has elapsed before removing compressor and mains plugs.
7. Check that all voltage inputs have been disconnected and that the necessary time has elapsed before commencing repair work.

Installation at high altitudes



At altitudes above 2 km, contact Danfoss regarding PELV. Installation, high altitudes



HIGH VOLTAGE

Frequency converters contain high voltage when connected to AC mains input power. Qualified personnel only should perform installation, start up, and maintenance. Failure to perform installation, start up, and maintenance by qualified personnel could result in death or serious injury.



UNINTENDED START

When the frequency converter is connected to AC mains, the motor may start at any time. The frequency converter, motor, and any driven equipment must be in operational readiness. Failure to be in operational readiness when the frequency converter is connected to AC mains could result in death, serious injury, equipment, or property damage.




DISCHARGE TIME

Frequency converters contain DC-link capacitors that can remain charged even when the frequency converter is not powered. To avoid electrical hazards, disconnect AC mains, any permanent magnet type motors, and any remote DC-link power supplies, including battery back-ups, UPS, and DC-link connections to other frequency converters. Wait for the capacitors to fully discharge before performing any service or repair work. The amount of wait time is listed in the *Discharge Time* table. Failure to wait the specified time after power has been removed before doing service or repair could result in death or serious injury.

| Voltage [V] | Cooling capacity [TR] | Minimum waiting time (minutes) |
|-------------|-----------------------|--------------------------------|
| 3x200 | 4-6.5 | 15 |
| 3x400 | 4-5 | 4 |
| 3x400 | 6.5 | 15 |

Table 2.1 Discharge Time



Equipment containing electrical components can not be disposed of together with domestic waste. It must be separately collected with electrical and electronic waste according to local and currently valid legislation.

2.2 CE Labeling

2.2.1 CE Conformity and Labeling

What is CE Conformity and Labeling?

The purpose of CE labeling is to avoid technical trade obstacles within EFTA and the EU. The EU has introduced the CE label as a simple way of showing whether a product complies with the relevant EU directives. The CE label says nothing about the specifications or quality of the product. Frequency converters are regulated by 3 EU directives:

The machinery directive (98/37/EEC)

All machines with critical moving parts are covered by the machinery directive of January 1, 1995. Since a frequency converter is largely electrical, it does not fall under the machinery directive. However, if a frequency converter is supplied for use in a machine, Danfoss provides information on safety aspects relating to the frequency converter. Danfoss do this by means of a manufacturer's declaration.

The low-voltage directive (73/23/EEC)

Frequency converters must be CE labeled in accordance with the low-voltage directive of January 1, 1997. The directive applies to all electrical equipment and appliances used in the 50-1000 V AC and the 75-1500 V DC voltage ranges. Danfoss CE-labels in accordance with the directive and issues a declaration of conformity upon request.

The EMC directive (89/336/EEC)

EMC is short for electromagnetic compatibility. The presence of electromagnetic compatibility means that the mutual interference between different components/appliances does not affect the way the appliances work. The EMC directive came into effect January 1, 1996. Danfoss CE-labels in accordance with the directive and issues a declaration of conformity upon request. To carry out EMC-correct installation, see the instructions in this Design Guide. In addition, Danfoss specifies which standards our products comply with. Danfoss offers the filters presented in the specifications and provide other types of assistance to ensure the optimum EMC result.

The frequency converter is most often used by professionals of the trade as a complex component forming part of a larger appliance, system or installation. Not that the responsibility for the final EMC properties of the appliance, system or installation rests with the installer.

2.2.2 What is Covered

The EU "Guidelines on the Application of Council Directive 89/336/EEC" outline three typical situations of using a frequency converter. See *chapter 2.2.3 Danfoss Frequency Converter and CE Labeling* for EMC coverage and CE labeling.

1. The frequency converter is sold directly to the end-consumer. The frequency converter is for example sold to a DIY market. The end-consumer is a layman. He installs the frequency converter himself for use with a hobby machine, a kitchen appliance, etc. For such applications, the frequency converter must be CE labeled in accordance with the EMC directive.
2. The frequency converter is sold for installation in a plant. The plant is built up by professionals of the trade. It could be a production plant or a heating/ventilation plant designed and installed by professionals of the trade. Neither the frequency converter nor the finished plant has to be CE labeled under the EMC directive. However, the unit must comply with the basic EMC requirements of the directive. This is ensured by using components, appliances, and systems that are CE labeled under the EMC directive.
3. The frequency converter is sold as part of a complete system. The system is being marketed as complete and could for example, be an air-conditioning system. The complete system must be CE labeled in accordance with the EMC directive. The manufacturer can ensure CE labeling under the EMC directive either by using CE labeled components or by testing the EMC of the system. If only CE labeled components are chosen, the entire system does not have to be tested.

2.2.3 Danfoss Frequency Converter and CE Labeling

CE labeling is a positive feature when used for its original purpose, that is, to facilitate trade within the EU and EFTA.

However, CE labeling may cover many different specifications. Check what a given CE label specifically covers.

The covered specifications can be very different and a CE label may therefore give the installer a false feeling of security when using a frequency converter as a component in a system or an appliance.

Danfoss CE labels the frequency converters in accordance with the low-voltage directive. This means that if the frequency converter is installed correctly, Danfoss guarantees compliance with the low-voltage directive. Danfoss issues a declaration of conformity that confirms our CE labeling in accordance with the low-voltage directive.

The CE label also applies to the EMC directive provided that the instructions for EMC-correct installation and

filtering are followed. On this basis, a declaration of conformity in accordance with the EMC directive is issued.

The Design Guide offers detailed instructions for installation to ensure EMC-correct installation. Furthermore, Danfoss specifies which our different products comply with.

Danfoss provides other types of assistance that can help to obtain the best EMC result.

2.2.4 Compliance with EMC Directive 89/336/EEC

As mentioned, the frequency converter is mostly used by professionals of the trade as a complex component forming part of a larger appliance, system, or installation. Not that the responsibility for the final EMC properties of the appliance, system or installation rests with the installer. As an aid to the installer, Danfoss has prepared EMC installation guidelines for the Power Drive system. The standards and test levels stated for Power Drive systems are complied with, if the EMC-correct instructions for installation are followed.

2.3 Air Humidity

The frequency converter has been designed to meet the IEC/EN 60068-2-3 standard, EN 50178 9.4.2.2 at 50 °C.

2.4 Aggressive Environments

A frequency converter contains many mechanical and electronic components. All are to some extent vulnerable to environmental effects.

CAUTION

The frequency converter should not be installed in environments with airborne liquids, particles, or gases capable of affecting and damaging the electronic components. Failure to take the necessary protective measures increases the risk of stoppages, thus reducing the life of the frequency converter.

Liquids can be carried through the air and condense in the frequency converter and may cause corrosion of components and metal parts. Steam, oil, and salt water may cause corrosion of components and metal parts. In such environments, use equipment with enclosure rating IP54. As an extra protection, coated printed circuit boards can be ordered as an option. (Standard on some power sizes.)

Airborne particles such as dust may cause mechanical, electrical, or thermal failure in the frequency converter. A typical indicator of excessive levels of airborne particles is

dust particles around the frequency converter fan. In dusty environments, use equipment with enclosure rating IP54 or a cabinet for IP20/TYPE 1 equipment.

In environments with high temperatures and humidity, corrosive gases such as sulphur, nitrogen, and chlorine compounds causes chemical processes on the frequency converter components.

Such chemical reactions rapidly affects and damages the electronic components. In such environments, mount the equipment in a cabinet with fresh air ventilation, keeping aggressive gases away from the frequency converter. An extra protection in such areas is a coating of the printed circuit boards, which can be ordered as an option.

NOTICE

Mounting frequency converters in aggressive environments increases the risk of stoppages and considerably reduces the life of the frequency converter.

Before installing the frequency converter, check the ambient air for liquids, particles, and gases. This is done by observing existing installations in this environment. Typical indicators of harmful airborne liquids are water or oil on metal parts, or corrosion of metal parts.

Excessive dust particle levels are often found on installation cabinets and existing electrical installations. One indicator of aggressive airborne gases is blackening of copper rails and cable ends on existing installations.

2.5 Vibration and Shock

The frequency converter has been tested according to the procedure based on the shown standards, *Table 2.2*

The frequency converter complies with requirements that exist for units mounted on the walls and floors of production premises, as well as in panels bolted to walls or floors.

| | |
|-------------------|-------------------------------|
| IEC/EN 60068-2-6 | Vibration (sinusoidal) - 1970 |
| IEC/EN 60068-2-64 | Vibration, broad-band random |

Table 2.2 Standards

2

2.6 Control Structures

Select open or closed loop in *parameter 1-00 Configuration Mode*.

2.6.1 Control Structure Open Loop




Illustration 2.1 Open Loop Structure

In the configuration shown in *Illustration 2.1*, *1-00 Configuration Mode* is set to *[0] Open loop*. The resulting reference from the reference handling system or the local reference is received and fed through the ramp limitation and speed limitation before being sent to the motor control. The output from the motor control is then limited by the maximum frequency limit.

2.6.2 Local (Hand On) and Remote (Auto On) Control

The frequency converter can be operated manually via the local control panel (LCP) or remotely via analog/digital inputs or serial bus. If allowed in *0-40 [Hand on] Key on LCP*, *0-44 [Off/Reset] Key on LCP*, and *0-42 [Auto on] Key on LCP*, it is possible to start and stop the frequency converter by LCP using the [Hand On] and [Off/Reset] keys. Alarms can be reset via the [Off/Reset] key.




Illustration 2.2 LCP Keys


Local reference forces the configuration mode to open loop, independent on the setting of *1-00 Configuration Mode*.

Local Reference is restored at power-down.

2.6.3 Control Structure Closed Loop

The internal controller allows the frequency converter to become an integral part of the controlled system. The frequency converter receives a feedback signal from a sensor in the system. It then compares this feedback to a set-point reference value and determines the error, if any, between these 2 signals. It then adjusts the speed of the motor to correct this error.

For example, consider an application where the speed is to be controlled so that the static pressure in a pipe is constant. The desired static pressure value is supplied to the frequency converter as the set-point reference. A static pressure sensor measures the actual static pressure in the pipe and supplies this to the frequency converter as a feedback signal. If the feedback signal is greater than the set-point reference, the frequency converter slows down to reduce the pressure. In a similar way, if the pipe pressure is lower than the set-point reference, the frequency converter automatically speed up to increase the pressure provided by the pump.




13088894.11

Illustration 2.3 Control Structure Closed Loop

While the default values for the frequency converter’s closed loop controller often provides satisfactory performance, the control of the system can often be optimised by adjusting some of the closed loop controller’s parameters.

2.6.4 Feedback Conversion

In some applications it may be useful to convert the feedback signal. One example of this is using a pressure signal to provide flow feedback. Since the square root of pressure is proportional to flow, the square root of the pressure signal yields a value proportional to the flow. See *Illustration 2.4*.



13088895.10

Illustration 2.4 Feedback Signal Conversion

2.6.5 Reference Handling

Details for open loop and closed loop operation.

2




Illustration 2.5 Block Diagram Showing Remote Reference

The remote reference is comprised of:

- Preset references
- External references (analog inputs and serial communication bus references)
- The preset relative reference
- Feedback controlled setpoint

Up to 8 preset references can be programmed in the frequency converter. The active preset reference can be selected using digital inputs or the serial communications bus. The reference can also be supplied externally, most commonly from an analog input. This external source is selected by one of the 3 Reference Source parameters (3-15 Reference 1 Source, 3-16 Reference 2 Source and 3-17 Reference 3 Source). All reference resources and the bus reference are added to produce the total external reference. The external reference, the preset reference or the sum of the 2 can be selected to be the active reference. Finally, this reference can be scaled using 3-14 Preset Relative Reference.

The scaled reference is calculated as follows:

$$Reference = X + X \times \left(\frac{Y}{100}\right)$$

Where X is the external reference, the preset reference or the sum of these and Y is 3-14 Preset Relative Reference in [%].

If Y, 3-14 Preset Relative Reference, is set to 0%, the reference is not affected by the scaling.

2.6.6 Closed Loop Set-up Wizard

| | |
|----|---|
| 1 | 0-01 Language 00 English |
| 2 | 0-06 Grid Type Size related |
| 3 | 0-60 Main Menu Password 00 |
| 4 | 1-00 Configuration Mode 00 Size related |
| 5 | 1-13 Compressor Selection 11 Closed loop |
| 6 | 3-02 Minimum Reference 0 Hz |
| 7 | 3-03 Maximum Reference 200 Hz |
| 8 | 3-10 Preset Reference 0% |
| 9 | 3-15 Reference 1 Source 11 Analog in 53 |
| 10 | 3-41 Ramp 1 Ramp Up Time 30.00 s |
| 11 | 3-42 Ramp 1 Ramp Down Time 30.00 s |
| 12 | 5-12 Terminal 27 Digital Input 6 Stop inverse |
| 13 | 5-40 Function Relay 1 Alarm |
| 14 | 5-40 Function Relay 2 Drive running |
| 15 | 6-10 Terminal 53 Low Voltage 0.07 V |
| 16 | 6-11 Terminal 53 High Voltage 10 V |
| 17 | 6-14 Terminal 53 Low Ref./Feedb. 30.000 Hz |
| 18 | 6-15 Terminal 53 High Ref./Feedb. 200.000 Hz |
| 19 | 6-22 Terminal 54 Low Current 4.00 mA |
| 20 | 6-23 Terminal 54 High Current 20.00 mA |
| 21 | 6-24 Terminal 54 Low Ref./Feedb. 0.000 |
| 22 | 6-25 Terminal 54 High Ref./Feedb. 4999.000 |
| 23 | 20-00 Feedback 1 Source 2 Analog input 54 |
| 24 | 20-04 Feedback 2 Conversion 0 Linear |
| 25 | 8-01 Control Site 00 Digital and ctrl.word |
| 26 | 8-30 Protocol 00 FC |
| 27 | 8-31 Address 1 |

130BD875.12

Illustration 2.6 Closed Loop Set-up Wizard

Closed loop wizard

| Parameter | Option | Default | Function |
|----------------------------|---|------------------|---|
| 0-01 Language | [0] English [1] Deutsch [2] Francais [3] Dansk [4] Spanish [5] Italiano [28] Bras.port | 0 | Select the language for the display. |
| 0-06 GridType | [0] 200-240 V/50 Hz/IT-grid [1] 200-240 V/50 Hz/Delta [2] 200-240 V/50 Hz [10] 380-440 V/50 Hz/IT-grid [11] 380-440 V/50 Hz/Delta [12] 380-440 V/50 Hz [20] 440-480 V/50 Hz/IT-grid [21] 440-480 V/50 Hz/Delta [22] 440-480 V/50 Hz [30] 525-600 V/50 Hz/IT-grid [31] 525-600 V/50 Hz/Delta [32] 525-600 V/50 Hz [100] 200-240 V/60 Hz/IT-grid [101] 200-240 V/60 Hz/Delta [102] 200-240 V/60 Hz [110] 380-440 V/60 Hz/IT-grid [111] 380-440 V/60 Hz/Delta [112] 380-440 V/60 Hz [120] 440-480 V/60 Hz/IT-grid [121] 440-480 V/60 Hz/Delta [122] 440-480 V/60 Hz [130] 525-600 V/60 Hz/IT-grid [131] 525-600 V/60 Hz/Delta [132] 525-600 V/60 Hz | Size related | Select the operating mode for restart upon reconnection of the frequency converter to mains voltage after power down. |
| 0-60 Main Menu Password | 0-999 | 0 | Define the password for access to the LCP. |
| 1-00 Configuration Mode | [0] Open loop [3] Closed loop | [0] Open loop | Select closed loop. |
| 1-13 Compressor Selection | [24] VZH028-R410A [25] VZH035-R410A [26] VZH044-R410A | Size related | Select the used compressor. |
| 3-02 Minimum Reference | -4999.0 - 200 Hz | 0 Hz | The minimum reference is the lowest value obtainable by summing all references. |
| 3-03 Maximum Reference | 0 - 200 Hz | 200 Hz | The maximum reference is the highest obtainable by summing all references |
| 3-10 Preset Reference | -100 - 100 % | 0 % | Setup a fix set point n preset reference [0]. |
| 3-15 Reference 1 Source | [0] No function [1] Analog in 53 [2] Analog in 54 [7] Pulse input 29 [11] Local bus reference | [1] Analog in 53 | Select the input to be used for the reference signal. |
| 3-41 Ramp 1 Ramp Up Time | 0.05-3600.0 s | 30.00 s | Ramp up time from 0 to 1-25 Motor Nominal Speed. |
| 3-42 Ramp 1 Ramp Down Time | 0.05-3600.0 s | 30.00 s | Ramp-down time from rated motor speed to 0. |

| Parameter | Option | Default | Function |
|---|---|---------------------------|---|
| 5-12 Terminal 27 Digital Input | [0] No operation [1] Reset [2] Coast inverse [3] Coast and reset inverse [4] Quick stop inverse [5] DC-brake inverse [6] Stop inverse [7] External Interlock [8] Start [9] Latched start [10] Reversing [11] Start reversing [14] Jog [16] Preset ref bit 0 [17] Preset ref bit 1 [18] Preset ref bit 2 [19] Freeze reference [20] Speed up [22] Speed down [23] Set-up select bit 0 [34] Ramp bit 0 [52] Run permissive [53] Hand start [54] Auto start [60] Counter A (up) [61] Counter A (down) [62] Reset Counter A [63] Counter B (up) [64] Counter B (down) [65] Reset Counter B | [6] Stop inverse | Select the input function for terminal 27. |
| 5-40 Function Relay [0] Function relay | See 5-40 Function Relay | Alarm | Select the function to control output relay 1. |
| 5-40 Function Relay [1] Function relay | See 5-40 Function Relay | Drive running | Select the function to control output relay 2. |
| 6-10 Terminal 53 Low Voltage | 0-10 V | 0.07 V | Enter the voltage that corresponds to the low reference value. |
| 6-11 Terminal 53 High Voltage | 0-10 V | 10 V | Enter the voltage that corresponds to the high reference value. |
| 6-14 Terminal 53 Low Ref./Feedb. Value | -4999 - 4999 | 30 | Enter the reference value that corresponds to the voltage set in 6-10 Terminal 53 Low Voltage. |
| 6-15 Terminal 53 High Ref./Feedb. Value | -4999 - 4999 | 200 | Enter the reference value that corresponds to the voltage set in 6-11 Terminal 53 High Voltage. |
| 6-22 Terminal 54 Low Current | 0.00-20.00 mA | 4.00 mA | Enter the current that corresponds to the low reference value. |
| 6-23 Terminal 54 High Current | 0-10 V | 10 V | Enter the current that corresponds to the high reference value. |
| 6-24 Terminal 54 Low Ref./Feedb. Value | -0.00-20.00 mA | 20.00 mA | Enter the reference value that corresponds to the current set in 6-20 Terminal 54 Low Voltage. |
| 6-25 Terminal 54 High Ref./Feedb. Value | -4999 - 4999 | Size related | Enter the reference value that corresponds to the current set in 6-21 Terminal 54 High Voltage. |
| 8-01 Control Site | [0] Digital and ctrl.word [1] Digital only [2] Controlword only | [0] Digital and ctrl.word | Select if digital, bus, or a combination of both should control the frequency converter. |

| Parameter | Option | Default | Function |
|-----------------------------|--|-----------------|---|
| 8-30 Protocol | [0] FC [2] Modbus RTU | [0] FC | Select the protocol for the integrated RS-485 port. |
| 8-32 Baud Rate | [0] 2400 Baud [1] 4800 Baud [2] 9600 Baud [3] 19200 Baud [4] 38400 Baud [5] 57600 Baud [6] 76800 Baud [7] 115200 Baud | [2] 9600 Baud | Select the baud rate for the RS-485 port. |
| 20-00 Feedback 1 Source | [0] No function [1] Analog Input 53 [2] Analog Input 54 [3] Pulse input 29 [100] Bus Feedback 1 [101] Bus Feedback 2 | [0] No function | Select which input will be used as the source of the feedback signal. |
| 20-01 Feedback 1 Conversion | [0] Linear [1] Square root | [0] Linear | Select how the feedback should be calculated |

Table 2.3 Closed Loop Applications Set-up

2.6.7 Tuning the Drive Closed Loop Controller

Once the frequency converter's closed loop controller has been set up, the performance of the controller should be tested. In many cases, its performance may be acceptable using the default values of *20-93 PI Proportional Gain* and *20-94 PI Integral Time*. However, in some cases it may be helpful to optimize these parameter values to provide faster system response while still controlling speed overshoot.

2.6.8 Manual PI Adjustment

1. Start the compressor.
2. Set *20-93 PI Proportional Gain* to 0.3 and increase it until the feedback signal begins to oscillate. If necessary, start and stop the frequency converter or make step changes in the set-point reference to attempt to cause oscillation. Next reduce the PI proportional gain until the feedback signal stabilises. Then reduce the proportional gain by 40-60%.
3. Set *20-94 PI Integral Time* to 20 s and reduce it until the feedback signal begins to oscillate. If necessary, start and stop the frequency converter or make step changes in the set-point reference to attempt to cause oscillation. Next, increase the PI integral time until the feedback signal stabilises. Then increase of the integral time by 15-50%.

2.7 General Aspects of EMC

2.7.1 General Aspects of EMC Emissions

Frequency converter (and other electrical devices) generate electronic or magnetic fields that may interfere with their environment. The electromagnetic compatibility (EMC) of these effects depends on the power and the harmonic characteristics of the devices.

Uncontrolled interaction between electrical devices in a system can degrade compatibility and impair reliable operation. Interference may take the form of mains harmonics distortion, electrostatic discharges, rapid voltage fluctuations, or high-frequency interference. Electrical devices generate interference along with being affected by interference from other generated sources.

Electrical interference usually arises at frequencies in the range 150 kHz to 30 MHz. Airborne interference from the frequency converter system in the range 30 MHz to 1 GHz is generated from the inverter, motor cable, and the compressor. Capacitive currents in the motor cable coupled with a high dU/dt from the compressor voltage generate leakage currents, as shown in *Illustration 2.7*.

The use of a screened motor cable increases the leakage current (see *Illustration 2.7*) because screened cables have higher capacitance to ground than unscreened cables. If the leakage current is not filtered, it causes greater interference on the mains in the radio frequency range below approximately 5 MHz. Since the leakage current (I_1) is carried back to the unit through the screen (I_3), there is in principle only a small electro-magnetic field (I_4) from the screened motor cable according to *Illustration 2.7*.


The screen reduces the radiated interference, but increases the low-frequency interference on the mains. Connect the motor cable screen to the frequency converter enclosure as well as on the compressor enclosure. This is best done by using integrated screen clamps so as to avoid twisted screen ends (pigtailed). Pigtails increase the screen impedance at higher frequencies, which reduces the screen effect and increases the leakage current (I_4).

If a screened cable is used for relay, control cable, signal interface and brake, mount the screen on the enclosure at both ends. In some situations, however, it is necessary to break the screen to avoid current loops.

If the screen is to be placed on a mounting plate for the frequency converter, the mounting plate must be made of metal, to convey the screen currents back to the unit. Moreover, ensure good electrical contact from the mounting plate through the mounting screws to the frequency converter chassis.

When unscreened cables are used, some emission requirements are not complied with, although most immunity requirements are observed.

To reduce the interference level from the entire system (unit+installation), make compressor and brake cables as short as possible. Avoid placing cables with a sensitive signal level alongside compressor and brake cables. Radio interference higher than 50 MHz (airborne) is especially generated by the control electronics.



| | | | | | |
|---|-------------|---|---------------------|---|----------------------|
| 1 | Ground wire | 3 | AC mains supply | 5 | Screened motor cable |
| 2 | Screen | 4 | Frequency converter | 6 | Motor |

Illustration 2.7 Generation of Leakage Currents

2.7.2 Emission Requirements

The EMC product standard for frequency converters defines 4 categories (C1, C2, C3 and C4) with specified requirements for emission and immunity. Table 2.4 states the definition of the 4 categories and the equivalent classification from EN 55011.

| Category | Definition | Equivalent emission class in EN 55011 |
|----------|--|---------------------------------------|
| C1 | Frequency converters installed in the first environment (home and office) with a supply voltage less than 1000 V. | Class B |
| C2 | Frequency converters installed in the first environment (home and office) with a supply voltage less than 1000 V, which are neither plug-in nor movable and are intended to be installed and commissioned by a professional. | Class A Group 1 |
| C3 | Frequency converters installed in the second environment (industrial) with a supply voltage lower than 1000 V. | Class A Group 2 |
| C4 | Frequency converters installed in the second environment with a supply voltage equal to or above 1000 V or rated current equal to or above 400 A or intended for use in complex systems. | No limit line. Make an EMC plan. |

Table 2.4 Correlation between IEC 61800-3 and EN 55011

When the generic (conducted) emission standards are used, the frequency converters are required to comply with the limits in Table 2.5.

| Environment | Generic emission standard | Equivalent emission class in EN 55011 |
|---|---|---------------------------------------|
| First environment (home and office) | EN/IEC 61000-6-3 Emission standard for residential, commercial and light industrial environments. | Class B |
| Second environment (industrial environment) | EN/IEC 61000-6-4 Emission standard for industrial environments. | Class A Group 1 |

Table 2.5 Correlation between Generic Emission Standards and EN 55011

2.7.3 EMC Test Results

The following test results have been obtained using a system with a frequency converter, a screened control cable, a control box with potentiometer, as well as a motor screened cable.

| RFI Filter Type | Conduct emission. Maximum shielded cable length [m] | | | | | | Radiated emission | | | |
|--------------------------|---|----------------------|-------------------------|----------------------|--------------------------------------|----------------------|-------------------------|----------------------|--------------------------------------|----------------------|
| | Industrial environment | | | | Housing, trades and light industries | | Industrial environment | | Housing, trades and light industries | |
| | EN 55011 Class A2 | | EN 55011 Class A1 | | EN 55011 Class B | | EN 55011 Class A1 | | EN 55011 Class B | |
| | Without external filter | With external filter | Without external filter | With external filter | Without external filter | With external filter | Without external filter | With external filter | Without external filter | With external filter |
| H4 RFI filter (Class A1) | | | | | | | | | | |
| CDS 803 IP20 | | | 25 | 50 | | 20 | Yes | Yes | | No |

Table 2.6 Test Results

2.7.4 General Aspects of Harmonics Emission

A frequency converter takes up a non-sinusoidal current from mains, which increases the input current I_{RMS}. A non-sinusoidal current is transformed with a Fourier analysis and split into sine-wave currents with different frequencies, that is, different harmonic currents I_n with 50 Hz basic frequency:

| | I ₁ | I ₅ | I ₇ |
|----|----------------|----------------|----------------|
| Hz | 50 | 250 | 350 |

Table 2.7 Harmonic Currents

The harmonics do not affect the power consumption directly, but increase the heat losses in the installation (transformer, cables). So, in plants with a high percentage of rectifier load, maintain harmonic currents at a low level to avoid overload of the transformer and high temperature in the cables.




Illustration 2.8 Intermediate Circuit Coils

NOTICE

Some of the harmonic currents might disturb communication equipment connected to the same transformer or cause resonance with power-factor correction batteries.

To ensure low harmonic currents, the frequency converter is equipped with intermediate circuit coils as standard. This normally reduces the input current I_{RMS} by 40%.

The voltage distortion on the mains supply voltage depends on the size of the harmonic currents multiplied by the mains impedance for the frequency in question. The total voltage distortion THD is calculated based on the individual voltage harmonics using this formula:

$$THD\% = \sqrt{U_5^2 + U_7^2 + \dots + U_N^2}$$

(U_N% of U)

2.7.5 Harmonics Emission Requirements

Equipment connected to the public supply network

| Options | Definition |
|---------|---|
| 1 | IEC/EN 61000-3-2 Class A for 3-phase balanced equipment (for professional equipment only up to 1 kW total power). |
| 2 | IEC/EN 61000-3-12 Equipment 16-75 A and professional equipment as from 1 kW up to 16 A phase current. |

Table 2.8 Connected Equipment

2.7.6 Harmonics Test Results (Emission)

Power sizes up to PK75 in T4 and P3K7 in T2 complies with IEC/EN 61000-3-2 Class A. Power sizes from P1K1 and up to P18K in T2 and up to P90K in T4 complies with IEC/EN 61000-3-12, Table 4.

| | Individual Harmonic Current I_n/I_1 (%) | | | |
|---|---|-------|----------|----------|
| | I_5 | I_7 | I_{11} | I_{13} |
| Actual 6.0-10 kW, IP20, 200 V (typical) | 32.6 | 16.6 | 8.0 | 6.0 |
| Limit for $R_{scc} \geq 120$ | 40 | 25 | 15 | 10 |
| | Harmonic current distortion factor (%) | | | |
| | THD | | PWHF | |
| Actual 6.0-10 kW, 200 V (typical) | 39 | | 41.4 | |
| Limit for $R_{scc} \geq 120$ | 48 | | 46 | |

Table 2.9 Harmonic Current 6.0-10 kW, 200 V

| | Individual Harmonic Current I_n/I_1 (%) | | | |
|---|---|-------|----------|----------|
| | I_5 | I_7 | I_{11} | I_{13} |
| Actual 6.0-10 kW, IP20, 380-480 V (typical) | 36.7 | 20.8 | 7.6 | 6.4 |
| Limit for $R_{scc} \geq 120$ | 40 | 25 | 15 | 10 |
| | Harmonic current distortion factor (%) | | | |
| | THD | | PWHF | |
| Actual 6.0-10 kW, 380-480 V (typical) | 44.4 | | 40.8 | |
| Limit for $R_{scc} \geq 120$ | 48 | | 46 | |

Table 2.10 Harmonic Current 6.0-10 kW, 380-480 V

It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment is connected only to a supply with a short-circuit power S_{sc} greater than or equal to specified above. Other power sizes can be connected to the public supply network by consultation with the distribution network operator.

Compliance with various system level guidelines: The harmonic current data in *Table 2.9* are given in accordance with IEC/EN 61000-3-12 with reference to the Power Drive Systems product standard. They may be used as the basis for calculation of the harmonic currents' influence on the power supply system and for the documentation of compliance with relevant regional guidelines: IEEE 519 -1992; G5/4.

If there is a need for further reduction of harmonic currents, passive or active filters in front of the frequency converters can be installed. Consult Danfoss for further information.

2.7.7 Immunity Requirements

The immunity requirements for frequency converters depend on the environment where they are installed. The requirements for the industrial environment are higher than the requirements for the home and office environment. All Danfoss frequency converters comply with the requirements for the industrial environment and consequently comply also with the lower requirements for home and office environment with a large safety margin.

2.8 Galvanic Isolation (PELV)

2.8.1 PELV - Protective Extra Low Voltage

PELV offers protection by way of extra low voltage. Protection against electric shock is ensured when the electrical supply is of the PELV type and the installation is made as described in local/national regulations on PELV supplies.


All control terminals and relay terminals 01-03/04-06 comply with PELV (Protective Extra Low Voltage) (Does not apply to grounded Delta leg above 440 V).

Galvanic (ensured) isolation is obtained by fulfilling requirements for higher isolation and by providing the relevant creepage/clearance distances. These requirements are described in the EN 61800-5-1 standard.

The components that make up the electrical isolation, as described, also comply with the requirements for higher isolation and the relevant test as described in EN 61800-5-1.

The PELV galvanic isolation can be shown in *Illustration 2.9*.

To maintain PELV all connections made to the control terminals must be PELV, e.g. thermistor must be reinforced/double insulated.



13088896.10

| | |
|---|---|
| 1 | Power supply (SMPS) |
| 2 | Optocouplers, communication between AOC and BOC |
| 3 | Custom relays |
| a | Control card terminals |

Illustration 2.9 Galvanic Isolation

CAUTION

Installation at high altitude:
At altitudes above 2000 m, contact Danfoss regarding PELV.

2.9 Earth Leakage Current

WARNING

DISCHARGE TIME

Touching the electrical parts could be fatal - even after the equipment has been disconnected from mains. Also make sure that other voltage inputs have been disconnected, such as load sharing (linkage of DC intermediate circuit), as well as the compressor connection for kinetic back-up.

Before touching any electrical parts, wait at least the amount of time indicated in *Table 2.1*.

Shorter time is allowed only if indicated on the nameplate for the specific unit.

NOTICE

Leakage Current

The earth leakage current from the frequency converter exceeds 3.5 mA. To ensure that the ground cable has a good mechanical connection to the ground connection, the cable cross section must be at least 10 mm² Cu or 16 mm² Al or 2 rated earth wires terminated separately.

Residual Current Device protection RCD

This product can cause a DC current in the protective conductor. Where a residual current device (RCD) is used for protection in case of direct or indirect contact, only an RCD of Type B is allowed on the supply side of this product. Otherwise, another protective measure shall be applied, such as separation from the environment by double or reinforced insulation, or isolation from the supply system by a transformer. See also Application Note *Protection against Electrical Hazards, MN90G*.

Protective earthing of the frequency converter and the use of RCDs must always follow national and local regulations.

2.10 Extreme Running Conditions

Short circuit (compressor phase – phase)

Current measurement in each of the 3 compressor phases or in the DC-link, protects the frequency converter against short circuits. A short circuit between 2 output phases causes an overcurrent in the inverter. The inverter is turned off individually when the short circuit current exceeds the permitted value (Alarm 16 Trip Lock).

For information about protecting the frequency converter against a short circuit at the load sharing and brake outputs, see the design guidelines.

Switching on the output

Switching on the output between the compressor and the frequency converter is fully permitted. The frequency converter is not damaged in any way by switching on the output. However, fault messages may appear.

Mains drop-out

During a mains drop-out, the frequency converter keeps running until the intermediate circuit voltage drops below the minimum stop level, which is typically 15% below the frequency converter's lowest rated supply voltage. The mains voltage before the drop-out and the compressor load determines how long it takes for the frequency converter to coast.

3 Selection

3.1 Options and Accessories

3.1.1 Local Control Panel (LCP)

| Ordering no. | Description |
|--------------|------------------------|
| 120Z0581 | LCP for all IP20 units |

Table 3.1 Ordering Number

| | |
|---------------------------|-------------|
| Enclosure | IP55 front |
| Max. cable length to unit | 10 ft (3 m) |
| Communication std. | RS-485 |

Table 3.2 Technical Data

3.1.2 Mounting of LCP in Panel Front

| Ordering no. | Description |
|--------------|-----------------------------|
| 132B0201 | LCP kit for remote mounting |

Table 3.3 Ordering Number

Step 1

Fit gasket on LCP.




Illustration 3.1 Fit Gasket

Step 2

Place LCP on panel, see dimensions of hole on *Illustration 3.2*.




Illustration 3.2 Place LCP on Panel

Step 3

Place bracket on back of the LCP, then slide down. Tighten screws and connect cable female side to LCP.




Illustration 3.3 Place Bracket on LCP

Step 4

Connect cable to frequency converter.




Illustration 3.4 Connect Cable

If the enclosure kit is used, an IP20 unit is upgraded to comply with enclosure IP21/TYPE 1.




Illustration 3.5 H3-H5

3

NOTICE

Use the provided thread cutting screws to fasten connector to the frequency converter, tightening torque 1.3 Nm.

3.1.3 IP21/TYPE 1 Enclosure Kit

IP21/TYPE 1 is an optional enclosure element available for IP20 units.

| Frame | Cooling capacity | | Height [mm] A | Width [mm] B | Depth [mm] C | IP21 kit ordering no. | Type 1 kit ordering no. |
|-------|------------------|-------------|---------------|--------------|--------------|-----------------------|-------------------------|
| | 3x200-240 V | 3x380-480 V | | | | | |
| H3 | | 4-5 TR | 346 | 106 | 210 | 132B0214 | 132B0224 |
| H4 | 4-5 TR | 6.5 TR | 374 | 141 | 245 | 132B0215 | 132B0225 |
| H5 | 6.5 TR | | 418 | 161 | 260 | 132B0216 | 132B0226 |

Table 3.4 Enclosure Kit Specifications

3.1.4 Decoupling Plate

Use the decoupling plate for EMC correct installation.

Shown here on a H3 enclosure.

3




Illustration 3.6 Decoupling Plate

| | Length [mm] | Width [mm] |
|-------|-------------|------------|
| H3 | 80.8 | 72.0 |
| H4/H5 | 85.0 | 84.8 |

Table 3.5 Dimensions, Decoupling Plate

| Frame | Cooling capacity | | Decoupling plate |
|-------|------------------|-------------|------------------|
| | 3x200-240 V | 3x380-480 V | |
| H3 | | 4-5 TR | 120Z0582 |
| H4 | 4-5 TR | 6.5 TR | 120Z0583 |
| H5 | 6.5 TR | | 120Z0583 |

Table 3.6 Decoupling Plate Specifications

4 How to Order

4.1 Configuration

4.1.1 Type Code String

| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 |
| C | D | S | 8 | 0 | 3 | P | | | | T | | | | | H | X | | | | X | X | X | S | X | X | X | X | A | X | B | X | C | X | X | X | X | D | X |

130BD938.10



Illustration 4.1 Type Code

| Description | Pos. | Possible choice |
|---------------------------|-------|---|
| Product group & FC series | 1-6 | CDS 803 |
| Power rating | 7-10 | 6.0-10 kW (P6K0-P10K) |
| Number of phases | 11 | Three phases (T) |
| Mains voltage | 11-12 | T2: 200-240 V AC T4: 380-480 V AC |
| Enclosure | 13-15 | E20: IP20/Chassis |
| RFI filter | 16-17 | H4: RFI filter class A1 |
| Brake | 18 | X: No brake chopper included |
| Display | 19 | A: Alpha Numeric Local Control Panel X: No Local Control Panel |
| Coating PCB | 20 | X: No coated PCB C: Coated PCB |
| Mains option | 21 | X: No mains option |
| Adaption | 22 | X: No adaption |
| Adaption | 23 | X: No adaption |
| Software release | 24-27 | SXXXX: Latest release - std. software |
| Software language | 28 | X: Standard |
| A options | 29-30 | AX: No A options |
| B options | 31-32 | BX: No B options |
| C0 options MCO | 33-34 | CX: No C options |
| C1 options | 35 | X: No C1 options |
| C option software | 36-37 | XX: No options |
| D options | 38-39 | DX: No D0 options |

Table 4.1 Type Code Descriptions

4.2 Ordering Numbers

4.2.1 External RFI Filter

External filters to fulfil A1 50 m/B1 20 m.

4

| Power [kW] Size 380-480 V | Type | A | B | C | D | E | F | G | H | I | J | K | L1 | Torque [Nm] | Weight [kg] | Ordering Number |
|------------------------------|--------------|-----|----|----|-----|-----|----|-----|---|------|----|------|----|-------------|-------------|-----------------|
| 6-7.5 | FN3258-16-45 | 250 | 45 | 70 | 220 | 235 | 25 | 4.5 | 1 | 10.6 | M5 | 22.5 | 31 | 0.7-0.8 | 0.8 | 132B0245 |
| 10 | FN3258-30-47 | 270 | 50 | 85 | 240 | 255 | 30 | 5.4 | 1 | 10.6 | M5 | 25 | 40 | 1.9-2.2 | 1.2 | 132B0246 |

Table 4.2 RFI Filters - Details




Illustration 4.2 RFI Filter

5 How to Install

5.1 Mechanical Dimensions

5.1.1 Side-by-Side Installation

The frequency converter can be mounted side-by-side but requires the clearance above and below for cooling.

| Frame | IP class | Power [kW(HP)] | | | Clearance above/below [mm(in)] |
|-------|----------|-------------------|------------------|-----------------|--------------------------------|
| | | 3x200-240 V | 3x380-480 V | 3x525-600 V | |
| H1 | IP20 | 0.25-1.5 (0.33-2) | 0.37-1.5 (0.5-2) | – | 100 (4) |
| H2 | IP20 | 2.2 (3) | 2.2-4 (3-5) | – | 100 (4) |
| H3 | IP20 | 3.7 (5) | 5.5-7.5 (7.5-10) | – | 100 (4) |
| H4 | IP20 | 5.5-7.5 (7.5-10) | 11-15 (15-20) | – | 100 (4) |
| H5 | IP20 | 11 (15) | 18.5-22 (25-30) | – | 100 (4) |
| H6 | IP20 | 15-18.5 (20-25) | 30-45 (40-60) | 18.5-30 (25-40) | 200 (7.9) |
| H7 | IP20 | 22-30 (30-40) | 55-75 (70-100) | 37-55 (50-70) | 200 (7.9) |
| H8 | IP20 | 37-45 (50-60) | 90 (125) | 75-90 (100-125) | 225 (8.9) |
| H9 | IP20 | – | – | 2.2-7.5 (3-10) | 100 (4) |
| H10 | IP20 | – | – | 11-15 (15-20) | 200 (7.9) |
| I2 | IP54 | – | 0.75-4.0 (1-5) | – | 100 (4) |
| I3 | IP54 | – | 5.5-7.5 (7.5-10) | – | 100 (4) |
| I4 | IP54 | – | 11-18.5 (15-25) | – | 100 (4) |
| I6 | IP54 | – | 22-37 (30-50) | – | 200 (7.9) |
| I7 | IP54 | – | 45-55 (60-70) | – | 200 (7.9) |
| I8 | IP54 | – | 75-90 (100-125) | – | 225 (8.9) |

Table 5.1 Clearance Required for Cooling

NOTICE

With IP21/NEMA Type1 option kit mounted, a distance of 50 mm (2 in) between the units is required.

5.1.2 Frequency Converter Dimensions

| Enclosure | | Power [kW(HP)] | | Height [mm (in)] | | Width [mm(in)] | | Depth [mm(in)] | Mounting hole [mm(in)] | | | Max. Weight | | |
|-----------|----------|-------------------|------------------|------------------|------------|----------------------------------|------------|----------------|------------------------|------------|-------------|-------------|------------|------------|
| Size | IP Class | 3x200-240 V | 3x380-480 V | 3x525-600 V | A | A ¹⁾ | a | B | b | C | d | e | f | kg(lb) |
| H1 | IP20 | 0.25-1.5 (0.33-2) | 0.37-1.5 (0.5-2) | - | 195 (7.7) | 273 (10.7) | 183 (7.2) | 75 (3.0) | 56 (2.2) | 168 (6.6) | 9 (0.35) | 4.5 (0.18) | 5.3 (0.21) | 2.1 (4.6) |
| H2 | IP20 | 2.2 (3) | 2.2-4.0 (3-5) | - | 227 (8.9) | 303 (11.9) | 212 (8.3) | 90 (3.5) | 65 (2.6) | 190 (7.5) | 11 (0.43) | 5.5 (0.22) | 7.4 (0.29) | 3.4 (7.5) |
| H3 | IP20 | 3.7 (5) | 5.5-7.5 (7.5-10) | - | 255 (10.0) | 329 (13.0) | 240 (9.4) | 100 (3.9) | 74 (2.9) | 206 (8.1) | 11 (0.43) | 5.5 (0.22) | 8.1 (0.32) | 4.5 (9.9) |
| H4 | IP20 | 5.5-7.5 (7.5-10) | 11-15 (15-20) | - | 296 (11.7) | 359 (14.1) | 275 (10.8) | 135 (5.3) | 105 (4.1) | 241 (9.5) | 12.6 (0.50) | 7 (0.28) | 8.4 (0.33) | 7.9 (17.4) |
| H5 | IP20 | 11 (15) | 18.5-22 (25-30) | - | 334 (13.1) | 402 (15.8) | 314 (12.4) | 150 (5.9) | 120 (4.7) | 255 (10) | 12.6 (0.50) | 7 (0.28) | 8.5 (0.33) | 9.5 (20.9) |
| H6 | IP20 | 15-18.5 (20-25) | 30-45 (40-60) | 18.5-30 (25-40) | 518 (20.4) | 595 (23.4)/635 (25) (45 kW) | 495 (19.5) | 239 (9.4) | 200 (7.9) | 242 (9.5) | - | 8.5 (0.33) | 15 (0.6) | 24.5 (54) |
| H7 | IP20 | 22-30 (30-40) | 55-75 (70-100) | 37-55 (50-70) | 550 (21.7) | 630 (24.8)/690 (27.2) (75 kW) | 521 (20.5) | 313 (12.3) | 270 (10.6) | 335 (13.2) | - | 8.5 (0.33) | 17 (0.67) | 36 (79) |
| H8 | IP20 | 37-45 (50-60) | 90 (125) | 75-90 (100-125) | 660 (26) | 800 (31.5) | 631 (24.8) | 375 (14.8) | 330 (13) | 335 (13.2) | - | 8.5 (0.33) | 17 (0.67) | 51 (112) |
| H9 | IP20 | - | - | 2.2-7.5 (3-10) | 269 (10.6) | 374 (14.7) | 257 (10.1) | 130 (5.1) | 110 (4.3) | 205 (8) | 11 (0.43) | 5.5 (0.22) | 9 (0.35) | 6.6 (14.6) |
| H10 | IP20 | - | - | 11-15 (15-20) | 399 (15.7) | 419 (16.5) | 380 (15) | 165 (6.5) | 140 (5.5) | 248 (9.8) | 12 (0.47) | 6.8 (0.27) | 7.5 (0.30) | 12 (26.5) |

1) Including decoupling plate
The dimensions are only for the physical units. When installing in an application it is necessary to allow space above and below the units for cooling. The amount of space for free air passage is listed in Table 5.1.

Table 5.3 Dimensions, Enclosure Size H1-H10

| Enclosure | | Power [kW(HP)] | | Height [mm (in)] | | Width [mm(in)] | | Depth [mm(in)] | | Mounting hole [mm(in)] | | | Max. Weight | |
|-----------|----------|----------------|------------------|------------------|------------|-----------------|---------------|----------------|------------|------------------------|-----------|------------|-------------|--------------|
| Size | IP Class | 3x200-240 V | 3x380-480 V | 3x525-600 V | A | A ¹⁾ | a | B | b | C | d | e | f | kg(lb) |
| I2 | IP54 | - | 0.75-4.0 (1-5) | - | 332 (13.1) | - | 318.5 (12.53) | 115 (4.5) | 74 (2.9) | 225 (8.9) | 11 (0.43) | 5.5 (0.22) | 9 (0.35) | 5.3 (11.7) |
| I3 | IP54 | - | 5.5-7.5 (7.5-10) | - | 368 (14.5) | - | 354 (13.9) | 135 (5.3) | 89 (3.5) | 237 (9.3) | 12 (0.47) | 6.5 (0.26) | 9.5 (0.37) | 7.2 (15.9) |
| I4 | IP54 | - | 11-18.5 (15-25) | - | 476 (18.7) | - | 460 (18.1) | 180 (7) | 133 (5.2) | 290 (11.4) | 12 (0.47) | 6.5 (0.26) | 9.5 (0.37) | 13.8 (30.42) |
| I6 | IP54 | - | 22-37 (30-50) | - | 650 (25.6) | - | 624 (24.6) | 242 (9.5) | 210 (8.3) | 260 (10.2) | 19 (0.75) | 9 (0.35) | 9 (0.35) | 27 (59.5) |
| I7 | IP54 | - | 45-55 (60-70) | - | 680 (26.8) | - | 648 (25.5) | 308 (12.1) | 272 (10.7) | 310 (12.2) | 19 (0.75) | 9 (0.35) | 9.8 (0.39) | 45 (99.2) |
| I8 | IP54 | - | 75-90 (100-125) | - | 770 (30) | - | 739 (29.1) | 370 (14.6) | 334 (13.2) | 335 (13.2) | 19 (0.75) | 9 (0.35) | 9.8 (0.39) | 65 (143.3) |

1) Including decoupling plate

The dimensions are only for the physical units. When installing in an application it is necessary to allow space above and below the units for cooling. The amount of space for free air passage is listed in Table 5.1.

Table 5.4 Dimensions, Enclosure Size I2-I8

5.1.3 Shipping Dimensions

| Enclosure frame size Mains voltage | H1 | H2 | H3 | H4 | H5 | H6 | H7 | H8 | H9 | H10 | I2 | I3 | I4 | I6 | I7 | I8 | |
|---------------------------------------|---------------------|-----------------|--------------------|--------------------|-------------------|-------------------|------------------|-------------------|--------------------|-----------------|------------------|--------------------|-------------------|-----------------|-----------------|---------------|--|
| 200-240 V AC [kW/HP] | 0.25-1.5/ 0.33-2 | 2.2/3 | 3.7/5 | 5.5-7.5/ 7.5-10 | 11/15 | 15-18.5/ 20 | 22-30/ 30-40 | 37-45/ 50-60 | | | | | | | | | |
| 380-480 V AC [kW/HP] | 0.37-1.5/ 0.5-2 | 2.2-4/ 3-5.4 | 5.5-7.5/ 7.5-10 | 11-15/ 15-20 | 18.5-22/ 25-30 | 30-45/ 40-60 | 55-75/ 73-100 | 90/ 125 | | | 0.75/ 1.0-5.0 | 5.5-7.5/ 7.5-10 | 11-18.5/ 15-25 | 22-37/ 30-50 | 45-55/ 60-70 | 75-90/ 125 | |
| 3x525-600 V AC) [kW/HP] | | | | | | 18.5-30/ 30-40 | 37-55/ 60-70 | 75-90/ 100-125 | 2.2-7.5/ 3.0-10 | 11-15/ 15-20 | | | | | | | |
| IP frame | IP20 | | | | | | | | | | IP54 | | | | | | |
| Maximum weight [kg] | 2.1 | 3.4 | 4.5 | 7.9 | 9.5 | 24.5 | 36 | 51 | 6.6 | 11.5 | 6.1 | 7.8 | 13.8 | 28.3 | 41.5 | 60.5 | |
| Shipping dimensions | | | | | | | | | | | | | | | | | |
| Height [mm/inch] | 255/10.0 | 300/ 11.8 | 330/ 13.0 | 380/ 15.0 | 420 / 16.5 | 850 | 850 | 850 | 380 | 500 | 440 | 470 | 588 | 850 | 850 | 950 | |
| Width [mm/inch] | 154/6.1 | 170/ 6.7 | 188/ 7.4 | 250/ 9.8 | 290/ 11.4 | 370 | 410 | 490 | 290 | 330 | 200 | 240 | 285 | 370 | 410 | 490 | |
| Depth [mm/inch] | 235/9.3 | 260/ 10.2 | 282/ 11.1 | 375/ 14.8 | 375/ 14.8 | 460 | 540 | 490 | 200 | 350 | 300 | 330 | 385 | 460 | 540 | 490 | |

Table 5.5 Shipping Dimensions

5.1.4 Field Mounting

For field mounting, IP21/TYPE 1 kits are recommended.

5.2 Electrical Data

5.2.1 Electrical Overview




Illustration 5.1 Basic Wiring Schematic Drawing

5.2.2 Electrical Installation in General

All cabling must comply with national and local regulations on cable cross-sections and ambient temperature. Copper conductors required, (75 °C) recommended.

| Enclosure | | Torque [Nm] | | | | | |
|-----------|----------|-------------|-----------------------|---------------|-------------------|--------|-------|
| Frame | IP class | Line | Compressor connection | DC connection | Control terminals | Ground | Relay |
| H3 | IP20 | 1.4 | 0.8 | 0.8 | 0.5 | 0.8 | 0.5 |
| H4 | IP20 | 1.2 | 1.2 | 1.2 | 0.5 | 0.8 | 0.5 |
| H5 | IP20 | 1.2 | 1.2 | 1.2 | 0.5 | 0.8 | 0.5 |

Table 5.6 Enclosure H3-H5

5.2.3 Connecting to Mains and Compressor


The frequency converter is designed to operate Danfoss VZH Compressors. For maximum cross-section on wires see *chapter 8.2 General Specifications*.

- Use a shielded/armored compressor cable to comply with EMC emission specifications, and connect this cable to both the decoupling plate and the compressor metal.
 - Keep compressor cable as short as possible to reduce the noise level and leakage currents.
 - For further details on mounting of the decoupling plate, see *VLT® Compressor Drive CDS 803 Decoupling Plate Installation Instructions*.
 - Also see *EMC-Correct Installation in the VLT® Compressor Drive CDS 803 Design Guide*.
1. Mount the ground wires to ground terminal.
 2. Connect compressor to terminals U, V and W, see *Table 5.7*.

| | |
|---|----|
| U | T1 |
| V | T2 |
| W | T3 |

Table 5.7 Connection of Compressor to Terminals

3. Mount mains supply to terminals L1, L2 and L3 and tighten.



| | |
|---|------------|
| 1 | Line |
| 2 | Ground |
| 3 | Compressor |
| 4 | Relays |

Illustration 5.2 H3-H5 Frame
 IP20 200-240 V 4-6.5 tons
 IP20 380-480 V 4-6.5 tons




Illustration 5.3 Mount the 2 screws in the mounting plate, slide it into place and tighten fully.




Illustration 5.5 When mounting cables, first mount and tighten ground cable.




Illustration 5.4 H3-H5 Frame




Illustration 5.6 Mount mains plug and tighten wires.




Illustration 5.7 Tighten support bracket on mains wires.

5.2.4 Fuses

Branch circuit protection

To protect the installation against electrical and fire hazard, all branch circuits in an installation, switch gear, machines etc., must be short-circuit and overcurrent protected according to national and local regulations.

Short circuit protection

Danfoss recommends using the fuses listed in *Table 5.8* to protect service personnel or equipment in case of an internal failure in the unit or short-circuit on DC-link. The frequency converter provides full short circuit protection in case of a short-circuit on the compressor.

Overcurrent protection

Provide overload protection to avoid overheating of the cables in the installation. Overcurrent protection must always be carried out according to local and national regulations. Circuit breakers and fuses must be designed for protection in a circuit capable of supplying a maximum of 100,000 A_{rms} (symmetrical), 480 V maximum.

UL/Non UL compliance

Use the fuses listed in *Table 5.8* to ensure compliance with UL or IEC 61800-5-1.

NOTICE

In the event of malfunction, failure to follow the protection recommendation may result in damage to the frequency converter.

| | Fuse | | | | |
|-------------------------|----------|----------|----------|----------|----------|
| | UL | | | | Non UL |
| | Bussmann | Bussmann | Bussmann | Bussmann | Max fuse |
| CDS 803 | Type RK5 | Type RK1 | Type J | Type T | Type G |
| 3x200-240 V IP20 | | | | | |
| 4 TR/VZH028 | FRS-R-50 | KTN-R50 | JKS-50 | JJN-50 | 50 |
| 5 TR/VZH035 | FRS-R-50 | KTN-R50 | JKS-50 | JJN-50 | 50 |
| 6.5 TR/VZH044 | FRS-R-80 | KTN-R80 | JKS-80 | JJN-80 | 65 |
| 3x380-480 V IP20 | | | | | |
| 4 TR/VZH028 | FRS-R-25 | KTS-R25 | JKS-25 | JJS-25 | 25 |
| 5 TR/VZH035 | FRS-R-25 | KTS-R25 | JKS-25 | JJS-25 | 25 |
| 6.5 TR/VZH044 | FRS-R-50 | KTS-R50 | JKS-50 | JJS-50 | 50 |

Table 5.8 Fuses

5.2.5 EMC Compliant Electrical Installation

General points to be observed to ensure EMC-correct electrical installation.

- Use only screened/armoured motor cables and screened/armoured control cables.
- Connect the screen to earth at both ends.
- Avoid installation with twisted screen ends (pigtailed), since this ruins the screening effect at high frequencies. Use the cable clamps provided instead.
- It is important to ensure good electrical contact from the installation plate through the installation screws to the metal cabinet of the frequency converter.
- Use starwashers and galvanically conductive installation plates.
- Do not use unscreened/unarmoured motor cables in the installation cabinets.

5




Illustration 5.8 EMC-correct Electrical Installation

NOTICE

For North America use metal conduits instead of shielded cables.

5.2.6 Control Terminals




Illustration 5.9 Location of Control Terminals

1. Place a screwdriver behind the terminal cover to activate the snap.
2. Tilt the screwdriver outwards to open the cover.

Control terminals

To make the compressor run:

1. Apply start signal on terminal 18
2. Connect terminals 12, 27 and terminal 53, 54 or 55




Illustration 5.10 Control Terminals

Set the functions of digital input 18, 19 and 27 in 5-00 *Digital Input Mode* (PNP is default value). Set the function of digital input 29 in 5-03 *Digital Input 29 Mode* (PNP is default value).

6 How to Programme

6.1 Programming with MCT 10 Set-up Software

The frequency converter can be programmed from a PC via RS-485 COM port by using the MCT 10 Set-up Software. Contact the local supplier for the software, or download it from www.danfoss.com/BusinessAreas/DrivesSolutions/softwaredownload

6.2 Local Control Panel (LCP)

The LCP is divided into 4 functional sections.

- A. Display
- B. Menu key
- C. Navigation keys and indicator lights (LEDs)
- D. Operation keys and indicator lights (LEDs)




Illustration 6.1 Local Control Panel (LCP)

A. Display

The LCD-display is back-lit with 2 alphanumeric lines. All data is displayed on the LCP.

Illustration 6.1 describes the information that can be read from the display.

| | |
|---|---|
| 1 | Parameter number and name. |
| 2 | Parameter value. |
| 3 | Set-up number shows the active set-up and the edit set-up. If the same set-up acts as both active and edit set-up, only that set-up number is shown (factory setting). When active and edit set-up differ, both numbers are shown in the display (set-up 12). The number flashing, indicates the edit set-up. |
| 4 | Motor direction is shown to the bottom left of the display – indicated by a small arrow pointing either clockwise or counterclockwise. |
| 5 | The triangle indicates if the LCP is in status, quick menu or main menu. |

Table 6.1 Legend to Illustration 6.1

B. Menu key

Press [Menu] to select between status, quick menu or main menu.

C. Navigation keys and indicator lights (LEDs)

| | |
|----|--|
| 6 | Com LED: Flashes when bus communication is communicating. |
| 7 | Green LED/On: Control section is working correctly. |
| 8 | Yellow LED/Warn.: Indicates a warning. |
| 9 | Flashing Red LED/Alarm: Indicates an alarm. |
| 10 | [Back]: For moving to the previous step or layer in the navigation structure. |
| 11 | [▲] [▼] [▶]: For navigating among parameter groups, parameters and within parameters. They can also be used for setting local reference. |
| 12 | [OK]: For selecting a parameter and for accepting changes to parameter settings. |

Table 6.2 Legend to Illustration 6.1

D. Operation keys and indicator lights (LEDs)

| | |
|----|---|
| 13 | [Hand On]: Starts the motor and enables control of the frequency converter via the LCP. NOTICE [2] coast inverse is the default option for 5-12 Terminal 27 Digital Input. This means that [Hand On] does not start the motor if there is no 24 V supply to terminal 27. Connect terminal 12 to terminal 27. |
| 14 | [Off/Reset]: Stops the motor (Off). If in alarm mode, the alarm is reset. |
| 15 | [Auto On]: Frequency converter is controlled either via control terminals or serial communication. |

Table 6.3 Legend to Illustration 6.1

6.3 Menus

6.3.1 Status Menu

In the *Status* menu, the selection options are:

- Motor Frequency [Hz], 16-13 *Frequency*.
- Motor Current [A], 16-14 *Motor current*.
- Motor Speed Reference in Percentage [%], 16-02 *Reference [%]*.
- Feedback, 16-52 *Feedback[Unit]*.
- Motor Power [kW] (if 0-03 *Regional Settings* is set to [1] *North America*, Motor Power is shown in the unit of hp instead of kW), 16-10 *Power [kW]* for kW, 16-11 *Power [hp]* for hp.
- Custom Readout 16-09 *Custom Readout*.

6.3.2 Quick Menu

Use the Quick Menu to programme the most common functions. The Quick Menu consists of:

- Wizard for open loop applications
- Closed loop set-up wizard
- Changes made

6.3.3 The Start-up Wizard

The built-in wizard menu guides the installer through the set-up of the frequency converter in a clear and structured way to set-up an open loop application. An open loop application is here an application with a start signal, analog reference (voltage or current) and optionally also relay signals (but no feedback signal from the process applied).




Illustration 6.2 Open Loop Application

The wizard is initially shown after power-up until any parameter has been changed. The wizard can always be accessed again through the *Quick Menu*. Press [OK] to start the wizard. Press [Back] to return to the status screen.





Illustration 6.3 Start-up/Quit Wizard


At power up the user is asked to choose the preferred language.




Power Up Screen



The next screen will be the Wizard screen.



Wizard Screen



Status Screen

The Wizard can always be reentered via the Quick Menu!

... the CDS 803 Wizard starts

- 4 Select Language
01 English
Setup 1 ▼
- 5 Select Grid Type
Size related
Setup 1 ▼
- 6 Select Main Menu Password
01
Setup 1 ▼
- 7 Select Compressor Selection
Size related
Setup 1 ▼
- 8 Select Max. reference
200 Hz
Setup 1 ▼
- 9 Select Reference 1 Source
01 Analog in 53
Setup 1 ▼
- 10 Select Ramp 1 Ramp Up Time
30 s
Setup 1 ▼
- 11 Select Ramp 1 Ramp Down Time
80 s
Setup 1 ▼
- 12 Select Terminal 27 Digital In
06 Stop inverse
Setup 1 ▼
- 13 Select Relay 1
09 Alarm
Setup 1 ▼
- 14 Select Relay 2
05 Drive Running
Setup 1 ▼
- 15 Select Terminal 53 Low Voltage
0.07 V
Setup 1 ▼
- 16 Select Terminal 53 High Voltage
10 V
Setup 1 ▼
- 17 Select Control Site
01 Digital and ctrl.word
Setup 1 ▼
- 18 Select Protocol
01 FC
Setup 1 ▼
- 19 Select Address
1
Setup 1 ▼



The Start-up wizard for open-loop applications

| Parameter | Option | Default | Function |
|----------------------------|---|------------------|---|
| 0-01 Language | [0] English [1] Deutsch [2] Francais [3] Dansk [4] Spanish [5] Italiano [28] Bras.port | [0] English | Select the language for the display. |
| 0-06 GridType | [0] 200-240 V/50 Hz/IT-grid [1] 200-240 V/50 Hz/Delta [2] 200-240 V/50 Hz [10] 380-440 V/50 Hz/IT-grid [11] 380-440 V/50 Hz/Delta [12] 380-440 V/50 Hz [20] 440-480 V/50 Hz/IT-grid [21] 440-480 V/50 Hz/Delta [22] 440-480 V/50 Hz [30] 525-600 V/50 Hz/IT-grid [31] 525-600 V/50 Hz/Delta [32] 525-600 V/50 Hz [100] 200-240 V/60 Hz/IT-grid [101] 200-240 V/60 Hz/Delta [102] 200-240 V/60 Hz [110] 380-440 V/60 Hz/IT-grid [111] 380-440 V/60 Hz/Delta [112] 380-440 V/60 Hz [120] 440-480 V/60 Hz/IT-grid [121] 440-480 V/60 Hz/Delta [122] 440-480 V/60 Hz [130] 525-600 V/60 Hz/IT-grid [131] 525-600 V/60 Hz/Delta [132] 525-600 V/60 Hz | Size related | Select operating mode for restart upon reconnection of the frequency converter to mains voltage after power-down. |
| 0-60 Main Menu Password | 0-999 | 0 | Define the password for access to the LCP. |
| 1-13 Compressor Selection | [24] VZH028-R410A [25] VZH035-R410A [26] VZH044-R410A | Size related | Select the used compressor. |
| 3-03 Maximum Reference | 0-200 Hz | 200 Hz | The maximum reference is the highest obtainable by summing all references. |
| 3-15 Reference 1 Source | [0] No function [1] Analog in 53 [2] Analog in 54 [7] Pulse input 29 [11] Local bus reference | [1] Analog in 53 | Select the input to be used for the reference signal. |
| 3-41 Ramp 1 Ramp Up Time | 0.05-3600.0 s | 30.00 s | Ramp-up time from 0 to 1-25 Motor Nominal Speed. |
| 3-42 Ramp 1 Ramp Down Time | 0.05-3600.0 s | 30.00 s | Ramp down time from rated motor speed to 0. |

| Parameter | Option | Default | Function |
|--|---|----------------------------|--|
| 5-12 Terminal 27 Digital Input | [0] No operation [1] Reset [2] Coast inverse [3] Coast and reset inverse [4] Quick stop inverse [5] DC-brake inverse [6] Stop inverse [7] External Interlock [8] Start [9] Latched start [10] Reversing [11] Start reversing [14] Jog [16] Preset ref bit 0 [17] Preset ref bit 1 [18] Preset ref bit 2 [19] Freeze reference [20] Speed up [22] Speed down [23] Set-up select bit 0 [34] Ramp bit 0 [52] Run permissive [53] Hand start [54] Auto start [60] Counter A (up) [61] Counter A (down) [62] Reset Counter A [63] Counter B (up) [64] Counter B (down) [65] Reset Counter B | [6] Stop inverse | Select the input function for terminal 27. |
| 5-40 Function Relay [0] Function relay | See 5-40 Function Relay | Alarm | Select the function to control output relay 1. |
| 5-40 Function Relay [1] Function relay | See 5-40 Function Relay | Drive running | Select the function to control output relay 2. |
| 6-10 Terminal 53 Low Voltage | 0-10 V | 0.07 V | Enter the voltage that corresponds to the low reference value. |
| 6-11 Terminal 53 High Voltage | 0-10 V | 10 V | Enter the voltage that corresponds to the high reference value. |
| 8-01 Control Site | [0] Digital and ctrl.word [1] Digital only [2] Controlword only | [0] Digital and ctrl. word | Select if digital, bus, or a combination of both should control the frequency converter. |
| 8-30 Protocol | [0] FC [2] Modbus RTU | [0] FC | Select the protocol for the integrated RS-485 port. |
| 8-32 Baud Rate | [0] 2400 Baud [1] 4800 Baud *[2] 9600 Baud [3] 19200 Baud [4] 38400 Baud [5] 57600 Baud [6] 76800 Baud [7] 115200 Baud | 9600 | Select the baud rate for the RS-485 port. |

Table 6.4 Open-loop Applications Set-up

The Start-up wizard for compressor functions




Illustration 6.5 Compressor Function Wizard

Compressor function wizard

| Parameter | Option | Default | Function |
|-------------------------------|-----------------------------|-------------|--|
| 28-00 Short Cycle Protection | [0] Disabled [1] Enabled | [1] Enabled | Select if short cycle protection is to be used. |
| 28-01 Interval between Starts | 0-3600 s | 300 s | Enter the minimum allowed time between starts. |
| 28-02 Minimum Run Time | 10-3600 s | 60 s | Enter the minimum allowed time to run before stop. |
| 28-10 Oil Return Management | [0] Off [1] On | [1] On | Select if oil return management is to be used. |
| 28-11 Low Speed Running Time | 1-1400 min | 20 min | Enter the low speed running time. |
| 28-13 Boost Duration | 10-3600 s | 60 s | Enter the boost duration for the oil return. |

Table 6.5 Compressor Function

The Start-up wizard for compressor closed-loop applications

6

| | | |
|----|--|--------------|
| 1 | 0-01 Language [0] English | 130BD0875.12 |
| 2 | 0-06 Grid Type Size related | |
| 3 | 0-60 Main Menu Password [0] | |
| 4 | 1-00 Configuration Mode [0] Size related | |
| 5 | 1-13 Compressor Selection [1] Closed loop | |
| 6 | 3-02 Minimum Reference [0] Hz | |
| 7 | 3-03 Maximum Reference 200 Hz | |
| 8 | 3-10 Preset Reference 0% | |
| 9 | 3-15 Reference 1 Source [1] Analog in 53 | |
| 10 | 3-41 Ramp 1 Ramp Up Time 30.00 s | |
| 11 | 3-42 Ramp 1 Ramp Down Time 30.00 s | |
| 12 | 5-12 Terminal 27 Digital Input [6] Stop inverse | |
| 13 | 5-40 Function Relay 1 Alarm | |
| 14 | 5-40 Function Relay 2 Drive running | |
| 15 | 6-10 Terminal 53 Low Voltage 0.07 V | |
| 16 | 6-11 Terminal 53 High Voltage 10 V | |
| 17 | 6-14 Terminal 53 Low Ref./Feedb. 30.000 Hz | |
| 18 | 6-15 Terminal 53 High Ref./Feedb. 200.000 Hz | |
| 19 | 6-22 Terminal 54 Low Current 4.00 mA | |
| 20 | 6-23 Terminal 54 High Current 20.00 mA | |
| 21 | 6-24 Terminal 54 Low Ref./Feedb. 0.000 | |
| 22 | 6-25 Terminal 54 High Ref./Feedb. 4999.000 | |
| 23 | 20-00 Feedback 1 Source [2] Analog input 54 | |
| 24 | 20-04 Feedback 2 Conversion [0] Linear | |
| 25 | 8-01 Control Site [0] Digital and ctrl.word | |
| 26 | 8-30 Protocol [0] FC | |
| 27 | 8-31 Address [1] | |

Illustration 6.6 Closed-loop Wizard

Closed-loop wizard

| Parameter | Option | Default | Function |
|----------------------------|---|------------------|---|
| 0-01 Language | [0] English [1] Deutsch [2] Francais [3] Dansk [4] Spanish [5] Italiano [28] Bras.port | 0 | Select the language for the display. |
| 0-06 GridType | [0] 200-240 V/50 Hz/IT-grid [1] 200-240 V/50 Hz/Delta [2] 200-240 V/50 Hz [10] 380-440 V/50 Hz/IT-grid [11] 380-440 V/50 Hz/Delta [12] 380-440 V/50 Hz [20] 440-480 V/50 Hz/IT-grid [21] 440-480 V/50 Hz/Delta [22] 440-480 V/50 Hz [30] 525-600 V/50 Hz/IT-grid [31] 525-600 V/50 Hz/Delta [32] 525-600 V/50 Hz [100] 200-240 V/60 Hz/IT-grid [101] 200-240 V/60 Hz/Delta [102] 200-240 V/60 Hz [110] 380-440 V/60 Hz/IT-grid [111] 380-440 V/60 Hz/Delta [112] 380-440 V/60 Hz [120] 440-480 V/60 Hz/IT-grid [121] 440-480 V/60 Hz/Delta [122] 440-480 V/60 Hz [130] 525-600 V/60 Hz/IT-grid [131] 525-600 V/60 Hz/Delta [132] 525-600 V/60 Hz | Size related | Select the operating mode for restart upon reconnection of the frequency converter to mains voltage after power down. |
| 0-60 Main Menu Password | 0-999 | 0 | Define the password for access to the LCP. |
| 1-00 Configuration Mode | [0] Open loop [3] Closed loop | [0] Open loop | Select closed loop. |
| 1-13 Compressor Selection | [24] VZH028-R410A [25] VZH035-R410A [26] VZH044-R410A | Size related | Select the used compressor. |
| 3-02 Minimum Reference | -4999.0 - 200 Hz | 0 Hz | The minimum reference is the lowest value obtainable by summing all references. |
| 3-03 Maximum Reference | 0 - 200 Hz | 200 Hz | The maximum reference is the highest obtainable by summing all references. |
| 3-10 Preset Reference | -100 - 100 % | 0 % | Set-up a fix setpoint in preset reference [0]. |
| 3-15 Reference 1 Source | [0] No function [1] Analog in 53 [2] Analog in 54 [7] Pulse input 29 [11] Local bus reference | [1] Analog in 53 | Select the input to be used for the reference signal. |
| 3-41 Ramp 1 Ramp Up Time | 0.05-3600.0 s | 30.00 s | Ramp-up time from 0 to 1-25 Motor Nominal Speed. |
| 3-42 Ramp 1 Ramp Down Time | 0.05-3600.0 s | 30.00 s | Ramp-down time from rated motor speed to 0. |

| Parameter | Option | Default | Function |
|---|---|---------------------------|---|
| 5-12 Terminal 27 Digital Input | [0] No operation [1] Reset [2] Coast inverse [3] Coast and reset inverse [4] Quick stop inverse [5] DC-brake inverse [6] Stop inverse [7] External Interlock [8] Start [9] Latched start [10] Reversing [11] Start reversing [14] Jog [16] Preset ref bit 0 [17] Preset ref bit 1 [18] Preset ref bit 2 [19] Freeze reference [20] Speed up [22] Speed down [23] Set-up select bit 0 [34] Ramp bit 0 [52] Run permissive [53] Hand start [54] Auto start [60] Counter A (up) [61] Counter A (down) [62] Reset Counter A [63] Counter B (up) [64] Counter B (down) [65] Reset Counter B | [6] Stop inverse | Select the input function for terminal 27. |
| 5-40 Function Relay [0] Function relay | See 5-40 Function Relay | Alarm | Select the function to control output relay 1. |
| 5-40 Function Relay [1] Function relay | See 5-40 Function Relay | Drive running | Select the function to control output relay 2. |
| 6-10 Terminal 53 Low Voltage | 0-10 V | 0.07 V | Enter the voltage that corresponds to the low reference value. |
| 6-11 Terminal 53 High Voltage | 0-10 V | 10 V | Enter the voltage that corresponds to the high reference value. |
| 6-14 Terminal 53 Low Ref./Feedb. Value | -4999 - 4999 | 30 | Enter the reference value that corresponds to the voltage set in 6-10 Terminal 53 Low Voltage. |
| 6-15 Terminal 53 High Ref./Feedb. Value | -4999 - 4999 | 200 | Enter the reference value that corresponds to the voltage set in 6-11 Terminal 53 High Voltage. |
| 6-22 Terminal 54 Low Current | 0.00-20.00 mA | 4.00 mA | Enter the current that corresponds to the low reference value. |
| 6-23 Terminal 54 High Current | 0-10 V | 10 V | Enter the current that corresponds to the high reference value. |
| 6-24 Terminal 54 Low Ref./Feedb. Value | -0.00-20.00 mA | 20.00 mA | Enter the reference value that corresponds to the current set in 6-20 Terminal 54 Low Voltage. |
| 6-25 Terminal 54 High Ref./Feedb. Value | -4999 - 4999 | Size related | Enter the reference value that corresponds to the current set in 6-21 Terminal 54 High Voltage. |
| 8-01 Control Site | [0] Digital and ctrl.word [1] Digital only [2] Controlword only | [0] Digital and ctrl.word | Select if digital, bus, or a combination of both should control the frequency converter. |

| Parameter | Option | Default | Function |
|-----------------------------|--|-----------------|---|
| 8-30 Protocol | [0] FC [2] Modbus RTU | [0] FC | Select the protocol for the integrated RS-485 port. |
| 8-32 Baud Rate | [0] 2400 Baud [1] 4800 Baud [2] 9600 Baud [3] 19200 Baud [4] 38400 Baud [5] 57600 Baud [6] 76800 Baud [7] 115200 Baud | [2] 9600 Baud | Select the baud rate for the RS-485 port. |
| 20-00 Feedback 1 Source | [0] No function [1] Analog Input 53 [2] Analog Input 54 [3] Pulse input 29 [100] Bus Feedback 1 [101] Bus Feedback 2 | [0] No function | Select which input to use as the source of the feedback signal. |
| 20-01 Feedback 1 Conversion | [0] Linear [1] Square root | [0] Linear | Select how calculate the feedback. |

Table 6.6 Closed-loop Applications Set-up

Changes made

Changes Made lists all parameters changed from default settings.

- The list shows only parameters which have been changed in the current edit-setup.
- Parameters which have been reset to default values are not listed.
- The message *Empty* indicates that no parameters have been changed.

To change parameter settings

1. Press [Menu] to enter the *Quick Menu* until indicator in display is placed above *Quick Menu*.
2. Press [▲] [▼] to select wizard, closed-loop set-up, compressor set-up or changes made, then press [OK].
3. Press [▲] [▼] to browse through the parameters in the *Quick Menu*.
4. Press [OK] to select a parameter.
5. Press [▲] [▼] to change the value of a parameter setting.
6. Press [OK] to accept the change.
7. Press either [Back] twice to enter *Status*, or press [Menu] once to enter *Main Menu*.

The Main Menu accesses all parameters

1. Press [Menu] until indicator in display is placed above *Main Menu*.
2. Press [▲] [▼] to browse through the parameter groups.
3. Press [OK] to select a parameter group.

4. Press [▲] [▼] to browse through the parameters in the specific group.
5. Press [Ok] to select the parameter.
6. Press [▲] [▼] to set/change the parameter value.

6.3.4 Main Menu

[Main Menu] is used for access to and programming of all parameters. The Main Menu parameters can be accessed readily unless a password has been created via *0-60 Main Menu Password*.

For the majority of VLT® HVAC Basic Drive applications it is not necessary to access the Main Menu parameters but instead the Quick Menu provides the simplest and quickest access to the typical required parameters.

The Main Menu accesses all parameters.

1. Press [Menu] until indicator in display is placed above "Main Menu".
2. Press [▲] [▼] to browse through the parameter groups.
3. Press [OK] to select a parameter group.
4. Press [▲] [▼] to browse through the parameters in the specific group.
5. Press [OK] to select the parameter.
6. Press [▲] [▼] to set/change the parameter value.

Press [Back] to go back one level.

6.4 Quick Transfer of Parameter Settings between Multiple Frequency Converters

Once the set-up of a frequency converter is complete, Danfoss recommends to store the data in the LCP or on a PC via MCT 10 Set-up Software tool.

Data transfer from frequency converter to LCP:



Stop the motor before performing this operation.

1. Go to 0-50 LCP Copy
2. Press [OK]
3. Select [1] All to LCP
4. Press [OK]

Connect the LCP to another frequency converter and copy the parameter settings to this frequency converter as well.

Data transfer from LCP to frequency converter:



Stop the motor before performing this operation.

1. Go to 0-50 LCP Copy
2. Press [OK]
3. Select [2] All from LCP
4. Press [OK]

6.5 Read-out and Programming of Indexed Parameters

Select the parameter, press [OK], and press [▲]/[▼] to scroll through the indexed values. To change the parameter value, select the indexed value and press [OK]. Change the value by pressing [▲]/[▼]. Press [OK] to accept the new setting. Press [Cancel] to abort. Press [Back] to leave the parameter.

6.6 Initialise the Frequency Converter to Default Settings in two Ways

Recommended initialisation (via 14-22 Operation Mode)

1. Select 14-22 Operation Mode.
2. Press [OK].
3. Select [2] Initialisation and Press [OK].
4. Cut off the mains supply and wait until the display turns off.
5. Reconnect the mains supply - the frequency converter is now reset.

Except the following parameters:

- 8-30 Protocol
- 8-31 Address
- 8-32 Baud Rate
- 8-33 Parity / Stop Bits
- 8-35 Minimum Response Delay
- 8-36 Maximum Response Delay
- 8-37 Maximum Inter-char delay
- 8-70 BACnet Device Instance
- 8-72 MS/TP Max Masters
- 8-73 MS/TP Max Info Frames
- 8-74 "I am" Service
- 8-75 Intialisation Password
- 15-00 Operating hours to 15-05 Over Volt's
- 15-03 Power Up's
- 15-04 Over Temp's
- 15-05 Over Volt's
- 15-30 Alarm Log: Error Code
- 15-4* Drive identification parameters
- 1-06 Clockwise Direction

2 finger initialisation

1. Power off the frequency converter.
2. Press [OK] and [Menu].
3. Power up the frequency converter while still pressing the keys above for 10 s.
4. The frequency converter is now reset, except the following parameters:

- 15-00 Operating hours
- 15-03 Power Up's
- 15-04 Over Temp's
- 15-05 Over Volt's
- 15-4* Drive identification parameters

Initialisation of parameters is confirmed by AL80 in the display after the power cycle.

7 RS-485 Installation and Set-up

7.1 RS-485

7.1.1 Overview

RS-485 is a 2-wire bus interface compatible with multi-drop network topology, that is, nodes can be connected as a bus, or via drop cables from a common trunk line. A total of 32 nodes can be connected to one network segment. Repeaters divide network segments, see *Illustration 7.1*.




Illustration 7.1 RS-485 Bus Interface

NOTICE

Each repeater functions as a node within the segment in which it is installed. Each node connected within a given network must have a unique node address across all segments.

Terminate each segment at both ends, using either the termination switch (S801) of the frequency converters or a biased termination resistor network. Always use screened twisted pair (STP) cable for bus cabling, and follow good common installation practice.

Low-impedance ground connection of the screen at every node is important, including at high frequencies. Thus, connect a large surface of the screen to ground, for example with a cable clamp or a conductive cable gland. It may be necessary to apply potential-equalising cables to maintain the same earth potential throughout the network - particularly in installations with long cables.

To prevent impedance mismatch, always use the same type of cable throughout the entire network. When connecting a motor to the frequency converter, always use screened motor cable.

| Cable | Screened twisted pair (STP) |
|------------------------|---|
| Impedance [Ω] | 120 |
| Cable length [m] | Max. 1200 (including drop lines) Max. 500 station-to-station |

Table 7.1 Cable Specifications

7.1.2 Network Connection

Connect the frequency converter to the RS-485 network as follows (see also *Illustration 7.2*):

1. Connect signal wires to terminal 68 (P+) and terminal 69 (N-) on the main control board of the frequency converter.
2. Connect the cable screen to the cable clamps.

NOTICE

Screened, twisted-pair cables are recommended to reduce noise between conductors.




Illustration 7.2 Network Connection

7.1.3 Frequency Converter Hardware Set-up

Use the terminator dip switch on the main control board of the frequency converter to terminate the RS-485 bus.

The factory setting for the dip switch is OFF.

7.1.4 Parameter Settings for Modbus Communication

| Parameter | Function |
|-------------------------------|--|
| 8-30 Protocol | Select the application protocol to run for the RS-485 interface. |
| 8-31 Address | Set the node address. NOTICE The address range depends on the protocol selected in <i>8-30 Protocol</i> |
| 8-32 Baud Rate | Set the baud rate. NOTICE The default baud rate depends on the protocol selected in <i>8-30 Protocol</i> |
| 8-33 Parity / Stop Bits | Set the parity and number of stop bits. NOTICE The default selection depends on the protocol selected in <i>8-30 Protocol</i> |
| 8-35 Minimum Response Delay | Specify a minimum delay time between receiving a request and transmitting a response. This function is for overcoming modem turnaround delays. |
| 8-36 Maximum Response Delay | Specify a maximum delay time between transmitting a request and receiving a response. |
| 8-37 Maximum Inter-char delay | If transmission is interrupted, specify a maximum delay time between two received bytes to ensure time-out. NOTICE The default selection depends on the protocol selected in <i>8-30 Protocol</i> |


Table 7.2 Modbus Communication Parameter Settings

7.1.5 EMC Precautions

To achieve interference-free operation of the RS485 network, Danfoss recommends the following EMC precautions.

NOTICE

Observe relevant national and local regulations, for example regarding protective earth connection. To avoid coupling of high-frequency noise between the cables, the RS485 communication cable must be kept away from motor and brake resistor cables. Normally, a distance of 200 mm (8 inches) is sufficient. Maintain the greatest possible distance between the cables, especially where cables run in parallel over long distances. When crossing is unavoidable, the RS485 cable must cross motor and brake resistor cables at an angle of 90°.



| | |
|---|-------------------------|
| 1 | Fieldbus cable |
| 2 | Minimum 200 mm distance |

Illustration 7.3 Minimum Distance between Communication and Power Cables

7.2 FC Protocol Overview

7.2.1 FC Protocol Overview

The FC protocol, also referred to as FC bus or standard bus, is the Danfoss standard fieldbus. It defines an access technique according to the master-follower principle for communications via a serial bus.

One master and a maximum of 126 followers can be connected to the bus. The master selects the individual followers via an address character in the telegram. A follower itself can never transmit without first being requested to do so, and direct message transfer between the individual followers is not possible. Communications occur in the half-duplex mode.

The master function cannot be transferred to another node (single-master system).

The physical layer is RS-485, thus utilising the RS-485 port built into the frequency converter. The FC protocol supports different telegram formats:

- A short format of 8 bytes for process data
- A long format of 16 bytes that also includes a parameter channel
- A format used for texts

7.2.2 FC with Modbus RTU

The FC protocol provides access to the control word and bus reference of the frequency converter.

The control word allows the Modbus master to control several important functions of the frequency converter.

- Start
- Stop of the frequency converter in various ways:
 - Coast stop
 - Quick stop
 - DC Brake stop
 - Normal (ramp) stop
- Reset after a fault trip
- Run at various preset speeds
- Run in reverse
- Change of the active set-up
- Control of the 2 relays built into the frequency converter

The bus reference is commonly used for speed control. It is also possible to access the parameters, read their values, and where possible, write values to them. This permits a range of control options, including controlling the setpoint

of the frequency converter when its internal PI controller is used.

7.3 Network Configuration

7.3.1 Frequency Converter Set-up

Set the following parameters to enable the FC protocol for the frequency converter.

| Parameter | Setting |
|-------------------------|-----------------------------------|
| 8-30 Protocol | FC |
| 8-31 Address | 1-126 |
| 8-32 Baud Rate | 2400-115200 |
| 8-33 Parity / Stop Bits | Even parity, 1 stop bit (default) |

Table 7.3 Network Configuration Parameters

7.4 FC Protocol Message Framing Structure

7.4.1 Content of a Character (byte)

Each character transferred begins with a start bit. Then 8 data bits are transferred, corresponding to a byte. Each character is secured via a parity bit. This bit is set at "1" when it reaches parity. Parity is when there is an equal number of 1s in the 8 data bits and the parity bit in total. A stop bit completes a character, thus consisting of 11 bits in all.




Illustration 7.4 Content of a Character

7.4.2 Telegram Structure

Each telegram has the following structure:

1. Start character (STX)=02 hex
2. A byte denoting the telegram length (LGE)
3. A byte denoting the frequency converter address (ADR)

A number of data bytes (variable, depending on the type of telegram) follows.

A data control byte (BCC) completes the telegram.




Illustration 7.5 Telegram Structure

7.4.3 Telegram Length (LGE)

The telegram length is the number of data bytes plus the address byte ADR and the data control byte BCC.

| | |
|----------------------------|--------------------------|
| 4 data bytes | LGE=4+1+1=6 bytes |
| 12 data bytes | LGE=12+1+1=14 bytes |
| Telegrams containing texts | 10 ¹ +n bytes |

Table 7.4 Length of Telegrams

1) The 10 represents the fixed characters, while the "n" is variable (depending on the length of the text).

7.4.4 Frequency Converter Address (ADR)

Address format 1-126

- Bit 7=1 (address format 1-126 active)
- Bit 0-6=frequency converter address 1-126
- Bit 0-6=0 Broadcast

The follower returns the address byte unchanged to the master in the response telegram.

7.4.5 Data Control Byte (BCC)

The checksum is calculated as an XOR-function. Before the first byte in the telegram is received, the calculated checksum is 0.

7.4.6 The Data Field

The structure of data blocks depends on the type of telegram. There are 3 telegram types, and the type applies for both control telegrams (master→follower) and response telegrams (follower→master).

The 3 types of telegram are:

Process block (PCD)

The PCD is made up of a data block of 4 bytes (2 words) and contains:

- Control word and reference value (from master to follower)
- Status word and present output frequency (from follower to master)




130BA269.10

Illustration 7.6 Process Block

Parameter block

The parameter block is used to transfer parameters between master and follower. The data block is made up of 12 bytes (6 words) and also contains the process block.




130BA271.10

Illustration 7.7 Parameter Block

Text block

The text block is used to read or write texts via the data block.



130BA270.10

Illustration 7.8 Text Block

7.4.7 The PKE Field

The PKE field contains 2 subfields: Parameter command and response (AK) and Parameter number (PNU):




Illustration 7.9 PKE Field

Bits no. 12-15 transfer parameter commands from master to follower and return processed follower responses to the master.

| Parameter commands master→follower | | | | |
|------------------------------------|----|----|----|---|
| Bit no. | | | | Parameter command |
| 15 | 14 | 13 | 12 | |
| 0 | 0 | 0 | 0 | No command |
| 0 | 0 | 0 | 1 | Read parameter value |
| 0 | 0 | 1 | 0 | Write parameter value in RAM (word) |
| 0 | 0 | 1 | 1 | Write parameter value in RAM (double word) |
| 1 | 1 | 0 | 1 | Write parameter value in RAM and EEprom (double word) |
| 1 | 1 | 1 | 0 | Write parameter value in RAM and EEprom (word) |
| 1 | 1 | 1 | 1 | Read text |

Table 7.5 Parameter Commands

| Response follower→master | | | | |
|--------------------------|----|----|----|---|
| Bit no. | | | | Response |
| 15 | 14 | 13 | 12 | |
| 0 | 0 | 0 | 0 | No response |
| 0 | 0 | 0 | 1 | Parameter value transferred (word) |
| 0 | 0 | 1 | 0 | Parameter value transferred (double word) |
| 0 | 1 | 1 | 1 | Command cannot be performed |
| 1 | 1 | 1 | 1 | text transferred |

Table 7.6 Response

If the command cannot be performed, the follower sends this response:

0111 Command cannot be performed

- and issues the following fault report in the parameter value:

| Error code | FC Specification |
|------------|--------------------------------------|
| 0 | Illegal Parameter Number |
| 1 | Parameter cannot be changed. |
| 2 | Upper or lower limit exceeded |
| 3 | Subindex corrupted |
| 4 | No Array |
| 5 | Wrong Data Type |
| 6 | Not used |
| 7 | Not used |
| 9 | Description element not available |
| 11 | No parameter write access |
| 15 | No text available |
| 17 | Not while Running |
| 18 | Other error |
| 100 | |
| >100 | |
| 130 | No bus access for this parameter |
| 131 | Write to factory set-up not possible |
| 132 | No LCP access |
| 252 | Unknown viewer |
| 253 | Request not supported |
| 254 | Unknown attribute |
| 255 | No error |

Table 7.7 Follower Report

7.4.8 Parameter Number (PNU)

Bits no. 0-11 transfer parameter numbers. The function of the relevant parameter is defined in the parameter description in *chapter 6 How to Programme*.

7.4.9 Index (IND)

The index is used with the parameter number to read/write-access parameters with an index, for example, *15-30 Alarm Log: Error Code*. The index consists of 2 bytes; a low byte, and a high byte.

Only the low byte is used as an index.

7.4.10 Parameter Value (PWE)

The parameter value block consists of 2 words (4 bytes), and the value depends on the defined command (AK). The master prompts for a parameter value when the PWE block contains no value. To change a parameter value (write), write the new value in the PWE block and send from the master to the follower.

When a follower responds to a parameter request (read command), the present parameter value in the PWE block is transferred and returned to the master. If a parameter contains several data options, e.g. *0-01 Language*, select the data value by entering the value in the PWE block. Serial communication is only capable of reading parameters containing data type 9 (text string).

15-40 FC Type to *15-53 Power Card Serial Number* contain data type 9.

For example, read the unit size and mains voltage range in *15-40 FC Type*. When a text string is transferred (read), the length of the telegram is variable, and the texts are of different lengths. The telegram length is defined in the second byte of the telegram (LGE). When using text transfer, the index character indicates whether it is a read or a write command.

To read a text via the PWE block, set the parameter command (AK) to 'F' hex. The index character high-byte must be "4".

7.4.11 Data Types Supported by the Frequency Converter

Unsigned means that there is no operational sign in the telegram.

| Data types | Description |
|------------|-------------|
| 3 | Integer 16 |
| 4 | Integer 32 |
| 5 | Unsigned 8 |
| 6 | Unsigned 16 |
| 7 | Unsigned 32 |
| 9 | Text string |

Table 7.8 Data Types

7.4.12 Conversion

The various attributes of each parameter are displayed in the chapter *Parameter Lists* in the *Programming Guide*. Parameter values are transferred as whole numbers only. Conversion factors are therefore used to transfer decimals.

4-12 Motor Speed Low Limit [Hz] has a conversion factor of 0.1.

To preset the minimum frequency to 10 Hz, transfer the value 100. A conversion factor of 0.1 means that the value transferred is multiplied by 0.1. The value 100 is thus perceived as 10.0.

| Conversion index | Conversion factor |
|------------------|-------------------|
| 74 | 3600 |
| 2 | 100 |
| 1 | 10 |
| 0 | 1 |
| -1 | 0.1 |
| -2 | 0.01 |
| -3 | 0.001 |
| -4 | 0.0001 |
| -5 | 0.00001 |

Table 7.9 Conversion

7.4.13 Process Words (PCD)

The block of process words is divided into 2 blocks of 16 bits, which always occur in the defined sequence.

| PCD 1 | PCD 2 |
|---|--------------------------|
| Control telegram (master→follower control word) | Reference-value |
| Control telegram (follower→master) status word | Present output frequency |

Table 7.10 Process Words (PCD)

7.5 Examples

7.5.1 Writing a Parameter Value

Change *4-14 Motor Speed High Limit [Hz]* to 100 Hz. Write the data in EEPROM.

PKE=E19E hex - Write single word in *4-14 Motor Speed High Limit [Hz]*:

- IND=0000 hex
- PWEHIGH=0000 hex
- PWELow=03E8 hex

Data value 1000, corresponding to 100 Hz, see *chapter 7.4.12 Conversion*.

The telegram looks like this:

| | | | | | | | |
|------|---|------|---|---------------------|---|--------------------|---|
| E19E | H | 0000 | H | 0000 | H | 03E8 | H |
| PKE | | IND | | PWE _{high} | | PWE _{low} | |

Illustration 7.10 Telegram

130BA092.10

NOTICE

4-14 Motor Speed High Limit [Hz] is a single word, and the parameter command for write in EEPROM is "E". Parameter 4-14 is 19E in hexadecimal.

The response from the follower to the master is:

| | | | | | | | |
|------|---|------|---|---------------------|---|--------------------|---|
| 119E | H | 0000 | H | 0000 | H | 03E8 | H |
| PKE | | IND | | PWE _{high} | | PWE _{low} | |

Illustration 7.11 Response from Master

130BA093.10

7.5.2 Reading a Parameter Value

Read the value in 3-41 Ramp 1 Ramp Up Time

PKE=1155 hex - Read parameter value in 3-41 Ramp 1 Ramp Up Time
 IND=0000 hex
 PWE_{HIGH}=0000 hex
 PWE_{LOW}=0000 hex

| | | | | | | | |
|------|---|------|---|---------------------|---|--------------------|---|
| 1155 | H | 0000 | H | 0000 | H | 0000 | H |
| PKE | | IND | | PWE _{high} | | PWE _{low} | |

Illustration 7.12 Telegram

130BA094.10

If the value in 3-41 Ramp 1 Ramp Up Time is 10 s, the response from the follower to the master is:

| | | | | | | | |
|------|---|------|---|---------------------|---|--------------------|---|
| 1155 | H | 0000 | H | 0000 | H | 03E8 | H |
| PKE | | IND | | PWE _{high} | | PWE _{low} | |

Illustration 7.13 Response

130BA267.10

3E8 hex corresponds to 1000 decimal. The conversion index for 3-41 Ramp 1 Ramp Up Time is -2, that is, 0.01. 3-41 Ramp 1 Ramp Up Time is of the type Unsigned 32.

7.6 Modbus RTU Overview

7.6.1 Assumptions

Danfoss assumes that the installed controller supports the interfaces in this document, and strictly observes all requirements and limitations stipulated in the controller and frequency converter.

7.6.2 What the User Should Already Know

The built-in Modbus RTU (Remote Terminal Unit) is designed to communicate with any controller that supports the interfaces defined in this document. It is assumed that the user has full knowledge of the capabilities and limitations of the controller.

7.6.3 Modbus RTU Overview

Regardless of the type of physical communication networks, the Modbus RTU Overview describes the process a controller uses to request access to another device. This process includes how the Modbus RTU responds to requests from another device, and how errors are detected and reported. It also establishes a common format for the layout and contents of message fields. During communications over a Modbus RTU network, the protocol determines:

- How each controller learns its device address
- Recognises a message addressed to it
- Determines which actions to take
- Extracts any data or other information contained in the message

If a reply is required, the controller constructs the reply message and sends it.

Controllers communicate using a master-follower technique in which only the master can initiate transactions (called queries). Followers respond by supplying the requested data to the master, or by taking the action requested in the query.

The master can address individual followers, or initiate a broadcast message to all followers. Followers return a response to queries that are addressed to them individually. No responses are returned to broadcast queries from the master. The Modbus RTU protocol establishes the format for the master's query by providing the device (or broadcast) address, a function code defining the requested action, any data to be sent, and an error-checking field. The follower's response message is also constructed using Modbus protocol. It contains fields confirming the action taken, any data to be returned, and an error-checking field. If an error occurs in receipt of the message, or if the follower is unable to perform the

requested action, the follower constructs an error message, and send it in response, or a time-out occurs.

7.6.4 Frequency Converter with Modbus RTU

The frequency converter communicates in Modbus RTU format over the built-in RS-485 interface. Modbus RTU provides access to the control word and bus reference of the frequency converter.

The control word allows the modbus master to control several important functions of the frequency converter:

- Start
- Stop of the frequency converter in various ways:
 - Coast stop
 - Quick stop
 - DC Brake stop
 - Normal (ramp) stop
- Reset after a fault trip
- Run at a variety of preset speeds
- Run in reverse
- Change the active set-up
- Control the frequency converter's built-in relay

The bus reference is commonly used for speed control. It is also possible to access the parameters, read their values, and where possible, write values to them. This permits a range of control options, including controlling the setpoint of the frequency converter when its internal PI controller is used.

7.7 Network Configuration

To enable Modbus RTU on the frequency converter, set the following parameters:

| Parameter | Setting |
|-------------------------|-----------------------------------|
| 8-30 Protocol | Modbus RTU |
| 8-31 Address | 1-247 |
| 8-32 Baud Rate | 2400-115200 |
| 8-33 Parity / Stop Bits | Even parity, 1 stop bit (default) |

Table 7.11 Network Configuration

7.8 Modbus RTU Message Framing Structure

7.8.1 Frequency Converter with Modbus RTU

The controllers are set up to communicate on the Modbus network using RTU (Remote Terminal Unit) mode, with each byte in a message containing 2 4-bit hexadecimal characters. The format for each byte is shown in *Table 7.12*.

| Start bit | Data byte | | | | | | Stop/parity | Stop |
|-----------|-----------|--|--|--|--|--|-------------|------|
| | | | | | | | | |

Table 7.12 Format for Each Byte

| | |
|-------------------|--|
| Coding System | 8-bit binary, hexadecimal 0-9, A-F. 2 hexadecimal characters contained in each 8-bit field of the message |
| Bits Per Byte | 1 start bit 8 data bits, least significant bit sent first 1 bit for even/odd parity; no bit for no parity 1 stop bit if parity is used; 2 bits if no parity |
| Error Check Field | Cyclical Redundancy Check (CRC) |

7.8.2 Modbus RTU Message Structure

The transmitting device places a Modbus RTU message into a frame with a known beginning and ending point. This allows receiving devices to begin at the start of the message, read the address portion, determine which device is addressed (or all devices, if the message is broadcast), and to recognise when the message is completed. Partial messages are detected and errors set as a result. Characters for transmission must be in hexadecimal 00 to FF format in each field. The frequency converter continuously monitors the network bus, also during 'silent' intervals. When the first field (the address field) is received, each frequency converter or device decodes it to determine which device is being addressed. Modbus RTU messages addressed to zero are broadcast messages. No response is permitted for broadcast messages. A typical message frame is shown in *Table 7.13*.

| Start | Address | Function | Data | CRC check | End |
|-------------|---------|----------|------------|-----------|-------------|
| T1-T2-T3-T4 | 8 bits | 8 bits | N x 8 bits | 16 bits | T1-T2-T3-T4 |

Table 7.13 Typical Modbus RTU Message Structure

7.8.3 Start/Stop Field

Messages start with a silent period of at least 3.5 character intervals. This is implemented as a multiple of character intervals at the selected network baud rate (shown as Start T1-T2-T3-T4). The first field to be transmitted is the device address. Following the last transmitted character, a similar period of at least 3.5 character intervals marks the end of the message. A new message can begin after this period. The entire message frame must be transmitted as a continuous stream. If a silent period of more than 1.5 character intervals occurs before completion of the frame, the receiving device flushes the incomplete message and assumes that the next byte is the address field of a new message. Similarly, if a new message begins before 3.5 character intervals after a previous message, the receiving device considers it a continuation of the previous message. This causes a time-out (no response from the follower), since the value in the final CRC field is not valid for the combined messages.

7.8.4 Address Field

The address field of a message frame contains 8 bits. Valid follower device addresses are in the range of 0-247 decimal. The individual follower devices are assigned addresses in the range of 1-247. (0 is reserved for broadcast mode, which all followers recognise.) A master addresses a follower by placing the follower address in the address field of the message. When the follower sends its response, it places its own address in this address field to let the master know which follower is responding.

7.8.5 Function Field

The function field of a message frame contains 8 bits. Valid codes are in the range of 1-FF. Function fields are used to send messages between master and follower. When a message is sent from a master to a follower device, the function code field tells the follower what kind of action to perform. When the follower responds to the master, it uses the function code field to indicate either a normal (error-free) response, or that some kind of error occurred (called an exception response). For a normal response, the follower simply echoes the original function code. For an exception response, the follower returns a code that is equivalent to the original function code with its most significant bit set to logic 1. In addition, the follower places a unique code into the data field of the response message. This tells the master what kind of error occurred, or the reason for the exception. Also refer to *chapter 7.8.10 Function Codes Supported by Modbus RTU* and *chapter 7.8.11 Modbus Exception Codes*

7.8.6 Data Field

The data field is constructed using sets of 2 hexadecimal digits, in the range of 00 to FF hexadecimal. These are made up of one RTU character. The data field of messages sent from a master to follower device contains additional information which the follower must use to take the action defined by the function code. This can include items such as coil or register addresses, the quantity of items to be handled, and the count of actual data bytes in the field.

7.8.7 CRC Check Field

Messages include an error-checking field, operating based on a Cyclical Redundancy Check (CRC) method. The CRC field checks the contents of the entire message. It is applied regardless of any parity check method used for the individual characters of the message. The CRC value is calculated by the transmitting device, which appends the CRC as the last field in the message. The receiving device recalculates a CRC during receipt of the message and compares the calculated value to the actual value received in the CRC field. If the 2 values are unequal, a bus time-out results. The error-checking field contains a 16-bit binary value implemented as 2 8-bit bytes. When this is done, the low-order byte of the field is appended first, followed by the high-order byte. The CRC high-order byte is the last byte sent in the message.

7.8.8 Coil Register Addressing

In Modbus, all data are organised in coils and holding registers. Coils hold a single bit, whereas holding registers hold a 2-byte word (that is 16 bits). All data addresses in Modbus messages are referenced to zero. The first occurrence of a data item is addressed as item number zero. For example: The coil known as 'coil 1' in a programmable controller is addressed as coil 0000 in the data address field of a Modbus message. Coil 127 decimal is addressed as coil 007Ehex (126 decimal). Holding register 40001 is addressed as register 0000 in the data address field of the message. The function code field already specifies a 'holding register' operation. Therefore, the '4XXXX' reference is implicit. Holding register 40108 is addressed as register 006Bhex (107 decimal).

| Coil Number | Description | Signal Direction |
|-------------|---|--------------------|
| 1-16 | Frequency converter control word (see Table 7.15) | Master to follower |
| 17-32 | Frequency converter speed or set-point reference Range 0x0-0xFFFF (-200% ... ~200%) | Master to follower |
| 33-48 | Frequency converter status word (see Table 7.16) | Follower to master |
| 49-64 | Open loop mode: Frequency converter output frequency Closed loop mode: Frequency converter feedback signal | Follower to master |
| 65 | Parameter write control (master to follower) | Master to follower |
| | 0 Parameter changes are written = to the RAM of the frequency converter | |
| | 1 Parameter changes are written = to the RAM and EEPROM of the frequency converter. | |
| 66-65536 | Reserved | |

Table 7.14 Coil Register

| Coil | 0 | 1 |
|------|----------------------|-----------------|
| 01 | Preset reference LSB | |
| 02 | Preset reference MSB | |
| 03 | DC brake | No DC brake |
| 04 | Coast stop | No coast stop |
| 05 | Quick stop | No quick stop |
| 06 | Freeze freq. | No freeze freq. |
| 07 | Ramp stop | Start |
| 08 | No reset | Reset |
| 09 | No jog | Jog |
| 10 | Ramp 1 | Ramp 2 |
| 11 | Data not valid | Data valid |
| 12 | Relay 1 off | Relay 1 on |
| 13 | Relay 2 off | Relay 2 on |
| 14 | Set up LSB | |
| 15 | | |
| 16 | No reversing | Reversing |

Table 7.15 Frequency Converter Control Word (FC Profile)

| Coil | 0 | 1 |
|------|-------------------------------|---------------------------|
| 33 | Control not ready | Control ready |
| 34 | Frequency converter not ready | Frequency converter ready |
| 35 | Coasting stop | Safety closed |
| 36 | No alarm | Alarm |
| 37 | Not used | Not used |
| 38 | Not used | Not used |
| 39 | Not used | Not used |
| 40 | No warning | Warning |
| 41 | Not at reference | At reference |
| 42 | Hand mode | Auto mode |
| 43 | Out of freq. range | In frequency range |
| 44 | Stopped | Running |
| 45 | Not used | Not used |
| 46 | No voltage warning | Voltage warning |
| 47 | Not in current limit | Current limit |
| 48 | No thermal warning | Thermal warning |

Table 7.16 Frequency Converter Status Word (FC Profile)

| Bus address | Bus register ¹⁾ | PLC Register | Content | Access | Description |
|-------------|----------------------------|--------------|---------------------|-------------------------------|---|
| 0 | 1 | 40001 | Reserved | | Reserved for Legacy Drives VLT 5000 and VLT 2800 |
| 1 | 2 | 40002 | Reserved | | Reserved for Legacy Drives VLT 5000 and VLT 2800 |
| 2 | 3 | 40003 | Reserved | | Reserved for Legacy Drives VLT 5000 and VLT 2800 |
| 3 | 4 | 40004 | Free | | |
| 4 | 5 | 40005 | Free | | |
| 5 | 6 | 40006 | Modbus conf | Read/Write | TCP only. Reserved for Modbus TCP (p12-28 and 12-29 - store in Eeprom etc.) |
| 6 | 7 | 40007 | Last error code | Read only | Error code received from parameter database, refer to WHAT 38295 for details |
| 7 | 8 | 40008 | Last error register | Read only | Address of register with which last error occurred, refer to WHAT 38296 for details |
| 8 | 9 | 40009 | Index pointer | Read/Write | Sub index of parameter to be accessed. Refer to WHAT 38297 for details |
| 9 | 10 | 40010 | FC par. 0-01 | Dependent on parameter access | Parameter 0-01 (Modbus Register=10 parameter number 20 bytes space reserved pr parameter in Modbus Map) |
| 19 | 20 | 40020 | FC par. 0-02 | Dependent on parameter access | Parameter 0-02 20 bytes space reserved pr parameter in Modbus Map |
| 29 | 30 | 40030 | FC par. xx-xx | Dependent on parameter access | Parameter 0-03 20 bytes space reserved pr parameter in Modbus Map |

Table 7.17 Adress/Registers

1) Value written in Modbus RTU telegram must be one or less than register number. E.g. Read Modbus Register 1 by writing value 0 in telegram.

7.8.9 How to Control the Frequency Converter

This section describes codes which can be used in the function and data fields of a Modbus RTU message.

7.8.10 Function Codes Supported by Modbus RTU

Modbus RTU supports use of the following function codes in the function field of a message.

| Function | Function code (hex) |
|--------------------------|---------------------|
| Read coils | 1 |
| Read holding registers | 3 |
| Write single coil | 5 |
| Write single register | 6 |
| Write multiple coils | F |
| Write multiple registers | 10 |
| Get comm. event counter | B |
| Report follower ID | 11 |

Table 7.18 Function Codes

| Function | Function Code | Sub-function code | Sub-function |
|-------------|---------------|-------------------|--|
| Diagnostics | 8 | 1 | Restart communication |
| | | 2 | Return diagnostic register |
| | | 10 | Clear counters and diagnostic register |
| | | 11 | Return bus message count |
| | | 12 | Return bus communication error count |
| | | 13 | Return follower error count |
| | | 14 | Return follower message count |

Table 7.19 Function Codes

7.8.11 Modbus Exception Codes

For a full explanation of the structure of an exception code response, refer to *chapter 7.8.5 Function Field*.

| Code | Name | Meaning |
|------|-------------------------|--|
| 1 | Illegal function | The function code received in the query is not an allowable action for the server (or follower). This may be because the function code is only applicable to newer devices, and was not implemented in the unit selected. It could also indicate that the server (or follower) is in the wrong state to process a request of this type, for example because it is not configured and is being asked to return register values. |
| 2 | Illegal data address | The data address received in the query is not an allowable address for the server (or follower). More specifically, the combination of reference number and transfer length is invalid. For a controller with 100 registers, a request with offset 96 and length 4 would succeed, a request with offset 96 and length 5 generates exception 02. |
| 3 | Illegal data value | A value contained in the query data field is not an allowable value for server (or follower). This indicates a fault in the structure of the remainder of a complex request, such as that the implied length is incorrect. It specifically does NOT mean that a data item submitted for storage in a register has a value outside the expectation of the application program, since the Modbus protocol is unaware of the significance of any particular value of any particular register. |
| 4 | Follower device failure | An unrecoverable error occurred while the server (or follower) was attempting to perform the requested action. |

Table 7.20 Modbus Exception Codes

7.9 How to Access Parameters

7.9.1 Parameter Handling

The PNU (Parameter Number) is translated from the register address contained in the Modbus read or write message. The parameter number is translated to Modbus as (10 x parameter number) DECIMAL. Example: Reading 3-12 *Catch up/slow Down Value* (16bit): The holding register 3120 holds the parameters value. A value of 1352 (Decimal), means that the parameter is set to 12.52%

Reading 3-14 *Preset Relative Reference* (32bit): The holding registers 3410 & 3411 holds the parameters value. A value of 11300 (Decimal), means that the parameter is set to 1113.00.

For information on the parameters, size and converting index, consult the product relevant programming guide.

7.9.2 Storage of Data

The coil 65 decimal determines whether data written to the frequency converter are stored in EEPROM and RAM (coil 65=1) or only in RAM (coil 65= 0).

7.9.3 IND (Index)

Some parameters in the frequency converter are array parameters e.g. 3-10 *Preset Reference*. Since the Modbus does not support arrays in the holding registers, the frequency converter has reserved the holding register 9 as pointer to the array. Before reading or writing an array parameter, set the holding register 9. Setting holding register to the value of 2 causes all following read/write to array parameters to be to the index 2.

7.9.4 Text Blocks

Parameters stored as text strings are accessed in the same way as the other parameters. The maximum text block size is 20 characters. If a read request for a parameter is for more characters than the parameter stores, the response is truncated. If the read request for a parameter is for fewer characters than the parameter stores, the response is space filled.

7.9.5 Conversion Factor

A parameter value can only be transferred as a whole number. Use a conversion factor to transfer decimals.

7.9.6 Parameter Values

Standard data types

Standard data types are int 16, int 32, uint 8, uint 16 and uint 32. They are stored as 4x registers (40001–4FFFF). The parameters are read using function 03hex "Read Holding Registers." Parameters are written using the function 6hex "Preset Single Register" for 1 register (16 bits), and the function 10 hex "Preset Multiple Registers" for 2 registers (32 bits). Readable sizes range from 1 register (16 bits) up to 10 registers (20 characters).

Non-standard data types

Non-standard data types are text strings and are stored as 4x registers (40001–4FFFF). The parameters are read using function 03hex "Read Holding Registers" and written using

function 10hex "Preset Multiple Registers." Readable sizes range from 1 register (2 characters) up to 10 registers (20 characters).

7.10 Examples

The following examples illustrate various Modbus RTU commands.

7.10.1 Read Coil Status (01 hex)

Description

This function reads the ON/OFF status of discrete outputs (coils) in the frequency converter. Broadcast is never supported for reads.

Query

The query message specifies the starting coil and quantity of coils to be read. Coil addresses start at zero, that is, coil 33 is addressed as 32.

Example of a request to read coils 33-48 (status word) from follower device 01.

| Field Name | Example (hex) |
|---------------------|----------------------------------|
| Follower Address | 01 (frequency converter address) |
| Function | 01 (read coils) |
| Starting Address HI | 00 |
| Starting Address LO | 20 (32 decimals) Coil 33 |
| No. of Points HI | 00 |
| No. of Points LO | 10 (16 decimals) |
| Error Check (CRC) | - |

Table 7.21 Query

Response

The coil status in the response message is packed as one coil per bit of the data field. Status is indicated as: 1=ON; 0=OFF. The LSB of the first data byte contains the coil addressed in the query. The other coils follow toward the high order end of this byte, and from 'low-order to high-order' in subsequent bytes.

If the returned coil quantity is not a multiple of 8, the remaining bits in the final data byte is padded with zeros (toward the high order end of the byte). The byte count field specifies the number of complete bytes of data.

| Field Name | Example (hex) |
|--------------------|----------------------------------|
| Follower Address | 01 (frequency converter address) |
| Function | 01 (read coils) |
| Byte Count | 02 (2 bytes of data) |
| Data (Coils 40-33) | 07 |
| Data (Coils 48-41) | 06 (STW=0607hex) |
| Error Check (CRC) | - |

Table 7.22 Response

NOTICE

Coils and registers are addressed explicitly with an offset of -1 in Modbus.

I.e. Coil 33 is addressed as Coil 32.

7.10.2 Force/Write Single Coil (05 hex)

Description

This function forces the coil to either ON or OFF. When broadcast, the function forces the same coil references in all attached followers.

Query

The query message specifies the coil 65 (parameter write control) to be forced. Coil addresses start at zero, that is, coil 65 is addressed as 64. Force Data=00 00hex (OFF) or FF 00hex (ON).

| Field Name | Example (hex) |
|-------------------|----------------------------------|
| Follower Address | 01 (Frequency converter address) |
| Function | 05 (write single coil) |
| Coil Address HI | 00 |
| Coil Address LO | 40 (64 decimal) Coil 65 |
| Force Data HI | FF |
| Force Data LO | 00 (FF 00=ON) |
| Error Check (CRC) | - |

Table 7.23 Query

Response

The normal response is an echo of the query, returned after the coil state has been forced.

| Field Name | Example (hex) |
|----------------------|---------------|
| Follower Address | 01 |
| Function | 05 |
| Force Data HI | FF |
| Force Data LO | 00 |
| Quantity of Coils HI | 00 |
| Quantity of Coils LO | 01 |
| Error Check (CRC) | - |

Table 7.24 Response

7.10.3 Force/Write Multiple Coils (0F hex)

Description

This function forces each coil in a sequence of coils to either ON or OFF. When broadcasting the function forces the same coil references in all attached followers.

Query

The query message specifies the coils 17 to 32 (speed set-point) to be forced.

| Field Name | Example (hex) |
|-------------------------------|----------------------------------|
| Follower Address | 01 (frequency converter address) |
| Function | 0F (write multiple coils) |
| Coil Address HI | 00 |
| Coil Address LO | 10 (coil address 17) |
| Quantity of Coils HI | 00 |
| Quantity of Coils LO | 10 (16 coils) |
| Byte Count | 02 |
| Force Data HI (Coils 8-1) | 20 |
| Force Data LO (Coils 16-9) | 00 (ref.=2000 hex) |
| Error Check (CRC) | - |

Table 7.25 Query

Response

The normal response returns the follower address, function code, starting address, and quantity of coils forced.

| Field Name | Example (hex) |
|----------------------|----------------------------------|
| Follower Address | 01 (frequency converter address) |
| Function | 0F (write multiple coils) |
| Coil Address HI | 00 |
| Coil Address LO | 10 (coil address 17) |
| Quantity of Coils HI | 00 |
| Quantity of Coils LO | 10 (16 coils) |
| Error Check (CRC) | - |

Table 7.26 Response

7.10.4 Read Holding Registers (03 hex)**Description**

This function reads the contents of holding registers in the follower.

Query

The query message specifies the starting register and quantity of registers to be read. Register addresses start at zero, that is, registers 1-4 are addressed as 0-3.

Example: Read 3-03 *Maximum Reference*, register 03030.

| Field Name | Example (hex) |
|---------------------|--|
| Follower Address | 01 |
| Function | 03 (read holding registers) |
| Starting Address HI | 0B (Register address 3029) |
| Starting Address LO | D5 (Register address 3029) |
| No. of Points HI | 00 |
| No. of Points LO | 02 - (3-03 <i>Maximum Reference</i> is 32 bits long, i.e. 2 registers) |
| Error Check (CRC) | - |

Table 7.27 Query

Response

The register data in the response message are packed as 2 bytes per register, with the binary contents right justified within each byte. For each register, the first byte contains the high-order bits and the second contains the low-order bits.

Example: hex 000088B8=35.000=35 Hz.

| Field Name | Example (hex) |
|-------------------------|---------------|
| Follower Address | 01 |
| Function | 03 |
| Byte Count | 04 |
| Data HI (Register 3030) | 00 |
| Data LO (Register 3030) | 16 |
| Data HI (Register 3031) | E3 |
| Data LO (Register 3031) | 60 |
| Error Check (CRC) | - |

Table 7.28 Response

7.10.5 Preset Single Register (06 hex)**Description**

This function presets a value into a single holding register.

Query

The query message specifies the register reference to be preset. Register addresses start at zero, that is, register 1 is addressed as 0.

Example: Write to 1-00 *Configuration Mode*, register 1000.

| Field Name | Example (hex) |
|---------------------|---------------------------|
| Follower Address | 01 |
| Function | 06 |
| Register Address HI | 03 (Register address 999) |
| Register Address LO | E7 (Register address 999) |
| Preset Data HI | 00 |
| Preset Data LO | 01 |
| Error Check (CRC) | - |

Table 7.29 Query

Response

The normal response is an echo of the query, returned after the register contents have been passed.

| Field Name | Example (hex) |
|---------------------|---------------|
| Follower Address | 01 |
| Function | 06 |
| Register Address HI | 03 |
| Register Address LO | E7 |
| Preset Data HI | 00 |
| Preset Data LO | 01 |
| Error Check (CRC) | - |

Table 7.30 Response

7.10.6 Preset Multiple Registers (10 hex)

Description

This function presets values into a sequence of holding registers.

Query

The query message specifies the register references to be preset. Register addresses start at zero, that is, register 1 is addressed as 0. Example of a request to preset 2 registers (set 1-24 Motor Current to 738 (7.38 A)):

| Field Name | Example (hex) |
|-------------------------------------|---------------|
| Follower Address | 01 |
| Function | 10 |
| Starting Address HI | 04 |
| Starting Address LO | 07 |
| No. of Registers HI | 00 |
| No. of registers LO | 02 |
| Byte Count | 04 |
| Write Data HI (Register 4: 1049) | 00 |
| Write Data LO (Register 4: 1049) | 00 |
| Write Data HI (Register 4: 1050) | 02 |
| Write Data LO (Register 4: 1050) | E2 |
| Error Check (CRC) | - |

Table 7.31 Query

Response

The normal response returns the follower address, function code, starting address, and quantity of registers preset.

| Field Name | Example (hex) |
|---------------------|---------------|
| Follower Address | 01 |
| Function | 10 |
| Starting Address HI | 04 |
| Starting Address LO | 19 |
| No. of Registers HI | 00 |
| No. of registers LO | 02 |
| Error Check (CRC) | - |

Table 7.32 Response

7.11 Danfoss FC Control Profile

7.11.1 Control Word According to FC Profile (8-10 Protocol = FC profile)




Illustration 7.14 Control Word According to FC Profile

| Bit | Bit value=0 | Bit value=1 |
|-----|-----------------------|------------------------|
| 00 | Reference value | external selection lsb |
| 01 | Reference value | external selection msb |
| 02 | DC brake | Ramp |
| 03 | Coasting | No coasting |
| 04 | Quick stop | Ramp |
| 05 | Hold output frequency | use ramp |
| 06 | Ramp stop | Start |
| 07 | No function | Reset |
| 08 | No function | Jog |
| 09 | Ramp 1 | Ramp 2 |
| 10 | Data invalid | Data valid |
| 11 | Relay 01 open | Relay 01 active |
| 12 | Relay 02 open | Relay 02 active |
| 13 | Parameter set-up | selection lsb |
| 15 | No function | Reverse |

Table 7.33 Control Word According to FC Profile

Explanation of the control bits

Bits 00/01

Bits 00 and 01 are used to select between the 4 reference values, which are pre-programmed in 3-10 Preset Reference according to the Table 7.34.

| Programmed ref. value | Parameter | Bit 01 | Bit 00 |
|-----------------------|---------------------------|--------|--------|
| 1 | 3-10 Preset Reference [0] | 0 | 0 |
| 2 | 3-10 Preset Reference [1] | 0 | 1 |
| 3 | 3-10 Preset Reference [2] | 1 | 0 |
| 4 | 3-10 Preset Reference [3] | 1 | 1 |

Table 7.34 Control Bits

NOTICE

Make a selection in 8-56 Preset Reference Select to define how Bit 00/01 gates with the corresponding function on the digital inputs.

Bit 02, DC brake

Bit 02='0': leads to DC braking and stop. Set braking current and duration in 2-01 DC Brake Current and 2-02 DC Braking Time.

Bit 02='1' leads to ramping.

Bit 03, Coasting

Bit 03='0': The frequency converter immediately "lets go" of the compressor, (the output transistors are "shut off") and it coasts to a standstill.

Bit 03='1': The frequency converter starts the compressor if the other starting conditions are met.

Make a selection in 8-50 Coasting Select to define how Bit 03 gates with the corresponding function on a digital input.

Bit 04, Quick stop

Bit 04='0': Makes the compressor speed ramp down to stop (set in 3-81 Quick Stop Ramp Time).

Bit 05, Hold output frequency

Bit 05='0': The present output frequency (in Hz) freezes. Change the frozen output frequency only with the digital inputs (5-10 Terminal 18 Digital Input to 5-13 Terminal 29 Digital Input) programmed to Speed up=21 and Slow down=22.

NOTICE

If Freeze output is active, the frequency converter can only be stopped by the following:

- Bit 03 Coasting stop
- Bit 02 DC braking
- Digital input (5-10 Terminal 18 Digital Input to 5-13 Terminal 29 Digital Input) programmed to DC braking=5, Coasting stop=2, or Reset and coasting stop=3.

Bit 06, Ramp stop/start

Bit 06='0': Causes a stop and makes the compressor speed ramp down to stop via the selected ramp down parameter.

Bit 06='1': Permits the Frequency converter to start the compressor, if the other starting conditions are met.

Make a selection in 8-53 Start Select to define how Bit 06 Ramp stop/start gates with the corresponding function on a digital input.

Bit 07, Reset

Bit 07='0': No reset.

Bit 07='1': Resets a trip. Reset is activated on the signal's leading edge, that is, when changing from logic '0' to logic '1'.

Bit 08, Jog

Bit 08='1': The output frequency is determined by 3-11 Jog Speed [Hz].

Bit 09, Selection of ramp 1/2

Bit 09='0': Ramp 1 is active (3-41 Ramp 1 Ramp Up Time to 3-42 Ramp 1 Ramp Down Time).

Bit 09='1': Ramp 2 (3-51 Ramp 2 Ramp Up Time to 3-52 Ramp 2 Ramp Down Time) is active.

Bit 10, Data not valid/Data valid

Tell the frequency converter whether to use or ignore the control word.

Bit 10='0': The control word is ignored.

Bit 10='1': The control word is used. This function is relevant because the telegram always contains the control word, regardless of the telegram type. Turn off the control word if not wanting to use it when updating or reading parameters.

Bit 11, Relay 01

Bit 11='0': Relay not activated.

Bit 11='1': Relay 01 activated provided that Control word bit 11=36 is chosen in 5-40 Function Relay.

Bit 12, Relay 02

Bit 12='0': Relay 02 is not activated.

Bit 12='1': Relay 02 is activated provided that Control word bit 12=37 is chosen in 5-40 Function Relay.

Bit 13, Selection of set-up

Use bit 13 to select from the 2 menu set-ups according to Table 7.35.

| Set-up | Bit 13 |
|--------|--------|
| 1 | 0 |
| 2 | 1 |

The function is only possible when Multi Set-Ups=9 is selected in 0-10 Active Set-up.

Make a selection in 8-55 Set-up Select to define how Bit 13 gates with the corresponding function on the digital inputs.

Bit 15 Reverse

Bit 15='0': No reversing.

Bit 15='1': Reversing. In the default setting, reversing is set to digital in 8-54 Reversing Select. Bit 15 causes reversing only when Serial communication, Logic or Logic and is selected.

7.11.2 Status Word According to FC Profile (STW) (8-30 Protocol = FC profile)




Illustration 7.15 Status Word

| Bit | Bit=0 | Bit=1 |
|-----|------------------------|---------------------|
| 00 | Control not ready | Control ready |
| 01 | Drive not ready | Drive ready |
| 02 | Coasting | Enable |
| 03 | No error | Trip |
| 04 | No error | Error (no trip) |
| 05 | Reserved | - |
| 06 | No error | Triplock |
| 07 | No warning | Warning |
| 08 | Speed≠reference | Speed=reference |
| 09 | Local operation | Bus control |
| 10 | Out of frequency limit | Frequency limit OK |
| 11 | No operation | In operation |
| 12 | Drive OK | Stopped, auto start |
| 13 | Voltage OK | Voltage exceeded |
| 14 | Torque OK | Torque exceeded |
| 15 | Timer OK | Timer exceeded |

Table 7.35 Status Word According to FC Profile

Explanation of the status bits

Bit 00, Control not ready/ready

Bit 00=’0’: The frequency converter trips.
 Bit 00=’1’: The frequency converter controls are ready but the power component does not necessarily receive any power supply (in case of external 24 V supply to controls).

Bit 01, Drive ready

Bit 01=’0’: The frequency converter is not ready.
 Bit 01=’1’: The frequency converter is ready for operation but the coasting command is active via the digital inputs or via serial communication.

Bit 02, Coasting stop

Bit 02=’0’: The frequency converter releases the compressor.
 Bit 02=’1’: The frequency converter starts the compressor with a start command.

Bit 03, No error/trip

Bit 03=’0’ : The frequency converter is not in fault mode.
 Bit 03=’1’: The frequency converter trips. To re-establish operation, press [Reset].

Bit 04, No error/error (no trip)

Bit 04=’0’: The frequency converter is not in fault mode.
 Bit 04=’1’: The frequency converter shows an error but does not trip.

Bit 05, Not used

Bit 05 is not used in the status word.

Bit 06, No error / triplock

Bit 06=’0’: The frequency converter is not in fault mode. Bit 06=’1’: The frequency converter is tripped and locked.

Bit 07, No warning/warning

Bit 07=’0’: There are no warnings.
 Bit 07=’1’: A warning has occurred.

Bit 08, Speed≠reference/speed=reference

Bit 08=’0’: The compressor is running but the present speed is different from the preset speed reference. It might for example, be the case when the speed ramps up/down during start/stop.
 Bit 08=’1’: The compressor speed matches the preset speed reference.

Bit 09, Local operation/bus control

Bit 09=’0’: [Off/Reset] is activate on the control unit or *Local control* in 3-13 Reference Site is selected. It is not possible to control the frequency converter via serial communication.
 Bit 09=’1’ It is possible to control the frequency converter via the fieldbus/serial communication.

Bit 10, Out of frequency limit

Bit 10=’0’: The output frequency has reached the value in 4-12 Motor Speed Low Limit [Hz] or 4-14 Motor Speed High Limit [Hz].
 Bit 10=’1’’: The output frequency is within the defined limits.

Bit 11, No operation/in operation

Bit 11=’0’: The compressor is not running.
 Bit 11=’1’: The coasting has a start signal or the output frequency is greater than 0 Hz.

Bit 12, Drive OK/stopped, autostart

Bit 12=’0’: There is no temporary over temperature on the inverter.
 Bit 12=’1’: The inverter stops because of over temperature but the unit does not trip and resumes operation once the over temperature stops.

Bit 13, Voltage OK/limit exceeded

Bit 13=’0’: There are no voltage warnings.
 Bit 13=’1’: The DC voltage in the frequency converter’s intermediate circuit is too low or too high.

Bit 14, Torque OK/limit exceeded

Bit 14=’0’: The compressor current is lower than the torque limit selected in 4-18 Current Limit.
 Bit 14=’1’: The torque limit in 4-18 Current Limit is exceeded.

Bit 15, Timer OK/limit exceeded

Bit 15='1': One of the timers exceeds 100%.

Bit 15='0': The timers for compressor thermal protection and thermal protection are not exceeded 100%.

7.11.3 Bus Speed Reference Value

Speed reference value is transmitted to the frequency converter in a relative value in %. The value is transmitted in the form of a 16-bit word; in integers (0-32767) the value 16384 (4000 hex) corresponds to 100%. Negative figures are formatted by means of 2's complement. The actual output frequency (MAV) is scaled in the same way as the bus reference.




Illustration 7.16 Actual Output Frequency (MAV)

The reference and MAV are scaled as follows:




Illustration 7.17 Reference and MAV

8 General Specifications

8.1 Mains Supply Specifications

8.1.1 Mains Supply 3x200-240 V AC

| Frequency converter | 4 TR/VZH028 | 5 TR/VZH035 | 6.5 TR/VZH044 |
|--|---------------|---------------|---------------|
| Typical shaft output [kW] | 6.0 | 7.5 | 10 |
| IP20 enclosure protection | H4 | H4 | H5 |
| Maximum cable size in terminals (mains, compressor) [mm ² /AWG] | 16/6 | 16/6 | 16/6 |
| Output current | | | |
| Continuous (3x200-240 V) [A] | 20.7 | 25.9 | 33.7 |
| Intermittent (3x200-240 V) [A] | - | - | 37.1 |
| Maximum input current | | | |
| Continuous 3x200-240 V) [A] | 23.0 | 28.3 | 37.0 |
| Intermittent (3x200-240 V) [A] | - | - | 41.5 |
| Maximum mains fuses, see <i>Table 5.8</i> | | | |
| Estimated power loss [W], Best case/typical ¹⁾ | 182/ 204 | 229/ 268 | 369/ 386 |
| Weight enclosure protection P20 [kg] | 7.9 | 7.9 | 9.5 |
| Efficiency [%], best case/ typical ¹⁾ | 97.3/ 97.0 | 98.5/ 97.1 | 97.2/ 97.1 |

Table 8.1 3x200-240 V AC

1) At rated load conditions

8.1.2 Mains Supply 3x380-480 V AC

| Frequency converter | 4 TR/VZH028 | 5 TR/VZH035 | 6.5 TR/VZH044 |
|--|-------------|-------------|---------------|
| Typical shaft output [kW] | 6.0 | 7.5 | 10 |
| IP20 enclosure protection | H3 | H3 | H4 |
| Maximum cable size in terminals (mains, compressor) [mm ² /AWG] | 4/10 | 4/10 | 16/6 |
| Output current | | | |
| Continuous (3x380-440 V) [A] | 11.6 | 14.3 | 16.4 |
| Intermittent (3x380-440 V) [A] | | | 18.0 |
| Continuous (3x440-480 V) [A] | 9.8 | 12.3 | 15.5 |
| Intermittent (3x440-480 V) [A] | | | 17.0 |
| Maximum input current | | | |
| Continuous (3x380-440 V) [A] | 12.7 | 15.1 | 18.0 |
| Intermittent (3x380-440 V) [A] | | | 19.8 |
| Continuous (3x440-480 V) [A] | 10.8 | 12.6 | 17.0 |
| Intermittent (3x440-480 V) [A] | | | 18.7 |
| Maximum mains fuses | | | |
| Estimated power loss [W], best case/typical ¹⁾ | 104/131 | 159/198 | 248/274 |
| Weight enclosure protection IP20 [kg] | 4.3 | 4.5 | 7.9 |
| Efficiency [%], best case/typical ¹⁾ | 98.4/98.0 | 98.2/97.8 | 98.1/97.9 |



Table 8.2 3x380-480 V AC

1) At rated load conditions

8.2 General Specifications

Protection and features

- Electronic thermal compressor protection against overload.
- Temperature monitoring of the heat sink ensures that the frequency converter trips in case of overtemperature.
- The frequency converter is protected against short-circuits between compressor terminals U, V, W.
- When a compressor phase is missing, the frequency converter trips and issues an alarm.
- When a mains phase is missing, the frequency converter trips or issues a warning (depending on the load).
- Monitoring of the intermediate circuit voltage ensures that the frequency converter trips, when the intermediate circuit voltage is too low or too high.
- The frequency converter is protected against ground faults on compressor terminals U, V, W.

Mains supply (L1, L2, L3)

| | |
|--|---|
| Supply voltage | 200-240 V ±10% |
| Supply voltage | 380-480 V ±10% |
| Supply frequency | 50/60 Hz |
| Maximum imbalance temporary between mains phases | 3.0% of rated supply voltage |
| True power factor (λ) | ≥0.9 nominal at rated load |
| Displacement power factor ($\cos\phi$) near unity | (>0.98) |
| Switching on the input supply L1, L2, L3 (power-ups) | Maximum 2 times/min. |
| Environment according to EN 60664-1 | Overvoltage category III/pollution degree 2 |
| The unit is suitable for use on a circuit capable of delivering not more than 100000 RMS symmetrical Amperes, 240/480 V maximum. | |

Compressor output (U, V, W)

| | |
|---------------------|--|
| Output voltage | 0-100% of supply voltage |
| Output frequency | 0-200 Hz (VVC ⁺), 0-400 Hz (u/f) |
| Switching on output | Unlimited |
| Ramp times | 0.05-3600 s |

Cable lengths and cross-sections

| | |
|--|------------------------------------|
| Maximum compressor cable length, screened/armoured (EMC correct installation) | See chapter 2.7.3 EMC Test Results |
| Maximum compressor cable length, unscreened/unarmoured | 50 m |
| Maximum cross-section to compressor, mains ¹⁾ | |
| Cross-section DC terminals for filter feedback on enclosure size H1-H3, I2, I3, I4 | 4 mm ² /11 AWG |
| Cross-section DC terminals for filter feedback on enclosure size H4-H5 | 16 mm ² /6 AWG |
| Maximum cross-section to control terminals, rigid wire | 2.5 mm ² /14 AWG |
| Maximum cross-section to control terminals, flexible cable | 2.5 mm ² /14 AWG |
| Minimum cross-section to control terminals | 0.05 mm ² /30 AWG |

1) See chapter 8.1.2 Mains Supply 3x380-480 V AC for more information

8.2.1 Digital Inputs

| | |
|--------------------------------------|--|
| Programmable digital inputs | 4 |
| Terminal number | 18, 19, 27, 29 |
| Logic | PNP or NPN |
| Voltage level | 0–24 V DC |
| Voltage level, logic 0 PNP | <5 V DC |
| Voltage level, logic 1 PNP | >10 V DC |
| Voltage level, logic 0 NPN | >19 V DC |
| Voltage level, logic 1 NPN | <14 V DC |
| Maximum voltage on input | 28 V DC |
| Input resistance, R_i | Approximately 4 k Ω |
| Digital input 29 as thermistor input | Fault: >2.9 k Ω and no fault: <800 Ω |
| Digital input 29 as Pulse input | Maximum frequency 32 kHz push-pull-driven & 5 kHz (O.C.) |

8.2.2 Analog Inputs

| | |
|----------------------------|--------------------------------------|
| Number of analog inputs | 2 |
| Terminal number | 53, 54 |
| Terminal 53 mode | Parameter 6-19: 1=voltage, 0=current |
| Terminal 54 mode | Parameter 6-29: 1=voltage, 0=current |
| Voltage level | 0–10 V |
| Input resistance, R_i | approximately 10 k Ω |
| Maximum voltage | 20 V |
| Current level | 0/4 to 20 mA (scalable) |
| Input resistance, R_i | <500 Ω |
| Maximum current | 29 mA |
| Resolution on analog input | 10 bit |

8.2.3 Analog Output

| | |
|---|-----------------------------------|
| Number of programmable analog outputs | 2 |
| Terminal number | 42, 45 ¹⁾ |
| Current range at analog output | 0/4–20 mA |
| Maximum load to common at analog output | 500 Ω |
| Maximum voltage at analog output | 17 V |
| Accuracy on analog output | Maximum error: 0.4% of full scale |
| Resolution on analog output | 10 bit |

1) Terminal 42 and 45 can also be programmed as digital outputs.

8.2.4 Digital Output

| | |
|--|----------------------|
| Number of digital outputs | 2 |
| Terminal number | 42, 45 ¹⁾ |
| Voltage level at digital output | 17 V |
| Maximum output current at digital output | 20 mA |
| Maximum load at digital output | 1 k Ω |

1) Terminals 42 and 45 can also be programmed as analog output.

8.2.5 Control Card, RS-485 Serial Communication

| | |
|-----------------|------------------------------------|
| Terminal number | 68 (P, TX+, RX+), 69 (N, TX-, RX-) |
| Terminal number | 61 common for terminals 68 and 69 |

8.2.6 Control Card, 24 V DC Output

| | |
|-----------------|-------|
| Terminal number | 12 |
| Maximum load | 80 mA |

8.2.7 Relay Output

| | |
|---|--|
| Programmable relay output | 2 |
| Relay 01 and 02 | 01-03 (NC), 01-02 (NO), 04-06 (NC), 04-05 (NO) |
| Maximum terminal load (AC-1) ¹⁾ on 01-02/04-05 (NO) (Resistive load) | 250 V AC, 3 A |
| Maximum terminal load (AC-15) ¹⁾ on 01-02/04-05 (NO) (Inductive load @ cosφ 0.4) | 250 V AC, 0.2 A |
| Maximum terminal load (DC-1) ¹⁾ on 01-02/04-05 (NO) (Resistive load) | 30 V DC, 2 A |
| Maximum terminal load (DC-13) ¹⁾ on 01-02/04-05 (NO) (Inductive load) | 24 V DC, 0.1 A |
| Maximum terminal load (AC-1) ¹⁾ on 01-03/04-06 (NC) (Resistive load) | 250 V AC, 3 A |
| Maximum terminal load (AC-15) ¹⁾ on 01-03/04-06 (NC) (Inductive load @ cosφ 0.4) | 250 V AC, 0.2 A |
| | 30 V DC, 2 A |
| Maximum terminal load (DC-1) ¹⁾ on 01-03/04-06 (NC) (Resistive load) | 24 V DC 10 mA, 24 V AC 20 mA |
| Environment according to EN 60664-1 | Overvoltage category III/pollution degree 2 |

1) IEC 60947 parts 4 and 5.

8.2.8 Control Card, 10 V DC Output¹⁾

| | |
|-----------------|---------------|
| Terminal number | 50 |
| Output voltage | 10.5 V ±0.5 V |
| Maximum load | 25 mA |

1) All inputs, outputs, circuits, DC supplies and relay contacts are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Surroundings

| | |
|---|---|
| Enclosure | IP20 |
| Enclosure kit available | IP21, TYPE 1 |
| Vibration test | 1.0 g |
| Maximum relative humidity | 5%-95% (IEC 60721-3-3; Class 3K3 (non-condensing) during operation) |
| Aggressive environment (IEC 60721-3-3), coated (standard) | Class 3C3 |
| Test method according to IEC 60068-2-43 H2S (10 days) | |
| Ambient temperature | 50 °C |

Derating for high ambient temperature, see *chapter 8.4 Derating according to Ambient Temperature and Switching Frequency*.

| | |
|---|------------------|
| Minimum ambient temperature during full-scale operation | 0 °C |
| Minimum ambient temperature at reduced performance | -20 °C |
| Temperature during storage/transport | -30 to +65/70 °C |
| Maximum altitude above sea level without derating | 1000 m |
| Maximum altitude above sea level with derating | 3000 m |

Derating for high altitude, see *chapter 8.4 Derating according to Ambient Temperature and Switching Frequency*.

| | |
|-------------------------|---|
| Safety standards | EN/IEC 61800-5-1, UL 508C |
| EMC standards, Emission | EN 61800-3, EN 61000-6-3/4, EN 55011, IEC 61800-3 |
| EMC standards, Immunity | EN 61800-3, EN 61000-3-12, EN 61000-6-1/2, EN 61000-4-2, EN 61000-4-3, EN 61000-4-4, EN 61000-4-5, EN 61000-4-6 |

8.3 Acoustic Noise or Vibration

If the compressor or the equipment driven by the compressor - e.g. a fan - is making noise or vibrations at certain frequencies, configure the following parameters or parameter groups to reduce or eliminate the noise or vibrations:

- Parameter group 4-6* *Speed Bypass*
- Set *parameter14-03 Overmodulation* to [0] Off
- Switching pattern and switching frequency
parameter group 14-0* *Inverter Switching*
- *Parameter 1-64 Resonance Dampening*

The acoustic noise from the frequency converter comes from 3 sources:

1. DC intermediate circuit coils
2. Integral fan
3. RFI filter choke

| Frame | Level [dBA] |
|-------|-------------|
| H3 | 53.8 |
| H4 | 64 |
| H5 | 63.7 |

Table 8.3 Typical Values Measured at a Distance of 1 m from the Unit

8.4 Derating according to Ambient Temperature and Switching Frequency

The ambient temperature measured over 24 hours should be at least 5 °C lower than the max. ambient temperature. If the frequency converter is operated at high ambient temperature, the continuous output current should be decreased. If the ambient temperature is higher than 50 °C or the installation by altitude is higher than 1000 m, a larger CDS 803 drive might be needed to run an undersized compressor. Consult Danfoss for support.




Illustration 8.1 400 V IP20 H3 6.0-7.5 kW




Illustration 8.3 400 V IP20 H4 10 kW




Illustration 8.4 200 V IP20 H5 10 kW




Illustration 8.2 200 V IP20 H4 6.0-7.5 kW

Index

A

Abbreviations..... 5

AC mains..... 9

Accessories..... 24

Acoustic noise..... 75

Advanced Vector Control..... 6

Aggressive environments..... 11

Air humidity..... 11

Analog input..... 73

Analog inputs..... 6

Analog output..... 73

B

Break-away torque..... 6

C

Cable

 Compressor cable..... 19

 Motor cable..... 20

Cable lengths..... 72

CE conformity and labeling..... 10

Changes made..... 41

Circuit breaker..... 36

Closed loop set-up wizard..... 41

Closed loop wizard..... 16

Coasting..... 6, 67, 68

Compressor output (U, V, W)..... 72

Compressor phases..... 23

Compressor protection..... 72

Connecting, mains and compressor..... 34

Control card, 10 V DC output..... 74

Control card, 24 V DC output..... 74

Control structure closed loop..... 13

Control structure open loop..... 12

Control terminal..... 39

Control Word..... 66

Covered, what is..... 10

Cross-sections..... 72

Current

 loops..... 19

 Leakage current..... 19

 Rated current..... 20

D

Data type, supported..... 57

DC brake..... 67

Decoupling plate..... 26

Definition..... 20

Definitions..... 6

Digital input..... 73

Digital output..... 73

Discharge time..... 9

Discharge Time..... 9

Display..... 40

Disposal..... 9

Drive closed loop controller, tuning..... 18

E

Earth leakage current..... 23

Earth leakage protection..... 19

Electrical installation, EMC compliant..... 37

Electrical installation, general..... 34

Electrical overview..... 33

EMC

 EMC..... 19, 20

 plan..... 20

 Emissions..... 19

EMC Complaint Installation..... 37

EMC Directive (89/336/EEC)..... 10

EMC Directive 89/336/EEC..... 11

EMC precautions..... 53

Emission requirements..... 19, 20

Environment

 Industrial..... 20

 Residential..... 20

Extreme running conditions..... 23

F

FC profile

 Protocol overview..... 53

FC Profile..... 66

FC with Modbus RTU..... 53

Feedback conversion..... 13

Field mounting..... 32

Freeze output..... 6

Frequency converter set-up..... 54

Function code..... 62

Fuse..... 36

G

Galvanic isolation..... 22

General aspects, harmonics emission..... 21

General Specifications..... 72

H

| | |
|--|----|
| Hardware set-up..... | 52 |
| Harmonic currents..... | 21 |
| Harmonics distortion..... | 19 |
| Harmonics emission requirements..... | 21 |
| Harmonics emission, general aspects..... | 21 |
| Harmonics test results (emission)..... | 22 |
| Hold output frequency..... | 67 |

I

| | |
|--------------------------------------|--------|
| Immunity requirements..... | 19, 22 |
| IND..... | 56 |
| Index (IND)..... | 56 |
| Indicator light..... | 40 |
| Initialise, frequency converter..... | 50 |
| Input power..... | 9 |
| Input supply, switching on..... | 72 |
| Installation, high altitudes..... | 9 |
| Intermediate circuit..... | 75 |
| IP21/TYPE 1 enclosure kit..... | 25 |

J

| | |
|----------|-------|
| Jog..... | 6, 67 |
|----------|-------|

K

| | |
|---------------------------------|----|
| Kit, IP21/TYPE 1 enclosure..... | 25 |
|---------------------------------|----|

L

| | |
|--|--------------|
| LCP..... | 6, 7, 12, 40 |
| LCP copy..... | 50 |
| Leakage current..... | 23 |
| Literature..... | 6 |
| Local (Hand On) Control..... | 12 |
| Low-voltage Directive (73/23/EEC)..... | 10 |

M

| | |
|--------------------------------------|----|
| Machinery Directive (98/37/EEC)..... | 10 |
| Main menu..... | 49 |
| Mains drop-out..... | 23 |
| Mains supply..... | 8 |
| Mains supply (L1, L2, L3)..... | 72 |
| Mains supply, 3x200-240 V AC..... | 70 |
| Mains supply, 3x380-480 V AC..... | 71 |
| Manual PI adjustment..... | 18 |
| Menu key..... | 40 |

| | |
|-------------------------------|----|
| Menus..... | 41 |
| Modbus communication..... | 52 |
| Modbus exception code..... | 63 |
| Modbus RTU..... | 59 |
| Modbus RTU overview..... | 58 |
| Modbus RTU Overview..... | 58 |
| Motor set-up..... | 41 |
| Motor thermal protection..... | 69 |

N

| | |
|----------------------------|----|
| Navigation key..... | 40 |
| Network configuration..... | 59 |
| Network connection..... | 52 |

O

| | |
|-----------------------------|----|
| Operation key..... | 40 |
| Options..... | 24 |
| Order, how to..... | 27 |
| Overcurrent protection..... | 36 |

P

| | |
|---|----------------|
| Parameter Number (PNU)..... | 56 |
| PELV, Protective Extra Low Voltage..... | 22 |
| PI adjustment, manual..... | 18 |
| PNU..... | 56 |
| Power factor..... | 8 |
| Precautions, EMC..... | 53 |
| Programme, how to..... | 40 |
| Programming..... | 40 |
| Protection..... | 11, 22, 23, 36 |
| Protection and features..... | 72 |
| Public supply network..... | 21 |

Q

| | |
|--|----|
| Quick menu..... | 41 |
| Quick transfer, parameter setting..... | 50 |

R

| | |
|--|-------|
| Rated motor speed..... | 6 |
| RCD..... | 6, 23 |
| Read holding registers (03 hex)..... | 65 |
| Read-out/programming, indexed parameter..... | 50 |
| Recommended initialisation..... | 50 |
| Reference handling..... | 14 |
| Remote (Auto On) Control..... | 12 |
| Requirements, harmonics emission..... | 21 |

| | |
|--|----|
| Residual Current Device..... | 23 |
| RS-485..... | 51 |
| RS-485 | |
| RS-485..... | 53 |
| RS-485 installation and set-up..... | 51 |
| RS-485 serial communication, control card..... | 73 |

S

| | |
|---|----|
| Serial communication port..... | 6 |
| Set-up, frequency converter..... | 54 |
| Set-up, hardware..... | 52 |
| Shock..... | 11 |
| Short circuit (compressor phase – phase)..... | 23 |
| Side-by-side installation..... | 29 |
| Specifications, general..... | 72 |
| Status menu..... | 41 |
| Status Word..... | 68 |
| Surroundings..... | 74 |
| Switching on the output..... | 23 |

T

| | |
|-------------------------------|----|
| Telegram length (LGE)..... | 54 |
| THD..... | 21 |
| Thermistor..... | 6 |
| Total voltage distortion..... | 21 |
| Type code string..... | 27 |

U

| | |
|--------------------|----|
| UL compliance..... | 36 |
|--------------------|----|

V

| | |
|-------------------------|----|
| Vibration..... | 11 |
| Voltage distortion..... | 21 |
| VVC+..... | 8 |

W

| | |
|-------------------------------------|----|
| Wizard, closed loop set-up..... | 41 |
| Wizard, open loop applications..... | 41 |



www.danfoss.com/drives

.....
Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.
.....

Danfoss A/S
Ulsnaes 1
DK-6300 Graasten
www.danfoss.com/drives

