



# Operating Instructions VLT<sup>®</sup> AutomationDrive FC 302

90–315 kW D-Frame





## Contents

<b>1 Introduction</b>	<b>3</b>
1.1 Purpose of the Manual	3
1.2 Additional Resources	3
1.3 Document and Software Version	3
1.4 Product Overview	3
1.5 Approvals and Certifications	6
1.6 Disposal	6
<b>2 Safety</b>	<b>7</b>
2.1 Safety Symbols	7
2.2 Qualified Personnel	7
2.3 Safety Precautions	7
<b>3 Mechanical Installation</b>	<b>9</b>
3.1 Unpacking	9
3.2 Installation Environments	9
3.3 Mounting	9
<b>4 Electrical Installation</b>	<b>11</b>
4.1 Safety Instructions	11
4.2 EMC-compliant Installation	11
4.3 Grounding	11
4.4 Wiring Schematic	12
4.5 Access	14
4.6 Motor Connection	14
4.7 AC Mains Connection	30
4.8 Control Wiring	31
4.8.1 Control Terminal Types	31
4.8.2 Wiring to Control Terminals	32
4.8.3 Enabling Motor Operation (Terminal 27)	32
4.8.4 Voltage/Current Input Selection (Switches)	32
4.8.5 Safe Torque Off (STO)	33
4.8.6 RS485 Serial Communication	33
4.9 Installation Check List	34
<b>5 Commissioning</b>	<b>35</b>
5.1 Safety Instructions	35
5.2 Applying Power	35
5.3 Local Control Panel Operation	35
5.4 Basic Programming	38

5.4.1 Commissioning via [Main Menu]	38
5.5 Checking Motor Rotation	39
5.6 Local-control Test	39
5.7 System Start-up	39
<b>6 Application Set-up Examples</b>	<b>40</b>
6.1 Introduction	40
6.2 Application Examples	40
<b>7 Maintenance, Diagnostics and Troubleshooting</b>	<b>46</b>
7.1 Maintenance and Service	46
7.2 Heat Sink Access Panel	46
7.3 Status Messages	47
7.4 Warning and Alarm Types	49
7.5 List of Warnings and Alarms	49
7.6 Troubleshooting	58
<b>8 Specifications</b>	<b>60</b>
8.1 Electrical Data	60
8.1.1 Mains Supply 3x380–500 V AC	60
8.1.2 Mains Supply 3x525–690 V AC	61
8.2 Mains Supply	63
8.3 Motor Output and Motor Data	63
8.4 Ambient Conditions	63
8.5 Cable Specifications	64
8.6 Control Input/Output and Control Data	64
8.7 Fuses	67
8.8 Connection Tightening Torques	69
8.9 Power Ratings, Weight and Dimensions	69
<b>9 Appendix</b>	<b>70</b>
9.1 Symbols, Abbreviations, and Conventions	70
9.2 Parameter Menu Structure	70
<b>Index</b>	<b>76</b>

# 1 Introduction

## 1.1 Purpose of the Manual

These operating instructions provide information for safe installation and commissioning of the frequency converter.

The operating instructions are intended for use by qualified personnel.

Read and follow the operating instructions to use the frequency converter safely and professionally, and pay particular attention to the safety instructions and general warnings. Always keep these operating instructions available with the frequency converter.

VLT® is a registered trademark.

## 1.2 Additional Resources

Other resources are available to understand advanced frequency converter functions and programming.

- The *VLT® AutomationDrive FC 302 Programming Guide* provides greater detail on working with parameters and many application examples.
- The *VLT® AutomationDrive FC 302 Design Guide* provides detailed information about capabilities and functionality to design motor control systems.
- Instructions for operation with optional equipment.

Supplementary publications and manuals are available from Danfoss. See [vlt-drives.danfoss.com/Support/Technical-Documentation/](http://vlt-drives.danfoss.com/Support/Technical-Documentation/) for listings.

## 1.3 Document and Software Version

This manual is regularly reviewed and updated. All suggestions for improvement are welcome. *Table 1.1* shows the document version and the corresponding software version.

Edition	Remarks	Software version
MG34U4xx	Replaces MG34U3xx	7.42

Table 1.1 Document and Software Version

## 1.4 Product Overview

### 1.4.1 Intended Use

The frequency converter is an electronic motor controller intended for:

- Regulation of motor speed in response to system feedback or to remote commands from external controllers. A power drive system consists of the frequency converter, the motor, and the equipment driven by the motor.
- System and motor status surveillance.

The frequency converter can also be used for motor protection.

Depending on the configuration, the frequency converter can be used in stand-alone applications or form part of a larger appliance or installation.

The frequency converter is allowed for use in residential, industrial, and commercial environments in accordance with local laws and standards.

### **NOTICE**

**In a residential environment, this product can cause radio interference, in which case supplementary mitigation measures can be required.**

### **Foreseeable misuse**

Do not use the frequency converter in applications which are non-compliant with specified operating conditions and environments. Ensure compliance with the conditions specified in *chapter 8 Specifications*.

1.4.2 Interior Views





Illustration 1.1 D1 Interior Components



1 LCP (local control panel)	9 Relay 2 (04, 05, 06)
2 RS485 serial bus connector	1 Lifting ring
3 Digital I/O and 24 V power supply	0
4 Analog I/O connector	1 Mounting holes
5 USB connector	1 Cable clamp (PE)
6 Serial bus terminal switch	2
7 Analog switches (A53), (A54)	1 Earth (ground)
8 Relay 1 (01, 02, 03)	3
	1 Motor output terminals 96 (U), 97 (V), 98 (W)
	1 Mains input terminals 91 (L1), 92 (L2), 93 (L3)
	1 TB5 (IP21/54 only). Terminal 6 block for anti-condensation heater

Illustration 1.2 Close-up View: LCP and Control Functions

**NOTICE**

For location of TB6 (terminal block for contactor), see *chapter 4.6 Motor Connection*.

### 1.4.3 Extended Options Cabinets

If a frequency converter is ordered with one of the following options, it is supplied with an options cabinet that makes it taller.

- Brake chopper
- Mains disconnect
- Contactor
- Mains disconnect with contactor
- Circuit breaker
- Oversized wiring cabinet
- Regeneration terminals
- Load share terminals

Illustration 1.3 shows an example of a frequency converter with an options cabinet. Table 1.2 lists the variants for the frequency converters that include input options.

Options unit designations	Extension cabinets	Possible options
D5h	D1h enclosure with short extension.	<ul style="list-style-type: none"> <li>• Brake.</li> <li>• Disconnect.</li> </ul>
D6h	D1h enclosure with tall extension.	<ul style="list-style-type: none"> <li>• Contactor.</li> <li>• Contactor with disconnect.</li> <li>• Circuit breaker.</li> </ul>
D7h	D2h enclosure with short extension.	<ul style="list-style-type: none"> <li>• Brake.</li> <li>• Disconnect.</li> </ul>
D8h	D2h enclosure with tall extension.	<ul style="list-style-type: none"> <li>• Contactor.</li> <li>• Contactor with disconnect.</li> <li>• Circuit breaker.</li> </ul>

Table 1.2 Overview of Extended Options

The D7h and D8h frequency converters (D2h plus options cabinet), include a 200 mm pedestal for floor mounting.

There is a safety latch on the front cover of the options cabinet. If the frequency converter is supplied with a mains disconnect or circuit breaker, the safety latch prevents the cabinet door from being opened while the frequency converter is energised. Before opening the door of the frequency converter, open the disconnect or circuit breaker (to de-energise the frequency converter) and remove the cover of the options cabinet.

For frequency converters purchased with a disconnect, contactor or circuit breaker, the nameplate label includes a type code for a replacement that does not include the

option. If there is a problem with the frequency converter, it is replaced independently of the options.





Illustration 1.3 D7h Enclosure

### 1.4.4 Block Diagram of the Frequency Converter

Illustration 1.4 is a block diagram of the internal components of the frequency converter.



Area	Title	Functions
1	Mains input	<ul style="list-style-type: none"> <li>3-phase AC mains power supply to the frequency converter.</li> </ul>
2	Rectifier	<ul style="list-style-type: none"> <li>The rectifier bridge converts the AC input to DC current to supply inverter power.</li> </ul>
3	DC bus	<ul style="list-style-type: none"> <li>Intermediate DC-bus circuit handles the DC current.</li> </ul>
4	DC reactors	<ul style="list-style-type: none"> <li>Filter the intermediate DC circuit voltage.</li> <li>Provide line transient protection.</li> <li>Reduce RMS current.</li> <li>Raise the power factor reflected back to the line.</li> <li>Reduce harmonics on the AC input.</li> </ul>
5	Capacitor bank	<ul style="list-style-type: none"> <li>Stores the DC power.</li> <li>Provides ride-through protection for short power losses.</li> </ul>
6	Inverter	<ul style="list-style-type: none"> <li>Converts the DC into a controlled PWM AC waveform for a controlled variable output to the motor.</li> </ul>
7	Output to motor	<ul style="list-style-type: none"> <li>Regulated 3-phase output power to the motor.</li> </ul>

Area	Title	Functions
8	Control circuitry	<ul style="list-style-type: none"> <li>Input power, internal processing, output, and motor current are monitored to provide efficient operation and control.</li> <li>User interface and external commands are monitored and performed.</li> <li>Status output and control can be provided.</li> </ul>

Table 1.3 Legend to Illustration 1.4

Illustration 1.4 Block Diagram of Frequency Converter

### 1.4.5 Enclosure Types and Power Ratings

For enclosure types and power ratings of the frequency converters, refer to *chapter 8.9 Power Ratings, Weight and Dimensions*.


## 1.5 Approvals and Certifications



More approvals and certifications are available. Contact the local Danfoss partner. Frequency converters of enclosure type T7 (525–690 V) are UL certified for only 525–600 V.

The frequency converter complies with UL 508C thermal memory retention requirements. For more information, refer to the section *Motor Thermal Protection* in the product-specific *design guide*.

### 1.6 Disposal



Do not dispose of equipment containing electrical components together with domestic waste. Collect it separately in accordance with local and currently valid legislation.



## 2 Safety

### 2.1 Safety Symbols

The following symbols are used in this manual:

#### **⚠ WARNING**

Indicates a potentially hazardous situation that could result in death or serious injury.

#### **⚠ CAUTION**

Indicates a potentially hazardous situation that could result in minor or moderate injury. It can also be used to alert against unsafe practices.

#### **NOTICE**

Indicates important information, including situations that can result in damage to equipment or property.

### 2.2 Qualified Personnel

Correct and reliable transport, storage, installation, operation, and maintenance are required for the trouble-free and safe operation of the frequency converter. Only qualified personnel are allowed to install and operate this equipment.

Qualified personnel are defined as trained staff, who are authorised to install, commission, and maintain equipment, systems, and circuits in accordance with pertinent laws and regulations. Additionally, the qualified personnel must be familiar with the instructions and safety measures described in these operating instructions.

### 2.3 Safety Precautions

#### **⚠ WARNING**

##### **HIGH VOLTAGE**

Frequency converters contain high voltage when connected to AC mains input, DC supply, or load sharing. Failure to perform installation, start-up, and maintenance by qualified personnel can result in death or serious injury.

- Only qualified personnel must perform installation, start-up, and maintenance.

#### **⚠ WARNING**

##### **UNINTENDED START**

When the frequency converter is connected to AC mains, DC supply, or load sharing, the motor may start at any time. Unintended start during programming, service, or repair work can result in death, serious injury, or property damage. The motor can start via an external switch, a serial bus command, an input reference signal from the LCP, or after a cleared fault condition.

To prevent unintended motor start:

- Disconnect the frequency converter from the mains.
- Press [Off/Reset] on the LCP before programming parameters.
- Completely wire and assemble the frequency converter, motor, and any driven equipment before connecting the frequency converter to AC mains, DC supply, or load sharing.

#### **⚠ WARNING**

##### **DISCHARGE TIME**

The frequency converter contains DC-link capacitors, which can remain charged even when the frequency converter is not powered. Failure to wait the specified time after power has been removed before performing service or repair work, could result in death or serious injury.

1. Stop the motor.
2. Disconnect AC mains, permanent magnet type motors, and remote DC-link power supplies, including battery back-ups, UPS, and DC-link connections to other frequency converters.
3. Wait for the capacitors to discharge fully, before performing any service or repair work. The duration of waiting time is specified in *Table 2.1*.

Voltage [V]	Power range [kW]	Minimum waiting time (minutes)
3x400	90–250	20
3x400	110–315	20
3x500	110–315	20
3x500	132–355	20
3x525	55–250	20
3x525	90–315	20
3x690	55–250	20
3x690	110–315	20

Table 2.1 Discharge Time

**⚠ WARNING****LEAKAGE CURRENT HAZARD**

Leakage currents exceed 3.5 mA. Failure to ground the frequency converter properly can result in death or serious injury.

- Ensure the correct grounding of the equipment by a certified electrical installer.

**⚠ WARNING****EQUIPMENT HAZARD**

Contact with rotating shafts and electrical equipment can result in death or serious injury.

- Ensure that only trained and qualified personnel perform installation, start-up, and maintenance.
- Ensure that electrical work conforms to national and local electrical codes.
- Follow the procedures in this manual.

**⚠ WARNING****UNINTENDED MOTOR ROTATION  
WINDMILLING**

Unintended rotation of permanent magnet motors creates voltage and can charge the unit, resulting in death, serious injury, or equipment damage.

- Ensure that permanent magnet motors are blocked to prevent unintended rotation.

**⚠ CAUTION****INTERNAL FAILURE HAZARD**

An internal failure in the frequency converter can result in serious injury, when the frequency converter is not properly closed.

- Ensure that all safety covers are in place and securely fastened before applying power.


### 3 Mechanical Installation

#### 3.1 Unpacking

##### 3.1.1 Items Supplied

Items supplied may vary according to product configuration.

- Make sure the items supplied and the information on the nameplate correspond to the order confirmation.
- Check the packaging and the frequency converter visually for damage caused by inappropriate handling during shipment. File any claim for damage with the carrier. Retain damaged parts for clarification.



1	Type code
2	Order number
3	Serial number
4	Power rating
5	Input voltage, frequency and current (at low/high voltages)
6	Output voltage, frequency and current (at low/high voltages)
7	Enclosure type and IP protection rating
8	Maximum ambient temperature
9	Certifications
10	Discharge time (Warning)

Illustration 3.1 Product Nameplate (Example)

#### **NOTICE**

Do not remove the nameplate from the frequency converter (loss of warranty).

#### 3.1.2 Storage

Ensure that the requirements for storage are fulfilled. Refer to *chapter 8.4 Ambient Conditions* for further details.

#### 3.2 Installation Environments

#### **NOTICE**

In environments with airborne liquids, particles, or corrosive gases, ensure that the IP/type rating of the equipment matches the installation environment. Failure to meet requirements for ambient conditions can reduce the lifetime of the frequency converter. Ensure that requirements for air humidity, temperature, and altitude are met.

Voltage [V]	Altitude restrictions
380–500	At altitudes above 3000 m, contact Danfoss regarding PELV
525–690	At altitudes above 2000 m, contact Danfoss regarding PELV

Table 3.1 Installation in High Altitudes

For detailed ambient conditions specifications, refer to *chapter 8.4 Ambient Conditions*.

#### 3.3 Mounting

#### **NOTICE**

Improper mounting can result in overheating and reduced performance.

#### Cooling

- Ensure that top and bottom clearance for air cooling is provided. Clearance requirement: 225 mm (9 in).
- Consider derating for temperatures starting between 45 °C (113 °F) and 50 °C (122 °F) and elevation 1000 m (3300 ft) above sea level. See the frequency converter design guide for detailed information.

The frequency converter utilises a back-channel cooling concept that removes heat sink cooling air. The heat sink cooling air carries approximately 90% of the heat out of the back channel of the frequency converter. Redirect the back-channel air from the panel or room by using:

- Duct cooling. A back-channel cooling kit is available to direct the heat sink cooling air out of the panel when an IP20/chassis frequency converter is installed in a Rittal enclosure. Use of

this kit reduces the heat in the panel and smaller door fans can be specified on the enclosure.

- Cooling out the back (top and bottom covers). The back-channel cooling air can be ventilated out of the room so that the heat from the back channel is not dissipated into the control room.

**NOTICE**

A door fan(s) is required on the enclosure to remove the heat not contained in the back-channel of the frequency converter. It also removes any additional losses generated by other components inside the frequency converter. Calculate the total required air flow so that the appropriate fan(s) can be selected.

Secure the necessary airflow over the heat sink. The flow rate is shown in *Table 3.2*.

Frame	Door fan/top fan	Heat sink fan
D1h/D3h/D5h/D6h	102 m <sup>3</sup> /hr (60 CFM)	420 m <sup>3</sup> /hr (250 CFM)
D2h/D4h/D7h/D8h	204 m <sup>3</sup> /hr (120 CFM)	840 m <sup>3</sup> /hr (500 CFM)

Table 3.2 Airflow

**Lifting**

Always lift the frequency converter using the dedicated lifting eyes. Use a bar to avoid bending the lifting holes.




Illustration 3.2 Recommended Lifting Method

**WARNING**

**RISK OF INJURY OR DEATH**

The lifting bar must be able to handle the weight of the frequency converter to ensure that it does not break during lifting.

- See *chapter 8.9 Power Ratings, Weight and Dimensions* for the weight of the different enclosure types.
- Maximum diameter for bar: 2.5 cm (1 inch).
- The angle from the top of the frequency converter to the lifting cable: 60° or greater.

Failure to follow recommendations could result in death or serious injury.

**Mounting**

1. Ensure that the strength of the mounting location supports the unit weight.
2. Locate the unit as near to the motor as possible. Keep the motor cables as short as possible.
3. Mount the unit vertically to a solid flat surface to provide cooling airflow. Ensure free space for cooling.
4. Ensure the access to open the door.
5. Ensure the cable entry from the bottom.

## 4 Electrical Installation

### 4.1 Safety Instructions

See *chapter 2 Safety* for general safety instructions.

#### **⚠ WARNING**

##### INDUCED VOLTAGE

Induced voltage from output motor cables that run together can charge equipment capacitors, even with the equipment turned off and locked out. Failure to run output motor cables separately or use screened cables could result in death or serious injury.

- Run output motor cables separately, or
- Use screened cables.

#### **⚠ CAUTION**

##### SHOCK HAZARD

The frequency converter can cause a DC current in the PE conductor. Failure to follow the recommendation below means the RCD may not provide the intended protection.

- When a residual current-operated protective device (RCD) is used for protection against electrical shock, only an RCD of Type B is permitted on the supply side.

##### Overcurrent protection

- Additional protective equipment, such as short-circuit protection or motor thermal protection between frequency converter and motor, is required for applications with multiple motors.
- Input fusing is required to provide short-circuit and overcurrent protection. If not factory-supplied, the installer must provide the fuses. See maximum fuse ratings in *chapter 8.7 Fuses*.

##### Wire type and ratings

- All wiring must comply with local and national regulations regarding cross-section and ambient temperature requirements.
- Power connection wire recommendation: Minimum 75 °C rated copper wire.

See *chapter 8.1 Electrical Data* and *chapter 8.5 Cable Specifications* for recommended wire sizes and types.

### 4.2 EMC-compliant Installation

To obtain an EMC-compliant installation, follow the instructions provided in

- *Chapter 4.3 Grounding*.
- *Chapter 4.4 Wiring Schematic*.
- *Chapter 4.6 Motor Connection*.
- *Chapter 4.8 Control Wiring*.

### 4.3 Grounding

#### **⚠ WARNING**

##### LEAKAGE CURRENT HAZARD

Leakage currents exceed 3.5 mA. Failure to ground the frequency converter properly could result in death or serious injury.

- Ensure the correct grounding of the equipment by a certified electrical installer.

##### For electrical safety

- Ground the frequency converter in accordance with applicable standards and directives.
- Use a dedicated ground wire for input power, motor power, and control wiring.
- Do not ground one frequency converter to another in a daisy chain fashion.
- Keep the ground wire connections as short as possible.
- Follow motor manufacturer wiring requirements.
- Minimum cable cross-section: 10 mm<sup>2</sup> (or 2 rated ground wires terminated separately).

##### For EMC-compliant installation

- Establish electrical contact between the cable screen and the frequency converter enclosure by using metal cable glands or by using the clamps provided on the equipment.
- Use high-strand wire to reduce electrical interference.
- Do not use pigtailed.


#### **NOTICE**

##### POTENTIAL EQUALISATION

Risk of electrical interference, when the ground potential between the frequency converter and the control system is different. Install equalising cables between the system components. Recommended cable cross-section: 16 mm<sup>2</sup>.

4.4 Wiring Schematic

4



130BC548.12

Illustration 4.1 Basic Wiring Schematic

A=Analog, D=Digital

\*Terminal 37 (optional) is used for Safe Torque Off. For Safe Torque Off installation instructions, refer to the *Safe Torque Off Operating Instructions for Danfoss VLT® Frequency Converters*.

\*\*Do not connect cable screen.




Illustration 4.2 Example of Proper Electrical Installation Using Conduit

## **NOTICE**

### **EMC INTERFERENCE**

Use screened cables for motor and control wiring, and separate cables for mains input, motor wiring and control wiring. Failure to isolate power, motor and control cables can result in unintended behaviour or reduced performance. Minimum 200 mm (7.9 in) clearance between mains input, motor and control cables is required.

## 4.5 Access

All terminals to the control cables are located underneath the LCP on the inside of the frequency converter. To access, open the door (IP21/54) or remove the front panel (IP20).

## 4.6 Motor Connection

### **⚠ WARNING**


#### INDUCED VOLTAGE

Induced voltage from output motor cables that run together can charge equipment capacitors, even with the equipment turned off and locked out. Failure to run output motor cables separately or use screened cables could result in death or serious injury.

- Comply with local and national electrical codes for cable sizes. For maximum wire sizes see *chapter 8.1 Electrical Data*.
- Follow motor manufacturer wiring requirements.
- Motor wiring knockouts or access panels are provided at the base of IP21 (NEMA1/12) and higher units.
- Do not wire a starting or pole-changing device (for example Dahlander motor or slip ring induction motor) between the frequency converter and the motor.

### Procedure


1. Strip a section of the outer cable insulation.
2. Position the stripped wire under the cable clamp to establish mechanical fixation and electrical contact between the cable screen and ground.
3. Connect the ground wire to the nearest grounding terminal in accordance with the grounding instructions provided in *chapter 4.3 Grounding*, see *Illustration 4.3*.
4. Connect the 3-phase motor wiring to terminals 96 (U), 97 (V), and 98 (W), see *Illustration 4.3*.
5. Tighten the terminals in accordance with the information provided in *chapter 8.8 Connection Tightening Torques*.



1308D53 1.10

Illustration 4.3 Motor Connection





4

Illustration 4.4 Terminal Locations, D1h




Illustration 4.5 Terminal Locations, D2h






Illustration 4.6 Terminal Locations, D3h




1	Front view
2	Side view

Illustration 4.7 Loadshare and Regeneration Terminals, D3h



4


Illustration 4.8 Terminal Locations, D4h



1	Front view
2	Side view


Illustration 4.9 Load Share and Regeneration Terminals, D4h

4



1	Mains terminals
2	Brake terminals
3	Motor terminals
4	Earth/ground terminals

Illustration 4.10 Terminal Locations, D5h with Disconnect Option



130BC536.11

4

1	Mains terminals
2	Brake terminals
3	Motor terminals
4	Earth/ground terminals

Illustration 4.11 Terminal Locations, D5h with Brake Option





Illustration 4.12 Oversized Wiring Cabinet, D5h




4

1	Mains terminals
2	TB6 terminal block for contactor
3	Brake terminals
4	Motor terminals
5	Earth/ground terminals

Illustration 4.13 Terminal Locations, D6h with Contactor Option

4




130BC538.12

1	Brake terminals
2	TB6 terminal block for contactor
3	Motor terminals
4	Earth/ground terminals
5	Mains terminals

Illustration 4.14 Terminal Locations, D6h with Contactor and Disconnect Options






1	Mains terminals
2	Brake terminals
3	Motor terminals
4	Earth/ground terminals


Illustration 4.15 Terminal Locations, D6h with Circuit Breaker Option

4



1	Mains terminals
2	Motor terminals
3	Earth/ground terminals
4	Brake terminals

Illustration 4.16 Terminal Locations, D7h with Disconnect Option



4

1	Mains terminals
2	Brake terminals
3	Motor terminals
4	Earth/ground terminals

Illustration 4.17 Terminal Locations, D7h with Brake Option





Illustration 4.18 Oversized Wiring Cabinet, D7h




1.30BC544.12

4

1	TB6 terminal block for contactor	4	Brake terminals
2	Motor terminals	5	Mains terminals
3	Earth/ground terminals		

Illustration 4.19 Terminal Locations, D8h with Contactor Option

4




1 TB6 terminal block for contactor	4 Motor terminals
2 Mains terminals	5 Earth/ground terminals
3 Brake terminals	

Illustration 4.20 Terminal Locations, D8h with Contactor and Disconnect Options

130BC546.11

4



1	Mains terminals	3	Motor terminals
2	Brake terminals	4	Earth/ground terminals

Illustration 4.21 Terminal Locations, D8h with Circuit Breaker Option


### 4.7 AC Mains Connection

- Size the wiring according to the input current of the frequency converter. For maximum wire sizes, see *chapter 8.1 Electrical Data*.
- Comply with local and national electrical codes for cable sizes.

**Procedure**

1. Connect the 3-phase AC input power wiring to terminals R, S, and T (see *Illustration 4.22*).
2. Depending on the configuration of the equipment, connect the input power to the mains input terminals or the input disconnect.
3. Ground the cable in accordance with the grounding instructions provided in *chapter 4.3 Grounding*.
4. When supplied from an isolated mains source (IT mains or floating delta) or TT/TN-S mains with a grounded leg (grounded delta), ensure that *parameter 14-50 RFI Filter* is set to [0] Off to avoid damage to the intermediate circuit and to reduce ground capacity currents.

4



1	Mains connection (R, S, T)
2	Motor connection (U, V, W)

**Illustration 4.22 Connecting to AC Mains**



## 4.8 Control Wiring

- Isolate the control wiring from the high power components in the frequency converter.
- When the frequency converter is connected to a thermistor, ensure that the thermistor control wiring is screened and reinforced/double insulated. A 24 V DC supply voltage is recommended.

### 4.8.1 Control Terminal Types

Illustration 4.23 and Illustration 4.24 show the removable frequency converter connectors. Terminal functions and default settings are summarised in Table 4.1 and Table 4.2.




Illustration 4.23 Control Terminal Locations




Illustration 4.24 Terminal Numbers

- Connector 1 provides 4 programmable digital inputs terminals, 2 additional digital terminals programmable as either input or output, a 24 V DC terminal supply voltage, and a common for optional customer supplied 24 V DC voltage. FC 302 and FC 301 (optional in A1 enclosure) also provide a digital input for STO function.
- Connector 2 terminals (+)68 and (-)69 for RS-485 serial communication connection.
- Connector 3 provides 2 analog inputs, 1 analog output, 10 V DC supply voltage, and commons for the inputs and output.
- Connector 4 is a USB port available for use with the MCT 10 Set-up Software.

Terminal description			
Terminal	Parameter	Default setting	Description
<b>Digital inputs/outputs</b>			
12, 13	-	+24 V DC	24 V DC supply voltage for digital inputs and external transducers. Maximum output current 200 mA (130 mA for FC 301) for all 24 V loads.
18	5-10	[8] Start	Digital inputs.
19	5-11	[10] Reversing	
32	5-14	[0] No operation	
33	5-15	[0] No operation	
27	5-12	[2] Coast inverse	For digital input or output. Default setting is input.
29	5-13	[14] JOG	
20	-		Common for digital inputs and 0 V potential for 24 V supply.
37	-	STO	Safe input.
<b>Analog inputs/outputs</b>			
39	-		Common for analog output.
42	6-50	[0] No operation	Programmable analog output. 0–20 mA or 4–20 mA at a maximum of 500 Ω.
50	-	+10 V DC	10 V DC analog supply voltage for potentiometer or thermistor. 15 mA maximum
53	6-1*	Reference	Analog input. For voltage or current. Switches A53 and A54 select mA or V.
54	6-2*	Feedback	
55	-		Common for analog input

Table 4.1 Terminal Description Digital Inputs/Outputs, Analog Inputs/Outputs

Terminal description			
Terminal	Parameter	Default setting	Description
<b>Serial communication</b>			
61	-		Integrated RC-filter for cable screen. ONLY for connecting the screen in the event of EMC problems.
68 (+)	8-3*		RS485 interface. A control card switch is provided for termination resistance.
69 (-)	8-3*		
<b>Relays</b>			
01, 02, 03	5-40 [0]	[0] No operation	Form C relay output. For AC or DC voltage and resistive or inductive loads.
04, 05, 06	5-40 [1]	[0] No operation	

Table 4.2 Terminal Description Serial Communication

**Additional terminals:**

- 2 form C relay outputs. The location of the outputs depends on the frequency converter configuration.
- Terminals located on built-in optional equipment. See the manual provided with the equipment option.

**4.8.2 Wiring to Control Terminals**

Control terminal connectors can be unplugged from the frequency converter for ease of installation, as shown in *Illustration 4.25*.




Illustration 4.25 Connecting Control Wires

**NOTICE**

Keep control wires as short as possible and separate from high power cables to minimise interference.

1. Open the contact by inserting a small screwdriver into the slot above the contact and push the screwdriver slightly upwards.
2. Insert the bare control wire into the contact.
3. Remove the screwdriver to fasten the control wire into the contact.
4. Ensure that the contact is firmly established and not loose. Loose control wiring can be the source of equipment faults or reduced performance.

See *chapter 8.5 Cable Specifications* for control terminal wiring sizes and *chapter 6 Application Set-up Examples* for typical control wiring connections.

**4.8.3 Enabling Motor Operation (Terminal 27)**

A jumper wire may be required between terminal 12 (or 13) and terminal 27 for the frequency converter to operate when using factory default programming values.

- Digital input terminal 27 is designed to receive 24 V DC external interlock command.
- When no interlock device is used, wire a jumper between control terminal 12 (recommended) or 13 to terminal 27. This provides an internal 24 V signal on terminal 27.
- When the status line at the bottom of the LCP reads *AUTO REMOTE COAST*, this indicates that the unit is ready to operate but is missing an input signal on terminal 27.
- When factory installed optional equipment is wired to terminal 27, do not remove that wiring.

**NOTICE**

The frequency converter cannot operate without a signal on terminal 27, unless terminal 27 is re-programmed.

**4.8.4 Voltage/Current Input Selection (Switches)**

The analog input terminals 53 and 54 allow setting of input signal to voltage (0–10 V) or current (0/4–20 mA).

**Default parameter setting:**

- Terminal 53: Speed reference signal in open loop (see *parameter 16-61 Terminal 53 Switch Setting*).
- Terminal 54: Feedback signal in closed loop (see *parameter 16-63 Terminal 54 Switch Setting*).

**NOTICE**

Disconnect power to the frequency converter before changing switch positions.

1. Remove the LCP (local control panel) (see *Illustration 4.26*).
2. Remove any optional equipment covering the switches.
3. Set switches A53 and A54 to select the signal type. U selects voltage, I selects current.




Illustration 4.26 Location of Terminal 53 and 54 Switches

### 4.8.5 Safe Torque Off (STO)

To run STO, additional wiring for the frequency converter is required. Refer to *VLT® Frequency Converters Safe Torque Off Operating Instructions* for further information.

### 4.8.6 RS485 Serial Communication

Connect RS485 serial communication wiring to terminals (+)68 and (-)69.

- Use screened serial communication cable (recommended).
- See *chapter 4.3 Grounding* for proper grounding.




Illustration 4.27 Serial Communication Wiring Diagram

For basic serial communication set-up, select the following:

1. Protocol type in *parameter 8-30 Protocol*.
  2. Frequency converter address in *parameter 8-31 Address*.
  3. Baud rate in *parameter 8-32 Baud Rate*.
- 2 communication protocols are internal to the frequency converter.
    - Danfoss FC
    - Modbus RTU
  - Functions can be programmed remotely using the protocol software and RS485 connection or in parameter group 8-\*\* *Communications and Options*.
  - Selecting a specific communication protocol changes various default parameter settings to match that protocol's specifications and makes additional protocol-specific parameters available.
  - Option cards for the frequency converter are available to provide additional communication protocols. See the option card documentation for installation and operation instructions.

## 4.9 Installation Check List

Before completing installation of the unit, inspect the entire installation as detailed in *Table 4.3*. Check and mark the items when completed.

**4**

Inspect for	Description	<input type="checkbox"/>
Auxiliary equipment	<ul style="list-style-type: none"> <li>Look for auxiliary equipment, switches, disconnects, or input fuses/circuit breakers, which may reside on the input power side of the frequency converter or output side to the motor. Ensure that they are ready for full-speed operation.</li> <li>Check the function and installation of any sensors used for feedback to the frequency converter.</li> <li>Remove any power factor correction capacitors on the motor(s).</li> <li>Adjust any power factor correction capacitors on the mains side and ensure that they are dampened.</li> </ul>	<input type="checkbox"/>
Cable routing	<ul style="list-style-type: none"> <li>Ensure that the motor wiring and control wiring are separated, screened, or in 3 separate metallic conduits for high-frequency interference isolation.</li> </ul>	<input type="checkbox"/>
Control wiring	<ul style="list-style-type: none"> <li>Check for broken or damaged wires and loose connections.</li> <li>Check that the control wiring is isolated from power and motor wiring for noise immunity.</li> <li>Check the voltage source of the signals, if necessary.</li> </ul> <p>The use of screened cable or twisted pair is recommended. Ensure that the shield is terminated correctly.</p>	<input type="checkbox"/>
Cooling clearance	<ul style="list-style-type: none"> <li>Ensure the top and bottom clearance is adequate to ensure proper air flow for cooling, see <i>chapter 3.3 Mounting</i>.</li> </ul>	<input type="checkbox"/>
Ambient conditions	<ul style="list-style-type: none"> <li>Check that requirements for ambient conditions are met.</li> </ul>	<input type="checkbox"/>
Fusing and circuit breakers	<ul style="list-style-type: none"> <li>Check for proper fusing or circuit breakers.</li> <li>Check that all fuses are inserted firmly and are in operational condition and that all circuit breakers are in the open position.</li> </ul>	<input type="checkbox"/>
Grounding	<ul style="list-style-type: none"> <li>Check for sufficient ground connections and ensure the those are tight and free of oxidation.</li> <li>Grounding to conduit, or mounting the back panel to a metal surface, is not a suitable grounding.</li> </ul>	<input type="checkbox"/>
Input and output power wiring	<ul style="list-style-type: none"> <li>Check for loose connections.</li> <li>Check that the motor and mains cables are in separate conduit or separated screened cables.</li> </ul>	<input type="checkbox"/>
Panel interior	<ul style="list-style-type: none"> <li>Inspect that the unit interior is free of dirt, metal chips, moisture, and corrosion.</li> <li>Check that the unit is mounted on an unpainted, metal surface.</li> </ul>	<input type="checkbox"/>
Switches	<ul style="list-style-type: none"> <li>Ensure that all switch and disconnect settings are in the proper positions.</li> </ul>	<input type="checkbox"/>
Vibration	<ul style="list-style-type: none"> <li>Check that the unit is mounted solidly, or that shock mounts are used, as necessary.</li> <li>Check for an unusual amount of vibration.</li> </ul>	<input type="checkbox"/>

Table 4.3 Installation Check List

### CAUTION

#### POTENTIAL HAZARD IN THE EVENT OF INTERNAL FAILURE

Risk of personal injury if the frequency converter is not properly closed.

- Before applying power, ensure all safety covers are in place and securely fastened.

## 5 Commissioning

### 5.1 Safety Instructions

See *chapter 2 Safety* for general safety instructions.

#### **⚠ WARNING**

##### HIGH VOLTAGE

Frequency converters contain high voltage when connected to AC mains input power. Failure to perform installation, start-up, and maintenance by qualified personnel could result in death or serious injury.

- Installation, start-up, and maintenance must be performed by qualified personnel only.

##### Before applying power:

1. Verify that there is no voltage on input terminals L1 (91), L2 (92), and L3 (93), phase-to-phase and phase-to-ground.
2. Verify that there is no voltage on output terminals 96 (U), 97 (V), and 98 (W), phase-to-phase and phase-to-ground.
3. Confirm continuity of the motor by measuring  $\Omega$  values on U-V (96-97), V-W (97-98), and W-U (98-96).
4. Check for proper grounding of the frequency converter as well as the motor.
5. Inspect the frequency converter for loose connections on the terminals.
6. Check that all cable glands are firmly tightened.
7. Ensure that input power to the unit is OFF and locked out. Do not rely on the frequency converter disconnect switches for input power isolation.
8. Confirm that the supply voltage matches the voltage of the frequency converter and the motor.
9. Close the door properly.

### 5.2 Applying Power

Apply power to the frequency converter using the following steps:

1. Confirm that the input voltage is balanced within 3%. If not, correct the input voltage imbalance before proceeding. Repeat this procedure after the voltage correction.
2. Ensure that any optional equipment wiring, matches the installation application.

3. Ensure that all operator devices are in the OFF position. Close all panel doors and fasten covers securely.
4. Apply power to the unit. DO NOT start the frequency converter now. For units with a disconnect switch, turn it to the ON position to apply power to the frequency converter.

### 5.3 Local Control Panel Operation

#### 5.3.1 Local Control Panel

The local control panel (LCP) is the combined display and keypad on the front of the unit.

##### The LCP has several user functions:

- Start, stop, and control speed when in local control.
- Display operational data, status, warnings and cautions.
- Programme frequency converter functions.
- Manually reset the frequency converter after a fault when auto-reset is inactive.

An optional numeric LCP (NLCP) is also available. The NLCP operates in a manner similar to the LCP. See the product relevant *programming guide* for details on use of the NLCP.

#### **NOTICE**

For commissioning via PC, install the MCT 10 Set-up Software. The software is available for download (basic version) or for ordering (advanced version, order number 130B1000). For more information and downloads, see [www.danfoss.com/BusinessAreas/DrivesSolutions/Software+MCT10/MCT10+Downloads.htm](http://www.danfoss.com/BusinessAreas/DrivesSolutions/Software+MCT10/MCT10+Downloads.htm).

#### 5.3.2 Start-up Message

#### **NOTICE**

During start-up, the LCP displays the message *INITIALISING*. When this message is no longer displayed, then the frequency converter is ready for operation. Adding or removing options can extend the duration of start-up.

### 5.3.3 LCP Layout

The LCP is divided into 4 functional groups (see *Illustration 5.1*).

- A. Display area
- B. Display menu keys
- C. Navigation keys and indicator lights (LEDs)
- D. Operation keys and reset




Illustration 5.1 Local Control Panel (LCP)

#### A. Display area

The display area is activated when the frequency converter receives power from the mains voltage, a DC bus terminal, or an external 24 V DC supply.

The information displayed on the LCP can be customised for user application. Select options in the *Quick Menu* Q3-13 *Display Settings*.

Display	Parameter number	Default setting
1	0-20	Speed [RPM]
2	0-21	Motor Current
3	0-22	Power [kW]
4	0-23	Frequency
5	0-24	Reference [%]

Table 5.1 Legend to *Illustration 5.1*, Display Area

#### B. Display menu keys

Menu keys are used for menu access for parameter set-up, toggling through status display modes during normal operation, and viewing fault log data.

	Key	Function
6	Status	Shows operational information.
7	Quick Menu	Allows access to programming parameters for initial set-up instructions and many detailed application instructions.
8	Main Menu	Allows access to all programming parameters.
9	Alarm Log	Displays a list of current warnings, the last 10 alarms, and the maintenance log.

Table 5.2 Legend to *Illustration 5.1*, Display Menu Keys

#### C. Navigation keys and indicator lights (LEDs)

Navigation keys are used for programming functions and moving the display cursor. The navigation keys also provide speed control in local operation. There are also 3 frequency converter status indicator lights in this area.

	Key	Function
10	Back	Reverts to the previous step or list in the menu structure.
11	Cancel	Cancels the last change or command as long as the display mode has not changed.
12	Info	Press for a definition of the function being displayed.
13	Navigation keys	Use the 4 navigation keys to move between items in the menu.
14	OK	Use to access parameter groups or to enable a selection.

Table 5.3 Legend to *Illustration 5.1*, Navigation Keys

	Indicator	Light	Function
15	On	Green	The ON light activates when the frequency converter receives power from the mains voltage, a DC bus terminal, or an external 24 V supply.
16	Warn	Yellow	When warning conditions are met, the yellow WARN light comes on and text appears in the display area identifying the problem.
17	Alarm	Red	A fault condition causes the red alarm light to flash and an alarm text is displayed.

Table 5.4 Legend to *Illustration 5.1*, Indicator Lights (LEDs)

## D. Operation keys and reset

Operation keys are located at the bottom of the LCP.

	Key	Function
18	Hand On	Starts the frequency converter in local control. <ul style="list-style-type: none"> <li>An external stop signal by control input or serial communication overrides the local hand on.</li> </ul>
19	Off	Stops the motor but does not remove power to the frequency converter.
20	Auto On	Puts the system in remote operational mode. <ul style="list-style-type: none"> <li>Responds to an external start command by control terminals or serial communication.</li> </ul>
21	Reset	Resets the frequency converter manually after a fault has been cleared.

Table 5.5 Legend to *Illustration 5.1, Operation Keys and Reset*

### NOTICE

The display contrast can be adjusted by pressing [Status] and the [▲]/[▼] keys.

## 5.3.4 Parameter Settings

Establishing the correct programming for applications often requires setting functions in several related parameters. Details for parameters are provided in *chapter 9.2 Parameter Menu Structure*.

Programming data is stored internally in the frequency converter.

- For back-up, upload data into the LCP memory.
- To download data to another frequency converter, connect the LCP to that unit and download the stored settings.
- Restoring factory default settings does not change data stored in the LCP memory.

## 5.3.5 Uploading/Downloading Data to/from the LCP

- Press [Off] to stop the motor before uploading or downloading data.
- Press [Main Menu], *parameter 0-50 LCP Copy* and press [OK].
- Select [1] *All to LCP* to upload data to the LCP or select [2] *All from LCP* to download data from the LCP.
- Press [OK]. A progress bar shows the uploading or downloading progress.
- Press [Hand On] or [Auto On] to return to normal operation.

## 5.3.6 Changing Parameter Settings

Parameter settings can be accessed and changed from the *Quick Menu* or from the *Main Menu*. The *Quick Menu* only gives access to a limited number of parameters.

- Press [Quick Menu] or [Main Menu] on the LCP.
- Press [▲] [▼] to browse through the parameter groups, press [OK] to select a parameter group.
- Press [▲] [▼] to browse through the parameters, press [OK] to select a parameter.
- Press [▲] [▼] to change the value of a parameter setting.
- Press [◀] [▶] to shift digit when a decimal parameter is in the editing state.
- Press [OK] to accept the change.
- Press either [Back] twice to enter *Status*, or press [Main Menu] once to enter the *Main Menu*.

### View changes

*Quick Menu Q5 - Changes Made* lists all parameters changed from default settings.

- The list only shows parameters, which have been changed in the current edit set-up.
- Parameters, which have been reset to default values, are not listed.
- The message *Empty* indicates that no parameters have been changed.

## 5.3.7 Restoring Default Settings

### NOTICE

**Risk of losing programming, motor data, localisation, and monitoring records by restoration of default settings. To provide a back-up, upload data to the LCP before initialisation.**

Restoring the default parameter settings is done by initialisation of the frequency converter. Initialisation is carried out through *parameter 14-22 Operation Mode* (recommended) or manually.

- Initialisation using *parameter 14-22 Operation Mode* does not reset frequency converter settings, such as operating hours, serial communication selections, personal menu settings, fault log, alarm log, and other monitoring functions.
- Manual initialisation erases all motor, programming, localisation, and monitoring data and restores factory default settings.

**Recommended initialisation procedure, via parameter 14-22 Operation Mode**

1. Press [Main Menu] twice to access parameters.
2. Scroll to *parameter 14-22 Operation Mode* and press [OK].
3. Scroll to [2] *Initialisation* and press [OK].
4. Remove power to the unit and wait for the display to turn off.
5. Apply power to the unit.

Default parameter settings are restored during start-up. This may take slightly longer than normal.

6. Alarm 80 is displayed.
7. Press [Reset] to return to operation mode.

**Manual initialisation procedure**

1. Remove power to the unit and wait for the display to turn off.
2. Press and hold [Status], [Main Menu], and [OK] at the same time while applying power to the unit (approximately 5 s, or until a click is heard, and the fan starts).

Factory default parameter settings are restored during start-up. This may take slightly longer than normal.

Manual initialisation does not reset the following frequency converter information:

- *Parameter 15-00 Operating hours*
- *Parameter 15-03 Power Up's*
- *Parameter 15-04 Over Temp's*
- *Parameter 15-05 Over Volt's*

**5.4 Basic Programming**

**5.4.1 Commissioning via [Main Menu]**

Recommended parameter settings are intended for start-up and check-out purposes. Application settings may vary.

Enter data with power ON, but before operating the frequency converter.

1. Press [Main Menu] on the LCP.
2. Press the navigation keys to scroll to parameter group 0-\*\* *Operation/Display* and press [OK].




Illustration 5.2 Main Menu

3. Press the navigation keys to scroll to parameter group 0-0\* *Basic Settings* and press [OK].




Illustration 5.3 Operation/Display

4. Press the navigation keys to scroll to parameter 0-03 *Regional Settings* and press [OK].




Illustration 5.4 Basic Settings


5. Press the navigation keys to select [0] *International* or [1] *North America* as appropriate and press [OK]. (This changes the default settings for a number of basic parameters).
6. Press [Main Menu] on the LCP.
7. Press the navigation keys to scroll to *parameter 0-01 Language*.
8. Select the language and press [OK].
9. If a jumper wire is in place between control terminals 12 and 27, leave *parameter 5-12 Terminal 27 Digital Input* at factory default. Otherwise, select *No Operation* in *parameter 5-12 Terminal 27 Digital Input*.



10. Make the application specific settings in the following parameters:
  - 10a *Parameter 3-02 Minimum Reference*
  - 10b *Parameter 3-03 Maximum Reference*
  - 10c *Parameter 3-41 Ramp 1 Ramp Up Time*
  - 10d *Parameter 3-42 Ramp 1 Ramp Down Time*
  - 10e *Parameter 3-13 Reference Site. Linked to Hand/Auto Local Remote.*

### 5.5 Checking Motor Rotation

The direction of rotation can be changed by switching 2 phases in the motor cable, or by changing the setting of *parameter 4-10 Motor Speed Direction*.



**Table 5.6 Wiring for Changing Motor Direction**

Perform a motor rotation check using *parameter 1-28 Motor Rotation Check* and following the steps shown in the display.

### 5.6 Local-control Test

1. Press [Hand On] to provide a local start command to the frequency converter.
2. Accelerate the frequency converter by pressing [▲] to full speed. Moving the cursor left of the decimal point provides quicker input changes.
3. Note any acceleration problems.
4. Press [Off]. Note any deceleration problems.

In the event of acceleration or deceleration problems, see *chapter 7.6 Troubleshooting*. See *chapter 7.5 List of Warnings and Alarms* for resetting the frequency converter after a trip.

### 5.7 System Start-up

The procedure in this section requires user-wiring and application programming to be completed. The following procedure is recommended after application set-up is completed.

1. Press [Auto On].
2. Apply an external run command.
3. Adjust the speed reference throughout the speed range.
4. Remove the external run command.
5. Check the sound and vibration levels of the motor to ensure that the system is working as intended.

If warnings or alarms occur, see *chapter 7.5 List of Warnings and Alarms*.

## 6 Application Set-up Examples

### 6.1 Introduction

The examples in this section are intended as a quick reference for common applications.

- Parameter settings are the regional default values unless otherwise indicated (selected in *parameter 0-03 Regional Settings*).
- Parameters associated with the terminals and their settings are shown next to the drawings.
- Where switch settings for analog terminals A53 or A54 are required, these are also shown.

#### NOTICE

When the optional Safe Torque Off feature is used, a jumper wire may be required between terminal 12 (or 13) and terminal 37 for the frequency converter to operate when using factory default programming values.

### 6.2 Application Examples

#### 6.2.1 Automatic motor adaptation (AMA)

FC		Parameters	
		Function	Setting
+24 V	12	Parameter 1-29 Automatic Motor Adaptation (AMA)	[1] Enable complete
+24 V	13		AMA
D IN	18		
D IN	19		
COM	20	Parameter 5-12 Terminal 27 Digital Input	[2]* Coast inverse
D IN	27		
D IN	29		
D IN	32		
D IN	33	* = Default Value	
D IN 37		Notes/comments: Parameter group 1-2* Motor Data must be set according to motor. D IN 37 is an option.	
+10 V	50		
A IN	53		
A IN	54		
COM	55		
A OUT	42		
COM	39		

Table 6.1 AMA with T27 connected

FC		Parameters	
		Function	Setting
+24 V	12	Parameter 1-29 Automatic Motor Adaptation (AMA)	[1] Enable complete
+24 V	13		AMA
D IN	18		
D IN	19		
COM	20	Parameter 5-12 Terminal 27 Digital Input	[0] No operation
D IN	27		
D IN	29		
D IN	32		
D IN	33	* = Default Value	
D IN 37		Notes/comments: Parameter group 1-2* Motor Data must be set according to motor. D IN 37 is an option.	
+10 V	50		
A IN	53		
A IN	54		
COM	55		
A OUT	42		
COM	39		

Table 6.2 AMA without T27 connected

#### 6.2.2 Speed

FC		Parameters	
		Function	Setting
+24 V	12	Parameter 6-10 Terminal 53 Low Voltage	0.07 V*
+24 V	13		
D IN	18		
D IN	19		
COM	20	Parameter 6-11 Terminal 53 High Voltage	10 V*
D IN	27		
D IN	29		
D IN	32		
D IN	33	* = Default Value	
D IN 37		Notes/comments: D IN 37 is an option.	
+10 V	50		
A IN	53	Parameter 6-14 Terminal 53 Low Ref./Feedb. Value	0 Hz
A IN	54		
COM	55	Parameter 6-15 Terminal 53 High Ref./Feedb. Value	50 Hz
A OUT	42		
COM	39	* = Default Value	
D IN 37		Notes/comments: D IN 37 is an option.	

Table 6.3 Analog Speed Reference (Voltage)

FC		Parameters	
		Function	Setting
+24 V	12	Parameter 6-12 Terminal 53 Low Current	4 mA*
+24 V	13		
D IN	18		
D IN	19		
COM	20		
D IN	27	Parameter 6-13 Terminal 53 High Current	20 mA*
D IN	29		
D IN	32	Parameter 6-14 Terminal 53 Low Ref./Feedb. Value	0 Hz
D IN	33		
D IN	37	Parameter 6-15 Terminal 53 High Ref./Feedb. Value	50 Hz
+10 V	50		
A IN	53	* = Default Value	
A IN	54	<b>Notes/comments:</b>	
COM	55	D IN 37 is an option.	
A OUT	42		
COM	39		

130BB927.10

4 - 20mA

U - I

A53

Table 6.4 Analog Speed Reference (Current)

FC		Parameters	
		Function	Setting
+24 V	12	Parameter 5-10 Terminal 18 Digital Input	[8] Start*
+24 V	13		
D IN	18	Parameter 5-12 Terminal 27 Digital Input	[19] Freeze Reference
D IN	19		
COM	20	parameter 5-13 Terminal 29 Digital Input	[21] Speed Up
D IN	27		
D IN	29	parameter 5-14 Terminal 32 Digital Input	[22] Speed Down
D IN	32		
D IN	33	* = Default Value	
D IN	37	<b>Notes/comments:</b>	
+10 V	50	D IN 37 is an option.	
A IN	53		
A IN	54		
COM	55		
A OUT	42		
COM	39		

130BB804.10

U - I

A53

Table 6.6 Speed Up/Down

FC		Parameters	
		Function	Setting
+24 V	12	Parameter 6-10 Terminal 53 Low Voltage	0.07 V*
+24 V	13		
D IN	18	Parameter 6-11 Terminal 53 High Voltage	10 V*
D IN	19		
COM	20	Parameter 6-14 Terminal 53 Low Ref./Feedb. Value	0 Hz
D IN	27		
D IN	29	Parameter 6-15 Terminal 53 High Ref./Feedb. Value	1500 Hz
D IN	32		
D IN	33	* = Default Value	
D IN	37	<b>Notes/comments:</b>	
+10 V	50	D IN 37 is an option.	
A IN	53		
A IN	54		
COM	55		
A OUT	42		
COM	39		

130BB663.10

≈ 5kΩ

U - I

A53

Table 6.5 Speed Reference (Using a Manual Potentiometer)




Illustration 6.1 Speed Up/Down

6.2.3 Start/Stop

		Parameters	
FC		Function	Setting
+24 V	120	Parameter 5-10 Terminal 18 Digital Input	[8] Start*
+24 V	130	Parameter 5-12 Terminal 27 Digital Input	[0] No operation
D IN	180	Parameter 5-19 Terminal 37 Safe Stop	[1] Safe Stop Alarm
D IN	190	* = Default Value	
COM	200	<b>Notes/comments:</b> If parameter 5-12 Terminal 27 Digital Input is set to [0] No operation, a jumper wire to terminal 27 is not needed. D IN 37 is an option.	
D IN	270		
D IN	290		
D IN	320		
D IN	330		
D IN	370		
+10	500		
A IN	530		
A IN	540		
COM	550		
A OUT	420		
COM	390		

Table 6.7 Start/Stop Command with Safe Stop Option




Illustration 6.2 Start/Stop Command with Safe Stop

		Parameters	
FC		Function	Setting
+24 V	120	Parameter 5-10 Terminal 18 Digital Input	[9] Latched Start
+24 V	130	Parameter 5-12 Terminal 27 Digital Input	[6] Stop Inverse
D IN	180	* = Default Value	
COM	200	<b>Notes/comments:</b> If parameter 5-12 Terminal 27 Digital Input is set to [0] No operation, a jumper wire to terminal 27 is not needed. D IN 37 is an option.	
D IN	270		
D IN	290		
D IN	320		
D IN	330		
D IN	370		
+10 V	500		
A IN	530		
A IN	540		
COM	550		
A OUT	420		
COM	390		

Table 6.8 Pulse Start/Stop




Illustration 6.3 Latched Start/Stop Inverse

		Parameters		
FC		Function	Setting	
+24 V	12	Parameter 5-10 Terminal 18 Digital Input	[8] Start	
+24 V	13			
D IN	18			
D IN	19			
COM	20	Parameter 5-11 Terminal 19 Digital Input	[10] Reversing*	
D IN	27			
D IN	29			
D IN	32			
D IN	33	Parameter 5-12 Terminal 27 Digital Input	[0] No operation	
D IN	37			
+10 V	50	Parameter 5-14 Terminal 32 Digital Input	[16] Preset ref bit 0	
A IN	53			
A IN	54			
COM	55			
A OUT	42	Parameter 5-15 Terminal 33 Digital Input	[17] Preset ref bit 1	
COM	39			
			Parameter 3-10 Preset Reference	Preset ref. 0 25%
				Preset ref. 1 50%
		Preset ref. 2 75%		
		Preset ref. 3 100%		
		* = Default Value		
		<b>Notes/comments:</b> D IN 37 is an option.		

Table 6.9 Start/Stop with Reversing and 4 Preset Speeds

6.2.4 External Alarm Reset

		Parameters	
FC		Function	Setting
+24 V	12	Parameter 5-11 Terminal 19 Digital Input	[1] Reset
+24 V	13		
D IN	18	* = Default Value	
D IN	19	<b>Notes/comments:</b> D IN 37 is an option.	
COM	20		
D IN	27		
D IN	29		
D IN	32		
D IN	33		
D IN	37		
+10 V	50		
A IN	53		
A IN	54		
COM	55		
A OUT	42		
COM	39		

Table 6.10 External Alarm Reset

6.2.5 RS485

		Parameters	
FC		Function	Setting
+24 V	12	Parameter 8-30 Protocol	FC*
+24 V	13		
D IN	18	Parameter 8-31 Address	1*
D IN	19		
COM	20	Parameter 8-32 Baud Rate	9600*
D IN	27		
D IN	29	* = Default Value	
D IN	32	<b>Notes/comments:</b> Select protocol, address and baud rate in the above mentioned parameters. D IN 37 is an option.	
D IN	33		
D IN	37		
+10 V	50		
A IN	53		
A IN	54		
COM	55		
A OUT	42		
COM	39		
	01	RS-485	
R1	02		
	03		
	04		
R2	05		
	06		
	61		
	68		
	69		

Table 6.11 RS485 Network Connection

6.2.6 Motor Thermistor



**WARNING**  
THERMISTOR INSULATION

Risk of personal injury or equipment damage.

- Use only thermistors with reinforced or double insulation to meet PELV insulation requirements.

VLT		Parameters	
		Function	Setting
+24 V	12	Parameter 1-90 <i>Motor Thermal Protection</i>	[2]
+24 V	13		Thermistor trip
D IN	18	Parameter 1-93 T <i>Thermistor Source</i>	[1] Analog
D IN	19		input 53
COM	20	* = Default Value	
D IN	27	<b>Notes/comments:</b> If only a warning is desired, parameter <i>parameter 1-90 Motor Thermal Protection</i> should be set to [1] <i>Thermistor warning</i> . D IN 37 is an option.	
D IN	29		
D IN	32		
D IN	33		
D IN	37		
+10 V	50		
A IN	53		
A IN	54		
COM	55		
A OUT	42		
COM	39		

Table 6.12 Motor Thermistor

6.2.7 SLC

FC		Parameters	
		Function	Setting
+24 V	12	Parameter 4-30 Mo <i>tor Feedback Loss Function</i>	[1] Warning
+24 V	13		
D IN	18	Parameter 4-31 Mo <i>tor Feedback Speed Error</i>	100 RPM
D IN	19		
COM	20	Parameter 4-32 Mo <i>tor Feedback Loss Timeout</i>	5 s
D IN	27		
D IN	29	Parameter 7-00 Spe <i>ed PID Feedback Source</i>	[2] MCB 102
D IN	32		
D IN	33	Parameter 17-11 Re <i>solution (PPR)</i>	1024*
D IN	37		
+10 V	50	Parameter 13-00 SL <i>Controller Mode</i>	[1] On
A IN	53		
A IN	54	Parameter 13-01 St <i>art Event</i>	[19] Warning
COM	55		
A OUT	42	Parameter 13-02 St <i>op Event</i>	[44] Reset key
COM	39		
		Parameter 13-10 Co <i>mparator Operand</i>	[21] Warning no.
		Parameter 13-11 Co <i>mparator Operator</i>	[1] ≈*
		Parameter 13-12 Co <i>mparator Value</i>	90
		Parameter 13-51 SL <i>Controller Event</i>	[22] Comparator 0
		Parameter 13-52 SL <i>Controller Action</i>	[32] Set digital out A low
		Parameter 5-40 Fun <i>ction Relay</i>	[80] SL digital output A
* = Default Value			
<b>Notes/comments:</b> If the limit in the feedback monitor is exceeded, Alarm 90, Feedback monitor is issued. The SLC monitors Alarm 90, Feedback monitor and if becomes TRUE, relay 1 is triggered. External equipment may then indicate that service may be required. If the feedback error goes below the limit again within 5 s, the frequency converter continues and the warning disappears. But relay 1 is still triggered until pressing [Reset] on the LCP.			

Table 6.13 Using SLC to Set a Relay

6.2.8 Mechanical Brake Control

		Parameters	
		Function	Setting
		Parameter 5-40 Function Relay	[32] Mech. brake ctrl.
		Parameter 5-10 Terminal 18 Digital Input	[8] Start*
		Parameter 5-11 Terminal 19 Digital Input	[11] Start reversing
		Parameter 1-71 Start Delay	0.2
		Parameter 1-72 Start Function	[5] VVC+/ FLUX Clockwise
		Parameter 1-76 Start Current	$I_{m,n}$
		Parameter 2-20 Release Brake Current	App. dependent
		Parameter 2-21 Activate Brake Speed [RPM]	Half of nominal slip of the motor
		*=Default Value	
		Notes/comments:	

6

Table 6.14 Mechanical Brake Control (Open Loop)




Illustration 6.4 Mechanical Brake Control (Open Loop)

## 7 Maintenance, Diagnostics and Troubleshooting

This chapter includes maintenance and service guidelines, status messages, warnings and alarms, and basic troubleshooting.

### 7.1 Maintenance and Service

Under normal operating conditions and load profiles, the frequency converter is maintenance-free throughout its designed lifetime. To prevent breakdown, danger, and damage, examine the frequency converter at regular intervals depending on the operating conditions. Replace worn or damaged parts with original spare parts or standard parts. For service and support, refer to [www.danfoss.com/contact/sales\\_and\\_services/](http://www.danfoss.com/contact/sales_and_services/).

#### **WARNING**

##### UNINTENDED START

When the frequency converter is connected to AC mains, DC supply, or load sharing, the motor may start at any time. Unintended start during programming, service, or repair work can result in death, serious injury, or property damage. The motor can start with an external switch, a fieldbus command, an input reference signal from the LCP or LOP, via remote operation using MCT 10 Set-up Software, or after a cleared fault condition.


To prevent unintended motor start:

- Disconnect the frequency converter from the mains.
- Press [Off/Reset] on the LCP before programming parameters.
- Completely wire and assemble the frequency converter, motor, and any driven equipment before connecting the frequency converter to AC mains, DC supply, or load sharing.

### 7.2 Heat Sink Access Panel

#### 7.2.1 Removing the Heat Sink Access Panel

The frequency converter has an optional access panel for accessing the heat sink.



130BD430.10

Illustration 7.1 Heat Sink Access Panel


1. Do not run the frequency converter during heat sink access panel removal.
2. If the frequency converter is mounted on a wall, or the back of it is otherwise inaccessible, reposition it so that the back is fully accessible.
3. Remove the screws (3 mm internal hex) connecting the access panel to the back of the enclosure. There are 5 or 9 screws depending on the size of the frequency converter.

Reinstall in reverse order of this procedure and tighten fasteners according to *chapter 8.8 Connection Tightening Torques*.



### 7.3 Status Messages

When the frequency converter is in *Status mode*, status messages are generated automatically and appear in the bottom line of the display (see *Illustration 7.2*).



1	Operation mode (see <i>Table 7.1</i> )
2	Reference site (see <i>Table 7.2</i> )
3	Operation status (see <i>Table 7.3</i> )

Illustration 7.2 Status Display

*Table 7.1* to *Table 7.3* describe the displayed status messages.

Off	The frequency converter does not react to any control signal until [Auto On] or [Hand On] is pressed.
Auto On	The frequency converter is controlled from the control terminals and/or the serial communication.
Hand On	The frequency converter is controlled by the navigation keys on the LCP. Stop commands, reset, reversing, DC brake, and other signals applied to the control terminals override local control.

Table 7.1 Operation Mode

Remote	The speed reference is given from external signals, serial communication, or internal preset references.
Local	The frequency converter uses [Hand On] control or reference values from the LCP.

Table 7.2 Reference Site

AC Brake	<i>Parameter 2-16 AC brake Max. Current</i> was selected in <i>parameter 2-10 Brake Function</i> . The AC brake overmagnetises the motor to achieve a controlled slow-down.
----------	---

AMA finish OK	Automatic motor adaptation (AMA) was carried out successfully.
AMA ready	AMA is ready to start. Press [Hand On] to start.
AMA running	AMA process is in progress.
Braking	The brake chopper is in operation. Generative energy is absorbed by the brake resistor.
Braking max.	The brake chopper is in operation. The power limit for the brake resistor defined in <i>parameter 2-12 Brake Power Limit (kW)</i> has been reached.
Coast	<ul style="list-style-type: none"> <li>Coast inverse was selected as a function for a digital input (parameter group 5-1* <i>Digital Inputs</i>). The corresponding terminal is not connected.</li> <li>Coast activated by serial communication.</li> </ul>
Ctrl. ramp-down	<p>[1] <i>Control Ramp-down</i> was selected in <i>parameter 14-10 Mains Failure</i>.</p> <ul style="list-style-type: none"> <li>The mains voltage is below the value set in <i>parameter 14-11 Mains Voltage at Mains Fault</i> at mains fault .</li> <li>The frequency converter ramps down the motor using a controlled ramp down.</li> </ul>
Current High	The frequency converter output current is above the limit set in <i>parameter 4-51 Warning Current High</i> .
Current Low	The frequency converter output current is below the limit set in <i>parameter 4-52 Warning Speed Low</i> .
DC Hold	[1] <i>DC hold</i> is selected in <i>parameter 1-80 Function at Stop</i> and a stop command is active. The motor is held by a DC current set in <i>parameter 2-00 DC Hold/Preheat Current</i> .
DC Stop	<p>The motor is held with a DC current (<i>parameter 2-01 DC Brake Current</i>) for a specified time (<i>parameter 2-02 DC Braking Time</i>).</p> <ul style="list-style-type: none"> <li>The DC Brake cut in speed is reached in <i>parameter 2-03 DC Brake Cut In Speed [RPM]</i> and a stop command is active.</li> <li>DC Brake (inverse) is selected as a function for a digital input (parameter group 5-1* <i>Digital Inputs</i>). The corresponding terminal is not active.</li> <li>The DC Brake is activated via serial communication.</li> </ul>
Feedback high	The sum of all active feedbacks is above the feedback limit set in <i>parameter 4-57 Warning Feedback High</i> .
Feedback low	The sum of all active feedbacks is below the feedback limit set in <i>parameter 4-56 Warning Feedback Low</i> .

Freeze output	<p>The remote reference is active, which holds the present speed.</p> <ul style="list-style-type: none"> <li>• <i>Freeze output</i> was selected as a function for a digital input (parameter group 5-1* <i>Digital Inputs</i>). The corresponding terminal is active. Speed control is only possible via the terminal functions <i>Speed Up</i> and <i>Speed Down</i>.</li> <li>• <i>Hold ramp</i> is activated via serial communication.</li> </ul>
Freeze output request	A freeze output command was given, but the motor remains stopped until a run permissive signal is received.
Freeze ref.	<i>Freeze Reference</i> was selected as a function for a digital input (parameter group 5-1* <i>Digital Inputs</i> ). The corresponding terminal is active. The frequency converter saves the actual reference. Changing the reference is now only possible via terminal functions <i>Speed Up</i> and <i>Speed Down</i> .
Jog request	A jog command was given, but the motor remains stopped until a run permissive signal is received via a digital input.
Jogging	<p>The motor is running as programmed in <i>parameter 3-19 Jog Speed [RPM]</i>.</p> <ul style="list-style-type: none"> <li>• <i>Jog</i> was selected as a function for a digital input (parameter group 5-1* <i>Digital Inputs</i>). The corresponding terminal (for example Terminal 29) is active.</li> <li>• The <i>Jog</i> function is activated via the serial communication.</li> <li>• The <i>Jog</i> function was selected as a reaction for a monitoring function (for example No signal). The monitoring function is active.</li> </ul>
Motor check	In <i>parameter 1-80 Function at Stop, [2] Motor Check</i> was selected. A stop command is active. To ensure that a motor is connected to the frequency converter, a permanent test current is applied to the motor.
OVC control	Overvoltage control was activated in <i>parameter 2-17 Over-voltage Control, [2] Enabled</i> . The connected motor supplies the frequency converter with generative energy. The overvoltage control adjusts the V/Hz ratio to run the motor in controlled mode and to prevent the frequency converter from tripping.
PowerUnit Off	<p>(Only frequency converters with an external 24 V power supply installed).</p> <p>Mains supply to the frequency converter was removed, and the control card is supplied by the external 24 V.</p>

Protection md	<p>Protection mode is active. The unit has detected a critical status (overcurrent or overvoltage).</p> <ul style="list-style-type: none"> <li>• To avoid tripping, switching frequency is reduced to 4 kHz.</li> <li>• If possible, protection mode ends after approximately 10 s.</li> <li>• Protection mode can be restricted in <i>parameter 14-26 Trip Delay at Inverter Fault</i>.</li> </ul>
QStop	<p>The motor is decelerating using <i>parameter 3-81 Quick Stop Ramp Time</i>.</p> <ul style="list-style-type: none"> <li>• <i>Quick stop inverse</i> was selected as a function for a digital input (parameter group 5-1* <i>Digital Inputs</i>). The corresponding terminal is not active.</li> <li>• The <i>quick stop</i> function was activated via serial communication.</li> </ul>
Ramping	The motor is accelerating/decelerating using the active ramp up/down. The reference, a limit value, or a standstill is not yet reached.
Ref. high	The sum of all active references is above the reference limit set in <i>parameter 4-55 Warning Reference High</i> .
Ref. low	The sum of all active references is below the reference limit set in <i>parameter 4-54 Warning Reference Low</i> .
Run on ref.	The frequency converter is running in the reference range. The feedback value matches the setpoint value.
Run request	A start command was given, but the motor remains stopped until a run permissive signal is received via digital input.
Running	The frequency converter drives the motor.
Sleep Mode	The energy-saving function is enabled. The motor has stopped, but restarts automatically when required.
Speed high	Motor speed is above the value set in <i>parameter 4-53 Warning Speed High</i> .
Speed low	Motor speed is below the value set in <i>parameter 4-52 Warning Speed Low</i> .
Standby	In <i>Auto On</i> mode, the frequency converter starts the motor with a start signal from a digital input or serial communication.
Start delay	In <i>parameter 1-71 Start Delay</i> , a delay starting time was set. A start command is activated and the motor starts after the start delay time expires.
Start fwd/rev	<i>Start forward</i> and <i>start reverse</i> were selected as functions for 2 different digital inputs (parameter group 5-1* <i>Digital Inputs</i> ). The motor starts in forward or reverse direction depending on which corresponding terminal is activated.

Stop	The frequency converter has received a stop command from the LCP, digital input, or serial communication.
Trip	An alarm occurred and the motor is stopped. Once the cause of the alarm is cleared, the frequency converter can be reset manually by pressing [Reset] or remotely by control terminals or serial communication.
Trip lock	An alarm occurred and the motor is stopped. Once the cause of the alarm is cleared, cycle power to the frequency converter. The frequency converter can then be reset manually by pressing [Reset], or remotely by control terminals or serial communication.

Table 7.3 Operation Status

**NOTICE**

In auto/remote mode, the frequency converter requires external commands to execute functions.

7.4 Warning and Alarm Types

**Warnings**

A warning is issued when an alarm condition is impending or when an abnormal operating condition is present and may result in the frequency converter issuing an alarm. A warning clears by itself when the abnormal condition ceases.

**Alarms**

**Trip**

An alarm is issued when the frequency converter is tripped, meaning that the frequency converter suspends operation to prevent frequency converter or system damage. The motor coasts to a stop. The frequency converter logic continues to operate and monitor the frequency converter status. After the fault condition is remedied, the frequency converter can be reset. It is then ready to restart operation.

**Resetting the frequency converter after trip/trip lock**

A trip can be reset in any of 4 ways:

- Press [Reset] on the LCP.
- Digital reset input command.
- Serial communication reset input command.
- Auto reset.

**Trip lock**

Input power is cycled. The motor coasts to a stop. The frequency converter continues to monitor the frequency converter status. Remove input power to the frequency converter, correct the cause of the fault, and reset the frequency converter.

**Warning and alarm displays**

- A warning is displayed in the LCP along with the warning number.
- An alarm flashes along with the alarm number.





Illustration 7.3 Alarm Display Example

In addition to the text and alarm code in the LCP, there are 3 status indicator lights (LEDs).



	Warning LED	Alarm LED
Warning	On	Off
Alarm	Off	On (flashing)
Trip-Lock	On	On (flashing)

Illustration 7.4 Status Indicator Lights (LEDs)

7.5 List of Warnings and Alarms

The following warning/alarm information defines each warning/alarm condition, provides the probable cause for the condition, and details a remedy or troubleshooting procedure.

**WARNING 1, 10 Volts low**

The control card voltage is less than 10 V from terminal 50. Remove some of the load from terminal 50, as the 10 V supply is overloaded. Maximum 15 mA or minimum 590 Ω.

A short circuit in a connected potentiometer or incorrect wiring of the potentiometer can cause this condition.

**Troubleshooting**

- Remove the wiring from terminal 50. If the warning clears, the problem is with the wiring. If the warning does not clear, replace the control card.

**WARNING/ALARM 2, Live zero error**

This warning or alarm only appears if programmed in *parameter 6-01 Live Zero Timeout Function*. The signal on 1 of the analog inputs is less than 50% of the minimum value programmed for that input. Broken wiring or a faulty device sending the signal can cause this condition.

**Troubleshooting**

- Check the connections on all the analog mains terminals.
  - Control card terminals 53 and 54 for signals, terminal 55 common.
  - VLT® General Purpose I/O MCB 101 terminals 11 and 12 for signals, terminal 10 common.
  - VLT® Analog I/O Option MCB 109 terminals 1, 3, and 5 for signals, terminals 2, 4, and 6 common.
- Check that the frequency converter programming and switch settings match the analog signal type.
- Perform an input terminal signal test.

**WARNING/ALARM 3, No motor**

No motor is connected to the output of the frequency converter.

**WARNING/ALARM 4, Mains phase loss**

A phase is missing on the supply side, or the mains voltage imbalance is too high. This message also appears for a fault in the input rectifier on the frequency converter. Options are programmed in *parameter 14-12 Function at Mains Imbalance*.

**Troubleshooting**

- Check the supply voltage and supply currents to the frequency converter.

**WARNING 5, DC link voltage high**

The DC-link voltage (DC) is higher than the high-voltage warning limit. The limit depends on the frequency converter voltage rating. The unit is still active.

**WARNING 6, DC link voltage low**

The DC-link voltage (DC) is lower than the low-voltage warning limit. The limit depends on the frequency converter voltage rating. The unit is still active.

**WARNING/ALARM 7, DC overvoltage**

If the DC-link voltage exceeds the limit, the frequency converter trips after a certain time.

**Troubleshooting**

- Connect a brake resistor.
- Extend the ramp time.
- Change the ramp type.
- Activate the functions in *parameter 2-10 Brake Function*.

- Increase *parameter 14-26 Trip Delay at Inverter Fault*.
- If the alarm/warning occurs during a power sag, use kinetic back-up (*parameter 14-10 Mains Failure*).

**WARNING/ALARM 8, DC under voltage**

If the DC-link voltage drops below the undervoltage limit, the frequency converter checks if a 24 V DC back-up supply is connected. If no 24 V DC back-up supply is connected, the frequency converter trips after a fixed time delay. The time delay varies with unit size.

**Troubleshooting**

- Check that the supply voltage matches the frequency converter voltage.
- Perform an input voltage test.
- Perform a soft charge circuit test.

**WARNING/ALARM 9, Inverter overload**

The frequency converter has run with more than 100% overload for too long and is about to cut out. The counter for electronic thermal inverter protection issues a warning at 98% and trips at 100% with an alarm. The frequency converter cannot be reset until the counter is below 90%.

**Troubleshooting**

- Compare the output current shown on the LCP with the frequency converter rated current.
- Compare the output current shown on the LCP with the measured motor current.
- Show the thermal frequency converter load on the LCP and monitor the value. When running above the frequency converter continuous current rating, the counter increases. When running below the frequency converter continuous current rating, the counter decreases.

**WARNING/ALARM 10, Motor overload temperature**

According to the electronic thermal protection (ETR), the motor is too hot. Select whether the frequency converter issues a warning or an alarm when the counter reaches 100% in *parameter 1-90 Motor Thermal Protection*. The fault occurs when the motor runs with more than 100% overload for too long.

**Troubleshooting**

- Check for motor overheating.
- Check if the motor is mechanically overloaded.
- Check that the motor current set in *parameter 1-24 Motor Current* is correct.
- Ensure that the motor data in *parameters 1-20 to 1-25* are set correctly.
- If an external fan is in use, check that it is selected in *parameter 1-91 Motor External Fan*.
- Running AMA in *parameter 1-29 Automatic Motor Adaptation (AMA)* tunes the frequency converter

to the motor more accurately and reduces thermal loading.

#### WARNING/ALARM 11, Motor thermistor overtemp

Check whether the thermistor is disconnected. Select whether the frequency converter issues a warning or an alarm in *parameter 1-90 Motor Thermal Protection*.

##### Troubleshooting

- Check for motor overheating.
- Check if the motor is mechanically overloaded.
- When using terminal 53 or 54, check that the thermistor is connected correctly between either terminal 53 or 54 (analog voltage input) and terminal 50 (+10 V supply). Also check that the terminal switch for 53 or 54 is set for voltage. Check that *parameter 1-93 Thermistor Source* selects terminal 53 or 54.
- When using terminal 18, 19, 31, 32, or 33 (digital inputs), check that the thermistor is connected correctly between the digital input terminal used (digital input PNP only) and terminal 50. Select the terminal to use in *parameter 1-93 Thermistor Source*.

#### WARNING/ALARM 12, Torque limit

The torque has exceeded the value in *parameter 4-16 Torque Limit Motor Mode* or the value in *parameter 4-17 Torque Limit Generator Mode*. *Parameter 14-25 Trip Delay at Torque Limit* can change this warning from a warning-only condition to a warning followed by an alarm.

##### Troubleshooting

- If the motor torque limit is exceeded during ramp-up, extend the ramp-up time.
- If the generator torque limit is exceeded during ramp-down, extend the ramp-down time.
- If torque limit occurs while running, increase the torque limit. Make sure that the system can operate safely at a higher torque.
- Check the application for excessive current draw on the motor.

#### WARNING/ALARM 13, Over current

The inverter peak current limit (approximately 200% of the rated current) is exceeded. The warning lasts approximately 1.5 s, then the frequency converter trips and issues an alarm. Shock loading or quick acceleration with high-inertia loads can cause this fault. If the acceleration during ramp-up is quick, the fault can also appear after kinetic back-up. If extended mechanical brake control is selected, a trip can be reset externally.

##### Troubleshooting

- Remove the power and check if the motor shaft can be turned.
- Check that the motor size matches the frequency converter.
- Check that the motor data is correct in *parameters 1-20 to 1-25*.

#### ALARM 14, Earth (ground) fault

There is current from the output phase to ground, either in the cable between the frequency converter and the motor, or in the motor itself. Ground fault is detected by the current transducers that measure current going out from the frequency converter and current going into the frequency converter from the motor. Ground fault is issued if the deviation of the two currents is too large (the current going out of the frequency converter should be the same as the current going into the frequency converter).

##### Troubleshooting

- Remove power to the frequency converter and repair the ground fault.
- Check for ground faults in the motor by measuring the resistance to ground of the motor cables and the motor with a megohmmeter.
- Reset any potential individual offset in the 3 current transducers in FC 302: perform the manual initialisation or perform a complete AMA. This method is most relevant after changing the power card.

#### ALARM 15, Hardware mismatch

A fitted option is not operational with the present control board hardware or software.

Record the value of the following parameters and contact Danfoss:

- *Parameter 15-40 FC Type*.
- *Parameter 15-41 Power Section*.
- *Parameter 15-42 Voltage*.
- *Parameter 15-43 Software Version*.
- *Parameter 15-45 Actual Typecode String*.
- *Parameter 15-49 SW ID Control Card*.
- *Parameter 15-50 SW ID Power Card*.
- *Parameter 15-60 Option Mounted*.
- *Parameter 15-61 Option SW Version* (for each option slot).

#### ALARM 16, Short circuit

There is short-circuiting in the motor or motor wiring.

##### Troubleshooting

- Remove the power to the frequency converter and repair the short circuit.

**WARNING/ALARM 17, Control word timeout**

There is no communication to the frequency converter. The warning is only active when *parameter 8-04 Control Word Timeout Function* is NOT set to [0] Off. If *parameter 8-04 Control Word Timeout Function* is set to [5] Stop and Trip, a warning appears, and the frequency converter ramps down to a stop and shows an alarm.

**Troubleshooting**

- Check the connections on the serial communication cable.
- Increase *parameter 8-03 Control Word Timeout Time*.
- Check the operation of the communication equipment.
- Verify a proper installation based on EMC requirements.

**WARNING/ALARM 20, Temp. input error**

The temperature sensor is not connected.

**WARNING/ALARM 21, Parameter error**

The parameter is out of range. The parameter number is reported in the display.

**Troubleshooting**

- Set the affected parameter to a valid value.

**WARNING/ALARM 22, Hoist mechanical brake**

The value of this warning/alarm shows the type of warning/alarm.

0 = The torque reference was not reached before timeout (*parameter 2-27 Torque Ramp Up Time*).

1 = Expected brake feedback not received before timeout (*parameter 2-23 Activate Brake Delay, parameter 2-25 Brake Release Time*).

**WARNING 23, Internal fan fault**

The fan warning function is an extra protective function that checks if the fan is running/mounted. The fan warning can be disabled in *parameter 14-53 Fan Monitor* ([0] Disabled).

For frequency converters with DC fans, there is a feedback sensor mounted in the fan. If the fan is commanded to run and there is no feedback from the sensor, this alarm appears. For frequency converters with AC fans, the voltage to the fan is monitored.

**Troubleshooting**

- Check for proper fan operation.
- Cycle power to the frequency converter and check that the fan operates briefly at start-up.
- Check the sensors on the heat sink and control card.

**WARNING 24, External fan fault**

The fan warning function is an extra protective function that checks if the fan is running/mounted. The fan warning can be disabled in *parameter 14-53 Fan Monitor* ([0] Disabled).

For frequency converters with DC fans, there is a feedback sensor mounted in the fan. If the fan is commanded to run and there is no feedback from the sensor, this alarm appears. For frequency converters with AC fans, the voltage to the fan is monitored.

**Troubleshooting**

- Check for proper fan operation.
- Cycle power to the frequency converter and check that the fan operates briefly at start-up.
- Check the sensors on the heat sink and control card.

**WARNING 25, Brake resistor short circuit**

The brake resistor is monitored during operation. If a short circuit occurs, the brake function is disabled and the warning appears. The frequency converter is still operational, but without the brake function.

**Troubleshooting**

- Remove the power to the frequency converter and replace the brake resistor (see *parameter 2-15 Brake Check*).

**WARNING/ALARM 26, Brake resistor power limit**

The power transmitted to the brake resistor is calculated as a mean value over the last 120 s of run time. The calculation is based on the DC-link voltage and the brake resistor value set in *parameter 2-16 AC brake Max. Current*. The warning is active when the dissipated braking power is higher than 90% of the brake resistor power. If option [2] Trip is selected in *parameter 2-13 Brake Power Monitoring*, the frequency converter trips when the dissipated braking power reaches 100%.

**WARNING/ALARM 27, Brake chopper fault**

The brake transistor is monitored during operation, and if a short circuit occurs, the brake function is disabled and a warning is issued. The frequency converter is still operational, but since the brake transistor has short-circuited, substantial power is transmitted to the brake resistor, even if it is inactive.

**Troubleshooting**

- Remove power to the frequency converter and remove the brake resistor.

**WARNING/ALARM 28, Brake check failed**

The brake resistor is not connected or not working. Check *parameter 2-15 Brake Check*.

**ALARM 30, Motor phase U missing**

Motor phase U between the frequency converter and the motor is missing.

**Troubleshooting**

- Remove the power from the frequency converter and check motor phase U.

**ALARM 31, Motor phase V missing**

Motor phase V between the frequency converter and the motor is missing.

**Troubleshooting**

- Remove the power from the frequency converter and check motor phase V.

**ALARM 32, Motor phase W missing**

Motor phase W between the frequency converter and the motor is missing.

**Troubleshooting**

- Remove the power from the frequency converter and check motor phase W.

**ALARM 33, Inrush fault**

Too many power-ups have occurred within a short time period.

**Troubleshooting**

- Let the unit cool to operating temperature.

**WARNING/ALARM 34, Fieldbus communication fault**

The fieldbus on the communication option card is not working.

**WARNING/ALARM 35, Option fault**

An option alarm is received. The alarm is option-specific. The most likely cause is a power-up or a communication fault.

**WARNING/ALARM 36, Mains failure**

This warning/alarm is only active if the supply voltage to the frequency converter is lost and *parameter 14-10 Mains Failure* is not set to option [0] *No Function*. Check the fuses to the frequency converter and mains supply to the unit.

**ALARM 37, Phase imbalance**

There is a current imbalance between the power units.

**ALARM 38, Internal fault**

When an internal fault occurs, a code number defined in *Table 7.4* is displayed.

**Troubleshooting**

- Cycle power.
- Check that the option is properly installed.
- Check for loose or missing wiring.

It may be necessary to contact the Danfoss supplier or service department. Note the code number for further troubleshooting directions.

Number	Text
0	The serial port cannot be initialised. Contact the Danfoss supplier or Danfoss Service Department.
256–258	The power EEPROM data is defective or too old. Replace the power card.
512–519	Internal fault. Contact the Danfoss supplier or Danfoss Service Department.
783	Parameter value outside of minimum/maximum limits.
1024–1284	Internal fault. Contact the Danfoss supplier or the Danfoss Service Department.
1299	The option software in slot A is too old.
1300	The option software in slot B is too old.

Number	Text
1302	The option software in slot C1 is too old.
1315	The option software in slot A is not supported (not allowed).
1316	The option software in slot B is not supported (not allowed).
1318	The option software in slot C1 is not supported (not allowed).
1379–2819	Internal fault. Contact the Danfoss supplier or Danfoss Service Department.
1792	HW reset of DSP.
1793	Motor derived parameters not transferred correctly to the DSP.
1794	Power data not transferred correctly at power-up to the DSP.
1795	The DSP has received too many unknown SPI telegrams. The frequency converter also uses this fault code if the MCO does not power up correctly, for example due to poor EMC protection or improper grounding.
1796	RAM copy error.
2561	Replace the control card.
2820	LCP stack overflow.
2821	Serial port overflow.
2822	USB port overflow.
3072–5122	Parameter value is outside its limits.
5123	Option in slot A: Hardware incompatible with the control board hardware.
5124	Option in slot B: Hardware incompatible with the control board hardware.
5125	Option in slot C0: Hardware incompatible with the control board hardware.
5126	Option in slot C1: Hardware incompatible with the control board hardware.
5376–6231	Internal fault. Contact the Danfoss supplier or Danfoss Service Department.

**Table 7.4 Internal Fault Codes**

**ALARM 39, Heat sink sensor**

No feedback from the heat sink temperature sensor.

The signal from the IGBT thermal sensor is not available on the power card. The problem could be on the power card, on the gate drive card, or the ribbon cable between the power card and gate drive card.

**WARNING 40, Overload of digital output terminal 27**

Check the load connected to terminal 27 or remove the short circuit connection. Check *parameter 5-00 Digital I/O Mode* and *parameter 5-01 Terminal 27 Mode*.

**WARNING 41, Overload of digital output terminal 29**

Check the load connected to terminal 29 or remove the short circuit connection. Check *parameter 5-00 Digital I/O Mode* and *parameter 5-02 Terminal 29 Mode*.

**WARNING 42, Overload of digital output on X30/6 or overload of digital output on X30/7**

For terminal X30/6, check the load connected to terminal X30/6 or remove the short circuit connection. Check *parameter 5-32 Term X30/6 Digi Out (MCB 101)*.

For terminal X30/7, check the load connected to terminal X30/7 or remove the short-circuit connection. Check *parameter 5-33 Term X30/7 Digi Out (MCB 101)*.

**ALARM 43, Ext. supply**

VLT® Extended Relay Option MCB 113 is mounted without external 24 V DC. Either connect an 24 V DC external supply or specify that no external supply is used via *parameter 14-80 Option Supplied by External 24VDC, [0] No.* A change in *parameter 14-80 Option Supplied by External 24VDC* requires a power cycle.

**ALARM 45, Earth fault 2**

Ground fault.

**Troubleshooting**

- Check for proper grounding and loose connections.
- Check for proper wire size.
- Check the motor cables for short circuits or leakage currents.

**ALARM 46, Power card supply**

The supply on the power card is out of range.

There are 3 supplies generated by the switch mode supply (SMPS) on the power card:

- 24 V
- 5 V
- $\pm 18$  V

When powered with 24 V DC with VLT® 24 V DC Supply MCB 107, only the 24 V and 5 V supplies are monitored. When powered with 3-phase mains voltage, all 3 supplies are monitored.

**Troubleshooting**

- Check for a defective power card.
- Check for a defective control card.
- Check for a defective option card.
- If a 24 V DC supply is used, verify proper supply power.

**WARNING 47, 24 V supply low**

The supply on the power card is out of range.

There are 3 supplies generated by the switch mode supply (SMPS) on the power card:

- 24 V
- 5 V
- $\pm 18$  V

**Troubleshooting**

- Check for a defective power card.

**WARNING 48, 1.8 V supply low**

The 1.8 V DC supply used on the control card is outside of the allowable limits. The supply is measured on the control card. Check for a defective control card. If an option card is present, check for overvoltage.

**WARNING 49, Speed limit**

When the speed is outside of the specified range in *parameter 4-11 Motor Speed Low Limit [RPM]* and *parameter 4-13 Motor Speed High Limit [RPM]*, the frequency converter shows a warning. When the speed is below the specified limit in *parameter 1-86 Trip Speed Low [RPM]* (except when starting or stopping), the frequency converter trips.

**ALARM 50, AMA calibration failed**

Contact the Danfoss supplier or Danfoss Service Department.

**ALARM 51, AMA check  $U_{nom}$  and  $I_{nom}$** 

The settings for motor voltage, motor current, and motor power are wrong. Check the settings in *parameters 1–20 to 1–25*.

**ALARM 52, AMA low  $I_{nom}$** 

The motor current is too low. Check the settings in *parameter 4-18 Current Limit*.

**ALARM 53, AMA motor too big**

The motor is too large for the AMA to operate.

**ALARM 54, AMA motor too small**

The motor is too small for the AMA to operate.

**ALARM 55, AMA parameter out of range**

The parameter values of the motor are outside of the acceptable range. AMA cannot run.

**ALARM 56, AMA interrupted by user**

The AMA is manually interrupted.

**ALARM 57, AMA internal fault**

Try to restart AMA. Repeated restarts can overheat the motor.

**ALARM 58, AMA Internal fault**

Contact the Danfoss supplier.

**WARNING 59, Current limit**

The current is higher than the value in *parameter 4-18 Current Limit*. Ensure that motor data in *parameters 1–20 to 1–25* are set correctly. Increase the current limit if necessary. Ensure that the system can operate safely at a higher limit.

**WARNING 60, External interlock**

A digital input signal is indicating a fault condition externally to the frequency converter. An external interlock has commanded the frequency converter to trip. Clear the external fault condition. To resume normal operation, apply 24 V DC to the terminal programmed for external interlock. Reset the frequency converter.

**WARNING/ALARM 61, Feedback error**

An error between calculated speed and speed measurement from feedback device.



**Troubleshooting**

- Check the settings for warning/alarm/disabling in *parameter 4-30 Motor Feedback Loss Function*.
- Set the tolerable error in *parameter 4-31 Motor Feedback Speed Error*.
- Set the tolerable feedback loss time in *parameter 4-32 Motor Feedback Loss Timeout*.

**WARNING 62, Output frequency at maximum limit**

The output frequency has reached the value set in *parameter 4-19 Max Output Frequency*. Check the application for possible causes. Possibly increase the output frequency limit. Be sure that the system can operate safely at a higher output frequency. The warning clears when the output drops below the maximum limit.

**ALARM 63, Mechanical brake low**

The actual motor current has not exceeded the release brake current within the start delay time window.

**ALARM 64, Voltage Limit**

The load and speed combination demands a motor voltage higher than the actual DC-link voltage.

**WARNING/ALARM 65, Control card over temperature**

The cut-out temperature of the control card is 80 °C.

**Troubleshooting**

- Check that the ambient operating temperature is within the limits.
- Check for clogged filters.
- Check the fan operation.
- Check the control card.

**WARNING 66, Heat sink temperature low**

The frequency converter is too cold to operate. This warning is based on the temperature sensor in the IGBT module.

Increase the ambient temperature of the unit. Also, a trickle amount of current can be supplied to the frequency converter whenever the motor is stopped by setting *parameter 2-00 DC Hold/Preheat Current* at 5% and *parameter 1-80 Function at Stop*.

**ALARM 67, Option module configuration has changed**

One or more options have either been added or removed since the last power-down. Check that the configuration change is intentional and reset the unit.

**ALARM 68, Safe Stop activated**

STO has been activated. To resume normal operation, apply 24 V DC to terminal 37, then send a reset signal (via bus, digital I/O, or by pressing [Reset]).

**ALARM 69, Power card temperature**

The temperature sensor on the power card is either too hot or too cold.

**Troubleshooting**

- Check that the ambient operating temperature is within limits.
- Check for clogged filters.
- Check fan operation.
- Check the power card.

**ALARM 70, Illegal FC configuration**

The control card and power card are incompatible. To check compatibility, contact the Danfoss supplier with the type code of the unit from the nameplate and the part numbers of the cards.

**ALARM 71, PTC 1 safe stop**

STO has been activated from the VLT® PTC Thermistor Card MCB 112 (motor too warm). Normal operation can be resumed when the MCB 112 applies 24 V DC to terminal 37 again (when the motor temperature reaches an acceptable level) and when the digital input from the MCB 112 is deactivated. When that happens, send a reset signal (via bus or digital I/O, or press [Reset]).

**ALARM 72, Dangerous failure**

STO with trip lock. An unexpected combination of STO commands has occurred:

- VLT® PTC Thermistor Card MCB 112 enables X44/10, but STO is not enabled.
- MCB 112 is the only device using STO (specified through selection [4] *PTC 1 Alarm* or [5] *PTC 1 Warning* in *parameter 5-19 Terminal 37 Safe Stop*), STO is activated, and X44/10 is not activated.

**WARNING 73, Safe Stop auto restart**

Safe Torque Off activated. With automatic restart enabled, the motor can start when the fault is cleared.

**ALARM 74, PTC Thermistor**

Alarm related to VLT® PTC Thermistor Card MCB 112. The PTC is not working.

**ALARM 75, Illegal profile sel.**

Do not write the parameter value while the motor runs. Stop motor before writing the MCO profile to *parameter 8-10 Control Word Profile*.

**WARNING 76, Power unit setup**

The required number of power units does not match the detected number of active power units.

**Troubleshooting**

When replacing an F-frame module, this warning occurs, if the power-specific data in the module power card does not match the rest of the frequency converter. Confirm that the spare part and its power card are the correct part number.

**WARNING 77, Reduced power mode**

The frequency converter is operating in reduced power mode (less than the allowed number of inverter sections). This warning is generated on power cycle when the

frequency converter is set to run with fewer inverters and remains on.

#### ALARM 78, Tracking error

The difference between setpoint value and actual value exceeds the value in *parameter 4-35 Tracking Error*. Disable the function or select an alarm/warning in *parameter 4-34 Tracking Error Function*. Investigate the mechanics around the load and motor, check feedback connections from motor encoder to frequency converter. Select motor feedback function in *parameter 4-30 Motor Feedback Loss Function*. Adjust tracking error band in *parameter 4-35 Tracking Error* and *parameter 4-37 Tracking Error Ramping*.

#### ALARM 79, Illegal power section configuration

The scaling card has an incorrect part number or is not installed. The MK102 connector on the power card could not be installed.

#### ALARM 80, Drive initialised to default value

Parameter settings are initialised to default settings after a manual reset. To clear the alarm, reset the unit.

#### ALARM 81, CSIV corrupt

CSIV file has syntax errors.

#### ALARM 82, CSIV parameter error

CSIV failed to initialise a parameter.

#### ALARM 83, Illegal option combination

The mounted options are incompatible.

#### ALARM 84, No safety option

The safety option was removed without applying a general reset. Reconnect the safety option.

#### ALARM 88, Option detection

A change in the option layout is detected. *Parameter 14-89 Option Detection* is set to [0] *Frozen configuration* and the option layout has been changed.

- To apply the change, enable option layout changes in *parameter 14-89 Option Detection*.
- Alternatively, restore the correct option configuration.

#### WARNING 89, Mechanical brake sliding

The hoist brake monitor detects a motor speed exceeding 10 RPM.

#### ALARM 90, Feedback monitor

Check the connection to encoder/resolver option and, if necessary, replace VLT® Encoder Input MCB 102 or VLT® Resolver Input MCB 103.

#### ALARM 91, Analog input 54 wrong settings

Set switch S202 in position OFF (voltage input) when a KTY sensor is connected to analog input terminal 54.

#### ALARM 99, Locked rotor

Rotor is blocked.

#### WARNING/ALARM 104, Mixing fan fault

The fan is not operating. The fan monitor checks that the fan is spinning at power-up or whenever the mixing fan is turned on. The mixing-fan fault can be configured as a warning or an alarm trip in *parameter 14-53 Fan Monitor*.

#### Troubleshooting

- Cycle power to the frequency converter to determine if the warning/alarm returns.

#### WARNING/ALARM 122, Mot. rotat. unexp.

The frequency converter performs a function that requires the motor to be at standstill, for example DC hold for PM motors.

#### WARNING 163, ATEX ETR cur.lim.warning

The frequency converter has run above the characteristic curve for more than 50 s. The warning is activated at 83% and deactivated at 65% of the permitted thermal overload.

#### ALARM 164, ATEX ETR cur.lim.alarm

Operating above the characteristic curve for more than 60 s within a period of 600 s activates the alarm, and the frequency converter trips.

#### WARNING 165, ATEX ETR freq.lim.warning

The frequency converter is running for more than 50 s below the permitted minimum frequency (*parameter 1-98 ATEX ETR interpol. points freq.*).

#### ALARM 166, ATEX ETR freq.lim.alarm

The frequency converter has operated for more than 60 s (in a period of 600 s) below the permitted minimum frequency (*parameter 1-98 ATEX ETR interpol. points freq.*).

#### ALARM 244, Heat Sink temperature

This alarm is only for enclosure type F frequency converters. It is equivalent to Alarm 29. The report value in the alarm log indicates which power module generated the alarm:

- 1 = Left most inverter module.
- 2 = Middle inverter module in enclosure size F12 or F13.
- 2 = Right inverter module in enclosure size F10 or F11.
- 2 = Second frequency converter from the left inverter module in enclosure size F14 or F15.
- 3 = Rght inverter module in enclosure sizes F12 or F13.
- 3 = Tird from the left intverter module in enclosure size F14 or F15.
- 4 = Far right inverter module in enclosure sizes F14 or F15.
- 5 = Rectifier module.
- 6 = Right rectifier module in enclosure sizes F14 or F15.

**WARNING 251, New typecode**

The power card or other components are replaced and the type code is changed.

**Troubleshooting**

- Reset to remove the warning and resume normal operation.

**WARNING 250, New spare part**

A component in the frequency converter has been replaced.

**Troubleshooting**

- Reset the frequency converter for normal operation.

## 7.6 Troubleshooting

Symptom	Possible cause	Test	Solution
Display dark/No function	Missing input power.	See <i>Table 4.3</i> .	Check the input power source.
	Missing or open fuses, or circuit breaker tripped.	See <i>open power fuses and tripped circuit breaker</i> in this table for possible causes.	Follow the recommendations provided.
	No power to the LCP.	Check the LCP cable for proper connection or damage.	Replace the faulty LCP or connection cable.
	Shortcut on control voltage (terminal 12 or 50) or at control terminals.	Check the 24 V control voltage supply for terminal 12/13 to 20-39 or 10 V supply for terminal 50 to 55.	Wire the terminals properly.
	Incompatible LCP (LCP from VLT® 2800 or 5000/6000/8000/ FCD or FCM).		Use only LCP 101 (P/N 130B1124) or LCP 102 (P/N. 130B1107).
	Wrong contrast setting.		Press [Status] + [▲]/[▼] to adjust the contrast.
	Display (LCP) is defective.	Test using a different LCP.	Replace the faulty LCP or connection cable.
	Internal voltage supply fault or SMPS is defective.		Contact supplier.
Intermittent display	Overloaded power supply (SMPS) due to improper control wiring or a fault within the frequency converter.	To rule out a problem in the control wiring, disconnect all control wiring by removing the terminal blocks.	If the display stays lit, the problem is in the control wiring. Check the wiring for shorts or incorrect connections. If the display continues to cut out, follow the procedure for <i>Display dark/No function</i> .
Motor not running	Service switch open or missing motor connection.	Check if the motor is connected and the connection is not interrupted (by a service switch or other devise).	Connect the motor and check the service switch.
	No mains power with 24 V DC option card.	If the display is functioning, but there is no output, check that mains power is applied to the frequency converter.	Apply mains power to run the unit.
	LCP Stop.	Check if [Off] has been pressed.	Press [Auto On] or [Hand On] (depending on operation mode) to run the motor.
	Missing start signal (Standby).	Check <i>parameter 5-10 Terminal 18 Digital Input</i> for correct setting for terminal 18 (use default setting).	Apply a valid start signal to start the motor.
	Motor coast signal active (Coasting).	Check <i>parameter 5-12 Terminal 27 Digital Input</i> for correct setting for terminal 27 (use default setting).	Apply 24 V on terminal 27 or programme this terminal to <i>No operation</i> .
	Wrong reference signal source.	Check reference signal: <ul style="list-style-type: none"> <li>• Local</li> <li>• remote or bus reference?</li> <li>• Preset reference active?</li> <li>• Terminal connection correct?</li> <li>• Scaling of terminals correct?</li> <li>• Reference signal available?</li> </ul>	Programme correct settings. Check <i>parameter 3-13 Reference Site</i> . Set preset reference active in parameter group 3-1* <i>References</i> . Check for correct wiring. Check scaling of terminals. Check reference signal.
Motor running in wrong direction	Motor rotation limit.	Check that <i>parameter 4-10 Motor Speed Direction</i> is programmed correctly.	Program correct settings.
	Active reversing signal.	Check if a reversing command is programmed for the terminal in parameter group 5-1* <i>Digital inputs</i> .	Deactivate reversing signal.
	Wrong motor phase connection.		See <i>chapter 5.5 Checking Motor Rotation</i> .

Symptom	Possible cause	Test	Solution
Motor is not reaching maximum speed	Frequency limits set wrong.	Check output limits in <i>parameter 4-13 Motor Speed High Limit [RPM]</i> , <i>parameter 4-14 Motor Speed High Limit [Hz]</i> , and <i>parameter 4-19 Max Output Frequency</i>	Programme correct limits.
	Reference input signal not scaled correctly.	Check reference input signal scaling in parameter group <i>6-0* Analog I/O mode</i> and parameter group <i>3-1* References</i> .	Programme correct settings.
Motor speed unstable	Possible incorrect parameter settings.	Check the settings of all motor parameters, including all motor compensation settings. For closed loop operation, check PID settings.	Check settings in parameter group <i>1-6* Load Depen. Setting</i> . For closed loop operation, check settings in parameter group <i>20-0* Feedback</i> .
Motor runs rough	Possible overmagnetisation.	Check for incorrect motor settings in all motor parameters.	Check motor settings in parameter groups <i>1-2* Motor data 1-3* Adv Motor Data</i> , and <i>1-5* Load Indep. Setting</i> .
Motor does not brake	Possible incorrect settings in the brake parameters. Possible too short ramp down times.	Check brake parameters. Check ramp time settings.	Check parameter group <i>2-0* DC Brake</i> and <i>3-0* Reference Limits</i> .
Open power fuses or circuit breaker trip	Phase-to-phase short.	Motor or panel has a short phase-to-phase. Check motor and panel phases for shorts.	Eliminate any shorts detected.
	Motor overload.	Motor is overloaded for the application.	Perform start-up test and verify that motor current is within specifications. If motor current is exceeding the nameplate full-load current, the motor may run only with reduced load. Review the specifications for the application.
	Loose connections.	Perform pre-start-up check for loose connections.	Tighten loose connections.
Mains current imbalance greater than 3%	Problem with mains power (see <i>Alarm 4 Mains phase loss</i> description).	Rotate input power leads into the 1 position: A to B, B to C, C to A.	If imbalanced leg follows the wire, it is a power problem. Check the mains power supply.
	Problem with the frequency converter.	Rotate input power leads into the frequency converter 1 position: A to B, B to C, C to A.	If the imbalanced leg stays on same input terminal, it is a problem with the frequency converter. Contact supplier.
Motor current imbalance greater than 3%	Problem with motor or motor wiring.	Rotate output motor leads 1 position: U to V, V to W, W to U.	If the imbalanced leg follows the wire, the problem is in the motor or motor wiring. Check motor and motor wiring.
	Problem with frequency converter.	Rotate output motor leads 1 position: U to V, V to W, W to U.	If the imbalanced leg stays on same output terminal, it is a problem with the unit. Contact supplier.
Frequency converter acceleration problems	Motor data are entered incorrectly.	If warnings or alarms occur, see <i>chapter 7.5 List of Warnings and Alarms</i> . Check that motor data are entered correctly.	Increase the ramp-up time in <i>parameter 3-41 Ramp 1 Ramp Up Time</i> . Increase current limit in <i>parameter 4-18 Current Limit</i> . Increase torque limit in <i>parameter 4-16 Torque Limit Motor Mode</i> .
Frequency converter deceleration problems	Motor data are entered incorrectly.	If warnings or alarms occur, see <i>chapter 7.5 List of Warnings and Alarms</i> . Check that motor data are entered correctly.	Increase the ramp-down time in <i>parameter 3-42 Ramp 1 Ramp Down Time</i> . Enable overvoltage control in <i>parameter 2-17 Over-voltage Control</i> .

Table 7.5 Troubleshooting

## 8 Specifications

### 8.1 Electrical Data

#### 8.1.1 Mains Supply 3x380–500 V AC

Type designation	N90K		N110		N132		N160		N200		N250	
High/normal load*	HO	NO	HO	NO	HO	NO	HO	NO	HO	NO	HO	NO
Typical shaft output at 400 V [kW]	90	110	110	132	132	160	160	200	200	250	250	315
Typical shaft output at 460 V [Hp]	125	150	150	200	200	250	250	300	300	350	350	450
Typical shaft output at 500 V [kW]	110	132	132	160	160	200	200	250	250	315	315	355
Enclosure protection rating IP21	D1h		D1h		D1h		D2h		D2h		D2h	
Enclosure protection rating IP54	D1h		D1h		D1h		D2h		D2h		D2h	
Enclosure protection rating IP20	D3h		D3h		D3h		D4h		D4h		D4h	
<b>Output current</b>												
Continuous (at 400 V) [A]	177	212	212	260	260	315	315	395	395	480	480	588
Intermittent (60 s overload) (at 400 V) [A]	266	233	318	286	390	347	473	435	593	528	720	647
Continuous (at 460/500 V) [A]	160	190	190	240	240	302	302	361	361	443	443	535
Intermittent (60 s overload) (at 460/500 V) [kVA]	240	209	285	264	360	332	453	397	542	487	665	588
Continuous kVA (at 400 V) [kVA]	123	147	147	180	180	218	218	274	274	333	333	407
Continuous kVA (at 460 V) [kVA]	127	151	151	191	191	241	241	288	288	353	353	426
Continuous kVA (at 500 V) [kVA]	139	165	165	208	208	262	262	313	313	384	384	463
<b>Maximum input current</b>												
Continuous (at 400 V) [A]	171	204	204	251	251	304	304	381	381	463	463	567
Continuous (at 460/500 V) [A]	154	183	183	231	231	291	291	348	348	427	427	516
<b>Additional specifications</b>												
Maximum cable size: Mains, motor, brake and load share mm (AWG)	2x95 (2x3/0)						2x185 (2x350 mcm)					
Maximum external mains fuses [A]	315		350		400		550		630		800	
Estimated power loss at 400 V [W] <sup>1)</sup>	2031	2559	2289	2954	2923	3770	3093	4116	4039	5137	5005	6674
Estimated power loss at 460 V [W] <sup>1)</sup>	1828	2261	2051	2724	2689	3628	2872	3569	3575	4566	4458	5714
Weight, enclosure protection rating IP21, IP54 kg (lbs.)	62 (135)						125 (275)					
Weight, enclosure protection rating IP20 kg (lbs.)	62 (135)						125 (275)					
Efficiency <sup>2)</sup>	0.98											
Output frequency	0–590 Hz											
Heatsink overtemperature trip	110 °C											
Control card ambient trip	75 °C											
*High overload=150% current for 60 s, Normal overload=110% current for 60 s.												

Table 8.1 Mains Supply 3x380–500 V AC

8.1.2 Mains Supply 3x525–690 V AC

Type designation	N55K		N75K		N90K		N110		N132		N160	
High/normal load*	HO	NO	HO	NO	HO	NO	HO	NO	HO	NO	HO	NO
Typical shaft output at 550 V [kW]	45	55	55	75	75	90	90	110	110	132	132	160
Typical shaft output at 575 V [hp]	60	75	75	100	100	125	125	150	150	200	200	250
Typical shaft output at 690 V [kW]	55	75	75	90	90	110	110	132	132	160	160	200
Enclosure protection rating IP21	D1h		D1h		D1h		D1h		D1h		D2h	
Enclosure protection rating IP54	D1h		D1h		D1h		D1h		D1h		D2h	
Enclosure protection rating IP20	D3h		D3h		D3h		D3h		D3h		D4h	
<b>Output current</b>												
Continuous (at 550 V) [A]	76	90	90	113	113	137	137	162	162	201	201	253
Intermittent (60 s overload) (at 550 V) [A]	114	99	135	124	170	151	206	178	243	221	302	278
Continuous (at 575/690 V) [A]	73	86	86	108	108	131	131	155	155	192	192	242
Intermittent (60 s overload) (at 575/690 V) [kVA]	110	95	129	119	162	144	197	171	233	211	288	266
Continuous kVA (at 550 V) [kVA]	69	87	82	103	103	129	125	157	147	185	183	229
Continuous kVA (at 575 V) [kVA]	73	86	86	108	108	131	131	154	154	191	191	241
Continuous kVA (at 690 V) [kVA]	87	103	103	129	129	157	157	185	185	229	229	289
<b>Maximum input current</b>												
Continuous (at 550 V) [A]	77	89	89	110	110	130	130	158	158	198	198	245
Continuous (at 575 V) [A]	74	85	85	106	106	124	124	151	151	189	189	234
Continuous (at 690 V)	77	87	87	109	109	128	128	155	155	197	197	240
<b>Additional specifications</b>												
Maximum cable size: Mains, motor, brake and load share mm (AWG)	2x95 (2x3/0)										2x185 (2x350)	
Maximum external mains fuses [A]	160		315		315		315		315		550	
Estimated power loss at 575 V [W] <sup>1)</sup>	1018	1162	1162	1428	1430	1740	1742	2101	2080	2649	2361	3074
Estimated power loss at 690 V [W] <sup>1)</sup>	1056	1203	1204	1476	1479	1796	1798	2165	2157	2738	2443	3172
Weight, enclosure protection rating IP21, IP54 kg (lbs.)	62 (135)										125 (275)	
Weight, enclosure protection rating IP20 kg (lbs.)	125 (275)											
Efficiency <sup>2)</sup>	0.98											
Output frequency	0–590 Hz											
Heatsink overtemperature trip	110 °C											
Control card ambient trip	75 °C											
*High overload=150% current for 60 s, Normal overload=110% current for 60 s.												

Table 8.2 Mains Supply 3x525–690 V AC

Type designation	N200		N250		N315	
High/normal load*	HO	NO	HO	NO	HO	NO
Typical shaft output at 550 V [kW]	160	200	200	250	250	315
Typical shaft output at 575 V [hp]	250	300	300	350	350	400
Typical shaft output at 690 V [kW]	200	250	250	315	315	400
Enclosure protection rating IP21	D2h		D2h		D2h	
Enclosure protection rating IP54	D2h		D2h		D2h	
Enclosure protection rating IP20	D4h		D4h		D4h	
<b>Output current</b>						
Continuous (at 550 V) [A]	253	303	303	360	360	418
Intermittent (60 s overload) (at 550 V)[A]	380	333	455	396	540	460
Continuous (at 575/690 V) [A]	242	290	290	344	344	400
Intermittent (60 s overload) (at 575/690 V) [kVA]	363	319	435	378	516	440
Continuous kVA (at 550 V) [kVA]	241	289	289	343	343	398
Continuous kVA (at 575 V) [kVA]	241	289	289	343	343	398
Continuous kVA (at 690 V) [kVA]	289	347	347	411	411	478
<b>Maximum input current</b>						
Continuous (at 550 V) [A]	245	299	299	355	355	408
Continuous (at 575 V) [A]	234	286	286	339	339	390
Continuous (at 690 V)	240	296	296	352	352	400
<b>Additional specifications</b>						
Maximum cable size: Mains, motor, brake and load share mm (AWG)	2x185 (2x350)					
Maximum external mains fuses [A]	550					
Estimated power loss at 575 V [W] <sup>1)</sup>	3012	3723	3642	4465	4146	5028
Estimated power loss at 690 V [W] <sup>1)</sup>	3121	3848	3768	4610	4254	5150
Weight, enclosure protection rating IP21, IP54 kg (lbs.)	125 (275)					
Weight, enclosure protection rating IP20 kg (lbs.)	125 (275)					
Efficiency <sup>2)</sup>	0.98					
Output frequency	0–590 Hz					
Heatsink overtemperature trip	110 °C					
Control card ambient trip	75 °C					
*High overload=150% current for 60 s, Normal overload=110% current for 60 s.						

**Table 8.3 Mains Supply 3x525–690 V AC**

1) Applies for dimensioning of frequency converter cooling. If the switching frequency is higher than the default setting, the power losses may increase. LCP and typical control card power consumptions are included. For power loss data according to EN 50598-2, refer to [www.danfoss.com/vlteneryefficiency](http://www.danfoss.com/vlteneryefficiency).

2) Efficiency measured at nominal current. For energy efficiency class, see chapter 8.4 Ambient Conditions. For part load losses, refer to [www.danfoss.com/vlteneryefficiency](http://www.danfoss.com/vlteneryefficiency).

The typical power loss is at nominal load conditions and expected to be within  $\pm 15\%$  (tolerance relates to variety in voltage and cable conditions).

The losses are based on the default switching frequency. The losses increase significantly at higher switching frequencies.

The options cabinet adds weight to the frequency converter. The maximum weights of the D5h–D8h frames is shown in *Table 8.4*



Enclosure size	Description	Maximum weight [kg (lbs.)]
D5h	D1h ratings+disconnect and/or brake chopper	166 (255)
D6h	D1h ratings+contactor and/or circuit breaker	129 (285)
D7h	D2h ratings+disconnect and/or brake chopper or oversized wiring cabinet	200 (440)
D8h	D2h ratings+contactor and/or circuit breaker	225 (496)

Table 8.4 D5h–D8h Weights

## 8.2 Mains Supply

Mains supply (L1, L2, L3)

Supply voltage 380–500 V ±10%, 525–690 V ±10%

*Mains voltage low/mains voltage drop-out:*

*During low mains voltage or a mains drop-out, the frequency converter continues until the DC-link voltage drops below the minimum stop level, which corresponds typically to 15% below the frequency converter's lowest rated supply voltage. Power-up and full torque cannot be expected at mains voltage lower than 10% below the frequency converter's lowest rated supply voltage.*

Supply frequency 50/60 Hz ±5%

Maximum imbalance temporary between mains phases 3.0% of rated supply voltage

True power factor ( $\lambda$ )  $\geq 0.9$  nominal at rated load

Displacement power factor ( $\cos \Phi$ ) near unity (>0.98)

Switching on input supply L1, L2, L3 (power ups) maximum 1 time/2 minutes

Environment according to EN60664-1 overvoltage category III/pollution degree 2

*The unit is suitable for use on a circuit capable of delivering not more than 100,000 RMS symmetrical Amperes, 480/600 V*



## 8.3 Motor Output and Motor Data

Motor output (U, V, W)

Output voltage 0–100% of supply voltage

Output frequency 0–590 Hz\*

Switching on output Unlimited

Ramp times 0.01–3600 s

\* *Dependent on voltage and power*

Torque characteristics

Starting torque (constant torque) maximum 160% for 60 s \*

Starting torque maximum 180% up to 0.5 s\*

Overload torque (constant torque) maximum 160% for 60 s\*

*Percentage relates to the frequency converter's nominal torque*

## 8.4 Ambient Conditions

Environment

Enclosure size D1h/D2h/D5h/D6h/D7h/D8h IP21/Type 1, IP54/Type12

Enclosure type D3h/D4h IP20/Chassis

Vibration test all enclosure types 1.0 g

Relative humidity 5%-95% (IEC 721-3-3; Class 3K3 (non-condensing) during operation

Aggressive environment (IEC 60068-2-43) H<sub>2</sub>S test class Kd

Test method according to IEC 60068-2-43 H<sub>2</sub>S (10 days)

Ambient temperature (at SFAVM switching mode)

- with derating maximum 55 °C

- with full output power of typical EFF2 motors (up to 90% output current) maximum 50 °C

- at full continuous FC output current maximum 45 °C

Minimum ambient temperature during full-scale operation	0 °C
Minimum ambient temperature at reduced performance	10 °C
Temperature during storage/transport	-25 to +65/70 °C
Maximum altitude above sea level without derating	1000 m
Maximum altitude above sea level with derating	3000 m

1) For more information on derating, see section on special conditions in the Design Guide.

EMC standards, Emission	EN 61800-3
EMC standards, Immunity	EN 61800-3
Energy efficiency class <sup>2)</sup>	IE2

2) Determined according to EN50598-2 at:

- Rated load.
- 90% rated frequency.
- Switching frequency factory setting.
- Switching pattern factory setting.

## 8.5 Cable Specifications

Cable lengths and cross-sections for control cables<sup>1)</sup>

Maximum motor cable length, screened/armoured	150 m
Maximum motor cable length, unscreened/unarmoured	300 m
Maximum cross-section to motor, mains, load sharing, and brake	
Maximum cross-section to control terminals, rigid wire	1.5 mm <sup>2</sup> /16 AWG (2x0.75 mm <sup>2</sup> )
Maximum cross-section to control terminals, flexible cable	1 mm <sup>2</sup> /18 AWG
Maximum cross-section to control terminals, cable with enclosed core	0.5 mm <sup>2</sup> /20 AWG
Minimum cross-section to control terminals	0.25 mm <sup>2</sup>

1) For power cables, see electrical tables in chapter 8.1 Electrical Data.

## 8.6 Control Input/Output and Control Data

Digital inputs

Programmable digital inputs	4 (6)
Terminal number	18, 19, 27 <sup>1)</sup> , 29 <sup>1)</sup> , 32, 33
Logic	PNP or NPN
Voltage level	0–24 V DC
Voltage level, logic 0 PNP	<5 V DC
Voltage level, logic 1 PNP	>10 V DC
Voltage level, logic 0 NPN	>19 V DC
Voltage level, logic 1 NPN	<14 V DC
Maximum voltage on input	28 V DC
Input resistance, R <sub>i</sub>	approximately 4 kΩ

All digital inputs are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

1) Terminals 27 and 29 can also be programmed as outputs.

Analog inputs

Number of analog inputs	2
Terminal number	53, 54
Modes	Voltage or current
Mode select	Switches A53 and A54
Voltage mode	Switch A53/A54=(U)
Voltage level	-10 V to +10 V (scaleable)
Input resistance, R <sub>i</sub>	approximately 10 kΩ
Maximum voltage	±20 V
Current mode	Switch A53/A54=(I)
Current level	0/4 to 20 mA (scaleable)

Input resistance, $R_i$	approximately 200 $\Omega$
Maximum current	30 mA
Resolution for analog inputs	10 bit (+ sign)
Accuracy of analog inputs	Maximum error 0.5% of full scale
Bandwidth	100 Hz

The analog inputs are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.




Illustration 8.1 PELV Isolation

Pulse inputs	
Programmable pulse inputs	2
Terminal number pulse	29, 33
Maximum frequency at terminal, 29, 33	110 kHz (push-pull driven)
Maximum frequency at terminal, 29, 33	5 kHz (open collector)
Minimum frequency at terminal 29, 33	4 Hz
Voltage level	see chapter 8.6.1 Digital Inputs
Maximum voltage on input	28 V DC
Input resistance, $R_i$	approximately 4 k $\Omega$
Pulse input accuracy (0.1–1 kHz)	Maximum error: 0.1% of full scale

Analog output	
Number of programmable analog outputs	1
Terminal number	42
Current range at analog output	0/4-20 mA
Maximum resistor load to common at analog output	500 $\Omega$
Accuracy on analog output	Maximum error: 0.8% of full scale
Resolution on analog output	8 bit

The analog output is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Control card, RS485 serial communication

Terminal number	68 (PTX+, RX+), 69 (N, TX-, RX-)
Terminal number 61	Common for terminals 68 and 69

The RS485 serial communication circuit is functionally separated from other central circuits and galvanically isolated from the supply voltage (PELV).

Digital output

Programmable digital/pulse outputs	2
Terminal number	27, 29 <sup>1)</sup>
Voltage level at digital/frequency output	0–24 V
Maximum output current (sink or source)	40 mA
Maximum load at frequency output	1 k $\Omega$
Maximum capacitive load at frequency output	10 nF
Minimum output frequency at frequency output	0 Hz
Maximum output frequency at frequency output	32 kHz
Accuracy of frequency output	Maximum error: 0.1 % of full scale

Resolution of frequency outputs 12 bit

1) Terminals 27 and 29 can also be programmed as inputs.

The digital output is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Control card, 24 V DC output

Terminal number 12, 13  
 Maximum load 200 mA

The 24 V DC supply is galvanically isolated from the supply voltage (PELV), but has the same potential as the analog and digital inputs and outputs.

Relay outputs

Programmable relay outputs 2

**Relay 01 Terminal number** 1–3 (break), 1–2 (make)

Maximum terminal load (AC-1)<sup>1)</sup> on 1–2 (NO) (Resistive load)<sup>2)3)</sup> 400 V AC, 2 A

Maximum terminal load (AC-15)<sup>1)</sup> on 1–2 (NO) (Inductive load @ cosφ 0.4) 240 V AC, 0.2 A

Maximum terminal load (DC-1)<sup>1)</sup> on 1–2 (NO) (Resistive load) 80 V DC, 2 A

Maximum terminal load (DC-13)<sup>1)</sup> on 1–2 (NO) (Inductive load) 24 V DC, 0.1 A

Maximum terminal load (AC-1)<sup>1)</sup> on 1–3 (NC) (Resistive load) 240 V AC, 2 A

Maximum terminal load (AC-15)<sup>1)</sup> on 1–3 (NC) (Inductive load @ cosφ 0.4) 240 V AC, 0.2 A

Maximum terminal load (DC-1)<sup>1)</sup> on 1–3 (NC) (Resistive load) 50 V DC, 2 A

Maximum terminal load (DC-13)<sup>1)</sup> on 1–3 (NC) (Inductive load) 24 V DC, 0.1 A

Minimum terminal load on 1–3 (NC), 1–2 (NO) 24 V DC 10 mA, 24 V AC 2 mA

Environment according to EN 60664-1 overvoltage category III/pollution degree 2

**Relay 02 Terminal number** 4–6 (break), 4–5 (make)

Maximum terminal load (AC-1)<sup>1)</sup> on 4–5 (NO) (Resistive load)<sup>2)3)</sup> 400 V AC, 2 A

Maximum terminal load (AC-15)<sup>1)</sup> on 4–5 (NO) (Inductive load @ cosφ 0.4) 240 V AC, 0.2 A

Maximum terminal load (DC-1)<sup>1)</sup> on 4–5 (NO) (Resistive load) 80 V DC, 2 A

Maximum terminal load (DC-13)<sup>1)</sup> on 4–5 (NO) (Inductive load) 24 V DC, 0.1 A

Maximum terminal load (AC-1)<sup>1)</sup> on 4–6 (NC) (Resistive load) 240 V AC, 2 A

Maximum terminal load (AC-15)<sup>1)</sup> on 4–6 (NC) (Inductive load @ cosφ 0.4) 240 V AC, 0.2 A

Maximum terminal load (DC-1)<sup>1)</sup> on 4–6 (NC) (Resistive load) 50 V DC, 2 A

Maximum terminal load (DC-13)<sup>1)</sup> on 4–6 (NC) (Inductive load) 24 V DC, 0.1 A

Minimum terminal load on 4–6 (NC), 4–5 (NO) 24 V DC 10 mA, 24 V AC 2 mA

Environment according to EN 60664-1 overvoltage category III/pollution degree 2

1) IEC 60947 part 4 and 5

The relay contacts are galvanically isolated from the rest of the circuit by reinforced isolation (PELV).

2) Overvoltage Category II

3) UL applications 300 V AC 2 A

Terminal number 50

Output voltage 10.5 V ±0.5 V

Maximum load 25 mA

The 10 V DC supply is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Control characteristics

Resolution of output frequency at 0–1000 Hz ±0.003 Hz

System response time (terminals 18, 19, 27, 29, 32, 33) ≤2 ms

Speed control range (open loop) 1:100 of synchronous speed

Speed accuracy (open loop) 30–4000 RPM: Maximum error of ±8 RPM

All control characteristics are based on a 4-pole asynchronous motor

Control card performance

Scan interval 5 ms

Control card, USB serial communication

USB standard	1.1 (full speed)
USB plug	USB type B device plug

**CAUTION**

Connection to PC is carried out via a standard host/device USB cable.  
 The USB connection is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.  
 The USB connection is not galvanically isolated from protection earth (ground). Use only isolated laptop/PC as connection to the USB connector on frequency converter or an isolated USB cable/converter.

8.7 Fuses

8.7.1 Fuse Selection

Use recommended fuses and/or circuit breakers on the supply side as protection in case of component break-down inside the frequency converter (first fault).

**NOTICE**

Use of fuses on the supply side is mandatory for IEC 60364 (CE) and NEC 2009 (UL) compliant installations.

Use the recommended fuses to ensure compliance with EN50178. Use of recommended fuses and circuit breakers ensures that possible damage to the frequency converter is limited to damages inside the unit. For further information, see *Application Note Fuses and Circuit Breakers*.

The fuses below are suitable for use on a circuit capable of delivering 100000 A<sub>rms</sub> (symmetrical), depending on the frequency converter voltage rating. With the proper fusing, the frequency converter short-circuit current rating (SCCR) is 100000 A<sub>rms</sub>.

N90K-N250	380–500 V	type aR
N55K-N315	525–690 V	type aR

Table 8.5 Recommended Fuses

Power size	Bussman PN	Littelfuse PN	Littelfuse PN	Bussmann PN	Siba PN	Ferraz-Shawmut PN	Ferraz-Shawmut PN (Europe)	Ferraz-Shawmut PN (North America)
N90K	170M2619	LA50QS300-4	L50S-300	FWH-300A	20 610 31.315	A50QS300-4	6,9URD31D08A0315	A070URD31KI0315
N110	170M2620	LA50QS350-4	L50S-350	FWH-350A	20 610 31.350	A50QS350-4	6,9URD31D08A0350	A070URD31KI0350
N132	170M2621	LA50QS400-4	L50S-400	FWH-400A	20 610 31.400	A50QS400-4	6,9URD31D08A0400	A070URD31KI0400
N160	170M4015	LA50QS500-4	L50S-500	FWH-500A	20 610 31.550	A50QS500-4	6,9URD31D08A0550	A070URD31KI0550
N200	170M4016	LA50QS600-4	L50S-600	FWH-600A	20 610 31.630	A50QS600-4	6,9URD31D08A0630	A070URD31KI0630
N250	170M4017	LA50QS800-4	L50S-800	FWH-800A	20 610 31.800	A50QS800-4	6,9URD32D08A0800	A070URD31KI0800

Table 8.6 Fuse Options for 380–500 V Frequency Converters

Power size	Bussmann PN	Siba PN	Ferraz-Shawmut European PN	Ferraz-Shawmut North American PN
N55k T7	170M2616	20 610 31.160	6,9URD30D08A0160	A070URD30KI0160
N75k T7	170M2619	20 610 31.315	6,9URD31D08A0315	A070URD31KI0315
N90k T7	170M2619	20 610 31.315	6,9URD31D08A0315	A070URD31KI0315
N110 T7	170M2619	20 610 31.315	6,9URD31D08A0315	A070URD31KI0315
N132 T7	170M2619	20 610 31.315	6,9URD31D08A0315	A070URD31KI0315
N160 T7	170M4015	20 620 31.550	6,9URD32D08A0550	A070URD32KI0550
N200 T7	170M4015	20 620 31.550	6,9URD32D08A0550	A070URD32KI0550
N250 T7	170M4015	20 620 31.550	6,9URD32D08A0550	A070URD32KI0550
N315 T7	170M4015	20 620 31.550	6,9URD32D08A0550	A070URD32KI0550

**Table 8.7 Fuse Options for 525–690 V Frequency Converters**

For UL compliance, use the Bussmann 170M series fuses for units supplied without a contactor-only option. See *Table 8.9* for SCCR ratings and UL fuse criteria if a contactor-only option is supplied with the frequency converter.

### 8.7.2 Short Circuit Current Rating (SCCR)

If the frequency converter is not supplied with a mains disconnect, contactor or circuit breaker, the Short Circuit Current Rating (SCCR) of the frequency converters is 100000 amps at all voltages (380–690 V).

If the frequency converter is supplied with a mains disconnect, the SCCR of the frequency converter is 100,000 amps at all voltages (380–690 V).

If the frequency converter is supplied with a circuit breaker, the SCCR depends on the voltage, see *Table 8.8*:

	415 V	480 V	600 V	690 V
D6h frame	120000 A	100000 A	65000 A	70000 A
D8h frame	100000 A	100000 A	42000 A	30000 A

**Table 8.8 Frequency Converter Supplied with a Circuit Breaker**

If the frequency converter is supplied with a contactor-only option and is externally fused according to *Table 8.9*, the SCCR of the frequency converter is as follows:

	415 V IEC <sup>1)</sup>	480 V UL <sup>2)</sup>	600 V UL <sup>2)</sup>	690 V IEC <sup>1)</sup>
D6h frame	100000 A	100000 A	100000 A	100000 A
D8h frame (not including the N250T5)	100000 A	100000 A	100000 A	100000 A
D8h frame (N250T5 only)	100000 A	Consult factory	Not applicable	

**Table 8.9 Frequency Converter Supplied with a Contactor**

- 1) With a Bussmann type LPJ-SP or Gould Shawmut type AJT fuse. 450 A max fuse size for D6h and 900 A max fuse size for D8h.
- 2) Must use Class J or L branch fuses for UL approval. 450 A max fuse size for D6h and 600 A max fuse size for D8h.

## 8.8 Connection Tightening Torques

Tighten with the correct torque when tightening all electrical connections. Too low or too high torque results in a bad electrical connection. To ensure correct torque, use a torque wrench.

Enclosure size	Terminal	Torque [Nm (in-lbs)]	Bolt size
D1h/D3h/D5h/D6h	Mains Motor Load sharing Regen	19–40 (168–354)	M10
	Earth (Ground) Brake	8.5–20.5 (75–181)	M8
	Heat sink access panel	2.27 (20)	
D2h/D4h/D7h/D8h	Mains Motor Regen Load sharing Earth (ground)	19–40 (168–354)	M10
	Brake	8.5–20.5 (75–181)	M8
	Heat sink access panel	2.27 (20)	

Table 8.10 Torque for Terminals

## 8.9 Power Ratings, Weight and Dimensions

Enclosure size		D1h	D2h	D3h	D4h	D3h	D4h
Rated power [kW]		90–132 kW (380–500 V)	160–250 kW (380–500 V)	90–132 kW (380–500 V)	160–250 kW (380–500 V)	With regeneration or load share terminals	
		90–132 kW (525–690 V)	160–315 kW (525–690 V)	37–132 kW (525–690 V)	160–315 kW (525–690 V)		
IP NEMA		21/54 Type 1/12	21/54 Type 1/12	20 Chassis	20 Chassis	20 Chassis	20 Chassis
Shipping dimensions [mm (inch)]	Height	587 (23)	587 (23)	587 (23)	587 (23)	587 (23)	587 (23)
	Width	997 (39)	1170 (46)	997 (39)	1170 (46)	1230 (48)	1430 (56)
	Depth	460 (18)	535 (21)	460 (18)	535 (21)	460 (18)	535 (21)
Frequency converter dimensions [mm (inch)]	Height	893 (35)	1099 (43)	909 (36)	1122 (44)	1004 (40)	1268 (50)
	Width	325 (13)	420 (17)	250 (10)	350 (14)	250 (10)	350 (14)
	Depth	378 (15)	378 (15)	375 (15)	375 (15)	375 (15)	375 (15)
Maximum weight [kg (lb)]		98 (216)	164 (362)	98 (216)	164 (362)	108 (238)	179 (395)

Table 8.11 Power Ratings, Weight, and Dimensions, Enclosure Size D1h-D4h

Enclosure size		D5h	D6h	D7h	D8h
Rated power [kW]					
IP NEMA		21/54 Type 1/12	21/54 Type 1/12	21/54 Type 1/12	21/54 Type 1/12
Shipping dimensions [mm (inch)]	Height	1805 (71)	1805 (71)	2490 (98)	2490 (98)
	Width	510 (20)	510 (20)	585 (23)	585 (23)
	Depth	635 (25)	635 (25)	640 (25)	640 (25)
Frequency converter dimensions [mm (inch)]	Height	1324 (52)	1665 (66)	1978 (78)	2284 (90)
	Width	325 (13)	325 (13)	420 (17)	420 (17)
	Depth	381 (15)	381 (15)	386 (15)	406 (16)
Maximum weight [kg (lb)]		449 (990)	449 (990)	530 (1168)	530 (1168)

Table 8.12 Power Ratings, Weight, and Dimensions, Enclosure Size D5h-D8h

## 9 Appendix

### 9.1 Symbols, Abbreviations, and Conventions

°C	Degrees celsius
AC	Alternating current
AEO	Automatic energy optimisation
AWG	American wire gauge
AMA	Automatic motor adaptation
DC	Direct current
EMC	Electro magnetic compatibility
ETR	Electronic thermal relay
$f_{M,N}$	Nominal motor frequency
FC	Frequency converter
$I_{INV}$	Rated inverter output current
$I_{LIM}$	Current limit
$I_{M,N}$	Nominal motor current
$I_{VLT,MAX}$	Maximum output current
$I_{VLT,N}$	Rated output current supplied by the frequency converter
IP	Ingress protection
LCP	Local control panel
MCT	Motion control tool
$n_s$	Synchronous motor speed
$P_{M,N}$	Nominal motor power
PELV	Protective extra low voltage
PCB	Printed circuit board
PM Motor	Permanent magnet motor
PWM	Pulse width modulated
RPM	Revolutions per minute
Regen	Regenerative terminals
$T_{LIM}$	Torque limit
$U_{M,N}$	Nominal motor voltage

Table 9.1 Symbols and Abbreviations

#### Conventions

Numbered lists indicate procedures.

Bullet lists indicate other information.

Italicised text indicates:

- Cross reference
- Link
- Parameter name

All dimensions are in [mm].

### 9.2 Parameter Menu Structure



<b>0-0*</b>	<b>Operation / Display</b>	Motor Construction	1-10	1-75	Start Speed [Hz]	3-01	Reference/Feedback Unit	3-94	Minimum Limit
<b>0-0*</b>	<b>Basic Settings</b>	Motor Model	1-11	1-76	Start Current	3-02	Minimum Reference	3-95	Ramp Delay
0-01	Language	Damping Gain	1-14	<b>1-8*</b>	<b>Stop Adjustments</b>	3-03	Maximum Reference	<b>4-1*</b>	<b>Limits / Warnings</b>
0-02	Motor Speed Unit	Low Speed Filter Time Const.	1-15	1-80	Function at Stop	3-04	Reference Function	4-1*	Motor Limits
0-03	Regional Settings	High Speed Filter Time Const.	1-16	1-81	Min Speed for Function at Stop [RPM]	3-1*	References	4-10	Motor Speed Direction
0-04	Operating State at Power-up (Hand)	Voltage filter time const.	1-17	1-82	Min Speed for Function at Stop [Hz]	3-10	Preset Reference	4-11	Motor Speed Low Limit [RPM]
0-09	Performance Monitor	Min. Current at No Load	1-18	1-83	Precise Stop Function	3-11	Catch up/slow Down Value	4-12	Motor Speed High Limit [RPM]
<b>0-1*</b>	<b>Set-up Operations</b>	<b>Motor Data</b>	1-2*	1-84	Precise Stop Counter Value	3-12	Reference Site	4-13	Motor Speed High Limit [RPM]
0-10	Active Set-up	Motor Power [kW]	1-20	1-85	Precise Stop Speed Compensation Delay	3-13	Preset Relative Reference	4-14	Motor Speed High Limit [Hz]
0-11	Edit Set-up	Motor Voltage [HP]	1-21	<b>1-9*</b>	<b>Motor Temperature</b>	3-14	Reference Resource 1	4-16	Torque Limit Motor Mode
0-12	This Set-up Linked to	Motor Voltage	1-22	1-90	Motor Thermal Protection	3-15	Reference Resource 2	4-17	Torque Limit Generator Mode
0-13	Readout: Linked Set-ups	Motor Current	1-24	1-91	Motor External Fan	3-16	Reference Resource 3	4-18	Current Limit
0-14	Readout: Edit Set-ups / Channel	Motor Nominal Speed	1-25	1-93	Thermistor Resource	3-17	Relative Scaling Reference Resource	4-19	Max Output Frequency
0-15	Readout: actual setup	Motor Cont. Rated Torque	1-26	1-94	ATEX ETR cur.lim. speed reduction	3-18	Jog Speed [RPM]	<b>4-2*</b>	<b>Limit Factors</b>
<b>0-2*</b>	<b>LCP Display</b>	Automatic Motor Adaptation (AMA)	1-29	1-95	DC Brake	3-19	Ramp 1	4-20	Torque Limit Factor Source
0-20	Display Line 1.1 Small	<b>Adv. Motor Data</b>	1-3*	1-96	KTY Thermistor Resource	3-4*	Ramp 1 Type	4-21	Speed Limit Factor Source
0-21	Display Line 1.2 Small	Stator Resistance (Rs)	1-30	1-97	KTY Threshold level	3-40	Ramp 1 Ramp Up Time	4-23	Brake Check Limit Factor Source
0-22	Display Line 1.3 Small	Rotor Resistance (Rr)	1-31	1-98	ATEX ETR interpul. points freq.	3-41	Ramp 1 Ramp Down Time	4-24	Brake Check Limit Factor
0-23	Display Line 2 Large	Stator Leakage Reactance (X1)	1-33	1-99	ATEX ETR interpul. points current	3-42	Ramp 1 S-ramp Ratio at Accel. Start	<b>4-3*</b>	<b>Motor Speed Mon.</b>
0-24	Display Line 3 Large	Rotor Leakage Reactance (X2)	1-34	<b>2-*</b>	<b>Brakes</b>	3-45	Ramp 1 S-ramp Ratio at Decel. Start	4-30	Motor Feedback Loss Function
0-25	My Personal Menu	Main Reactance (Xh)	1-35	2-0*	DC-Brake	3-46	Ramp 1 S-ramp Ratio at Accel. End	4-31	Motor Feedback Speed Error
<b>0-3*</b>	<b>LCP Custom Readout</b>	Iron Loss Resistance (Rfe)	1-36	2-00	DC Hold Current	3-47	Ramp 1 S-ramp Ratio at Decel. Start	4-32	Motor Feedback Loss Timeout
0-30	Unit for User-defined Readout	d-axis Inductance (Ld)	1-37	2-01	DC Brake Current	3-48	Ramp 1 S-ramp Ratio at Decel. End	4-34	Tracking Error Function
0-31	Min Value of User-defined Readout	q-axis Inductance (Lq)	1-38	2-02	DC Braking Time	<b>3-5*</b>	Ramp 2	4-35	Tracking Error
0-32	Max Value of User-defined Readout	Motor Poles	1-39	2-03	DC Brake Cut In Speed [RPM]	3-50	Ramp 2 Type	4-36	Tracking Error Timeout
0-33	Source for User-defined Readout	Back EMF at 1000 RPM	1-40	2-04	DC Brake Cut In Speed [Hz]	3-51	Ramp 2 Ramp Up Time	4-37	Tracking Error Ramping
0-37	Display Text 1	Motor Angle Offset	1-41	2-06	Maximum Reference	3-52	Ramp 2 Ramp Down Time	4-38	Tracking Error Ramping Timeout
0-38	Display Text 2	d-axis Inductance Sat. (LdSat)	1-44	2-06	Parking Current	3-55	Ramp 2 S-ramp Ratio at Accel. Start	4-39	Tracking Error After Ramping Timeout
0-39	Display Text 3	q-axis Inductance Sat. (LqSat)	1-45	2-07	Parking Time	3-56	Ramp 2 S-ramp Ratio at Accel. End	<b>4-4*</b>	<b>Speed Monitor</b>
<b>0-4*</b>	<b>LCP Keypad</b>	Position Detection Gain	1-46	2-10	Brake Energy Funct.	3-57	Ramp 2 S-ramp Ratio at Decel. Start	4-43	Motor Speed Monitor Function
0-40	[Hand on] Key on LCP	Torque Calibration	1-47	2-11	Brake Function	3-58	Ramp 2 S-ramp Ratio at Decel. End	4-44	Motor Speed Monitor Max
0-41	[Off] Key on LCP	Inductance Sat. Point	1-48	2-12	Brake Resistor (ohm)	<b>3-6*</b>	Ramp 3	4-45	Motor Speed Monitor Timeout
0-42	[Auto on] Key on LCP	<b>Load Indep. Setting</b>	1-5*	2-11	Brake Power Limit (kW)	3-60	Ramp 3 Type	<b>4-5*</b>	<b>Adj. Warnings</b>
0-43	[Reset] Key on LCP	Motor Magnetisation at Zero Speed	1-50	2-12	Brake Power Monitoring	3-61	Ramp 3 Ramp up Time	4-50	Warning Current Low
0-44	[Off/Reset] Key on LCP	Min Speed Normal Magnetising [RPM]	1-51	2-13	Brake Check	3-62	Ramp 3 Ramp down Time	4-51	Warning Current High
0-45	[Drive Bypass] Key on LCP	Min Speed Normal Magnetising [Hz]	1-52	2-15	AC brake Max. Current	3-65	Ramp 3 S-ramp Ratio at Accel. Start	4-52	Warning Speed Low
<b>0-5*</b>	<b>Copy/Save</b>	Model Shift Frequency	1-53	2-16	Over-voltage Control	3-66	Ramp 3 S-ramp Ratio at Accel. End	4-53	Warning Speed High
0-50	LCP Copy	Voltage reduction in fieldweakening	1-54	2-17	Brake Check Condition	3-67	Ramp 3 S-ramp Ratio at Decel. Start	4-54	Warning Reference Low
0-51	Set-up Copy	U/f Characteristic - U	1-55	2-18	Over-voltage Gain	3-68	Ramp 3 S-ramp Ratio at Decel. End	4-55	Warning Reference High
<b>0-6*</b>	<b>Password</b>	U/f Characteristic - F	1-56	2-19	<b>Mechanical Brake</b>	<b>3-7*</b>	Ramp 4	4-56	Warning Feedback Low
0-60	Main Menu Password	Flying Start Test Pulses Frequency	1-58	2-2*	Release Brake Current	3-70	Ramp 4 Type	4-57	Warning Feedback High
0-61	Access to Main Menu w/o Password	Flying Start Test Pulses Frequency	1-59	2-20	Activate Brake Speed [RPM]	3-71	Ramp 4 Ramp up Time	4-58	Missing Motor Phase Function
0-65	Quick Menu Password	<b>Load Depen. Setting</b>	<b>1-6*</b>	2-21	Activate Brake Speed [Hz]	3-72	Ramp 4 Ramp Down Time	4-59	Motor Check At Start
0-66	Access to Quick Menu w/o Password	Low Speed Load Compensation	1-60	2-22	Stop Delay	3-75	Ramp 4 S-ramp Ratio at Accel. Start	<b>4-6*</b>	<b>Speed Bypass</b>
0-67	Bus Password Access	High Speed Load Compensation	1-61	2-23	Brake Release Time	3-76	Ramp 4 S-ramp Ratio at Accel. End	4-60	Bypass Speed From [RPM]
0-68	Safety Parameters Password	Slip Compensation Time Constant	1-62	2-24	Torque Ref	3-77	Ramp 4 S-ramp Ratio at Decel. Start	4-61	Bypass Speed From [Hz]
0-69	Password Protection of Safety Parameters	Resonance Damping	1-63	2-25	Torque Ramp Up Time	3-78	Ramp 4 S-ramp Ratio at Decel. End	4-62	Bypass Speed To [RPM]
<b>1-1*</b>	<b>Load and Motor</b>	Resonance Damping Time Constant	1-64	2-26	Gain Boost Factor	<b>3-8*</b>	<b>Other Ramps</b>	4-63	Bypass Speed To [Hz]
<b>1-0*</b>	<b>General Settings</b>	Min. Current at Low Speed	1-65	2-27	Torque Ramp Down Time	3-80	Jog Ramp Time	<b>5-*</b>	<b>Digital In/Out</b>
1-00	Configuration Mode	Load Type	1-66	2-28	Adv. Mech Brake	3-81	Quick Stop Ramp Time	<b>5-0*</b>	<b>Digital I/O mode</b>
1-01	Motor Control Principle	Motor Inertia	1-68	2-29	Position P Start Proportional Gain	3-82	Quick Stop Ramp Type	5-00	Digital I/O Mode
1-02	Flux Motor Feedback Source	System Inertia	1-69	2-30	Speed PID Start Proportional Gain	3-83	Quick Stop S-ramp Ratio at Decel. Start	5-01	Terminal 27 Mode
1-03	Torque Characteristics	<b>Start Adjustments</b>	<b>1-7*</b>	2-31	Speed PID Start Integral Time	3-84	Quick Stop S-ramp Ratio at Decel. End	5-02	Terminal 29 Mode
1-04	Overload Mode	PM Start Mode	1-70	2-32	Speed PID Start Lowpass Filter Time	3-85	Ramp Lowpass Filter Time	<b>5-1*</b>	<b>Digital Inputs</b>
1-05	Local Mode Configuration	Start Delay	1-71	2-33	Reference Range	3-90	Step Size	5-10	Terminal 18 Digital Input
1-06	Clockwise Direction	Start Function	1-72	<b>3-*</b>	<b>Reference / Ramps</b>	3-91	Ramp Time	5-11	Terminal 19 Digital Input
1-07	Motor Angle Offset Adjust	Flying Start	1-73	3-00	Reference Range	3-92	Power Restore	5-12	Terminal 27 Digital Input
<b>1-1*</b>	<b>Special Settings</b>	Start Speed [RPM]	1-74	3-00	Reference Range	3-93	Maximum Limit	5-13	Terminal 29 Digital Input
								5-14	Terminal 32 Digital Input



5-15	Terminal 33 Digital Input	6-12	Terminal 53 Low Current	7-07	Speed PID Feedback Gear Ratio	8-31	Address	9-75	DO Identification
5-16	Terminal X30/2 Digital Input	6-13	Terminal 53 High Current	7-08	Speed PID Feed Forward Factor	8-32	FC Port Baud Rate	9-80	Defined Parameters (1)
5-17	Terminal X30/3 Digital Input	6-14	Terminal 53 Low Ref./Feedb. Value	7-09	Speed PID Error Correction w/ Ramp	8-33	Parity / Stop Bits	9-81	Defined Parameters (2)
5-18	Terminal X30/4 Digital Input	6-15	Terminal 53 High Ref./Feedb. Value	7-10	Torque PI Ctrl.	8-34	Estimated cycle time	9-82	Defined Parameters (3)
5-19	Terminal 37 Safe Stop	6-16	Terminal 53 Filter Time Constant	7-11	Torque PI Feedback Source	8-35	Minimum Response Delay	9-83	Defined Parameters (4)
5-20	Terminal X46/1 Digital Input	6-2*	Analog Input 2	7-12	Torque PI Proportional Gain	8-36	Max Response Delay	9-84	Defined Parameters (5)
5-21	Terminal X46/3 Digital Input	6-20	Terminal 54 Low Voltage	7-13	Torque PI Integration Time	8-37	Max Inter-Char Delay	9-85	Defined Parameters (6)
5-22	Terminal X46/5 Digital Input	6-21	Terminal 54 High Voltage	7-16	Torque PI Lowpass Filter Time	8-4*	FC MC protocol set	9-90	Changed Parameters (1)
5-23	Terminal X46/7 Digital Input	6-22	Terminal 54 Low Current	7-18	Torque PI Feed Forward Factor	8-40	Telegram Selection	9-91	Changed Parameters (2)
5-24	Terminal X46/9 Digital Input	6-23	Terminal 54 High Current	7-19	Current Controller Rise Time	8-41	Parameters for Signals	9-92	Changed Parameters (3)
5-25	Terminal X46/11 Digital Input	6-24	Terminal 54 Low Ref./Feedb. Value	7-2*	Process Ctrl. Feedb	8-42	PCD Write Configuration	9-93	Changed Parameters (4)
5-26	Terminal X46/13 Digital Input	6-25	Terminal 54 High Ref./Feedb. Value	7-20	Process CL Feedback 1 Resource	8-43	PCD Read Configuration	9-94	Changed Parameters (5)
5-3*	Digital Outputs	6-26	Terminal 54 Filter Time Constant	7-22	Process CL Feedback 2 Resource	8-45	BTM Transaction Command	9-99	Profibus Revision Counter
5-30	Terminal 27 Digital Output	6-3*	Analog Input 3	7-3*	Process PI Ctrl.	8-46	BTM Transaction Status	10-**	CAN Fields
5-31	Terminal 29 Digital Output	6-30	Terminal X30/11 Low Voltage	7-30	Process PID Normal/ Inverse Control	8-47	BTM Timeout	10-0*	Common Settings
5-32	Term X30/6 Digi Out (MCB 101)	6-31	Terminal X30/11 High Voltage	7-31	Process PID Anti Windup	8-48	BTM Maximum Errors	10-00	CAN Protocol
5-33	Term X30/7 Digi Out (MCB 101)	6-34	Term. X30/11 Low Ref./Feedb. Value	7-32	Process PID Start Speed	8-49	BTM Error Log	10-01	Baud Rate Select
5-4*	Relays	6-35	Term. X30/11 High Ref./Feedb. Value	7-33	Process PID Proportional Gain	8-5*	Digital/Bus	10-02	MAC ID
5-41	Function Relay	6-36	Term. X30/11 Filter Time Constant	7-34	Process PID Integral Time	8-50	Coasting Select	10-05	Readout Transmit Error Counter
5-42	Off Delay, Relay	6-4*	Analog Input 4	7-35	Process PID Differentiation Time	8-51	Quick Stop Select	10-06	Readout Receive Error Counter
5-50	Term. 29 Low Frequency	6-40	Terminal X30/12 Low Voltage	7-36	Process PID Diff. Gain Limit	8-52	DC Brake Select	10-07	Readout Bus Off Counter
5-51	Term. 29 High Frequency	6-44	Term. X30/12 High Voltage	7-38	Process PID Feed Forward Factor	8-53	Start Select	10-1*	DeviceNet
5-52	Term. 29 Low Ref./Feedb. Value	6-46	Term. X30/12 Low Ref./Feedb. Value	7-39	On Reference Bandwidth	8-54	Reversing Select	10-10	Process Data Type Selection
5-53	Term. 29 High Ref./Feedb. Value	6-50	Terminal 42 Output	7-4*	Adv. Process PID I	8-55	Set-up Select	10-11	Process Data Config Write
5-54	Pulse Filter Time Constant #29	6-51	Terminal 42 Output Min Scale	7-41	Process PID I-part Reset	8-56	Preset Reference Select	10-12	Process Data Config Read
5-55	Term. 33 Low Frequency	6-52	Terminal 42 Output Max Scale	7-42	Process PID Output Neg. Clamp	8-57	Profidrive OFF2 Select	10-13	Warning Parameter
5-56	Term. 33 High Frequency	6-53	Term. 42 Output Bus Ctrl	7-44	Process PID Gain Scale at Min. Ref.	8-58	Profidrive OFF3 Select	10-14	Net Reference
5-57	Term. 33 Low Ref./Feedb. Value	6-55	Terminal 42 Output Timeout Preset	7-45	Process PID Feed Fwd Resource	8-8*	FC Port Diagnostics	10-15	Net Control
5-58	Term. 33 High Ref./Feedb. Value	6-6*	Analog Output 2	7-46	Process PID Feed Fwd Normal/ Inv. Ctrl.	8-80	Bus Message Count	10-2*	COS Filters
5-59	Pulse Filter Time Constant #33	6-61	Terminal X30/8 Output	7-48	PCD Feed Forward	8-81	Bus Error Count	10-20	COS Filter 1
5-6*	Pulse Output	6-62	Terminal X30/8 Min. Scale	7-49	Process PID Output Normal/ Inv. Ctrl.	8-82	Slave Messages Rcvd	10-21	COS Filter 2
5-62	Terminal 27 Pulse Output Variable	6-63	Terminal X30/8 Max. Scale	7-5*	Adv. Process PID II	8-9*	Bus Jog Error Count	10-22	COS Filter 3
5-63	Terminal 29 Pulse Output Variable	6-64	Terminal X30/8 Bus Control	7-50	Process PID Extended PID	8-90	Bus Jog 1 Speed	10-23	COS Filter 4
5-65	Pulse Output Max Freq #29	6-66	Terminal X30/8 Output Timeout Preset	7-51	Process PID Feed Fwd Gain	8-90	Bus Jog 2 Speed	10-3*	Parameter Access
5-66	Terminal X30/6 Pulse Output Variable	6-67	Terminal X45/1 Output	7-52	Process PID Feed Fwd Ramp up	9-**	PROFIBUS	10-30	Array Index
5-68	Pulse Output Max Freq #X30/6	6-7*	Analog Output 3	7-53	Process PID Feed Fwd Ramp down	9-00	Setpoint	10-31	Store Data Values
5-70	Term 32/33 Pulses Per Revolution	6-70	Terminal X45/1 Min. Scale	7-56	Process PID Ref. Filter Time	9-07	Actual Value	10-32	Store Always
5-71	Term 32/33 Encoder Direction	6-72	Terminal X45/1 Max. Scale	7-57	Process PID Fb. Filter Time	9-15	PCD Write Configuration	10-32	DeviceNet Revision
5-80	AHF Cap Reconnect Delay	6-73	Terminal X45/1 Bus Control	8-**	Comm. and Options	9-16	PCD Read Configuration	10-34	DeviceNet Product Code
5-9*	Bus Controlled	6-74	Terminal X45/1 Output Timeout Preset	8-0*	General Settings	9-18	Node Address	10-39	DeviceNet F Parameters
5-90	Digital & Relay Bus Control	6-8*	Analog Output 4	8-01	Control Site	9-19	Drive Unit System Number	10-5*	CANopen
5-93	Pulse Out #27 Bus Control	6-80	Terminal X45/3 Output	8-02	Control Word Source	9-22	Telegram Selection	10-50	Process Data Config Write.
5-94	Pulse Out #27 Timeout Preset	6-81	Terminal X45/3 Min. Scale	8-03	Control Word Timeout	9-23	Parameter Edit	10-51	Process Data Config Read.
5-95	Pulse Out #29 Bus Control	6-82	Terminal X45/3 Max. Scale	8-04	Control Word Timeout Function	9-27	Parameter Edit	12-0*	IP Settings
5-96	Pulse Out #29 Timeout Preset	6-83	Terminal X45/3 Bus Control	8-05	End-of-Timeout Function	9-28	Process Control	12-00	IP Address Assignment
5-97	Pulse Out #X30/6 Bus Control	6-84	Terminal X45/3 Output Timeout Preset	8-06	Reset Control Word Timeout	9-45	Fault Message Counter	12-01	IP Address
5-98	Pulse Out #X30/6 Timeout Preset	7-**	Controllers	8-07	Diagnosis Trigger	9-52	Fault Code	12-02	Subnet Mask
6-0*	Analog I/O Mode	7-0*	Speed PID Ctrl.	8-08	Readout Filtering	9-53	Fault Number	12-03	Default Gateway
6-00	Live Zero Timeout Time	7-01	Speed PID Feedback Source	8-1*	Ctrl. Word Settings	9-63	Fault Situation Counter	12-04	DHCP Server
6-01	Live Zero Timeout Function	7-02	Speed PID Proportional Gain	8-10	Control Word Profile	9-64	Actual Baud Rate	12-05	Lease Expires
6-1*	Analog Input 1	7-03	Speed PID Integral Time	8-13	Configurable Status Word STW	9-65	Device Identification	12-06	Name Servers
6-10	Terminal 53 Low Voltage	7-04	Speed PID Differentiation Time	8-14	Configurable Control Word CTW	9-66	Profile Number	12-07	Domain Name
6-11	Terminal 53 High Voltage	7-05	Speed PID Diff. Gain Limit	8-17	Configurable Alarm and Warningword	9-67	Control Word 1	12-08	Host Name
		7-06	Speed PID Lowpass Filter Time	8-19	Product Code	9-68	Status Word 1	12-09	Physical Address
				8-3*	FC Port Settings	9-70	Edit Set-up	12-1*	Ethernet Link Parameters
				8-30	Protocol	9-71	Profibus Save Data Values	12-10	Link Status
						9-72	ProfibusDriveReset	12-11	Link Duration
								12-12	Auto Negotiation

12-13	Link Speed	13-01	Start Event	14-52	Fan Control	15-62	Option Ordering No	16-47	Motor Phase W Current
12-14	Link Duplex	13-02	Stop Event	14-53	Fan Monitor	15-63	Option Serial No	16-48	Speed Ref. After Ramp [RPM]
12-18	Supervisor MAC	13-03	Reset SLC	14-55	Output Filter	15-70	Option in Slot A	16-49	Current Fault Source
12-19	Supervisor IP Addr.	13-1* <b>Comparators</b>		14-56	Capacitance Output Filter	15-71	Slot A Option SW Version	16-5* <b>Ref. &amp; Feedb.</b>	
12-20	Control Instance	13-10	Comparator Operand	14-57	Inductance Output Filter	15-72	Option in Slot B	16-50	External Reference
12-21	Process Data Config Write	13-11	Comparator Operator	14-59	Actual Number of Inverter Units	15-73	Slot B Option SW Version	16-51	Pulse Reference
12-22	Process Data Config Read	13-1* <b>RS Flip Flops</b>		14-7* <b>Compatibility</b>		15-74	Option in Slot C0/E0	16-52	Feedback(Unit)
12-23	Process Data Config Write Size	13-15	RS-FF Operand S	14-73	Legacy Alarm Word	15-75	Slot C0/E0 Option SW Version	16-53	Digi Pot Reference
12-24	Process Data Config Read Size	13-16	RS-FF Operand R	14-74	Legacy Warning Word	15-76	Option in Slot C1/E1	16-57	Feedback [RPM]
12-27	Master Address	13-2* <b>Timers</b>		14-8* <b>Ext. Status Word</b>		15-77	Slot C1/E1 Option SW Version	16-6* <b>Inputs &amp; Outputs</b>	
12-28	Store Data Values	13-20	SL Controller Timer	14-80	Option Supplied by External 24VDC	15-8* <b>Operating Data II</b>		16-60	Digital Input
12-29	Store Always	13-4* <b>Logic Rules</b>		14-88	Option Data Storage	15-80	Fan Running Hours	16-61	Terminal 53 Switch Setting
12-30	EtherNet/IP	13-40	Logic Rule Boolean 1	14-89	Option Detection	15-81	Preset Fan Running Hours	16-62	Analog Input 53
12-30	Warning Parameter	13-41	Logic Rule Operator 1	14-9* <b>Fault Settings</b>		15-89	Configuration Change Counter	16-63	Terminal 54 Switch Setting
12-31	Net Reference	13-42	Logic Rule Boolean 2	14-90	Fault Level	15-9* <b>Parameter Info</b>		16-64	Analog Input 54
12-32	Net Control	13-43	Logic Rule Operator 2	15-0* <b>Drive Information</b>		15-92	Defined Parameters	16-65	Analog Output 42 [mA]
12-33	CIP Revision	13-44	Logic Rule Boolean 3	15-0* <b>Operating Data</b>		15-93	Modified Parameters	16-66	Digital Output [bin]
12-34	CIP Product Code	13-5* <b>States</b>		15-00	Operating hours	15-98	Drive Identification	16-67	Freq. Input #29 [Hz]
12-35	EDS Parameter	13-51	SL Controller Event	15-01	Running hours	15-99	Parameter Metadata	16-68	Freq. Input #33 [Hz]
12-37	COS Inhibit Timer	13-52	SL Controller Action	15-02	kWh Counter	16-0* <b>Data Readouts</b>		16-69	Pulse Output #27 [Hz]
12-38	COS Filter	14-0* <b>Special Functions</b>		15-03	Power Up's	16-0* <b>General Status</b>		16-70	Pulse Output #29 [Hz]
12-4* <b>Modbus TCP</b>		14-0* <b>Inverter Switching</b>		15-04	Over Temp's	16-00	Control Word	16-71	Relay Output [bin]
12-40	Status Parameter	14-00	Switching Pattern	15-05	Over Volt's	16-01	Reference [Unit]	16-72	Counter A
12-41	Slave Message Count	14-01	Switching Frequency	15-06	Reset kWh Counter	16-02	Reference %	16-73	Counter B
12-42	Slave Exception Message Count	14-03	Overmodulation	15-07	Reset Running Hours Counter	16-03	Status Word	16-74	Prec. Stop Counter
12-5* <b>EtherCAT</b>		14-04	PWM Random	15-1* <b>Data Log Settings</b>		16-05	Main Actual Value [%]	16-75	Analog In X30/11
12-50	Configured Station Alias	14-06	Dead Time Compensation	15-10	Logging Source	16-06	Absolute Position	16-76	Analog In X30/12
12-51	Configured Station Address	14-1* <b>Mains On/Off</b>		15-11	Logging Interval	16-09	Custom Readout	16-77	Analog Out X30/8 [mA]
12-59	EtherCAT Status	14-10	Mains Failure	15-12	Trigger Event	16-1* <b>Motor Status</b>		16-78	Analog Out X45/1 [mA]
12-6* <b>Network PowerLink</b>		14-11	Mains Voltage at Mains Fault	15-13	Logging Mode	16-10	Power [kW]	16-79	Analog Out X45/3 [mA]
12-60	Node ID	14-12	Function at Mains Imbalance	15-14	Samples Before Trigger	16-11	Power [hp]	16-8* <b>Fieldbus &amp; FC Port</b>	
12-62	SDO Timeout	14-14	Kin. Backup Time Out	15-2* <b>Historic Log</b>		16-12	Motor Voltage	16-80	Fieldbus CTW 1
12-63	Basic Ethernet Timeout	14-15	Kin. Backup Trip Recovery Level	15-20	Historic Log: Event	16-13	Frequency	16-82	Fieldbus REF 1
12-66	Threshold	14-16	Kin. Backup Gain	15-21	Historic Log: Value	16-14	Motor current	16-84	Comm. Option STW
12-67	Threshold Counters	14-2* <b>Trip Reset</b>		15-22	Historic Log: Time	16-15	Frequency [%]	16-85	FC Port CTW 1
12-68	Cumulative Counters	14-20	Reset Mode	15-3* <b>Fault Log</b>		16-16	Torque [Nm]	16-86	FC Port REF 1
12-69	Ethernet PowerLink Status	14-21	Automatic Restart Time	15-30	Fault Log: Error Code	16-17	Speed [RPM]	16-87	Bus Readout Alarm/Warning
12-8* <b>Other Ethernet Services</b>		14-22	Operation Mode	15-31	Fault Log: Value	16-18	Motor Thermal	16-89	Configurable Alarm/Warning Word
12-80	FTP Server	14-23	Typecode Setting	15-32	Fault Log: Time	16-19	KTY sensor temperature	16-90	Alarm Word
12-81	HTTP Server	14-24	Trip Delay at Current Limit	15-4* <b>Drive Identification</b>		16-20	Motor Angle	16-91	Alarm Word 2
12-82	SMTP Service	14-25	Trip Delay at Torque Limit	15-40	FC Type	16-21	Torque [%] High Res.	16-92	Warning Word
12-83	SNMP Agent	14-26	Trip Delay at Inverter Fault	15-42	Voltage	16-22	Torque [%]	16-93	Warning Word 2
12-84	Address Conflict Detection	14-28	Production Settings	15-43	Software Version	16-23	Motor Shaft Power [kW]	16-94	Ext. Status Word
12-89	Transparent Socket Channel Port	14-29	Service Code	15-44	Ordered Typecode String	16-24	Calibrated Stator Resistance	17-0* <b>Feedback</b>	
12-9* <b>Advanced Ethernet Services</b>		14-3* <b>Current Limit Ctrl.</b>		15-45	Actual Typecode String	16-3* <b>Drive Status</b>		17-1* <b>Inc. Enc. Interface</b>	
12-90	Cable Diagnostic	14-30	Current Lim Ctrl, Proportional Gain	15-46	Frequency Converter Ordering No	16-30	DC Link Voltage	17-10	Signal Type
12-91	Auto Cross Over	14-31	Current Lim Ctrl, Integration Time	15-47	Frequency Converter Ordering No	16-32	Brake Energy /s	17-11	Resolution (PPR)
12-92	IGMP Snooping	14-32	Current Lim Ctrl, Filter Time	15-48	LCP Id No	16-33	Brake Energy Average	17-2* <b>Abs. Enc. Interface</b>	
12-93	Cable Error Length	14-35	Stall Protection	15-49	SW ID Control Card	16-34	Heatsink Temp.	17-20	Protocol Selection
12-94	Broadcast Storm Protection	14-36	Fieldweakening Function	15-50	SW ID Power Card	16-35	Inverter Thermal	17-21	Resolution (Positions/Rev)
12-95	Inactivity timeout	14-4* <b>Energy Optimising</b>		15-51	Frequency Converter Serial Number	16-36	Inv. Nom. Current	17-24	SSI Data Length
12-96	Port Config	14-40	VT Level	15-51	Power Card Serial Number	16-37	Inv. Max. Current	17-25	Clock Rate
12-97	QoS Priority	14-41	AEO Minimum Magnetisation	15-53	Power Card Serial Number	16-38	SL Controller State	17-26	SSI Data Format
12-98	Interface Counters	14-42	Minimum AEO Frequency	15-54	Config File Name	16-39	Control Card Temp.	17-34	HIPERFACE Baudrate
12-99	Media Counters	14-43	Motor Cosphi	15-59	CSV Filename	16-40	Logging Buffer Full	17-3* <b>Resolver Interface</b>	
13-0* <b>Smart Logic</b>		14-5* <b>Environment</b>		15-60	Option Mounted	16-41	LCP Bottom Statusline	17-50	Poles
13-0* <b>SLC Settings</b>		14-50	RFI Filter	15-61	Option SW Version	16-45	Motor Phase U Current	17-51	Input Voltage
13-00	SL Controller Mode	14-51	DC Link Compensation			16-46	Motor Phase V Current	17-52	Input Frequency



17-53	Transformation Ratio	30-26	Light Load Current [%]	32-67	Max. Tolerated Position Error	33-43	Negative Software End Limit Active	34-25	PCD 5 Read from MCO
17-56	Encoder Sim. Resolution	30-27	Light Load Speed [%]	32-68	Reverse Behavior for Slave	33-44	Positive Software End Limit Active	34-26	PCD 6 Read from MCO
17-59	Resolver Interface	<b>30-8*</b>	<b>Compatibility (I)</b>	32-69	Sampling Time for PID Control	33-45	Time in Target Window	34-27	PCD 7 Read from MCO
17-6*	<b>Monitoring and App.</b>	30-80	d-axis Inductance (Ld)	32-70	Scan Time for Profile Generator	33-46	Target Window Limit/Value	34-28	PCD 8 Read from MCO
17-60	Feedback Direction	30-81	Brake Resistor (ohm)	32-71	Size of the Control Window (Activation)	33-47	Size of Target Window	34-29	PCD 9 Read from MCO
17-61	Feedback Signal Monitoring	30-83	Speed PID Proportional Gain			<b>33-5*</b>	<b>I/O Configuration</b>	34-30	PCD 10 Read from MCO
17-7*	<b>Absolute Position</b>	30-84	Process PID Proportional Gain	32-72	Size of the Control Window (Deactiv.)	33-50	Terminal X57/1 Digital Input	<b>34-4*</b>	<b>Inputs &amp; Outputs</b>
17-70	Absolute Position Display Unit	<b>31-1**</b>	<b>Bypass Option</b>	32-73	Integral limit filter time	33-51	Terminal X57/2 Digital Input	34-40	Digital Inputs
17-71	Absolute Position Display Scale	31-00	Bypass Mode	32-74	Position error filter time	33-52	Terminal X57/3 Digital Input	34-41	Digital Outputs
17-72	Absolute Position Numerator	31-01	Bypass Start Time Delay	<b>32-8*</b>	<b>Velocity &amp; Accel.</b>	33-53	Terminal X57/4 Digital Input	<b>34-5*</b>	<b>Process Data</b>
17-73	Absolute Position Denominator	31-02	Bypass Trip Time Delay	32-80	Maximum Velocity (Encoder)	33-54	Terminal X57/5 Digital Input	34-50	Actual Position
17-74	Absolute Position Offset	31-03	Test Mode Activation	32-81	Shortest Ramp	33-55	Terminal X57/6 Digital Input	34-51	Commanded Position
<b>18-1**</b>	<b>Data Readouts 2</b>	31-10	Bypass Status Word	32-82	Ramp Type	33-56	Terminal X57/7 Digital Input	34-52	Actual Master Position
18-3*	<b>Analog Readouts</b>	31-11	Bypass Running Hours	32-83	Velocity Resolution	33-57	Terminal X57/8 Digital Input	34-53	Slave Index Position
18-36	Analog Input X48/2 [mA]	31-19	Remote Bypass Activation	32-84	Default Velocity	33-58	Terminal X57/9 Digital Input	34-54	Master Index Position
18-37	Temp. Input X48/4	<b>32-0**</b>	<b>MCO Basic Settings</b>	32-86	Default Acceleration	33-59	Terminal X57/10 Digital Input	34-55	Curve Position
18-38	Temp. Input X48/7	<b>32-0**</b>	<b>Encoder 2</b>	32-86	Acc. up for limited jerk	33-60	Terminal X59/1 and X59/2 Mode	34-56	Track Error
18-39	Temp. Input X48/10	32-00	Incremental Signal Type	32-87	Acc. down for limited jerk	33-61	Terminal X59/1 Digital Input	34-57	Synchronizing Error
<b>18-4*</b>	<b>PGIO Data Readouts</b>	32-01	Incremental Resolution	32-88	Dec. up for limited jerk	33-62	Terminal X59/1 Digital Output	34-58	Actual Velocity
18-43	Analog Out X49/7	32-02	Absolute Protocol	32-89	Dec. down for limited jerk	33-63	Terminal X59/2 Digital Output	34-59	Actual Master Velocity
18-44	Analog Out X49/9	32-03	Absolute Resolution	<b>32-9*</b>	<b>Development</b>	33-64	Terminal X59/2 Digital Output	34-60	Synchronizing Status
18-45	Analog Out X49/11	32-04	Absolute Encoder Baudrate X55	<b>33-1**</b>	<b>MCO Adv. Settings</b>	33-65	Terminal X59/3 Digital Output	34-61	Axis Status
<b>18-5*</b>	<b>Active Alarms/Warnings</b>	32-05	Absolute Encoder Data Length	<b>33-0*</b>	<b>Home Motion</b>	33-66	Terminal X59/4 Digital Output	34-62	Program Status
18-55	Active Alarm Numbers	32-06	Absolute Encoder Clock Frequency	33-00	Force HOME	33-67	Terminal X59/5 Digital Output	34-64	MCO 302 Status
18-56	Active Warning Numbers	32-07	Absolute Encoder Clock Generation	33-01	Ramp for Home	33-68	Terminal X59/6 Digital Output	34-65	MCO 302 Control
<b>18-6*</b>	<b>Inputs &amp; Outputs 2</b>	32-08	Absolute Encoder Cable Length	33-02	Ramp for Home Motion	33-69	Terminal X59/7 Digital Output	<b>34-7*</b>	<b>Diagnosis Readouts</b>
18-60	Digital Input 2	32-09	Encoder Monitoring	33-03	Velocity of Home Motion	33-70	Terminal X59/8 Digital Output	34-70	MCO Alarm Word 1
<b>18-9*</b>	<b>PID Readouts</b>	32-10	Rotational Direction	33-04	Behaviour during HomeMotion	<b>33-8*</b>	<b>Global Parameters</b>	34-71	MCO Alarm Word 2
18-90	Process PID Error	32-11	User Unit Denominator	<b>33-1*</b>	<b>Synchronization</b>	33-80	Activated Program Number	<b>35-1**</b>	<b>Sensor Input Option</b>
18-91	Process PID Output	32-12	User Unit Numerator	33-10	Sync Factor Master	33-81	Power-up State	<b>35-0*</b>	<b>Temp. Input Mode</b>
18-92	Process PID Clamped Output	32-13	Enc.2 Control	33-11	Sync Factor Slave	33-82	Drive Status Monitoring	35-00	Term. X48/4 Temperature Unit
18-93	Process PID Gain Scaled Output	32-14	Enc.2 node ID	33-12	Position Offset for Synchronization	33-83	Behaviour after Error	35-01	Term. X48/4 Input Type
<b>22-2**</b>	<b>Appl. Functions</b>	32-15	Enc.2 CAN guard	33-13	Accuracy Window for Position Sync.	33-84	Behaviour after Esc.	35-02	Term. X48/7 Temperature Unit
22-0*	Miscellaneous	<b>32-3*</b>	<b>Encoder 1</b>	33-14	Relative Slave Velocity Limit	33-85	MCO Supplied by External 24VDC	35-03	Term. X48/7 Input Type
22-00	External Interlock Delay	32-30	Incremental Signal Type	33-15	Marker Number for Master	33-86	Terminal state at alarm	35-04	Term. X48/10 Temperature Unit
<b>30-3**</b>	<b>Special Features</b>	32-31	Incremental Resolution	33-16	Marker Number for Slave	33-87	Terminal state at alarm	35-05	Term. X48/10 Input Type
30-0*	Wobbler	32-32	Absolute Protocol	33-17	Master Marker Distance	33-88	Status port at alarm	35-06	Temperature Sensor Alarm Function
30-00	Wobble Mode	32-33	Absolute Resolution	33-18	Slave Marker Distance	<b>33-9*</b>	<b>MCO Port Settings</b>	<b>35-1*</b>	<b>Temp. Input X48/4</b>
30-01	Wobble Delta Frequency [Hz]	32-35	Absolute Encoder Data Length	33-19	Master Marker Type	33-90	X62 MCO CAN node ID	35-14	Term. X48/4 Filter Time Constant
30-02	Wobble Delta Frequency [%]	32-36	Absolute Encoder Clock Frequency	33-20	Slave Marker Type	33-91	X62 MCO CAN baud rate	35-15	Term. X48/4 Temp. Monitor
30-03	Wobble Delta Freq. Scaling Resource	32-37	Absolute Encoder Clock Generation	33-21	Master Marker Tolerance Window	33-94	X60 MCO RS485 serial termination	35-16	Term. X48/4 Low Temp. Limit
30-04	Wobble Jump Frequency [Hz]	32-38	Absolute Encoder Cable Length	33-22	Slave Marker Tolerance Window	33-95	X60 MCO RS485 serial baud rate	35-17	Term. X48/4 High Temp. Limit
30-05	Wobble Jump Frequency [%]	32-39	Encoder Monitoring	33-23	Start Behaviour for Marker Sync	<b>34-1**</b>	<b>MCO Data Readouts</b>	<b>35-2*</b>	<b>Temp. Input X48/7</b>
30-06	Wobble Jump Time	32-40	Encoder Termination	33-24	Marker Number for Fault	<b>34-0*</b>	<b>PCD Write Par.</b>	35-24	Term. X48/7 Filter Time Constant
30-07	Wobble Sequence Time	32-43	Enc.1 Control	33-25	Marker Number for Ready	34-01	PCD 1 Write to MCO	35-25	Term. X48/7 Temp. Monitor
30-08	Wobble Up/ Down Time	32-44	Enc.1 node ID	33-26	Velocity Filter	34-02	PCD 2 Write to MCO	35-26	Term. X48/7 Low Temp. Limit
30-09	Wobble Random Function	32-45	Enc.1 CAN guard	33-27	Offset Filter Time	34-03	PCD 3 Write to MCO	35-27	Term. X48/7 High Temp. Limit
30-10	Wobble Ratio	<b>32-5*</b>	<b>Feedback source</b>	33-28	Marker Filter Configuration	34-04	PCD 4 Write to MCO	<b>35-3*</b>	<b>Temp. Input X48/10</b>
30-11	Wobble Random Ratio Max.	32-50	Source Slave	33-29	Filter Time for Marker Filter	34-05	PCD 5 Write to MCO	35-34	Term. X48/10 Filter Time Constant
30-12	Wobble Random Ratio Min.	32-51	MCO 302 Last Will	33-30	Maximum Marker Correction	34-06	PCD 6 Write to MCO	35-35	Term. X48/10 Temp. Monitor
30-19	Wobble Delta Freq. Scaled	32-52	Source Master	33-31	Synchronisation Type	34-07	PCD 7 Write to MCO	35-36	Term. X48/10 Low Temp. Limit
<b>30-2*</b>	<b>Adv. Start Adjust</b>	<b>32-6*</b>	<b>PID Controller</b>	33-32	Feed Forward Velocity Adaptation	34-08	PCD 8 Write to MCO	35-37	Term. X48/10 High Temp. Limit
30-20	High Starting Torque Time [s]	32-60	Proportional factor	33-33	Velocity Filter Window	34-09	PCD 9 Write to MCO	<b>35-4*</b>	<b>Analog Input X48/2</b>
30-21	High Starting Torque Current [%]	32-61	Derivative factor	33-34	Slave Marker filter time	34-10	PCD 10 Write to MCO	35-42	Term. X48/2 Low Current
30-22	Locked Rotor Protection	32-62	Integral factor	<b>33-4*</b>	<b>Limit Handling</b>	<b>34-2*</b>	<b>PCD Read Par.</b>	35-43	Term. X48/2 High Current
30-23	Locked Rotor Detection Time [s]	32-63	Limit Value for Integral Sum	33-40	Behaviour atEnd Limit Switch	34-21	PCD 1 Read from MCO	35-44	Term. X48/2 Low Ref./Feedb. Value
30-24	Locked Rotor Detection Speed Error [%]	32-64	PID Bandwidth	33-41	Negative Software End Limit	34-22	PCD 2 Read from MCO	35-45	Term. X48/2 High Ref./Feedb. Value
		32-65	Velocity Feed-Forward	33-42	Positive Software End Limit	34-23	PCD 3 Read from MCO	35-46	Term. X48/2 Filter Time Constant
30-25	Light Load Delay [s]	32-66	Acceleration Feed-Forward			34-24	PCD 4 Read from MCO		

<b>36-3** Programmable I/O Option</b>		
<b>36-0* I/O Mode</b>	42-51 Speed Limit	99-53 PC Debug 1
36-03 Terminal X49/7 Mode	42-52 Fail Safe Reaction	99-54 PC Debug 2
36-04 Terminal X49/9 Mode	42-53 Start Ramp	99-55 PC Debug Array
36-05 Terminal X49/11 Mode	42-54 Ramp Down Time	99-56 Fan 1 Feedback
<b>36-4* Output X49/7</b>	<b>42-5* Safe Fieldbus</b>	99-57 Fan 2 Feedback
36-40 Terminal X49/7 Analogue Output	42-60 Telegram Selection	99-58 PC Auxiliary Temp
36-42 Terminal X49/7 Min. Scale	42-61 Destination Address	99-59 Power Card Temp.
36-43 Terminal X49/7 Max. Scale	<b>42-8* Status</b>	<b>99-8* RTDC</b>
36-44 Terminal X49/7 Bus Control	42-80 Safe Option Status	99-80 tCon1 Selection
36-45 Terminal X49/7 Timeout Preset	42-81 Safe Option Status 2	99-81 tCon2 Selection
<b>36-5* Output X49/9</b>	42-82 Safe Control Word	99-82 Trig Compare Selection
36-50 Terminal X49/9 Analogue Output	42-83 Safe Status Word	99-83 Trig Compare Operator
36-52 Terminal X49/9 Min. Scale	42-85 Active Safe Func.	99-84 Trig Compare Operand
36-53 Terminal X49/9 Max. Scale	42-86 Safe Option Info	99-85 Trig Start
36-54 Terminal X49/9 Bus Control	42-87 Time Until Manual Test	99-86 Pre-trigger
36-55 Terminal X49/9 Timeout Preset	42-88 Supported Customization File Version	<b>99-9* Internal Values</b>
<b>36-6* Output X49/11</b>	<b>42-9* Special</b>	99-90 Options present
36-60 Terminal X49/11 Analogue Output	42-90 Restart Safe Option	99-91 Motor Power Internal
36-62 Terminal X49/11 Min. Scale	<b>99-9* Devel support</b>	99-92 Motor Voltage Internal
36-63 Terminal X49/11 Max. Scale	<b>99-0* DSP Debug</b>	99-93 Motor Frequency Internal
36-64 Terminal X49/11 Bus Control	99-00 DAC 1 selection	<b>600-3** PROFIsafe</b>
36-65 Terminal X49/11 Timeout Preset	99-01 DAC 2 selection	600-22 PROFIdrive/safe Tel. Selected
<b>42-2** Safety Functions</b>	99-02 DAC 3 selection	600-44 Fault Message Counter
<b>42-1* Speed Monitoring</b>	99-03 DAC 4 selection	600-47 Fault Number
42-10 Measured Speed Source	99-04 DAC 1 scale	600-52 Fault Situation Counter
42-11 Encoder Resolution	99-05 DAC 2 scale	<b>601-3** PROFIdrive 2</b>
42-12 Encoder Direction	99-06 DAC 3 scale	601-22 PROFIdrive Safety Channel Tel. No.
42-13 Gear Ratio	99-07 DAC 4 scale	
42-14 Feedback Type	99-08 Test param 1	
42-15 Feedback Filter	99-09 Test param 2	
42-17 Tolerance Error	99-10 DAC Option Slot	
42-18 Zero Speed Timer	<b>99-1* Hardware Control</b>	
42-19 Zero Speed Limit	99-11 RFI 2	
<b>42-2* Safe Input</b>	99-12 Fan	
42-20 Safe Function	<b>99-1* Software Readouts</b>	
42-21 Type	99-13 Idle time	
42-22 Discrepancy Time	99-14 Paramdb requests in queue	
42-23 Stable Signal Time	99-15 Secondary Timer at Inverter Fault	
42-24 Restart Behaviour	99-16 No of Current Sensors	
<b>42-3* General</b>	99-17 tCon1 time	
42-30 External Failure Reaction	99-18 tCon2 time	
42-31 Reset Source	99-19 Time Optimize Measure	
42-33 Parameter Set Name	<b>99-2* Heatsink Readouts</b>	
42-35 S-CRC Value	99-20 HS Temp. (PC1)	
42-36 Level 1 Password	99-21 HS Temp. (PC2)	
<b>42-4* SSI</b>	99-22 HS Temp. (PC3)	
42-40 Type	99-23 HS Temp. (PC4)	
42-41 Ramp Profile	99-24 HS Temp. (PC5)	
42-42 Delay Time	99-25 HS Temp. (PC6)	
42-43 Delta T	99-26 HS Temp. (PC7)	
42-44 Deceleration Rate	99-27 HS Temp. (PC8)	
42-45 Delta V	<b>99-4* Software Control</b>	
42-46 Zero Speed	99-40 StartupWizardState	
42-47 Ramp Time	99-41 Performance Measurements	
42-48 S-ramp Ratio at Decel. Start	<b>99-5* PC Debug</b>	
42-49 S-ramp Ratio at Decel. End	99-50 PC Debug Selection	
<b>42-5* SLS</b>	99-51 PC Debug Argument	
42-50 Cut Off Speed	99-52 PC Debug 0	

**Index**

**A**

Abbreviation..... 70

AC input..... 6, 30

AC mains..... 6, 30

AC waveform..... 6

Additional resources..... 3

Alarm log..... 36

Alarms..... 49

AMA..... 47, 51, 54

AMA with T27 connected..... 40

AMA without T27 connected..... 40

Ambient condition..... 63

Analog input..... 31, 64

Analog output..... 31, 65

Analog signal..... 50

Analog speed reference..... 40

Approval..... 6

Auto on..... 39, 47, 48

Auto On..... 37

Automatic Motor Adaptation (AMA)..... 40

Auto-reset..... 35

Auxiliary equipment..... 34

**B**

Block diagram..... 6

Brake

    control..... 51

    limit..... 52

    resistor..... 50

Braking..... 47

**C**

Cable length and cross-section..... 64

Cable routing..... 34

Cable specification..... 64

Certification..... 6

Circuit breaker..... 34, 67

Clearance requirement..... 9

Closed loop..... 32

Communication option..... 53

Conduct..... 34

Control

    card..... 50

    word time-out..... 52

Control card

    Performance..... 66

    RS485 serial communication..... 65

Control characteristic..... 66

Control signal..... 47

Control terminal..... 37, 38, 47, 49

Control wiring..... 11, 13, 32, 34

Convention..... 70

Cooling..... 9

Cooling clearance..... 34

Current

    rating..... 50

    Output current..... 50

Current limit..... 59

**D**

DC current..... 6, 11, 47

DC link..... 50

Default setting..... 37

Digital input..... 32, 48, 64

Digital output..... 65

Dimension, shipping..... 69

Discharge time..... 7

Disconnect switch..... 35

**E**

Efficiency..... 60, 61, 62

Electrical interference..... 11

EMC..... 11

EMC interference..... 13

Energy efficiency class..... 63

Extended options cabinet..... 5

External alarm reset..... 43

External command..... 49

External commands..... 6

External controller..... 3

**F**

Fault log..... 36

FC..... 33

Feedback..... 32, 34, 47, 53

Floating delta..... 30

FLUX..... 45

Fuse..... 11, 34, 53, 67

**G**

Ground connection..... 34

Ground wire.....	11	MCT 10.....	31, 35
Grounded delta.....	30	Mechanical brake control.....	45
Grounding.....	14, 30, 34, 35	Menu key.....	36
<b>H</b>		Menu structure.....	36
Hand on.....	37, 47	Modbus RTU.....	33
Harmonics.....	6	<b>Motor</b>	
Heat sink.....	53	current.....	54
High voltage.....	7, 35	data.....	50, 54
<b>I</b>		power.....	54
Initialisation.....	38	thermistor.....	43
Input current.....	30	Thermistor.....	44
Input disconnect.....	30	Motor cable.....	14
Input power.....	6, 11, 13, 30, 34, 35, 49	Motor connection.....	14
Input power wiring.....	34	Motor current.....	6, 36
Input signal.....	32	Motor data.....	59
Input terminal.....	30, 32, 35	Motor output (U, V, W).....	63
Input voltage.....	35	Motor power.....	11, 36
<b>Inputs</b>		Motor protection.....	3
Analog input.....	50	Motor rotation check.....	39
Digital input.....	51	Motor speed.....	38
Installation.....	32, 33, 34	Motor status.....	3
Installation environment.....	9	Motor thermal protection.....	44
Intended use.....	3	Motor wiring.....	13, 34
Interference isolation.....	34	Mounting.....	10, 34
Interior view.....	4	<b>N</b>	
Intermediate circuit.....	50	Nameplate.....	9
Isolated main.....	30	Navigation key.....	36, 38, 47
<b>J</b>		<b>O</b>	
Jumper.....	32	Open loop.....	32, 45, 66
<b>L</b>		Operation key.....	36
Leakage current.....	8, 11	Optional equipment.....	32, 35
Lifting.....	10	Output current.....	47, 65
Load share.....	69	Output power wiring.....	34
Load sharing.....	7	Output terminal.....	35
Local control.....	35, 37, 47	Overcurrent protection.....	11
Local control panel (LCP).....	35	Overheating.....	51
<b>M</b>		Overtemperature.....	51
Main menu.....	36	Overvoltage.....	48, 59
Mains supply (L1, L2, L3).....	63	<b>P</b>	
Mains voltage.....	36, 47	Parameter menu structure.....	71
Maintenance.....	46	PELV.....	43, 66
Manual initialisation.....	38	Phase loss.....	50
		Potential equalisation.....	11
		Power connection.....	11

Power factor.....	6, 34	Supply voltage.....	31, 35, 53, 65
Programming.....	32, 35, 36, 37	Switch.....	32
Pulse input.....	65	Switching frequency.....	48
Pulse start/stop.....	42	Symbol.....	70
<b>Q</b>		System feedback.....	3
Qualified personnel.....	7	<b>T</b>	
Quick menu.....	36	Terminal 53.....	32
<b>R</b>		Terminal 54.....	32
Ramp-down time.....	59	Terminal location, D1h.....	15
Ramp-up time.....	59	Terminal location, D2h.....	15
Reference.....	36, 40, 47, 48	Terminal location, D3h.....	16
Relay output.....	66	Terminal location, D4h.....	17
Remote command.....	3	Terminals	
Remote reference.....	48	Input.....	50
Reset.....	35, 36, 37, 38, 49, 50, 51, 55	Terminal 54.....	56
RFI filter.....	30	Thermal protection.....	6
RMS current.....	6	Thermistor.....	31
RS485.....	43	Thermistor control wiring.....	31
RS485 serial communication.....	33	Torque.....	51
Run command.....	39	Torque characteristic.....	63
Run permissive.....	48	Torque limit.....	59
<b>S</b>		Torque, terminal.....	69
Safe Torque Off.....	33	Transient protection.....	6
Safety.....	8	Trip.....	44
Screened cable.....	13, 34	Trip lock.....	49
Serial communication.....	31, 37, 47, 48, 49	Trips.....	49
Service.....	46	Troubleshooting.....	59
Setpoint.....	48	<b>U</b>	
Set-up.....	36, 39	Unintended motor rotation.....	8
Shipping dimension.....	69	Unintended start.....	7, 46
Short circuit.....	51	<b>V</b>	
Short circuit current rating (SCCR).....	68	Voltage imbalance.....	50
SLC.....	44	<b>W</b>	
Sleep mode.....	48	Warnings.....	49
Specifications.....	33	Weight.....	69
Speed reference.....	32, 39, 40, 47	Windmilling.....	8
Speed reference, analog.....	40	Wire size.....	11, 14
Start/stop command.....	42		
Start-up.....	38		
Status display.....	47		
Status mode.....	47		
STO.....	33		
Storage.....	9		







.....  
Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.  
.....

Danfoss A/S  
Ulsnaes 1  
DK-6300 Graasten  
vlt-drives.danfoss.com

