

GE
Industrial Solutions

AF-650 GP™ General Purpose Drive

Quick Guide



a product of
ecomagination





1 Safety

1.1 Safety Symbols

The following symbols are used in this manual:

⚠ WARNING

Indicates a potentially hazardous situation that could result in death or serious injury.

⚠ CAUTION

Indicates a potentially hazardous situation that could result in minor or moderate injury. It can also be used to alert against unsafe practices.

NOTICE

Indicates important information, including situations that can result in damage to equipment or property.

1.2 Qualified Personnel

Correct and reliable transport, storage, installation, operation, and maintenance are required for the trouble-free and safe operation of the drive. Only qualified personnel are allowed to install and operate this equipment.

Qualified personnel are defined as trained staff, who are authorized to install, commission, and maintain equipment, systems, and circuits in accordance with pertinent laws and regulations. Also, the qualified personnel must be familiar with the instructions and safety measures described in these operating instructions.

1.3 Safety Precautions

⚠ WARNING

HIGH VOLTAGE

Drives contain high voltage when connected to AC mains input, DC supply, or load sharing. Failure to perform installation, start-up, and maintenance by qualified personnel can result in death or serious injury.

- Only qualified personnel must perform installation, start-up, and maintenance.

⚠ WARNING

UNINTENDED START

When the frequency converter is connected to AC mains, DC supply, or load sharing, the motor may start at any time. Unintended start during programming, service, or repair work can result in death, serious injury, or property damage. The motor can start via an external switch, a fieldbus command, an input reference signal from the keypad, or after a cleared fault condition.

To prevent unintended motor start:

- Disconnect the frequency converter from the mains.
- Press [Off/Reset] on the keypad before programming parameters.
- Completely wire and assemble the frequency converter, motor, and any driven equipment before connecting the frequency converter to AC mains, DC supply, or load sharing.

⚠ WARNING

DISCHARGE TIME

The frequency converter contains DC-link capacitors, which can remain charged even when the frequency converter is not powered. High voltage can be present even when the warning indicator lights are off. Failure to wait the specified time after power has been removed before performing service or repair work, could result in death or serious injury.

1. Stop the motor.
2. Disconnect AC mains, permanent magnet type motors, and remote DC-link supplies, including battery back-ups, UPS, and DC-link connections to other frequency converters.
3. Wait for the capacitors to discharge fully, before performing any service or repair work. The duration of waiting time is specified in *Table 1.1*.



Safety

| Voltage [V] | Power size [kW (hp)] | Minimum waiting time (minutes) |
|-------------|----------------------|--------------------------------|
| 200–240 | 0.25–3.7 (1/3–5) | 4 |
| | 5.5–37 (7.5–50) | 15 |
| 380–500 | 0.37–7.5 (1/2–10) | 4 |
| | 11–75 (15–100) | 15 |
| | 90–250 (125–350) | 20 |
| | 315–800 (450–1200) | 40 |
| 525–600 | 0.75–7.5 (1–10) | 4 |
| | 11–75 (15–100) | 15 |
| 525–690 | 11–75 (15–100) | 15 |
| | 90–315 (125–400) | 20 |
| | 355–1200 (500–1350) | 30 |

Table 1.1 Discharge Time

⚠ WARNING

LEAKAGE CURRENT HAZARD

Leakage currents exceed 3.5 mA. Failure to ground the drive properly can result in death or serious injury.

- Ensure the correct grounding of the equipment by a certified electrical installer.

⚠ WARNING

EQUIPMENT HAZARD

Contact with rotating shafts and electrical equipment can result in death or serious injury.

- Ensure that only trained and qualified personnel perform installation, start-up, and maintenance.
- Ensure that electrical work conforms to national and local electrical codes.
- Follow the procedures in this guide.

⚠ WARNING

UNINTENDED MOTOR ROTATION

WINDMILLING

Unintended rotation of permanent magnet motors creates voltage and can charge the unit, resulting in death, serious injury, or equipment damage.

- Ensure that permanent magnet motors are blocked to prevent unintended rotation.

⚠ CAUTION


INTERNAL FAILURE HAZARD

An internal failure in the drive can result in serious injury when the drive is not properly closed.

- Ensure that all safety covers are in place and securely fastened before applying power.



2 Introduction



130BB492.10

| | | | |
|---|--|----|--|
| 1 | Keypad | 10 | Motor output terminals 96 (U), 97 (V), 98 (W) |
| 2 | RS485 serial bus connector (+68, -69) | 11 | Relay 1 (01, 02, 03) |
| 3 | Analog I/O connector | 12 | Relay 2 (04, 05, 06) |
| 4 | Keypad input plug | 13 | Brake (-81, +82) and load sharing (-88, +89) terminals |
| 5 | Analog switches (A53), (A54) | 14 | Mains input terminals 91 (L1), 92 (L2), 93 (L3) |
| 6 | Cable strain relief/PE ground | 15 | USB connector |
| 7 | Decoupling plate | 16 | Serial bus terminal switch |
| 8 | Grounding clamp (PE) | 17 | Digital I/O and 24 V power supply |
| 9 | Shielded cable grounding clamp and strain relief | 18 | Control cable cover plate |

Illustration 2.1 Exploded View Unit Sizes 12–13, IP20

NOTICE

Consult the AF-650 GP Design & Installation Guide for other unit sizes.



3 Installation

3

3.1 Installation Site Check List

- The frequency converter relies on the ambient air for cooling. Observe the limitations on ambient air temperature for optimal operation.
- Ensure that the installation location has sufficient support strength to mount the frequency converter.
- Keep the manual, drawings, and diagrams accessible for detailed installation and operation instructions. It is important that the manual is available for equipment operators.
- Locate equipment as near to the motor as possible. Keep motor cables as short as possible. Check the motor characteristics for actual tolerances.

Do not exceed:

- 300 m (1000 ft) for unshielded motor cables.
- 150 m (500 ft) for shielded cable.

- Ensure that the ingress protection rating of the frequency converter is suitable for the installation environment. IP55 (NEMA 12) or IP66 (NEMA 4) enclosures may be necessary.

CAUTION

INGRESS PROTECTION

IP54, IP55, and IP66 ratings can only be guaranteed if the unit is properly closed.

- Ensure that all cable glands and unused holes for glands are properly sealed.
- Ensure that the unit cover is properly closed.

CAUTION

DEVICE DAMAGE THROUGH CONTAMINATION

Do not leave the frequency converter uncovered.

3.2 Frequency Converter and Motor Pre-installation Check List

- Compare the model number of unit on the nameplate to what was ordered to verify the proper equipment.
- Ensure each of the following are rated for same voltage:
 - Mains (power)
 - Frequency converter
 - Motor

- Ensure that the frequency converter output current rating is equal to or greater than motor full load current for peak motor performance:
 - Motor size and frequency converter power must match for proper overload protection.
 - If frequency converter rating is less than motor, full motor output cannot be achieved.

3.3 Mechanical Installation

3.3.1 Cooling

- To provide cooling airflow, mount the unit to a solid flat surface or to the optional backplate (see chapter 3.3.3 Mounting).
- Top and bottom clearance for air cooling must be provided. Generally, 100–225 mm (4–10 in) is required. See *Illustration 3.1* for clearance requirements.
- Improper mounting can result in over heating and reduced performance.
- Derating for temperatures starting between 40 °C (104 °F) and 50 °C (122 °F) and elevation 1000 m (3300 ft) above sea level must be considered. See the equipment Design Guide for detailed information.




Illustration 3.1 Top and Bottom Cooling Clearance



| Voltage [V] | Power size [kW (hp)] | Clearance a/b [mm (in)] |
|-------------|----------------------|-------------------------|
| 200–240 | 0.25–3.7 (1/3–5) | 100 (4) |
| | 5.5–22 (7.5–30) | 200 (8) |
| | > 22 (30) | 225 (10) |
| 380–500 | 0.37–7.5 (1/2–10) | 100 (4) |
| | 11–45 (15–60) | 200 (8) |
| | > 45 (60) | 225 (10) |
| 525–600 | 0.37–7.5 (1/2–10) | 100 (4) |
| | 11–45 (15–60) | 200 (8) |
| | > 45 (60) | 225 (10) |
| 525–690 | All | 225 (10) |

Table 3.1 Minimum Airflow Clearance Requirements




Illustration 3.2 Proper Mounting with Backplate

3.3.2 Lifting

- Check the weight of the unit to determine a safe lifting method.
- Ensure that the lifting device is suitable for the task.
- If necessary, plan for a hoist, crane, or forklift with the appropriate rating to move the unit.
- For lifting, use hoist rings on the unit, when provided.

3.3.3 Mounting

- Mount the unit vertically.
- The frequency converter allows side-by-side installation.
- Ensure that the strength of the mounting location supports the unit weight.
- Mount the unit to a solid flat surface or to the optional backplate to provide cooling airflow (see *Illustration 3.2* and *Illustration 3.3*).
- Improper mounting can result in over heating and reduced performance.
- Use the slotted mounting holes on the unit for wall mount, when provided.
- For outdoor installations of Nema 4X/IP66 drives: The drive must be installed under a suitable cover to protect from direct exposure to sun, snow, and ice.

Item A in *Illustration 3.2* and *Illustration 3.3* is a backplate properly installed for required airflow to cool the unit.




Illustration 3.3 Proper Mounting with Railings

NOTICE

Back plate is needed when mounted on railings.

Installation

3.4 Electrical Installation

This section contains detailed instructions for wiring the frequency converter.

The following tasks are described:

- Wiring the motor to the frequency converter output terminals.
- Wiring the AC mains to the frequency converter input terminals.
- Connecting control and serial communication wiring.
- After power has been applied, checking input and motor power; programming control terminals for their intended functions.




Illustration 3.4 Basic Wiring Schematic Drawing

A=Analog, D=Digital

Terminal 37 is used for Safe Torque Off. Refer to *Safe Torque Off Operating Instructions* for further information.

*The brake chopper factory option must be ordered to use dynamic brake resistors

**The DC bus option must be ordered from factory.



3.4.1 Requirements

WARNING

EQUIPMENT HAZARD!

Rotating shafts and electrical equipment can be hazardous. All electrical work must conform to national and local electrical codes. It is recommended that installation, start up, and maintenance is performed only by trained and qualified personnel. Failure to follow these guidelines could result in death or serious injury.

CAUTION

WIRING ISOLATION!

Run input power, motor wiring, and control wiring in three separate metallic conduits or use separated shielded cable for high frequency noise isolation. Failure to isolate power, motor, and control wiring could result in less than optimum frequency converter and associated equipment performance.

For your safety, comply with the following requirements:

- Electronic controls equipment is connected to hazardous mains voltage. Extreme care should be taken to protect against electrical hazards when applying power to the unit.
- Run motor cables from multiple frequency converters separately. Induced voltage from output motor cables run together can charge equipment capacitors even with the equipment turned off and locked out.

Overload and equipment protection

- An electronically activated function within the frequency converter provides overload protection for the motor. The overload calculates the level of increase to activate timing for the trip (controller output stop) function. The higher the current draw, the quicker the trip response. The overload provides Class 20 motor protection. See *chapter 7 Warnings and Alarm* for details on the trip function.
- Because the motor wiring carries high frequency current, it is important that wiring for mains, motor power, and control are run separately. Use metallic conduit or separated shielded wire. Failure to isolate power, motor, and control wiring could result in less than optimum equipment performance.
- All frequency converters must be provided with short circuit and overcurrent protection. Input fusing is required to provide this protection, see *Illustration 3.5*. Fuses must be provided by the

installer as part of installation. See maximum fuse ratings in *chapter 9.1.1 CE Compliance*.




Illustration 3.5 Frequency Converter Fuses

Wire type and ratings

- All wiring must comply with local and national regulations regarding cross-section and ambient temperature requirements.
- GE recommends that all power connections be made with a minimum 75 ° C (167°F) rated copper wire.

3.4.2 Grounding Requirements

WARNING

GROUNDING HAZARD!

For operator safety, it is important to ground the frequency converter properly in accordance with national and local electrical codes and instructions contained within these instructions. Ground currents are higher than 3.5 mA. Failure to ground the frequency converter properly could result in death or serious injury.

NOTICE

It is the responsibility of the user or certified electrical installer to ensure correct grounding of the equipment in accordance with national and local electrical codes and standards.

- Follow all local and national electrical codes to ground electrical equipment properly.
- Proper protective grounding for equipment with ground currents higher than 3.5 mA must be established, see *chapter 3.4.2.1 Leakage Current (>3.5 mA)*.

Installation

- A dedicated ground wire is required for input power, motor power, and control wiring.
- Use the clamps provided with on the equipment for proper ground connections.
- Do not ground one frequency converter to another in a “daisy chain” fashion.
- Keep the ground wire connections as short as possible.
- Use of high-strand wire to reduce electrical noise is recommended.
- Follow motor manufacturer wiring requirements.

3.4.2.1 Leakage Current (>3.5 mA)

Follow national and local codes regarding protective earthing of equipment with a leakage current > 3.5 mA. Frequency converter technology implies high frequency switching at high power. This generates a leakage current in the ground connection. A fault current in the frequency converter at the output power terminals might contain a DC component which can charge the filter capacitors and cause a transient ground current. The ground leakage current depends on various system configurations including RFI filtering, shielded motor cables, and frequency converter power.

EN/IEC61800-5-1 (Power Drive System Product Standard) requires special care if the leakage current exceeds 3.5 mA.

Grounding must be reinforced in one of the following ways:

- Ground wire of at least 10 mm² (8 AWG).
- Two separate ground wires both complying with the dimensioning rules.

See EN 60364-5-54 § 543.7 for further information.

Using RCDs

Where residual current devices (RCDs), also known as earth leakage circuit breakers (ELCBs), are used, comply with the following:

- Use RCDs of type B only which are capable of detecting AC and DC currents.
- Use RCDs with an inrush delay to prevent faults due to transient ground currents.
- Dimension RCDs according to the system configuration and environmental considerations.

3.4.2.2 Grounding Using Shielded Cable

Grounding clamps are provided for motor wiring (see *Illustration 3.6*).




Illustration 3.6 Grounding with Shielded Cable

3.4.3 Motor Connection

WARNING

INDUCED VOLTAGE!

Run output motor cables from multiple frequency converters separately. Induced voltage from output motor cables run together can charge equipment capacitors even with the equipment turned off and locked out. Failure to run output motor cables separately could result in death or serious injury.

- For maximum wire sizes, see *Table 10.1*.
- Comply with local and national electrical codes for cable sizes.
- Motor wiring knockouts or access panels are provided at the base of IP21 and higher (Nema 1, 12, and 4/4X Indoor) units.
- Do not install power factor correction capacitors between the frequency converter and the motor.
- Do not wire a starting or pole-changing device between the frequency converter and the motor.
- Connect the 3-phase motor wiring to terminals 96 (U), 97 (V), and 98 (W).
- Ground the cable in accordance with grounding instructions provided.
- Torque terminals in accordance with the information provided in *chapter 10 Terminal and Applicable Wire*.
- Follow motor manufacturer wiring requirements.

Illustration 3.7 shows mains input, motor, and grounding for basic frequency converters. Actual configurations vary with unit types and optional equipment.




Illustration 3.7 Example of Motor, Mains, and Ground Wiring

3.4.4 AC Mains Connection


- Size wiring based on the input current of the frequency converter. For maximum wire sizes, see *Table 10.1*.
- Comply with local and national electrical codes for cable sizes.
- Connect 3-phase AC input power wiring to terminals L1, L2, and L3 (see *Illustration 3.7*).
- Depending on the configuration of the equipment, input power is connected to the mains input power or the input disconnect.
- Ground the cable in accordance with grounding instructions provided in *chapter 3.4.2 Grounding Requirements*.
- All frequency converters may be used with an isolated input source and with ground reference power lines. When supplied from an isolated mains source (IT mains or floating delta) or TT/TN-S mains with a grounded leg (grounded delta), set *parameter SP-50 RFI Filter* to [0] Off. When off, the internal RFI filter capacitors between the chassis and the intermediate circuit are isolated to avoid damage to the DC link and to reduce ground capacity currents in accordance with IEC 61800-3.

3.4.5 Control Wiring

- Isolate control wiring from high-power components in the frequency converter.
- If the frequency converter is connected to a thermistor, for PELV isolation, optional thermistor control wiring must be reinforced/double insulated. A 24 V DC supply voltage is recommended.

3.4.5.1 Access

- Remove access cover plate with a screwdriver. See *Illustration 3.8*.
- Or remove front cover by loosening attaching screws. See *Illustration 3.9*. Tightening torque for front cover is 2.0 Nm for unit size 15 Nm and 2.2 Nm for unit sizes 2X and 3X.



130BT248
Illustration 3.8 Control Wiring Access for IP20/Open Chassis Enclosures




Illustration 3.9 Control Wiring Access for IP55/ Nema 12 and IP66/Nema 4/4X Indoor

optional customer supplied 24 V DC voltage. A digital input for STO (Safe Torque Off) function.

- **Connector 2** terminals (+)68 and (-)69 are for an RS485 serial communications connection.
- **Connector 3** provides two analog inputs, one analog output, 10 V DC supply voltage, and commons for the inputs and output.
- **Connector 4** is a USB port available for use with the DCT-10.
- Also provided are two Form C relay outputs that are in various locations depending after the frequency converter configuration and size.
- Some options available for ordering with the unit may provide extra terminals. See the manual provided with the equipment option.

See *chapter 8.1 General Technical Data* for terminal ratings details.

3.4.5.2 Control Terminal Types

Illustration 3.10 shows the removable frequency converter connectors. Terminal functions and default settings are summarized in Table 3.3.




Illustration 3.10 Control Terminal Locations




Illustration 3.11 Terminal Numbers

- **Connector 1** provides four programmable digital inputs terminals, two extra digital terminals programmable as either input or output, a 24 V DC terminal supply voltage, and a common for

| Terminal description | | | |
|-------------------------------|-----------|-----------------------|---|
| Terminal | Parameter | Default setting | Description |
| Digital inputs/outputs | | | |
| 12, 13 | – | +24 V DC | 24 V DC supply voltage. Maximum output current is 200 mA total for all 24 V loads. Useable for digital inputs and external transducers. |
| 18 | E-01 | [8] Start | Digital inputs. |
| 19 | E-02 | [10] Reversing | |
| 32 | E-05 | [0] No operation | |
| 33 | E-06 | [0] No operation | |
| 27 | E-03 | [0] No operation | Selectable for either digital input or output. Default setting is input. |
| 29 | E-04 | [14] Jog | |
| 20 | – | | Common for digital inputs and 0 V potential for 24 V supply. |
| 37 | – | Safe Torque Off (STO) | Safe input. Used for STO. |
| Analog inputs/outputs | | | |
| 39 | – | – | Common for analog output. |
| 42 | AN-50 | [0] No operation | Programmable analog output. The analog signal is 0–20 mA or 4–20 mA at a maximum of 500 Ω |

| Terminal description | | | |
|-------------------------------|-----------|-----------------|---|
| Terminal | Parameter | Default setting | Description |
| Digital inputs/outputs | | | |
| 50 | - | +10 V DC | 10 V DC analog supply voltage. 15 mA maximum commonly used for potentiometer or thermistor. |
| 53 | AN-1# | Reference | Analog input. |
| 54 | AN-2# | Feedback | Selectable for voltage or current. Switches A53 and A54 select mA or V. |
| 55 | - | - | Common for analog input. |

Table 3.2 Terminal Description Digital Inputs/Outputs, Analog Inputs/Outputs

| Terminal description | | | |
|-----------------------------|-----------|------------------|---|
| Terminal | Parameter | Default setting | Description |
| Serial communication | | | |
| 61 | - | - | Integrated RC-Filter for cable screen. ONLY for connecting the shield when experiencing EMC problems. |
| 68 (+) | O-3# | - | RS485 Interface. A control card switch is provided for termination resistance. |
| 69 (-) | O-3# | - | |
| Relays | | | |
| 01, 02, 03 | E-24 | [0] No operation | Form C relay output. Usable for AC or DC voltage and resistive or inductive loads. |
| 04, 05, 06 | E-24 | [0] No operation | |

Table 3.3 Terminal Description Serial Communication

3.4.5.3 Wiring to Control Terminals

Control terminal connectors can be unplugged from the frequency converter for ease of installation, as shown in *Illustration 3.10*.

1. Open the contact by inserting a small screwdriver into the slot above or below the contact, as shown in *Illustration 3.12*.
2. Insert the bared control wire into the contact.
3. Remove the screwdriver to fasten the control wire into the contact.
4. Ensure that the contact is firmly established and not loose. Loose control wiring can be the source

of equipment faults or less than optimal operation.





Illustration 3.12 Connecting Control Wiring

3.4.5.4 Using Shielded Control Cables

Correct screening

The preferred method usually is to secure control and serial communication cables with screening clamps provided at both ends to ensure best possible high frequency cable contact.

If the ground potential between the frequency converter and the PLC is different, electric noise may occur that disturbs the entire system. Solve this problem by fitting an equalizing cable next to the control cable. Minimum cable cross-section: 16 mm² (6 AWG).



| | |
|---|------------------------------------|
| 1 | Minimum 16 mm ² (6 AWG) |
| 2 | Equalizing cable |

Illustration 3.13 Correct Screening

50/60 Hz ground loops

With long control cables, ground loops may occur. To eliminate ground loops, connect one end of the screen-to-ground with a 100 nF capacitor (keeping leads short).





Illustration 3.14 50/60 Hz Ground Loops

Installation

Avoid EMC noise on serial communication


This terminal is connected to ground via an internal RC link. Use twisted-pair cables to reduce interference between conductors. The recommended method is in *Illustration 3.15*:



| | |
|---|------------------------------------|
| 1 | Minimum 16 mm ² (6 AWG) |
| 2 | Equalizing cable |

Illustration 3.15 Twisted-pair Cables

Alternatively, the connection to terminal 61 can be omitted:



| | |
|---|------------------------------------|
| 1 | Minimum 16 mm ² (6 AWG) |
| 2 | Equalizing cable |

Illustration 3.16 Twisted-pair Cables without Terminal 61

3.4.5.5 Control Terminal Functions

Frequency converter functions are commanded by receiving control input signals.

- Each terminal must be programmed for the function it is supporting in the parameters associated with that terminal. See *Table 3.3* for terminals and associated parameters.
- It is important to confirm that the control terminal is programmed for the correct function. See *chapter 5 User Interface* for details on accessing parameters and for details on programming.
- The default terminal programming is intended to initiate frequency converter functioning in a typical operational mode.

3.4.5.6 Terminal 53 and 54 Switches

- Analog input terminals 53 and 54 can select either voltage (-10 V to 10 V) or current (0/4–20 mA) input signals.
- Remove power to the frequency converter before changing switch positions.
- Set switches A53 and A54 to select the signal type. U selects voltage, I selects current.
- The switches are accessible when the keypad has been removed (see *Illustration 3.17*).

NOTICE

Some option cards available for the unit may cover these switches and must be removed to change switch settings. Always remove power to the unit before removing option cards.

- Terminal 53 default is for a speed reference signal in open loop set in *parameter DR-61 Terminal 53 Switch Setting*.
- Terminal 54 default is for a feedback signal in closed loop set in *parameter DR-63 Terminal 54 Switch Setting*.




Illustration 3.17 Location of Terminals 53 and 54 Switches and Bus Termination Switch



3.4.5.7 Terminal 37

Terminal 37 Safe Torque Off function

The AF-650 GP is available with Safe Torque Off functionality via control terminal 37. Safe torque off (STO) disables the control voltage of the power semiconductors of the frequency converter output stage which in turn prevents generating the voltage required to rotate the motor. To run STO, additional wiring for the frequency converter is required. Refer to *Safe Torque Off Operating Instructions* for further information.

3.4.6 Serial Communication

Connect RS485 serial communication wiring to terminals (+)68 and (-)69.

- Shielded serial communication cable is recommended.
- See *chapter 3.4.2 Grounding Requirements* for proper grounding.




Illustration 3.18 Serial Communication Wiring Diagram

For basic serial communication set-up, select the following:

1. Protocol type in *parameter O-30 Protocol*.
 2. Frequency converter address in *parameter O-31 Address*.
 3. Baud rate in *parameter O-32 Drive Port Baud Rate*.
- Two communication protocols are internal to the frequency converter.
 - Drive profile
 - Modbus RTU
 - Functions can be programmed remotely using the protocol software and RS485 connection or in parameter group *O-## Options/Comms*.
 - Selecting a specific communication protocol changes various default parameter settings to match that protocol's specifications along with making extra protocol-specific parameters available.
 - Option cards which install into the frequency converter are available to provide extra communication protocols. See the option-card documentation for installation and operation instructions.



4 Start-up and Functional Testing

4.1 Pre-start

4.1.1 Safety Inspection

4

⚠ WARNING

HIGH VOLTAGE

If input and output connections have been connected improperly, there is potential for high voltage on these terminals. If power leads for multiple motors are improperly run in same conduit, there is potential for leakage current to charge capacitors within the frequency converter, even when disconnected from mains input.

- For initial start-up, make no assumptions about power components.
- Follow pre-start procedures.

Failure to follow pre-start procedures could result in personal injury or damage to equipment.

1. Switch off the Input power to the unit and ensure that it is locked out. Do not rely on the frequency converter disconnect switches for input power isolation.
2. Verify that there is no voltage on input terminals L1 (91), L2 (92), and L3 (93), phase-to-phase, and phase-to-ground.
3. Verify that there is no voltage on output terminals 96 (U), 97 (V), and 98 (W), phase-to-phase, and phase-to-ground.
4. Confirm continuity of the motor by measuring ohm values on U-V (96-97), V-W (97-98), and W-U (98-96).
5. Check for proper grounding of the frequency converter and the motor.
6. Inspect the frequency converter for loose connections on terminals.
7. Record the following motor nameplate data:
 - 7a Power
 - 7b Voltage
 - 7c Frequency
 - 7d Full load current
 - 7e Nominal speed.

These values are needed to program the motor nameplate data later.

8. Confirm that the supply voltage matches the voltage of the frequency converter and the motor.



4.1.2 Pre-start

CAUTION

Before applying power to the unit, inspect the entire installation as detailed in *Table 4.1*. Check mark those items when completed.

| Inspect for | Description | ☑ |
|-------------------------------|---|---|
| Auxiliary equipment | <ul style="list-style-type: none"> Look for auxiliary equipment, switches, disconnects, or input fuses/circuit breakers on the input power side of the frequency converter or output side to the motor. Ensure that they are ready for full speed operation. Check function and installation of any sensors used for feedback to the frequency converter. Remove power factor correction capacitors on motors, if present. | |
| Cable routing | <ul style="list-style-type: none"> Use separate metallic conduits for each of the following: <ul style="list-style-type: none"> Input power Motor wiring Control wiring | |
| Control wiring | <ul style="list-style-type: none"> Check for broken or damaged wires and loose connections. Check that control wiring is isolated from power and motor wiring for noise immunity. Check the voltage source of the signals. Use shielded or twisted-pair cable. Ensure that the shield is terminated correctly. | |
| Cooling clearance | <ul style="list-style-type: none"> Measure that top and bottom clearance is adequate to ensure proper air flow for cooling. | |
| EMC considerations | <ul style="list-style-type: none"> Check for proper installation regarding electromagnetic compatibility. | |
| Environmental considerations | <ul style="list-style-type: none"> See equipment label for the maximum ambient operating temperature limits. Humidity levels must be 5–95%, non-condensing. | |
| Fusing and circuit breakers | <ul style="list-style-type: none"> Check for proper fusing or circuit breakers. Check that all fuses are inserted firmly and in operational condition, and that all circuit breakers are in the open position. | |
| Grounding | <ul style="list-style-type: none"> The unit requires a ground wire from its enclosure to the building ground. Check for good ground connections that are tight and free of oxidation. Grounding to conduit or mounting the back panel to a metal surface is not sufficient. | |
| Input and output power wiring | <ul style="list-style-type: none"> Check for loose connections. Check that motor and mains are in separate conduit or separated shielded cables. | |
| Panel interior | <ul style="list-style-type: none"> Inspect that the unit interior is free of debris and corrosion. | |
| Switches | <ul style="list-style-type: none"> Ensure that all switch and disconnect settings are in the proper positions. | |
| Vibration | <ul style="list-style-type: none"> Check that the unit is mounted solidly or that shock mounts are used as necessary. Check for an unusual amount of vibration. | |

Table 4.1 Start-up Checklist



4.2 Applying Power

⚠ WARNING

HIGH VOLTAGE!

Frequency converters contain high voltage when connected to the energized DC bus. Only qualified personnel should install, start up, and maintain the frequency converters. Failure to let qualified personnel install, start up and maintain the frequency converters could result in death or serious injury.

⚠ WARNING

UNINTENDED START!

When the frequency converter is connected to the energized DC bus, the motor may start at any time. The frequency converter, motor, and any driven equipment must be in operational readiness. Failure to be in operational readiness when the frequency converter is connected to the energized DC bus could result in death, serious injury, equipment, or property damage.

1. Confirm that input voltage is balanced within 3%. If not, correct input voltage imbalance before proceeding. Repeat procedure after voltage correction.
2. Ensure optional equipment wiring, if present, matches installation application.
3. Ensure that all operator devices are in the OFF position. Panel doors closed, or a cover-mounted.
4. Apply power to the unit. DO NOT start the frequency converter now. For units with a disconnect switch, turn to the ON position to apply power to the frequency converter.

4.3 Basic Operational Programming

Frequency converters require basic operational programming before running for best performance. Basic operational programming requires entering motor nameplate data for the motor being operated and the minimum and maximum motor speeds. Parameter settings recommended are intended for start-up and checkout purposes. Application settings may vary. See *chapter 5.1 Keypad* for detailed instructions on entering data through the keypad.

Enter data in accordance with the following procedure.

1. Press [Quick Menu] on the keypad.
2. Use the navigation keys to scroll to Quick Start.
3. Press [OK].

4. Select language and press [OK]. Then enter the motor data in parameters P-02, P-03, P-06, P-07, F-04, and F-05. The information can be found on the motor nameplate.

Parameter P-07 Motor Power [kW] or parameter P-02 Motor Power [HP]

Parameter F-05 Motor Rated Voltage

Parameter F-04 Base Frequency

Parameter P-03 Motor Current

Parameter P-06 Base Speed

5. Enter *parameter F-01 Frequency Setting 1* and press [OK].
6. Enter *parameter F-02 Operation Method*. Local, Remote, or Linked to Hand/Auto. In local mode the reference is entered on the keypad, and in remote that reference is sourced depending on *parameter F-01 Frequency Setting 1*.
7. Enter the accel/decel time in *parameter F-07 Accel Time 1* and *parameter F-08 Decel Time 1*.
8. For *parameter F-10 Electronic Overload*, enter Elec OL Trip 1 for Class 20 overload protection. For further information, see *chapter 3.4.1 Requirements*.
9. For *parameter F-17 Motor Speed High Limit [RPM]* or *parameter F-15 Motor Speed High Limit [Hz]*, enter the application requirements.
10. For *parameter F-18 Motor Speed Low Limit [RPM]* or *parameter F-16 Motor Speed Low Limit [Hz]*, enter the application requirements.
11. Set *parameter H-08 Reverse Lock* to Clockwise, Counterclockwise or Both directions.
12. In *parameter P-04 Auto Tune*, select Reduced Auto Tune or Full Auto Tune and follow on-screen instructions.

4.4 Auto Tune

Auto tune is a test procedure that measures the electrical characteristics of the motor to optimize compatibility between the frequency converter and the motor.

- The frequency converter builds a mathematical model of the motor for regulating output motor current. The procedure also tests the input phase balance of electrical power. It compares the motor characteristics with the data entered in P-0#.
- It does not cause the motor to run or harm to the motor



- Some motors may be unable to run the complete version of the test. In that case, select [2] *Reduced Auto Tune*
- If an output filter is connected to the motor, select [2] *Reduced Auto Tune*
- If warnings or alarms occur, see *chapter 7 Warnings and Alarm*
- Run this procedure on a cold motor for best results

4.5 Check Motor Rotation

Before running the frequency converter, check the motor rotation.

1. Press [Hand].
2. Press [▲] for positive speed reference.
3. Check that the speed shown is positive.
4. Verify that the wiring between the frequency converter and the motor is correct.
5. Verify that the motor running direction matches the setting in *parameter H-48 Clockwise Direction*.
 - When *parameter H-48 Clockwise Direction* is set to [0] *Normal* (default clockwise):
 - a. Verify that the motor turns clockwise.
 - b. Verify that the keypad direction arrow is clockwise.
 - When *parameter H-48 Clockwise Direction* is set to [1] *Inverse* (counterclockwise):
 - a. Verify that the motor turns counterclockwise.
 - b. Verify that the keypad direction arrow is counterclockwise.

4.6 Local-control Test

CAUTION

MOTOR START!

Ensure that the motor, system, and any attached equipment are ready for start. It is the responsibility of the user to ensure safe operation under any operational condition. Failure to ensure that the motor, system, and any attached equipment are ready for start could result in personal injury or equipment damage.

NOTICE

The Hand key on the keypad provides a local start command to the frequency converter. The [Off] key provides the stop function.

When operating in local mode, the up and down keys on the keypad increase and decrease the speed output of the drive. The left and right keys move the display cursor in the numeric display.

1. Press [Hand].
2. Accelerate the frequency converter by pressing [▲] to full speed. Moving the cursor left of the decimal point provides quicker input changes.
3. Note any acceleration problems.
4. Press [Off].
5. Note any deceleration problems.

If acceleration problems were encountered:

- If warnings or alarms occur, see *chapter 7 Warnings and Alarm*
- Check that motor data is entered correctly
- Increase the ramp time in *parameter F-07 Accel Time 1*
- Increase current limit in *parameter F-43 Current Limit*
- Increase torque limit in *parameter F-40 Torque Limiter (Driving)*

If deceleration problems were encountered:

- If warnings or alarms occur, see *chapter 7 Warnings and Alarm*.
- Check that motor data is entered correctly.
- Increase the ramp time in *parameter F-08 Decel Time 1*.
- Enable overvoltage control in *parameter B-17 Over-voltage Control*.

See *chapter 7.4 Warning and Alarm Definitions* for resetting the frequency converter after a trip.

NOTICE

Chapter 4.1 Pre-start through *chapter 4.6 Local-control Test* in this chapter conclude the procedures for applying power to the frequency converter, basic programming, set-up, and functional testing.



4.7 System Start Up

The procedure in this section requires user-wiring and application programming to be completed. is intended to help with this task. The following procedure is recommended after application set-up by the user is completed.

4

⚠ CAUTION

MOTOR START!

Ensure that the motor, system, and any attached equipment are ready for start. It is the responsibility of the user to ensure safe operation under any operational condition. Failure to ensure that the motor, system, and any attached equipment are ready for start could result in personal injury or equipment damage.

1. Press [Auto].
2. Ensure that external control functions are properly wired to the frequency converter and all programming completed.
3. Apply an external run command.
4. Adjust the speed reference throughout the speed range.
5. Remove the external run command.
6. Note any problems.

If warnings or alarms occur, see *chapter 7 Warnings and Alarm*.



5 User Interface

5.1 Keypad

The keypad is the combined display and keys on the front of the unit. The keypad is the user interface to the frequency converter.

The keypad has several user functions:


- Start, stop, and control speed when in local control
- Show operational data, status, warnings, and cautions
- Programming frequency converter functions
- Manually reset the frequency converter after a fault when auto reset is inactive

NOTICE

The display contrast can be adjusted by pressing [Status] and [▲]/[▼] keys.

5.1.1 Keypad Layout

The keypad is divided into 4 functional groups (see *Illustration 5.1*).



130BC362.10

| | |
|---|---|
| a | Display area. |
| b | Display menu keys for changing the display to show status options, programming, or error message history. |
| c | Navigation keys for programming functions, moving the display cursor, and speed control in local operation. The status indicator lights are also in this group. |
| d | Operational mode keys and reset. |

Illustration 5.1 Keypad


User Interface

5.1.2 Setting Keypad Display Values

The display area is activated when the frequency converter receives power from mains voltage, a DC bus terminal, or an external 24 V supply.

The information shown on the keypad can be customized for user application.

- Each display readout has a parameter associated with it.
- Options are selected in main menu K-2#
- The frequency converter status at the bottom line of the display is generated automatically and is not selectable.



| Display | Parameter number | Default setting |
|---------|------------------|-----------------|
| 1.1 | K-20 | Speed [RPM] |
| 1.2 | K-21 | Motor Current |
| 1.3 | K-22 | Power [kW] |
| 2 | K-23 | Frequency |
| 3 | K-24 | Reference [%] |

Table 5.1

Illustration 5.2 Keypad Display Values

5.1.3 Display Menu Keys

Menu keys are used for menu access for parameter set-up, toggling through status display modes during normal operation, and viewing fault log data.



Illustration 5.3 Menu Keys

| Key | Function |
|-------------------|--|
| Status | <p>Press to show operational information.</p> <ul style="list-style-type: none"> • Press repeatedly to scroll through each status display • Press and hold [Status] plus [▲] or [▼] to adjust the display brightness • The symbol in the upper right corner of the display shows the motor rotation direction and which set-up is active. This is not programmable. |
| Quick Menu | <p>Allows access to programming parameters for initial set-up instructions and many detailed application instructions.</p> <ul style="list-style-type: none"> • Press to access <i>Quick Start</i> for sequenced instructions to program the basic frequency controller set-up • Press to access <i>Trending</i> for realtime logging on keypad display. • Press to access <i>Parameter Data Check</i> for changes in parameter data set. • Follow the sequence of parameters as presented for the function set-up |
| Main Menu | <p>Allows access to all programming parameters.</p> <ul style="list-style-type: none"> • Press twice to access top-level index • Press once to return to the last location accessed • Press and hold to enter a parameter number for direct access to that parameter |
| Alarm Log | <p>Shows a list of current warnings, the last 5 alarms, and the maintenance log.</p> <ul style="list-style-type: none"> • For details about the frequency converter before it entered the alarm mode, select the alarm number using the navigation keys and press [OK]. |

Table 5.2 Legend to Illustration 5.3

5.1.4 Navigation Keys

Navigation keys are used for programming functions and moving the display cursor. The navigation keys also provide speed control in local (hand) operation. There are also 3 frequency converter status indicator lights in this area.




Illustration 5.4 Navigation Keys

| Key | Function |
|-----------------|---|
| Back | Reverts to the previous step or list in the menu structure. |
| Cancel | Cancels the last change or command as long as the display mode has not changed. |
| Info | Press for a definition of the function being shown. |
| Navigation Keys | Press the 4 navigation keys to move between items in the menu. |
| OK | Press to access parameter groups or to enable a choice. |

Table 5.3 Navigation Keys Functions

| Light | Indicator | Function |
|--------|-----------|--|
| Green | ON | The ON light activates when the frequency converter receives power from mains voltage, a DC bus terminal, or a 24 V external supply. |
| Yellow | WARN | When warning conditions are met, the yellow WARN light comes on and text appears in the display area identifying the problem. |
| Red | ALARM | A fault condition causes the red alarm light to flash and an alarm text is shown. |

Table 5.4 Indicator Lights Functions

5.1.5 Operation Keys

Operation keys are located at the bottom of the keypad.




Illustration 5.5 Operation Keys

| Key | Function |
|-------|--|
| Hand | Starts the frequency converter in local control. <ul style="list-style-type: none"> Use the navigation keys to control frequency converter speed. An external stop signal by control input or serial communication overrides the local hand. |
| Off | Stops the motor, but does not remove power to the frequency converter. |
| Auto | Puts the system in remote operational mode. <ul style="list-style-type: none"> Responds to an external start command by control terminals or serial communication. Speed reference is from an external source. |
| Reset | Resets the frequency converter manually after a fault has been cleared. |

Table 5.5 Operation Keys Functions

5.2 Back-up and Copying Parameter Settings

Programming data is stored internally in the frequency converter.

- The data can be uploaded into the keypad memory as storage back-up.
- Once stored in the keypad, the data can be downloaded back into the frequency converter.
- Data can also be downloaded into other frequency converters by connecting the keypad into those units and downloading the stored settings. (This is a quick way to program multiple units with the same settings).
- Restoring of the frequency converter to restore factory default settings does not change data stored in the keypad memory.



⚠ WARNING

UNINTENDED START

When the frequency converter is connected to AC mains, or DC power supply, the motor may start at any time. Unintended start during programming, service, or repair work can result in death, serious injury, or property damage. The motor can start with an external switch, a serial bus command, an input reference signal from the keypad, or after a cleared fault condition.

To prevent unintended motor start:

- Disconnect the frequency converter from mains.
- Press [Off/Reset] on the keypad, before programming parameters.
- The frequency converter, motor, and any driven equipment must be fully wired and assembled when the frequency converter is connected to AC mains, or DC power supply.

5.2.1 Uploading data to the keypad

1. Press [Off] to stop the motor before uploading or downloading data.
2. Go to *parameter K-50 Keypad Copy*.
3. Press [OK].
4. Select [1] *All to keypad*.
5. Press [OK]. A progress bar shows the uploading process.
6. Press [Hand] or [Auto] to return to normal operation.

5.2.2 Downloading Data from the Keypad

1. Press [Off] to stop the motor before uploading or downloading data.
2. Go to *parameter K-50 Keypad Copy*.
3. Press [OK].
4. Select [2] *All from keypad*.
5. Press [OK]. A progress bar shows the downloading process.
6. Press [Hand] or [Auto] to return to normal operation.

5.3 Restoring Default Settings

NOTICE

Restore sets the unit to factory default settings. Any programming, motor data, localization, and monitoring records are lost. Uploading data to the keypad provides a back-up before restoring.

Restoring the frequency converter parameter settings back to default values is done by restoring of the frequency converter. Restoring can be carried out via *parameter H-03 Restore Factory Settings* or manually.

- Restoring using *parameter H-03 Restore Factory Settings* does not change frequency converter data such as hours run, serial communication selections, personal menu settings, fault log, alarm log, and other monitoring functions.
- Using *parameter H-03 Restore Factory Settings* is recommended.
- Manual restore erases all motor, programming, localization, and monitoring data and restores factory default settings.

5.3.1 Recommended Restoring

1. Press [Main Menu] twice to access parameters.
2. Scroll to *parameter H-03 Restore Factory Settings*.
3. Press [OK].
4. Scroll to [2] *Restore Factory Settings*.
5. Press [OK].
6. Remove power to the unit and wait for the display to turn off.
7. Apply power to the unit.

Default parameter settings are restored during start-up. This may take slightly longer than normal.

8. Alarm 80 is shown.
9. Press [Reset] to return to operation mode.

5.3.2 Manual Restoring

1. Remove power to the unit and wait for the display to turn off.
2. Press and hold [Status], [Main Menu], and [OK] at the same time and apply power to the unit.

Factory default parameter settings are restored during start-up. This may take slightly longer than normal.

Manual restoring does not reset the following frequency converter information:

- *Parameter ID-00 Operating hours*
- *Parameter ID-03 Power Up's*
- *Parameter ID-04 Over Temp's*
- *Parameter ID-05 Over Volt's*



6 Parameter Menu Structure



Parameter Menu Structure

6

6.1.1 Main Menu Structure

| Code | Description | Code | Description | Code | Description | Code | Description |
|------|-----------------------------------|------|---|------|--------------------------------------|-------|--|
| K-0# | Keypad Setup | E-21 | Terminal 29 Digital Output | C-34 | Frequency Command 3 | H-40 | Configuration Mode |
| K-01 | Language | E-24 | Function Relay | P-0# | Motor Data | H-41 | Motor Control Principle |
| K-02 | Motor Speed Unit | E-26 | On Delay, Relay | P-01 | Motor Poles | H-42 | Flux Motor Feedback Source |
| K-03 | Regional Settings | E-27 | Off Delay, Relay | P-02 | Motor Power [HP] | H-43 | Torque Characteristics |
| K-04 | Operating State at Power-up | E-5# | I/O Mode / Add On I/O | P-03 | Motor Current | H-44 | Constant or Variable Torque OL |
| K-1# | Keypad Set-up Operations | E-51 | Terminal 27 Mode | P-04 | Auto Tune | H-45 | Local Mode Configuration |
| K-10 | Active Set-up | E-52 | Terminal 29 Mode | P-05 | Motor Cont. Rated Torque | H-46 | Back EMF at 1000 RPM |
| K-11 | Edit Set-up | E-53 | Terminal X30/2 Digital Input | P-06 | Base Speed | H-47 | Motor Angle Offset |
| K-12 | This Set-up Linked to | E-54 | Terminal X30/3 Digital Input | P-07 | Motor Power [kW] | H-48 | Clockwise Direction |
| K-13 | Readout: Linked Set-ups | E-55 | Terminal X30/4 Digital Input | P-09 | Slip Compensation | H-49 | Motor Angle Offset Adjust |
| K-14 | Readout: Actual Set-ups / Channel | E-56 | Term X30/6 Digi Out (OPCGPIO) | P-10 | Slip Compensation Time Constant | H-5# | Load Indep. Settings |
| K-15 | Readout: Actual Set-up | E-57 | Term X30/7 Digi Out (OPCGPIO) | P-2# | Motor Selection | H-50 | Motor Magnetisation at Zero Speed |
| K-2# | Keypad Display | E-6# | Pulse Input | P-20 | Motor Construction | H-51 | Min Speed Normal Magnetising [RPM] |
| K-20 | Display Line 1:1 Small | E-61 | Term. 29 Low Frequency | P-24 | Damping Gain | H-52 | Min Speed Normal Magnetising [Hz] |
| K-21 | Display Line 1:2 Small | E-62 | Term. 29 High Frequency | P-25 | Low Speed Filter Time Const. | H-53 | Model Shift Frequency |
| K-22 | Display Line 1:3 Small | E-63 | Term. 29 Low Ref./Feedb. Value | P-26 | High Speed Filter Time Const. | H-54 | Voltage reduction in fieldweakening |
| K-23 | Display Line 2 Large | E-64 | Term. 29 High Ref./Feedb. Value | P-27 | Voltage filter time const. | H-55 | U/f Characteristic - U |
| K-24 | Display Line 3 Large | E-66 | Pulse Filter Time Constant #29 | P-28 | Min. Current at No Load | H-56 | U/f Characteristic - F |
| K-25 | Quick Start | E-67 | Term. 33 Low Frequency | P-3# | Adv. Motor Data | H-59 | Flying Start Test Pulses Frequency |
| K-3# | Keypad Custom Readout | E-68 | Term. 33 High Frequency | P-30 | Stator Resistance (Rs) | H-6# | Load Depen. Settings |
| K-30 | Unit for Custom Readout | E-69 | Term. 33 Low Ref./Feedb. Value | P-31 | Rotor Resistance (Rr) | H-61 | High Speed Load Compensation |
| K-31 | Min Value of Custom Readout | E-69 | Term. 33 High Ref./Feedb. Value | P-33 | Stator Leakage Reactance (X1) | H-62 | Brake Check Limit Factor Source |
| K-32 | Max Value of Custom Readout | E-7# | Pulse Output | P-34 | Rotor Leakage Reactance (X2) | H-63 | Brake Check Limit Factor |
| K-37 | Display Text 1 | E-70 | Terminal 27 Pulse Output Variable | P-35 | Main Reactance (Xh) | H-64 | Resonance Dampening |
| K-38 | Display Text 2 | E-72 | Pulse Output Max Freq #27 | P-36 | Iron Loss Resistance (Rfe) | H-65 | Resonance Dampening Time Constant |
| K-39 | Display Text 3 | E-73 | Terminal 29 Pulse Output Variable | P-37 | d-axis Inductance (Ld) | H-66 | Min. Current at Low Speed |
| K-4# | Keypad Buttons | E-75 | Terminal X30/6 Pulse Output Variable | P-38 | q-axis Inductance (Lq) | H-67 | Torque Limit Factor Source |
| K-40 | [Hand] Button on Keypad | E-76 | Terminal X30/6 Pulse Output Variable | P-45 | q-axis Inductance Sat. (LqSat) | H-7# | Adjustable Warnings |
| K-41 | [Off] Button on Keypad | E-8# | 24V Encoder Input | P-46 | Position Detection Gain | H-70 | Warning Current Low |
| K-42 | [Auto] Button on Keypad | E-80 | Term 32/33 Pulses Per Revolution | P-47 | Torque Calibration | H-71 | Warning Current High |
| K-43 | [Reset] Button on Keypad | E-81 | Term 32/33 Encoder Direction | P-48 | Inductance Sat. Point | H-72 | Warning Speed Low |
| K-5# | Copy/Save | E-90 | Bus Controlled | H-## | High Perf Parameters | H-73 | Warning Speed High |
| K-50 | Keypad Copy | E-93 | Digital & Relay Bus Control | H-01 | Option Detection | H-74 | Warning Reference Low |
| K-51 | Set-up Copy | E-94 | Pulse Out #27 Bus Control | H-02 | Option Data Storage | H-75 | Warning Reference High |
| K-6# | Password Protection | E-95 | Pulse Out #29 Bus Control | H-03 | Restore Factory Settings | H-76 | Warning Feedback Low |
| K-60 | Main Menu Password | E-96 | Pulse Out #29 Timeout Preset | H-04 | Auto-Reset (Times) | H-77 | Warning Feedback High |
| K-61 | Access to Main Menu w/o Password | E-97 | Pulse Out #X30/6 Bus Control | H-05 | Auto-Reset (Reset Interval) | H-78 | Missing Motor Phase Function |
| K-65 | Quick Menu Password | E-98 | Pulse Out #X30/6 Timeout Preset | H-07 | Accel/Decel Time 1 Type | H-8# | Stop Adjustments |
| K-66 | Access to Quick Menu w/o Password | C-# | Frequency Control Functions | H-08 | Reverse Lock | H-80 | Function at Stop |
| K-67 | Bus Password Access | C-0# | Frequency Control Functions | H-09 | Start Mode | H-81 | Min Speed for Function at Stop [RPM] |
| F-# | Parameter Data Set | C-01 | Jump Frequency From [Hz] | H-2# | Motor Feedback Monitoring | H-82 | Min Speed for Function at Stop [Hz] |
| F-0# | Fundamental 0 | C-02 | Jump Speed From [RPM] | H-20 | Motor Feedback Loss Function | H-83 | Precise Stop Function |
| F-01 | Frequency Setting 1 | C-03 | Jump Speed To [RPM] | H-21 | Motor Feedback Speed Error | H-84 | Precise Stop Counter Value |
| F-02 | Operation Method | C-04 | Jump Frequency To [Hz] | H-22 | Motor Feedback Loss Timeout | H-85 | Precise Stop Speed Compensation |
| F-03 | Max Output Frequency 1 | C-05 | Multi-step Frequency 1 - 8 | H-23 | Motor Check At Start | Delay | |
| F-04 | Base Frequency | C-2# | Jog Setup | H-25 | Tracking Error | H-87 | Load Type |
| F-05 | Motor Rated Voltage | C-20 | Jog Speed [Hz] | H-26 | Tracking Error Timeout | H-88 | Motor Inertia |
| F-07 | Accel Time 1 | C-21 | Jog Speed [RPM] | H-27 | Tracking Error Ramping | H-89 | System Inertia |
| F-08 | Decel Time 1 | C-22 | Jog Accel/Decel Time | H-28 | Tracking Error Ramping Timeout | H-9# | Motor Temperature |
| F-09 | Torque Boost | C-24 | Quick Stop Ramp Type | H-29 | Tracking Error After Ramping Timeout | H-94 | ATEX overload cur.lim. speed reduction |
| F-1# | Fundamental 1 | C-25 | Quick Stop S-ramp Ratio at Decel. Start | H-3# | Speed Monitor | H-95 | KTY Sensor Type |
| F-10 | Electronic Overload | C-26 | Quick Stop S-ramp Ratio at Decel. End | H-30 | Motor Speed Monitor Function | H-96 | KTY Threshold level |
| F-11 | Motor External Fan | C-29 | Ramp Lowpass Filter Time | H-31 | Motor Speed Monitor Max | H-97 | ATEX overload interpol. points freq. |
| | | C-3# | Frequency Setting 2 and 3 | H-32 | Motor Speed Monitor Timeout | H-98 | ATEX overload interpol. points current |
| | | C-30 | Frequency Command 2 | H-4# | Advanced Settings | | |



| | | | | |
|--|---|--|--|---------------------------------------|
| AN-0# Analog In / Out | SP-2# Reset Functions | SP-96 Accel Time 4 S-ramp Ratio at Accel. End | DN-02 MAC ID | PB-93 Changed Parameters (4) |
| AN-0# Analog I/O Mode | SP-23 Typecode Setting | SP-97 Decel Time 4 S-ramp Ratio at Decel. Start | DN-05 Readout Transmit Error Counter | PB-94 Changed Parameters (5) |
| AN-01 Live Zero Timeout Time | SP-24 Trip Delay at Current Limit | SP-98 Decel Time 4 S-ramp Ratio at Decel. End | DN-06 Readout Receive Error Counter | PB-99 Profibus Revision Counter |
| AN-01 Live Zero Timeout Function | SP-25 Trip Delay at Torque Limit | O-0# Options / Comms | DN-07 Readout Bus Off Counter | EN-0# IP Settings |
| AN-1# Analog Input 53 | SP-26 Trip Delay at Drive Fault | O-0# General Settings | DN-1# DeviceNet | EN-00 IP Address Assignment |
| AN-10 Terminal 53 Low Voltage | SP-29 Service Code | O-01 Control Site | DN-10 Process Data Type Selection | EN-01 IP Address |
| AN-11 Terminal 53 High Voltage | SP-3# Current Limit Ctrl. | O-02 Control Word Source | DN-11 Process Data Config Write | EN-02 Subnet Mask |
| AN-12 Terminal 53 Low Current | SP-30 Current Lim Contr. Proportional Gain | O-03 Control Word Timeout Time | DN-12 Process Data Config Read | EN-03 Default Gateway |
| AN-13 Terminal 53 High Current | SP-31 Current Lim Contr. Integration Time | O-04 Control Word Timeout Function | DN-13 Warning Parameter | EN-04 DHCP Server |
| AN-14 Terminal 53 Low Ref./Feedb. Value | SP-32 Current Lim Ctrl. Filter Time | O-05 Reset-Control Word Timeout | DN-14 Net Control | EN-05 Lease Expires |
| AN-15 Terminal 53 High Ref./Feedb. Value | SP-33 Stall Protection | O-06 Diagnosis Trigger | DN-18 internal_process_data_config_write | EN-06 Name Servers |
| AN-16 Terminal 53 Filter Time Constant | SP-36 Fieldweakening Function | O-07 Readout Filtering | DN-19 internal_process_data_config_read | EN-07 Domain Name |
| AN-17 Terminal 53 Live Zero | SP-37 Fieldweakening Speed | O-08 Control Word Profile | DN-2# COS Filters | EN-08 Host Name |
| AN-2# Analog Input 54 | SP-4# Energy Savings | O-09 Configurable Status Word STW | DN-20 COS Filter 1 | EN-09 Physical Address |
| AN-20 Terminal 54 Low Voltage | SP-40 VT Level | O-10 Configurable Control Word CTW | DN-21 COS Filter 2 | EN-1# Ethernet Link Parameters |
| AN-21 Terminal 54 High Voltage | SP-41 Energy Savings Min. Magnetisation | O-11 Store Data Values | DN-22 COS Filter 3 | EN-10 Link Status |
| AN-22 Terminal 54 Low Voltage | SP-42 Energy Savings Min. Frequency | O-12 Configurable Alarm and Warningword Product Code | DN-23 COS Filter 4 | EN-11 Link Duration |
| AN-23 Terminal 54 High Current | SP-43 Motor Cosphi | O-3# Drive Port Settings | DN-3# Parameter Access | EN-12 Auto Negotiation |
| AN-24 Terminal 54 Low Ref./Feedb. Value | SP-5# Environment | O-30 Protocol | DN-31 Store Data Values | EN-13 Link Speed |
| AN-25 Terminal 54 High Ref./Feedb. Value | SP-50 RFI Filter | O-31 Address | DN-32 DeviceNet Revision | EN-14 Link Duplex |
| AN-26 Terminal 54 Filter Time Constant | SP-51 DC Link Compensation | O-32 Drive Port Baud Rate | DN-33 Store Always | EN-2# Process Data |
| AN-27 Terminal 54 Live Zero | SP-52 Fan Operation | O-33 Drive Port Parity | DN-34 DeviceNet Product Code | EN-20 Control Instance |
| AN-3# Analog Input X30/11 | SP-53 Fan Monitor | O-34 Estimated cycle time | DN-39 DeviceNet F Parameters | EN-21 Process Data Config Write |
| AN-30 Terminal X30/11 Low Voltage | SP-54 AHF Cap Reconnect Delay | O-35 Minimum Response Delay | DN-5# DeviceNet Process Data | EN-22 Process Data Config Read |
| AN-31 Terminal X30/11 High Voltage | SP-55 Output Filter | O-36 Max Response Delay | PB-# PROFIdrive | EN-23 Process Data Config Write Size |
| AN-34 Term. X30/11 Low Ref./Feedb. Value | SP-56 Capacitance Output Filter | O-37 Max Inter-Char Delay | PB-00 Setpoint | EN-24 Process Data Config Read Size |
| AN-35 Term. X30/11 High Ref./Feedb. Value | SP-57 Inductance Output Filter | O-4# Drive MC Port Settings | PB-07 Actual Value | EN-27 Primary Master |
| AN-36 Term. X30/11 Filter Time Constant | SP-59 Actual Number of Inverter Units | O-40 Telegram Selection | PB-15 PCD Write Configuration | EN-28 Store Data Values |
| AN-37 Term. X30/11 Live Zero | SP-6# Automatic Derate | O-41 Parameters for Signals | PB-18 PCD Read Configuration | EN-29 Store Always |
| AN-4# Analog Input X30/12 | SP-7# Additional ACC/DEC settings | O-42 PCD Write Configuration | PB-22 Telegram Selection | EN-3# EtherNet/IP |
| AN-40 Terminal X30/12 Low Voltage | SP-71 Accel Time 1 S-ramp Ratio at Accel. Start | O-43 PCD Read Configuration | PB-27 Parameter Edit | EN-30 Warning Parameter |
| AN-41 Terminal X30/12 High Voltage | SP-72 Accel Time 1 S-ramp Ratio at Decel. End | O-5# Digital / Bus | PB-28 Process Control | EN-31 Net Reference |
| AN-44 Term. X30/12 Low Ref./Feedb. Value | SP-73 Decel Time 1 S-ramp Ratio at Decel. Start | O-50 Coasting Select | PB-44 Fault Message Counter | EN-32 Net Control |
| AN-45 Term. X30/12 High Ref./Feedb. Value | SP-74 Decel Time 1 S-ramp Ratio at Decel. End | O-51 Quick Stop Select | PB-45 Fault Code | EN-33 CIP Revision |
| AN-46 Term. X30/12 Filter Time Constant | SP-76 Accel/Decel Time 2 Type | O-52 DC Brake Select | PB-47 Fault Number | EN-34 CIP Product Code |
| AN-47 Term. X30/12 Live Zero | SP-79 Accel Time 2 S-ramp Ratio at Accel. Start | O-53 Start Select | PB-52 Fault Situation Counter | EN-35 ED5 Parameter |
| AN-50 Terminal 42 Output | SP-80 Accel Time 2 S-ramp Ratio at Decel. End | O-54 Reversing Select | PB-63 Actual Baud Rate | EN-37 COS Inhibit Timer |
| AN-51 Terminal 42 Output Min Scale | SP-81 Decel Time 2 S-ramp Ratio at Decel. Start | O-55 Set-up Select | PB-65 Profile Number | EN-38 COS Filter |
| AN-52 Terminal 42 Output Max Scale | SP-82 Decel Time 2 S-ramp Ratio at Decel. End | O-56 Preset Reference Select | EN-4# Modbus TCP | EN-40 Status Parameter |
| AN-53 Terminal 42 Output Bus Control | SP-84 Accel/Decel Ramp 3 Type | O-57 Profidrive OFF2 Select | EN-41 Slave Message Count | EN-42 Slave Exception Message Count |
| AN-54 Terminal 42 Output Timeout Preset | SP-87 Accel Time 3 S-ramp Ratio at Accel. Start | O-58 Profidrive OFF3 Select | EN-8# Other Ethernet Services | EN-80 FTP Server |
| AN-5# Analog Output 42 | SP-88 Accel Time 3 S-ramp Ratio at Decel. End | O-8# Drive Port Diagnostics | EN-81 HTTP Server | EN-82 SMTP Service |
| AN-5# Terminal 42 Output | SP-89 Decel Time 3 S-ramp Ratio at Decel. Start | O-80 Bus Message Count | EN-88 Transparent Socket Channel Port | EN-89 Transparent Socket Channel Port |
| AN-6 Terminal X30/8 Min. Scale | SP-90 Decel Time 3 S-ramp Ratio at Decel. End | O-81 Bus Error Count | EN-9# Advanced Ethernet Services | EN-90 Cable Diagnostic |
| AN-62 Terminal X30/8 Max. Scale | SP-92 Accel/Decel Ramp 4 Type | O-82 Slave Messages Rcvd | EN-91 MDI-X | EN-92 IGMP Snooping |
| AN-63 Terminal X30/8 Bus Control | SP-95 Accel Time 4 S-ramp Ratio at Accel. Start | O-83 Slave Error Count | EN-93 Cable Error Length | EN-94 Broadcast Storm Protection |
| AN-64 Terminal X30/8 Output Timeout Preset | SP-99 Decel Time 4 S-ramp Ratio at Accel. Start | O-9# Bus Jog / Feedback | EN-95 Broadcast Storm Filter | EN-96 Port Mirroring |
| SP-# Special Functions | | O-90 Bus Jog 1 Speed | EN-98 Interface Counters | EN-99 Media Counters |
| SP-0# Fault Settings | | O-91 Bus Jog 2 Speed | | |
| SP-00 Fault Level | | DN-# DeviceNet Fields | | |
| SP-1# Line On/Off | | DN-00 DeviceNet Protocol | | |
| SP-10 Line failure | | DN-01 Baud Rate Select | | |
| SP-11 Line Voltage at Input Fault | | | | |
| SP-12 Function at Line Imbalance | | | | |
| SP-14 Kin. Backup Time Out | | | | |
| SP-15 Kin. Backup Trip Recovery Level | | | | |
| SP-16 Kin. Backup Gain | | | | |



Parameter Menu Structure

| | | | | |
|--|---------------------------------------|------------------------------------|-----------------------------------|---------------------------------|
| EC-# Feedback Option | IO-41 Terminal X49/7 Digital Output | ID-53 Power Card Serial Number | DR-45 Motor Phase U Current | Adv Parameter Data Set |
| EC-1# Inc. Enc. Interface | IO-42 Terminal X49/7 Min. Scale | ID-59 Filename | DR-46 Motor Phase V Current | LC-# Logic Controller |
| EC-10 Signal Type | IO-43 Terminal X49/7 Max. Scale | ID-6# Option Ident | DR-47 Motor Phase W Current | LC-0# LC Settings |
| EC-11 Resolution (PPR) | IO-44 Terminal X49/7 Bus Control | ID-60 Option Mounted | DR-48 Speed Ref. After Ramp [RPM] | LC-00 Logic Controller Mode |
| EC-2# Abs. Enc. Interface | IO-45 Terminal X49/7 Timeout Preset | ID-61 Option SW Version | DR-49 Current Fault Source | LC-01 Start Event |
| EC-20 Protocol Selection | IO-5# Output X49/9 | ID-62 Option Ordering No | DR-5# Ref. & Feedb. | LC-02 Stop Event |
| EC-21 Resolution (Positions/Rev) | IO-50 Terminal X49/9 Analogue Output | ID-63 Option Serial No | DR-50 External Reference | LC-03 Reset Logic Controller |
| EC-24 SSI Data Length | IO-51 Terminal X49/9 Digital Output | ID-70 Option in Slot A | DR-51 Pulse Reference | LC-1# Comparators |
| EC-25 Clock Rate | IO-52 Terminal X49/9 Min. Scale | ID-71 Slot A Option SW Version | DR-52 Feedback[Unit] | LC-10 Comparator Operand |
| EC-26 SSI Data Format | IO-53 Terminal X49/9 Max. Scale | ID-72 Option in Slot B | DR-53 Digi Pot Reference | LC-11 Comparator Operator |
| EC-34 HIPERFACE Boardrate | IO-54 Terminal X49/9 Bus Control | ID-73 Slot B Option SW Version | DR-57 Feedback [RPM] | LC-1# RS Flip Flaps |
| RS-56 Encoder Sim. Resolution | IO-55 Terminal X49/9 Timeout Preset | ID-74 Option in Slot C1 | DR-6# Inputs & Outputs | LC-15 RS-FF Operand S |
| EC-6# Monitoring and App. | IO-6# Output X49/11 | ID-75 Slot C0 Option SW Version | DR-60 Digital Input | LC-16 RS-FF Operand R |
| EC-60 Feedback Direction | IO-60 Terminal X49/11 Analogue Output | ID-76 Option in Slot C2 | DR-61 Terminal 53 Switch Setting | LC-2# Timers |
| EC-61 Feedback Signal Monitoring | IO-61 Terminal X49/11 Digital Output | ID-77 Slot C1 Option SW Version | DR-62 Analog Input 53 | LC-20 Logic Controller Timer |
| RS-# Resolver Interface | IO-62 Terminal X49/11 Min. Scale | ID-8# Operating Data II | DR-63 Terminal 54 Switch Setting | LC-4# Logic Rules |
| RS-50 Poles | IO-63 Terminal X49/11 Max. Scale | ID-80 Fan Running Hours | DR-64 Analog Input 54 | LC-40 Logic Rule Boolean 1 |
| RS-51 Input Voltage | IO-64 Terminal X49/11 Bus Control | ID-81 Preset Fan Running Hours | DR-65 Analog Output 42 [mA] | LC-41 Logic Rule Operator 1 |
| RS-53 Transformation Ratio | IO-65 Terminal X49/11 Timeout Preset | ID-9# Parameter Info | DR-66 Digital Output [bin] | LC-42 Logic Rule Boolean 2 |
| RS-56 Encoder Sim. Resolution | Parameter Data Check | ID-92 Defined Parameters | DR-67 Freq. Input #29 [Hz] | LC-43 Logic Rule Operator 2 |
| IO-# Programmable I/O Option | Last 10 Changes | ID-93 Modified Parameters | DR-68 Freq. Input #33 [Hz] | LC-44 Logic Rule Boolean 3 |
| IO-0# I/O Mode | Since Factory Setting | ID-98 Drive Identification | DR-69 Pulse Output #27 [Hz] | LC-5# States |
| IO-00 Terminal X49/1 Mode | Drive Information | ID-99 Parameter Metadata | DR-70 Pulse Output #29 [Hz] | LC-51 Logic Controller Event |
| IO-01 Terminal X49/3 Mode | Operating Data | Data Readouts | DR-71 Relay Output [bin] | LC-52 Logic Controller Action |
| IO-02 Terminal X49/5 Mode | ID-00 Operating hours | DR-0# General Status | B-# Braking Functions | B-0# DC-Brake |
| IO-03 Terminal X49/7 Mode | ID-01 Running Hours | DR-00 Control Word | B-00 DC Hold Current | B-00 DC Brake Current |
| IO-04 Terminal X49/7 Mode | ID-02 kWh Counter | DR-01 Reference [Unit] | B-01 DC Brake Current | B-02 DC Braking Time |
| IO-05 Terminal X49/11 Mode | ID-03 Power Up's | DR-02 Reference % | B-03 DC Brake Cut In Speed [RPM] | B-03 DC Brake Cut In Speed [Hz] |
| IO-1# Analog Input X49/1 | ID-04 Over Temp's | DR-03 Status Word | B-04 DC Brake Cut In Speed [RPM] | B-04 DC Brake Cut In Speed [Hz] |
| IO-10 Terminal X49/1 Low Voltage | ID-05 Over Volt's | DR-05 Main Actual Value [%] | B-05 Maximum Reference | B-06 Parking Current |
| IO-11 Terminal X49/1 Low Current | ID-06 Reset kWh Counter | DR-09 Custom Readout | B-07 Parking Time | B-1# Brake Energy Funct. |
| IO-12 Terminal X49/1 High Voltage | ID-07 Reset Running Hours Counter | DR-1# Motor Status | B-10 Brake Function | B-11 Brake Resistor (ohm) |
| IO-13 Terminal X49/1 High Current | ID-1# Data Trending Settings | DR-10 Power [kW] | B-12 Brake Power Limit (kW) | B-13 Braking Thermal Overload |
| IO-14 Term. X49/1 Low Ref./Feedb. Value | ID-10 Trending Source | DR-11 Power [hp] | B-15 Brake Check | B-16 AC brake Max. Current |
| IO-15 Term. X49/1 High Ref./Feedb. Value | ID-11 Trending Interval | DR-12 Motor Voltage | B-17 Over-voltage Control | B-18 Brake Check Condition |
| IO-16 Term. X49/1 Filter Time Constant | ID-12 Trigger Event | DR-13 Frequency | B-19 Over-voltage Gain | B-2# Mechanical Brake |
| IO-17 Term. X49/1 Live Zero | ID-13 Trending Mode | DR-14 Motor current | B-20 Release Brake Current | B-21 Activate Brake Speed [RPM] |
| IO-2# Analog Input X49/3 | ID-14 Samples Before Trigger | DR-15 Frequency [%] | B-22 Activate Brake Speed [Hz] | B-23 Activate Brake Delay |
| IO-20 Terminal X49/3 Low Voltage | ID-2# Historic Log | DR-16 Torque [Nm] | B-24 Stop Delay | B-25 Brake Release Time |
| IO-21 Terminal X49/3 Low Current | ID-20 Historic Log: Event | DR-18 Motor Thermal | B-26 Torque Ref | B-27 Torque Ramp Time |
| IO-22 Terminal X49/3 High Voltage | ID-21 Historic Log: Value | DR-19 KTY sensor temperature | B-28 Gain Boost Factor | PI-# PID Controls |
| IO-23 Terminal X49/3 High Current | ID-3# Alarm Log | DR-20 Motor Angle | PI-0# Speed PID Control | PI-00 Speed PID Feedback Source |
| IO-24 Term. X49/3 Low Ref./Feedb. Value | ID-30 Fault Log: Error Code | DR-21 Torque [%] High Res. | PI-01 Speed PID Droop | |
| IO-25 Term. X49/3 High Ref./Feedb. Value | ID-31 Fault Log: Value | DR-22 Torque [%] | | |
| IO-26 Term. X49/3 Filter Time Constant | ID-32 Fault Log: Time | DR-23 Motor Shaft Power [kW] | | |
| | ID-4# Drive Identification | DR-24 Calibrated Stator Resistance | | |
| | ID-40 Drive Type | DR-25 Torque [Nm] High | | |
| | ID-41 Power Section | DR-3# Drive Status | | |
| | ID-42 Voltage | DR-30 DC Link Voltage | | |
| | ID-43 Software Version | DR-32 Brake Energy /s | | |
| | ID-44 Ordered Typecode String | DR-33 Brake Energy Average | | |
| | ID-45 Actual Typecode String | DR-34 Heatsink Temp. | | |
| | ID-46 GE Product No. | DR-35 Drive Thermal | | |
| | ID-47 Power Card Ordering No | DR-36 Drive Nominal Current | | |
| | ID-48 Keypad ID Number | DR-37 Drive Max. Current | | |
| | ID-49 SW ID Control Card | DR-38 Logic Controller State | | |
| | ID-50 SW ID Power Card | DR-39 Control Card Temp. | | |
| | ID-51 Drive Serial Number | DR-40 Trending Buffer Full | | |



| | | | |
|-------|---|-------|--|
| PI-02 | Speed PID Proportional Gain | SF-06 | Wobble Jump Time |
| PI-03 | Speed PID Integral Time | SF-07 | Wobble Sequence Time |
| PI-04 | Speed PID Differentiation Time | SF-08 | Wobble Up/ Down Time |
| PI-05 | Speed PID Diff. Gain Limit | SF-09 | Wobble Random Function |
| PI-06 | Speed PID Lowpass Filter Time | SF-10 | Wobble Ratio |
| PI-07 | Speed PID Feedback Gear Ratio | SF-11 | Wobble Random Ratio Max. |
| PI-08 | Speed PID Feed Forward Factor | SF-12 | Wobble Random Ratio Min. |
| PI-09 | Speed PID Error Correction w/ Ramp | SF-19 | Wobble Delta Freq. Scaled |
| PI-1# | Torque PI Ctrl. | SF-2# | Adv. Start Adjust |
| PI-10 | Torque PI Feedback Source | SF-20 | High Starting Torque Time [s] |
| PI-12 | Torque PI Proportional Gain | SF-21 | High Starting Torque Current [%] |
| PI-13 | Torque PI Integration Time | SF-22 | Locked Rotor Protection |
| PI-16 | Torque PI Lowpass Filter Time | SF-23 | Locked Rotor Detection Time [s] |
| PI-18 | Torque PI Feed Forward Factor | SF-24 | Locked Rotor Detection Speed Error [%] |
| PI-19 | Current Controller Rise Time | SF-25 | Light Load Delay [s] |
| PI-2# | Process PID Feedback | SF-26 | Light Load Current [%] |
| PI-20 | Process CL Feedback 1 Resource | SF-27 | Light Load Speed [%] |
| PI-22 | Process CL Feedback 2 Resource | SF-3# | Miscellaneous |
| PI-3# | Process PID Control | SF-30 | External Interlock Delay |
| PI-30 | Process PID Normal/ Inverse Control | SF-84 | Process PID Proportional Gain |
| PI-31 | Process PID Anti Windup | | |
| PI-32 | Process PID Start Speed | | |
| PI-33 | Process PID Proportional Gain | | |
| PI-34 | Process PID Integral Time | | |
| PI-35 | Process PID Differentiation Time | | |
| PI-36 | Process PID Diff. Gain Limit | | |
| PI-38 | Process PID Feed Forward Factor | | |
| PI-39 | On Reference Bandwidth | | |
| PI-4# | Adv. Process PID I | | |
| PI-40 | Process PID I-part Reset | | |
| PI-41 | Process PID Output Neg. Clamp | | |
| PI-42 | Process PID Output Pos. Clamp | | |
| PI-43 | Process PID Gain Scale at Min. Ref. | | |
| PI-44 | Process PID Gain Scale at Max. Ref. | | |
| PI-45 | Process PID Feed Fwd Resource | | |
| PI-46 | Process PID Feed Fwd Normal/ Inv. Ctrl. | | |
| PI-48 | PCD Feed Forward | | |
| PI-49 | Process PID Output Normal/ Inv. Ctrl. | | |
| PI-5# | Adv. Process PID II | | |
| PI-50 | Process PID Extended PID | | |
| PI-51 | Process PID Feed Fwd Gain | | |
| PI-52 | Process PID Feed Fwd Ramp up | | |
| PI-53 | Process PID Feed Fwd Ramp down | | |
| PI-56 | Process PID Ref. Filter Time | | |
| PI-57 | Process PID Fb. Filter Time | | |
| PI-6# | PID Readouts | | |
| PI-60 | Process PID Error | | |
| PI-61 | Process PID Output | | |
| PI-62 | Process PID Clamped Output | | |
| PI-63 | Process PID Gain Scaled Output | | |
| SF-## | Special Features | | |
| SF-0# | Wobbler | | |
| SF-00 | Wobble Mode | | |
| SF-01 | Wobble Delta Frequency [Hz] | | |
| SF-02 | Wobble Delta Frequency [%] | | |
| SF-03 | Wobble Delta Freq. Scaling Resource | | |
| SF-04 | Wobble Jump Frequency [Hz] | | |
| SF-05 | Wobble Jump Frequency [%] | | |



6.2 Remote Programming with DCT-10

GE has a software program available for developing, storing, and transferring frequency converter programming. The DCT-10 allows the user to connect a PC to the frequency converter and perform live programming rather than using the keypad. Also, all frequency converter programming can be done off-line and downloaded to the frequency converter. Or the entire frequency converter profile can be loaded onto the PC for back-up storage or analysis.

The USB connector or RS485 terminal is available for connecting to the frequency converter.

For more details, go to www.geelectrical.com/drives

7 Warnings and Alarm

7.1 System Monitoring

The frequency converter monitors the condition of its input power, output, and motor factors, and other system performance indicators. A warning or alarm does not necessarily indicate a problem internally in the frequency converter.

Often, it indicates failure conditions from:

- Input voltage.
- Motor load.
- Motor temperature.
- External signals.
- Other areas monitored by internal logic.

Investigate as indicated in the alarm or warning.

7.2 Warning and Alarm Types

Warnings

A warning is issued when an alarm condition is impending or when an abnormal operating condition is present and may result in the frequency converter issuing an alarm. A warning clears by itself when the abnormal condition is removed.

Alarms

Trip

An alarm is issued when the frequency converter is tripped, that is, the frequency converter suspends operation to prevent frequency converter or system damage. The motor will coast to a stop. The frequency converter logic continues to operate and monitor the frequency converter status. After the fault condition is remedied, the frequency converter can be reset. It is then ready to start operation again.


A trip can be reset in any of 4 ways:

- Press [Reset] on the keypad
- Digital reset input command
- Serial communication reset input command
- Auto reset

Trip lock

An alarm that causes the frequency converter to trip lock requires that input power is cycled. The motor will coast to a stop. The frequency converter logic continues to operate and monitor the frequency converter status. Remove input power to the frequency converter and correct the cause of the fault, then restore power. This action puts the frequency converter into a trip condition as described above and may be reset in any of those 4 ways.


7.3 Warning and Alarm Displays



130BP085.11

Illustration 7.1 Warning Display


An alarm or trip lock alarm flashes in the display along with the alarm number.



130BP086.11

Illustration 7.2 Alarm Display

In addition to the text and alarm code in the keypad, there are 3 status indicator lights.



130BP467.10

Illustration 7.3 Status Indicator Lights



Warnings and Alarm

| | Warning LED | Alarm LED |
|-----------|-------------|---------------|
| Warning | On | Off |
| Alarm | Off | On (Flashing) |
| Trip lock | On | On (Flashing) |

Table 7.1 Status Indicator Lights Explanations

7.4 Warning and Alarm Definitions

Table 7.2 defines whether a warning is issued before an alarm, and whether the alarm trips the unit or trip locks the unit.

| No. | Description | Warning | Alarm/Trip | Alarm/Trip Lock | Parameter Reference |
|-----|--------------------------------------|---------|------------|-----------------|--|
| 1 | 10 Volts low | X | | | |
| 2 | Live zero error | (X) | (X) | | Parameter AN-01 Live Zero Timeout Function |
| 3 | No motor | (X) | | | Parameter H-80 Function at Stop |
| 4 | Mains phase loss | (X) | (X) | (X) | Parameter SP-12 Function at Line Imbalance |
| 5 | DC link voltage high | X | | | |
| 6 | DC link voltage low | X | | | |
| 7 | DC over-voltage | X | X | | |
| 8 | DC under voltage | X | X | | |
| 9 | Inverter overloaded | X | X | | |
| 10 | Motor Electronic OL over temperature | (X) | (X) | | Parameter F-10 Electronic Overload |
| 11 | Motor thermistor over temperature | (X) | (X) | | Parameter F-10 Electronic Overload |
| 12 | Torque limit | X | X | | Parameter F-40 Torque Limiter (Driving) Parameter F-41 Torque Limiter (Braking) |
| 13 | Over Current | X | X | X | |
| 14 | Earth Fault | X | X | X | |
| 15 | Hardware mismatch | | X | X | |
| 16 | Short Circuit | | X | X | |
| 17 | Control word time-out | (X) | (X) | | Parameter O-04 Control Word Timeout Function |
| 20 | Temp. Input Error | | | | |
| 21 | Param Error | | | | |
| 22 | Hoist Mech. Brake | (X) | (X) | | Parameter group B-2# |
| 23 | Internal Fans | X | | | |
| 24 | External Fans | X | | | |
| 25 | Brake resistor short-circuited | X | | | |
| 26 | Brake resistor power limit | (X) | (X) | | Parameter B-13 Braking Thermal Overload |
| 27 | Brake chopper short-circuited | X | X | | |
| 28 | Brake check | (X) | (X) | | Parameter B-15 Brake Check |
| 29 | Heatsink temp | X | X | X | |
| 30 | Motor phase U missing | (X) | (X) | (X) | Parameter H-78 Missing Motor Phase Function |
| 31 | Motor phase V missing | (X) | (X) | (X) | Parameter H-78 Missing Motor Phase Function |
| 32 | Motor phase W missing | (X) | (X) | (X) | Parameter H-78 Missing Motor Phase Function |
| 33 | Inrush Fault | | X | X | |
| 34 | Network communication fault | X | X | | |
| 35 | Option Fault | | | | |
| 36 | Mains failure | X | X | | |



Warnings and Alarm

AF-650 GP™ Quick Guide

| No. | Description | Warning | Alarm/Trip | Alarm/Trip Lock | Parameter Reference |
|-----|---|---------|-------------------|-----------------|--|
| 37 | Phase imbalance | | X | | |
| 38 | Internal Fault | | X | X | |
| 39 | Heatsink sensor | | X | X | |
| 40 | Overload of Digital Output Terminal 27 | (X) | | | Parameter E-00 Digital I/O Mode, parameter E-51 Terminal 27 Mode |
| 41 | Overload of Digital Output Terminal 29 | (X) | | | Parameter E-00 Digital I/O Mode, parameter E-52 Terminal 29 Mode |
| 42 | Ovrid X30/6-7 | (X) | | | |
| 43 | Ext. Supply (option) | | | | |
| 45 | Earth Fault 2 | X | X | X | |
| 46 | Pwr. card supply | | X | X | |
| 47 | 24 V supply low | X | X | X | |
| 48 | 1.8 V supply low | | X | X | |
| 49 | Speed limit | X | | | |
| 50 | Auto Tune calibration failed | | X | | |
| 51 | Auto Tune check U_{nom} and I_{nom} | | X | | |
| 52 | Auto Tune low I_{nom} | | X | | |
| 53 | Auto Tune motor too big | | X | | |
| 54 | Auto Tune motor too small | | X | | |
| 55 | Auto Tune parameter out of range | | X | | |
| 56 | Auto Tune interrupted by user | | X | | |
| 57 | Auto Tune time-out | | X | | |
| 58 | Auto Tune internal fault | X | X | | |
| 59 | Current limit | X | | | Parameter F-43 Current Limit |
| 61 | Feedback Error | (X) | (X) | | Parameter H-20 Motor Feedback Loss Function |
| 62 | Output Frequency at Maximum Limit | X | | | |
| 63 | Mechanical Brake Low | | (X) | | Parameter B-20 Release Brake Current |
| 64 | Voltage Limit | X | | | |
| 65 | Control Board Over-temperature | X | X | X | |
| 66 | Heat sink Temperature Low | X | | | |
| 67 | Option Module Configuration has Changed | | X | | |
| 68 | Safe Stop | (X) | (X) ¹⁾ | | Parameter E-07 Terminal 37 Safe Stop |
| 69 | Pwr. Card Temp | | X | X | |
| 70 | Illegal Drive configuration | | | X | |
| 76 | Power Unit Setup | X | | | |
| 77 | Reduced power mode | X | | | Parameter SP-59 Actual Number of Inverter Units |
| 78 | Tracking Error | (X) | (X) | | Parameter H-24 Tracking Error Function |
| 79 | Illegal PS config | | X | X | |
| 80 | Drive Restored to Factory Settings | | X | | |
| 83 | Illegal Option Combination | | | X | |
| 90 | Feedback Monitor | (X) | (X) | | Parameter EC-61 Feedback Signal Monitoring |
| 91 | Analog input 54 wrong settings | | | X | S202 |
| 243 | Brake IGBT | X | X | X | |
| 244 | Heatsink temp | X | X | X | |
| 245 | Heatsink sensor | | X | X | |
| 246 | Pwr.card supply | | | X | |
| 247 | Pwr.card temp | | X | X | |
| 248 | Illegal PS config | | | X | |
| 249 | Rect. low temp. | X | | | |



Warnings and Alarm

| No. | Description | Warning | Alarm/Trip | Alarm/Trip Lock | Parameter Reference |
|-----|-----------------|---------|------------|-----------------|---------------------|
| 250 | New spare parts | | | X | |
| 251 | New Type Code | | X | X | |

Table 7.2 Alarm/Warning Code List

(X) Dependent on parameter

1) Cannot be auto reset via parameter H-04 Auto-Reset (Times)



8 Specifications

8.1 General Technical Data

Mains supply

| | |
|----------------------------|----------------|
| Supply terminals (6-pulse) | L1, L2, L3 |
| Supply voltage | 200–240 V ±10% |
| Supply voltage | 380–500 V ±10% |
| Supply voltage | 525–690 V ±10% |

Mains voltage low/mains drop-out:

During low mains voltage or a mains drop-out, the drive continues until the DC-link voltage drops below the minimum stop level, which corresponds typically to 15% below the frequency converter's lowest rated supply voltage. Power-up and full torque cannot be expected at mains voltage lower than 10% below the frequency converter's lowest rated supply voltage.

| | |
|---|---|
| Supply frequency | 50/60 Hz ±5% |
| Max. imbalance temporary between mains phases | 3.0% of rated supply voltage |
| True Power Factor (λ) | ≥ 0.9 nominal at rated load |
| Displacement Power Factor ($\cos \phi$) | near unity (> 0.98) |
| Switching on input supply L1, L2, L3 (power-ups) ≤ 7.5 kW/10 hp | maximum 2 times/minute |
| Switching on input supply L1, L2, L3 (power-ups) 11–75 kW (15–100 hp) | maximum 1 time/minute |
| Switching on input supply L1, L2, L3 (power-ups) ≥ 90 kW/125 hp | maximum 1 time/2 minute |
| Environment according to EN60664-1 | overvoltage category III/pollution degree 2 |

The unit is suitable for use on a circuit capable of delivering not more than 100kAIC RMS symmetrical Amperes, 240/500/600/690 V maximum.

Motor output (U, V, W)

| | |
|-------------------------------|--------------------------|
| Output voltage | 0–100% of supply voltage |
| Output frequency | 0–590 Hz |
| Output frequency in Flux Mode | 0–300 Hz |
| Switching on output | Unlimited |
| Ramp times | 0.01–3600 s |

1) Voltage and power dependent

Torque characteristics

| | |
|--|--|
| Starting torque (constant torque) | maximum 150% for 60 s ¹⁾ once in 10 minutes |
| Starting/overload torque (variable torque) | maximum 110% for 60 s ¹⁾ once in 10 minutes |
| Torque rise time in Flux Vector Vector Control (for 5 kHz fsw) | 1 ms |
| Torque rise time in Advanced Vector Control (independent of fsw) | 10 ms |

1) Percentage relates to the nominal torque.

2) The torque response time depends on application and load but as a rule, the torque step from 0 to reference is 4–5 x torque rise time.

Digital inputs

| | |
|--|--|
| Programmable digital inputs | 4 (6) ¹⁾ |
| Terminal number | 18, 19, 27 ¹⁾ , 29 ¹⁾ , 32, 33 |
| Logic | PNP or NPN |
| Voltage level | 0–24 V DC |
| Voltage level, logic 0 PNP | <5 V DC |
| Voltage level, logic 1 PNP | >10 V DC |
| Voltage level, logic 0 NPN ²⁾ | >19 V DC |
| Voltage level, logic 1 NPN ²⁾ | <14 V DC |
| Maximum voltage on input | 28 V DC |
| Pulse frequency range | 0–110 kHz |
| (Duty cycle) minimum pulse width | 4.5 ms |
| Input resistance, R _i | approximately 4 kΩ |



Specifications

STO terminal 37²⁾ (terminal 37 is fixed PNP logic)

| | |
|-------------------------------|-----------|
| Voltage level | 0–24 V DC |
| Voltage level, logic 0 PNP | <4 V DC |
| Voltage level, logic 1 PNP | >20 V DC |
| Maximum voltage on input | 28 V DC |
| Typical input current at 24 V | 50 mA rms |
| Typical input current at 20 V | 60 mA rms |
| Input capacitance | 400 nF |

All digital inputs are galvanically isolated from the supply voltage (PELV) and other high voltage terminals.

- 1) Terminals 27 and 29 can also be programmed as output.
- 2) See for further information about terminal 37 and STO.

Analog inputs

| | |
|------------------------------|-----------------------------------|
| Number of analog inputs | 2 |
| Terminal number | 53, 54 |
| Modes | Voltage or current |
| Mode select | Switch S201 and switch S202 |
| Voltage mode | Switch S201/switch S202 = OFF (U) |
| Voltage level | -10 V to +10 V (scaleable) |
| Input resistance, R_i | approximately 10 k Ω |
| Maximum voltage | ± 20 V |
| Current mode | Switch S201/switch S202 = ON (I) |
| Current level | 0/4 to 20 mA (scaleable) |
| Input resistance, R_i | approximately 200 Ω |
| Maximum current | 30 mA |
| Resolution for analog inputs | 10 bit (+ sign) |
| Accuracy of analog inputs | Maximum error 0.5% of full scale |
| Bandwidth | 100 Hz |

The analog inputs are galvanically isolated from the supply voltage (PELV) and other high voltage terminals.




Illustration 8.1 PELV Isolation



Specifications **AF-650 GP™ Quick Guide**

Pulse/encoder inputs

| | |
|--|--|
| Programmable pulse/encoder inputs | 2/1 |
| Terminal number pulse/encoder | 29, 33 ¹⁾ /32 ²⁾ , 33 ²⁾ |
| Maximum frequency at terminal 29, 32, 33 | 110 kHz (push-pull driven) |
| Maximum frequency at terminal 29, 32, 33 | 5 kHz (open collector) |
| Minimum frequency at terminal 29, 32, 33 | 4 Hz |
| Voltage level | See section 5-1* <i>Digital Inputs</i> in the <i>programming guide</i> . |
| Maximum voltage on input | 28 V DC |
| Input resistance, R _i | Approximately 4 kΩ |
| Pulse input accuracy (0.1–1 kHz) | Maximum error: 0.1% of full scale |
| Encoder input accuracy (1–11 kHz) | Maximum error: 0.05% of full scale |

The pulse and encoder inputs (terminals 29, 32, 33) are galvanically isolated from the supply voltage (PELV) and other high voltage terminals.

1) Pulse inputs are 29 and 33.

2) Encoder inputs: 32=A, 33=B.

Digital output

| | |
|--|-----------------------------------|
| Programmable digital/pulse outputs | 2 |
| Terminal number | 27, 29 ¹⁾ |
| Voltage level at digital/frequency output | 0–24 V |
| Maximum output current (sink or source) | 40 mA |
| Maximum load at frequency output | 1 kΩ |
| Maximum capacitive load at frequency output | 10 nF |
| Minimum output frequency at frequency output | 0 Hz |
| Maximum output frequency at frequency output | 32 kHz |
| Accuracy of frequency output | Maximum error: 0.1% of full scale |
| Resolution of frequency outputs | 12 bit |

1) Terminal 27 and 29 can also be programmed as input.

The digital output is galvanically isolated from the supply voltage (PELV) and other high voltage terminals.

Analog output

| | |
|--|-----------------------------------|
| Number of programmable analog outputs | 1 |
| Terminal number | 42 |
| Current range at analog output | 0/4 to 20 mA |
| Maximum load GND - analog output less than | 500 Ω |
| Accuracy on analog output | Maximum error: 0.5% of full scale |
| Resolution on analog output | 12 bit |

The analog output is galvanically isolated from the supply voltage (PELV) and other high voltage terminals.

Control card, 24 V DC output

| | |
|-----------------|---------------|
| Terminal number | 12, 13 |
| Output voltage | 24 V +1, -3 V |
| Maximum load | 200 mA |

The 24 V DC supply is galvanically isolated from the supply voltage (PELV), but has the same potential as the analog and digital inputs and outputs.

Control card, 10 V DC output

| | |
|-----------------|---------------|
| Terminal number | ±50 |
| Output voltage | 10.5 V ±0.5 V |
| Maximum load | 15 mA |

The 10 V DC supply is galvanically isolated from the supply voltage (PELV) and other high voltage terminals.



Specifications

Control card, RS485 serial communication

| | |
|--------------------|------------------------------------|
| Terminal number | 68 (P, TX+, RX+), 69 (N, TX-, RX-) |
| Terminal number 61 | Common for terminals 68 and 69 |

The RS485 serial communication circuit is functionally separated from other central circuits and galvanically isolated from the supply voltage (PELV).

Control card, USB serial communication

| | |
|--------------|------------------|
| USB standard | 1.1 (Full speed) |
| USB plug | USB type B plug |

Connection to PC is carried out via a standard host/device USB cable.

The USB connection is galvanically isolated from the supply voltage (PELV) and other high voltage terminals.

The USB ground connection is not galvanically isolated from protective earth. Use only an isolated laptop as PC connection to the USB connector on the frequency converter.

Relay outputs

| | |
|---|---|
| Programmable relay outputs | 2 Form C |
| Relay 01 terminal number | 1-3 (break), 1-2 (make) |
| Maximum terminal load (AC-1) ¹⁾ on 1-3 (NC), 1-2 (NO) (resistive load) | 240 V AC, 2 A |
| Maximum terminal load (AC-15) ¹⁾ (inductive load @ cosφ 0.4) | 240 V AC, 0.2 A |
| Maximum terminal load (DC-1) ¹⁾ on 1-2 (NO), 1-3 (NC) (resistive load) | 60 V DC, 1 A |
| Maximum terminal load (DC-13) ¹⁾ (inductive load) | 24 V DC, 0.1 A |
| Relay 02 terminal number | 4-6 (break), 4-5 (make) |
| Maximum terminal load (AC-1) ¹⁾ on 4-5 (NO) (resistive load) ²⁾³⁾ overvoltage cat. II | 400 V AC, 2 A |
| Maximum terminal load (AC-15) ¹⁾ on 4-5 (NO) (inductive load @ cosφ 0.4) | 240 V AC, 0.2 A |
| Maximum terminal load (DC-1) ¹⁾ on 4-5 (NO) (resistive load) | 80 V DC, 2 A |
| Maximum terminal load (DC-13) ¹⁾ on 4-5 (NO) (inductive load) | 24 V DC, 0.1 A |
| Maximum terminal load (AC-1) ¹⁾ on 4-6 (NC) (resistive load) | 240 V AC, 2 A |
| Maximum terminal load (AC-15) ¹⁾ on 4-6 (NC) (inductive load @ cosφ 0.4) | 240 V AC, 0.2 A |
| Maximum terminal load (DC-1) ¹⁾ on 4-6 (NC) (resistive load) | 50 V DC, 2 A |
| Maximum terminal load (DC-13) ¹⁾ on 4-6 (NC) (inductive load) | 24 V DC, 0.1 A |
| Minimum terminal load on 1-3 (NC), 1-2 (NO), 4-6 (NC), 4-5 (NO) | 24 V DC 10 mA, 24 V AC 20 mA |
| Environment according to EN 60664-1 | Overvoltage category III/pollution degree 2 |

1) IEC 60947 part 4 and 5

The relay contacts are galvanically isolated from the rest of the circuit by reinforced isolation (PELV).

2) Overvoltage Category II.

3) UL applications 300 V AC2A.

Cable lengths and cross-sections for control cables

| | |
|---|------------------------------|
| Maximum motor cable length, shielded | 150 m |
| Maximum motor cable length, unshielded | 300 m |
| Maximum cross-section to control terminals, flexible/rigid wire without cable end sleeves | 2.5 mm ² /14 AWG |
| Maximum cross-section to control terminals, with ferrules without plastic sleeves | 2.5 mm ² /14 AWG |
| Maximum cross-section to control terminals, with ferrules with plastic sleeves | 1 mm ² /18 AWG |
| Minimum cross-section to control terminals | 0.25 mm ² /24 AWG |

Control card performance

| | |
|---------------|------|
| Scan interval | 1 ms |
|---------------|------|



Specifications

AF-650 GP™ Quick Guide

Control characteristics

| | |
|--|-----------------------------------|
| Resolution of output frequency at 0–590 Hz | ±0.003 Hz |
| Repeat accuracy of precise start/stop (terminals 18, 19) | ≤±0.1 ms |
| System response time (terminals 18, 19, 27, 29, 32, 33) | ≤2 ms |
| Speed control range (open loop) | 1:100 of synchronous speed |
| Speed control range (closed loop) | 1:1000 of synchronous speed |
| Speed accuracy (open loop) | 30–4000 RPM: error ±8 RPM |
| Speed accuracy (closed loop), depending on resolution of feedback device | 0–6000 RPM: error ±0.15 RPM |
| Torque control accuracy (speed feedback) | maximum error ±5% of rated torque |

All control characteristics are based on a 4-pole asynchronous motor.

Environment

| | |
|--|--|
| Vibration test | 1.0 g |
| Max. relative humidity | 5–93%(IEC 721-3-3; Class 3K3 (non-condensing) during operation |
| Aggressive environment (IEC 60068-2-43) H ₂ S test | class Kd |
| Ambient temperature | Max. 50 °C (122 °F) |
| 1) Only for ≤3.7 kW (5 hp)(200–240 V), ≤7.5 kW (10 hp) (400–500 V) | |
| 2) As enclosure kit for ≤3.7 kW (5 hp) (200–240 V), ≤7.5 kW (10 hp) (400–500 V) | |
| 3) Derating for high ambient temperature, see special conditions in the Design Guide | |
| Minimum ambient temperature during full-scale operation | 0 °C (32°F) |
| Minimum ambient temperature at reduced performance | -10 °C (14°F) |
| Temperature during storage/transport | -25 to +65/70 °C (-13 to 149/158 °F) |
| Maximum altitude above sea level without derating | 1000 m (3300 ft) |

Derating for high altitude, see special conditions in the design guide

| | |
|-------------------------|--|
| EMC standards, Emission | EN 61800-3, EN 61000-6-3/4, EN 55011 EN 61800-3, EN 61000-6-1/2, |
| EMC standards, Immunity | EN 61000-4-2, EN 61000-4-3, EN 61000-4-4, EN 61000-4-5, EN 61000-4-6 |

See section on special conditions in the AF-650 GP Design & Installation Guide.

Protection and Features

- Electronic motor thermal protection against overload.
- Temperature monitoring of the heat sink ensures that the frequency converter trips if the temperature reaches a predefined level. An overload temperature cannot be reset until the temperature of the heat sink is below the values stated in the tables on the following pages (Guideline - these temperatures may vary for different power sizes, Unit Sizes, enclosure ratings and so on).
- The frequency converter is protected against short circuits on motor terminals U, V, W.
- If a mains phase is missing, the frequency converter trips or issues a warning (depending on the load).
- Monitoring of the DC-link voltage ensures that the frequency converter trips if the DC-link voltage is too low or too high.
- The frequency converter constantly checks for critical levels of internal temperature, load current, high voltage on the DC link, and low motor speeds. As a response to a critical level, the frequency converter can adjust the switching frequency and/or change the switching pattern to ensure the performance of the frequency converter.



9 Installation

It is recommended to use fuses and/or circuit breakers on the supply side as protection if there is component break-down inside the frequency converter (first fault).

NOTICE

Using fuses and/or circuit breakers on the supply side is mandatory to ensure compliance with IEC 60364 for CE or NEC 2009 for UL.

▲WARNING

Protect personnel and property against the consequence of component break-down internally in the frequency converter.

Branch Circuit Protection

To protect the installation against electrical and fire hazard, all branch circuits in an installation, switch gear, machines, and so on, must be protected against short circuit and overcurrent according to national/international regulations.

NOTICE

The recommendations given do not cover branch circuit protection for UL.

Short-circuit protection

GE recommends using the fuses/circuit breakers mentioned below to protect service personnel and property if there is component break-down in the frequency converter.

Overcurrent protection

The frequency converter provides overload protection to limit threats to human life, property damage and to avoid fire hazard due to overheating of the cables in the installation. The frequency converter is equipped with an

internal overcurrent protection (*parameter F-43 Current Limit*) that can be used for upstream overload protection (UL applications excluded). Moreover, fuses or circuit breakers can be used to provide the overcurrent protection in the installation. Overcurrent protection must always be carried out according to national regulations.

▲WARNING

If there is malfunction, not following the recommendation may result in personnel risk and damage to the frequency converter and other equipment.

The following tables list the recommended rated current. Recommended fuses are of the type gG for small to medium power sizes. For larger powers, aR fuses are recommended. Circuit breakers must be used provided they meet the national/international regulations and they limit the energy into the frequency converter to an equal or lower level than the compliant circuit breakers. If fuses/circuit breakers according to recommendations are selected, possible damages on the frequency converter will mainly be limited to damages inside the unit.

9.1.1 CE Compliance

Fuses or circuit breakers are mandatory to comply with IEC 60364. GE recommend using a selection of the following.

The fuses below are suitable for use on a circuit capable of delivering 100000 Arms (symmetrical), 240 V, 500 V, 600 V, or 690 V depending on the frequency converter voltage rating. With the proper fusing, the frequency converter short circuit current rating (SCCR) is 100000 Arms.



Installation AF-650 GP™ Quick Guide

| AF-650 GP 3-phase [hp] | Recommended fuse size | Recommended max fuse | Recommended circuit breaker | Maximum trip level [A] |
|------------------------|-----------------------|----------------------|-----------------------------|------------------------|
| IP20/Open Chassis | | | | |
| 1/3 | gG-16 | gG-25 | PKZM0-25 | 25 |
| 1/2 | | | | |
| 1 | | | | |
| 2 | | | | |
| 3 | | | | |
| 5 | gG-20 | gG-32 | PKZM4-50 | 50 |
| 7.5 | gG-50 | gG-63 | | |
| 10 | gG-80 | gG-125 | NZMB1-A100 | 100 |
| 15 | | | | |
| 20 | | | | |
| 25 | gG-125 | gG-150 | NZMB2-A200 | 150 |
| 30 | aR-160 | aR-160 | | |
| 40 | aR-200 | aR-200 | | |
| 50 | aR-250 | aR-250 | NZMB2-A250 | 250 |

Table 9.1 200–240 V, Unit Sizes 1X, 2X, and 3X



Installation

| AF-650 GP 3-phase [hp] | Recommended fuse size | Recommended maximum fuse | Recommended circuit breaker | Maximum trip level [A] |
|------------------------|-----------------------|--------------------------|-----------------------------|------------------------|
| IP20/Open Chassis | | | | |
| 1/2 | gG-16 | gG-25 | PKZM0-25 | 25 |
| 1 | | | | |
| 2 | | | | |
| 3 | | | | |
| 5 | | | | |
| 7.5 | gG-20 | gG-32 | | |
| 10 | | | | |
| 15 | gG-50 | gG-63 | PKZM4-50 | 50 |
| 20 | | | | |
| 25 | gG-80 | gG-125 | NZMB1-A100 | 100 |
| 30 | | | | |
| 40 | | | | |
| 50 | gG-125 | gG-150 | NZMB2-A200 | 150 |
| 60 | | | | |
| 75 | aR-250 | aR-250 | NZMB2-A250 | 250 |
| 100 | | | | |
| 125 | | | | |
| 150 | aR-900 | aR-900 | - | - |
| 200 | | | | |
| 250 | | | | |
| 300 | | | | |
| 350 | | | | |
| 450 | | | | |
| 500 | | | | |
| 550 | | | | |
| 600 | | | | |
| 650 | | | | |
| 750 | aR-1600 | aR-1600 | | |
| 900 | | | | |
| 1000 | aR-2000 | aR-2000 | | |
| 1200 | | | | |
| | aR-2500 | aR-2500 | | |
| | | | | |

Table 9.2 380–500 V, Unit Sizes 1X, 2X, 3X, 4X, 4hX, 5X, and 6X

9



Installation AF-650 GP™ Quick Guide

| AF-650 GP 3-phase [hp] | Recommended fuse size | Recommended maximum fuse | Recommended circuit breaker | Maximum trip level [A] |
|------------------------|-----------------------|--------------------------|-----------------------------|------------------------|
| IP20/Open Chassis | | | | |
| 1 | gG-10 | gG-25 | PKZM0-25 | 25 |
| 2 | | | | |
| 3 | | | | |
| 5 | | | | |
| 7.5 | gG-16 | gG-32 | PKZM4-50 | 50 |
| 10 | | | | |
| 15 | gG-35 | gG-63 | PKZM4-50 | 50 |
| 20 | | | | |
| 25 | gG-63 | gG-125 | NZMB1-A100 | 100 |
| 30 | | | | |
| 40 | | | | |
| 50 | gG-100 | gG-150 | NZMB2-A200 | 150 |
| 60 | | | | |
| 75 | aR-250 | aR-250 | NZMB2-A250 | 250 |
| 100 | | | | |

Table 9.3 525–600 V, Unit Sizes 1X, 2X, and 3X

| AF-650 GP 3-phase [hp] | Recommended fuse size | Recommended maximum fuse | Recommended circuit breaker | Maximum trip level [A] |
|--|-----------------------|--------------------------|-----------------------------|------------------------|
| IP21/Nema 1 and IP55/Nema 12 and IP66/Nema 4 | | | | |
| 15 | gG-25 | gG-63 | - | - |
| 20 | gG-32 | | | |
| 25 | | | | |
| 30 | gG-40 | | | |
| 40 | gG-63 | gG-80 | | |
| 50 | | gG-100 | | |
| 60 | gG-80 | gG-125 | | |
| 75 | gG-100 | gG-160 | | |
| 100 | gG-125 | | | |
| 125 | aR-250 | aR-250 | | |
| 150 | aR-315 | aR-315 | | |
| 200 | aR-350 | aR-350 | | |
| 250 | | | | |
| 300 | aR-400 | aR-400 | | |
| 350 | aR-500 | aR-500 | | |
| 400 | aR-550 | aR-550 | | |
| 500 | aR-700 | aR-700 | | |
| 550 | | | | |
| 650 | aR-900 | aR-900 | | |
| 750 | | | | |
| 900 | aR-1600 | aR-1600 | | |
| 1000 | | | | |
| 1150 | | | | |
| 1250 | | | | |
| 1350 | | | aR-2000 | aR-2000 |

Table 9.4 525–690 V, Unit Sizes 2X, 3X, 4X, 4hX, 5X, and 6X



Installation

9.1.2 Fuse Specifications

| AF-650 GP 3-phase [kW (hp)] | Recommended fuse size | Recommended maximum fuse |
|-----------------------------|-----------------------|--------------------------|
| 0.25 (1/3) | gG-16 | gG-25 |
| 0.37 (1/2) | | |
| 0.75 (1) | | |
| 1.5 (2) | | |
| 2.2 (3) | | |
| 3.7 (5) | gG-20 | gG-32 |
| 5.5 (7.5) | gG-50 | gG-63 |
| 7.5 (10) | gG-80 | gG-125 |
| 11 (15) | | |
| 15 (20) | | |
| 18.5 (25) | gG-125 | gG-150 |
| 22 (30) | aR-160 | aR-160 |
| 30 (40) | aR-200 | aR-200 |
| 37 (50) | aR-250 | aR-250 |

Table 9.5 200–240 V, IP20/Open Chassis

| AF-650 GP 3-phase [kW (hp)] | Recommended fuse size | Recommended maximum fuse |
|-----------------------------|-----------------------|--------------------------|
| 0.25 (1/3) | gG-20 | gG-32 |
| 0.37 (1/2) | | |
| 0.75 (1) | | |
| 1.5 (2) | | |
| 2.2 (3) | | |
| 3.7 (5) | gG-63 | gG-80 |
| 5.5 (7.5) | | |
| 7.5 (10) | gG-80 | gG-100 |
| 11 (15) | gG-125 | gG-160 |
| 15 (20) | | |
| 18.5 (25) | aR-160 | aR-160 |
| 22 (30) | | |
| 30 (40) | aR-200 | aR-200 |
| 37 (50) | aR-250 | aR-250 |

Table 9.6 200–240 V, IP55/Nema 12 and IP66/Nema 4X



Installation

AF-650 GP™ Quick Guide

| AF-650 GP 3-phase [kW (hp)] | Recommended fuse size | Recommended maximum fuse |
|-----------------------------|-----------------------|--------------------------|
| 0.37 (1/2) | gG-16 | gG-25 |
| 0.75 (1) | | |
| 1.5 (2) | | |
| 2.2 (3) | | |
| 3.7 (5) | | |
| 5.5 (7.5) | gG-20 | gG-32 |
| 7.5 (10) | | |
| 11 (15) | gG-50 | gG-63 |
| 15 (20) | | |
| 18.5 (25) | gG-80 | gG-125 |
| 22 (30) | | |
| 30 (40) | | |
| 37 (50) | | |
| 45 (60) | gG-125 | gG-150 |
| 55 (75) | aR-160 | aR-160 |
| 75 (100) | aR-250 | aR-250 |
| 90 (125) | | |
| 110 (150) | aR-300 | aR-300 |
| 132 (200) | aR-350 | aR-350 |
| 160 (250) | aR-400 | aR-400 |
| 200 (300) | aR-500 | aR-500 |
| 250 (350) | aR-630 | aR-630 |
| 315 (450) | aR-700 | aR-700 |
| 355 (500) | | |
| 400 (550) | | |
| 450 (600) | aR-900 | aR-900 |
| 500 (650) | | |
| 560 (750) | aR-1600 | aR-1600 |
| 630 (900) | | |
| 710 (1000) | aR-2000 | aR-2000 |
| 800 (1200) | | |
| | aR-2500 | aR-2500 |

9

Table 9.7 380–500 V, IP20/Open Chassis



Installation

| AF-650 GP 3-phase [kW (hp)] | Recommended fuse size | Recommended maximum fuse |
|-----------------------------|-----------------------|--------------------------|
| 0.37 (1/2) | gG-20 | gG-32 |
| 0.75 (1) | | |
| 1.5 (2) | | |
| 2.2 (3) | | |
| 3.7 (5) | | |
| 5.5 (7.5) | | |
| 7.5 (10) | | |
| 11 (15) | gG-50 | gG-80 |
| 15 (20) | | |
| 18.5 (25) | gG-80 | gG-100 |
| 22 (30) | | |
| 30 (40) | gG-125 | gG-160 |
| 37 (50) | | |
| 45 (60) | | |
| 55 (75) | aR-250 | aR-250 |
| 75 (100) | | |
| 90 (125) | aR-300 | aR-300 |
| 110 (150) | aR-350 | aR-350 |
| 132 (200) | aR-400 | aR-400 |
| 160 (250) | aR-500 | aR-500 |
| 200 (300) | aR-630 | aR-630 |
| 250 (350) | aR-700 | aR-700 |
| 315 (450) | aR-900 | aR-900 |
| 355 (500) | | |
| 400 (550) | | |
| 450 (600) | aR-1600 | aR-1600 |
| 500 (650) | | |
| 560 (750) | aR-2000 | aR-2000 |
| 630 (900) | | |
| 710 (1000) | aR-2500 | aR-2500 |
| 800 (1200) | | |

Table 9.8 380–500 V, IP55/Nema 12 and IP66/Nema 4X

| AF-650 GP 3-phase [kW (hp)] | Recommended fuse size | Recommended maximum fuse |
|-----------------------------|-----------------------|--------------------------|
| 0.75 (1) | gG-10 | gG-25 |
| 1.5 (2) | | |
| 2.2 (3) | | |
| 3.7 (5) | | |
| 5.5 (7.5) | gG-16 | gG-32 |
| 7.5 (10) | | |
| 11 (15) | gG-35 | gG-63 |
| 15 (20) | | |
| 18.5 (25) | gG-63 | gG-125 |
| 22 (30) | | |
| 30 (40) | | |
| 37 (50) | gG-100 | gG-150 |
| 45 (60) | | |
| 55 (75) | aR-250 | aR-250 |
| 75 (100) | | |

Table 9.9 525–600 V, IP20/Open Chassis



Installation

AF-650 GP™ Quick Guide

| AF-650 GP 3-phase [kW (hp)] | Recommended fuse size | Recommended maximum fuse |
|-----------------------------|-----------------------|--------------------------|
| 0.75 (1) | gG-16 | gG-32 |
| 1.5 (2) | | |
| 2.2 (3) | | |
| 3.7 (5) | | |
| 5.5 (7.5) | | |
| 7.5 (10) | | |
| 11 (15) | gG-35 | gG-80 |
| 15 (20) | | |
| 18.5 (25) | gG-50 | gG-100 |
| 22 (30) | | |
| 30 (40) | gG-125 | gG-160 |
| 37 (50) | | |
| 45 (60) | | |
| 55 (75) | | |
| 75 (100) | aR-250 | aR-250 |

Table 9.10 525–600 V, IP55/Nema 12 and IP66/Nema 4X

| AF-650 GP 3-phase [kW (hp)] | Recommended fuse size | Recommended maximum fuse |
|-----------------------------|-----------------------|--------------------------|
| 11 (15) | gG-25 | gG-63 |
| 15 (20) | gG-32 | |
| 18.5 (25) | | |
| 22 (30) | gG-40 | |
| 30 (40) | gG-63 | gG-80 |
| 37 (50) | | gG-100 |
| 45 (60) | gG-80 | gG-125 |
| 55 (75) | gG-100 | gG-160 |
| 75 (100) | gG-125 | |
| 90 (125) | aR-250 | aR-250 |
| 110 (150) | aR-315 | aR-315 |
| 132 (200) | aR-350 | aR-350 |
| 160 (250) | | |
| 200 (300) | aR-400 | aR-400 |
| 250 (350) | aR-500 | aR-500 |
| 315 (400) | aR-550 | aR-550 |
| 355 (500) | aR-700 | aR-700 |
| 400 (550) | | |
| 500 (650) | aR-900 | aR-900 |
| 560 (750) | | |
| 630 (900) | | |
| 710 (1000) | aR-1600 | aR-1600 |
| 800 (1150) | | |
| 900 (1250) | | |
| 1000 (1350) | | |
| | aR-2000 | aR-2000 |

Table 9.11 525–690 V, IP21/Nema 1 and IP55/Nema 12 and IP66/Nema 4X



Installation

9.1.3 NEC and UL Compliance

Fuses or Circuit Breakers are mandatory to comply with NEC 2009. We recommend using a selection of the following.

The fuses below are suitable for use on a circuit capable of delivering 100000 Arms (symmetrical), 240 V, or 500 V, or 600 V depending on the frequency converter voltage rating. With the proper fusing, the drive Short Circuit Current Rating (SCCR) is 100000 Arms.

| AF-650 GP Power | Recommended maximum fuse | | | | | |
|------------------------|--------------------------|----------|----------|----------|----------|----------|
| | Bussmann | Bussmann | Bussmann | Bussmann | Bussmann | Bussmann |
| [kW (hp)] | Type RK1 ¹⁾ | Type J | Type T | Type CC | Type CC | Type CC |
| 0.25–0.37 (1/3–1/2) | KTN-R-05 | JKS-05 | JJN-05 | FNQ-R-5 | KTK-R-5 | LP-CC-5 |
| 0.75 (1) | KTN-R-10 | JKS-10 | JJN-10 | FNQ-R-10 | KTK-R-10 | LP-CC-10 |
| 1.5 (2) | KTN-R-15 | JKS-15 | JJN-15 | FNQ-R-15 | KTK-R-15 | LP-CC-15 |
| 2.2 (3) | KTN-R-20 | JKS-20 | JJN-20 | FNQ-R-20 | KTK-R-20 | LP-CC-20 |
| 3.7 (5) | KTN-R-30 | JKS-30 | JJN-30 | FNQ-R-30 | KTK-R-30 | LP-CC-30 |
| 5.5 (7.5) | KTN-R-50 | KS-50 | JJN-50 | – | – | – |
| 7.5 (10) | KTN-R-60 | JKS-60 | JJN-60 | – | – | – |
| 11 (15) | KTN-R-80 | JKS-80 | JJN-80 | – | – | – |
| 15–18.5 (20–25) | KTN-R-125 | JKS-125 | JJN-125 | – | – | – |
| 22 (30) | KTN-R-150 | JKS-150 | JJN-150 | – | – | – |
| 30 (40) | KTN-R-200 | JKS-200 | JJN-200 | – | – | – |
| 37 (50) | KTN-R-250 | JKS-250 | JJN-250 | – | – | – |

Table 9.12 200–240 V

| AF-650 GP Power | Recommended maximum fuse | | | |
|------------------------|--------------------------|------------|----------------|------------------------|
| | SIBA | Littelfuse | Ferraz-Shawmut | Ferraz-Shawmut |
| [kW (hp)] | Type RK1 | Type RK1 | Type CC | Type RK1 ³⁾ |
| 0.25–0.37 (1/3–1/2) | 5017906-005 | KLN-R-05 | ATM-R-05 | A2K-05-R |
| 0.75 (1) | 5017906-010 | KLN-R-10 | ATM-R-10 | A2K-10-R |
| 1.5 (2) | 5017906-016 | KLN-R-15 | ATM-R-15 | A2K-15-R |
| 2.2 (3) | 5017906-020 | KLN-R-20 | ATM-R-20 | A2K-20-R |
| 3.7 (5) | 5012406-032 | KLN-R-30 | ATM-R-30 | A2K-30-R |
| 5.5 (7.5) | 5014006-050 | KLN-R-50 | – | A2K-50-R |
| 7.5 (10) | 5014006-063 | KLN-R-60 | – | A2K-60-R |
| 11 (15) | 5014006-080 | KLN-R-80 | – | A2K-80-R |
| 15–18.5 (20–25) | 2028220-125 | KLN-R-125 | – | A2K-125-R |
| 22 (30) | 2028220-150 | KLN-R-150 | – | A2K-150-R |
| 30 (40) | 2028220-200 | KLN-R-200 | – | A2K-200-R |
| 37 (50) | 2028220-250 | KLN-R-250 | – | A2K-250-R |

Table 9.13 200–240 V



Installation

AF-650 GP™ Quick Guide

| AF-650 GP | Recommended maximum fuse | | | |
|------------------------|--------------------------|------------|---------------------|----------------|
| | Bussmann | Littelfuse | Ferraz-Shawmut | Ferraz-Shawmut |
| [kW (hp)] | Type JFHR2 ²⁾ | JFHR2 | JFHR2 ⁴⁾ | J |
| 0.25–0.37 (1/3–1/2) | FWX-5 | – | – | HSJ-6 |
| 0.75 (1) | FWX-10 | – | – | HSJ-10 |
| 1.5 (2) | FWX-15 | – | – | HSJ-15 |
| 2.2 (3) | FWX-20 | – | – | HSJ-20 |
| 3.7 (5) | FWX-30 | – | – | HSJ-30 |
| 5.5 (7.5) | FWX-50 | – | – | HSJ-50 |
| 7.5 (10) | FWX-60 | – | – | HSJ-60 |
| 11 (15) | FWX-80 | – | – | HSJ-80 |
| 15–18.5 (20–25) | FWX-125 | – | – | HSJ-125 |
| 22 (30) | FWX-150 | L25S-150 | A25X-150 | HSJ-150 |
| 30 (40) | FWX-200 | L25S-200 | A25X-200 | HSJ-200 |
| 37 (50) | FWX-250 | L25S-250 | A25X-250 | HSJ-250 |

Table 9.14 200–240 V

- 1) KTS-fuses from Bussmann may substitute KTN for 240 V frequency converters.
- 2) FWH-fuses from Bussmann may substitute FWX for 240 V frequency converters.
- 3) A6KR fuses from Ferraz Shawmut may substitute A2KR for 240 V frequency converters.
- 4) A50X fuses from Ferraz Shawmut may substitute A25X for 240 V frequency converters.

9

| AF-650 GP | Recommended maximum fuse | | | | | |
|----------------------|--------------------------|----------|----------|----------|----------|----------|
| | Bussmann | Bussmann | Bussmann | Bussmann | Bussmann | Bussmann |
| [kW (hp)] | Type RK1 | Type J | Type T | Type CC | Type CC | Type CC |
| 0.37–0.75 (1/2–1) | KTS-R-6 | JKS-6 | JJS-6 | FNQ-R-6 | KTK-R-6 | LP-CC-6 |
| 1.5–2.2 (2–3) | KTS-R-10 | JKS-10 | JJS-10 | FNQ-R-10 | KTK-R-10 | LP-CC-10 |
| 3.7 (5) | KTS-R-20 | JKS-20 | JJS-20 | FNQ-R-20 | KTK-R-20 | LP-CC-20 |
| 5.5 (7.5) | KTS-R-25 | JKS-25 | JJS-25 | FNQ-R-25 | KTK-R-25 | LP-CC-25 |
| 7.5 (10) | KTS-R-30 | JKS-30 | JJS-30 | FNQ-R-30 | KTK-R-30 | LP-CC-30 |
| 11 (15) | KTS-R-40 | JKS-40 | JJS-40 | – | – | – |
| 15 (20) | KTS-R-50 | JKS-50 | JJS-50 | – | – | – |
| 18.5 (25) | KTS-R-60 | JKS-60 | JJS-60 | – | – | – |
| 22 (30) | KTS-R-80 | JKS-80 | JJS-80 | – | – | – |
| 30 (40) | KTS-R-100 | JKS-100 | JJS-100 | – | – | – |
| 37 (50) | KTS-R-125 | JKS-125 | JJS-125 | – | – | – |
| 45 (60) | KTS-R-150 | JKS-150 | JJS-150 | – | – | – |
| 55 (75) | KTS-R-200 | JKS-200 | JJS-200 | – | – | – |
| 75 (100) | KTS-R-250 | JKS-250 | JJS-250 | – | – | – |

Table 9.15 380–500 V



Installation

| AF-650 GP | Recommended maximum fuse | | | |
|----------------------|--------------------------|------------|----------------|----------------|
| | SIBA | Littelfuse | Ferraz-Shawmut | Ferraz-Shawmut |
| [kW (hp)] | Type RK1 | Type RK1 | Type CC | Type RK1 |
| 0.37–0.75 (1/2–1) | 5017906-006 | KLS-R-6 | ATM-R-6 | A6K-6-R |
| 1.5–2.2 (2–3) | 5017906-010 | KLS-R-10 | ATM-R-10 | A6K-10-R |
| 3.7 (5) | 5017906-020 | KLS-R-20 | ATM-R-20 | A6K-20-R |
| 5.5 (7.5) | 5017906-025 | KLS-R-25 | ATM-R-25 | A6K-25-R |
| 7.5 (10) | 5012406-032 | KLS-R-30 | ATM-R-30 | A6K-30-R |
| 11 (15) | 5014006-040 | KLS-R-40 | – | A6K-40-R |
| 15 (20) | 5014006-050 | KLS-R-50 | – | A6K-50-R |
| 18.5 (25) | 5014006-063 | KLS-R-60 | – | A6K-60-R |
| 22 (30) | 2028220-100 | KLS-R-80 | – | A6K-80-R |
| 30 (40) | 2028220-125 | KLS-R-100 | – | A6K-100-R |
| 37 (50) | 2028220-125 | KLS-R-125 | – | A6K-125-R |
| 45 (60) | 2028220-160 | KLS-R-150 | – | A6K-150-R |
| 55 (75) | 2028220-200 | KLS-R-200 | – | A6K-200-R |
| 75 (100) | 2028220-250 | KLS-R-250 | – | A6K-250-R |

Table 9.16 380–500 V

| AF-650 GP | Recommended maximum fuse | | | |
|----------------------|--------------------------|----------------|---------------------|------------|
| | Bussmann | Ferraz Shawmut | Ferraz Shawmut | Littelfuse |
| [kW (hp)] | JFHR2 | J | JFHR2 ¹⁾ | JFHR2 |
| 0.37–0.75 (1/2–1) | FWH-6 | HSJ-6 | – | – |
| 1.5–2.2 (2–3) | FWH-10 | HSJ-10 | – | – |
| 3.7 (5) | FWH-20 | HSJ-20 | – | – |
| 5.5 (7.5) | FWH-25 | HSJ-25 | – | – |
| 7.5 (10) | FWH-30 | HSJ-30 | – | – |
| 11 (15) | FWH-40 | HSJ-40 | – | – |
| 15 (20) | FWH-50 | HSJ-50 | – | – |
| 18.5 (25) | FWH-60 | HSJ-60 | – | – |
| 22 (30) | FWH-80 | HSJ-80 | – | – |
| 30 (40) | FWH-100 | HSJ-100 | – | – |
| 37 (50) | FWH-125 | HSJ-125 | – | – |
| 45 (60) | FWH-150 | HSJ-150 | – | – |
| 55 (75) | FWH-200 | HSJ-200 | A50-P-225 | L50-S-225 |
| 75 (100) | FWH-250 | HSJ-250 | A50-P-250 | L50-S-250 |

Table 9.17 380–500 V

1) Ferraz Shawmut A50QS fuses may substitute for A50P fuses.



Installation

AF-650 GP™ Quick Guide

| AF-650 GP | Recommended maximum fuse | | | | | Bussmann |
|------------------|--------------------------|----------|----------|----------|----------|----------|
| | Bussmann | Bussmann | Bussmann | Bussmann | Bussmann | |
| [kW (hp)] | Type RK1 | Type J | Type T | Type CC | Type CC | Type CC |
| 0.75 (1) | KTS-R-5 | JKS-5 | JJS-6 | FNQ-R-5 | KTK-R-5 | LP-CC-5 |
| 1.5–2.2 (2–3) | KTS-R-10 | JKS-10 | JJS-10 | FNQ-R-10 | KTK-R-10 | LP-CC-10 |
| 3.7 (5) | KTS-R-20 | JKS-20 | JJS-20 | FNQ-R-20 | KTK-R-20 | LP-CC-20 |
| 5.5 (7.5) | KTS-R-25 | JKS-25 | JJS-25 | FNQ-R-25 | KTK-R-25 | LP-CC-25 |
| 7.5 (10) | KTS-R-30 | JKS-30 | JJS-30 | FNQ-R-30 | KTK-R-30 | LP-CC-30 |
| 11 (15) | KTS-R-35 | JKS-35 | JJS-35 | – | – | – |
| 15 (20) | KTS-R-45 | JKS-45 | JJS-45 | – | – | – |
| 18.5 (25) | KTS-R-50 | JKS-50 | JJS-50 | – | – | – |
| 22 (30) | KTS-R-60 | JKS-60 | JJS-60 | – | – | – |
| 30 (40) | KTS-R-80 | JKS-80 | JJS-80 | – | – | – |
| 37 (50) | KTS-R-100 | JKS-100 | JJS-100 | – | – | – |
| 45 (60) | KTS-R-125 | JKS-125 | JJS-125 | – | – | – |
| 55 (75) | KTS-R-150 | JKS-150 | JJS-150 | – | – | – |
| 75 (100) | KTS-R-175 | JKS-175 | JJS-175 | – | – | – |

Table 9.18 525–600 V

| AF-650 GP | Recommended maximum fuse | | | Ferraz-Shawmut |
|------------------|--------------------------|------------|----------------|----------------|
| | SIBA | Littelfuse | Ferraz-Shawmut | |
| [kW (hp)] | Type RK1 | Type RK1 | Type RK1 | J |
| 0.75 (1) | 5017906-005 | KLS-R-005 | A6K-5-R | HSJ-6 |
| 1.5–2.2 (2–3) | 5017906-010 | KLS-R-010 | A6K-10-R | HSJ-10 |
| 3.7 (5) | 5017906-020 | KLS-R-020 | A6K-20-R | HSJ-20 |
| 5.5 (7.5) | 5017906-025 | KLS-R-025 | A6K-25-R | HSJ-25 |
| 7.5 (10) | 5017906-030 | KLS-R-030 | A6K-30-R | HSJ-30 |
| 11 (15) | 5014006-040 | KLS-R-035 | A6K-35-R | HSJ-35 |
| 15 (20) | 5014006-050 | KLS-R-045 | A6K-45-R | HSJ-45 |
| 18.5 (25) | 5014006-050 | KLS-R-050 | A6K-50-R | HSJ-50 |
| 22 (30) | 5014006-063 | KLS-R-060 | A6K-60-R | HSJ-60 |
| 30 (40) | 5014006-080 | KLS-R-075 | A6K-80-R | HSJ-80 |
| 37 (50) | 5014006-100 | KLS-R-100 | A6K-100-R | HSJ-100 |
| 45 (60) | 2028220-125 | KLS-R-125 | A6K-125-R | HSJ-125 |
| 55 (75) | 2028220-150 | KLS-R-150 | A6K-150-R | HSJ-150 |
| 75 (100) | 2028220-200 | KLS-R-175 | A6K-175-R | HSJ-175 |

Table 9.19 525–600 V

1) 170M fuses shown from Bussmann use the -/80 visual indicator. -TN/80 Type T, -/110 or TN/110 Type T indicator fuses of the same size and amperage may be substituted.



Installation

| AF-650 GP [kW (hp)] | Recommended maximum fuse | | | | | | | |
|---------------------------|--------------------------|--------------------------------|-----------------------------|-----------------------------|-----------------------------|----------------------------------|---|--------------------------------------|
| | Maximum pre- fuse | Bussmann E52273 RK1/JDDZ | Bussmann E4273 J/JDDZ | Bussmann E4273 T/JDDZ | SIBA E180276 RK1/JDDZ | Littelfuse E81895 RK1/JDDZ | Ferraz- Shawmut E163267/E2137 RK1/JDDZ | Ferraz- Shawmut E2137 J/HSJ |
| 11 (15) | 30 A | KTS-R-30 | JKS-30 | JKJS-30 | 5017906-030 | KLS-R-030 | A6K-30-R | HST-30 |
| 15–18.5 (20–25) | 45 A | KTS-R-45 | JKS-45 | JJS-45 | 5014006-050 | KLS-R-045 | A6K-45-R | HST-45 |
| 22 (30) | 60 A | KTS-R-60 | JKS-60 | JJS-60 | 5014006-063 | KLS-R-060 | A6K-60-R | HST-60 |
| 30 (40) | 80 A | KTS-R-80 | JKS-80 | JJS-80 | 5014006-080 | KLS-R-075 | A6K-80-R | HST-80 |
| 37 (50) | 90 A | KTS-R-90 | JKS-90 | JJS-90 | 5014006-100 | KLS-R-090 | A6K-90-R | HST-90 |
| 45 (60) | 100 A | KTS-R-100 | JKS-100 | JJS-100 | 5014006-100 | KLS-R-100 | A6K-100-R | HST-100 |
| 55 (75) | 125 A | KTS-R-125 | JKS-125 | JJS-125 | 2028220-125 | KLS-150 | A6K-125-R | HST-125 |
| 75 (100) | 150 A | KTS-R-150 | JKS-150 | JJS-150 | 2028220-150 | KLS-175 | A6K-150-R | HST-150 |

* UL Compliance only 525–600 V

Table 9.20 525–690 V*, 100 hp and below, Unit Sizes 2x and 3x

| AF-650 GP [kW (hp)] | Recommended maximum fuse | | | | |
|---------------------------|---------------------------|---|-----------------------|-----------------------------|-------------------|
| | Bussmann PN Type JFHR2 | Alternate Bussmann PN Type T/JDDZ | Siba PN Type JFHR2 | Littelfuse PN Type JFHR2 | Ferraz Shawmut PN |
| 90 (125) | 170M2619 | JJS-300 | 20 610 31.315 | L50-S-300 | 6.9URD31D08A0315 |
| 110 (150) | 170M2620 | JJS-350 | 20 610 31.350 | L50-S-350 | 6.9URD31D08A0350 |
| 132 (200) | 170M2621 | JJS-400 | 20 610 31.400 | L50-S-400 | 6.9URD31D08A0400 |
| 160 (250) | 170M4015 | JJS-500 | 20 610 31.550 | L50-S-500 | 6.9URD31D08A0550 |
| 200 (300) | 170M4016 | JJS-600 | 20 610 31.630 | L50-S-600 | 6.9URD31D08A0630 |
| 250 (350) | 170M4017 | – | 20 610 31.800 | – | 6.9URD31D08A0700 |
| 315 (450) | 170M6013 | – | 22 610 32.900 | – | 6.9URD33D08A0900 |
| 355 (500) | 170M6013 | – | 22 610 32.900 | – | 6.9URD33D08A0900 |
| 400 (550) | 170M6013 | – | 22 610 32.900 | – | 6.9URD33D08A0900 |
| 450 (600) | 170M7081 | – | – | – | – |
| 500 (650) | 170M7081 | – | – | – | – |
| 560 (750) | 170M7082 | – | – | – | – |
| 630 (900) | 170M7082 | – | – | – | – |
| 710 (1000) | 170M7083 | – | – | – | – |
| 800 (1200) | 170M7083 | – | – | – | – |

Table 9.21 380–500 V, above 125 hp



Installation

AF-650 GP™ Quick Guide

| AF-650 GP [kW (hp)] | Bussmann PN | Rating | Alternate Siba PN |
|------------------------|-------------|---------------|-------------------|
| 450 (600) | 170M8611 | 1100A, 1000 V | 20 781 32.1000 |
| 500 (650) | 170M8611 | 1100A, 1000 V | 20 781 32.1000 |
| 560 (750) | 170M6467 | 1400A, 700 V | 20 681 32.1400 |
| 630 (900) | 170M6467 | 1400A, 700 V | 20 681 32.1400 |
| 710 (1000) | 170M8611 | 1100A, 1000 V | 20 781 32.1000 |
| 800 (1200) | 170M6467 | 1400A, 700 V | 20 681 32.1400 |

Table 9.22 380–500 V, 600 hp and above

| AF-650 GP [kW (hp)] | Bussmann PN | Siba PN Type JFHR2 | Ferraz Shawmut PN Type JFHR2 |
|------------------------|-------------|-----------------------|---------------------------------|
| 90 (125) | 170M2616 | 20 610 31.315 | 6,9URD30D08A0315 |
| 110 (150) | 170M2619 | 20 610 31.315 | 6,9URD31D08A0315 |
| 132 (200) | 170M2619 | 20 610 31.315 | 6,9URD31D08A0315 |
| 160 (250) | 170M4015 | 20 610 31.550 | 6,9URD32D08A0550 |
| 200 (300) | 170M4015 | 20 610 31.550 | 6,9URD32D08A0550 |
| 250 (350) | 170M4015 | 20 610 31.550 | 6,9URD32D08A0550 |
| 315 (400) | 170M4015 | 20 610 31.550 | 6,9URD32D08A0550 |
| 335 (450) | 170M4017 | 20 610 32.700 | 6,9URD31D08A0700 |
| 355 (500) | 170M6013 | 22 610 32.900 | 6,9URD33D08A0900 |
| 415 (600) | 170M6013 | 22 610 32.900 | 6,9URD33D08A0900 |
| 500/650 | 170M7081 | | |
| 560 (750) | 170M7081 | | |
| 710 (950) | 170M7081 | | |
| 785 (1050) | 170M7081 | | |
| 800 (1150) | 170M7082 | | |
| 1000 (1350) | 170M7083 | | |

Table 9.23 525–690 V, above 125 hp

| AF-650 GP [kW (hp)] | Bussmann PN | Rating | Alternate Siba PN |
|------------------------|-------------|----------------|-------------------|
| 630 (900) | 170M8611 | 1100 A, 1000 V | 20 781 32.1000 |
| 710 (1000) | 170M8611 | 1100 A, 1000 V | 20 781 32.1000 |
| 800 (1150) | 170M8611 | 1100 A, 1000 V | 20 781 32.1000 |
| 900 (1250) | 170M8611 | 1100 A, 1000 V | 20 781 32.1000 |
| 1000 (1350) | 170M8611 | 1100 A, 1000 V | 20 781 32.1000 |
| 1200 (1600) | 170M8611 | 1100 A, 1000 V | 20 781 32.1000 |

Table 9.24 525–690 V, 900 hp and above

*170M fuses from Bussmann shown use the -/80 visual indicator, -TN/80 Type T, -/110 or TN/110 Type T indicator fuses of the same size and amperage may be substituted for external use

**Any minimum 500 V UL listed fuse with associated current rating may be used to meet UL requirements.



10 Terminal and Applicable Wire

10.1 Cables

10

| 200-240 V [kW (hp)] | Power [kW (hp)] | | | Enclosure | Mains | | Motor | | Load share | | Brake | | Ground* | |
|------------------------|------------------------|-------------------------|-------------------------|-----------------|---|---|---|---|---|---|---|---|--------------------|---------------------------------------|
| | 380-500 V [kW (hp)] | 525-600 V [kW (hp)] | 575-690 V [kW (hp)] | | Tightening g torque [Nm (in- lbs)] | Wire size [mm ² (AWG)] | Tightening g torque [Nm (in- lbs)] | Wire size [mm ² (AWG)] | Tightening g torque [Nm (in- lbs)] | Wire size [mm ² (AWG)] | Tightening g torque [Nm (in- lbs)] | Wire size [mm ² (AWG)] | | Tightening torque [Nm (in-lbs)] |
| 0.25-2.2 (1/3-3) | 0.37-4 (1/2-59) | 0.75-4 (1-59) | - | IP20 | 4 (10) | 1.8 (16) | 4 (10) | 1.8 (16) | 4 (10) | 1.8 (16) | 4 (10) | 1.8 (16) | 4 (10) | 3 (27) |
| 3.7 (5) | 5.5-7.5 (7.5-10) | 5.5-7.5 (7.5-10) | - | IP20 | 4 (10) | 1.8 (16) | 4 (10) | 1.8 (16) | 4 (10) | 1.8 (16) | 4 (10) | 1.8 (16) | 4 (10) | |
| 0.25-3.7 (1/3-5) | 0.37-7.5 (1/2-10) | 0.75-7.5 (1-10) | - | IP55 or IP66 | 4 (10) | 1.8 (16) | 4 (10) | 1.8 (16) | 4 (10) | 1.8 (16) | 4 (10) | 1.8 (16) | 4 (10) | 3 (27) |
| 5.5-7.5 (7.5-10) | 11-15 (15-20) | 11-15 (15-20) | - | IP20 | 16 (6) | 1.5 (14) | 16 (6) | 1.5 (14) | 16 (6) | 1.5 (14) | 16 (6) | 1.5 (14) | 16 (6) | |
| 5.5-7.5 (7.5-10) | 11-15 (15-20) | 11-15 (15-20) | - | IP55 or IP66 | 16 (6) | 1.5 (14) | 16 (6) | 1.5 (14) | 16 (6) | 1.5 (14) | 16 (6) | 1.5 (14) | 16 (6) | 3 (27) |
| 11-15 (15-20) | 18.5-30 (25-40) | 18.5-30 (25-40) | - | IP20 | 35 (2) | 4.5 (40) | 35 (2) | 4.5 (40) | 35 (2) | 4.5 (40) | 35 (2) | 4.5 (40) | 35 (2) | |
| 11 (15) | 18.5-22 (25-30) | 18.5-22 (25-30) | 11-22 (15-30) | IP55 or IP66 | 35 (2) | 4.5 (40) | 35 (2) | 4.5 (40) | 35 (2) | 4.5 (40) | 35 (2) | 4.5 (40) | 35 (2) | 3 (27) |
| 18.5-22 (25-30) | 37-45 (50-60) | 37-45 (50-60) | - | IP20 | 50 (1) | 10 (89) | 50 (1) | 10 (89) | 50 (1) | 10 (89) | 50 (1) | 10 (89) | 50 (1) | |
| 18.5-22 (25-30) | 30-45 (40-60) | 30-45 (40-60) | - | IP55 or IP66 | 90 (3/0) | 10 (89) | 90 (3/0) | 10 (89) | 90 (3/0) | 10 (89) | 90 (3/0) | 10 (89) | 90 (3/0) | 3 (27) |
| 30-37 (40-50) | 55-75 (75-100) | 55-75 (75-100) | - | IP20 | 150 (300) | 14 (124) | 150 (300) | 14 (124) | 120 (4/0) | 14 (124) | 95 (4/0) | 14 (124) | 120 (4/0) | |
| 30-37 (40-50) | 55-75 (75-100) | 55-75 (75-100) | - | IP55 or IP66 | 120 (4/0) | 14 (124) | 120 (4/0) | 14 (124) | 120 (4/0) | 14 (124) | 120 (4/0) | 14 (124) | 120 (4/0) | 3 (27) |
| 90-132 (125-200) | 90-132 (125-200) | 90-132 (125-200) | 90-132 (125-200) | All | 2x95 (2x3/0) | 19 (75) | 2x95 (2x3/0) | 19 (75) | 2x95 (2x3/0) | 19 (75) | 2x95 (2x3/0) | 19 (75) | 2x95 (2x3/0) | |
| 160-250 (250-350) | 160-250 (250-350) | 160-315 (250-400) | 160-315 (250-400) | All | 2x185 (2x350) | 19 (168) | 2x185 (2x350) | 19 (168) | 2x185 (2x350) | 19 (168) | 2x185 (2x350) | 19 (168) | 2x185 (2x350) | 3 (27) |
| 315-400 (350-550) | 315-400 (350-550) | 355-560 (500-750) | 355-560 (500-750) | All | 4x240 (4x500) | 19 (168) | 4x240 (4x500) | 19 (168) | 4x240 (4x500) | 19 (168) | 4x240 (4x500) | 19 (168) | 4x240 (4x500) | |
| 450-630 (600-900) | 450-630 (600-900) | 630-800 (900-1150) | 630-800 (900-1150) | All | 8x150 (8x300) | 19 (168) | 8x150 (8x300) | 19 (168) | 8x150 (8x300) | 19 (168) | 8x150 (8x300) | 19 (168) | 8x150 (8x300) | 3 (27) |
| 710-800 (1000-1200) | 710-800 (1000-1200) | 900-1200 (1250-1600) | 900-1200 (1250-1600) | All | 12x150 (12x300) | 19 (168) | 12x150 (12x300) | 19 (168) | 12x150 (12x300) | 19 (168) | 12x150 (12x300) | 19 (168) | 12x150 (12x300) | |

* Maximum cable size according to national code

Table 10.1 Cables

The instructions do not purport to cover all details or variations in equipment nor to provide for every possible contingency to be met in connection with installation, operation or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the GE company.

AF-650 GP is trademark of the General Electric Company.

GE
41 Woodford Avenue
Plainville, CT 06062

www.geelectrical.com/drives



imagination at work

130R0287



DET-758C