

GE
Industrial Solutions

AF-650 GP™ General Purpose Drive for Special Applications

Quick Guide



a product of
ecomagination



**Contents**

1 Safety	4
1.1 Safety Symbols	4
1.2 Qualified Personnel	4
1.3 Safety Precautions	4
2 Introduction	6
3 Installation	7
3.1 Installation Site Check List	7
3.2 Frequency Converter and Motor Pre-installation Check List	7
3.3 Mechanical Installation	7
3.3.1 Cooling	7
3.3.2 Lifting	8
3.3.3 Mounting	8
3.4 Electrical Installation	9
3.4.1 Requirements	10
3.4.2 Grounding Requirements	10
3.4.2.1 Leakage Current (>3.5 mA)	11
3.4.2.2 Grounding Using Shielded Cable	11
3.4.3 Motor Connection	11
3.4.4 AC Mains Connection	12
3.4.5 Control Wiring	12
3.4.5.1 Access	12
3.4.5.2 Control Terminal Types	13
3.4.5.3 Wiring to Control Terminals	14
3.4.5.4 Using Shielded Control Cables	14
3.4.5.5 Control Terminal Functions	15
3.4.5.6 Terminal 53 and 54 Switches	15
3.4.5.7 Terminal 37	15
3.4.6 Serial Communication	16
4 Start-up and Functional Testing	17
4.1 Pre-start	17
4.1.1 Safety Inspection	17
4.2 Applying Power	19
4.3 Basic Operational Programming	19
4.4 Auto Tune	19
4.5 Check Motor Rotation	20
4.6 Local-control Test	20
4.7 System Start Up	21



Contents

4.8 Battery Back-up	21
4.8.1 Introduction	21
4.8.2 Operating Principle	21
4.8.3 Programming	22
4.8.3.1 Preparation	22
4.8.3.2 Basic Settings	22
4.8.4 Parameters for Battery Back-up Application	22
4.8.5 Updates to Existing Parameters	23
4.8.6 External Equipment and Component Sizing Considerations	23
4.8.6.1 DC Fuse and Isolation Diode Sizing	23
4.8.6.2 DC Inrush Considerations	24
4.8.7 Motor Operation with Reduced DC-link Voltage Considerations	25
5 User Interface	26
5.1 Keypad	26
5.1.1 Keypad Layout	26
5.1.2 Setting Keypad Display Values	27
5.1.3 Display Menu Keys	27
5.1.4 Navigation Keys	28
5.1.5 Operation Keys	28
5.2 Back-up and Copying Parameter Settings	28
5.2.1 Uploading data to the keypad	29
5.2.2 Downloading Data from the Keypad	29
5.3 Restoring Default Settings	29
5.3.1 Recommended Restoring	29
5.3.2 Manual Restoring	29
6 Parameter Menu Structure	30
6.1 Main Menu Structure	30
6.2 Remote Programming with DCT-10	35
7 Warnings and Alarm	36
7.1 System Monitoring	36
7.2 Warning and Alarm Types	36
7.3 Warning and Alarm Displays	36
7.4 Warning and Alarm Definitions	37
8 Specifications	40
8.1 General Technical Data	40
8.2 Fuses	44
8.2.1 CE Compliance	45
8.2.2 Fuse Specifications	45



8.2.3 NEC and UL Compliance	45
9 Terminal and Applicable Wire	47
9.1 Cables	47
Index	48



1 Safety

1.1 Safety Symbols

The following symbols are used in this guide:



Indicates a potentially hazardous situation that could result in death or serious injury.



Indicates a potentially hazardous situation that could result in minor or moderate injury. It can also be used to alert against unsafe practices.



Indicates important information, including situations that can result in damage to equipment or property.

1.2 Qualified Personnel

Correct and reliable transport, storage, installation, operation, and maintenance are required for the trouble-free and safe operation of the drive. Only qualified personnel are allowed to install and operate this equipment.

Qualified personnel are defined as trained staff, who are authorized to install, commission, and maintain equipment, systems, and circuits in accordance with pertinent laws and regulations. Also, the qualified personnel must be familiar with the instructions and safety measures described in this manual.

1.3 Safety Precautions



HIGH VOLTAGE

Drives contain high voltage when connected to AC mains input or DC battery. Failure to perform installation, start-up, and maintenance by qualified personnel can result in death or serious injury.

- Only qualified personnel must perform installation, start-up, and maintenance.



UNINTENDED START

When the frequency converter is connected to AC mains or DC battery, the motor may start at any time. Unintended start during programming, service, or repair work can result in death, serious injury, or property damage. The motor can start via an external switch, a fieldbus command, an input reference signal from the keypad, or after a cleared fault condition.

To prevent unintended motor start:

- Disconnect the frequency converter from the mains.
- Press [Off/Reset] on the keypad before programming parameters.
- Completely wire and assemble the frequency converter, motor, and any driven equipment before connecting the frequency converter to AC mains or DC battery.



DISCHARGE TIME

The frequency converter contains DC-link capacitors, which can remain charged even when the frequency converter is not powered. High voltage can be present even when the warning indicator lights are off. Failure to wait the specified time after power has been removed before performing service or repair work, could result in death or serious injury.

1. Stop the motor.
2. Disconnect AC mains, permanent magnet type motors, and remote DC-link supplies, including battery back-ups, UPS, and DC-link connections to other frequency converters.
3. Wait for the capacitors to discharge fully, before performing any service or repair work. The duration of waiting time is specified in *Table 1.1*.

Voltage [V]	Power size [kW (hp)]	Minimum waiting time (minutes)
380–480	18 (25)	15
	37 (50)	
	75 (100)	
380–480	132 (200)	20
	250 (350)	

Table 1.1 Discharge Time

**⚠ WARNING****LEAKAGE CURRENT HAZARD**

Leakage currents exceed 3.5 mA. Failure to ground the drive properly can result in death or serious injury.

- Ensure the correct grounding of the equipment by a certified electrical installer.

⚠ WARNING**EQUIPMENT HAZARD**

Contact with rotating shafts and electrical equipment can result in death or serious injury.

- Ensure that only trained and qualified personnel perform installation, start-up, and maintenance.
- Ensure that electrical work conforms to national and local electrical codes.
- Follow the procedures in this guide.

⚠ WARNING**UNINTENDED MOTOR ROTATION****WINDMILLING**

Unintended rotation of permanent magnet motors creates voltage and can charge the unit, resulting in death, serious injury, or equipment damage.

- Ensure that permanent magnet motors are blocked to prevent unintended rotation.

⚠ CAUTION**INTERNAL FAILURE HAZARD**


An internal failure in the drive can result in serious injury when the drive is not properly closed.

- Ensure that all safety covers are in place and securely fastened before applying power.



2 Introduction

2



130BB492.10

1	Keypad	10	Motor output terminals 96 (U), 97 (V), 98 (W)
2	RS485 serial bus connector (+68, -69)	11	Relay 1 (01, 02, 03)
3	Analog I/O connector	12	Relay 2 (04, 05, 06)
4	Keypad input plug	13	Brake (-81, +82) and DC battery input (-88, +89) terminals
5	Analog switches (A53), (A54)	14	Mains input terminals 91 (L1), 92 (L2), 93 (L3)
6	Cable strain relief/PE ground	15	USB connector
7	Decoupling plate	16	Serial bus terminal switch
8	Grounding clamp (PE)	17	Digital I/O and 24 V power supply
9	Shielded cable grounding clamp and strain relief	18	Control cable cover plate

Illustration 2.1 Exploded View Unit Sizes 12–13, IP20

NOTICE

Consult the AF-650 GP Design & Installation Guide for other unit sizes.



3 Installation

3.1 Installation Site Check List

- The frequency converter relies on the ambient air for cooling. Observe the limitations on ambient air temperature for optimal operation.
- Ensure that the installation location has sufficient support strength to mount the frequency converter.
- Keep the manual, drawings, and diagrams accessible for detailed installation and operation instructions. It is important that the manual is available for equipment operators.
- Locate equipment as near to the motor as possible. Keep motor cables as short as possible. Check the motor characteristics for actual tolerances.

Do not exceed:

- 300 m (1000 ft) for unshielded motor cables.
- 150 m (500 ft) for shielded cable.

CAUTION

DEVICE DAMAGE THROUGH CONTAMINATION
Do not leave the frequency converter uncovered.

3.2 Frequency Converter and Motor Pre-installation Check List

- Compare the model number of unit on the nameplate to what was ordered to verify the proper equipment.
- Ensure each of the following are rated for same voltage:
 - Mains (power)
 - Frequency converter
 - Motor
- Ensure that the frequency converter output current rating is equal to or greater than motor full load current for peak motor performance:
 - Motor size and frequency converter power must match for proper overload protection.
 - If frequency converter rating is less than motor, full motor output cannot be achieved.

3.3 Mechanical Installation

3.3.1 Cooling

- To provide cooling airflow, mount the unit to a solid flat surface or to the optional backplate (see chapter 3.3.3 Mounting).
- Top and bottom clearance for air cooling must be provided. Generally, 100–225 mm (4–10 in) is required. See *Illustration 3.1* for clearance requirements.
- Improper mounting can result in over heating and reduced performance.
- Derating for temperatures starting between 40 °C (104 °F) and 50 °C (122 °F) and elevation 1000 m (3300 ft) above sea level must be considered. See the equipment Design Guide for detailed information.




Illustration 3.1 Top and Bottom Cooling Clearance

Voltage [V]	Power size [kW (hp)]	Clearance a/b [mm (in)]
380–480	18, 37 (25, 50)	200 (8)
	75, 132, 250 (100, 200, 350)	225 (10)

Table 3.1 Minimum Airflow Clearance Requirements

Installation

3

3.3.2 Lifting

- Check the weight of the unit to determine a safe lifting method.
- Ensure that the lifting device is suitable for the task.
- If necessary, plan for a hoist, crane, or forklift with the appropriate rating to move the unit.
- For lifting, use hoist rings on the unit, when provided.

3.3.3 Mounting

- Mount the unit vertically.
- The frequency converter allows side-by-side installation.
- Ensure that the strength of the mounting location supports the unit weight.
- Mount the unit to a solid flat surface or to the optional backplate to provide cooling airflow (see *Illustration 3.2* and *Illustration 3.3*).
- Improper mounting can result in over heating and reduced performance.
- Use the slotted mounting holes on the unit for wall mount, when provided.




Illustration 3.2 Proper Mounting with Backplate

Item A in *Illustration 3.2* and *Illustration 3.3* is a backplate properly installed for required airflow to cool the unit.




Illustration 3.3 Proper Mounting with Railings

NOTICE

Back plate is needed when mounted on railings.

3.4 Electrical Installation

This section contains detailed instructions for wiring the frequency converter.

The following tasks are described:

- Wiring the motor to the frequency converter output terminals.
- Wiring the AC mains to the frequency converter input terminals.
- Connecting control and serial communication wiring.
- After power has been applied, checking input and motor power; programming control terminals for their intended functions.




Illustration 3.4 Basic Wiring Schematic Drawing

A=Analog, D=Digital

Terminal 37 is used for Safe Torque Off. Refer to *Safe Torque Off Operating Instructions* for further information.

*The brake chopper factory option must be ordered to use dynamic brake resistors.



3.4.1 Requirements

WARNING

EQUIPMENT HAZARD!

Rotating shafts and electrical equipment can be hazardous. All electrical work must conform to national and local electrical codes. It is recommended that installation, start up, and maintenance is performed only by trained and qualified personnel. Failure to follow these guidelines could result in death or serious injury.

CAUTION

WIRING ISOLATION!

Run input power, motor wiring, and control wiring in three separate metallic conduits or use separated shielded cable for high frequency noise isolation. Failure to isolate power, motor, and control wiring could result in less than optimum frequency converter and associated equipment performance.


For your safety, comply with the following requirements:

- Electronic controls equipment is connected to hazardous mains voltage. Extreme care should be taken to protect against electrical hazards when applying power to the unit.
- Run motor cables from multiple frequency converters separately. Induced voltage from output motor cables run together can charge equipment capacitors even with the equipment turned off and locked out.

Overload and equipment protection

- An electronically activated function within the frequency converter provides overload protection for the motor. The overload calculates the level of increase to activate timing for the trip (controller output stop) function. The higher the current draw, the quicker the trip response. The overload provides Class 20 motor protection. See *chapter 7 Warnings and Alarm* for details on the trip function.
- Because the motor wiring carries high frequency current, it is important that wiring for mains, motor power, and control are run separately. Use metallic conduit or separated shielded wire. Failure to isolate power, motor, and control wiring could result in less than optimum equipment performance.
- All frequency converters must be provided with short circuit and overcurrent protection. Input fusing is required to provide this protection, see *Illustration 3.5*. Fuses must be provided by the

installer as part of installation. See maximum fuse ratings in *chapter 8.2 Fuses*.



1	Fuses
2	Ground

Illustration 3.5 Frequency Converter Fuses

Wire type and ratings

- All wiring must comply with local and national regulations regarding cross-section and ambient temperature requirements.
- GE recommends that all power connections be made with a minimum 75 ° C (167°F) rated copper wire.

3.4.2 Grounding Requirements

WARNING

GROUNDING HAZARD!

For operator safety, it is important to ground the frequency converter properly in accordance with national and local electrical codes and instructions contained within these instructions. Ground currents are higher than 3.5 mA. Failure to ground the frequency converter properly could result in death or serious injury.

NOTICE

It is the responsibility of the user or certified electrical installer to ensure correct grounding of the equipment in accordance with national and local electrical codes and standards.

- Follow all local and national electrical codes to ground electrical equipment properly.
- Proper protective grounding for equipment with ground currents higher than 3.5 mA must be established, see *chapter 3.4.2.1 Leakage Current (>3.5 mA)*.

- A dedicated ground wire is required for input power, motor power, and control wiring.
- Use the clamps provided with on the equipment for proper ground connections.
- Do not ground one frequency converter to another in a “daisy chain” fashion.
- Keep the ground wire connections as short as possible.
- Use of high-strand wire to reduce electrical noise is recommended.
- Follow motor manufacturer wiring requirements.

3.4.2.1 Leakage Current (>3.5 mA)

Follow national and local codes regarding protective earthing of equipment with a leakage current > 3.5 mA. Frequency converter technology implies high frequency switching at high power. This generates a leakage current in the ground connection. A fault current in the frequency converter at the output power terminals might contain a DC component which can charge the filter capacitors and cause a transient ground current. The ground leakage current depends on various system configurations including RFI filtering, shielded motor cables, and frequency converter power.

EN/IEC61800-5-1 (Power Drive System Product Standard) requires special care if the leakage current exceeds 3.5 mA.

Grounding must be reinforced in one of the following ways:

- Ground wire of at least 10 mm² (8 AWG).
- Two separate ground wires both complying with the dimensioning rules.

See EN 60364-5-54 § 543.7 for further information.

Using RCDs

Where residual current devices (RCDs), also known as earth leakage circuit breakers (ELCBs), are used, comply with the following:

- Use RCDs of type B only which are capable of detecting AC and DC currents.
- Use RCDs with an inrush delay to prevent faults due to transient ground currents.
- Dimension RCDs according to the system configuration and environmental considerations.

3.4.2.2 Grounding Using Shielded Cable

Grounding clamps are provided for motor wiring (see *Illustration 3.6*).




Illustration 3.6 Grounding with Shielded Cable

3.4.3 Motor Connection


WARNING

INDUCED VOLTAGE!

Run output motor cables from multiple frequency converters separately. Induced voltage from output motor cables run together can charge equipment capacitors even with the equipment turned off and locked out. Failure to run output motor cables separately could result in death or serious injury.

- For maximum wire sizes, see *Table 9.1*.
- Comply with local and national electrical codes for cable sizes.
- Do not install power factor correction capacitors between the frequency converter and the motor.
- Do not wire a starting or pole-changing device between the frequency converter and the motor.
- Connect the 3-phase motor wiring to terminals 96 (U), 97 (V), and 98 (W).
- Ground the cable in accordance with grounding instructions provided.
- Torque terminals in accordance with the information provided in *chapter 9 Terminal and Applicable Wire*.
- Follow motor manufacturer wiring requirements.

Illustration 3.7 shows mains input, motor, and grounding for basic frequency converters. Actual configurations vary with unit types and optional equipment.



130BB920.10

Illustration 3.7 Example of Motor, Mains, and Ground Wiring

3.4.4 AC Mains Connection


- Size wiring based on the input current of the frequency converter. For maximum wire sizes, see *Table 9.1*.
- Comply with local and national electrical codes for cable sizes.
- Connect 3-phase AC input power wiring to terminals L1, L2, and L3 (see *Illustration 3.7*).
- Depending on the configuration of the equipment, input power is connected to the mains input power or the input disconnect.
- Ground the cable in accordance with grounding instructions provided in *chapter 3.4.2 Grounding Requirements*.
- All frequency converters may be used with an isolated input source and with ground reference power lines. When supplied from an isolated mains source (IT mains or floating delta) or TT/TN-S mains with a grounded leg (grounded delta), set *parameter SP-50 RFI Filter* to [0] Off. When off, the internal RFI filter capacitors between the chassis and the intermediate circuit are isolated to avoid damage to the DC link and to reduce ground capacity currents in accordance with IEC 61800-3.

3.4.5 Control Wiring

- Isolate control wiring from high-power components in the frequency converter.
- If the frequency converter is connected to a thermistor, for PELV isolation, optional thermistor control wiring must be reinforced/double insulated. A 24 V DC supply voltage is recommended.

3.4.5.1 Access

- Remove access cover plate with a screwdriver. See *Illustration 3.8*.
- Or remove front cover by loosening attaching screws. Tightening torque for front cover is 2.0 Nm for unit size 15 Nm and 2.2 Nm for unit sizes 2X and 3X.



130BT248

Illustration 3.8 Control Wiring Access for IP20/Open Chassis Enclosures

3.4.5.2 Control Terminal Types

Illustration 3.9 shows the removable frequency converter connectors. Terminal functions and default settings are summarized in Table 3.3.




Illustration 3.9 Control Terminal Locations




Illustration 3.10 Terminal Numbers

- **Connector 1** provides four programmable digital inputs terminals, two extra digital terminals programmable as either input or output, a 24 V DC terminal supply voltage, and a common for optional customer supplied 24 V DC voltage. A digital input for STO (Safe Torque Off) function.
- **Connector 2** terminals (+)68 and (-)69 are for an RS485 serial communications connection.
- **Connector 3** provides two analog inputs, one analog output, 10 V DC supply voltage, and commons for the inputs and output.
- **Connector 4** is a USB port available for use with the DCT-10.
- Also provided are two Form C relay outputs that are in various locations depending after the frequency converter configuration and size.
- Some options available for ordering with the unit may provide extra terminals. See the manual provided with the equipment option.

See chapter 8.1 General Technical Data for terminal ratings details.

Terminal description			
Terminal	Parameter	Default setting	Description
Digital inputs/outputs			
12, 13	–	+24 V DC	24 V DC supply voltage. Maximum output current is 200 mA total for all 24 V loads. Useable for digital inputs and external transducers.
18	E-01	[8] Start	Digital inputs.
19	E-02	[10] Reversing	
32	E-05	[0] No operation	
33	E-06	[0] No operation	
27	E-03	[0] No operation	Selectable for either digital input or output. Default setting is input.
29	E-04	[14] Jog	
20	–		Common for digital inputs and 0 V potential for 24 V supply.
37	–	Safe Torque Off (STO)	Safe input. Used for STO.
Analog inputs/outputs			
39	–	–	Common for analog output.
42	AN-50	[0] No operation	Programmable analog output. The analog signal is 0–20 mA or 4–20 mA at a maximum of 500 Ω
50	–	+10 V DC	10 V DC analog supply voltage. 15 mA maximum commonly used for potentiometer or thermistor.
53	AN-1#	Reference	Analog input.
54	AN-2#	Feedback	Selectable for voltage or current. Switches A53 and A54 select mA or V.
55	–	–	Common for analog input.

Table 3.2 Terminal Description Digital Inputs/Outputs, Analog Inputs/Outputs

Installation

3

Terminal description			
Terminal	Parameter	Default setting	Description
Serial communication			
61	-	-	Integrated RC-Filter for cable screen. ONLY for connecting the shield when experiencing EMC problems.
68 (+)	O-3#	-	RS485 Interface. A control card switch is provided for termination resistance.
69 (-)	O-3#	-	
Relays			
01, 02, 03	E-24	[0] No operation	Form C relay output. Usable for AC or DC voltage and resistive or inductive loads.
04, 05, 06	E-24	[0] No operation	

Table 3.3 Terminal Description Serial Communication

3.4.5.3 Wiring to Control Terminals

Control terminal connectors can be unplugged from the frequency converter for ease of installation, as shown in *Illustration 3.9*.

1. Open the contact by inserting a small screwdriver into the slot above or below the contact, as shown in *Illustration 3.11*.
2. Insert the bared control wire into the contact.
3. Remove the screwdriver to fasten the control wire into the contact.
4. Ensure that the contact is firmly established and not loose. Loose control wiring can be the source of equipment faults or less than optimal operation.





Illustration 3.11 Connecting Control Wiring

3.4.5.4 Using Shielded Control Cables

Correct screening

The preferred method usually is to secure control and serial communication cables with screening clamps provided at both ends to ensure best possible high frequency cable contact.

If the ground potential between the frequency converter and the PLC is different, electric noise may occur that disturbs the entire system. Solve this problem by fitting an equalizing cable next to the control cable. Minimum cable cross-section: 16 mm² (6 AWG).



1	Minimum 16 mm ² (6 AWG)
2	Equalizing cable

Illustration 3.12 Correct Screening

50/60 Hz ground loops

With long control cables, ground loops may occur. To eliminate ground loops, connect one end of the screen-to-ground with a 100 nF capacitor (keeping leads short).





Illustration 3.13 50/60 Hz Ground Loops

Avoid EMC noise on serial communication


This terminal is connected to ground via an internal RC link. Use twisted-pair cables to reduce interference between conductors. The recommended method is in *Illustration 3.14*:



1	Minimum 16 mm ² (6 AWG)
2	Equalizing cable

Illustration 3.14 Twisted-pair Cables

Alternatively, the connection to terminal 61 can be omitted:



1	Minimum 16 mm ² (6 AWG)
2	Equalizing cable

Illustration 3.15 Twisted-pair Cables without Terminal 61

3.4.5.5 Control Terminal Functions

Frequency converter functions are commanded by receiving control input signals.

- Each terminal must be programmed for the function it is supporting in the parameters associated with that terminal. See *Table 3.3* for terminals and associated parameters.
- It is important to confirm that the control terminal is programmed for the correct function. See *chapter 5 User Interface* for details on accessing parameters and *chapter 6 Parameter Menu Structure* for details on programming.
- The default terminal programming is intended to initiate frequency converter functioning in a typical operational mode.

3.4.5.6 Terminal 53 and 54 Switches

- Analog input terminals 53 and 54 can select either voltage (-10 V to 10 V) or current (0/4–20 mA) input signals.
- Remove power to the frequency converter before changing switch positions.
- Set switches A53 and A54 to select the signal type. U selects voltage, I selects current.
- The switches are accessible when the keypad has been removed (see *Illustration 3.16*).

NOTICE

Some option cards available for the unit may cover these switches and must be removed to change switch settings. Always remove power to the unit before removing option cards.

- Terminal 53 default is for a speed reference signal in open loop set in *parameter DR-61 Terminal 53 Switch Setting*.
- Terminal 54 default is for a feedback signal in closed loop set in *parameter DR-63 Terminal 54 Switch Setting*.




Illustration 3.16 Location of Terminals 53 and 54 Switches and Bus Termination Switch

3.4.5.7 Terminal 37

Terminal 37 Safe Torque Off function

The AF-650 GP is available with Safe Torque Off functionality via control terminal 37. Safe torque off (STO) disables the control voltage of the power semiconductors of the frequency converter output stage which in turn prevents generating the voltage required to rotate the motor. To run STO, additional wiring for the frequency converter is required. Refer to *Safe Torque Off Operating Instructions* for further information.

3.4.6 Serial Communication

Connect RS485 serial communication wiring to terminals (+)68 and (-)69.

3

- Shielded serial communication cable is recommended.
- See *chapter 3.4.2 Grounding Requirements* for proper grounding.




Illustration 3.17 Serial Communication Wiring Diagram

For basic serial communication set-up, select the following:

1. Protocol type in *parameter O-30 Protocol*.
 2. Frequency converter address in *parameter O-31 Address*.
 3. Baud rate in *parameter O-32 Drive Port Baud Rate*.
- Two communication protocols are internal to the frequency converter.
 - Drive profile
 - Modbus RTU
 - Functions can be programmed remotely using the protocol software and RS485 connection or in *parameter group O-## Options/Comms*.
 - Selecting a specific communication protocol changes various default parameter settings to match that protocol's specifications along with making extra protocol-specific parameters available.
 - Option cards which install into the frequency converter are available to provide extra communication protocols. See the option-card documentation for installation and operation instructions.



4 Start-up and Functional Testing

4.1 Pre-start

4.1.1 Safety Inspection

▲WARNING

HIGH VOLTAGE

If input and output connections have been connected improperly, there is potential for high voltage on these terminals. If power leads for multiple motors are improperly run in same conduit, there is potential for leakage current to charge capacitors within the frequency converter, even when disconnected from mains input.

- For initial start-up, make no assumptions about power components.
- Follow pre-start procedures.

Failure to follow pre-start procedures could result in personal injury or damage to equipment.

1. Switch off the Input power to the unit and ensure that it is locked out. Do not rely on the frequency converter disconnect switches for input power isolation.
2. Verify that there is no voltage on input terminals L1 (91), L2 (92), and L3 (93), phase-to-phase, and phase-to-ground.
3. Verify that there is no voltage on output terminals 96 (U), 97 (V), and 98 (W), phase-to-phase, and phase-to-ground.
4. Confirm continuity of the motor by measuring ohm values on U-V (96-97), V-W (97-98), and W-U (98-96).
5. Check for proper grounding of the frequency converter and the motor.
6. Inspect the frequency converter for loose connections on terminals.
7. Record the following motor nameplate data:
 - 7a Power
 - 7b Voltage
 - 7c Frequency
 - 7d Full load current
 - 7e Nominal speed.

These values are needed to program the motor nameplate data later.

8. Confirm that the supply voltage matches the voltage of the frequency converter and the motor.



Start-up and Functional Tes...

4.1.2 Pre-start

CAUTION

Before applying power to the unit, inspect the entire installation as detailed in *Table 4.1*. Check mark those items when completed.

4

Inspect for	Description	<input checked="" type="checkbox"/>
Auxiliary equipment	<ul style="list-style-type: none"> Look for auxiliary equipment, switches, disconnects, or input fuses/circuit breakers on the input power side of the frequency converter or output side to the motor. Ensure that they are ready for full speed operation. Check function and installation of any sensors used for feedback to the frequency converter. Remove power factor correction capacitors on motors, if present. 	
Cable routing	<ul style="list-style-type: none"> Use separate metallic conduits for each of the following: <ul style="list-style-type: none"> Input power Motor wiring Control wiring 	
Control wiring	<ul style="list-style-type: none"> Check for broken or damaged wires and loose connections. Check that control wiring is isolated from power and motor wiring for noise immunity. Check the voltage source of the signals. Use shielded or twisted-pair cable. Ensure that the shield is terminated correctly. 	
Cooling clearance	<ul style="list-style-type: none"> Measure that top and bottom clearance is adequate to ensure proper air flow for cooling. 	
EMC considerations	<ul style="list-style-type: none"> Check for proper installation regarding electromagnetic compatibility. 	
Environmental considerations	<ul style="list-style-type: none"> See equipment label for the maximum ambient operating temperature limits. Humidity levels must be 5–95%, non-condensing. 	
Fusing and circuit breakers	<ul style="list-style-type: none"> Check for proper fusing or circuit breakers. Check that all fuses are inserted firmly and in operational condition, and that all circuit breakers are in the open position. 	
Grounding	<ul style="list-style-type: none"> The unit requires a ground wire from its enclosure to the building ground. Check for good ground connections that are tight and free of oxidation. Grounding to conduit or mounting the back panel to a metal surface is not sufficient. 	
Input and output power wiring	<ul style="list-style-type: none"> Check for loose connections. Check that motor and mains are in separate conduit or separated shielded cables. 	
Panel interior	<ul style="list-style-type: none"> Inspect that the unit interior is free of debris and corrosion. 	
Switches	<ul style="list-style-type: none"> Ensure that all switch and disconnect settings are in the proper positions. 	
Vibration	<ul style="list-style-type: none"> Check that the unit is mounted solidly or that shock mounts are used as necessary. Check for an unusual amount of vibration. 	

Table 4.1 Start-up Checklist



4.2 Applying Power

⚠ WARNING

HIGH VOLTAGE!

Frequency converters contain high voltage when connected to the energized DC bus. Only qualified personnel should install, start up, and maintain the frequency converters. Failure to let qualified personnel install, start up and maintain the frequency converters could result in death or serious injury.

⚠ WARNING

UNINTENDED START!

When the frequency converter is connected to the energized DC bus, the motor may start at any time. The frequency converter, motor, and any driven equipment must be in operational readiness. Failure to be in operational readiness when the frequency converter is connected to the energized DC bus could result in death, serious injury, equipment, or property damage.

1. Confirm that input voltage is balanced within 3%. If not, correct input voltage imbalance before proceeding. Repeat procedure after voltage correction.
2. Ensure optional equipment wiring, if present, matches installation application.
3. Ensure that all operator devices are in the OFF position. Panel doors closed, or a cover-mounted.
4. Apply power to the unit. DO NOT start the frequency converter now. For units with a disconnect switch, turn to the ON position to apply power to the frequency converter.

4.3 Basic Operational Programming

Frequency converters require basic operational programming before running for best performance. Basic operational programming requires entering motor nameplate data for the motor being operated and the minimum and maximum motor speeds. Parameter settings recommended are intended for start-up and checkout purposes. Application settings may vary. See *chapter 5.1 Keypad* for detailed instructions on entering data through the keypad.

Enter data in accordance with the following procedure.

1. Press [Quick Menu] on the keypad.
2. Use the navigation keys to scroll to Quick Start.
3. Press [OK].

4. Select language and press [OK]. Then enter the motor data in parameters P-02, P-03, P-06, P-07, F-04, and F-05. The information can be found on the motor nameplate.

*Parameter P-07 Motor Power [kW] or
parameter P-02 Motor Power [HP]*

Parameter F-05 Motor Rated Voltage

Parameter F-04 Base Frequency

Parameter P-03 Motor Current

Parameter P-06 Base Speed

5. Enter *parameter F-01 Frequency Setting 1* and press [OK].
6. Enter *parameter F-02 Operation Method*. Local, Remote, or Linked to Hand/Auto. In local mode the reference is entered on the keypad, and in remote that reference is sourced depending on *parameter F-01 Frequency Setting 1*.
7. Enter the accel/decel time in *parameter F-07 Accel Time 1* and *parameter F-08 Decel Time 1*.
8. For *parameter F-10 Electronic Overload*, enter Elec OL Trip 1 for Class 20 overload protection. For further information, see *chapter 3.4.1 Requirements*.
9. For *parameter F-17 Motor Speed High Limit [RPM]* or *parameter F-15 Motor Speed High Limit [Hz]*, enter the application requirements.
10. For *parameter F-18 Motor Speed Low Limit [RPM]* or *parameter F-16 Motor Speed Low Limit [Hz]*, enter the application requirements.
11. Set *parameter H-08 Reverse Lock* to Clockwise, Counterclockwise or Both directions.
12. In *parameter P-04 Auto Tune*, select Reduced Auto Tune or Full Auto Tune and follow on-screen instructions.

4.4 Auto Tune

Auto tune is a test procedure that measures the electrical characteristics of the motor to optimize compatibility between the frequency converter and the motor.

- The frequency converter builds a mathematical model of the motor for regulating output motor current. The procedure also tests the input phase balance of electrical power. It compares the motor characteristics with the data entered in P-0#.
- It does not cause the motor to run or harm to the motor.



- Some motors may be unable to run the complete version of the test. In that case, select [2] *Reduced Auto Tune*.
- If an output filter is connected to the motor, select [2] *Reduced Auto Tune*.
- If warnings or alarms occur, see *chapter 7 Warnings and Alarm*
- Run this procedure on a cold motor for best results.

4.5 Check Motor Rotation

Before running the frequency converter, check the motor rotation.

1. Press [Hand].
2. Press [▲] for positive speed reference.
3. Check that the speed shown is positive.
4. Verify that the wiring between the frequency converter and the motor is correct.
5. Verify that the motor running direction matches the setting in *parameter H-48 Clockwise Direction*.
 - 5a When *parameter H-48 Clockwise Direction* is set to [0] *Normal* (default clockwise):
 - a. Verify that the motor turns clockwise.
 - b. Verify that the keypad direction arrow is clockwise.
 - 5b When *parameter H-48 Clockwise Direction* is set to [1] *Inverse* (counterclockwise):
 - a. Verify that the motor turns counterclockwise.
 - b. Verify that the keypad direction arrow is counterclockwise.

4.6 Local-control Test

CAUTION

MOTOR START!

Ensure that the motor, system, and any attached equipment are ready for start. It is the responsibility of the user to ensure safe operation under any operational condition. Failure to ensure that the motor, system, and any attached equipment are ready for start could result in personal injury or equipment damage.

NOTICE

The Hand key on the keypad provides a local start command to the frequency converter. The [Off] key provides the stop function.

When operating in local mode, the up and down keys on the keypad increase and decrease the speed output of the drive. The left and right keys move the display cursor in the numeric display.

1. Press [Hand].
2. Accelerate the frequency converter by pressing [▲] to full speed. Moving the cursor left of the decimal point provides quicker input changes.
3. Note any acceleration problems.
4. Press [Off].
5. Note any deceleration problems.

If acceleration problems were encountered:

- If warnings or alarms occur, see *chapter 7 Warnings and Alarm*
- Check that motor data is entered correctly
- Increase the ramp time in *parameter F-07 Accel Time 1*
- Increase current limit in *parameter F-43 Current Limit*
- Increase torque limit in *parameter F-40 Torque Limiter (Driving)*

If deceleration problems were encountered:

- If warnings or alarms occur, see *chapter 7 Warnings and Alarm*.
- Check that motor data is entered correctly.
- Increase the ramp time in *parameter F-08 Decel Time 1*.
- Enable overvoltage control in *parameter B-17 Over-voltage Control*.

See *chapter 7.4 Warning and Alarm Definitions* for resetting the frequency converter after a trip.

NOTICE

Chapter 4.1 Pre-start through *chapter 4.6 Local-control Test* in this chapter conclude the procedures for applying power to the frequency converter, basic programming, set-up, and functional testing.



4.7 System Start Up

The procedure in this section requires user-wiring and application programming to be completed. The following procedure (step 1–6) is recommended after application set-up by the user is completed.

CAUTION

MOTOR START!

Ensure that the motor, system, and any attached equipment are ready for start. It is the responsibility of the user to ensure safe operation under any operational condition. Failure to ensure that the motor, system, and any attached equipment are ready for start could result in personal injury or equipment damage.

1. Press [Auto].
2. Ensure that external control functions are properly wired to the frequency converter and all programming completed.
3. Apply an external run command.
4. Adjust the speed reference throughout the speed range.
5. Remove the external run command.
6. Note any problems.

If warnings or alarms occur, see *chapter 7 Warnings and Alarm*.

4.8 Battery Back-up

4.8.1 Introduction

Use the battery back-up function for fault-tolerant applications where a load that has a variable torque characteristic over the whole speed range needs continuous operation when AC mains is lost and it is acceptable to operate at lower rate of output conditions.

Examples of fault-tolerant applications:

- Centrifugal pumps
- Fans

Examples of output conditions:

- Speed
- Flow
- Pressure
- Load
- Torque

If the AC mains source is lost, an interconnected DC battery source supplies power to the critical loads with no interruption.

The output current and power ratings for operation in battery back-up are summarized in *Table 4.2*:

Voltage [V]	Power size [kW (hp)]	235 V battery current limit [A _{rms}]	165 V battery current limit [A _{rms}]	235 V DC power limit ²⁾ [kW]	165 V DC power limit ²⁾ [kW]
380–480	18 (25)	40 ¹⁾	40 ¹⁾	8	6
	37 (50)	80 ¹⁾	80 ¹⁾	16	12
	75 (100)	120 ¹⁾	120 ¹⁾	25	17
	132 (200)	302 ¹⁾	302 ¹⁾	62	44
	250 (350)	535	535	110	77

Table 4.2 Power Ratings

1) Estimated based on preliminary testing

2) Assumes 0.85 power factor, $V_{Line-to-Line} = 0.612 * V_{DC}$, efficiency = 97%

4.8.2 Operating Principle

When supplied by AC mains, the frequency converter's DC link is nearly at a constant value approximately equal to the peak of the rectified line-to-line input voltage. The frequency converter's constant DC link can also be supplied by an external DC supply, in this case, a battery back-up supply. To provide an uninterrupted output, the battery back-up supply is connected to the frequency converter's DC link through a blocking diode. This connection provides a fixed minimum DC-link voltage to the source with the highest voltage providing power to the load, and no reverse power flows back to the battery back-up supply.

Operating modes

- Normal operation: AC source is present and the motor runs at variable speed controlled by its dedicated frequency converter. It can reach its nominal performances.
- Degraded operation: AC source is lost and the emergency DC source from batteries allows continuous running of the motor at part load without any interruption.
- Back to normal operation: AC source is restored and the motor resumes normal operation without any interruption.



4.8.3 Programming

4.8.3.1 Preparation

To configure frequency converter for battery back-up operation, complete the following tasks:

- Apply nominal 3-phase mains voltage to the frequency converter.
- Check the motor phase.
- In hand-on mode, set the frequency to a low positive value, for example +3 Hz.
- Make sure that the motor rotates in the positive direction. If it rotates in the negative direction, exchange the motor phases.
- Remove all signals to inputs.
- Press [Off] on the keypad.
- Restore the frequency converter in *parameter H-03 Restore Factory Settings*.
- Perform an auto tune.

4.8.3.2 Basic Settings

- Enable emergency power mode in *parameter SF-40 Emergency Power Mode*.
- Set the motor speed limit for high battery in *parameter SF-41 Speed Limit, High Battery [RPM]* or *parameter SF-42 Speed Limit, High Battery [Hz]*.
- Set the motor speed limit for low battery in *parameter SF-43 Speed Limit, Low Battery [RPM]* or *parameter SF-44 Speed Limit, Low Battery [Hz]*.
- Set the motor current limit for high battery in *parameter SF-45 Current Limit, High Battery*.
- Set the motor current limit for low battery in *parameter SF-46 Current Limit, Low Battery*.

The speed limits and current limits for high and low battery voltages are linear between the 2 setpoints. This allows the output to be automatically limited based on the measured battery voltage as it discharges over time.

In addition to the emergency mode specific parameters configured above, set the following parameters to ensure proper DC battery operation:

- To avoid output current oscillations at low voltage set *parameter F-38 Overmodulation* to [0] Off.
- To achieve the best output current regulation, set *parameter H-41 Motor Control Principle* to [2] Flux Sensorless or [3] Flux w/ motor feedback.
- To avoid nuisance current limit warnings at start-up, reduce *parameter H-66 Min. Current at Low Speed*.
- Set *parameter SP-10 Line failure* to [0] No function.

The frequency converter status can be monitored using the additional readout parameters of *parameter DR-42 Actual Current Limit [A]* and *parameter DR-43 Actual Speed Limit [RPM]* and *parameter DR-44 Actual Speed Limit*.

The emergency mode status can also be used to configure digital outputs, provide emergency mode indication in *parameter O-13 Configurable Status Word STW*, and can be used in the built-in logic controller in *parameter LC-10 Comparator Operand*.

4.8.4 Parameters for Battery Back-up Application

SF-40 Emergency Power Mode

Emergency power mode allows the frequency converter to run with reduced power capabilities from an emergency power supply.

Option: **Function:**

[0] *	Disabled	
[1]	Enabled	

SF-41 Speed Limit, High Battery [RPM]

Range: **Function:**

3600 RPM*	[0.0-par.F-17 RPM]	The speed limit that takes effect when the frequency converter is operating in emergency power supply mode and the battery voltage is at its highest value.
-----------	--------------------	---

SF-42 Speed Limit, High Battery [Hz]

Range: **Function:**

120.0 Hz*	[0.0-par.F-15 Hz]	The speed limit that takes effect when the frequency converter is operating in emergency power supply mode and the battery voltage is at its highest value.
-----------	-------------------	---

SF-43 Speed Limit, Low Battery [RPM]

Range: **Function:**

3600 RPM*	[0.0-par.SF-41 RPM]	The speed limit that takes effect when the frequency converter is operating in emergency power supply mode and the battery voltage is at its lowest value.
-----------	---------------------	--

SF-44 Speed Limit, Low Battery [Hz]

Range: **Function:**

120.0 Hz*	[0.0-par.SF-42 Hz]	The speed limit that takes effect when the frequency converter is operating in emergency power supply mode and the battery voltage is at its lowest value.
-----------	--------------------	--



SF-45 Current Limit, High Battery [A]

Range:		Function:
Power Size Dependent A*	[0.0-Power Size Dependent A]	The output current limit that takes effect when the frequency converter is operating in emergency power supply mode and the battery voltage is at its highest value.

SF-46 Current Limit, Low Battery [A]

Range:		Function:
Power Size Dependent A*	[0.0-SF-45 A]	The current limit that takes effect when the frequency converter is operating in emergency power supply mode and the battery voltage is at its lowest value.

DR-42 Actual Current Limit [A]

Range:		Function:
0.0 A*	[0.0-10000.0 A]	The actual active motor current limit in Amps.

DR-43 Actual Speed Limit [RPM]

Range:		Function:
3600 RPM*	[0.0-10000.0 A]	The actual active motor speed limit in RPM.

DR-44 Actual Speed Limit [Hz]

Range:		Function:
120.0 Hz*	[0.0-10000.0 A]	The actual active motor speed limit in Hz.

4.8.5 Updates to Existing Parameters

The emergency mode state is added to the list of available items to assign to digital outputs, for example terminals 27 and 29, relay 1, relay 2 and so on.

Range:		Function:
200*	[Emergency Mode]	The value is high when the frequency converter is in the emergency power mode state.

The emergency mode state is also added to the list of available options for:

O-13 Configurable Status Word STW

Range:		Function:
93*	[Emergency Mode]	Allows bit 5 and bits 12–15 to be set as high when the frequency converter is in the emergency power mode state.

LC-10 Comparator Operand

Range:		Function:
213*	[Emergency Mode]	The value is high when the frequency converter is in the emergency power mode state.

4.8.6 External Equipment and Component Sizing Considerations

4.8.6.1 DC Fuse and Isolation Diode Sizing

To protect the DC bus against short circuits and the frequency converters from overload, install fuses in series with the load sharing terminals of all connected units.

NOTICE

Respect the following guidelines when dimensioning the DC bus fuses.

- The voltage class of the fuse must be able to handle the maximum DC bus voltage ($1.35 \times U_{LL}$)
- The fuse must be a fast semiconductor type, for example aR or gR.
- The maximum fuse current rating must not exceed the mains fuse current rating for the individual frequency converter
 $(I_{fuse, DC-link, max} \leq I_{fuse, mains})$

The recommended DC bus fuses are based on equation 1 and the fuse is selected up 1 size after rounding up to the next available fuse size. The nominal voltage, U_{LL} , is reduced by 10% as a worst case scenario in the calculation to allow for tolerances.

Equation 1: Calculation of DC bus fuse - AC mains

$$I_{DC} = \frac{P_{in}}{U_{DC}} = \frac{P_{in}}{1.35 \times U_{LL,n} \times 0.9}$$

Equation 2: Calculation of DC bus fuse - battery

If the maximum power supplied when running on the DC battery is less than calculated power at full mains voltage, the DC fuses may be decreased. Using a calculated frequency converter output power and an assumed frequency converter efficiency of 97%:

$$I_{DC} = \frac{P_{out}}{U_{DC} \times \eta} = \frac{P_{out}}{U_{Battery} \times 0.97}$$

Remember to round up 1 size after rounding up to the next available fuse size and to calculate over the entire DC battery operating range.

Example: For equation 1 - $U_{LL}=400$ V and $P_{in}=90$ kW gives $I_{DC}=185.2$ A.

Equation 2 for $U_{Battery}=235$ V and $P_{out}=39.6$ kW gives $I_{DC}=173.7$ A.

For both cases, the next available fuse size is aR-200, hence aR-250 is selected.


NOTICE

The recommendations are for ambient temperatures of around 20 °C (68 °F). At 40 °C (104 °F) gR/aR fuses are rounded 1 size further up, that is, rounded up to the nearest fuse size and 2 further sizes up. For high ambient temperatures, contact the fuse supplier.

The isolation diode voltage and current considerations are calculated similar to the DC fuse. The diode should be sized for the maximum DC-link voltage and the maximum DC current.

4.8.6.2 DC Inrush Considerations

Take care when connecting the DC battery to the frequency converter to avoid potential inrush currents which may damage the frequency converter, the isolation diode, or clear the fuses. One possible strategy is shown in *Illustration 4.1*.



1308F073.10

Illustration 4.1 Example DC Battery Connection

The frequency converter has a large DC-link capacitance that must be charged. The charge current for a successful charge-up is a decreasing exponential waveform.

The soft charge resistance should be selected to provide an appropriate charge-up time of approximately 5 times the RxC time constant of the circuit.

To calculate the effective RMS charge current that the soft charge resistor sees, use the following equations:

Equation 3: Calculation of soft charge resistor current

$$I_{RMS} = \sqrt{\frac{1}{T} \left(\frac{V_{DC}}{R_{charge}} \right)^2 \times (1 - e^{-2t/\tau})}$$

Example: RMS current for 2 s of charging with a 235 V DC link, 90 Ω soft charge resistor, 4.05 mF capacitor bank: $\tau = R \times C = 0.3645$ s.

Equation 4: Example soft charge resistor current

$$I_{RMS} = \sqrt{\frac{1}{2} \left(\frac{235}{90} \right)^2 \times \frac{0.3645}{2} \times (1 - e^{-4/0.3645})} = 0.79 \text{ A}$$

Resistor power required: $P_R = I^2 \times R = 56 \text{ W}$



4.8.7 Motor Operation with Reduced DC-link Voltage Considerations

Notes

- A frequency converter is able to output a maximum 3-phase, line-to-line voltage which is approximately equal to 70% of its DC-link voltage. For example, a 570 V DC link can output a 400 V AC line-to-line voltage.
- An induction machine's torque capability is proportional to the square of its input voltage.
- If the ratio of frequency converter output voltage to frequency is kept constant (constant flux operation), the motor torque is proportional to phase current.
- If a speed is required which exceeds the constant flux capability of the frequency converter (see bullet 1 and bullet 3), the motor is now operated in the field weakening range.
- In the field weakening range, the slip for a given load may be larger than the slip for that same operating point in the constant flux range.
- An asynchronous motor's rotor losses are equal to the equal to the motor's slip multiplied with the air gap power. In the field weakening range, this may be much larger than the rated rotor losses.
- Do not exceed the motor's operating limits, especially if motor cooling is a function of its operating speed.

5 User Interface

5.1 Keypad

The keypad is the combined display and keys on the front of the unit. The keypad is the user interface to the frequency converter.

The keypad has several user functions:


- Start, stop, and control speed when in local control
- Show operational data, status, warnings, and cautions
- Programming frequency converter functions
- Manually reset the frequency converter after a fault when auto reset is inactive

NOTICE

The display contrast can be adjusted by pressing [Status] and [▲]/[▼] keys.

5.1.1 Keypad Layout

The keypad is divided into 4 functional groups (see *Illustration 5.1*).



a	Display area.
b	Display menu keys for changing the display to show status options, programming, or error message history.
c	Navigation keys for programming functions, moving the display cursor, and speed control in local operation. The status indicator lights are also in this group.
d	Operational mode keys and reset.

Illustration 5.1 Keypad




5.1.2 Setting Keypad Display Values

The display area is activated when the frequency converter receives power from mains voltage, a DC bus terminal, or an external 24 V supply.

The information shown on the keypad can be customized for user application.

- Each display readout has a parameter associated with it.
- Options are selected in main menu K-2#
- The frequency converter status at the bottom line of the display is generated automatically and is not selectable.



Display	Parameter number	Default setting
1.1	K-20	Speed [RPM]
1.2	K-21	Motor Current
1.3	K-22	Power [kW]
2	K-23	Frequency
3	K-24	Reference [%]

Table 5.1

Illustration 5.2 Keypad Display Values

5.1.3 Display Menu Keys

Menu keys are used for menu access for parameter set-up, toggling through status display modes during normal operation, and viewing fault log data.



Illustration 5.3 Menu Keys

Key	Function
Status	Press to show operational information. <ul style="list-style-type: none"> • Press repeatedly to scroll through each status display • Press and hold [Status] plus [▲] or [▼] to adjust the display brightness • The symbol in the upper right corner of the display shows the motor rotation direction and which set-up is active. This is not programmable.
Quick Menu	Allows access to programming parameters for initial set-up instructions and many detailed application instructions. <ul style="list-style-type: none"> • Press to access <i>Quick Start</i> for sequenced instructions to program the basic frequency controller set-up • Press to access <i>Trending</i> for realtime logging on keypad display. • Press to access <i>Parameter Data Check</i> for changes in parameter data set. • Follow the sequence of parameters as presented for the function set-up
Main Menu	Allows access to all programming parameters. <ul style="list-style-type: none"> • Press twice to access top-level index • Press once to return to the last location accessed • Press and hold to enter a parameter number for direct access to that parameter
Alarm Log	Shows a list of current warnings, the last 5 alarms, and the maintenance log. <ul style="list-style-type: none"> • For details about the frequency converter before it entered the alarm mode, select the alarm number using the navigation keys and press [OK].

Table 5.2 Legend to Illustration 5.3

User Interface

5.1.4 Navigation Keys

Navigation keys are used for programming functions and moving the display cursor. The navigation keys also provide speed control in local (hand) operation. There are also 3 frequency converter status indicator lights in this area.




Illustration 5.4 Navigation Keys

Key	Function
Back	Reverts to the previous step or list in the menu structure.
Cancel	Cancels the last change or command as long as the display mode has not changed.
Info	Press for a definition of the function being shown.
Navigation Keys	Press the 4 navigation keys to move between items in the menu.
OK	Press to access parameter groups or to enable a choice.

Table 5.3 Navigation Keys Functions

Light	Indicator	Function
Green	ON	The ON light activates when the frequency converter receives power from mains voltage, a DC bus terminal, or a 24 V external supply.
Yellow	WARN	When warning conditions are met, the yellow WARN light comes on and text appears in the display area identifying the problem.
Red	ALARM	A fault condition causes the red alarm light to flash and an alarm text is shown.

Table 5.4 Indicator Lights Functions

5.1.5 Operation Keys

Operation keys are located at the bottom of the keypad.




Illustration 5.5 Operation Keys

Key	Function
Hand	Starts the frequency converter in local control. <ul style="list-style-type: none"> Use the navigation keys to control frequency converter speed. An external stop signal by control input or serial communication overrides the local hand.
Off	Stops the motor, but does not remove power to the frequency converter.
Auto	Puts the system in remote operational mode. <ul style="list-style-type: none"> Responds to an external start command by control terminals or serial communication. Speed reference is from an external source.
Reset	Resets the frequency converter manually after a fault has been cleared.

Table 5.5 Operation Keys Functions

5.2 Back-up and Copying Parameter Settings

Programming data is stored internally in the frequency converter.

- The data can be uploaded into the keypad memory as storage back-up.
- Once stored in the keypad, the data can be downloaded back into the frequency converter.
- Data can also be downloaded into other frequency converters by connecting the keypad into those units and downloading the stored settings. (This is a quick way to program multiple units with the same settings).
- Restoring of the frequency converter to restore factory default settings does not change data stored in the keypad memory.

**WARNING****UNINTENDED START**

When the frequency converter is connected to AC mains, or DC power supply, the motor may start at any time. Unintended start during programming, service, or repair work can result in death, serious injury, or property damage. The motor can start with an external switch, a serial bus command, an input reference signal from the keypad, or after a cleared fault condition.

To prevent unintended motor start:

- Disconnect the frequency converter from mains.
- Press [Off/Reset] on the keypad, before programming parameters.
- The frequency converter, motor, and any driven equipment must be fully wired and assembled when the frequency converter is connected to AC mains, or DC power supply.

5.2.1 Uploading data to the keypad

1. Press [Off] to stop the motor before uploading or downloading data.
2. Go to *parameter K-50 Keypad Copy*.
3. Press [OK].
4. Select [1] *All to keypad*.
5. Press [OK]. A progress bar shows the uploading process.
6. Press [Hand] or [Auto] to return to normal operation.

5.2.2 Downloading Data from the Keypad

1. Press [Off] to stop the motor before uploading or downloading data.
2. Go to *parameter K-50 Keypad Copy*.
3. Press [OK].
4. Select [2] *All from keypad*.
5. Press [OK]. A progress bar shows the downloading process.
6. Press [Hand] or [Auto] to return to normal operation.

5.3 Restoring Default Settings

NOTICE

Restore sets the unit to factory default settings. Any programming, motor data, localization, and monitoring records are lost. Uploading data to the keypad provides a back-up before restoring.

Restoring the frequency converter parameter settings back to default values is done by restoring of the frequency converter. Restoring can be carried out via *parameter H-03 Restore Factory Settings* or manually.

- Restoring using *parameter H-03 Restore Factory Settings* does not change frequency converter data such as hours run, serial communication selections, personal menu settings, fault log, alarm log, and other monitoring functions.
- Using *parameter H-03 Restore Factory Settings* is recommended.
- Manual restore erases all motor, programming, localization, and monitoring data and restores factory default settings.

5.3.1 Recommended Restoring

1. Press [Main Menu] twice to access parameters.
2. Scroll to *parameter H-03 Restore Factory Settings*.
3. Press [OK].
4. Scroll to [2] *Restore Factory Settings*.
5. Press [OK].
6. Remove power to the unit and wait for the display to turn off.
7. Apply power to the unit.

Default parameter settings are restored during start-up. This may take slightly longer than normal.

8. Alarm 80 is shown.
9. Press [Reset] to return to operation mode.

5.3.2 Manual Restoring

1. Remove power to the unit and wait for the display to turn off.
2. Press and hold [Status], [Main Menu], and [OK] at the same time and apply power to the unit.

Factory default parameter settings are restored during start-up. This may take slightly longer than normal.

Manual restoring does not reset the following frequency converter information:

- *Parameter ID-00 Operating hours*
- *Parameter ID-03 Power Up's*
- *Parameter ID-04 Over Temp's*
- *Parameter ID-05 Over Volt's*



6 Parameter Menu Structure

6.1 Main Menu Structure



K-0# Language	K-01 Motor Thermistor Input	E-21 Terminal 29 Digital Output	C-34 Frequency Command 3	H-40 Configuration Mode
K-01 Key Pad Basic Settings	F-15 Motor Speed High Limit [Hz]	E-24 Function Relay	P-0# Motor Data	H-41 Motor Control Principle
K-02 Language	F-16 Motor Speed Low Limit [Hz]	E-26 On Delay, Relay	P-01 Motor Poles	H-42 Flux Motor Feedback Source
K-03 Regional Settings	F-17 Motor Speed High Limit [RPM]	E-27 Off Delay, Relay	P-02 Motor Power [HP]	H-43 Torque Characteristics
K-04 Operating State at Power-up	F-18 Motor Speed Low Limit [RPM]	E-5# I/O Mode / Add On I/O	P-03 Motor Current	H-44 Constant or Variable Torque OL
K-1# Key Pad Set-up Operations	F-2# Fundamental 2	E-51 Terminal 27 Mode	P-04 Auto Tune	H-45 Local Mode Configuration
K-01 Key Pad Set-up Operations	F-20 PM Start Mode	E-52 Terminal 29 Mode	P-05 Motor Cont. Rated Torque	H-46 Back EMF at 1000 RPM
K-10 Active Set-up	F-22 Start Speed [RPM]	E-53 Terminal X30/2 Digital Input	P-06 Base Speed	H-47 Motor Angle Offset
K-11 Edit Set-up	F-23 Start Speed [Hz]	E-54 Terminal X30/3 Digital Input	P-07 Motor Power [kW]	H-48 Clockwise Direction
K-12 This Set-up Linked to	F-24 Holding Time	E-56 Terminal X30/4 Digital Input	P-09 Slip Compensation	H-49 Clockwise Direction
K-13 Readout: Linked Set-ups	F-25 Start Function	E-57 Term X30/6 Digi Out (OPCGPIO)	P-10 Slip Compensation Time Constant	H-5# Load Indep. Settings
K-14 Readout: Actual Set-ups / Channel	F-26 Motor Noise (Carrier Freq)	E-6# Term X30/7 Digi Out (OPCGPIO)	P-2# Motor Selection	H-50 Motor Magnetisation at Zero Speed
K-2# Key Pad Display	F-27 Motor Tone Random	E-60 Term. 29 Low Frequency	P-20 Motor Construction	H-51 Min Speed Normal Magnetising [RPM]
K-20 Display Line 1,1 Small	F-28 Dead Time Compensation	E-61 Term. 29 High Frequency	P-24 Damping Gain	H-52 Min Speed Normal Magnetising [Hz]
K-21 Display Line 1,2 Small	F-29 Start Current	E-62 Term. 29 Low Ref./Feedb. Value	P-25 Low Speed Filter Time Const.	H-53 Model Shift Frequency
K-22 Display Line 1,3 Small	F-3# Fundamental 3	E-63 Term. 29 High Ref./Feedb. Value	P-26 High Speed Filter Time Const.	H-54 Voltage reduction in fieldweakening
K-23 Display Line 2 Large	F-33 Source for User-defined Readout	E-64 Pulse Filter Time Constant #29	P-27 Voltage filter time const.	H-55 U/f Characteristic - U
K-24 Display Line 3 Large	F-37 Adv. Switching Pattern	E-66 Term. 33 Low Frequency	P-28 Min. Current at No Load	H-56 U/f Characteristic - F
K-25 Quick Start	F-38 Overmodulation	E-67 Term. 33 High Frequency	P-3# Adv. Motor Data	H-59 Flying Start Test Pulses Frequency
K-3# Key Pad Custom Readout	F-40 Torque Limiter (Driving)	E-68 Term. 33 Low Ref./Feedb. Value	P-30 Stator Resistance (Rs)	H-6# Load Depen. Settings
K-30 Unit for Custom Readout	F-41 Torque Limiter (Braking)	E-69 Term. 33 High Ref./Feedb. Value	P-31 Rotor Resistance (Rr)	H-61 High Speed Load Compensation
K-31 Min Value of Custom Readout	F-43 Current Limit	E-7# Pulse Output	P-33 Stator Leakage Reactance (Xl)	H-62 Brake Check Limit Factor Source
K-32 Max Value of Custom Readout	F-4# Extended References	E-70 Terminal 27 Pulse Output Variable	P-34 Rotor Leakage Reactance (X2)	H-63 Brake Check Limit Factor
K-37 Display Text 1	F-50 Reference Range	E-72 Pulse Output Max Freq #27	P-35 Main Reactance (Xh)	H-64 Resonance Dampening
K-38 Display Text 2	F-51 Reference/Feedback Unit	E-73 Terminal 29 Pulse Output Variable	P-36 Iron Loss Resistance (Rfe)	H-65 Resonance Dampening Time Constant
K-39 Display Text 3	F-52 Minimum Reference	E-75 Terminal X30/6 Pulse Output Variable	P-37 d-axis Inductance (Ld)	H-66 Min. Current at Low Speed
K-4# Key Pad Buttons	F-53 Maximum Reference	E-76 Terminal X30/6 Pulse Output Variable	P-38 q-axis Inductance (Lq)	H-67 Torque Limit Factor Source
K-40 [Hand] Button on Keypad	F-5# References	E-78 Pulse Output Max Freq #X30/6	P-45 q-axis Inductance Sat. (LqSat)	H-7# Adjustable Warnings
K-41 [Off] Button on Keypad	F-62 Catch up/slow Down Value	E-8# 24V Encoder Input	P-46 Position Detection Gain	H-70 Warning Current Low
K-42 [Auto] Button on Keypad	F-64 Preset Relative Reference	E-80 Term 32/33 Pulses Per Revolution	P-47 Torque Calibration	H-71 Warning Current High
K-43 [Reset] Button on Keypad	F-68 Relative Scaling Reference Resource	E-81 Term 32/33 Encoder Direction	P-48 Inductance Sat. Point	H-72 Warning Speed Low
K-5# Copy/Save	F-9# Digital Potentiometer	E-90 Digital & Relay Bus Control	H-# High Perf Parameters	H-73 Warning Speed High
K-50 Keypad Copy	F-90 Step Size	E-93 Pulse Out #27 Bus Control	H-01 Option Detection	H-74 Warning Reference Low
K-51 Set-up Copy	F-91 Accel/Decel Time	E-94 Pulse Out #29 Bus Control	H-02 Option Data Storage	H-75 Warning Reference High
K-6# Password Protection	F-92 Power Restore	E-95 Pulse Out #29 Timeout Preset	H-03 Restore Factory Settings	H-76 Warning Feedback Low
K-60 Main Menu Password	F-94 Maximum Limit	E-96 Pulse Out #29 Timeout Preset	H-04 Auto-Reset (Times)	H-77 Warning Feedback High
K-61 Access to Main Menu w/o Password	F-95 Accel/Decel Ramp Delay	E-97 Pulse Out #X30/6 Bus Control	H-05 Auto-Reset (Reset Interval)	H-78 Missing Motor Phase Function
K-65 Quick Menu Password	E-# Digital In/Out	E-98 Pulse Out #X30/6 Timeout Preset	H-07 Accel/Decel Time 1 Type	H-8# Stop Adjustments
K-66 Access to Quick Menu w/o Password	E-0# Digital Inputs	C-# Frequency Control Functions	H-08 Reverse Lock	H-80 Function at Stop
K-67 Bus Password Access	E-00 Digital I/O Mode	C-0# Frequency Control Functions	H-09 Start Mode	H-81 Min Speed for Function at Stop [RPM]
F-# Parameter Data Set	E-01 Terminal 18 Digital Input	C-01 Jump Frequency From [Hz]	H-2# Motor Feedback Monitoring	H-82 Min Speed for Function at Stop [Hz]
F-0# Fundamental 0	E-02 Terminal 19 Digital Input	C-02 Jump Speed From [RPM]	H-20 Motor Feedback Loss Function	H-83 Precise Stop Function
F-01 Frequency Setting 1	E-03 Terminal 27 Digital Input	C-03 Jump Speed To [RPM]	H-21 Motor Feedback Speed Error	H-84 Precise Stop Counter Value
F-02 Operation Method	E-04 Terminal 29 Digital Input	C-04 Jump Frequency To [Hz]	H-22 Motor Feedback Loss Timeout	H-85 Precise Stop Speed Compensation
F-03 Max Output Frequency 1	E-05 Terminal 32 Digital Input	C-05 Multi-step Frequency 1 - 8	H-23 Motor Check At Start	H-87 Delay
F-04 Base Frequency	E-06 Terminal 33 Digital Input	C-2# Jog Setup	H-24 Tracking Error	H-88 Motor Inertia
F-05 Motor Rated Voltage	E-07 Terminal 37 Safe Stop	C-20 Jog Speed [Hz]	H-25 Tracking Error	H-89 System Inertia
F-07 Accel Time 1	E-1# Additional Accel Decel Ramps	C-21 Jog Speed [RPM]	H-26 Tracking Error Timeout	H-9# Motor Temperature
F-08 Decel Time 1	E-10 Accel Time 2	C-22 Jog Accel/Decel Time	H-27 Tracking Error Ramping	H-94 ATEX overload cur.lim.-speed reduction
F-09 Torque Boost	E-11 Decel Time 2	C-24 Quick Stop Ramp Type	H-28 Tracking Error Ramping Timeout	H-95 KTY Sensor Type
F-1# Fundamental 1	E-12 Accel Time 3	C-25 Quick Stop Ramp Ratio	H-29 Tracking Error After Ramping Timeout	H-96 KTY Threshold level
F-10 Electronic Overload	E-13 Decel Time 3	C-26 Quick Stop S-ramp Ratio at Decel. End	H-3# Speed Monitor	H-97 KTY Threshold level
F-11 Motor External Fan	E-14 Accel Time 4	C-29 Ramp Lowpass Filter Time	H-30 Motor Speed Monitor Function	H-98 ATEX overload interpol. points freq.
	E-15 Decel Time 4	C-3# Frequency Setting 2 and 3	H-31 Motor Speed Monitor Max	H-99 ATEX overload interpol. points current
	E-20 Terminal 27 Digital Output	C-30 Frequency Command 2	H-4# Advanced Settings	



Parameter Menu Structure

6

AN-0# Analog I/O Mode	AN-00 Live Zero Timeout Time	AN-01 Line Voltage at Input Fault	AN-1# Analog Input 53	AN-10 Terminal 53 Low Voltage	AN-11 Terminal 53 High Voltage	AN-12 Terminal 53 Low Current	AN-13 Terminal 53 High Current	AN-14 Terminal 53 Low Ref./Feedb. Value	AN-15 Terminal 53 High Ref./Feedb. Value	AN-16 Terminal 53 Filter Time Constant	AN-17 Terminal 53 Live Zero	AN-2# Analog Input 54	AN-20 Terminal 54 Low Voltage	AN-21 Terminal 54 High Voltage	AN-22 Terminal 54 Low Current	AN-23 Terminal 54 High Current	AN-24 Terminal 54 Low Ref./Feedb. Value	AN-25 Terminal 54 High Ref./Feedb. Value	AN-26 Terminal 54 Filter Time Constant	AN-27 Terminal 54 Live Zero	AN-3# Analog Input X30/11	AN-30 Terminal X30/11 Low Voltage	AN-31 Terminal X30/11 High Voltage	AN-34 Term. X30/11 Low Ref./Feedb. Value	AN-35 Term. X30/11 High Ref./Feedb. Value	AN-36 Term. X30/11 Filter Time Constant	AN-37 Term. X30/11 Live Zero	AN-4# Analog Input X30/12	AN-40 Terminal X30/12 Low Voltage	AN-41 Terminal X30/12 High Voltage	AN-44 Term. X30/12 Low Ref./Feedb. Value	AN-45 Term. X30/12 High Ref./Feedb. Value	AN-46 Term. X30/12 Filter Time Constant	AN-47 Term. X30/12 Live Zero	AN-5# Analog Output 42	AN-50 Terminal 42 Output Min Scale	AN-51 Terminal 42 Output Max Scale	AN-53 Terminal 42 Output Bus Control	AN-54 Terminal 42 Output Timeout Preset	AN-6# Analog Output X30/8	AN-60 Terminal X30/8 Output	AN-61 Terminal X30/8 Min. Scale	AN-62 Terminal X30/8 Max. Scale	AN-63 Terminal X30/8 Bus Control	AN-64 Terminal X30/8 Output Timeout Preset	SF-## Battery Back-up Application	SF-40 Emergency Power Mode	SF-41 Speed Limit, High Battery [RPM]	SF-42 Speed Limit, High Battery [Hz]	SF-43 Speed Limit, Low Battery [RPM]	SF-44 Speed Limit, Low Battery [Hz]	SF-45 Current Limit, High Battery [A]	SF-46 Current Limit, Low Battery [A]	SP-## Special Functions	SP-0# Fault Settings	SP-00 Fault Level	SP-1# Line On/Off	SP-10 Line failure	SP-11 Line Voltage at Input Fault	SP-12 Function at Line Imbalance	SP-14 Kin. Backup Time Out	SP-15 Kin. Backup Trip Recovery Level	SP-16 Kin. Backup Gain	SP-2# Reset Functions	SP-23 Typecode Setting	SP-24 Trip Delay at Current Limit	SP-25 Trip Delay at Torque Limit	SP-26 Trip Delay at Drive Fault	SP-29 Service Code	SP-3# Current Limit Ctrl.	SP-30 Current Lim Contr, Proportional Gain	SP-31 Current Lim Contr, Integration Time	SP-32 Current Lim Ctrl, Filter Time	SP-35 Stall Protection	SP-36 Fieldweakening Function	SP-37 Fieldweakening Speed	SP-4# Energy Savings	SP-40 VT Level	SP-41 Energy Savings Min. Magnetisation	SP-42 Energy Savings Min. Frequency	SP-43 Motor Cosphi	SP-5# Environment	SP-50 RFI Filter	SP-51 DC Link Compensation	SP-52 Fan Operation	SP-53 Fan Monitor	SP-54 AHF Cap Reconnect Delay	SP-55 Output Filter	SP-56 Capacitance Output Filter	SP-57 Inductance Output Filter	SP-59 Actual Number of Inverter Units	SP-6# Automatic Derate	SP-7# Additional ACC/DEC settings	SP-71 Accel Time 1 S-ramp Ratio at Accel, Start	SP-72 Accel Time 1 S-ramp Ratio at Accel, End	SP-73 Decel Time 1 S-ramp Ratio at Decel, Start	SP-74 Decel Time 1 S-ramp Ratio at Decel, End	SP-76 Accel/Decel Time 2 Type	SP-79 Accel Time 2 S-ramp Ratio at Accel, Start	SP-80 Accel Time 2 S-ramp Ratio at Accel, End	SP-81 Decel Time 2 S-ramp Ratio at Decel, Start	SP-82 Decel Time 2 S-ramp Ratio at Decel, End	SP-84 Accel/Decel Ramp 3 Type	SP-87 Accel Time 3 S-ramp Ratio at Accel, Start	SP-00 Fault Level	SP-1# Line On/Off	SP-10 Line failure	SP-11 Line Voltage at Input Fault	SP-12 Function at Line Imbalance	SP-14 Kin. Backup Time Out	SP-15 Kin. Backup Trip Recovery Level	SP-16 Kin. Backup Gain	SP-2# Reset Functions	SP-23 Typecode Setting	SP-24 Trip Delay at Current Limit	SP-25 Trip Delay at Torque Limit	SP-26 Trip Delay at Drive Fault	SP-29 Service Code	SP-3# Current Limit Ctrl.	SP-30 Current Lim Contr, Proportional Gain	SP-31 Current Lim Contr, Integration Time	SP-32 Current Lim Ctrl, Filter Time	SP-35 Stall Protection	SP-36 Fieldweakening Function	SP-37 Fieldweakening Speed	SP-4# Energy Savings	SP-40 VT Level	SP-41 Energy Savings Min. Magnetisation	SP-42 Energy Savings Min. Frequency	SP-43 Motor Cosphi	SP-5# Environment	SP-50 RFI Filter	SP-51 DC Link Compensation	SP-52 Fan Operation	SP-53 Fan Monitor	SP-54 AHF Cap Reconnect Delay	SP-55 Output Filter	SP-56 Capacitance Output Filter	SP-57 Inductance Output Filter	SP-59 Actual Number of Inverter Units	SP-6# Automatic Derate	SP-7# Additional ACC/DEC settings	SP-71 Accel Time 1 S-ramp Ratio at Accel, Start	SP-72 Accel Time 1 S-ramp Ratio at Accel, End	SP-73 Decel Time 1 S-ramp Ratio at Decel, Start	SP-74 Decel Time 1 S-ramp Ratio at Decel, End	SP-76 Accel/Decel Time 2 Type	SP-79 Accel Time 2 S-ramp Ratio at Accel, Start	SP-80 Accel Time 2 S-ramp Ratio at Accel, End	SP-81 Decel Time 2 S-ramp Ratio at Decel, Start	SP-82 Decel Time 2 S-ramp Ratio at Decel, End	SP-84 Accel/Decel Ramp 3 Type	SP-87 Accel Time 3 S-ramp Ratio at Accel, Start
SP-88 Accel Time 3 S-ramp Ratio at Accel, End	SP-89 Decel Time 3 S-ramp Ratio at Decel, Start	SP-90 Decel Time 3 S-ramp Ratio at Decel, End	SP-92 Accel/Decel Ramp 4 Type	SP-95 Accel Time 4 S-ramp Ratio at Accel, Start	SP-96 Accel Time 4 S-ramp Ratio at Accel, End	SP-97 Decel Time 4 S-ramp Ratio at Decel, Start	SP-98 Decel Time 4 S-ramp Ratio at Decel, End	O-## Options / Comms	O-0# General Settings	O-01 Control Site	O-02 Control Word Source	O-03 Control Word Timeout Time	O-04 Control Word Timeout Function	O-05 End-of-Timeout Function	O-06 Reset Control Word Timeout	O-07 Diagnosis Trigger	O-08 Readout Filtering	O-1# Control Settings	O-10 Control Word Profile	O-13 Configurable Status Word STW	O-14 Configurable Control Word CTW	O-16 Store Data Values	O-17 Configurable Alarm and Warningword Product Code	O-3# Drive Port Settings	O-30 Protocol	O-31 Address	O-32 Drive Port Baud Rate	O-33 Drive Port Parity	O-34 Estimated cycle time	O-35 Minimum Response Delay	O-36 Max Inter-Char Delay	O-37 Max Inter-Char Delay	O-4# Drive MC Port Settings	O-40 Telegram Selection	O-41 Parameters for Signals	O-42 PCD Write Configuration	O-43 PCD Read Configuration	O-5# Digital / Bus	O-50 Coasting Select	O-51 Quick Stop Select	O-52 DC Brake Select	O-53 Start Select	O-54 Reversing Select	O-55 Set-up Select	O-56 Preset Reference Select	O-57 Profdrive OFF2 Select	O-58 Profdrive OFF3 Select	O-8# Drive Port Diagnostics	O-80 Bus Message Count	O-81 Bus Error Count																																																																																																							
SP-88 Accel Time 3 S-ramp Ratio at Accel, End	SP-89 Decel Time 3 S-ramp Ratio at Decel, Start	SP-90 Decel Time 3 S-ramp Ratio at Decel, End	SP-92 Accel/Decel Ramp 4 Type	SP-95 Accel Time 4 S-ramp Ratio at Accel, Start	SP-96 Accel Time 4 S-ramp Ratio at Accel, End	SP-97 Decel Time 4 S-ramp Ratio at Decel, Start	SP-98 Decel Time 4 S-ramp Ratio at Decel, End	O-## Options / Comms	O-0# General Settings	O-01 Control Site	O-02 Control Word Source	O-03 Control Word Timeout Time	O-04 Control Word Timeout Function	O-05 End-of-Timeout Function	O-06 Reset Control Word Timeout	O-07 Diagnosis Trigger	O-08 Readout Filtering	O-1# Control Settings	O-10 Control Word Profile	O-13 Configurable Status Word STW	O-14 Configurable Control Word CTW	O-16 Store Data Values	O-17 Configurable Alarm and Warningword Product Code	O-3# Drive Port Settings	O-30 Protocol	O-31 Address	O-32 Drive Port Baud Rate	O-33 Drive Port Parity	O-34 Estimated cycle time	O-35 Minimum Response Delay	O-36 Max Inter-Char Delay	O-37 Max Inter-Char Delay	O-4# Drive MC Port Settings	O-40 Telegram Selection	O-41 Parameters for Signals	O-42 PCD Write Configuration	O-43 PCD Read Configuration	O-5# Digital / Bus	O-50 Coasting Select	O-51 Quick Stop Select	O-52 DC Brake Select	O-53 Start Select	O-54 Reversing Select	O-55 Set-up Select	O-56 Preset Reference Select	O-57 Profdrive OFF2 Select	O-58 Profdrive OFF3 Select	O-8# Drive Port Diagnostics	O-80 Bus Message Count	O-81 Bus Error Count																																																																																																							
SP-88 Accel Time 3 S-ramp Ratio at Accel, End	SP-89 Decel Time 3 S-ramp Ratio at Decel, Start	SP-90 Decel Time 3 S-ramp Ratio at Decel, End	SP-92 Accel/Decel Ramp 4 Type	SP-95 Accel Time 4 S-ramp Ratio at Accel, Start	SP-96 Accel Time 4 S-ramp Ratio at Accel, End	SP-97 Decel Time 4 S-ramp Ratio at Decel, Start	SP-98 Decel Time 4 S-ramp Ratio at Decel, End	O-## Options / Comms	O-0# General Settings	O-01 Control Site	O-02 Control Word Source	O-03 Control Word Timeout Time	O-04 Control Word Timeout Function	O-05 End-of-Timeout Function	O-06 Reset Control Word Timeout	O-07 Diagnosis Trigger	O-08 Readout Filtering	O-1# Control Settings	O-10 Control Word Profile	O-13 Configurable Status Word STW	O-14 Configurable Control Word CTW	O-16 Store Data Values	O-17 Configurable Alarm and Warningword Product Code	O-3# Drive Port Settings	O-30 Protocol	O-31 Address	O-32 Drive Port Baud Rate	O-33 Drive Port Parity	O-34 Estimated cycle time	O-35 Minimum Response Delay	O-36 Max Inter-Char Delay	O-37 Max Inter-Char Delay	O-4# Drive MC Port Settings	O-40 Telegram Selection	O-41 Parameters for Signals	O-42 PCD Write Configuration	O-43 PCD Read Configuration	O-5# Digital / Bus	O-50 Coasting Select	O-51 Quick Stop Select	O-52 DC Brake Select	O-53 Start Select	O-54 Reversing Select	O-55 Set-up Select	O-56 Preset Reference Select	O-57 Profdrive OFF2 Select	O-58 Profdrive OFF3 Select	O-8# Drive Port Diagnostics	O-80 Bus Message Count	O-81 Bus Error Count																																																																																																							



Parameter Menu Structure

AF-650 GP™ General Purpose Drive for Special Applications Quick Guide

EN-91 MDI-X	IO-32 Terminal X49/5 High Voltage	ID-44 Ordered Typecode String	DR-33 Brake Energy Average	LG-4# OPCPRGIO Data Readouts
EN-92 IGMP Snooping	IO-33 Terminal X49/5 High Current	ID-45 Actual Typecode String	DR-34 Heatsink Temp.	LG-40 Analog Input X49/1
EN-93 Cable Error Length	IO-34 Term. X49/5 Low Ref/Feedb. Value	ID-46 GE Product No.	DR-35 Drive Thermal	LG-41 Analog Input X49/3
EN-94 Broadcast Storm Protection	IO-35 Term. X49/5 High Ref/Feedb. Value	ID-47 Power Card Ordering No	DR-36 Drive Nominal Current	LG-42 Analog Input X49/5
EN-95 Broadcast Storm Filter	IO-36 Term. X49/5 Filter Time Constant	ID-48 Keypad ID Number	DR-37 Drive Max. Current	LG-43 Analog Out X49/7
EN-96 Port Mirroring	IO-37 Term. X49/5 Live Zero	ID-49 SW ID Control Card	DR-38 Logic Controller State	LG-44 Analog Out X49/9
EN-98 Interface Counters	IO-4# Output X49/7	ID-50 SW ID Power Card	DR-39 Control Card Temp.	LG-45 Analog Out X49/11
EN-99 Media Counters	IO-40 Terminal X49/7 Analogue Output	ID-51 Drive Serial Number	DR-40 Trending Buffer Full	LG-46 X49 Digital Output [bin]
EC-# Feedback Option	IO-41 Terminal X49/7 Digital Output	ID-53 Power Card Serial Number	DR-42 Actual Current Limit [A]	LG-5# Active Alarms/Warnings
EC-1# Inc. Interface	IO-42 Terminal X49/7 Min. Scale	ID-59 Filename	DR-43 Actual Speed Limit [RPM]	LG-55 Active Alarm Numbers
EC-10 Signal Type	IO-43 Terminal X49/7 Max. Scale	ID-6# Option Ident	DR-44 Actual Speed Limit [Hz]	LG-56 Active Warning Numbers
EC-11 Resolution (PPR)	IO-44 Terminal X49/7 Bus Control	ID-60 Option Mounted	DR-45 Motor Phase U Current	Adv Parameter Data Set
EC-2# Abs. Enc. Interface	IO-45 Terminal X49/7 Timeout Preset	ID-61 Option SW Version	DR-46 Motor Phase V Current	LC-# Logic Controller
EC-20 Protocol Selection	IO-5# Output X49/9	ID-62 Option Ordering No	DR-47 Motor Phase W Current	LC-0# LC Settings
EC-21 Resolution (Positions/Rev)	IO-50 Terminal X49/9 Analogue Output	ID-63 Option Serial No	DR-48 Speed Ref. After Ramp [RPM]	LC-00 Logic Controller Mode
EC-25 Clock Rate	IO-51 Terminal X49/9 Digital Output	ID-70 Option in Slot A	DR-49 Current Fault Source	LC-01 Start Event
EC-26 SSI Data Format	IO-52 Terminal X49/9 Min. Scale	ID-71 Slot A Option SW Version	DR-50 External Reference	LC-02 Stop Event
RS-34 HIPERFACE Baudrate	IO-53 Terminal X49/9 Max. Scale	ID-72 Option in Slot B	DR-51 Pulse Reference	LC-03 Reset Logic Controller
RS-56 Encoder Sim. Resolution	IO-55 Terminal X49/9 Timeout Preset	ID-73 Slot B Option SW Version	DR-52 Feedback[Unit]	LC-1# Comparators
EC-6# Monitoring and App.	IO-6# Output X49/11	ID-74 Option in Slot C1	DR-53 Digi Pot Reference	LC-10 Comparator Operand
EC-60 Feedback Direction	IO-60 Terminal X49/11 Analogue Output	ID-75 Slot CO Option SW Version	DR-57 Feedback [RPM]	LC-11 Comparator Operator
EC-61 Feedback Signal Monitoring	IO-61 Terminal X49/11 Digital Output	ID-76 Option in Slot C2	DR-6# Inputs & Outputs	LC-12 Comparator Value
RS-# Resolver Interface	IO-62 Terminal X49/11 Min. Scale	ID-77 Slot C1 Option SW Version	DR-60 Digital Input	LC-1# RS Flip Flops
RS-50 Poles	IO-63 Terminal X49/11 Max. Scale	ID-8# Operating Data II	DR-61 Terminal 53 Switch Setting	LC-15 RS-FF Operand S
RS-52 Input Voltage	IO-64 Terminal X49/11 Bus Control	ID-80 Fan Running Hours	DR-62 Analog Input 53	LC-16 RS-FF Operand R
RS-53 Transformation Ratio	IO-65 Terminal X49/11 Timeout Preset	ID-9# Parameter Info	DR-63 Terminal 54 Switch Setting	LC-2# Timers
RS-56 Encoder Sim. Resolution	Param Data Check	ID-92 Defined Parameters	DR-64 Analog Input 54	LC-20 Logic Controller Timer
RS-59 Resolver Interface	Last 10 Changes	ID-93 Modified Parameters	DR-65 Analog Output 42 [mA]	LC-4# Logic Rules
IO-# Programmable I/O Option	Drive Information	ID-98 Drive Identification	DR-66 Digital Output [bin]	LC-40 Logic Rule Boolean 1
IO-0# I/O Mode	Since Factory Setting	ID-99 Parameter Metadata	DR-67 Freq. Input #29 [Hz]	LC-41 Logic Rule Operator 1
IO-00 Terminal X49/1 Mode	IO-0# Operating Data	DR-0# General Status	DR-68 Freq. Input #33 [Hz]	LC-42 Logic Rule Boolean 2
IO-01 Terminal X49/3 Mode	IO-00 Operating hours	DR-01 Control Word	DR-69 Pulse Output #27 [Hz]	LC-44 Logic Rule Boolean 3
IO-02 Terminal X49/5 Mode	IO-01 Running Hours	DR-02 Reference [Unit]	DR-70 Pulse Output #29 [Hz]	LC-5# States
IO-03 Terminal X49/7 Mode	IO-02 kWh Counter	DR-03 Status Word	DR-71 Relay Output [bin]	LC-52 Logic Controller Event
IO-04 Terminal X49/9 Mode	IO-03 Power Up's	DR-05 Main Actual Value [%]	DR-72 Counter A	B-# Braking Functions
IO-05 Terminal X49/11 Mode	IO-04 Over Temp's	DR-09 Custom Readout	DR-73 Counter B	B-0# DC-Brake
IO-1# Analog Input X49/1	IO-05 Over Volt's	DR-10 Power [kW]	DR-74 Prec. Stop Counter	B-00 DC Hold Current
IO-10 Terminal X49/1 Low Voltage	IO-06 Reset kWh Counter	DR-11 Motor Status	DR-75 Analog In X30/11	B-01 DC Brake Current
IO-11 Terminal X49/1 High Voltage	IO-07 Reset Running Hours Counter	DR-12 Motor Voltage	DR-76 Analog In X30/12	B-02 DC Braking Time
IO-12 Terminal X49/1 High Current	IO-1# Data Trending Settings	DR-13 Frequency	DR-77 Analog Out X30/8 [mA]	B-03 DC Brake Cut In Speed [RPM]
IO-14 Term. X49/1 Low Ref/Feedb. Value	IO-10 Trending Source	DR-14 Motor current	DR-80 Fieldbus CTTW 1	B-04 DC Brake Cut In Speed [Hz]
IO-15 Term. X49/1 High Ref/Feedb. Value	IO-11 Trending Interval	DR-15 Frequency [%]	DR-82 Fieldbus REF 1	B-05 Maximum Reference
IO-16 Term. X49/1 Filter Time Constant	IO-12 Trigger Event	DR-16 Torque [Nm]	DR-84 Comm. Option STW	B-06 Parking Current
IO-17 Term. X49/1 Live Zero	IO-13 Trending Mode	DR-17 Speed [RPM]	DR-85 Drive Port CTTW 1	B-1# Brake Energy Funct.
IO-2# Analog Input X49/3	IO-14 Samples Before Trigger	DR-18 Motor Thermal	DR-86 Drive Port REF 1	B-10 Brake Function
IO-20 Terminal X49/3 Low Voltage	IO-2# Historic Log	DR-19 KTY sensor temperature	DR-87 Bus Readout Alarm/Warning	B-11 Brake Resistor (ohm)
IO-21 Terminal X49/3 Low Current	IO-20 Historic Log: Event	DR-20 Motor Angle	99-30 Configurable Alarm/Warning Word	B-12 Brake Power Limit (kW)
IO-22 Terminal X49/3 High Voltage	IO-21 Historic Log: Value	DR-21 Torque [%] High Res.	99-31 internal_ProfibusPCD_Config_Read	B-13 Braking Thermal Overload
IO-23 Terminal X49/3 High Current	IO-22 Historic Log: Time	DR-22 Torque [%]	DR-9# Diagnosis Readouts	B-15 Brake Check
IO-24 Term. X49/3 Low Ref/Feedb. Value	IO-23 Alarm Log	DR-23 Torque [Nm]	DR-90 Alarm Word	B-16 AC brake Max. Current
IO-25 Term. X49/3 High Ref/Feedb. Value	IO-30 Fault Log: Error Code	DR-24 Calibrated Stator Resistance	DR-91 Alarm Word 2	B-17 Over-voltage Control
IO-26 Term. X49/3 Filter Time Constant	IO-31 Fault Log: Value	DR-25 Torque [Nm] High	DR-92 Warning Word	B-18 Brake Check Condition
IO-27 Term. X49/3 Live Zero	IO-32 Fault Log: Time	DR-3# Drive Status	DR-93 Warning Word 2	B-19 Over-voltage Gain
IO-3# Analog Input X49/5	IO-4# Drive Type	DR-30 DC Link Voltage	DR-94 Ext. Status Word	B-2# Mechanical Brake
IO-30 Terminal X49/5 Low Voltage	IO-41 Power Section	DR-32 Brake Energy / s	DR-95 Ext. Status Word 2	B-20 Release Brake Current
IO-31 Terminal X49/5 Low Current	IO-42 Voltage			B-21 Activate Brake Speed [RPM]
	IO-43 Software Version			



Parameter Menu Structure

6

B-22	Activate Brake Speed [Hz]	PI-61	Process PID Output
B-23	Activate Brake Delay	PI-62	Process PID Clamped Output
B-24	Stop Delay	PI-63	Process PID Gain Scaled Output
B-25	Brake Release Time	SF-0#	Special Features
B-26	Torque Ref	SF-0#	Wobbler
B-27	Torque Ramp Time	SF-00	Wobble Mode
B-28	Gain Boost Factor	SF-01	Wobble Delta Frequency [Hz]
PI-#	PID Controls	SF-02	Wobble Delta Frequency [%]
PI-0#	Speed PID Control	SF-03	Wobble Delta Freq. Scaling Resource
PI-00	Speed PID Feedback Source	SF-04	Wobble Jump Frequency [Hz]
PI-01	Speed PID Droop	SF-05	Wobble Jump Frequency [%]
PI-02	Speed PID Proportional Gain	SF-06	Wobble Jump Time
PI-03	Speed PID Integral Time	SF-07	Wobble Sequence Time
PI-04	Speed PID Differentiation Time	SF-08	Wobble Up/ Down Time
PI-05	Speed PID Diff. Gain Limit	SF-09	Wobble Random Function
PI-06	Speed PID Lowpass Filter Time	SF-10	Wobble Ratio
PI-07	Speed PID Feedback Gear Ratio	SF-11	Wobble Random Ratio Max.
PI-08	Speed PID Feed Forward Factor	SF-12	Wobble Random Ratio Min.
PI-09	Speed PID Error Correction w/ Ramp	SF-19	Wobble Delta Freq. Scaled
PI-1#	Torque PI Ctrl.	SF-2#	Adv. Start Adjust
PI-10	Torque PI Feedback Source	SF-20	High Starting Torque Time [s]
PI-12	Torque PI Proportional Gain	SF-21	High Starting Torque Current [%]
PI-13	Torque PI Integration Time	SF-22	Locked Rotor Protection
PI-16	Torque PI Lowpass Filter Time	SF-23	Locked Rotor Detection Time [s]
PI-18	Torque PI Feed Forward Factor	SF-24	Locked Rotor Detection Speed Error [%]
PI-19	Current Controller Rise Time	SF-25	Light Load Delay [s]
PI-2#	Process PID Feedback	SF-26	Light Load Current [%]
PI-20	Process CL Feedback 1 Resource	SF-27	Light Load Speed [%]
PI-22	Process CL Feedback 2 Resource	SF-3#	Miscellaneous
PI-3#	Process PID Control	SF-30	External Interlock Delay
PI-30	Process PID Normal/ Inverse Control	SF-84	Process PID Proportional Gain
PI-31	Process PID Anti Windup		
PI-32	Process PID Start Speed		
PI-33	Process PID Proportional Gain		
PI-34	Process PID Integral Time		
PI-35	Process PID Differentiation Time		
PI-36	Process PID Diff. Gain Limit		
PI-38	Process PID Feed Forward Factor		
PI-39	On Reference Bandwidth		
PI-4#	Adv. Process PID I		
PI-40	Process PID I-part Reset		
PI-41	Process PID Output Neg. Clamp		
PI-42	Process PID Output Pos. Clamp		
PI-43	Process PID Gain Scale at Min. Ref.		
PI-44	Process PID Gain Scale at Max. Ref.		
PI-45	Process PID Feed Fwd Resource		
PI-46	Process PID Feed Fwd Normal/ Inv. Ctrl.		
PI-48	PCD Feed Forward		
PI-49	Process PID Output Normal/ Inv. Ctrl.		
PI-5#	Adv. Process PID II		
PI-50	Process PID Extended PID		
PI-51	Process PID Feed Fwd Gain		
PI-52	Process PID Feed Fwd Ramp up		
PI-53	Process PID Feed Fwd Ramp down		
PI-56	Process PID Ref. Filter Time		
PI-57	Process PID Fb. Filter Time		
PI-6#	PID Readouts		
PI-60	Process PID Error		



6.2 Remote Programming with DCT-10

GE has a software program available for developing, storing, and transferring frequency converter programming. The DCT-10 allows the user to connect a PC to the frequency converter and perform live programming rather than using the keypad. Also, all frequency converter programming can be done off-line and downloaded to the frequency converter. Or the entire frequency converter profile can be loaded onto the PC for back-up storage or analysis.

The USB connector or RS485 terminal is available for connecting to the frequency converter.

For more details, go to www.geelectrical.com/drives

7 Warnings and Alarm

7.1 System Monitoring

The frequency converter monitors the condition of its input power, output, and motor factors, and other system performance indicators. A warning or alarm does not necessarily indicate a problem internally in the frequency converter.

Often, it indicates failure conditions from:

- Input voltage.
- Motor load.
- Motor temperature.
- External signals.
- Other areas monitored by internal logic.

Investigate as indicated in the alarm or warning.

7.2 Warning and Alarm Types

Warnings

A warning is issued when an alarm condition is impending or when an abnormal operating condition is present and may result in the frequency converter issuing an alarm. A warning clears by itself when the abnormal condition is removed.

Alarms

Trip

An alarm is issued when the frequency converter is tripped, that is, the frequency converter suspends operation to prevent frequency converter or system damage. The motor will coast to a stop. The frequency converter logic continues to operate and monitor the frequency converter status. After the fault condition is remedied, the frequency converter can be reset. It is then ready to start operation again.

A trip can be reset in any of 4 ways:

- Press [Reset] on the keypad
- Digital reset input command
- Serial communication reset input command
- Auto reset

Trip lock

An alarm that causes the frequency converter to trip lock requires that input power is cycled. The motor will coast to a stop. The frequency converter logic continues to operate and monitor the frequency converter status. Remove input power to the frequency converter and correct the cause of the fault, then restore power. This action puts the frequency converter into a trip condition as described above and may be reset in any of those 4 ways.

7.3 Warning and Alarm Displays




Illustration 7.1 Warning Display

An alarm or trip lock alarm flashes in the display along with the alarm number.




Illustration 7.2 Alarm Display

In addition to the text and alarm code in the keypad, there are 3 status indicator lights.




Illustration 7.3 Status Indicator Lights



	Warning LED	Alarm LED
Warning	On	Off
Alarm	Off	On (Flashing)
Trip lock	On	On (Flashing)

Table 7.1 Status Indicator Lights Explanations

7.4 Warning and Alarm Definitions

Table 7.2 defines whether a warning is issued before an alarm, and whether the alarm trips the unit or trip locks the unit.

No.	Description	Warning	Alarm/Trip	Alarm/Trip lock	Parameter reference
1	10 Volts low	X			
2	Live zero error	(X)	(X)		Parameter AN-01 Live Zero Timeout Function
3	No motor	(X)			Parameter H-80 Function at Stop
4	Mains phase loss	(X)	(X)	(X)	Parameter SP-12 Function at Line Imbalance
5	DC link voltage high	X			
6	DC link voltage low	X			
7	DC over-voltage	X	X		
8	DC under voltage	X	X		
9	Inverter overloaded	X	X		
10	Motor Electronic OL over temperature	(X)	(X)		Parameter F-10 Electronic Overload
11	Motor thermistor over temperature	(X)	(X)		Parameter F-10 Electronic Overload
12	Torque limit	X	X		Parameter F-40 Torque Limiter (Driving) Parameter F-41 Torque Limiter (Braking)
13	Over Current	X	X	X	
14	Earth Fault	X	X	X	
15	Hardware mismatch		X	X	
16	Short Circuit		X	X	
17	Control word time-out	(X)	(X)		Parameter O-04 Control Word Timeout Function
20	Temp. Input Error				
21	Param Error				
22	Hoist Mech. Brake	(X)	(X)		Parameter group B-2#
23	Internal Fans	X			
24	External Fans	X			
25	Brake resistor short-circuited	X			
26	Brake resistor power limit	(X)	(X)		Parameter B-13 Braking Thermal Overload
27	Brake chopper short-circuited	X	X		
28	Brake check	(X)	(X)		Parameter B-15 Brake Check
29	Heatsink temp	X	X	X	
30	Motor phase U missing	(X)	(X)	(X)	Parameter H-78 Missing Motor Phase Function
31	Motor phase V missing	(X)	(X)	(X)	Parameter H-78 Missing Motor Phase Function
32	Motor phase W missing	(X)	(X)	(X)	Parameter H-78 Missing Motor Phase Function
33	Inrush Fault		X	X	
34	Network communication fault	X	X		
35	Option Fault				
36	Mains failure	X	X		



Warnings and Alarm

No.	Description	Warning	Alarm/Trip	Alarm/Trip lock	Parameter reference
37	Phase imbalance		X		
38	Internal Fault		X	X	
39	Heatsink sensor		X	X	
40	Overload of Digital Output Terminal 27	(X)			<i>Parameter E-00 Digital I/O Mode, parameter E-51 Terminal 27 Mode</i>
41	Overload of Digital Output Terminal 29	(X)			<i>Parameter E-00 Digital I/O Mode, parameter E-52 Terminal 29 Mode</i>
42	Ovrid X30/6-7	(X)			
43	Ext. Supply (option)				
45	Earth Fault 2	X	X	X	
46	Pwr. card supply		X	X	
47	24 V supply low	X	X	X	
48	1.8 V supply low		X	X	
49	Speed limit	X			
50	Auto Tune calibration failed		X		
51	Auto Tune check U_{nom} and I_{nom}		X		
52	Auto Tune low I_{nom}		X		
53	Auto Tune motor too big		X		
54	Auto Tune motor too small		X		
55	Auto Tune parameter out of range		X		
56	Auto Tune interrupted by user		X		
57	Auto Tune time-out		X		
58	Auto Tune internal fault	X	X		
59	Current limit	X			<i>Parameter F-43 Current Limit</i>
61	Feedback Error	(X)	(X)		<i>Parameter H-20 Motor Feedback Loss Function</i>
62	Output Frequency at Maximum Limit	X			
63	Mechanical Brake Low		(X)		<i>Parameter B-20 Release Brake Current</i>
64	Voltage Limit	X			
65	Control Board Over-temperature	X	X	X	
66	Heat sink Temperature Low	X			
67	Option Module Configuration has Changed		X		
68	Safe Stop	(X)	(X) ¹⁾		<i>Parameter E-07 Terminal 37 Safe Stop</i>
69	Pwr. Card Temp		X	X	
70	Illegal Drive configuration			X	
76	Power Unit Setup	X			
77	Reduced power mode	X			<i>Parameter SP-59 Actual Number of Inverter Units</i>
78	Tracking Error	(X)	(X)		<i>Parameter H-24 Tracking Error Function</i>
79	Illegal PS config		X	X	
80	Drive Restored to Factory Settings		X		
83	Illegal Option Combination			X	
90	Feedback Monitor	(X)	(X)		<i>Parameter EC-61 Feedback Signal Monitoring</i>
91	Analog input 54 wrong settings			X	S202
243	Brake IGBT	X	X	X	
244	Heatsink temp	X	X	X	
245	Heatsink sensor		X	X	
246	Pwr.card supply			X	
247	Pwr.card temp		X	X	
248	Illegal PS config			X	
249	Rect. low temp.	X			

**Warnings and Alarm****AF-650 GP™ General Purpose Drive for Special Applications Quick Guide**

No.	Description	Warning	Alarm/Trip	Alarm/Trip lock	Parameter reference
250	New spare parts			X	
251	New Type Code		X	X	

Table 7.2 Alarm/Warning Code List

(X) Dependent on parameter

1) Cannot be auto reset via parameter H-04 Auto-Reset (Times)



Specifications

8 Specifications

8.1 General Technical Data

Mains supply	
Supply terminals (6-pulse)	L1, L2, L3
Supply voltage	380–480 V \pm 10%

Mains voltage low/mains drop-out:

During low mains voltage or a mains drop-out, the drive continues until the DC-link voltage drops below the minimum stop level, which corresponds typically to 15% below the frequency converter's lowest rated supply voltage. Power-up and full torque cannot be expected at mains voltage lower than 10% below the frequency converter's lowest rated supply voltage.

Supply frequency	50/60 Hz \pm 5%
Maximum imbalance temporary between mains phases	3.0% of rated supply voltage
True Power Factor (λ)	\geq 0.9 nominal at rated load
Displacement Power Factor ($\cos \phi$)	near unity ($>$ 0.98)
Switching on input supply L1, L2, L3 (power-ups) 18.5–75 kW (25–100 hp)	maximum 1 time/minute
Switching on input supply L1, L2, L3 (power-ups) \geq 132 kW (200 hp)	maximum 1 time/2 minute
Environment according to EN60664-1	overvoltage category III/pollution degree 2

The unit is suitable for use on a circuit capable of delivering not more than 100kAIC RMS symmetrical Amperes, 240/500/600/690 V maximum.

Motor output (U, V, W)	
Output voltage	0–100% of supply voltage
Output frequency	0–590 Hz
Output frequency in Flux Mode	0–300 Hz
Switching on output	Unlimited
Ramp times	0.01–3600 s

1) Voltage and power dependent

Torque characteristics	
Starting torque (constant torque)	Maximum 150% for 60 s ¹⁾ once in 10 minutes
Starting/overload torque (variable torque)	Maximum 110% for 60 s ¹⁾ once in 10 minutes
Torque rise time in Flux Vector Vector Control (for 5 kHz fsw)	1 ms
Torque rise time in Advanced Vector Control (independent of fsw)	10 ms

1) Percentage relates to the nominal torque.

2) The torque response time depends on application and load but as a rule, the torque step from 0 to reference is 4–5 x torque rise time.

Digital inputs	
Programmable digital inputs	4 (6) ¹⁾
Terminal number	18, 19, 27 ¹⁾ , 29 ¹⁾ , 32, 33
Logic	PNP or NPN
Voltage level	0–24 V DC
Voltage level, logic 0 PNP	<5 V DC
Voltage level, logic 1 PNP	>10 V DC
Voltage level, logic 0 NPN ²⁾	>19 V DC
Voltage level, logic 1 NPN ²⁾	<14 V DC
Maximum voltage on input	28 V DC
Pulse frequency range	0–110 kHz
(Duty cycle) minimum pulse width	4.5 ms
Input resistance, R _i	approximately 4 k Ω

1) Terminals 27 and 29 can also be programmed as output.



Specifications **AF-650 GP™ General Purpose Drive for Special Applications Quick Guide**

STO terminal 37²⁾ (terminal 37 is fixed PNP logic)

Voltage level	0–24 V DC
Voltage level, logic 0 PNP	<4 V DC
Voltage level, logic 1 PNP	>20 V DC
Maximum voltage on input	28 V DC
Typical input current at 24 V	50 mA rms
Typical input current at 20 V	60 mA rms
Input capacitance	400 nF

All digital inputs are galvanically isolated from the supply voltage (PELV) and other high voltage terminals.

2) See chapter 3.4.5.7 Terminal 37 for further information about terminal 37 and STO.

Analog inputs

Number of analog inputs	2
Terminal number	53, 54
Modes	Voltage or current
Mode select	Switch S201 and switch S202
Voltage mode	Switch S201/switch S202 = OFF (U)
Voltage level	-10 V to +10 V (scaleable)
Input resistance, R_i	approximately 10 k Ω
Maximum voltage	± 20 V
Current mode	Switch S201/switch S202 = ON (I)
Current level	0/4 to 20 mA (scaleable)
Input resistance, R_i	approximately 200 Ω
Maximum current	30 mA
Resolution for analog inputs	10 bit (+ sign)
Accuracy of analog inputs	Maximum error 0.5% of full scale
Bandwidth	100 Hz

The analog inputs are galvanically isolated from the supply voltage (PELV) and other high voltage terminals.




Illustration 8.1 PELV Isolation

Pulse/encoder inputs

Programmable pulse/encoder inputs	2/1
Terminal number pulse/encoder	29, 33 ¹⁾ /32 ²⁾ , 33 ²⁾
Maximum frequency at terminal 29, 32, 33	110 kHz (Push-pull driven)
Maximum frequency at terminal 29, 32, 33	5 kHz (Open collector)
Minimum frequency at terminal 29, 32, 33	4 Hz
Voltage level	See section E-0# Digital Inputs in the programming guide.
Maximum voltage on input	28 V DC
Input resistance, R_i	Approximately 4 k Ω
Pulse input accuracy (0.1–1 kHz)	Maximum error: 0.1% of full scale
Encoder input accuracy (1–11 kHz)	Maximum error: 0.05% of full scale

The pulse and encoder inputs (terminals 29, 32, 33) are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

1) Pulse inputs are 29 and 33.

2) Encoder inputs: 32=A, 33=B.



Specifications

Digital output

Programmable digital/pulse outputs	2
Terminal number	27, 29 ¹⁾
Voltage level at digital/frequency output	0–24 V
Maximum output current (sink or source)	40 mA
Maximum load at frequency output	1 k Ω
Maximum capacitive load at frequency output	10 nF
Minimum output frequency at frequency output	0 Hz
Maximum output frequency at frequency output	32 kHz
Accuracy of frequency output	Maximum error: 0.1% of full scale
Resolution of frequency outputs	12 bit

1) Terminal 27 and 29 can also be programmed as input.

The digital output is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Analog output

Number of programmable analog outputs	1
Terminal number	42
Current range at analog output	0/4 to 20 mA
Maximum load GND - analog output less than	500 Ω
Accuracy on analog output	Maximum error: 0.5% of full scale
Resolution on analog output	12 bit

The analog output is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Control card, 24 V DC output

Terminal number	12, 13
Output voltage	24 V +1, -3 V
Maximum load	200 mA

The 24 V DC supply is galvanically isolated from the supply voltage (PELV), but has the same potential as the analog and digital inputs and outputs.

Control card, 10 V DC output

Terminal number	± 50
Output voltage	10.5 V ± 0.5 V
Maximum load	15 mA

The 10 V DC supply is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Control card, RS485 serial communication

Terminal number	68 (P, TX+, RX+), 69 (N, TX-, RX-)
Terminal number 61	Common for terminals 68 and 69

The RS485 serial communication circuit is functionally separated from other central circuits and galvanically isolated from the supply voltage (PELV).

Control card, USB serial communication

USB standard	1.1 (full speed)
USB plug	USB type B plug

Connection to PC is carried out via a standard host/device USB cable.

The USB connection is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

The USB ground connection is not galvanically isolated from protective earth. Use only an isolated laptop as PC connection to the USB connector on the frequency converter.

Relay outputs

Programmable relay outputs	2 Form C
Relay 01 terminal number	1–3 (break), 1–2 (make)
Maximum terminal load (AC-1) ¹⁾ on 1–3 (NC), 1–2 (NO) (resistive load)	240 V AC, 2 A
Maximum terminal load (AC-15) ¹⁾ (inductive load @ $\cos\phi$ 0.4)	240 V AC, 0.2 A
Maximum terminal load (DC-1) ¹⁾ on 1–2 (NO), 1–3 (NC) (resistive load)	60 V DC, 1 A
Maximum terminal load (DC-13) ¹⁾ (inductive load)	24 V DC, 0.1 A
Relay 02 terminal number	4–6 (break), 4–5 (make)



Specifications **AF-650 GP™ General Purpose Drive for Special Applications Quick Guide**

Maximum terminal load (AC-1) ¹⁾ on 4-5 (NO) (resistive load) ²⁾³⁾ overvoltage cat. II	400 V AC, 2 A
Maximum terminal load (AC-15) ¹⁾ on 4-5 (NO) (inductive load @ cosφ 0.4)	240 V AC, 0.2 A
Maximum terminal load (DC-1) ¹⁾ on 4-5 (NO) (resistive load)	80 V DC, 2 A
Maximum terminal load (DC-13) ¹⁾ on 4-5 (NO) (inductive load)	24 V DC, 0.1 A
Maximum terminal load (AC-1) ¹⁾ on 4-6 (NC) (resistive load)	240 V AC, 2 A
Maximum terminal load (AC-15) ¹⁾ on 4-6 (NC) (inductive load @ cosφ 0.4)	240 V AC, 0.2 A
Maximum terminal load (DC-1) ¹⁾ on 4-6 (NC) (resistive load)	50 V DC, 2 A
Maximum terminal load (DC-13) ¹⁾ on 4-6 (NC) (inductive load)	24 V DC, 0.1 A
Minimum terminal load on 1-3 (NC), 1-2 (NO), 4-6 (NC), 4-5 (NO)	24 V DC 10 mA, 24 V AC 20 mA
Environment according to EN 60664-1	Overvoltage category III/pollution degree 2

1) IEC 60947 part 4 and 5

The relay contacts are galvanically isolated from the rest of the circuit by reinforced isolation (PELV).

2) Overvoltage Category II.

3) UL applications 300 V AC2A.

Cable lengths and cross-sections for control cables

Maximum motor cable length, shielded	150 m
Maximum motor cable length, unshielded	300 m
Maximum cross-section to control terminals, flexible/rigid wire without cable end sleeves	2.5 mm ² /14 AWG
Maximum cross-section to control terminals, with ferrules without plastic sleeves	2.5 mm ² /14 AWG
Maximum cross-section to control terminals, with ferrules with plastic sleeves	1 mm ² /18 AWG
Minimum cross-section to control terminals	0.25 mm ² /24 AWG

Control card performance

Scan interval	1 ms
---------------	------

Control characteristics

Resolution of output frequency at 0-590 Hz	±0.003 Hz
Repeat accuracy of precise start/stop (terminals 18, 19)	≤±0.1 ms
System response time (terminals 18, 19, 27, 29, 32, 33)	≤2 ms
Speed control range (open loop)	1:100 of synchronous speed
Speed control range (closed loop)	1:1000 of synchronous speed
Speed accuracy (open loop)	30-4000 RPM: error ±8 RPM
Speed accuracy (closed loop), depending on resolution of feedback device	0-6000 RPM: error ±0.15 RPM
Torque control accuracy (speed feedback)	Maximum error ±5% of rated torque

All control characteristics are based on a 4-pole asynchronous motor.

Environment

Vibration test	1.0 g
Max. relative humidity	5-93%(IEC 721-3-3; Class 3K3 (non-condensing) during operation
Aggressive environment (IEC 60068-2-43) H ₂ S test	class Kd
Ambient temperature	Max. 50 °C (122 °F)

1) Only for ≤3.7 kW (5 hp)(200-240 V), ≤7.5 kW (10 hp) (400-500 V)

2) As enclosure kit for ≤3.7 kW (5 hp) (200-240 V), ≤7.5 kW (10 hp) (400-500 V)

3) Derating for high ambient temperature, see special conditions in the Design Guide

Minimum ambient temperature during full-scale operation	0 °C (32°F)
Minimum ambient temperature at reduced performance	-10 °C (14°F)
Temperature during storage/transport	-25 to +65/70 °C (-13 to 149/158 °F)
Maximum altitude above sea level without derating	1000 m (3300 ft)

Derating for high altitude, see special conditions in the design guide

EMC standards, Emission	EN 61800-3, EN 61000-6-3/4, EN 55011
EMC standards, Immunity	EN 61800-3, EN 61000-6-1/2, EN 61000-4-2, EN 61000-4-3, EN 61000-4-4, EN 61000-4-5, EN 61000-4-6

See section on special conditions in the AF-650 GP Design & Installation Guide.



Specifications

Protection and Features

- Electronic motor thermal protection against overload.
- If the temperature reaches $95\text{ °C} \pm 5\text{ °C}$, temperature monitoring of the heat sink ensures that the frequency converter trips. An overload temperature cannot be reset until the temperature of the heat sink is below $70\text{ °C} \pm 5\text{ °C}$ (Guideline - these temperatures may vary for different power sizes, enclosures etc.). The frequency converter has an auto derating function to avoid its heatsink reaching 95 °C .
- The frequency converter is protected against short circuits on motor terminals U, V, W.
- If a mains phase is missing, the frequency converter trips or issues a warning (depending on the load).
- If the DC-link voltage is too low or too high, monitoring of the DC-link voltage ensures that the frequency converter trips.
- The frequency converter constantly checks for critical levels of internal temperature, load current, high voltage on the DC link, and low motor speeds. As a response to a critical level, the frequency converter can adjust the switching frequency and/or change the switching pattern to ensure the performance of the frequency converter.

8.2 Fuses

It is recommended to use fuses and/or circuit breakers on the supply side as protection if there is component break-down inside the frequency converter (first fault).

8

NOTICE

Using fuses and/or circuit breakers on the supply side is mandatory to ensure compliance with IEC 60364 for CE or NEC 2009 for UL.

⚠ WARNING

Protect personnel and property against the consequence of component break-down internally in the frequency converter.

Branch circuit protection

To protect the installation against electrical and fire hazard, all branch circuits in an installation, switch gear, machines, and so on, must be protected against short circuit and overcurrent according to national/international regulations.

NOTICE

The recommendations given do not cover branch circuit protection for UL.

Short-circuit protection

GE recommends using the fuses/circuit breakers mentioned below to protect service personnel and property if there is component break-down in the frequency converter.

Overcurrent protection

The frequency converter provides overload protection to limit threats to human life, property damage and to avoid fire hazard due to overheating of the cables in the installation. The frequency converter is equipped with an internal overcurrent protection (*parameter F-43 Current Limit*) that can be used for upstream overload protection (UL applications excluded). Moreover, fuses or circuit breakers can be used to provide the overcurrent protection in the installation. Overcurrent protection must always be carried out according to national regulations.

⚠ WARNING

If there is malfunction, not following the recommendation may result in personnel risk and damage to the frequency converter and other equipment.

The following tables list the recommended rated current. Recommended fuses are of the type gG for small to medium power sizes. For larger powers, aR fuses are recommended. Circuit breakers must be used provided they meet the national/international regulations and they limit the energy into the frequency converter to an equal or lower level than the compliant circuit breakers. If fuses/circuit breakers according to recommendations are selected, possible damages on the frequency converter will mainly be limited to damages inside the unit.



8.2.1 CE Compliance

Fuses or circuit breakers are mandatory to comply with IEC 60364. GE recommend using a selection of the following.

The fuses below are suitable for use on a circuit capable of delivering 100000 Arms (symmetrical), 240 V, 500 V, 600 V, or 690 V depending on the frequency converter voltage rating. With the proper fusing, the frequency converter short circuit current rating (SCCR) is 100000 Arms.

AF-650 GP 3-phase [hp]	Recommended fuse size	Recommended maximum fuse	Recommended circuit breaker	Maximum trip level [A]
IP20/Open Chassis				
25	gG-80	gG-125	NZMB1-A100	100
40				
50	gG-125	gG-150	NZMB2-A200	150
100	aR-250	aR-250	NZMB2-A250	250
200	gG-400	gG-400	-	-
350	aR-700	aR-700		

Table 8.1 380–480 V, Unit Sizes 3X, 4hX

8.2.2 Fuse Specifications

AF-650 GP 3-phase [kW (hp)]	Recommended fuse size	Recommended maximum fuse
18.5 (25)	gG-80	gG-125
37 (50)	gG-125	gG-150
75 (100)	aR-250	aR-250
132 (200)	aR-400	aR-400
250 (350)	aR-700	aR-700

Table 8.2 380–500 V, IP20/Open Chassis

8.2.3 NEC and UL Compliance

AF-650 GP	Recommended maximum fuse					
	Bussmann	Bussmann	Bussmann	Bussmann	Bussmann	Bussmann
[kW (hp)]	Type RK1	Type J	Type T	Type CC	Type CC	Type CC
18.5 (25)	KTS-R-60	JKS-60	JJS-60	-	-	-
37 (50)	KTS-R-125	JKS-125	JJS-125	-	-	-
75 (100)	KTS-R-250	JKS-250	JJS-250	-	-	-

Table 8.3 380–500 V

AF-650 GP	Recommended maximum fuse			
	SIBA	Littelfuse	Ferraz-Shawmut	Ferraz-Shawmut
[kW (hp)]	Type RK1	Type RK1	Type CC	Type RK1
18.5 (25)	5014006-063	KLS-R-60	-	A6K-60-R
37 (50)	2028220-125	KLS-R-125	-	A6K-125-R
75 (100)	2028220-250	KLS-R-250	-	A6K-250-R

Table 8.4 380–500 V



Specifications

	Recommended maximum fuse			
AF-650 GP	Bussmann	Ferraz Shawmut	Ferraz Shawmut	Littelfuse
[kW (hp)]	JFHR2	J	JFHR2 ¹⁾	JFHR2
18.5 (25)	FWH-60	HSJ-60	-	-
37 (50)	FWH-125	HSJ-125	-	-
75 (100)	FWH-250	HSJ-250	A50-P-250	L50-S-250

Table 8.5 380–500 V

1) Ferraz Shawmut A50QS fuses may substitute for A50P fuses.

	Recommended maximum fuse				
AF-650 GP	Bussmann PN	Alternate Bussmann PN	Siba PN	Littelfuse PN	Ferraz Shawmut PN
[kW (hp)]	Type JFHR2	Type T/JDDZ	Type JFHR2	Type JFHR2	
132 (200)	170M2621	JJS-400	20 610 31.400	L50-S-400	6.9URD31D08A0400
250 (350)	170M4017	-	20 610 31.800	-	6.9URD31D08A0700

Table 8.6 380–500 V, above 125 hp



9 Terminal and Applicable Wire

9.1 Cables

Power [kW (hp)] 380-500 V [kW (hp)]	Enclosure	Mains		Motor		DC battery		Brake		Ground* Tightening torque [Nm (in-lbs)]
		Tightening torque [Nm (in-lbs)]	Wire size [mm ² (AWG)]	Tightening torque [Nm (in-lbs)]	Wire size [mm ² (AWG)]	Tightening torque [Nm (in-lbs)]	Wire size [mm ² (AWG)]	Tightening torque [Nm (in-lbs)]	Wire size [mm ² (AWG)]	
18.5 (25)	IP20	4.5 (40)	35 (2)	4.5 (40)	35 (2)	4.5 (40)	35 (2)	4.5 (40)	35 (2)	3 (27)
37 (50)	IP20	10 (89)	50 (1)	10 (89)	50 (1)	10 (89)	50 (1)	10 (89)	50 (1)	
75 (100)	IP20	14 (124)	150 (300)	14 (124)	150 (300)	14 (124)	95 (4/0)	14 (124)	95 (4/0)	8.5 (75)
132 (200)	IP20	19 (168)	2x95 (2x3/0)	19 (168)	2x95 (2x3/0)	19 (75)	2x95 (2x3/0)	8.5 (75)	2x95 (2x3/0)	
250 (350)	IP20	19 (168)	2x185 (2x350)	19 (168)	2x185 (2x350)	19 (75)	2x185 (2x350)	8.5 (75)	2x185 (2x350)	19 (168)

* Maximum cable size according to national code

Table 9.1 Cables



Index

Index

A

AC input.....	12
AC mains.....	9, 12
Alarm Log.....	27
Alarm/warning types.....	36
Alarms.....	36
Analog inputs.....	13
Analog output.....	13, 42
Auto.....	28
Auto tune.....	19
Auto-reset.....	26

B

Back plate.....	8
Basic operational programming.....	19
Branch circuit protection.....	44

C

Cable	
Screened cable.....	18
Cable lengths, cross sections.....	43
Circuit breaker.....	18
Circuit breakers.....	44
Clearance requirements.....	7
Closed loop.....	15
Conduit.....	10, 18
Control	
characteristics.....	43
wiring.....	18
Control cables.....	14
Control card	
Control card.....	42, 43
RS485.....	42
Serial communication.....	42
USB serial communication.....	42
Control terminal.....	28
Control terminals.....	9, 14, 19
Control wire.....	14
Control wiring.....	10, 11, 14
Cooling.....	7
Cooling clearance.....	18
Current limit.....	20
Current rating.....	7

D

DC battery.....	4
-----------------	---

DCT-10.....	13, 35
Derating.....	7
Digital inputs.....	13
Digital output.....	42
Discharge time.....	4
Disconnect switch.....	17, 19
Downloading data from the keypad.....	29
Drive profile.....	16

E

Electrical noise.....	11
EMC.....	18

F

Fault log.....	27
Feedback.....	15, 18
Floating delta.....	12
Full load current.....	7, 17
Functional testing.....	20
Fuse.....	18
Fuses.....	44
Fusing.....	10, 18

G

Ground connection.....	18
Ground connections.....	11
Ground loops.....	14
Ground wire.....	11, 18
Grounded delta.....	12
Grounding.....	10, 11, 12, 17, 18
Grounding, using shielded cable.....	11

H

Hand.....	20, 28
High voltage.....	4

I

IEC 61800-3.....	12
Induced voltage.....	10
Input	
Analog input.....	41
Digital input.....	40
power.....	18
Input current.....	12
Input disconnect.....	12
Input power.....	10, 11, 12, 17, 36
Input signals.....	15



Index **AF-650 GP™ General Purpose Drive for Special Applications Quick Guide**

Input terminal..... 17
Input terminals..... 9, 15
Input voltage..... 19
Installation..... 7, 8, 10, 14, 16, 18, 19
Isolated mains..... 12

L

Leakage current..... 5, 10, 17
Lifting..... 8
Local control..... 26, 28
Local mode..... 20
Local operation..... 26
Local start..... 20
Local-control test..... 20

M

Main menu..... 27
Main Menu..... 27
Mains..... 10
Mains voltage..... 27, 28
Menu key..... 26
Menu keys..... 27
Menu structure..... 28
Modbus RTU..... 16
Motor
 protection..... 44
 wiring..... 18
 Rotation..... 20
 Unintended motor rotation..... 5
Motor cables..... 7, 10, 11
Motor current..... 19
Motor Current..... 27
Motor data..... 19, 20
Motor output..... 40
Motor power..... 9, 10, 11
Motor protection..... 10
Motor rotation..... 27
Motor speeds..... 19
Motor wiring..... 10, 11
Mounting..... 8, 18
Multiple frequency converters..... 10, 11
Multiple motors..... 17

N

Navigation key..... 26, 28
Navigation keys..... 19
Noise isolation..... 10, 18

O

Open loop..... 15
Operation key..... 28
Operational programming, basic..... 19
Optional equipment..... 11, 19
Output performance (U, V, W)..... 40
Output terminal..... 17
Output terminals..... 9
Overload protection..... 7, 10
Overvoltage..... 20

P

Parameter setting..... 28
PELV..... 12
Performance..... 43
Power
 Input power..... 18, 36
 Input voltage..... 36
 factor..... 18
 Power, input..... 36
Power connections..... 10
Power factor..... 11
Pre-start..... 17
Programming..... 19, 20, 26, 27, 28, 35
Pulse/encoder input..... 41

Q

Qualified personnel..... 4
Quick Menu..... 27
Quick set-up..... 19

R

Ramp time..... 20
RCD..... 11
Reference..... 27
Relay output..... 42
Relay outputs..... 13
Remote programming..... 35
Remote Programming..... 35
Reset..... 26, 28, 29, 36
Restore..... 29
Restoring..... 29
Restoring default setting..... 29
Restoring Default Settings..... 29
RFI filter..... 12
Run command..... 21



Index

S		Warning/alarm types..... 36
Safety.....	5	Windmilling..... 5
Safety inspection.....	17	Wire sizes..... 11
Screened control cables.....	14	
Serial communication.....	9, 13, 14, 16, 28, 36	
Serial communication		
Serial communication.....	42	
Set-up.....	21, 27	
Shielded cable.....	7, 10	
Shielded cable, grounding.....	11	
Shielded wire.....	10	
Smart Application Set-up (SAS).....	19	
Specifications.....	16	
Speed reference.....	15, 21	
Start-up.....	29	
Supply voltage.....	12, 13, 17	
Surroundings.....	43	
System monitoring.....	36	
System Start Up.....	21	
T		
Temperature limit.....	18	
Terminal 53.....	15	
Terminal 54.....	15	
Terminal programming.....	15	
Thermistor.....	12	
Thermistor control wiring.....	12	
Torque		
characteristics.....	40	
Torque limit.....	20	
Trip.....	36	
Trip function.....	10	
Trip lock.....	36	
U		
Unintended start.....	4, 29	
Uploading data to the keypad.....	29	
V		
Voltage		
Voltage, input.....	36	
Voltage level.....	40	
W		
Warning and alarm displays.....	36	
Warning and alarm types.....	36	



The instructions do not purport to cover all details or variations in equipment nor to provide for every possible contingency to be met in connection with installation, operation or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the GE company.

AF-650 GP is trademark of the General Electric Company.

GE
41 Woodford Avenue
Plainville, CT 06062

www.geelectrical.com/drives



imagination at work

130R0702



DET-864