

Operating Guide

VLT® HVAC Basic Drive FC 101 Liquid Cooled



Contents

1	Introduction	5
1.1	Purpose of this Operating Guide	5
1.2	Trademarks	5
1.3	Additional Resources	5
1.3.1	Other Resources	5
1.3.2	MCT 10 Set-up Software Support	5
1.4	Document and Software Version	5
1.5	Disposal	6
2	Safety	7
2.1	Safety Symbols	7
2.2	Qualified Personnel	7
2.3	Safety Precautions	7
2.4	Motor Thermal Protection	9
3	Installation	10
3.1	Mechanical Installation	10
3.1.1	Side-by-side Installation	10
3.1.2	Drive Dimensions	11
3.1.3	Assembly	12
3.1.4	Thermal Switch Mating Connector Details (H3 & H4)	14
3.1.5	Liquid Cooling	14
3.1.6	Servicing the Drive	16
3.2	Electrical Installation	17
3.2.1	Tightening Torques	17
3.2.2	IT Mains	18
3.2.3	Mains and Motor Connection	18
3.2.3.1	Introduction	18
3.2.3.2	Connecting to Mains and Motor	19
3.2.3.3	Relays and Terminals on Enclosure Sizes H3–H4	19
3.2.4	Fuses and Circuit Breakers	20
3.2.4.1	Branch Circuit Protection	20
3.2.4.2	Short-circuit Protection	20
3.2.4.3	Overcurrent Protection	20
3.2.4.4	CE Compliance	20
3.2.4.5	Recommendation of Fuses and Circuit Breakers	20
3.2.5	EMC-correct Electrical Installation	20
3.2.6	Control Terminals	23
3.2.7	Electrical Wiring	23
3.2.8	Acoustic Noise or Vibration	24

4	Programming	25
4.1	Local Control Panel (LCP)	25
4.2	Set-up Wizard	26
4.2.1	Set-up Wizard Introduction	26
4.2.2	Set-up Wizard for Open-loop Applications	28
4.2.3	Set-up Wizard for Closed-loop Applications	34
4.2.4	Motor Set-up	39
4.2.5	Changes Made Function	43
4.2.6	Changing Parameter Settings	44
4.2.7	Accessing All Parameters via the Main Menu	44
4.3	Parameter List	45
5	Warnings and Alarms	47
5.1	List of Warnings and Alarms	47
6	Specifications	50
6.1	Mains Supply 3x380–480 V AC	50
6.2	EMC Emission Test Results	50
6.3	Special Conditions	51
6.3.1	Derating for Ambient Temperature and Switching Frequency	51
6.3.2	Derating for Low Air Pressure and High Altitudes	52
6.4	General Technical Data	52
6.4.1	Protection and Features	52
6.4.2	Mains Supply (L1, L2, L3)	52
6.4.3	Motor Output (U, V, W)	53
6.4.4	Cable Length and Cross-section	53
6.4.5	Digital Inputs	53
6.4.6	Analog Inputs	53
6.4.7	Analog Outputs	54
6.4.8	Digital Output	54
6.4.9	Control Card, RS485 Serial Communication	54
6.4.10	Control Card, 24 V DC Output	55
6.4.11	Relay Output	55
6.4.12	Control Card, 10 V DC Output	55
6.4.13	Ambient Conditions	55
6.4.14	Thermal Switch (Fan Failure Detection)	56

1 Introduction

1.1 Purpose of this Operating Guide

This operating guide provides information for safe installation and commissioning of the AC drive. It is intended for use by qualified personnel. Read and follow the instructions to use the drive safely and professionally. Pay particular attention to the safety instructions and general warnings. Always keep this operating guide available with the drive.

1.2 Trademarks

VLT® is a registered trademark for Danfoss A/S.

1.3 Additional Resources

1.3.1 Other Resources

Other resources are available to understand advanced drive functions and programming.

- The VLT® HVAC Basic Drive FC 101 Programming Guide provides information on how to program and includes complete parameter descriptions.
- The VLT® HVAC Basic Drive FC 101 Design Guide provides all technical information about the drive. It also lists options and accessories.

The technical documentation is available in electronic form online at www.danfoss.com.

1.3.2 MCT 10 Set-up Software Support

Download the software from the service and support section on www.danfoss.com.

During the installation process of the software, enter access code 81463800 to activate the VLT® HVAC Basic Drive FC 101 Liquid Cooled functionality. A license key is not required for using the VLT® HVAC Basic Drive FC 101 Liquid Cooled functionality.

The latest software does not always contain the latest updates for drives. Contact the local sales office for the latest drive updates (in the form of *.upd files), or download the drive updates from the service and support section on www.danfoss.com.

1.4 Document and Software Version

The operating guide is regularly reviewed and updated. All suggestions for improvement are welcome.

Table 1: Document and Software Version

Edition	Remarks	Software version
MG18Q1xx	First edition.	4.23

1.5 Disposal



Do not dispose of equipment containing electrical components together with domestic waste.

Collect it separately in accordance with local and currently valid legislation.

2 Safety

2.1 Safety Symbols

The following symbols are used in this manual:

⚠ DANGER ⚠

Indicates a hazardous situation which, if not avoided, will result in death or serious injury.

⚠ WARNING ⚠

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

⚠ CAUTION ⚠

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

Indicates information considered important, but not hazard-related (for example, messages relating to property damage).

2.2 Qualified Personnel

To allow trouble-free and safe operation of the unit, only qualified personnel with proven skills are allowed to transport, store, assemble, install, program, commission, maintain, and decommission this equipment.

Persons with proven skills:

- Are qualified electrical engineers, or persons who have received training from qualified electrical engineers and are suitably experienced to operate devices, systems, plant, and machinery in accordance with pertinent laws and regulations.
- Are familiar with the basic regulations concerning health and safety/accident prevention.
- Have read and understood the safety guidelines given in all manuals provided with the unit, especially the instructions given in the Operating Guide.
- Have good knowledge of the generic and specialist standards applicable to the specific application.

2.3 Safety Precautions

⚠ WARNING ⚠

HIGH VOLTAGE

AC drives contain high voltage when connected to AC mains input, DC supply, or load sharing. Failure to perform installation, start-up, and maintenance by qualified personnel can result in death or serious injury.

- Only qualified personnel must perform installation, start-up, and maintenance.

⚠ WARNING ⚠

UNINTENDED START

When the drive is connected to AC mains, DC supply, or load sharing, the motor may start at any time. Unintended start during programming, service, or repair work can result in death, serious injury, or property damage. Start the motor with an external switch, a fieldbus command, an input reference signal from the local control panel (LCP), via remote operation using MCT 10 software, or after a cleared fault condition.

- Disconnect the drive from the mains.
- Press [Off/Reset] on the LCP before programming parameters.
- Ensure that the drive is fully wired and assembled when it is connected to AC mains, DC supply, or load sharing.

⚠ WARNING ⚠

DISCHARGE TIME

The drive contains DC-link capacitors, which can remain charged even when the drive is not powered. High voltage can be present even when the warning indicator lights are off.

Failure to wait the specified time after power has been removed before performing service or repair work could result in death or serious injury.

- Stop the motor.
- Disconnect AC mains, permanent magnet type motors, and remote DC-link supplies, including battery back-ups, UPS, and DC-link connections to other drives.
- Wait for the capacitors to discharge fully. The minimum waiting time is specified in the table *Discharge time* and is also visible on the nameplate on top of the drive.
- Before performing any service or repair work, use an appropriate voltage measuring device to make sure that the capacitors are fully discharged.

Table 2: Discharge Time

Voltage [V]	Power range [kW (hp)]	Minimum waiting time (minutes)
3x400	7.5 (10)	4
3x400	11 (15)	15
3x400	15 (20)	15

⚠ WARNING ⚠

LEAKAGE CURRENT HAZARD

Leakage currents exceed 3.5 mA. Failure to ground the drive properly can result in death or serious injury.

- Ensure the correct grounding of the equipment by a certified electrical installer.

⚠ WARNING ⚠**EQUIPMENT HAZARD**

Contact with rotating shafts and electrical equipment can result in death or serious injury.

- Ensure that only trained and qualified personnel perform installation, start-up, and maintenance.
- Ensure that electrical work conforms to national and local electrical codes.
- Follow the procedures in this manual.

⚠ CAUTION ⚠**INTERNAL FAILURE HAZARD**

An internal failure in the drive can result in serious injury when the drive is not properly closed.

- Ensure that all safety covers are in place and securely fastened before applying power.

2.4 Motor Thermal Protection

Procedure

1. Set *parameter 1-90 Motor Thermal Protection* to [4] *ETR trip 1* to enable the motor thermal protection function.

3 Installation

3.1 Mechanical Installation

3.1.1 Side-by-side Installation

The drive can be mounted side by side but requires clearance above and below for cooling.





Illustration 1: Clearance Required for Cooling

Table 3: Clearance Required for Cooling

Size	IP class	3x380–480 V [kW (hp)]	Clearance above/below [mm (in)]
H3	IP20	7.5 (10)	100 (3.94)
H4	IP20	11–15 (15–20)	100 (3.94)

3.1.2 Drive Dimensions



e30bu391.10

Illustration 2: Dimensions

Table 4: Dimensions, Enclosure Sizes H3–H4


Enclosure Size		H3	H4
IP class		IP20	IP20
Power [kW (hp)]	3x380–480 V	7.5 (10)	11–15 (15–20)
Height [mm (in)]	A	255 (10.0)	296 (11.7)
	a	240 (9.4)	275 (10.8)
	G	276.5 (10.9)	315 (12.4)
	H	333 (13.1)	382 (15.0)
Width [mm (in)]	B	100 (3.9)	135 (5.3)
	b	74 (2.9)	105 (4.1)
	J	114 (4.5)	149.5 (5.9)
Depth [mm (in)]	C	206 (8.1)	241 (9.5)
Mounting hole [mm (in)]	d	11 (0.43)	12.6 (0.50)
	e	5.5 (0.22)	7 (0.28)
	f	8.1 (0.32)	8.4 (0.33)
Copper tube [mm (in)]	K	9.6 (0.38)	15.9 (0.63)
	L	40 (1.57)	40 (1.57)
Maximum weight kg (lb)		4.4 (9.7)	7.4 (16.3)

The dimensions are only for the physical units.


3.1.3 Assembly

Procedure


1. Assemble the drive with mounting bracket.




2. Fix the drive with 4xM5/M6 (H3/H4) screws.




3. Support the copper tube with the tie wrap and fix it with 3xM4 screws.



4. Remove the existing holder plate mounting screw.



5. Mount the drive and connect it to the application.



3.1.4 Thermal Switch Mating Connector Details (H3 & H4)

Table 5: Thermal Switch Mating Connector Details (H3 & H4)

Part Description	Manufacturer	Manufacturer P/N
Micro-fit 3.0 receptacle housing, single row, 2 circuits	Molex	0436450200
Micro-fit 3.0 crimp terminal, male, 20-24 AWG	Molex	0430310001

3.1.5 Liquid Cooling

Table 6: Liquid Cooling

Power [kW (hp)]	Cooling agent	Copper tube size [mm (in)]	Flow rate (Kg/Hr)		Coolant refrigerant temperature	
			Minimum	Maximum	Minimum	Maximum
7.5 (10)	Refrigerant (R410-A) ⁽¹⁾	9.55 (0.375)	90	157.5	35 °C (95 °F)	45 °C (113 °F)
11 (15)		15.88 (0.625)	96	143.5		
15 (20)		15.88 (0.625)	130	190		

¹ Cooling agent for the system is in scope of customers.

 CAUTION 

BRAZING OF COPPER TUBE

During brazing of the drive copper tubes with the system, the temperature around IGBT and cold plate portion rises. If the temperature exceeds 60 °C (140 °F), the drive trips.

- Pay attention to the temperature during brazing of the copper tube.

 CAUTION 

CONDENSATION


Avoid condensation on the cold plate and copper tube inside the drive.

- Maintain the refrigerant temperature in the range of 35–45 °C (95–113 °F).


3.1.6 Servicing the Drive

Procedure


1. Remove the drive mounting screws 4XM5/M6 (H3/H4).




2. Pull the drive out.



3. Apply adequate thermal paste in hatched section.



4. Fix the new/repaired drive to the mounting bracket 4XM5/M6 (H3/H4).



3.2 Electrical Installation

3.2.1 Tightening Torques

All cabling must comply with national and local regulations on cable cross-sections and ambient temperature. Copper conductors are required. 75 °C (167 °F) is recommended.

Table 7: Tightening Torques for Enclosure Sizes H3–H4, 3x380–480 V

Power [kW (hp)]				Torque [Nm (in-lb)]				
Enclosure size	IP class	3x380–480 V	Mains	Motor	DC connection	Control terminals	Ground	Relay
H3	IP20	7.5 (10)	0.8 (7)	0.8 (7)	0.8 (7)	0.5 (4)	0.8 (7)	0.5 (4)
H4	IP20	11–15 (15–20)	1.2 (11)	1.2 (11)	1.2 (11)	0.5 (4)	0.8 (7)	0.5 (4)

3.2.2 IT Mains


⚠ CAUTION ⚠

IT Mains

Installation on isolated mains source, that is, IT mains.

- Ensure that the supply voltage does not exceed 440 V (3x380–480 V units) when connected to mains.

On IP20, 380–480 V 7.5 kW (10 hp), 11 kW (15 hp), 15 kW (20 hp) units, open the RFI switch by removing the screw on the side of the drive when at IT grid.



e30bu392.10

- 1 EMC screw

Illustration 12: IP20, 380–480 V 7.5 kW (10 hp), 11 kW (15 hp), 15 kW (20 hp)

3.2.3 Mains and Motor Connection

3.2.3.1 Introduction


The drive is designed to operate all standard 3-phase asynchronous motors.

- Use a shielded/armored motor cable to comply with EMC emission specifications and connect this cable to both the decoupling plate and the motor.
- Keep the motor cable as short as possible to reduce the noise level and leakage currents.
- Also see EMC-Correct Installation in the design guide.

3.2.3.2 Connecting to Mains and Motor

1. Mount the ground cables to the ground terminal.
2. Connect the motor to terminals U, V, and W, and then tighten the screws according to the suggested tightening torques.
3. Connect the mains supply to terminals L1, L2, and L3, and then tighten the screws according to the suggested tightening torques.

3.2.3.3 Relays and Terminals on Enclosure Sizes H3–H4



1 Mains/input terminals	2 Ground terminals
3 Motor/output terminals	4 Thermal switch connector
5 Relay output connectors	6 Digital/analog I/O connector
7 RS485 connector	

Illustration 13: Enclosure Sizes H3–H4, IP20, 380–480 V, 7.5 kW (10 hp), 11 kW (15 hp), 15 kW (20 hp)

3.2.4 Fuses and Circuit Breakers

3.2.4.1 Branch Circuit Protection

To prevent fire hazards, protect the branch circuits in an installation - switch gear, machines, and so on - against short circuits and overcurrent. Follow national and local regulations.

3.2.4.2 Short-circuit Protection

Danfoss recommends using the fuses and circuit breakers listed in this chapter to protect service personnel or other equipment in case of an internal failure in the unit or a short circuit on the DC link. The drive provides full short-circuit protection in case of a short circuit on the motor.

3.2.4.3 Overcurrent Protection

Provide overload protection to avoid overheating of the cables in the installation. Overcurrent protection must always be carried out according to local and national regulations. Circuit breakers and fuses must be designed for protection in a circuit capable of supplying a maximum of 100000 A_{rms}(symmetrical), 480 V maximum.

3.2.4.4 CE Compliance

To ensure compliance with IEC 61800-5-1, use the circuit breakers or fuses listed in this chapter. Circuit breakers must be designed for protection in a circuit capable of supplying a maximum of 10000 A_{rms} (symmetrical), 480 V maximum.

3.2.4.5 Recommendation of Fuses and Circuit Breakers

NOTICE

In the event of malfunction, failure to follow the protection recommendation may result in damage to the drive.

Table 8: Fuses and Circuit Breakers (Non-UL)

Power [kW (hp)]	Circuit breaker	Maximum Fuse
		Type gG
3x380–480 V IP20		
7.5 (10)	–	25
11 (15)	–	50
15 (20)	–	50

3.2.5 EMC-correct Electrical Installation

General points to be observed to ensure EMC-correct electrical installation:

- Use only shielded/armored motor cables and shielded/armored control cables.
- Ground the shield at both ends.
- Avoid installation with twisted shield ends (pigtailed), because it reduces the shielding effect at high frequencies. Use the cable clamps provided.
- Ensure the same potential between the drive and the ground potential of PLC.
- It is important to ensure good electrical contact from the installation plate through the installation screws to the metal cabinet of the drive.
- Use star washers and galvanically conductive installation plates.

e30bb761.12





Illustration 14: EMC-correct Electrical Installation

3.2.6 Control Terminals

Remove the terminal cover to access the control terminals.

Use a flat-edged screwdriver to push down the lock lever of the terminal cover under the LCP, then remove the terminal cover as shown in the following illustration.




e30bd331.1C

Illustration 15: Removing the Terminal Cover

The following illustration shows all the drive control terminals. Applying start (terminal 18), connection between terminals 12-27, and an analog reference (terminal 53 or 54, and 55) make the drive run.

The digital input mode of terminal 18, 19, and 27 is set in *parameter 5-00 Digital Input Mode* (PNP is default value). Digital input 29 mode is set in *parameter 5-03 Digital Input 29 Mode* (PNP is default value).



e30bf892.10

Illustration 16: Control Terminals

3.2.7 Electrical Wiring




Illustration 17: Basic Wiring Schematic Drawing

3.2.8 Acoustic Noise or Vibration

If the motor or the equipment driven by the motor - for example, a fan - is making noise or vibrations at certain frequencies, configure the following parameters or parameter groups to reduce or eliminate the noise or vibrations:

- *Parameter group 4-6* Speed Bypass.*
- *Set parameter 14-03 Overmodulation to [0] Off.*
- *Switching pattern and switching frequency parameter group 14-0* Inverter Switching.*
- *Parameter 1-64 Resonance Dampening.*

4 Programming

4.1 Local Control Panel (LCP)

The drive can be programmed from the LCP or from a PC via the RS485 COM port by installing the MCT 10 Set-up Software.

The LCP is divided into 4 functional sections.

- A. Display
- B. Menu key
- C. Navigation keys and indicator lights
- D. Operation keys and indicator lights




Illustration 18: Local Control Panel (LCP)

A. Display

The LCD-display is illuminated with 2 alphanumeric lines. All data is shown on the LCP. The [illustration 18](#) describes the information that can be read from the display.

Table 9: Legend to Section A

1	Parameter number and name.
2	Parameter value.
3	Set-up number shows the active set-up and the edit set-up. If the same set-up acts as both active and edit set-up, only that set-up number is shown (factory setting). When active and edit set-up differ, both numbers are shown in the display (set-up 12). The number flashing indicates the edit set-up.
4	Motor direction is shown to the bottom left of the display – indicated by a small arrow pointing either clockwise or counter-clockwise.

5	The triangle indicates if the LCP is in Status, Quick Menu, or Main Menu.
---	---

B. Menu key

Press [Menu] to select among Status, Quick Menu, or Main Menu.

C. Navigation keys and indicator lights

Table 10: Legend to Section C

6	Com. LED: Flashes during bus communication.
7	Green LED/On: Control section is working correctly.
8	Yellow LED/Warn.: Indicates a warning.
9	Flashing Red LED/Alarm: Indicates an alarm.
10	[Back]: For moving to the previous step or layer in the navigation structure.
11	[▲] [▼] [▶]: For navigating among parameter groups and parameters, and within parameters. They can also be used for setting local reference.
12	[OK]: For selecting a parameter and for accepting changes to parameter settings.

D. Operation keys and indicator lights


Table 11: Legend to Section D

13	[Hand On]: Starts the motor and enables control of the drive via the LCP.
<div style="background-color: #cccccc; padding: 5px; margin: 5px 0;">NOTICE</div> <p><i>[2] Coast inverse is the default option for parameter 5-12 Terminal 27 Digital Input. If there is no 24 V supply to terminal 27, [Hand On] does not start the motor. Connect terminal 12 to terminal 27.</i></p>	
14	[Off/Reset]: Stops the motor (Off). If in alarm mode, the alarm is reset.
15	[Auto On]: The drive is controlled either via control terminals or serial communication.

4.2 Set-up Wizard

4.2.1 Set-up Wizard Introduction


The built-in wizard menu guides the installer through the set-up of the drive in a clear and structured manner for open-loop and closed-loop applications, and for quick motor settings.



e30bb674.11

Illustration 19: Drive Wiring


The wizard is shown after power-up until any parameter has been changed. The wizard can always be accessed again through the quick menu. Press [OK] to start the wizard. Press [Back] to return to the status view.



e30bb629.10

Illustration 20: Start-up/Quit Wizard

4.2.2 Set-up Wizard for Open-loop Applications



e30bc244.16

Illustration 21: Set-up Wizard for Open-loop Applications

Table 12: Set-up Wizard for Open-loop Applications

Parameter	Option	Default	Usage
<i>Parameter 0-03 Regional Settings</i>	<i>[0] International</i> <i>[1] US</i>	<i>[0] International</i>	–
<i>Parameter 0-06 GridType</i>	<i>[10] 380–440 V/50 Hz/IT-grid</i> <i>[11] 380–440 V/50 Hz/Delta</i> <i>[12] 380–440 V/50 Hz</i> <i>[20] 440–480 V/50 Hz/IT-grid</i> <i>[21] 440–480 V/50 Hz/Delta</i> <i>[22] 440–480 V/50 Hz</i> <i>[110] 380–440 V/60 Hz/IT-grid</i> <i>[111] 380–440 V/60 Hz/Delta</i> <i>[112] 380–440 V/60 Hz</i> <i>[120] 440–480 V/60 Hz/IT-grid</i> <i>[121] 440–480 V/60 Hz/Delta</i> <i>[122] 440–480 V/60 Hz</i>	Size related	Select the operating mode for restart after reconnection of the drive to mains voltage after power down.

Parameter	Option	Default	Usage
Parameter 1-10 Motor Construction	*[0] Asynchron [1] PM, non-salient SPM [3] PM, salient IPM	[0] Asynchron	Setting the parameter value might change these parameters: <ul style="list-style-type: none"> • Parameter 1-01 Motor Control Principle. • Parameter 1-03 Torque Characteristics. • Parameter 1-08 Motor Control Bandwidth. • Parameter 1-14 Damping Gain. • Parameter 1-15 Low Speed Filter Time Const. • Parameter 1-16 High Speed Filter Time Const. • Parameter 1-17 Voltage Filter Time Const. • Parameter 1-20 Motor Power. • Parameter 1-22 Motor Voltage. • Parameter 1-23 Motor Frequency. • Parameter 1-24 Motor Current. • Parameter 1-25 Motor Nominal Speed. • Parameter 1-26 Motor Cont. Rated Torque. • Parameter 1-30 Stator Resistance (Rs). • Parameter 1-33 Stator Leakage Reactance (X1). • Parameter 1-35 Main Reactance (Xh). • Parameter 1-37 d-axis Inductance (Ld). • Parameter 1-38 q-axis Inductance (Lq). • Parameter 1-39 Motor Poles. • Parameter 1-40 Back EMF at 1000 RPM. • Parameter 1-44 d-axis Inductance Sat. (LdSat). • Parameter 1-45 q-axis Inductance Sat. (LqSat). • Parameter 1-46 Position Detection Gain. • Parameter 1-48 Current at Min Inductance for d-axis. • Parameter 1-49 Current at Min Inductance for q-axis. • Parameter 1-66 Min. Current at Low Speed. • Parameter 1-70 PM Start Mode. • Parameter 1-72 Start Function. • Parameter 1-73 Flying Start. • Parameter 1-80 Function at Stop. • Parameter 1-82 Min Speed for Function at Stop [Hz]. • Parameter 1-90 Motor Thermal Protection. • Parameter 2-00 DC Hold/Motor Preheat Current. • Parameter 2-01 DC Brake Current. • Parameter 2-02 DC Braking Time. • Parameter 2-04 DC Brake Cut In Speed. • Parameter 2-10 Brake Function. • Parameter 4-14 Motor Speed High Limit [Hz]. • Parameter 4-19 Max Output Frequency. • Parameter 4-58 Missing Motor Phase Function. • Parameter 14-65 Speed Derate Dead Time Compensation.

Parameter	Option	Default	Usage
Parameter 1-20 Motor Power	0.12–110 kW/0.16–150 hp	Size related	Enter the motor power from the nameplate data.
Parameter 1-22 Motor Voltage	50–1000 V	Size related	Enter the motor voltage from the nameplate data.
Parameter 1-23 Motor Frequency	20–400 Hz	Size related	Enter the motor frequency from the nameplate data.
Parameter 1-24 Motor Current	0.01–10000.00 A	Size related	Enter the motor current from the nameplate data.
Parameter 1-25 Motor Nominal Speed	50–9999 RPM	Size related	Enter the motor nominal speed from the nameplate data.
Parameter 1-26 Motor Cont. Rated Torque	0.1–1000.0 Nm	Size related	This parameter is available when <i>parameter 1-10 Motor Construction</i> is set to options that enable permanent motor mode. <div style="border: 1px solid black; padding: 5px; text-align: center;"> <p>NOTICE</p> <p>Changing this parameter affects the settings of other parameters.</p> </div>
Parameter 1-29 Automatic Motor Adaption (AMA)	See <i>parameter 1-29 Automatic Motor Adaption (AMA)</i> .	Off	Performing an AMA optimizes motor performance.
Parameter 1-30 Stator Resistance (Rs)	0.000–99.990 Ω	Size related	Set the stator resistance value.
Parameter 1-37 d-axis Inductance (Ld)	0.000–1000.000 mH	Size related	Enter the value of the d-axis inductance. Obtain the value from the permanent magnet motor datasheet.
Parameter 1-38 q-axis Inductance (Lq)	0.000–1000.000 mH	Size related	Enter the value of the q-axis inductance.
Parameter 1-39 Motor Poles	2–100	4	Enter the number of motor poles.
Parameter 1-40 Back EMF at 1000 RPM	10–9000 V	Size related	Line-line RMS back EMF voltage at 1000 RPM.
Parameter 1-42 Motor Cable Length	0–100 m	50 m	Enter the motor cable length.
Parameter 1-44 d-axis Inductance Sat. (LdSat)	0.000–1000.000 mH	Size related	This parameter corresponds to the inductance saturation of Ld. Ideally, this parameter has the same value as <i>parameter 1-37 d-axis Inductance (Ld)</i> . However, if the motor supplier provides an induction curve, enter the induction value, which is 200% of the nominal current.
Parameter 1-45 q-axis Inductance Sat. (LqSat)	0.000–1000.000 mH	Size related	This parameter corresponds to the inductance saturation of Lq. Ideally, this parameter has the same value as <i>parameter 1-38 q-axis Inductance (Lq)</i> . However, if the motor supplier provides an induction curve, enter the induction value, which is 200% of the nominal current.
Parameter 1-46 Position Detection Gain	20–200%	100%	Adjusts the height of the test pulse during position detection at start.

Parameter	Option	Default	Usage
<i>Parameter 1-48 Current at Min Inductance for d-axis</i>	20–200%	100%	Enter the inductance saturation point.
<i>Parameter 1-49 Current at Min Inductance for q-axis</i>	20–200%	100%	This parameter specifies the saturation curve of the d- and q-inductance values. From 20–100% of this parameter, the inductances are linearly approximated due to <i>parameter 1-37 d-axis Inductance (Ld)</i> , <i>parameter 1-38 q-axis Inductance (Lq)</i> , <i>parameter 1-44 d-axis Inductance Sat. (LdSat)</i> , and <i>parameter 1-45 q-axis Inductance Sat. (LqSat)</i> .
<i>Parameter 1-70 PM Start Mode</i>	[0] Rotor Detection [1] Parking	[0] Rotor Detection	Select the PM motor start mode.
<i>Parameter 1-73 Flying Start</i>	[0] Disabled [1] Enabled	[0] Disabled	Select [1] Enabled to enable the drive to catch a motor spinning due to mains dropout. Select [0] Disabled if this function is not required. When this parameter is set to [1] Enabled, <i>parameter 1-71 Start Delay</i> and <i>parameter 1-72 Start Function</i> are not functional. <i>Parameter 1-73 Flying Start</i> is active in VVC ⁺ mode only.
<i>Parameter 3-02 Minimum Reference</i>	-4999.000–4999.000	0	The minimum reference is the lowest value obtainable by summing all references.
<i>Parameter 3-03 Maximum Reference</i>	-4999.000–4999.000	50	The maximum reference is the lowest obtainable by summing all references.
<i>Parameter 3-41 Ramp 1 Ramp Up Time</i>	0.05–3600.00 s	Size related	If asynchronous motor is selected, the ramp-up time is from 0 to rated <i>parameter 1-23 Motor Frequency</i> . If PM motor is selected, the ramp-up time is from 0 to <i>parameter 1-25 Motor Nominal Speed</i> .
<i>Parameter 3-42 Ramp 1 Ramp Down Time</i>	0.05–3600.00 s	Size related	For asynchronous motors, the ramp-down time is from rated <i>parameter 1-23 Motor Frequency</i> to 0. For PM motors, the ramp-down time is from <i>parameter 1-25 Motor Nominal Speed</i> to 0.
<i>Parameter 4-12 Motor Speed Low Limit [Hz]</i>	0.0–400.0 Hz	0 Hz	Enter the minimum limit for low speed.
<i>Parameter 4-14 Motor Speed High Limit [Hz]</i>	0.0–400.0 Hz	100 Hz	Enter the maximum limit for high speed.
<i>Parameter 4-19 Max Output Frequency</i>	0.0–400.0 Hz	100 Hz	Enter the maximum output frequency value. If <i>parameter 4-19 Max Output Frequency</i> is set lower than <i>parameter 4-14 Motor Speed High Limit [Hz]</i> , <i>parameter 4-14 Motor Speed High Limit [Hz]</i> will be set equal to <i>parameter 4-19 Max Output Frequency</i> automatically.
<i>Parameter 5-40 Function Relay</i>	See <i>parameter 5-40 Function Relay</i> .	[9] Alarm	Select the function to control output relay 1.
<i>Parameter 5-40 Function Relay</i>	See <i>parameter 5-40 Function Relay</i> .	[5] Drive running	Select the function to control output relay 2.
<i>Parameter 6-10 Terminal 53 Low Voltage</i>	0.00–10.00 V	0.07 V	Enter the voltage that corresponds to the low reference value.
<i>Parameter 6-11 Terminal 53 High Voltage</i>	0.00–10.00 V	10 V	Enter the voltage that corresponds to the high reference value.
<i>Parameter 6-12 Terminal 53 Low Current</i>	0.00–20.00 mA	4 mA	Enter the current that corresponds to the low reference value.

Parameter	Option	Default	Usage
<i>Parameter 6-13 Terminal 53 High Current</i>	<i>0.00–20.00 mA</i>	<i>20 mA</i>	Enter the current that corresponds to the high reference value.
<i>Parameter 6-19 Terminal 53 mode</i>	<i>[0] Current</i> <i>[1] Voltage</i>	<i>[1] Voltage</i>	Select if terminal 53 is used for current or voltage input.
<i>Parameter 30-22 Locked Rotor Detection</i>	<i>[0] Off</i> <i>[1] On</i>	<i>[0] Off</i>	–
<i>Parameter 30-23 Locked Rotor Detection Time [s]</i>	<i>0.05–1 s</i>	<i>0.10 s</i>	–

4.2.3 Set-up Wizard for Closed-loop Applications

e30bc402.14




Illustration 22: Set-up Wizard for Closed-loop Applications

Table 13: Set-up Wizard for Closed-loop Applications

Parameter	Range	Default	Usage
Parameter 0-03 Regional Settings	[0] International [1] US	[0] International	–
Parameter 0-06 GridType	[10] 380–440 V/50 Hz/IT-grid [11] 380–440 V/50 Hz/Delta [12] 380–440 V/50 Hz [20] 440–480 V/50 Hz/IT-grid [21] 440–480 V/50 Hz/Delta [22] 440–480 V/50 Hz [110] 380–440 V/60 Hz/IT-grid [111] 380–440 V/60 Hz/Delta [112] 380–440 V/60 Hz [120] 440–480 V/60 Hz/IT-grid [121] 440–480 V/60 Hz/Delta [122] 440–480 V/60 Hz	Size selected	Select the operating mode for restart after reconnection of the drive to mains voltage after power down.
Parameter 1-00 Configuration Mode	[0] Open loop [3] Closed loop	[0] Open loop	Select [3] Closed loop.

Parameter	Range	Default	Usage
Parameter 1-10 Motor Construction	<p>*[0] Asynchron</p> <p>[1] PM, non-salient SPM</p> <p>[3] PM, salient IPM</p>	[0] Asynchron	<p>Setting the parameter value might change these parameters:</p> <ul style="list-style-type: none"> • Parameter 1-01 Motor Control Principle. • Parameter 1-03 Torque Characteristics. • Parameter 1-08 Motor Control Bandwidth. • Parameter 1-14 Damping Gain. • Parameter 1-15 Low Speed Filter Time Const. • Parameter 1-16 High Speed Filter Time Const. • Parameter 1-17 Voltage Filter Time Const. • Parameter 1-20 Motor Power. • Parameter 1-22 Motor Voltage. • Parameter 1-23 Motor Frequency. • Parameter 1-24 Motor Current. • Parameter 1-25 Motor Nominal Speed. • Parameter 1-26 Motor Cont. Rated Torque. • Parameter 1-30 Stator Resistance (Rs). • Parameter 1-33 Stator Leakage Reactance (X1). • Parameter 1-35 Main Reactance (Xh). • Parameter 1-37 d-axis Inductance (Ld). • Parameter 1-38 q-axis Inductance (Lq). • Parameter 1-39 Motor Poles. • Parameter 1-40 Back EMF at 1000 RPM. • Parameter 1-44 d-axis Inductance Sat. (LdSat). • Parameter 1-45 q-axis Inductance Sat. (LqSat). • Parameter 1-46 Position Detection Gain. • Parameter 1-48 Current at Min Inductance for d-axis. • Parameter 1-49 Current at Min Inductance for q-axis. • Parameter 1-66 Min. Current at Low Speed. • Parameter 1-70 PM Start Mode. • Parameter 1-72 Start Function. • Parameter 1-73 Flying Start. • Parameter 1-80 Function at Stop. • Parameter 1-82 Min Speed for Function at Stop [Hz]. • Parameter 1-90 Motor Thermal Protection. • Parameter 2-00 DC Hold/Motor Preheat Current. • Parameter 2-01 DC Brake Current. • Parameter 2-02 DC Braking Time. • Parameter 2-04 DC Brake Cut In Speed. • Parameter 2-10 Brake Function. • Parameter 4-14 Motor Speed High Limit [Hz]. • Parameter 4-19 Max Output Frequency. • Parameter 4-58 Missing Motor Phase Function. • Parameter 14-65 Speed Derate Dead Time Compensation.

Parameter	Range	Default	Usage
Parameter 1-20 Motor Power	0.09–110 kW	Size related	Enter the motor power from the nameplate data.
Parameter 1-22 Motor Voltage	50–1000 V	Size related	Enter the motor voltage from the nameplate data.
Parameter 1-23 Motor Frequency	20–400 Hz	Size related	Enter the motor frequency from the nameplate data.
Parameter 1-24 Motor Current	0–10000 A	Size related	Enter the motor current from the nameplate data.
Parameter 1-25 Motor Nominal Speed	50–9999 RPM	Size related	Enter the motor nominal speed from the nameplate data.
Parameter 1-26 Motor Cont. Rated Torque	0.1–1000.0 Nm	Size related	This parameter is available when <i>parameter 1-10 Motor Construction</i> is set to options that enable permanent motor mode. <div style="text-align: center; border: 1px solid black; padding: 5px;"> <p>NOTICE</p> <p>Changing this parameter affects the settings of other parameters.</p> </div>
Parameter 1-29 Automatic Motor Adaption (AMA)	–	Off	Performing an AMA optimizes motor performance.
Parameter 1-30 Stator Resistance (Rs)	0–99.990 Ω	Size related	Set the stator resistance value.
Parameter 1-37 d-axis Inductance (Ld)	0.000–1000.000 mH	Size related	Enter the value of the d-axis inductance. Obtain the value from the permanent magnet motor datasheet.
Parameter 1-38 q-axis Inductance (Lq)	0.000–1000.000 mH	Size related	Enter the value of the q-axis inductance.
Parameter 1-39 Motor Poles	2–100	4	Enter the number of motor poles.
Parameter 1-40 Back EMF at 1000 RPM	10–9000 V	Size related	Line-line RMS back EMF voltage at 1000 RPM.
Parameter 1-42 Motor Cable Length	0–100 m	50 m	Enter the motor cable length.
Parameter 1-44 d-axis Inductance Sat. (LdSat)	0.000–1000.000 mH	Size related	This parameter corresponds to the inductance saturation of Ld. Ideally, this parameter has the same value as <i>parameter 1-37 d-axis Inductance (Ld)</i> . However, if the motor supplier provides an induction curve, enter the induction value, which is 200% of the nominal current.
Parameter 1-45 q-axis Inductance Sat. (LqSat)	0.000–1000.000 mH	Size related	This parameter corresponds to the inductance saturation of Lq. Ideally, this parameter has the same value as <i>parameter 1-38 q-axis Inductance (Lq)</i> . However, if the motor supplier provides an induction curve, enter the induction value, which is 200% of the nominal current.
Parameter 1-46 Position Detection Gain	20–200%	100%	Adjusts the height of the test pulse during position detection at start.
Parameter 1-48 Current at Min Inductance for d-axis	20–200%	100%	Enter the inductance saturation point.

Parameter	Range	Default	Usage
<i>Parameter 1-49 Current at Min Inductance for q-axis</i>	20–200%	100%	This parameter specifies the saturation curve of the d- and q-inductance values. From 20–100% of this parameter, the inductances are linearly approximated due to <i>parameter 1-37 d-axis Inductance (Ld)</i> , <i>parameter 1-38 q-axis Inductance (Lq)</i> , <i>parameter 1-44 d-axis Inductance Sat. (LdSat)</i> , and <i>parameter 1-45 q-axis Inductance Sat. (LqSat)</i> .
<i>Parameter 1-70 PM Start Mode</i>	[0] Rotor Detection [1] Parking	[0] Rotor Detection	Select the PM motor start mode.
<i>Parameter 1-73 Flying Start</i>	[0] Disabled [1] Enabled	[0] Disabled	Select [1] Enabled to enable the drive to catch a spinning motor in, for example, fan applications. When PM is selected, this parameter is enabled.
<i>Parameter 3-02 Minimum Reference</i>	-4999.000–4999.000	0	The minimum reference is the lowest value obtainable by summing all references.
<i>Parameter 3-03 Maximum Reference</i>	-4999.000–4999.000	50	The maximum reference is the highest value obtainable by summing all references.
<i>Parameter 3-10 Preset Reference</i>	-100–100%	0	Enter the setpoint.
<i>Parameter 3-41 Ramp 1 Ramp Up Time</i>	0.05–3600.0 s	Size related	Ramp-up time from 0 to rated <i>parameter 1-23 Motor Frequency</i> for asynchronous motors. Ramp-up time from 0 to <i>parameter 1-25 Motor Nominal Speed</i> for PM motors.
<i>Parameter 3-42 Ramp 1 Ramp Down Time</i>	0.05–3600.0 s	Size related	Ramp-down time from rated <i>parameter 1-23 Motor Frequency</i> to 0 for asynchronous motors. Ramp-down time from <i>parameter 1-25 Motor Nominal Speed</i> to 0 for PM motors.
<i>Parameter 4-12 Motor Speed Low Limit [Hz]</i>	0.0–400.0 Hz	0.0 Hz	Enter the minimum limit for low speed.
<i>Parameter 4-14 Motor Speed High Limit [Hz]</i>	0.0–400.0 Hz	100 Hz	Enter the minimum limit for high speed.
<i>Parameter 4-19 Max Output Frequency</i>	0.0–400.0 Hz	100 Hz	Enter the maximum output frequency value. If <i>parameter 4-19 Max Output Frequency</i> is set lower than <i>parameter 4-14 Motor Speed High Limit [Hz]</i> , <i>parameter 4-14 Motor Speed High Limit [Hz]</i> will be set equal to <i>parameter 4-19 Max Output Frequency</i> automatically.
<i>Parameter 6-20 Terminal 54 Low Voltage</i>	0.00–10.00 V	0.07 V	Enter the voltage that corresponds to the low reference value.
<i>Parameter 6-21 Terminal 54 High Voltage</i>	0.00–10.00 V	10.00 V	Enter the voltage that corresponds to the high reference value.
<i>Parameter 6-22 Terminal 54 Low Current</i>	0.00–20.00 mA	4.00 mA	Enter the current that corresponds to the low reference value.
<i>Parameter 6-23 Terminal 54 High Current</i>	0.00–20.00 mA	20.00 mA	Enter the current that corresponds to the high reference value.
<i>Parameter 6-24 Terminal 54 Low Ref./Feedb. Value</i>	-4999–4999	0	Enter the feedback value that corresponds to the voltage or current set in <i>parameter 6-20 Terminal 54 Low Voltage/parameter 6-22 Terminal 54 Low Current</i> .

Parameter	Range	Default	Usage
<i>Parameter 6-25 Terminal 54 High Ref./Feedb. Value</i>	-4999–4999	50	Enter the feedback value that corresponds to the voltage or current set in <i>parameter 6-21 Terminal 54 High Voltage/parameter 6-23 Terminal 54 High Current</i> .
<i>Parameter 6-26 Terminal 54 Filter Time Constant</i>	0.00–10.00 s	0.01	Enter the filter time constant.
<i>Parameter 6-29 Terminal 54 mode</i>	[0] Current [1] Voltage	[1] Voltage	Select if terminal 54 is used for current or voltage input.
<i>Parameter 20-81 PI Normal/Inverse Control</i>	[0] Normal [1] Inverse	[0] Normal	Select [0] Normal to set the process control to increase the output speed when the process error is positive. Select [1] Inverse to reduce the output speed.
<i>Parameter 20-83 PI Start Speed [Hz]</i>	0–200 Hz	0 Hz	Enter the motor speed to be attained as a start signal for commencement of PI control.
<i>Parameter 20-93 PI Proportional Gain</i>	0.00–10.00	0.01	Enter the process controller proportional gain. Quick control is obtained at high amplification. However, if amplification is too high, the process may become unstable.
<i>Parameter 20-94 PI Integral Time</i>	0.1–999.0 s	999.0 s	Enter the process controller integral time. Obtain quick control through a short integral time, though if the integral time is too short, the process becomes unstable. An excessively long integral time disables the integral action.
<i>Parameter 30-22 Locked Rotor Detection</i>	[0] Off [1] On	[0] Off	–
<i>Parameter 30-23 Locked Rotor Detection Time [s]</i>	0.05–1.00 s	0.10 s	–

4.2.4 Motor Set-up

The motor set-up wizard guides users through the needed motor parameters.

Table 14: Motor Set-up Wizard Settings

Parameter	Range	Default	Usage
<i>Parameter 0-03 Regional Settings</i>	[0] International [1] US	[0] International	–

Parameter	Range	Default	Usage
<i>Parameter 0-06 GridType</i>	<p>[10] 380–440 V/50 Hz/IT-grid</p> <p>[11] 380–440 V/50 Hz/Delta</p> <p>[12] 380–440 V/50 Hz</p> <p>[20] 440–480 V/50 Hz/IT-grid</p> <p>[21] 440–480 V/50 Hz/Delta</p> <p>[22] 440–480 V/50 Hz</p> <p>[110] 380–440 V/60 Hz/IT-grid</p> <p>[111] 380–440 V/60 Hz/Delta</p> <p>[112] 380–440 V/60 Hz</p> <p>[120] 440–480 V/60 Hz/IT-grid</p> <p>[121] 440–480 V/60 Hz/Delta</p> <p>[122] 440–480 V/60 Hz</p>	Size selected	Select the operating mode for restart after reconnection of the drive to mains voltage after power down.

Parameter	Range	Default	Usage
Parameter 1-10 Motor Construction	<p>*[0] Asynchron</p> <p>[1] PM, non-salient SPM</p> <p>[3] PM, salient IPM</p>	[0] Asynchron	<p>Setting the parameter value might change these parameters:</p> <ul style="list-style-type: none"> • Parameter 1-01 Motor Control Principle. • Parameter 1-03 Torque Characteristics. • Parameter 1-08 Motor Control Bandwidth. • Parameter 1-14 Damping Gain. • Parameter 1-15 Low Speed Filter Time Const. • Parameter 1-16 High Speed Filter Time Const. • Parameter 1-17 Voltage Filter Time Const. • Parameter 1-20 Motor Power. • Parameter 1-22 Motor Voltage. • Parameter 1-23 Motor Frequency. • Parameter 1-24 Motor Current. • Parameter 1-25 Motor Nominal Speed. • Parameter 1-26 Motor Cont. Rated Torque. • Parameter 1-30 Stator Resistance (Rs). • Parameter 1-33 Stator Leakage Reactance (X1). • Parameter 1-35 Main Reactance (Xh). • Parameter 1-37 d-axis Inductance (Ld). • Parameter 1-38 q-axis Inductance (Lq). • Parameter 1-39 Motor Poles. • Parameter 1-40 Back EMF at 1000 RPM. • Parameter 1-44 d-axis Inductance Sat. (LdSat). • Parameter 1-45 q-axis Inductance Sat. (LqSat). • Parameter 1-46 Position Detection Gain. • Parameter 1-48 Current at Min Inductance for d-axis. • Parameter 1-49 Current at Min Inductance for q-axis. • Parameter 1-66 Min. Current at Low Speed. • Parameter 1-70 PM Start Mode. • Parameter 1-72 Start Function. • Parameter 1-73 Flying Start. • Parameter 1-80 Function at Stop. • Parameter 1-82 Min Speed for Function at Stop [Hz]. • Parameter 1-90 Motor Thermal Protection. • Parameter 2-00 DC Hold/Motor Preheat Current. • Parameter 2-01 DC Brake Current. • Parameter 2-02 DC Braking Time. • Parameter 2-04 DC Brake Cut In Speed. • Parameter 2-10 Brake Function. • Parameter 4-14 Motor Speed High Limit [Hz]. • Parameter 4-19 Max Output Frequency. • Parameter 4-58 Missing Motor Phase Function. • Parameter 14-65 Speed Derate Dead Time Compensation.

Parameter	Range	Default	Usage
Parameter 1-20 Motor Power	0.12–110 kW/0.16–150 hp	Size related	Enter the motor power from the nameplate data.
Parameter 1-22 Motor Voltage	50–1000 V	Size related	Enter the motor voltage from the nameplate data.
Parameter 1-23 Motor Frequency	20–400 Hz	Size related	Enter the motor frequency from the nameplate data.
Parameter 1-24 Motor Current	0.01–10000.00 A	Size related	Enter the motor current from the nameplate data.
Parameter 1-25 Motor Nominal Speed	50–9999 RPM	Size related	Enter the motor nominal speed from the nameplate data.
Parameter 1-26 Motor Cont. Rated Torque	0.1–1000.0 Nm	Size related	<p>This parameter is available when <i>parameter 1-10 Motor Construction</i> is set to options that enable permanent motor mode.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p style="text-align: center; margin: 0;">NOTICE</p> <p style="margin: 0;">Changing this parameter affects the settings of other parameters.</p> </div>
Parameter 1-30 Stator Resistance (Rs)	0–99.990 Ω	Size related	Set the stator resistance value.
Parameter 1-37 d-axis Inductance (Ld)	0.000–1000.000 mH	Size related	Enter the value of the d-axis inductance. Obtain the value from the permanent magnet motor datasheet.
Parameter 1-38 q-axis Inductance (Lq)	0.000–1000.000 mH	Size related	Enter the value of the q-axis inductance.
Parameter 1-39 Motor Poles	2–100	4	Enter the number of motor poles.
Parameter 1-40 Back EMF at 1000 RPM	10–9000 V	Size related	Line-line RMS back EMF voltage at 1000 RPM.
Parameter 1-42 Motor Cable Length	0–100 m	50 m	Enter the motor cable length.
Parameter 1-44 d-axis Inductance Sat. (LdSat)	0.000–1000.000 mH	Size related	This parameter corresponds to the inductance saturation of Ld. Ideally, this parameter has the same value as <i>parameter 1-37 d-axis Inductance (Ld)</i> . However, if the motor supplier provides an induction curve, enter the induction value, which is 200% of the nominal current.
Parameter 1-45 q-axis Inductance Sat. (LqSat)	0.000–1000.000 mH	Size related	This parameter corresponds to the inductance saturation of Lq. Ideally, this parameter has the same value as <i>parameter 1-38 q-axis Inductance (Lq)</i> . However, if the motor supplier provides an induction curve, enter the induction value, which is 200% of the nominal current.
Parameter 1-46 Position Detection Gain	20–200%	100%	Adjusts the height of the test pulse during position detection at start.
Parameter 1-48 Current at Min Inductance for d-axis	20–200%	100%	Enter the inductance saturation point.

Parameter	Range	Default	Usage
<i>Parameter 1-49 Current at Min Inductance for q-axis</i>	20–200%	100%	This parameter specifies the saturation curve of the d- and q-inductance values. From 20–100% of this parameter, the inductances are linearly approximated due to <i>parameter 1-37 d-axis Inductance (Ld)</i> , <i>parameter 1-38 q-axis Inductance (Lq)</i> , <i>parameter 1-44 d-axis Inductance Sat. (LdSat)</i> , and <i>parameter 1-45 q-axis Inductance Sat. (LqSat)</i> .
<i>Parameter 1-70 PM Start Mode</i>	[0] Rotor Detection [1] Parking	[0] Rotor Detection	Select the PM motor start mode.
<i>Parameter 1-73 Flying Start</i>	[0] Disabled [1] Enabled	[0] Disabled	Select [1] Enabled to enable the drive to catch a spinning motor.
<i>Parameter 3-41 Ramp 1 Ramp Up Time</i>	0.05–3600.0 s	Size related	Ramp-up time from 0 to rated <i>parameter 1-23 Motor Frequency</i> .
<i>Parameter 3-42 Ramp 1 Ramp Down Time</i>	0.05–3600.0 s	Size related	Ramp-down time from rated <i>parameter 1-23 Motor Frequency</i> to 0.
<i>Parameter 4-12 Motor Speed Low Limit [Hz]</i>	0.0–400.0 Hz	0.0 Hz	Enter the minimum limit for low speed.
<i>Parameter 4-14 Motor Speed High Limit [Hz]</i>	0.0–400.0 Hz	100.0 Hz	Enter the maximum limit for high speed.
<i>Parameter 4-19 Max Output Frequency</i>	0.0–400.0 Hz	100.0 Hz	Enter the maximum output frequency value. If <i>parameter 4-19 Max Output Frequency</i> is set lower than <i>parameter 4-14 Motor Speed High Limit [Hz]</i> , <i>parameter 4-14 Motor Speed High Limit [Hz]</i> will be set equal to <i>parameter 4-19 Max Output Frequency</i> automatically.
<i>Parameter 30-22 Locked Rotor Detection</i>	[0] Off [1] On	[0] Off	–
<i>Parameter 30-23 Locked Rotor Detection Time [s]</i>	0.05–1.00 s	0.10 s	–

4.2.5 Changes Made Function

The changes made function lists all parameters changed from default settings.

- The list shows only parameters that have been changed in the current edit set-up.
- Parameters that have been reset to default values are not listed.
- The message *Empty* indicates that no parameters have been changed.

4.2.6 Changing Parameter Settings

Procedure

1. To enter the Quick Menu, press the [Menu] key until the indicator in the display is placed above Quick Menu.
2. Press [▲] [▼] to select the wizard, closed-loop setup, motor set-up, or changes made.
3. Press [OK].
4. Press [▲] [▼] to browse through the parameters in the Quick Menu.
5. Press [OK] to select a parameter.
6. Press [▲] [▼] to change the value of a parameter setting.
7. Press [OK] to accept the change.
8. Press either [Back] twice to enter Status, or press [Menu] once to enter the Main Menu.

4.2.7 Accessing All Parameters via the Main Menu

Procedure

1. Press the [Menu] key until the indicator in the display is placed above Main Menu.
2. Press [▲] [▼] to browse through the parameter groups.
3. Press [OK] to select a parameter group.
4. Press [▲] [▼] to browse through the parameters in the specific group.
5. Press [OK] to select the parameter.
6. Press [▲] [▼] to set/change the parameter value.
7. Press [OK] to accept the change.

4.3 Parameter List

0-0*	Operation / Display	1-43	Motor Cable Length Feet	3-8*	Other Ramps	6-15	Terminal 53 High Ref./Feedb. Value	8-8*	FC Port Diagnostics
0-0*	Basic Settings	1-44	d-axis Inductance Sat. (LdSat)	3-80	Jog Ramp Time	6-16	Terminal 53 Filter Time Constant	8-80	Bus Message Count
0-01	Language	1-45	q-axis Inductance Sat. (LqSat)	3-81	Quick Stop Ramp Time	6-19	Terminal 53 mode	8-81	Bus Error Count
0-03	Regional Settings	1-46	Position Detection Gain	4-1*	Limits / Warnings	6-2*	Analog Input 54	8-82	Slave Messages Rcvd
0-04	Operating State at Power-up	1-48	Current at Min Inductance for d-axis	4-1*	Motor Limits	6-20	Terminal 54 Low Voltage	8-83	Slave Error Count
0-06	GridType	1-49	Current at Min Inductance for q-axis	4-10	Motor Speed Direction	6-21	Terminal 54 High Voltage	8-84	Slave Messages Sent
0-07	Auto DC Braking	1-5*	Load Indep. Setting	4-12	Motor Speed Low Limit (Hz)	6-22	Terminal 54 Low Current	8-85	Slave Timeout Errors
0-1*	Set-up Operations	1-50	Motor Magnetisation at Zero Speed	4-14	Motor Speed High Limit (Hz)	6-23	Terminal 54 High Current	8-88	Reset FC port Diagnostics
0-10	Active Set-up	1-52	Min Speed Normal Magnetising (Hz)	4-18	Current Limit	6-24	Terminal 54 Low Ref./Feedb. Value	8-9*	Bus Feedback
0-11	Programming Set-up	1-55	U/f Characteristic - U	4-19	Max Output Frequency	6-25	Terminal 54 High Ref./Feedb. Value	8-94	Bus Feedback 1
0-12	Link Setups	1-56	U/f Characteristic - F	4-4*	Adj. Warnings 2	6-26	Terminal 54 Filter Time Constant	8-95	Bus Feedback 2
0-3*	Custom Readout	1-6*	Load Depen. Setting	4-40	Warning Freq. Low	6-29	Terminal 54 mode	13-3*	Smart Logic
0-30	Custom Readout Unit	1-62	Slip Compensation	4-41	Warning Freq. High	6-7*	Analog/Digital Output 45	13-0*	SLC Settings
0-31	Custom Readout Min Value	1-63	Slip Compensation Time Constant	4-5*	Adj. Warnings	6-70	Terminal 45 Mode	13-00	SL Controller Mode
0-32	Custom Readout Max Value	1-64	Resonance Dampening	4-50	Warning Current Low	6-71	Terminal 45 Analog Output	13-01	Start Event
0-37	Display Text 1	1-65	Resonance Dampening Time Constant	4-51	Warning Current High	6-72	Terminal 45 Digital Output	13-02	Stop Event
0-38	Display Text 2	1-66	Min. Current at Low Speed	4-54	Warning Reference Low	6-73	Terminal 45 Output Min Scale	13-03	Reset SLC
0-39	Display Text 3	1-7*	Start Adjustments	4-55	Warning Reference High	6-74	Terminal 45 Output Max Scale	13-1*	Comparators
0-4*	LCP Keypad	1-70	Start Mode	4-56	Warning Feedback Low	6-76	Terminal 45 Output Bus Control	13-10	Comparator Operand
0-40	[Hand on] Key on LCP	1-71	Start Delay	4-57	Warning Feedback High	6-9*	Analog/Digital Output 42	13-11	Comparator Operator
0-42	[Auto on] Key on LCP	1-72	Start Function	4-58	Missing Motor Phase Function	6-90	Terminal 42 Mode	13-12	Comparator Value
0-44	[Off/Reset] Key on LCP	1-73	Flying Start	4-6*	Speed Bypass	6-91	Terminal 42 Analog Output	13-2*	Timers
0-5*	Copy/Save	1-8*	Stop Adjustments	4-61	Bypass Speed From (Hz)	6-92	Terminal 42 Digital Output	13-20	SL Controller Timer
0-51	Set-up Copy	1-80	Function at Stop	4-63	Bypass Speed To (Hz)	6-93	Terminal 42 Output Min Scale	13-4*	Logic Rules
0-6*	Password	1-82	Min Speed for Function at Stop (Hz)	4-64	Semi-Auto Bypass Set-up	6-94	Terminal 42 Output Max Scale	13-40	Logic Rule Boolean 1
0-60	Main Menu Password	1-88	AC Brake Gain	5-*	Digital In/Out	6-96	Terminal 42 Output Bus Control	13-41	Logic Rule Operator 1
0-61	Access to Main Menu w/o Password	1-9*	Motor Temperature	5-0*	Digital I/O mode	6-98	Drive Type	13-42	Logic Rule Boolean 2
1-*	Load and Motor	1-93	Thermistor Source	5-03	Digital Input 29 Mode	8-0*	General Settings	13-43	Logic Rule Operator 2
1-0*	General Settings	2-*	Brakes	5-03	Digital Input 29 Mode	8-0*	General Settings	13-44	Logic Rule Boolean 3
1-00	Configuration Mode	2-0*	DC Brake	5-1*	Digital Inputs	8-01	Control Site	13-5*	States
1-01	Motor Control Principle	2-0*	DC Hold/Motor Preheat Current	5-10	Terminal 18 Digital Input	8-02	Control Source	13-51	SL Controller Event
1-03	Torque Characteristics	2-00	DC Brake Current	5-11	Terminal 19 Digital Input	8-03	Control Timeout Time	13-52	SL Controller Action
1-06	Clockwise Direction	2-02	DC Braking Time	5-12	Terminal 20 Digital Input	8-04	Control Timeout Function	14-*	Special Functions
1-1*	Motor Selection	2-02	DC Brake Cut In Speed	5-13	Terminal 29 Digital Input	8-3*	FC Port Settings	14-0*	Inverter Switching
1-10	Motor Construction	2-04	DC Brake Cut In Speed	5-3*	Digital Outputs	8-30	Protocol	14-01	Switching Frequency
1-14	Damping Gain	2-06	Parking Current	5-34	On Delay Digital Output	8-31	Address	14-03	Overmodulation
1-15	Low Speed Filter Time Const.	2-07	Parking Time	5-35	Off Delay Digital Output	8-32	Baud Rate	14-07	Dead Time Compensation Level
1-16	High Speed Filter Time Const.	2-1*	Brake Energy Funct.	5-4*	Relays	8-33	Parity / Stop Bits	14-08	Damping Gain Factor
1-17	Voltage filter time const.	2-10	Brake Function	5-40	Function Relay	8-35	Minimum Response Delay	14-09	Dead Time Bias Current Level
1-2*	Motor Data	2-16	AC Brake, Max current	5-41	On Delay, Relay	8-36	Maximum Response Delay	14-1*	Mains Failure
1-20	Motor Power	2-17	Over-voltage Control	5-42	Off Delay, Relay	8-37	Maximum Inter-char delay	14-10	Mains Failure
1-22	Motor Voltage	2-19	Over-voltage Gain	5-5*	Pulse Input	8-4*	FC MC protocol set	14-11	Mains Fault Voltage Level
1-23	Motor Frequency	3-*	Reference / Ramps	5-50	Term. 29 Low Frequency	8-42	PCD Write Configuration	14-12	Response to Mains Imbalance
1-24	Motor Current	3-0*	Reference Limits	5-51	Term. 29 High Frequency	8-43	PCD Read Configuration	14-15	Kin. Back-up Trip Recovery Level
1-25	Motor Nominal Speed	3-02	Minimum Reference	5-52	Term. 29 Low Ref./Feedb. Value	8-5*	Digital/Bus	14-2*	Reset Functions
1-26	Motor Cont. Rated Torque	3-03	Maximum Reference	5-53	Term. 29 High Ref./Feedb. Value	8-50	Coasting Select	14-20	Reset Mode
1-3*	Adv. Motor Data	3-1*	References	5-9*	Bus Controlled	8-51	Quick Stop Select	14-21	Automatic Restart Time
1-30	Stator Resistance (Rs)	3-10	Preset Reference	5-90	Digital & Relay Bus Control	8-52	DC Brake Select	14-22	Operation Mode
1-33	Stator Leakage Reactance (Xl)	3-11	Jog Speed (Hz)	6-0*	Analog In/Out	8-53	Start Select	14-23	Typecode Setting
1-35	Main Reactance (Xh)	3-14	Preset Relative Reference	6-00	Live Zero Timeout Time	8-54	Reversing Select	14-27	Action At Inverter Fault
1-37	d-axis Inductance (Ld)	3-15	Reference 1 Source	6-01	Live Zero Timeout Function	8-55	Set-up Select	14-28	Production Settings
1-38	q-axis Inductance (Lq)	3-16	Reference 2 Source	6-02	Fire Mode Live Zero Timeout Function	8-56	Preset Reference Select	14-29	Service Code
1-39	Motor Poles	3-17	Reference 3 Source	6-1*	Analog Input 53	8-70	BACnet	14-30	Current Lim. Ctrl.
1-40	Back EMF at 1000 RPM	3-41	Ramp 1	6-10	Terminal 53 Low Voltage	8-72	BACnet Device Instance	14-31	Current Lim. Ctrl, Proportional Gain
1-42	Motor Cable Length	3-42	Ramp 1 Ramp Up Time	6-11	Terminal 53 High Voltage	8-73	MS/TP Max Masters	14-32	Current Lim. Ctrl, Integration Time
		3-51	Ramp 2 Ramp Up Time	6-12	Terminal 53 Low Current	8-74	MS/TP Max Info Frames	14-4*	Energy Optimising
		3-52	Ramp 2 Ramp Down Time	6-13	Terminal 53 High Current	8-75	Initialisation Password	14-40	VT Level
				6-14	Terminal 53 Low Ref./Feedb. Value	8-79	Protocol Firmware version	14-41	AEO Minimum Magnetisation

e30bu382.10

14-44	d-axis current optimization for IPM	16-11	Power [hp]	24-07	Fire Mode Feedback Source
14-5* Environment		16-12	Motor Voltage	24-09	FM Alarm Handling
14-50	REF Filter	16-13	Frequency	24-1* Drive Bypass	
14-51	DC-Link Voltage Compensation	16-14	Motor current	24-10	Drive Bypass Function
14-52	Fan Control	16-15	Frequency [%]	24-11	Drive Bypass Delay Time
14-53	Fan Monitor	16-16	Torque [Nm]	30-2** Special Features	
14-55	Output Filter	16-17	Speed [RPM]	30-2** Adv. Start Adjust	
14-6* Auto Derate		16-18	Motor Thermal	30-22	Locked Rotor Protection
14-61	Function at Inverter Overload	16-22	Torque [%]	30-23	Locked Rotor Detection Time [s]
14-63	Min Switch Frequency	16-26	Power Filtered [kW]	30-5* Unit Configuration	
14-64	Dead Time Compensation Zero Current Level	16-27	Power Filtered [hp]	30-58	LockPassword
14-65	Speed Derate Dead Time Compensation	16-3* Drive Status			
14-9* Fault Settings		16-30	DC Link Voltage		
14-90	Fault Level	16-34	Heatsink Temp.		
16-35	Inverter Thermal	16-36	Inv. Nom. Current		
16-37	Inv. Max. Current	16-38	SL Controller State		
15-0* Drive Information		16-5* Ref. & Feedb.			
15-00	Operating hours	16-50	External Reference		
15-01	Running Hours	16-52	Feedback[Unit]		
15-02	kWh Counter	16-54	Feedback 1 [Unit]		
15-03	Power Up's	16-55	Feedback 2 [Unit]		
15-04	Over Temp's	16-6* Inputs & Outputs			
15-05	Over Volt's	16-60	Digital Input		
15-06	Reset kWh Counter	16-61	Terminal 53 Setting		
15-07	Reset Running Hours Counter	16-62	Analog input 53		
15-3* Alarm Log		16-63	Terminal 54 Setting		
15-30	Alarm Log: Error Code	16-64	Analog input 54		
15-31	InternalFaultReason	16-65	Analog output 42 [mA]		
15-4* Drive Identification		16-66	Digital Output		
15-40	FC Type	16-67	Pulse input 29 [Hz]		
15-41	Power Section	16-71	Relay output		
15-42	Voltage	16-72	Counter A		
15-43	Software Version	16-73	Counter B		
15-44	Ordered TypeCode	16-79	Analog output 45 [mA]		
15-45	Actual Typecode String	16-8* Fieldbus & FC Port			
15-46	Drive Ordering No	16-86	FC Port REF 1		
15-48	LCP Id No	16-9* Diagnosis Readouts			
15-49	SW ID Control Card	16-90	Alarm Word		
15-50	SW ID Power Card	16-91	Alarm Word 2		
15-51	Drive Serial Number	16-92	Warning Word		
15-52	OEM Information	16-93	Warning Word 2		
15-53	Power Card Serial Number	16-94	Ext. Status Word		
15-57	File Version	16-95	Ext. Status Word 2		
15-59	Filename	16-97	Alarm Word 3		
15-9* Parameter Info		16-98	Warning Word 3		
15-92	Defined Parameters	18-2** Info & Readouts			
15-97	Application Type	18-1* Fire Mode Log			
15-98	Drive Identification	18-10	FireMode LogEvent		
16-2** Data Readouts		18-5* Ref. & Feedb.			
16-0* General Status		18-50	Sensorless Readout [unit]		
16-00	Control Word	20-0** Drive Closed Loop			
16-01	Reference [Unit]	20-0* Feedback			
16-02	Reference [%]	20-00	Feedback 1 Source		
16-03	Status Word	20-01	Feedback 1 Conversion		
16-05	Main Actual Value [%]	20-03	Feedback 2 Source		
16-09	Custom Readout	20-04	Feedback 2 Conversion		
16-1* Motor Status		20-12	Reference/Feedback Unit		
16-10	Power [kW]				
20-2* Feedback/Setpoint		22-0*	Miscellaneous		
20-20	Feedback Function	22-01	Power Filter Time		
20-21	Setpoint 1	22-02	Sleepmode CL Control Mode		
20-6* Sensorless		22-23	No-Flow Function		
20-60	Sensorless Unit	22-24	No-Flow Delay		
20-69	Sensorless Information	22-3* No-Flow Power Tuning			
20-8* PI Basic Settings		22-30	No-Flow Power		
20-81	PI Normal/ Inverse Control	22-31	Power Correction Factor		
20-83	PI Start Speed [Hz]	22-33	Low Speed [Hz]		
20-84	On Reference Bandwidth	22-34	Low Speed Power [kW]		
20-9* PI Controller		22-37	High Speed [Hz]		
20-91	PI Anti Windup	22-38	High Speed Power [kW]		
20-93	PI Proportional Gain	22-4* Sleep Mode			
20-94	PI Integral Time	22-40	Minimum Run Time		
20-97	PI Feed Forward Factor	22-41	Minimum Sleep Time		
22-2** Appl. Functions		22-43	Wake-Up Speed [Hz]		
22-0*	Miscellaneous	22-44	Wake-Up Ref./FB Diff		
22-01	Power Filter Time	22-45	Setpoint Boost		
22-02	Sleepmode CL Control Mode	22-46	Maximum Boost Time		
22-23	No-Flow Function	22-47	Sleep Speed [Hz]		
22-24	No-Flow Delay	22-48	Sleep Delay Time		
22-3* No-Flow Power Tuning		22-49	Wake-Up Delay Time		
22-30	No-Flow Power	22-6* Broken Belt Detection			
22-31	Power Correction Factor	22-60	Broken Belt Function		
22-33	Low Speed [Hz]	22-62	Broken Belt Torque		
22-34	Low Speed Power [kW]	22-8* Flow Compensation			
22-37	High Speed [Hz]	22-80	Flow Compensation		
22-38	High Speed Power [kW]	22-81	Square-linear Curve Approximation		
22-4* Sleep Mode		22-82	Work Point Calculation		
22-40	Minimum Run Time	22-84	Speed at No-Flow [Hz]		
22-41	Minimum Sleep Time	22-86	Speed at Design Point [Hz]		
22-43	Wake-Up Speed [Hz]	22-87	Pressure at No-Flow Speed		
22-44	Wake-Up Ref./FB Diff	22-88	Pressure at Rated Speed		
22-45	Setpoint Boost	22-89	Flow at Design Point		
22-46	Maximum Boost Time	22-90	Flow at Rated Speed		
22-47	Sleep Speed [Hz]	22-9** Appl. Functions 2			
22-48	Sleep Delay Time	24-0* Fire Mode			
22-6* Broken Belt Detection		24-00	FM Function		
22-60	Broken Belt Function	24-01	Fire Mode Configuration		
22-62	Broken Belt Torque	24-05	FM Preset Reference		
22-8* Flow Compensation		24-06	Fire Mode Reference Source		
22-80	Flow Compensation				
22-81	Square-linear Curve Approximation				
22-82	Work Point Calculation				
22-84	Speed at No-Flow [Hz]				
22-86	Speed at Design Point [Hz]				
22-87	Pressure at No-Flow Speed				
22-88	Pressure at Rated Speed				
22-89	Flow at Design Point				
22-90	Flow at Rated Speed				

e30bu383.10

5 Warnings and Alarms

5.1 List of Warnings and Alarms

Table 15: Warnings and Alarms

Fault number	Alarm/warning bit number	Fault text	Warning	Alarm	Trip locked	Cause of problem
2	16	Live zero error	X	X	–	Signal on terminal 53 or 54 is less than 50% of the value set in <i>parameter 6-10 Terminal 53 Low Voltage</i> , <i>parameter 6-12 Terminal 53 Low Current</i> , <i>parameter 6-20 Terminal 54 Low Voltage</i> , or <i>parameter 6-22 Terminal 54 Low Current</i> . See also <i>parameter group 6-0* Analog I/O Mode</i> .
4	14	Mains ph. loss	X	X	X	Missing phase on the supply side or too high voltage imbalance. Check the supply voltage. See <i>parameter 14-12 Function at Mains Imbalance</i> .
7	11	DC over volt	X	X	–	Intermediate circuit voltage exceeds the limit.
8	10	DC under volt	X	X	–	Intermediate circuit voltage drops below voltage warning low-limit.
9	9	Inverter overload	X	X	–	More than 100% load for a long time.
10	8	Motor ETR over	X	X	–	Motor is too hot due to more than 100% load for a long time. See <i>parameter 1-90 Motor Thermal Protection</i> .
11	7	Motor th over	X	X	–	Thermistor or thermistor connection is disconnected. See <i>parameter 1-90 Motor Thermal Protection</i> .
13	5	Over Current	X	X	X	Inverter peak current limit is exceeded.
14	2	Earth Fault	–	X	X	Discharge from output phases to ground.
16	12	Short Circuit	–	X	X	Short circuit in motor or on motor terminals.
17	4	Ctrl. word TO	X	X	–	No communication to drive. See <i>parameter group 8-0* General Settings</i> .
24	50	Fan Fault	X	X	–	The heat sink cooling fan is not working.
30	19	U phase loss	–	X	X	Motor phase U is missing. Check the phase. See <i>parameter 4-58 Missing Motor Phase Function</i> .
31	20	V phase loss	–	X	X	Motor phase V is missing. Check the phase. See <i>parameter 4-58 Missing Motor Phase Function</i> .
32	21	W phase loss	–	X	X	Motor phase W is missing. Check the phase. See <i>parameter 4-58 Missing Motor Phase Function</i> .
38	17	Internal fault	–	X	X	Contact the local Danfoss supplier.
44	28	Earth Fault	–	X	X	Discharge from output phases to ground, using the value of <i>parameter 15-31 Alarm Log Value</i> if possible.
46	33	Control Voltage Fault	–	X	X	Control voltage is low. Contact the local Danfoss supplier.

Fault number	Alarm/warning bit number	Fault text	Warning	Alarm	Trip locked	Cause of problem
47	23	24 V supply low	X	X	X	24 V DC supply may be overloaded.
50	–	AMA calibration failed	–	X	–	Contact the local Danfoss supplier.
51	15	AMA Unom, Inom	–	X	–	The setting of motor voltage, motor current, and motor power is wrong. Check the settings.
52	–	AMA low Inom	–	X	–	The motor current is too low. Check the settings.
53	–	AMA big motor	–	X	–	The motor is too big to perform AMA.
54	–	AMA small mot	–	X	–	The motor is too small to perform AMA.
55	–	AMA par. range	–	X	–	The parameter values found from the motor are outside the acceptable range.
56	–	AMA user interrupt	–	X	–	The AMA has been interrupted by the user.
57	–	AMA timeout	–	X	–	<p>Try to start the AMA again a number of times, until the AMA is carried out.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p style="text-align: center; margin: 0;">NOTICE</p> <p style="margin: 0;">Repeated runs may heat the motor to a level where the resistance R_s and R_r are increased. In most cases, however, this is not critical.</p> </div>
58	–	AMA internal	X	X	–	Contact the local Danfoss supplier.
59	25	Current limit	X	–	–	The current is higher than the value in <i>parameter 4-18 Current Limit</i> .
60	44	External Interlock	–	X	–	External interlock has been activated. To resume normal operation, apply 24 V DC to the terminal programmed for external interlock and reset the drive (via serial communication, digital I/O, or by pressing [Reset] button on the LCP).
66	26	Heat sink Temperature Low	X	–	–	This warning is based on the temperature sensor in the IGBT module.
69	1	Pwr. Card Temp	X	X	X	The temperature sensor on the power card exceeds the upper or lower limits.
70	36	Illegal FC configuration	–	X	X	The control card and power card are not matched.
79	–	Illegal power section configuration	X	X	–	Internal fault. Contact the local Danfoss supplier.

Fault number	Alarm/warning bit number	Fault text	Warning	Alarm	Trip locked	Cause of problem
80	29	Drive initialised	–	X	–	All parameter settings are initialized to default settings.
87	47	Auto DC Braking	X	–	–	The drive is auto DC braking.
95	40	Broken Belt	X	X	–	Torque is below the torque level set for no load, indicating a broken belt. See <i>parameter group 22-6* Broken Belt Detection</i> .
126	–	Motor Rotating	–	X	–	High back EMF voltage. Stop the rotor of the PM motor.
200	–	Fire Mode	X	–	–	Fire mode has been activated.
202	–	Fire Mode Limits Exceeded	X	–	–	Fire mode has suppressed 1 or more warranty voiding alarms.
250	–	New spare-part	–	X	X	The power or switch mode power supply has been exchanged. Contact the local Danfoss supplier.
251	–	New Type-code	–	X	X	The drive has a new type code. Contact the local Danfoss supplier.

6 Specifications

6.1 Mains Supply 3x380–480 V AC

Table 16: 3x380–480 V AC, 7.5–15 kW (10–20 hp), Enclosure Sizes H3–H4

Drive	P7K5	P11K	P15K
Typical shaft output [kW]	7.5	11.0	15.0
Typical shaft output [hp]	10.0	15.0	20.0
Protection rating IP20	H3	H4	H4
Maximum cable size in terminals (mains, motor) [mm ² (AWG)]	4 (10)	16 (6)	16 (6)
Output current at 40°C (104°F) ambient temperature and 45°C (113°F) refrigerant temperature			
Continuous (3x380–440 V) [A]	15.5	23.0	31.0
Intermittent (3x380–440 V) [A]	17.1	25.3	34.0
Continuous (3x441–480 V) [A]	14.0	21.0	27.0
Intermittent (3x441–480 V) [A]	15.4	23.1	29.7
Maximum input current			
Continuous (3x380–440 V) [A]	15.1	22.1	29.9
Intermittent (3x380–440 V) [A]	16.6	24.3	32.9
Continuous (3x441–480 V) [A]	12.6	18.4	24.7
Intermittent (3x441–480 V) [A]	13.9	20.2	27.2
Maximum mains fuses	See chapter Fuses and Circuit Breakers.		
Estimated power loss [W], best case/typical ⁽¹⁾	159/198	248/274	353/379
Weight enclosure protection rating IP20 [kg (lb)]	4.4 (9.7)	7.4 (16.3)	7.4 (16.3)
Efficiency [%], best case/typical ⁽²⁾	98.2/97.8	98.1/97.9	98.0/97.8
Output current at 50°C (122°F) ambient temperature and 45°C (113°F) refrigerant temperature			
Continuous (3x380–440 V) [A]	14.0	20.9	28.0
Intermittent (3x380–440 V) [A]	15.4	23.0	30.8
Continuous (3x441–480 V) [A]	12.6	19.1	24.0
Intermittent (3x441–480 V) [A]	13.9	21.0	26.4

¹ Applies for dimensioning of drive cooling. If the switching frequency is higher than the default setting, the power losses may increase. LCP and typical control card power consumptions are included. For power loss data according to EN 50598-2, refer to drives.danfoss.com/knowledge-center/energy-efficiency-directive/#/.

² Typical: under rated condition. Best case: the optimal condition is adopted, such as the higher input voltage and lower switching frequency.

6.2 EMC Emission Test Results

The following test results have been obtained using a system with a drive, a shielded control cable, a control box with potentiometer, and a shielded motor cable.


Table 17: EMC Emission Test Results

RFI filter type	Conduct emission. Maximum shielded cable length [m (ft)]						Radiated emission			
	Industrial environment									
EN 55011	Class A Group 2		Class A Group 1		Class B		Class A Group 1		Class B	
	Industrial environment		Industrial environment		Housing, trades, and light industries		Industrial environment		Housing, trades, and light industries	
EN/IEC 61800-3	Category C3		Category C2		Category C1		Category C2		Category C1	
	Second environment Industrial		First environment Home and office		First environment Home and office		First environment Home and office		First environment Home and office	
	Without external filter	With external filter	Without external filter	With external filter	Without external filter	With external filter	Without external filter	With external filter	Without external filter	With external filter
H4 RFI filter (EN55011 A1, EN/IEC61800-3 C2)										
7.5–15 kW (10–20 hp) 3x380–480 V IP20	–	–	25 (82)	50 (164)	–	20 (66)	Yes	Yes	–	No

6.3 Special Conditions


6.3.1 Derating for Ambient Temperature and Switching Frequency

Ensure that the ambient temperature measured over 24 hours is at least 5 °C (41 °F) lower than the maximum ambient temperature that is specified for the drive. If the drive is operated at a high ambient temperature, decrease the continuous output current.



40°C (104 °F) is the refrigerant temperature.

Illustration 25: 400 V IP20 H3 7.5 kW (10 hp)



40°C (104 °F) is the refrigerant temperature.

Illustration 26: 400 V IP20 H4 11–15 kW (15–20 hp)

6.3.2 Derating for Low Air Pressure and High Altitudes

The cooling capability of air is decreased at low air pressure. For altitudes above 2000 m (6562 ft), contact Danfoss regarding PELV. Below 1000 m (3281 ft) altitude, derating is not necessary. For altitudes above 1000 m (3281 ft), decrease the ambient temperature or the maximum output current. Decrease the output by 1% per 100 m (328 ft) altitude above 1000 m (3281 ft) or reduce the maximum ambient temperature by 1 °C (33.8 °F) per 200 m (656 ft).

6.4 General Technical Data

6.4.1 Protection and Features

- Electronic motor thermal protection against overload.
- Temperature monitoring of the heat sink ensures that the drive trips if there is overtemperature.
- The drive is protected against short circuits between motor terminals U, V, W.
- When a motor phase is missing, the drive trips and issues an alarm.
- When a mains phase is missing, the drive trips or issues a warning (depending on the load).
- Monitoring of the DC-link voltage ensures that the drive trips when the DC-link voltage is too low or too high.
- The drive is protected against ground faults on motor terminals U, V, W.

6.4.2 Mains Supply (L1, L2, L3)

Supply voltage	380–480 V ±10%
Supply frequency	50/60 Hz
Maximum imbalance temporary between mains phases	3.0% of rated supply voltage
True power factor (λ)	≥0.9 nominal at rated load
Displacement power factor ($\cos\phi$) near unity	(>0.98)
Switching on the input supply L1, L2, L3 (power-ups) enclosure sizes H3–H4	Maximum 1 time/30 s
Environment according to EN 60664-1	Overtoltage category III/pollution degree 2

The unit is suitable for use on a circuit capable of delivering not more than 100000 A_{rms} symmetrical Amperes, 240/480 V maximum.

6.4.3 Motor Output (U, V, W)

Output voltage	0–100% of supply voltage
Output frequency	0–200 Hz (VVC ⁺), 0–400 Hz (u/f)
Switching on output	Unlimited
Ramp times	0.05–3600 s

6.4.4 Cable Length and Cross-section

Maximum motor cable length, shielded/armored (EMC-correct installation)	See chapter EMC Emission Test Results
Maximum motor cable length, unshielded/unarmoured	50 m (164 ft)
Maximum cross-section to motor, mains	See chapter Mains Supply 3x380–480 V AC for more information.
Cross-section DC terminals for filter feedback on enclosure sizes H3	4 mm ² /11 AWG
Cross-section DC terminals for filter feedback on enclosure sizes H4	16 mm ² /6 AWG
Maximum cross-section to control terminals, rigid wire	2.5 mm ² /14 AWG
Maximum cross-section to control terminals, flexible cable	2.5 mm ² /14 AWG
Minimum cross-section to control terminals	0.05 mm ² /30 AWG
Minimum cross-section of thermal switch wires with mating connector	0.22 mm ² /24 AWG
Maximum cross-section of thermal switch wires with mating connector	0.52 mm ² /20 AWG

6.4.5 Digital Inputs

Programmable digital inputs	4
Terminal number	18, 19, 27, 29
Logic	PNP or NPN
Voltage level	0–24 V DC
Voltage level, logic 0 PNP	<5 V DC
Voltage level, logic 1 PNP	>10 V DC
Voltage level, logic 0 NPN	>19 V DC
Voltage level, logic 1 NPN	<14 V DC
Maximum voltage on input	28 V DC
Input resistance, R _i	Approximately 4 kΩ
Digital input 29 as thermistor input	Fault: >2.9 kΩ and no fault: <800 Ω
Digital input 29 as pulse input	Maximum frequency 32 kHz push-pull-driven & 5 kHz (O.C.)

6.4.6 Analog Inputs

Number of analog inputs	2
Terminal number	53, 54
Terminal 53 mode	Parameter 6-19 Terminal 53 mode: 1=voltage, 0=current
Terminal 54 mode	Parameter 6-29 Terminal 54 mode: 1=voltage, 0=current
Voltage level	0–10 V

Input resistance, R_i	Approximately 10 k Ω
Maximum voltage	20 V
Current level	0/4–20 mA (scalable)
Input resistance, R_i	<500 Ω
Maximum current	29 mA
Resolution on analog input	10 bit

6.4.7 Analog Outputs

Number of programmable analog outputs	2
Terminal number	42, 45 ⁽¹⁾
Current range at analog output	0/4–20 mA
The load resistor to common at analog out	\leq 500 Ω
Maximum voltage at analog output	17 V
Accuracy on analog output	Maximum error: 0.4% of full scale
Resolution on analog output	10 bit

¹ Terminals 42 and 45 can also be programmed as digital outputs.

6.4.8 Digital Output

Number of digital outputs	4
Terminals 27 and 29	
Terminal number	27, 29 ⁽¹⁾
Voltage level at digital output	0–24 V
Maximum output current (sink and source)	40 mA
Terminals 42 and 45	
Terminal number	42, 45 ⁽²⁾
Voltage level at digital output	17 V
Maximum output current at digital output	20 mA
The load resistor at digital output	\geq 1 k Ω

¹ Terminals 27 and 29 can also be programmed as input.

² Terminals 42 and 45 can also be programmed as analog output.

The digital outputs are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

6.4.9 Control Card, RS485 Serial Communication

Terminal number	68 (P, TX+, RX+), 69 (N, TX-, RX-)
Terminal number	61 common for terminals 68 and 69

6.4.10 Control Card, 24 V DC Output

Terminal number	12
Maximum load	80 mA

6.4.11 Relay Output

Programmable relay output	2
Relay 01 and 02	01–03 (NC), 01–02 (NO), 04–06 (NC), 04–05 (NO)
Maximum terminal load (AC-1) ⁽¹⁾ on 01–02/04–05 (NO) (Resistive load)	250 V AC, 3 A
Maximum terminal load (AC-15) ⁽¹⁾ on 01–02/04–05 (NO) (Inductive load @ cosφ 0.4)	250 V AC, 0.2 A
Maximum terminal load (DC-1) ⁽¹⁾ on 01–02/04–05 (NO) (Resistive load)	30 V DC, 2 A
Maximum terminal load (DC-13) ⁽¹⁾ on 01–02/04–05 (NO) (Inductive load)	24 V DC, 0.1 A
Maximum terminal load (AC-1) ⁽¹⁾ on 01–03/04–06 (NC) (Resistive load)	250 V AC, 3 A
Maximum terminal load (AC-15) ⁽¹⁾ on 01–03/04–06 (NC) (Inductive load @ cosφ 0.4)	250 V AC, 0.2 A
Maximum terminal load (DC-1) ⁽¹⁾ on 01–03/04–06 (NC) (Resistive load)	30 V DC, 2 A
Minimum terminal load on 01–03 (NC), 01–02 (NO)	24 V DC 10 mA, 24 V AC 20 mA
Environment according to EN 60664-1	Overvoltage category III/pollution degree 2

¹ IEC 60947 parts 4 and 5. Endurance of the relay varies with different load type, switching current, ambient temperature, driving configuration, working profile, and so forth. It is recommended to mount a snubber circuit when connecting inductive loads to the relays.

NOTICE

Relay is only for resistive load. Non-resistive load cannot be connected with relay contacts.

6.4.12 Control Card, 10 V DC Output

Terminal number	50
Output voltage	10.5 V ±0.5 V
Maximum load	25 mA

6.4.13 Ambient Conditions

Enclosure protection rating	IP20
Enclosure kit available	IP21, TYPE 1
Vibration test	1.0 g & 1.14 g RMS
Maximum relative humidity	5–95% (IEC 60721-3-3; Class 3K3 (non-condensing) during operation)
Aggressive environment (IEC 60721-3-3), coated (standard) enclosure sizes H3–H4	Class 3C3
Test method according to IEC 60068-2-43 H2S (10 days)	
Ambient temperature	See maximum output current at 40/50 °C (104/122 °F) in chapter Mains Supply 3x380–480 V AC.

Maximum refrigerant temperature	45 °C (113 °F)
Minimum ambient temperature during full-scale operation	0 °C (32 °F)
Temperature during storage/transport	-30 to +65/70 °C (-22 to +149/158°F)
Safety standards	EN/IEC 61800-5-1
EMC standards, Emission	EN 61800-3, EN 61000-6-3/4, EN 55011, IEC 61800-3
EMC standards, Immunity	EN 61800-3, EN 61000-3-12, EN 61000-6-1/2, EN 61000-4-2, EN 61000-4-3, EN 61000-4-4, EN 61000-4-5, EN 61000-4-6
Energy efficiency class ⁽¹⁾	IE2
Maximum ambient temperature with derating	50 °C (122 °F)
Maximum ambient temperature without derating	40 °C (104 °F)
Maximum refrigerant temperature without derating	45 °C (113 °F)

¹ Determined according to EN 50598-2 at:

- Rated load.
- 90% rated frequency.
- Switching frequency factory setting.
- Switching pattern factory setting.

6.4.14 Thermal Switch (Fan Failure Detection)

Maximum terminal load	48 V DC/2.2 A
-----------------------	---------------

Index

1		Indicator light	26
10 V DC output	55	Installation	
		Qualified personnel	7
2		L	
24 V DC output	55	LCP	25
A		Liquid cooling	14
Additional resource	5	Load sharing	7
Ambient condition	55	Local control panel	25
Ambient temperature	51	Low air pressure	52
Analog input	53	M	
B		MCT 10 set-up software	5, 25
Branch circuit protection	20	Menu key	26
C		Motor output (U, V, W)	53
CE compliance	20	Motor overload protection	52
Circuit breaker	20	N	
Control card	54, 55, 55	Navigation key	26
Cooling clearance	10	O	
D		Operation key	26
Derating	51, 52	Overcurrent protection	20
Digital input	53	P	
Digital output	54	Programming	25
Display	25	Protection	52
Document version	5	Purpose of the manual	5
E		Q	
Electrical installation	17	Qualified personnel	5, 7
EMC-correct electrical installation	20	R	
Energy efficiency class	56	Relay output	55
F		RS485 serial communication	54
Fan failure detection	56	S	
Fuse	20	Short-circuit protection	20
H		Side-by-side installation	10
High altitudes	52	Software version	5
High voltage	7	Switching frequency	51
I		Symbols	7

T

Thermal switch 56

W

Wiring schematic 23

ENGINEERING
TOMORROW

Danfoss

.....
Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.
.....

Danfoss A/S
Ulsnaes 1
DK-6300 Graasten
vlt-drives.danfoss.com

