

■ Contents

| | |
|--|----|
| Introduction | 4 |
| Software version | 4 |
| Definitions | 5 |
| Safety regulations | 7 |
| Warning against unintended start | 7 |
| Introduction to Instruction Manual | 9 |
| Control principle | 10 |
| AEO - Automatic Energy Optimization | 11 |
| Example of application - Constant pressure regulation in water supply system | 12 |
| PC software and serial communication | 13 |
| Cascade Controller Option | 13 |
| Unpacking and ordering an AFD | 22 |
| Type code ordering number string | 22 |
| TYPE CODE Table/Ordering form | 25 |
| | |
| Installation | 26 |
| General technical data | 26 |
| Technical data, line supply 3 x 200 - 240 V | 31 |
| Technical data, line supply 3 x 380 - 480 V | 33 |
| Technical data, line supply 3 x 525 - 600 V | 38 |
| Fuses | 41 |
| Mechanical dimensions | 43 |
| Mechanical installation | 47 |
| IP 00 VLT 8450-8600 380-480 V | 49 |
| General information about electrical installation | 50 |
| High voltage warning | 50 |
| Grounding | 50 |
| Cables | 50 |
| Shielded/armored cables | 50 |
| Extra protection with regard to indirect contact | 52 |
| RFI switch | 53 |
| High voltage test | 55 |
| Heat emission from VLT 8000 AQUA | 55 |
| EMC-correct electrical installation | 56 |
| Earthing/Grounding of shielded/armored control cables | 59 |
| Electrical installation, enclosures | 60 |
| Use of EMC-correct cables | 68 |
| Tightening torque and screw sizes | 69 |
| Line connection | 70 |
| Motor connection | 70 |
| DC bus connection | 72 |
| High-voltage relay | 72 |
| Electrical installation, control cables | 73 |
| Switches 1-4 | 74 |
| Connection example VLT 8000 AQUA | 76 |
| Control unit LCP | 79 |

| | |
|---|------------|
| Control keys for parameter setup | 79 |
| Indicator lamps | 80 |
| Local control | 80 |
| Display mode | 81 |
| Navigation between display modes | 82 |
| Changing data | 84 |
| Manual initialization | 85 |
| Quick Menu | 86 |
| | |
| Programming | 88 |
| Operation and Display 001-017 | 88 |
| The Setup configuration | 88 |
| Setup of user-defined readout | 89 |
| Load and motor 100-124 | 95 |
| Configuration | 95 |
| Motor power factor (Cos ϕ) | 102 |
| References and limits 200-228 | 105 |
| Reference handling | 106 |
| Reference type | 109 |
| Initial ramp parameter 229 | 114 |
| Fill Mode | 114 |
| Fill Rate parameter 230 | 115 |
| Filled Setpoint parameter 231 | 115 |
| Inputs and outputs 300-328 | 116 |
| Analog inputs | 119 |
| Analog/digital outputs | 122 |
| Relay outputs | 125 |
| Application functions 400-434 | 128 |
| Sleep mode | 129 |
| PID for process control | 134 |
| PID overview | 136 |
| Feedback handling | 136 |
| Serial communication for FC protocol | 143 |
| Protocols | 143 |
| Telegram communication | 143 |
| Telegram build-up under FC protocol | 144 |
| Data character (byte) | 145 |
| Process word | 149 |
| Control word as per FC protocol | 150 |
| Status word as per FC protocol | 151 |
| Serial communication 500-556 | 154 |
| Warning words 1+2 and Alarm word | 162 |
| Service functions 600-631 | 164 |
| Electrical installation of the relay card | 169 |
| | |
| All about VLT 8000 AQUA | 171 |
| Status messages | 171 |
| List of warnings and alarms | 173 |
| Special conditions | 179 |

| | |
|---|-----|
| Aggressive environments | 179 |
| Calculation of resulting reference | 180 |
| Extreme running conditions | 182 |
| Peak voltage on motor | 183 |
| Derating for ambient temperature | 185 |
| Switching on the input | 185 |
| Efficiency | 188 |
| Line supply interference/harmonics | 190 |
| CE labelling | 191 |
| EMC test results (Emission, Immunity) | 192 |
| EMC Immunity | 194 |
| Factory settings | 196 |

VLT 8000 AQUA

Instruction Manual
Software version: 1.3x



This Instruction Manual can be used for all VLT 8000 AQUA, AFDs (Adjustable Frequency Drives) with software version 1.3x.

The software version number can be seen from parameter 624

176FA145.12

■ Definitions

Definitions are given in alphabetical order.

AEO:

Automatic Energy Optimization – function that dynamically adjusts the voltage supplied to a variable torque load to optimize motor power factor and motor efficiency.

AFD:

Adjustable Frequency Drive; also known as VFDs, (Variable Frequency Drives).

Analog inputs:

The analog inputs can be used for controlling various functions of the AFD. There are two types of analog inputs:

Current input, 0-20 mA

Voltage input, 0-10 V DC.

Analog reference:

A signal transmitted to input 53, 54 or 60.

Can be voltage or current.

Analog outputs:

There are two analog outputs, which are able to supply a signal of 0-20 mA, 4-20 mA or a digital signal.

Automatic motor adjustment, AMA:

Automatic motor adjustment algorithm, which determines the electrical parameters for the connected motor, at standstill.

AWG:

Means American Wire Gauge.

Control command:

By means of the control unit and the digital inputs, it is possible to start and stop the connected motor. Functions are divided into two groups, with the following priorities:

- | | |
|---------|--|
| Group 1 | Reset, Coasting stop, Reset and Coasting stop, DC braking, Stop and the [OFF/ STOP] key. |
| Group 2 | Start, Pulse start, Reversing, Start reversing, Jog and Freeze output |

Group 1 functions are called Start-disable commands. The difference between group 1 and group 2 is that in group 1 all stop signals must be cancelled for the motor to start. The motor can then be started by means of a single start signal in group 2.

A stop command given as a group 1 command results in the display indication STOP. A missing stop command given as a group 2 command results in the display indication STAND BY.

CT:

Constant torque: used for e.g. heavy, solid sludge pumps and centrifuges.

Digital inputs:

The digital inputs can be used for controlling various functions of the AFD.

Digital outputs:

There are four digital outputs, two of which activate a relay switch. The outputs are able to supply a 24 V DC signal at a maximum load of 24mA.

f_{JOG}

The output frequency from the AFD transmitted to the motor when the jog function is activated (via digital terminals or serial communication).

f_M

The output frequency from the AFD transmitted to the motor.

f_{M,N}

The rated motor frequency (nameplate data).

f_{MAX}

Maximum output frequency transmitted to the motor.

f_{MIN}

Minimum output frequency transmitted to the motor.

I_M

The current transmitted to the motor.

I_{M,N}

The rated motor current (nameplate data).

Initializing:

If Initializing is carried out (see parameter 620 *Operating mode*), the AFD returns to the factory setting.

I_{VLT,MAX}

The maximum output current.

I_{VLT,N}

The rated output current supplied by the AFD.

LCP:

The control panel, which makes up a complete interface for control and programming of VLT 8000 AQUA.

The control panel is detachable and may, as an alternative, be installed up to 10 feet away from the AFD, i.e. in a front panel, by means of the installation kit option.

LSB:

Least significant bit.
Used in serial communication.

MCM:

Stands for Mille Circular Mil, an American measuring unit for cable cross-section.

MSB:

Most significant bit.
Used in serial communication.

$n_{M,N}$

The rated motor speed (nameplate data).

η_{VLT}

The efficiency of the AFD is defined as the ratio between the power output and the power input.

On-line/off-line parameters:

On-line parameters are activated immediately after the data value is changed. Off-line parameters are not activated until OK has been entered on the control unit.

PCB: Printed circuit board.

PELV: Protective extra low voltage.

PID:

The PID regulator maintains the desired speed (pressure, temperature, etc.) by adjusting the output frequency to match the varying load.

$P_{M,N}$

The rated power delivered by the motor (nameplate data).

Preset reference:

A permanently defined reference, which can be set from -100% to +100% of the reference range. There are four preset references, which can be selected via the digital terminals.

Ref_{MAX}

The maximum value which the reference signal may have. Set in parameter 205 *Maximum reference*, *Ref_{MAX}*.

Ref_{MIN}

The smallest value which the reference signal may have. Set in parameter 204 *Minimum reference*, *Ref_{MIN}*.

Setup:

There are four Setups, in which it is possible to save parameter settings. It is possible to change between the four parameter Setups.

Start-disable command:

A stop command that belongs to group 1 of the control commands - see this group.

Stop command:

See Control commands.

Thermistor:

A temperature-dependent resistor placed where the temperature is to be monitored (AFD or motor).

Trip:

A state which occurs in different situations, e.g. if the AFD is subjected to an overtemperature. A trip can be cancelled by pressing reset or, in some cases, automatically.

Trip locked:

A state which occurs in different situations, e.g. if the AFD is subject to an overtemperature. A locked trip can be cancelled by removing line power, then reapplying it and starting the.

U/F:

Voltage to frequency ratio that is supplied to the motor.

U_M

The voltage transmitted to the motor.

$U_{M,}$

The rated motor voltage (nameplate data).

$U_{VLT, MAX}$

The maximum output voltage.

VFD:

See AFD.

VT characteristics:

Variable torque characteristics, used for centrifugal pumps and fans.



The voltage of the adjustable frequency drive is dangerous whenever the equipment is connected to line. Incorrect installation of the motor or the AFD may cause damage to the equipment, serious personal injury or death. Consequently, the instructions in this manual, as well as national and local rules and safety regulations, must be complied with.

■ Safety regulations

1. The AFD must be disconnected from the line if repair work is to be carried out. Check that the line supply has been disconnected and that the necessary time has passed before removing motor and line plugs.
2. The [OFF/STOP] key on the control panel of the AFD does not disconnect the equipment from line and is thus not to be used as a safety switch.
3. Correct protective earthing/grounding of the equipment must be established, the user must be protected against supply voltage, and the motor must be protected against overload in accordance with the National Electrical Code and local codes.
4. The ground leakage currents are higher than 3.5mA.
5. Protection against motor overload is not included in the factory setting. If this function is required, set parameter 117, *Motor thermal protection*, to data value ETR trip or data value ETR warning.
Note: The function is initialised at 1.0 x rated motor current and rated motor frequency (see parameter 117, *Motor thermal protection*). In UL/cUL

- applications ETR provides Class 20, over-load protection in accordance with the NEC®.
6. Do not remove the plugs for the motor and line supply while the AFD is connected to line. Check that the line supply has been disconnected and that the necessary time has passed before removing motor and line plugs.
7. Please note that the AFD has more voltage inputs than L1, L2, L3 when the DC-bus terminals or AUX 24 V option are used. Check that all voltage inputs have been disconnected and that the necessary time has passed before repair work is commenced.

■ Warning against unintended start

1. The motor can be brought to a stop by means of digital commands, bus commands, references or a local stop, while the AFD is connected to line. If personal safety considerations make it necessary to ensure that no unintended start occurs, these stop functions are not sufficient.
2. While parameters are being changed, the motor may start. Consequently, the stop key [OFF/STOP] must always be activated, following which data can be modified.
3. A stopped motor may start if a fault occurs in the electronics of the AFD, or if a temporary overload or a fault in the supply line or the motor connection ceases.

Warning:

Touching the electrical parts may be fatal - even after the equipment has been disconnected from line.

| | |
|---------------------------|--------------------------|
| VLT 8006-8062, 200-240 V: | wait at least 15 minutes |
| VLT 8006-8072, 380-480 V: | wait at least 15 minutes |
| VLT 8102-8352, 380-480 V: | wait at least 20 minutes |
| VLT 8450-8600, 380-480 V: | wait at least 15 minutes |
| VLT 8002-8006, 525-600 V: | wait at least 4 minutes |
| VLT 8008-8027, 525-600 V: | wait at least 15 minutes |
| VLT 8032-8300, 525-600 V: | wait at least 30 minutes |

176FA159.12

■ Use on isolated line

See section *RFI Switch* regarding use on isolated line.



It is the responsibility of the user or the person installing the VLT to provide proper earthing/grounding, as well as motor overload and branch circuit protection according to local codes such as the Nation Electrical Code (NEC).

**NOTE**

Electrostatic Precaution; Electrostatic discharge (ESD). Many electronic components are sensitive to static electricity. Voltages so low that they cannot be felt, seen or heard, can reduce the life, affect performance, or completely destroy sensitive electronic components. When performing service, proper ESD equipment should be used to prevent possible damage from occurring.



The Adjustable Frequency Drive contains dangerous voltages when connected to line voltage. After disconnecting from the line wait at least


- 15 minutes for VLT 8006-8062, 200-240 V
- 15 minutes for VLT 8006-8072, 380-480 V
- 20 minutes for VLT 8102-8352, 380-480 V
- 15 minutes for VLT 8450-8600, 380-480 V
- 4 minutes for VLT 8002-8006, 525-600 V
- 15 minutes for VLT 8008-8027, 525-600 V
- 30 minutes for VLT 8032-8300, 525-600 V


before touching any electrical components. Also make sure that other voltage inputs have been disconnected, such as external 24 VDC and load-sharing (linkage of DC intermediate circuit). Only a competent electrician should carry out the electrical installation. Improper installation of the motor or the VLT may cause equipment failure, serious injury or death. Follow this manual and National Electrical Codes (NEC) and local safety codes.


■ Introduction to Instruction Manual

This Instruction Manual is divided into four sections with information about VLT 8000 AQUA.

- Introduction to AQUA: This section tells you the advantages you can obtain by using a VLT 8000 AQUA - such as Automatic Energy Optimization, Constant Torque or Variable Torque and other AQUA relevant functions. This section also contains examples of applications as well as information about Danfoss.
- Installation: This section tells you how to carry out a mechanically correct installation of the VLT 8000 AQUA. Furthermore, a list is given of line and motor connections, together with a description of the control card terminals.
- Programming: This section describes the control unit and the software parameters for the VLT 8000 AQUA. Also included is a guide to the Quick Setup menu, which allows you to get started on your application very quickly.
- All about VLT 8000 AQUA: This section gives information about status, warning and error messages from the VLT 8000 AQUA. Additionally, information is given on technical data, ser-vice, factory settings and special conditions.

 **NOTE**
Indicates something to be noted by the reader.


 Indicates a general warning

 Indicates a high-voltage warning

■ **Control principle**

An AFD rectifies AC voltage from line into DC voltage, after which this DC voltage is converted into a AC current with a variable amplitude and frequency.

The motor is thus supplied with variable voltage and frequency, which enables infinitely variable speed control of three-phased, standard AC motors.



1. Line voltage

3 x 200 - 240 V AC, 50 / 60 Hz.

3 x 380 - 480 V AC, 50 / 60 Hz.

3 x 525 - 600 V AC, 50 / 60 Hz.

2. Rectifier

A three-phase rectifier bridge that rectifies AC current into DC current.

3. Intermediate circuit

DC voltage = 1.35 x line voltage [V].

4. Intermediate circuit coils

Even out the intermediate circuit voltage and reduce the harmonic current feedback to the line supply.

5. Intermediate circuit capacitors

Even out the intermediate circuit voltage.

6. Inverter

Converts DC voltage into variable AC voltage with a variable frequency.

7. Motor voltage

Variable AC voltage, 0-100% of line supply voltage.


8. Control card

This is where to find the computer that controls the inverter which generates the pulse pattern by which the DC voltage is converted into variable AC voltage with a variable frequency.

■ AEO - Automatic Energy Optimization

AEO is intended for use on Variable Torque single motor applications. Normally, the U/f characteristics have to be set on the basis of the expected load at different frequencies. However, knowing the load at a given frequency in an installation is often a problem. This problem can be solved by using a VLT 8000 AQUA with its integral Automatic Energy Optimization (AEO), which ensures optimum energy utilization. All VLT 8000 AQUA units feature this function as a factory setting, i.e. it is not necessary to adjust the AFD U/f ratio in order to obtain maximum energy savings. In other AFDs, the given load and voltage/frequency ratio (U/f) must be assessed to carry out correct setting of the AFD. Using Automatic Energy Optimization (AEO), you no longer need to calculate or assess the system characteristics of the installation, since Danfoss VLT 8000 AQUA units guarantee optimum, load-dependent energy consumption by the motor at all times.

The figure on the right illustrates the working range of the AEO function, within which energy optimization is enabled.



If the AEO function has been selected in parameter 101, Torque characteristics, this function will be constantly active. If there is a major deviation from the optimum U/f ratio, the AFD will quickly adjust itself.



Advantages of the AEO function

- Automatic energy optimization
- Compensation if an oversize motor is used
- AEO matches operations to daily or seasonal fluctuations
- Energy savings in a constant volume system
- Compensation in the oversynchronous working range
- Reduces acoustic motor noise

■ Example of application - Constant pressure regulation in water supply system

The demand for water from waterworks varies considerably during the course of a day. In the night, practically no water is used, while in the morning and in the evening the consumption is high. In order to maintain a suitable pressure in the water supply lines in relation to the current demand, the water supply pumps are equipped with speed control. The use of AFD's enables the energy consumed by the pumps to be kept at a minimum, while optimizing the water supply to consumers.

A VLT 8000 AQUA with its integral PID controller ensures simple and quick installation. For example, an IP54/NEMA 12 unit can be mounted close to the pump on the wall and the existing line cables can be used as line supply to the AFD. A Pressure transmitter (e.g. Danfoss MBS 33 or MBS 3000) can be fitted a few meters (feet) from the joint outlet point from the waterworks to obtain closed loop regulation. Danfoss MBS 33 and MBS 3000 is a two-wire transmitter (4-20 mA) that can be powered directly from a VLT 8000 AQUA. The required setpoint (e.g. 5 bar) can be set locally in parameter 418 *Setpoint 1*.



Assume:

Transmitter is scaled 0-10 Bar, minimum flow is achieved at 30 Hz. An increase in motor speed increases the pressure.

Set the following parameters:

| | | |
|----------|-----------------------------------|---------------------|
| Par. 100 | Configuration | Closed loop [1] |
| Par. 201 | Minimum Output Frequency | 30 Hz |
| Par. 202 | Maximum Output Frequency | 50 Hz (or 60 Hz) |
| Par. 204 | Minimum Reference | 0 Bar |
| Par. 205 | Maximum Reference | 10 Bar |
| Par. 302 | Terminal 18 Digital inputs | Start [1] |
| Par. 314 | Terminal 60, analog input current | Feedback signal [2] |
| Par. 315 | Terminal 60, min. scaling | 4 mA |
| Par. 316 | Terminal 60, max. scaling | 20 mA |
| Par. 403 | Sleep mode timer | 10 sec. |
| Par. 404 | Sleep frequency | 15 Hz |
| Par. 405 | Wake-up frequency | 20 Hz |
| Par. 406 | Boost setpoint | 125% |
| Par. 413 | Minimum Feedback | 0 Bar |
| Par. 414 | Maximum Feedback | 10 Bar |
| Par. 415 | Process units | Bar [16] |
| Par. 418 | Setpoint 1 | 5 bar |
| Par. 420 | PID control action | Normal |
| Par. 423 | PID Proportional gain | 0.3* |
| Par. 424 | PID Integral time | 30 sec.* |

* The PID tuning parameters depend on the actual system dynamics.

■ **PC software and serial communication**

Danfoss offers various options for serial communication. Using serial communication, it is possible to monitor, program and control one or several AFDs from a centrally located computer. All VLT 8000 AQUA units have an RS 485 port and FC protocol as standard. A bus option card allows higher transmission speed than RS 485. In addition, a higher number of units can be linked to the bus and alternative transmission media can be used. Danfoss offers the following option cards for communication:

- Profibus
- LonWorks
- DeviceNet
- Modbus RTU

Information on the installation of various options is not included in this manual.

Using the RS 485 port enables communication, e.g. with a PC. A Windows™ program, called *MCT 10*, is available for this purpose. It can be used to monitor, program and control one or several VLT 8000 AQUA units.

■ **Cascade Controller Option**



In "Standard Mode", one motor is controlled by the drive that has the Cascade Controller Option card installed in it. Up to four additional fixed speed motors can be sequenced on & off, as required by the process, in lead-lag mode.

In "Master/Slave Mode", the drive that has the Cascade Controller option card installed in it, along with its associated motor, is designated as the master. Up to four additional motors, each with its own drive, can be operated in slave mode. The Cascade Controller functions to stage the slave drives/motors - on & off (as required), as a function of "best system operating efficiency".


In "Lead Pump Alternation Mode", it is possible to average out the usage of the pumps. This is done by making the frequency converter switch between the pumps (max. 4) by means of a timer. Please note that this mode requires an external relay setup.

Consult your Danfoss Sales Office for additional information.

■ **Accessories**



IP 20 bottom cover



Application option

| Type | Description | Order no. |
|--|--|-------------------|
| IP 4x top cover IP ¹⁾ | Option, VLT type 8006-8011 380-480 V compact | 175Z0928 |
| IP 4 x top cover ¹⁾ | Option, VLT type 8002-8011 525-600 V compact | 175Z0928 |
| NEMA 12 bonding plate ²⁾ | Option, VLT type 8006-8011 380-480 V | 175H4195 |
| IP 20 terminal cover | Option, VLT type 8006-8022 200-240 V | 175Z4622 |
| IP 20 terminal cover | Option, VLT type 8027-8032 200-240 V | 175Z4623 |
| IP 20 terminal cover | Option, VLT type 6016-6042 380-480 V | 175Z4622 |
| IP 20 terminal cover | Option, VLT type 8016-8042 525-600 V | 175Z4622 |
| IP 20 terminal cover | Option, VLT type 8052-8072 380-480 V | 175Z4623 |
| IP 20 terminal cover | Option, VLT type 8102-8122 380-480 V | 175Z4280 |
| IP 20 terminal cover | Option, VLT type 8052-8072 525-600 V | 175Z4623 |
| IP 20 bottom cover | Option, VLT type 8042-8062 200-240 V | 176F1800 |
| IP 20 bottom cover | Option, VLT type 8100-8150 525-600 V | 176F1800 |
| IP 20 bottom cover | Option, VLT type 8200-8300 525-600 V | 176F1801 |
| Terminal adaptor kit | VLT type 8042-8062 200-240 V, IP 54 | 176F1808 |
| Terminal adaptor kit | VLT type 8042-8062 200-240 V, IP 00/NEMA 1 | 176F1805 |
| Terminal adaptor kit | VLT type 8100-8150 525-600 V, IP 00/NEMA 1 | 176F1805 |
| Terminal adaptor kit | VLT type 8200-8300 525-600 V, IP 00/NEMA 1 | 176F1811 |
| Terminal adaptor kit | VLT type 8450-8600, 380-480 V, EX | 176F1815 |
| Control panel LCP | Separate LCP | 175Z7804 |
| LCP remote-mounting kit IP 00 & 20 ³⁾ | Remote-mounting kit, incl. 10 ft cable | 175Z0850 |
| LCP remote-mounting kit IP 54 ⁴⁾ | Remote-mounting kit, incl. 10 ft cable | 175Z7802 |
| LCP blind cover | for all IP00/IP20 drives | 175Z7806 |
| Cable for LCP | Separate cable (10 ft) | 175Z0929 |
| Relay card | Application card with four relay outputs | 175Z3691 |
| Cascade controller card | With conformal coating | 175Z3692 |
| Profibus option | Without/with conformal coating | 175Z3685/175Z3686 |
| LonWorks option, Free topology | Without conformal coating | 176F0225 |
| Modbus RTU option | Without conformal coating | 175Z3362 |
| DeviceNet option | Without conformal coating | 176F0224 |
| MCT 10 Set-up software | CD-Rom | 130B1000 |
| MCT 31 Harmonic calculation | CD-Rom | 130B1031 |

1) IP 4x/NEMA 1 top cover is for IP 20 units only and only horizontal surfaces comply with IP 4x. The kit also contains a bonding plate (UL).

2) NEMA 12 bonding plate (UL) is only for IP 54 units.

3) The remote-mounting kit is only for IP 00 and IP 20 units. Enclosure of the remote-mounting kit is IP 65.

4) The remote-mounting kit is only for IP 54 units. Enclosure of the remote-mounting kit is IP 65.

VLT 8000 AQUA is available with an integral fieldbus option or application option. Ordering numbers for the individual VLT types with integrated options can be seen from the relevant manuals or instructions. In addition, the ordering number system can be used for ordering an AFD with an option.

■ LC filters for VLT 8000 AQUA

When a motor is controlled by an AFD, resonance noise will be heard from the motor. This noise, which is caused by the design of the motor, occurs each time one of the inverter switches in the AFD is activated. Consequently, the resonance noise frequency corresponds to the switching frequency of the AFD.

For the VLT 8000 AQUA, Danfoss offers a LC filter to dampen the acoustic motor noise.

This filter reduces the voltage rise time, the peak voltage U_{PEAK} and the ripple current ΔI to the motor, thereby making current and voltage almost sinusoidal. The acoustic motor noise is therefore reduced to a minimum.

Because of the ripple current in the coils, there will be some noise from the coils. This problem can be solved entirely by integrating the filter in a cabinet or similar.

■ Examples of the use of LC filtersSubmersible pumps

For small motors with up to and including 5.5 kW rated motor power, use an LC filter, unless the motor is equipped with phase separation paper. This applies e.g. to all wet running motors. If these motors are used without LC filter in connection with an AFD, the motor windings will short-circuit. If in doubt, ask the motor manufacturer whether the motor in question is equipped with phase separation paper.

Well pumps

If immersion pumps are used, e.g. submerged pumps or well pumps, the supplier should be contacted for clarification of requirements. It is recommended to use a LC filter if an AFD is used for well pump applications.

**NOTE**

If an AFD controls several motors in parallel, the motor cables must be added up to give the total cable length.

■ Ordering numbers, LC filter modules
Line supply 3 x 200 - 240 V

| LC filter for VLT type | LC filter enclosure | Rated current at 200 V | Max. output frequency | Power loss | Order no. |
|------------------------|---------------------|------------------------|-----------------------|------------|-----------|
| 8006-8008 | IP 00 | 25.0 A | 60 Hz | 85 W | 175Z4600 |
| 8011 | IP 00 | 32 A | 60 Hz | 90 W | 175Z4601 |
| 8016 | IP 00 | 46 A | 60 Hz | 110 W | 175Z4602 |
| 8022 | IP 00 | 61 A | 60 Hz | 170 W | 175Z4603 |
| 8027 | IP 00 | 73 A | 60 Hz | 250 W | 175Z4604 |
| 8032 | IP 00 | 88 A | 60 Hz | 320 W | 175Z4605 |

Line supply 3 x 380 - 480


| LC filter for VLT type | LC filter enclosure | Rated current at 400/480 V | Max. output frequency | Power loss | Order no. |
|------------------------|---------------------|----------------------------|-----------------------|------------|-----------|
| 8006-8011 | IP 20 | 16 A / 16 A | 120 Hz | | 175Z0832 |
| 8016 | IP 00 | 24 A / 21.7 A | 60 Hz | 125 W | 175Z4606 |
| 8022 | IP 00 | 32 A / 27.9 A | 60 Hz | 130 W | 175Z4607 |
| 8027 | IP 00 | 37.5 A / 32 A | 60 Hz | 140 W | 175Z4608 |
| 8032 | IP 00 | 44 A / 41.4 A | 60 Hz | 170 W | 175Z4609 |
| 8042 | IP 00 | 61 A / 54 A | 60 Hz | 250 W | 175Z4610 |
| 8052 | IP 00 | 73 A / 65 A | 60 Hz | 360 W | 175Z4611 |
| 8062 | IP 00 | 90 A / 78 A | 60 Hz | 450 W | 175Z4612 |
| 8072 | IP 20 | 106 A / 106 A | 60 Hz | | 175Z4701 |
| 8102 | IP 20 | 147 A / 130 A | 60 Hz | | 175Z4702 |
| 8122 | IP 20 | 177 A / 160 A | 60 Hz | | 175Z4703 |
| 8152 | IP 20 | 212 A / 190 A | 60 Hz | | 175Z4704 |
| 8202 | IP 20 | 260 A / 240 A | 60 Hz | | 175Z4705 |
| 8252 | IP 20 | 315 A / 302 A | 60 Hz | | 175Z4706 |
| 8302 | IP 20 | 395 A / 361 A | 60 Hz | | 175Z4707 |
| 8352 | IP 20 | 480 A / 443 A | 60 Hz | | 175Z3139 |
| 8450 | IP 20 | 600 A / 540 A | 60 Hz | | 175Z3140 |
| 8500 | IP 20 | 658 A / 590 A | 60 Hz | | 175Z3141 |
| 8600 | IP 20 | 745 A / 678 A | 60 Hz | | 175Z3142 |

Regarding LC filters for 525 - 600 V, please contact Danfoss.


NOTE

When using LC filters, the switching frequency must be 4.5 kHz (see parameter 407).

■ LC filters VLT 8006-8011 380 - 480 V



175ZA106.11

The drawing on the left gives the measurements of IP 20 LC filters for the above-mentioned power range. Min. space above and under enclosure: 100 mm.

IP 20 LC filters have been designed for side-by-side installation without any space between enclosures.

Max. motor cable length:

- 150 m shielded/armored cable
- 300 m unshielded/unarmored cable


If EMC standards are to be complied with:

- EN 55011-1B: Max. 50 shielded/armored cable
- Bookstyle: Max. 20 m shielded/armored cable
- EN 55011-1A: Max. 150 m shielded/armored cable

Weight: 175Z0832 9.5 kg

Introduction

■ Installation of LC filter IP 20



■ **LC filters VLT 8006-8032, 200 - 240 V /
8016-8062 380 - 480 V**

The table and the drawing give the measurements of IP 00 LC filters for Compact units.

IP 00 LC filters must be integrated and protected against dust, water and corrosive gases.

Max. motor cable length:


- 150 m shielded/armored cable
- 300 m unshielded/unarmored cable

If EMC standards are to be complied with:

- EN 55011-1B: Max. 50 shielded/armored cable
- EN 55011-1A: Max. 150 m shielded/armored cable

LC filter IP 00

| LC type | A [mm] | B [mm] | C [mm] | D [mm] | E [mm] | F [mm] | G [mm] | Weight [kg] |
|----------|--------|--------|--------|--------|--------|--------|--------|-------------|
| 175Z4600 | 220 | 135 | 92 | 190 | 68 | 170 | 8 | 10 |
| 175Z4601 | 220 | 145 | 102 | 190 | 78 | 170 | 8 | 13 |
| 175Z4602 | 250 | 165 | 117 | 210 | 92 | 180 | 8 | 17 |
| 175Z4603 | 295 | 200 | 151 | 240 | 126 | 190 | 11 | 29 |
| 175Z4604 | 355 | 205 | 152 | 300 | 121 | 240 | 11 | 38 |
| 175Z4605 | 360 | 215 | 165 | 300 | 134 | 240 | 11 | 49 |
| 175Z4606 | 280 | 170 | 121 | 240 | 96 | 190 | 11 | 18 |
| 175Z4607 | 280 | 175 | 125 | 240 | 100 | 190 | 11 | 20 |
| 175Z4608 | 280 | 180 | 131 | 240 | 106 | 190 | 11 | 23 |
| 175Z4609 | 295 | 200 | 151 | 240 | 126 | 190 | 11 | 29 |
| 175Z4610 | 355 | 205 | 152 | 300 | 121 | 240 | 11 | 38 |
| 175Z4611 | 355 | 235 | 177 | 300 | 146 | 240 | 11 | 50 |
| 175Z4612 | 405 | 230 | 163 | 360 | 126 | 310 | 11 | 65 |



■ **LC filter VLT 8042-8062 200-240 V /
8072-8600 380 - 480 V**

The table and the drawing give the measurements of IP 20 LC filters. IP 20 LC filters must be integrated and protected against dust, water and aggressive gases.


Max. motor cable length:

- 150 m shielded/armored cable
 - 300 m unshielded/unarmored cable
- If EMC standards are to be complied with:
- EN 55011-1B: Max. 50 m shielded/armored cable
 - EN 55011-1A: Max. 150 m shielded/armored cable

LC-filter IP 20

| LC type | A [mm] | B [mm] | C [mm] | D [mm] | E [mm] | F [mm] | G [mm] | Weight [kg] |
|----------|--------|--------|--------|--------|--------|--------|--------|-------------|
| 175Z4701 | 740 | 550 | 600 | | | | | 70 |
| 175Z4702 | 740 | 550 | 600 | | | | | 70 |
| 175Z4703 | 740 | 550 | 600 | | | | | 110 |
| 175Z4704 | 740 | 550 | 600 | | | | | 120 |
| 175Z4705 | 830 | 630 | 650 | | | | | 220 |
| 175Z4706 | 830 | 630 | 650 | | | | | 250 |
| 175Z4707 | 830 | 630 | 650 | | | | | 250 |
| 175Z3139 | 1350 | 800 | 1000 | | | | | 350 |
| 175Z3140 | 1350 | 800 | 1000 | | | | | 400 |
| 175Z3141 | 1350 | 800 | 1000 | | | | | 400 |
| 175Z3142 | 1350 | 800 | 1000 | | | | | 470 |

175HA428.10



■ Harmonic filter

Harmonic currents do not directly affect the electricity consumption but has an impact on following conditions:

- Higher total current to be handled by the installations
- Increases load on transformer (sometimes it will require a larger transformer, particular at retrofit)
 - Increases heat losses in transformer and installation
 - In some cases demands larger cables, switches and fuses

- Higher voltage distortion due to higher current
- Increase risk for disturbing electronic equipment connected to same grid

A high percentage of rectifier load from e.g. AFDs, will increase the harmonic current, which must be reduced to avoid the above consequences. Therefore the AFD has as standard, built in DC coils reducing the total current with about 40% (compared

to devices without any arrangement for harmonic suppression), down to 40-45% ThiD.

In some cases there is a need for further suppression (e.g. retrofit with AFDs). For this purpose Danfoss can offer two advanced harmonic filters AHF05 and AHF10, bringing the harmonic current down to around 5% and 10% respectively. For further details see instruction MG.80.BX.YY.

■ Ordering numbers, Harmonic filters

Harmonic filters are used to reduce line harmonics

- AHF 010: 10% current distortion
- AHF 005: 5% current distortion

380-415V, 50Hz

| I _{AHF,N} | Typical Motor Used [kW] | Danfoss ordering number | | VLT 8000 |
|--|-------------------------|-------------------------|----------|------------|
| | | AHF 005 | AHF 010 | |
| 10 A | 4, 5.5 | 175G6600 | 175G6622 | 8006, 8008 |
| 19 A | 7.5 | 175G6601 | 175G6623 | 8011, 8016 |
| 26 A | 11 | 175G6602 | 175G6624 | 8022 |
| 35 A | 15, 18.5 | 175G6603 | 175G6625 | 8027 |
| 43 A | 22 | 175G6604 | 175G6626 | 8032 |
| 72 A | 30, 37 | 175G6605 | 175G6627 | 8042, 8052 |
| 101 A | 45, 55 | 175G6606 | 175G6628 | 8062, 8072 |
| 144 A | 75 | 175G6607 | 175G6629 | 8102 |
| 180 A | 90 | 175G6608 | 175G6630 | 8122 |
| 217 A | 110 | 175G6609 | 175G6631 | 8152 |
| 289 A | 132, 160 | 175G6610 | 175G6632 | 8202, 8252 |
| 324 A | | 175G6611 | 175G6633 | |
| Higher ratings can be achieved by paralleling the filter units | | | | |
| 360 A | 200 | Two 180 A units | | 8302 |
| 434 A | 250 | Two 217 A units | | 8352 |
| 578 A | 315 | Two 289 A units | | 8450 |
| 613 A | 355 | 289 A and 324 A units | | 8600 |

440-480V, 60Hz



VLT® 8000 AQUA

| IAHF,N | Typical Motor Used [HP] | Danfoss ordering number | | VLT 8000 |
|--|----------------------------|-------------------------|----------|------------|
| | | AHF 005 | AHF 010 | |
| 19 A | 10, 15 | 175G6612 | 175G6634 | 8011, 8016 |
| 26 A | 20 | 175G6613 | 175G6635 | 8022 |
| 35 A | 25, 30 | 175G6614 | 175G6636 | 8027, 8032 |
| 43 A | 40 | 175G6615 | 175G6637 | 8042 |
| 72 A | 50, 60 | 175G6616 | 175G6638 | 8052, 8062 |
| 101 A | 75 | 175G6617 | 175G6639 | 8072 |
| 144 A | 100, 125 | 175G6618 | 175G6640 | 8102, 8122 |
| 180 A | 150 | 175G6619 | 175G6641 | 8152 |
| 217 A | 200 | 175G6620 | 175G6642 | 8202 |
| 289 A | 250 | 175G6621 | 175G6643 | 8252 |
| Higher ratings can be achieved by paralleling the filter units | | | | |
| 324 A | 300 | 144 A and 180 A units | | 8302 |
| 397 A | 350 | 180 A and 217 A units | | 8352 |
| 506 A | 450 | 217 A and 289 A units | | 8450 |
| 578 A | 500 | Two 289 A units | | 8600 |

Introduction

Please note that the matching of the Danfoss AFD and filter is pre-calculated based on 400V/480V and assuming typical motor load (4 pole) and 160 % torque. For other combinations, please consult MG.80.BX.YY.

■ Unpacking and ordering an AFD

If you are in doubt as to which AFD you have received and which options it contains, use the following to find out.

■ Type code ordering number string

On the basis of your order, the AFD is given an ordering number that can be seen from the nameplate on the unit. The number may look as follows:

VLT-8008-A-T4-C20-R3-DL-F10-A00-C0

This means that the AFD ordered is a VLT 8008 for three-phase line voltage of 380-480 V (**T4**) in Compact enclosure IP 20 (**C20**). The hardware variant is with integral RFI filter, classes A & B (**R3**). The AFD features a control unit (**DL**) with a PROFIBUS option card (**F10**). No option card (A00) and no conformal coating (C0) Character no. 8 (**A**) indicates the application range of the unit: **A** = AQUA.

Chassis: This enclosure is only available for the larger power sizes of the VLT 8000 AQUA series. It is recommended for installation in standard cabinets.

IP 20/NEMA 1: This enclosure is used as standard enclosure for VLT 8000 AQUA. It is ideal for cabinet installation in areas where a high degree of protection is required. This enclosure also permits side-by-side installation.

NEMA 12: This enclosure can be fitted direct to the wall. Cabinets are not required. IP 54 units can also be installed side-by-side.

Hardware variant

The units in the program are available in the following hardware variants:

- ST: Standard unit with or without control unit. Without DC terminals, except for VLT 8042-8062, 200-240 V
VLT 8016-8300, 525-600 V
- SL: Standard unit with DC terminals.
- EX: Extended unit for VLT type 8152-8600 with control unit, DC terminals, connection of external 24 V DC supply for back-up of control PCB.
- DX: Extended unit for VLT type 8152-8600 with control unit, DC terminals, built-in line fuses and disconnect, connection of external 24 V DC supply for back-up of control PCB.
- PF: Standard unit for VLT 8152-8352 with 24 V DC supply for back-up of control PCB and built-in main fuses. No DC terminals.
- PS: Standard unit for VLT 8152-8352 with 24 V DC supply for back-up of control PCB. No DC terminals.
- PD: Standard unit for VLT 8152-8352 with 24 V DC supply for back-up of control PCB, built-in main fuses and disconnect. No DC terminals.

RFI filter

Units for a line voltage of 380-480 V and a motor power of up to 7.5 kW (VLT 8011) are always supplied with an integral class A1 & B filter. Units for higher motor power than these can be ordered either with or without an RFI filter. RFI filters are not available for 525-600 V units.

Control unit (keypad and display)

All types of units in the program, except for IP 54 units, can be ordered either with or without the control unit. IP 54 units always come *with* a control unit.

All types of units in the program are available with built-in application options including a relay card with four relays or a cascade controller card.

Conformal Coating

All types of units in the programme are available with or without conformal coating of the PCB.

200-240 V

| Typecode Position in string | T2 9-10 | C00 11-13 | C20 11-13 | CN1 11-13 | C54 11-13 | ST 14-15 | SL 14-15 | R0 16-17 | R1 16-17 | R3 16-17 |
|--------------------------------|------------|--------------|--------------|--------------|--------------|-------------|-------------|-------------|-------------|-------------|
| 4.0 kW/5.0 HP | 8006 | | X | | X | X | X | X | | X |
| 5.5 kW/7.5 HP | 8008 | | X | | X | X | X | X | | X |
| 7.5 kW/10 HP | 8011 | | X | | X | X | X | X | | X |
| 11 kW/15 HP | 8016 | | X | | X | X | X | X | | X |
| 15 kW/20 HP | 8022 | | X | | X | X | X | X | | X |
| 18.5 kW/25 HP | 8027 | | X | | X | X | X | X | | X |
| 22 kW/30 HP | 8032 | | X | | X | X | X | X | | X |
| 30 kW/40 HP | 8042 | X | | X | X | X | | X | X | |
| 37 kW/50 HP | 8052 | X | | X | X | X | | X | X | |
| 45 kW/60 HP | 8062 | X | | X | X | X | | X | X | |

380-480 V

| Typecode Position in string | T4 9-10 | C00 11-13 | C20 11-13 | CN1 11-13 | C54 11-13 | ST 14-15 | SL 14-15 | EX 14-15 | DX 14-15 | PS 14-15 | PD 14-15 | PF 14-15 | R0 16-17 | R1 16-17 | R3 16-17 |
|--------------------------------|------------|--------------|--------------|--------------|--------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|
| 4.0 kW/5.0 HP | 8006 | | X | | X | X | | | | | | | | | X |
| 5.5 kW/7.5 HP | 8008 | | X | | X | X | | | | | | | | | X |
| 7.5 kW/10 HP | 8011 | | X | | X | X | | | | | | | | X | |
| 11 kW/15 HP | 8016 | | X | | X | X | X | | | | | | X | | X |
| 15 kW/20 HP | 8022 | | X | | X | X | X | | | | | | X | | X |
| 18.5 kW/25 HP | 8027 | | X | | X | X | X | | | | | | X | | X |
| 22 kW/30 HP | 8032 | | X | | X | X | X | | | | | | X | | X |
| 30 kW/40 HP | 8042 | | X | | X | X | X | | | | | | X | | X |
| 37 kW/50 HP | 8052 | | X | | X | X | X | | | | | | X | | X |
| 45 kW/60 HP | 8062 | | X | | X | X | X | | | | | | X | | X |
| 55 kW/75 HP | 8072 | | X | | X | X | X | | | | | | X | | X |
| 75 kW/100 HP | 8102 | | X | | X | X | X | | | | | | X | | X |
| 90 kW/125 HP | 8122 | | X | | X | X | X | | | | | | X | | X |
| 110 kW/150 HP | 8152 | X | | X | X | X | | X | X | X | X | X | X | X | |
| 132 kW/200 HP | 8202 | X | | X | X | X | | X | X | X | X | X | X | X | |
| 160 kW/250 HP | 8252 | X | | X | X | X | | X | X | X | X | X | X | X | |
| 200 kW/300 HP | 8302 | X | | X | X | X | | X | X | X | X | X | X | X | |
| 250 kW/350 HP | 8352 | X | | X | X | X | | X | X | X | X | X | X | X | |
| 315 kW/450 HP | 8450 | (X) | | X | X | | | X | (X) | | | | X | X | |
| 355 kW/500 HP | 8500 | (X) | | X | X | | | X | (X) | | | | X | X | |
| 400 kW/600 HP | 8550 | (X) | | X | X | | | X | (X) | | | | X | X | |

(X): Compact IP 00 enclosure not available with DX

Voltage

T2: 200-240 VAC

T4: 380-480 VAC

Enclosure

C00: Compact IP 00

C20: Compact IP 20

CN1: Compact NEMA 1

C54: Compact IP 54

Hardware variant

ST: Standard

SL: Standard with DC terminals

EX: Extended with 24 V supply and DC terminals

DX: Extended with 24 V supply, DC terminals, disconnect and fuse

PS: Standard with 24 V supply

PD: Standard with 24 V supply, fuse and disconnect

PF: Standard with 24 V supply and fuse

RFI filter

R0: Without filter

R1: Class A1 filter

R3: Class A1 and B filter


NOTE

NEMA 1 exceeds IP 20

525-600 V

| Typecode Position in string | T6 9-10 | C00 11-13 | C20 11-13 | CN1 11-13 | ST 14-15 | R0 16-17 |
|--------------------------------|------------|--------------|--------------|--------------|-------------|-------------|
| 1.1 kW/1.5 HP | 8002 | | X | X | X | X |
| 1.5 kW/2.0 HP | 8003 | | X | X | X | X |
| 2.2 kW/3.0 HP | 8004 | | X | X | X | X |
| 3.0 kW/4.0 HP | 8005 | | X | X | X | X |
| 4.0 kW/5.0 HP | 8006 | | X | X | X | X |
| 5.5 kW/7.5 HP | 8008 | | X | X | X | X |
| 7.5 kW/10 HP | 8011 | | X | X | X | X |
| 11 kW/15 HP | 8016 | | | X | X | X |
| 15 kW/20 HP | 8022 | | | X | X | X |
| 18.5 kW/25 HP | 8027 | | | X | X | X |
| 22 kW/30 HP | 8032 | | | X | X | X |
| 30 kW/40 HP | 8042 | | | X | X | X |
| 37 kW/50 HP | 8052 | | | X | X | X |
| 45 kW/60 HP | 8062 | | | X | X | X |
| 55 kW/75 HP | 8072 | | | X | X | X |
| 75 kW/100 HP | 8100 | X | | X | X | X |
| 90 kW/125 HP | 8125 | X | | X | X | X |
| 110 kW/150 HP | 8150 | X | | X | X | X |
| 132 kW/200 HP | 8200 | X | | X | X | X |
| 160 kW/250 HP | 8250 | X | | X | X | X |
| 200 kW/300 HP | 8300 | X | | X | X | X |

T6: 525-600 VAC

C00: Compact IP 00

C20: Compact IP 20

CN1: Compact NEMA 1

ST: Standard

R0: Without filter

1) Not available with enclosure compact IP 54

2) Not available with fieldbus options (Fxx)

3) Not available for power sizes from 8450 to 8600


NOTE

NEMA 1 exceeds IP 20

Optional selections, 200-600 V

| | |
|---------------------------|------------------------|
| Display | Position: 18-19 |
| D0 ¹⁾ | Without LCP |
| DL | With LCP |
| Fieldbus option | Position: 20-22 |
| F00 | No options |
| F10 | Profibus DP V1 |
| F30 | DeviceNet |
| F40 | LonWorks free topology |
| Application option | Position: 23-25 |
| A00 | No options |
| A31 ²⁾ | Relay card 4 relays |
| A32 | Cascade Controller |
| Coating | Position: 26-27 |
| C0 ³⁾ | No coating |
| C1 | With coating |

TYPE CODE Table/Ordering form

| | | | | | | | | | | | | | | | |
|-----|---|--|--|---|---|---|--|--|---|---|---|--|---|--|---|
| VLT | 8 | | | A | T | C | | | R | D | F | | A | | C |
|-----|---|--|--|---|---|---|--|--|---|---|---|--|---|--|---|

Power sizes
e.g. 8008

Application range
A

Mains voltage
T2
T4
T6

Enclosure
C00
C20
C54
CN1

Hardware variant
ST
SL
PS
PD
PF
EX
DX

RFI filter
R0
R1
R3

Display unit (LCP)
DO
DL

Fieldbus option card
F00
F10
F30
F40

Application option card
A00
A31
A32

Coating
C0
C1

No. units of this type

Required delivery date

Ordered by:

Date:

Take a copy of the ordering forms. Fill them in and send or fax your order to the nearest office of the Danfoss sales organisation

176FA206.1.1

Introduction

■ General technical data

 Line supply (L1, L2, L3):

| | |
|---|------------------------------------|
| Supply voltage 200-240 V units | 3 x 200/208/220/230/240 V ±10% |
| Supply voltage 380-480 V units | 3 x 380/400/415/440/460/480 V ±10% |
| Supply voltage 525-600 V units | 3 x 525/550/575/600 V ±10% |
| Supply frequency | 50/60 Hz +/- 1% |
| Max. imbalance of supply voltage: | |
| VLT 8006 - 8011 AQUA / 380 - 480 V and VLT 8002 - 8011 AQUA / 525 - 600 V ... | ±2.0% of rated supply voltage |
| VLT 8016 - 8072 AQUA / 525 - 600 V, 380 - 480 V and | |
| VLT 8006 - 8032 AQUA / 200 - 240 V | ±1.5% of rated supply voltage |
| VLT 8100 - 8300 AQUA / 525 - 600 V, VLT 8102 - 8600 AQUA / 380 - 480 V and | |
| VLT 8042 - 8062 AQUA / 200 - 240 V | ±3.0% of rated supply voltage |
| Displacement factor / cos. ϕ | near unity (> 0.98) |
| True Power Factor (λ) | nominal 0.90 at rated load |
| Input Line (L1, L2, L3) Allowable On-OFF Switching Sequences | approx. 1 time/2 min. |
| Max. short-circuit current | 100 kA |

 VLT output data (U, V, W):

| | |
|--|---------------------------|
| Output voltage | 0-100% of supply voltage |
| Output frequency | 0 - 120 Hz |
| Rated motor voltage, 200-240 V units | 200/208/220/230/240 V |
| Rated motor voltage, 380-480 V units | 380/400/415/440/460/480 V |
| Rated motor voltage, 525-600 V units | 525/550/575 V |
| Rated motor frequency | 50/60 Hz |
| Switching on output | Unlimited |
| Ramp times | 1- 3600 sec. |

 Torque characteristics:

| | |
|--|--------------------------------|
| Starting torque | 110% for 1 min. |
| Starting torque (parameter 110 <i>High break-away torque</i>) | Max. torque: 130% for 0.5 sec. |
| Acceleration torque | 100% |
| Overload torque | 110% |

 Control card, digital inputs:

| | |
|---|---------------------------------|
| Number of programmable digital inputs | 8 |
| Terminal nos. | 16, 17, 18, 19, 27, 29, 32, 33 |
| Voltage level | 0-24 V DC (PNP positive logics) |
| Voltage level, logical "0" | < 5 V DC |
| Voltage level, logical "1" | > 10 V DC |
| Maximum voltage on input | 28 V DC |
| Input resistance, R_i | approx. 2 k Ω |
| Scanning time per input | 3 msec. |

Reliable galvanic isolation: All digital inputs are galvanically isolated from the supply voltage (PELV). In addition, the digital inputs can be isolated from the other terminals on the control card by connecting an external 24 V DC supply and opening switch 4. See switches 1-4.

Control card, analog inputs:

| | |
|---|-----------------------------|
| No. of programmable analog voltage inputs/thermistor inputs | 2 |
| Terminal nos. | 53, 54 |
| Voltage level | 0 - 10 V DC (scalable) |
| Input resistance, R_i | approx. 10 Ω |
| No. of programmable analog current inputs | 1 |
| Terminal no. ground | 55 |
| Current range | 0/4 - 20 mA (scalable) |
| Input resistance, R_i | approx. 200 Ω |
| Resolution | 10 bit + sign |
| Accuracy on input | Max. error 1% of full scale |
| Scanning time per input | 3 msec. |

Reliable galvanic isolation: All analog inputs are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Control card, pulse input:

| | |
|--|---------------------------------|
| No. of programmable pulse inputs | 3 |
| Terminal nos. | 17, 29, 33 |
| Max. frequency on terminal 17 | 5 kHz |
| Max. frequency on terminals 29, 33 | 20 kHz (PNP open collector) |
| Max. frequency on terminals 29, 33 | 65 kHz (Push-pull) |
| Voltage level | 0-24 V DC (PNP positive logics) |
| Voltage level, logic "0" | < 5 V DC |
| Voltage level, logic "1" | > 10 V DC |
| Maximum voltage on input | 28 V DC |
| Input resistance, R_i | approx. 2 k Ω |
| Scanning time per input | 3 msec. |
| Resolution | 10 bit + sign |
| Accuracy (100-1 kHz), terminals 17, 29, 33 | Max. error: 0.5% of full scale |
| Accuracy (1-5 kHz), terminal 17 | Max. error: 0.1% of full scale |
| Accuracy (1-65 kHz), terminals 29, 33 | Max. error: 0.1% of full scale |

Reliable galvanic isolation: All pulse inputs are galvanically isolated from the supply voltage (PELV). In addition, pulse inputs can be isolated from the other terminals on the control card by connecting an external 24 V DC supply and opening switch 4. See switches 1-4.

Control card, digital/pulse and analog outputs:

| | |
|---|--------------------------------|
| No. of programmable digital and analog outputs | 2 |
| Terminal nos. | 42, 45 |
| Voltage level at digital/pulse output | 0 - 24 V DC |
| Minimum load to frame (terminal 39) at digital/pulse output | 600 Ω |
| Frequency ranges (digital output used as pulse output) | 0-32 kHz |
| Current range at analog output | 0/4 - 20 mA |
| Maximum load to frame (terminal 39) at analog output | 500 Ω |
| Accuracy of analog output | Max. error: 1.5% of full scale |
| Resolution on analog output | 8 bit |

Reliable galvanic isolation: All digital and analog outputs are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Control card, 24 V DC supply:

| | |
|----------------------------|--------|
| Terminal nos. | 12, 13 |
| Max. load | 200 mA |
| Terminal nos. ground | 20, 39 |

Reliable galvanic isolation: The 24 V DC supply is galvanically isolated from the supply voltage (PELV), but has the same potential as the analog outputs.

 Control card, RS 485 serial communication :

| | |
|--------------------|------------------------------|
| Terminal nos. | 68 (TX+, RX+), 69 (TX-, RX-) |
|--------------------|------------------------------|

Reliable galvanic isolation: Full galvanic isolation (PELV).

 Relay outputs:

| | |
|--|---------------------------------|
| No. of programmable relay outputs | 2 |
| Terminal nos., control card | 4-5 (make) |
| Max. terminal load (AC) on 4-5, control card | 50 V AC, 1 A, 60 VA |
| Max. terminal load (DC-1 (IEC 947)) on 4-5, control card | 75 V DC, 1 A, 30 W |
| Max. terminal load (DC-1) on 4-5, control card for UL/cUL applications | 30 V AC, 1 A / 42.5 V DC, 1A |
| Terminal nos., power card and relay card | 1-3 (break), 1-2 (make) |
| Max. terminal load (AC) on 1-3, 1-2 power card | 240 V AC, 2 A, 60 VA |
| Max. terminal load DC-1 (IEC 947) on 1-3, 1-2, power card and relay card | 50 V DC, 2 A |
| Min. terminal load on 1-3, 1-2, power card | 24 V DC, 10 mA, 24 V AC, 100 mA |

 External 24 Volt DC supply (only available with VLT 8152-8600, 380-480 V):

| | |
|---------------------------|--|
| Terminal nos. | 35, 36 |
| Voltage range | 24 V DC \pm 15% (max. 37 V DC for 10 sec.) |
| Max. voltage ripple | 2 V DC |
| Power consumption | 15 W - 50 W (50 W for start-up, 20 msec.) |
| Min. pre-fuse | 6 Amp |

Reliable galvanic isolation: Full galvanic isolation if the external 24 V DC supply is also of the PELV type.

 Cable lengths and cross-sections:

| | |
|--|-------------------------------|
| Max. motor cable length, shielded cable | 150m/500 ft |
| Max. motor cable length, unshielded cable | 300m/1000 ft |
| Max. motor cable length, shielded cable VLT 8011 380-480 V | 100m/330 ft |
| Max. motor cable length, shielded cable VLT 8011 550-600 V | 50m/164 ft |
| Max. DC-bus cable length, shielded cable | 25m/82 ft from AFD to DC bar. |
| <i>Max. cable cross-section to motor, see next section</i> | |
| Max. cross-section for control cables | 1.5 mm ² /16 AWG |
| Max. cross-section for serial communication | 1.5 mm ² /16 AWG |

If UL/cUL is to be complied with, cable with temperature class 60/75°C / 140/167°F must be used (VLT 8002 - 8072 (550 - 600 V), VLT 8006 - 8072 (380 - 480 V) and VLT 8002 - 8032 (200 - 240V). If UL/cUL is to be complied with, cable with temperature class 75°C/167°F must be used (VLT 8100 - 8300 (550 - 600 V), VLT 8102 - 8600 (380 - 480 V), VLT 8042 - 8062 (200 - 240 V)

Control characteristics:

| | |
|--|----------------------------------|
| Frequency range | 0 - 120 Hz |
| Resolution on output frequency | ±0.003 Hz |
| System response time | 3 msec. |
| Speed, control range (open loop) | 1:100 of synchro. speed |
| Speed, accuracy (open loop) | < 1500 rpm: max. error ± 7.5 rpm |
| > 1500 rpm: max. error of 0.5% of actual speed | |
| Process, accuracy (closed loop) | < 1500 rpm: max. error ± 1.5 rpm |
| > 1500 rpm: max. error of 0.1% of actual speed | |

All control characteristics are based on a 4-pole asynchronous motor

Accuracy of display readout (parameters 009-012 Display readout):

| | |
|--|---|
| Motor current, 0 - 140% load | Max. error: ±2.0% of rated output current |
| Power kW, Power HP, 0 - 90% load | Max. error: ±5.0% of rated output power |

Externals:

| | |
|--|---|
| Enclosure | IP00/Chassis, IP20/IP21/NEMA 1, IP54/NEMA 12 |
| Vibration test | 0.7 g RMS 18-1000 Hz random. 3 directions for 2 hours (IEC 68-2-34/35/36) |
| Max. relative humidity | 93 % +2 %, -3 % (IEC 68-2-3) for storage/transport |
| Max. relative humidity | 95% non condensing (IEC 721-3-3; class 3K3) for operation |
| Aggressive environment (IEC 721-3-3) | Uncoated class 3C2 |
| Aggressive environment (IEC 721-3-3) | Coated class 3C3 |
| Ambient temperature, VLT 8006-8011 380-480 V, 8002-8011 525-600 V, IP 20//NEMA 1 | |
| Max. 45°C (117°F) (24-hour average max. 40°C (104°F)) | |
| Ambient temperature IP00/Chassis, IP20/NEMA 1, IP54/NEMA 12, VLT 8011 480 V | Max. 40°C/104°F (24-hour average max. 35°C/95°F) |
| <i>see Derating for high ambient temperature</i> | |
| Min. ambient temperature in full operation | 0°C (32°F) |
| Min. ambient temperature at reduced performance | -10°C (14°F) |
| Temperature during storage/transport | -25° - +65°/70°C (-13° - +149°/158°F) |
| Max. altitude above sea level | 1000 m (3300 ft) |
| <i>see Derating for high air pressure</i> | |

Installation

NOTE


VLT 8002-8300, 525-600 V units do not comply with EMC, Low Voltage or PELV directives.

VLT 8000 AQUA protection

- Electronic motor thermal protection against overload.
- Temperature monitoring of heat-sink ensures that the AFD cuts out if the temperature reaches 90°C (194°F) for IP00/Chassis and IP20/NEMA 1. For IP54/NEMA 12, the cut-out temperature is 80°C (176°F). An overtemperature can only be reset when the temperature of the heat-sink has fallen below 60°C (140°F). VLT 8151-8202 380-480 V cuts out at 80°C (176°F) and can be reset if the temperature is below 60°C (140 °F). VLT 8252-8352, 380-480 V cuts out at 105°C (230°F) and can be reset if the temperature has fallen below 70°C (154°F)
- The AFD is protected against short-circuiting on motor terminals U, V, W.
- The AFD is protected against ground fault on motor terminals U, V, W.
- Monitoring of the intermediate circuit voltage ensures that the AFD cuts out if the intermediate circuit voltage gets too high or too low.
- If a motor phase is missing, the AFD cuts out.

- If there is a line fault, the AFD is able to carry out a controlled deramping.
- If a line phase is missing, the AFD will cut out or autoderate when a load is placed on the motor. Alternatively, the drive can be programmed to decrease its output frequency as needed to maintain operation if desirable.


■ Technical data, line supply 3 x 200 - 240 V

| According to international requirements | | VLT type | 8006 | 8008 | 8011 |
|---|--|--------------------------|------------------------------|-------|-------|
|  | Output current ⁴⁾ | $I_{VLT,N}$ [A] | 16.7 | 24.2 | 30.8 |
| | | $I_{VLT,MAX}$ (60 s) [A] | 18.4 | 26.6 | 33.9 |
| | Output power (240 V) | $S_{VLT,N}$ [kVA] | 6.9 | 10.1 | 12.8 |
| | Typical shaft output | $P_{VLT,N}$ [kW] | 4.0 | 5.5 | 7.5 |
| | Typical shaft output | $P_{VLT,N}$ [HP] | 5 | 7.5 | 10 |
| Max. cable cross-section to motor and DC-bus | [mm ²]/[AWG] | | 10/8 | 16/6 | 16/6 |
| Max. input current | (200 V) (RMS) $I_{L,N}$ [A] | | 16.0 | 23.0 | 30.0 |
| Max. cable cross-section power | [mm ²]/[AWG] ²⁾ | | 4/10 | 16/6 | 16/6 |
| Max. pre-fuses | [-]/UL ¹⁾ [A] | | 35/30 | 50 | 60 |
| Line contactor | [Danfoss type] | | CI 6 | CI 9 | CI 16 |
| Efficiency ³⁾ | | | 0.95 | 0.95 | 0.95 |
| Weight IP 20 | [kg/lbs] | | 23/51 | 23/51 | 23/51 |
| Weight IP 54 | [kg/lbs] | | 35/77 | 35/77 | 38/84 |
| Power loss at max. load. [W] | Total | | 194 | 426 | 545 |
| Enclosure | VLT type | | IP 20/ NEMA 1, IP 54/NEMA 12 | | |

Installation



1. For type of fuse, see section *Fuses*.
2. American Wire Gauge.
3. Measured using 30 m/100 ft shielded motor cables at rated load and rated frequency.
4. Current ratings fulfill UL requirements for 208-240 V.

■ Technical data, line supply 3 x 200 - 240 V

| According to international requirements | VLT type | 8016 | 8022 | 8027 | 8032 | 8042 | 8052 | 8062 |
|---|---|----------------------------------|--------|--------|--------|----------------------|-----------------------------|------------------------------|
|  Output current ⁴⁾ | $I_{VLT,N}$ [A] (200-230 V) | 46.2 | 59.4 | 74.8 | 88.0 | 115 | 143 | 170 |
| | $I_{VLT,MAX}$ (60 s) [A] (200-230 V) | 50.6 | 65.3 | 82.3 | 96.8 | 127 | 158 | 187 |
| | $I_{VLT,N}$ [A] (240 V) | 46.0 | 59.4 | 74.8 | 88.0 | 104 | 130 | 154 |
| | $I_{VLT,MAX}$ (60 s) [A] (240 V) | 50.6 | 65.3 | 82.3 | 96.8 | 115 | 143 | 170 |
| Output power | $S_{VLT,N}$ [kVA] (240 V) | 19.1 | 24.7 | 31.1 | 36.6 | 41.0 | 52.0 | 61.0 |
| | Typical shaft output | $P_{VLT,N}$ [kW] | 11 | 15 | 18.5 | 22 | 30 | 37 |
| Typical shaft output | $P_{VLT,N}$ [HP] | 15 | 20 | 25 | 30 | 40 | 50 | 60 |
| Max. cable cross-section to motor and DC-bus [mm ²]/[AWG] ^{2) 5)} | Copper | 16/6 | 35/2 | 35/2 | 50/0 | 70/1/0 | 95/3/0 | 120/4/0 |
| | Aluminium ⁶⁾ | 16/6 | 35/2 | 35/2 | 50/0 | 95/3/0 ⁵⁾ | 90/250 mcm ⁵⁾ | 120/300 mcm ⁵⁾ |
| Min. cable cross-section to motor and DC-bus [mm ²]/[AWG] ²⁾ | | 10/8 | 10/8 | 10/8 | 16/6 | 10/8 | 10/8 | 10/8 |
| Max. input current (200 V) (RMS) $I_{L,N}$ [A] | | 46.0 | 59.2 | 74.8 | 88.0 | 101.3 | 126.6 | 149.9 |
| Max. cable cross-section power [mm ²]/[AWG] ^{2) 5)} | Copper | 16/6 | 35/2 | 35/2 | 50/0 | 70/1/0 | 95/3/0 | 120/4/0 |
| | Aluminium ⁶⁾ | 16/6 | 35/2 | 35/2 | 50/0 | 95/3/0 ⁵⁾ | 90/250 mcm ⁵⁾ | 120/300 mcm ⁵⁾ |
| Max. pre-fuses | [-/UL ¹⁾ [A] | 60 | 80 | 125 | 125 | 150 | 200 | 250 |
| Line contactor | [Danfoss type] | CI 32 | CI 32 | CI 37 | CI 61 | CI 85 | CI 85 | CI 141 |
| | [AC value] | AC-1 | AC-1 | AC-1 | AC-1 | | | |
| Efficiency ³⁾ | | 0.95 | 0.95 | 0.95 | 0.95 | 0.95 | 0.95 | 0.95 |
| Weight IP 00/Chassis | [kg/lbs] | - | - | - | - | 90/198 | 90/198 | 90/198 |
| Weight IP 20/NEMA 1 | [kg/lbs] | 23/51 | 30/66 | 30/66 | 48/106 | 101/223 | 101/223 | 101/223 |
| Weight IP 54 | [kg/lbs] | 38/84 | 49/108 | 50/110 | 55/121 | 104/229 | 104/229 | 104/229 |
| Power loss at max. load. | [W] | 545 | 783 | 1042 | 1243 | 1089 | 1361 | 1613 |
| Enclosure | | IP 00/IP 20/NEMA 1/IP 54/NEMA 12 | | | | | | |



1. For type of fuse, see section *Fuses*.
2. American Wire Gauge.
3. Measured using 30 m/100 ft shielded motor cables at rated load and rated frequency.
4. Current ratings fulfill UL requirements for 208-240 V.
5. Connection stud 1 x M8 / 2 x M8.
6. Aluminium cables with cross section above 35 mm² must be connected by use of an Al-Cu connector.

■ Technical data, line supply 3 x 380 - 480 V

| According to international requirements | | VLT type | 8006 | 8008 | 8011 |
|--|-----------------------------------|---|----------|----------------------------|---------|
|  | Output current | $I_{VLT,N}$ [A] (380-440 V) | 10.0 | 13.0 | 16.0 |
| | | $I_{VLT, MAX}$ (60 s) [A] (380-440 V) | 11.0 | 14.3 | 17.6 |
| | | $I_{VLT,N}$ [A] (441-480 V) | 8.2 | 11.0 | 14.0 |
| | | $I_{VLT, MAX}$ (60 s) [A] (441-480 V) | 9.0 | 12.1 | 15.4 |
| | Output power | $S_{VLT,N}$ [kVA] (400 V) | 7.2 | 9.3 | 11.5 |
| | | $S_{VLT,N}$ [kVA] (460 V) | 6.5 | 8.8 | 11.2 |
| | Typical shaft output | $P_{VLT,N}$ [kW] | 4.0 | 5.5 | 7.5 |
| | Typical shaft output | $P_{VLT,N}$ [HP] | 5 | 7.5 | 10 |
| | Max. cable cross-section to motor | [mm ²] / [AWG] ^{2) 4)} | 4/10 | 4/10 | 4/10 |
|  | Max. input current (RMS) | $I_{L,N}$ [A] (380 V) | 9.1 | 12.2 | 15.0 |
| | | $I_{L,N}$ [A] (480 V) | 8.3 | 10.6 | 14.0 |
| | Max. cable cross-section power | [mm ²] / [AWG] ^{2) 4)} | 4/10 | 4/10 | 4/10 |
| | Max. pre-fuses | [-]/UL ¹⁾ [A] | 25/20 | 25/25 | 35/30 |
| | Line contactor | [Danfoss type] | CI 6 | CI 6 | CI 6 |
| | Efficiency ³⁾ | | 0.96 | 0.96 | 0.96 |
| | Weight IP 20/NEMA 1 | [kg/lbs] | 10.5/23 | 10.5/23 | 10.5/23 |
| | Weight IP 54/NEMA 12 | [kg/lbs] | 14/31 | 14/31 | 14/31 |
| | Power loss at max. load. [W] | Total | 198 | 250 | 295 |
| | | Enclosure | VLT type | IP 20/NEMA 1/IP 54/NEMA 12 | |

1. For type of fuse, see section *Fuses*.
 2. American Wire Gauge.
 3. Measured using 30 m/100 ft shielded motor cables at rated load and rated frequency.
 4. Max. cable cross section is the maximum possible cable cross section that can be fitted on the terminals.
- Always comply with national and local regulations on min. cable cross-section.



■ Technical data, line supply 3 x 380 - 480 V

| According to international requirements | | VLT type | 8016 | 8022 | 8027 | 8032 | 8042 |
|---|---|---|-------|-------|-------|-------|--------|
|  | Output current | $I_{VLT,N}$ [A] (380-440 V) | 24.0 | 32.0 | 37.5 | 44.0 | 61.0 |
| | | $I_{VLT,MAX}$ (60 s) [A] (380-440 V) | 26.4 | 35.2 | 41.3 | 48.4 | 67.1 |
| | Output power | $I_{VLT,N}$ [A] (441-480 V) | 21.0 | 27.0 | 34.0 | 40.0 | 52.0 |
| | | $I_{VLT,MAX}$ (60 s) [A] (441-480 V) | 23.1 | 29.7 | 37.4 | 44.0 | 57.2 |
| | | $S_{VLT,N}$ [kVA] (400 V) | 17.3 | 23.0 | 27.0 | 31.6 | 43.8 |
| | | $S_{VLT,N}$ [kVA] (460 V) | 16.7 | 21.5 | 27.1 | 31.9 | 41.4 |
| Typical shaft output | $P_{VLT,N}$ [kW] | 11 | 15 | 18.5 | 22 | 30 | |
| Typical shaft output | $P_{VLT,N}$ [HP] | 15 | 20 | 25 | 30 | 40 | |
| Max. cable cross-section to motor and DC-bus, IP 20 | [mm ²]/[AWG] ^{2) 4)} | 16/6 | 16/6 | 16/6 | 35/2 | 35/2 | |
| Max. cable cross-section to motor and DC-bus, IP 54 | | 16/6 | 16/6 | 16/6 | 16/6 | 35/2 | |
| Min. cable cross-section to motor and DC-bus | | 10/8 | 10/8 | 10/8 | 10/8 | 10/8 | |
|  | Max. input current (RMS) | $I_{L,N}$ [A] (380 V) | 24.0 | 32.0 | 37.5 | 44.0 | 60.0 |
| | | $I_{L,N}$ [A] (480 V) | 21.0 | 27.6 | 34.0 | 41.0 | 53.0 |
| | Max. cable cross-section power, IP 20 | [mm ²]/[AWG] ^{2) 4)} | 16/6 | 16/6 | 16/6 | 35/2 | 35/2 |
| | Max. cable cross-section power, IP 54 | | 16/6 | 16/6 | 16/6 | 16/6 | 35/2 |
| | Max. pre-fuses | [-]/[UL ¹⁾] [A] | 63/40 | 63/40 | 63/50 | 63/60 | 80/80 |
| | Line contactor | [Danfoss type] | CI 9 | CI 16 | CI 16 | CI 32 | CI 32 |
| | Efficiency at rated frequency | | 0.96 | 0.96 | 0.96 | 0.96 | 0.96 |
| | Weight IP 20/NEMA 1 | [kg/lbs] | 21/46 | 21/46 | 22/49 | 27/60 | 28/62 |
| | Weight IP 54/NEMA 12 | [kg/lbs] | 41/90 | 41/90 | 42/93 | 42/93 | 54/119 |
| | Power loss at max. load. | [W] | 419 | 559 | 655 | 768 | 1065 |
| Enclosure | | IP 20/NEMA 1/ IP 54/NEMA 12 | | | | | |

1. For type of fuse, see section *Fuses*.
 2. American Wire Gauge.
 3. Measured using 30 m/100 ft shielded motor cables at rated load and rated frequency.
 4. Min. cable cross-section is the smallest cable cross-section allowed to be fitted on the terminals. Max. cable cross section is the maximum possible cable cross section that can be fitted on the terminals.
- Always comply with national and local regulations on min. cable cross-section.

■ Technical data, line supply 3 x 380 - 480 V



| According to international requirements | | VLT type | 8052 | 8062 | 8072 | 8102 | 8122 |
|---|---------------------------------------|----------|----------------------------|---------|---------|-----------|------------|
| Output current | $I_{VLT,N}$ [A] (380-440 V) | | 73.0 | 90.0 | 106 | 147 | 177 |
| | $I_{VLT, MAX}$ (60 s) [A] (380-440 V) | | 80.3 | 99.0 | 117 | 162 | 195 |
| | $I_{VLT,N}$ [A] (441-480 V) | | 65.0 | 77.0 | 106 | 130 | 160 |
| | $I_{VLT, MAX}$ (60 s) [A] (441-480 V) | | 71.5 | 84.7 | 117 | 143 | 176 |
| Output power | $S_{VLT,N}$ [kVA] (400 V) | | 52.5 | 64.7 | 73.4 | 102 | 123 |
| | $S_{VLT,N}$ [kVA] (460 V) | | 51.8 | 61.3 | 84.5 | 104 | 127 |
| Typical shaft output | $P_{VLT,N}$ [kW] | | 37 | 45 | 55 | 75 | 90 |
| Typical shaft output | $P_{VLT,N}$ [HP] | | 50 | 60 | 75 | 100 | 125 |
| Max. cable cross-section to motor and DC-bus, IP 20 | $[mm^2]/[AWG]^{2) 4) 6)}$ | | | | | 120 / 250 | 120 / 250 |
| | | | 35/2 | 50/0 | 50/0 | | $mcm^{5)}$ |
| Max. cable cross-section to motor and DC-bus, IP 54 | $[mm^2]/[AWG]^{2) 4) 6)}$ | | | | | 150 / 300 | 150 / 300 |
| | | | 35/2 | 50/0 | 50/0 | | $mcm^{5)}$ |
| Min. cable cross-section to motor and DC-bus | $[mm^2]/[AWG]^{2) 4)}$ | | 10/8 | 16/6 | 16/6 | 25/4 | 25/4 |
| Max. input current (RMS) | $I_{L,N}$ [A] (380 V) | | 72.0 | 89.0 | 104 | 145 | 174 |
| | $I_{L,N}$ [A] (480 V) | | 64.0 | 77.0 | 104 | 128 | 158 |
| Max. cable cross-section power, IP 20 | $[mm^2]/[AWG]^{2) 4) 6)}$ | | | | | 120 / 250 | 120 / 250 |
| | | | 35/2 | 50/0 | 50/0 | | mcm |
| Max. cable cross-section power, IP 54 | $[mm^2]/[AWG]^{2) 4) 6)}$ | | | | | 150 / 300 | 150 / 300 |
| | | | 35/2 | 50/0 | 50/0 | | mcm |
| Max. pre-fuses | $[-]/[UL^{1)}]$ [A] | | 100/100 | 125/125 | 150/150 | 225/225 | 250/250 |
| Line contactor | [Danfoss type] | | CI 37 | CI 61 | CI 85 | CI 85 | CI 141 |
| Efficiency at rated frequency | | | 0.96 | 0.96 | 0.96 | 0.98 | 0.98 |
| Weight IP 20/NEMA 1 | [kg/lbs] | | 41/90 | 42/93 | 43/96 | 54/119 | 54/119 |
| Weight IP 54/NEMA 12 | [kg/lbs] | | 56/123 | 56/123 | 60/132 | 77/170 | 77/170 |
| Power loss at max. load. | [W] | | 1275 | 1571 | 1851 | <1400 | <1600 |
| Enclosure | | | IP 20/NEMA 1/IP 54/NEMA 12 | | | | |


Installation

1. For type of fuse, see section *Fuses*.
2. American Wire Gauge.
3. Measured using 30 m/100 ft shielded motor cables at rated load and rated frequency.
4. Min. cable cross-section is the smallest cable cross-section allowed to be fitted on the terminals.
Max. cable cross section is the maximum possible cable cross section that can be fitted on the terminals.
Always comply with national and local regulations on min. cable cross-section.
5. DC connection 95 mm²/AWG 3/0.
6. Aluminium cables with cross-section above 35 mm² must be connected by use of an Al-Cu connector.

■ Technical data, line supply 3 x 380 - 480 V



| According to international requirements | | VLT type | 8152 | 8202 | 8252 | 8302 | 8352 |
|--|--------------------------------------|----------|--|----------|----------|----------|----------|
| Output current | $I_{VLT,N}$ [A] (380-440 V) | | 212 | 260 | 315 | 395 | 480 |
| | $I_{VLT,MAX}$ (60 s) [A] (380-440 V) | | 233 | 286 | 347 | 435 | 528 |
| | $I_{VLT,N}$ [A] (441-480 V) | | 190 | 240 | 302 | 361 | 443 |
| | $I_{VLT,MAX}$ (60 s) [A] (441-480 V) | | 209 | 264 | 332 | 397 | 487 |
| Output power | $S_{VLT,N}$ [kVA] (400 V) | | 147 | 180 | 218 | 274 | 333 |
| | $S_{VLT,N}$ [kVA] (460 V) | | 151 | 191 | 241 | 288 | 353 |
| Typical shaft output (380-440 V) $P_{VLT,N}$ [kW] | | | 110 | 132 | 160 | 200 | 250 |
| Typical shaft output (441-480 V) $P_{VLT,N}$ [HP] | | | 150 | 200 | 250 | 300 | 350 |
| Max. cable cross-section to motor and DC-bus [mm ²] 2) 4) 5) | | | 2x70 | 2x70 | 2x185 | 2x185 | 2x185 |
| Max. cable cross-section to motor and DC-bus [AWG] 2) 4) 5) | | | mcm | mcm | mcm | mcm | mcm |
| Min. cable cross-section to motor and DC-bus [mm ² /AWG] 2) 4) 5) | | | 35/2 | 35/2 | 35/2 | 35/2 | 35/2 |
| Max. input current (RMS) | $I_{L,N}$ [A] (380 V) | | 208 | 256 | 317 | 385 | 467 |
| | $I_{L,N}$ [A] (480 V) | | 185 | 236 | 304 | 356 | 431 |
| Max. cable cross-section to power [mm ²] 4) 5) | | | 2x70 | 2x70 | 2x185 | 2x185 | 2x185 |
| Max. cable cross-section to power [AWG] 2) 4) 5) | | | 2x2/0 | 2x2/0 | 2x350 | 2x350 | 2x350 |
| Max. pre-fuses | [-]/UL ¹⁾ [A] | | 300/300 | 350/350 | 450/400 | 500/500 | 630/600 |
| Line contactor | [Danfoss type] | | CI 141 | CI 250EL | CI 250EL | CI 300EL | CI 300EL |
| Weight IP 00/Chassis | [kg/lbs] | | 89/196 | 89/196 | 134/295 | 134/295 | 154/295 |
| Weight IP 20/NEMA 1 | [kg/lbs] | | 96/212 | 96/212 | 143/315 | 143/212 | 163/212 |
| Weight IP 54/NEMA 12 | [kg/lbs] | | 96/212 | 96/212 | 143/212 | 143/212 | 163/212 |
| Efficiency at rated frequency | | | 0.98 | | | | |
| Power loss at max. load. | [W] | | 2619 | 3309 | 4163 | 4977 | 6107 |
| Enclosure | | | IP 00/Chassis/IP 21/NEMA 1/IP 54/NEMA 12 | | | | |



1. For type of fuse, see section *Fuses*.
2. American Wire Gauge.
3. Measured using 30 m/100 ft shielded motor cables at rated load and rated frequency.
4. Min. cable cross-section is the smallest cable cross-section allowed to be fitted on the terminals. Max. cable cross section is the maximum possible cable cross section that can be fitted on the terminals.
Always comply with national and local regulations on min. cable cross-section.
5. Connection bolt 1 x M10 / 2 x M10 (line and motor), connection bolt 1 x M8 / 2 x M8 (DC-bus).


■ Technical data, line supply 3 x 380 - 480 V


| According to international requirements | | VLT type | 8450 | 8500 | 8600 |
|--|--------------------------------------|--------------------------|--|-------------|-------------|
| Output current | $I_{VLT,N}$ [A] (380-440 V) | | 600 | 658 | 745 |
| | $I_{VLT,MAX}$ (60 s) [A] (380-440 V) | | 660 | 724 | 820 |
| | $I_{VLT,N}$ [A] (441-480 V) | | 540 | 590 | 678 |
| | $I_{VLT,MAX}$ (60 s) [A] (441-480 V) | | 594 | 649 | 746 |
| Output power | $S_{VLT,N}$ [kVA] (400 V) | | 416 | 456 | 516 |
| | $S_{VLT,N}$ [kVA] (480 V) | | 430 | 470 | 540 |
| Typical shaft output (380-440 V) $P_{VLT,N}$ [kW] | | | 315 | 355 | 400 |
| Typical shaft output (441-480 V) $P_{VLT,N}$ [HP] | | | 450 | 500 | 600 |
| Max. cable cross-section to motor and DC-bus [mm ²] ^{4) 5)} | | | 2 x 400 | 2 x 400 | 2 x 400 |
| | | | 3 x 150 | 3 x 150 | 3 x 150 |
| Max. cable cross-section to motor and DC-bus [AWG] ^{2) 4) 5)} | | | 2 x 750 mcm | 2 x 750 mcm | 2 x 750 mcm |
| | | | 3 x 350 mcm | 3 x 350 mcm | 3 x 350 mcm |
| Min. cable cross-section to motor and DC-bus [mm ²] ^{4) 5)} | | | 70 | 70 | 70 |
| Min. cable cross-section to motor and DC-bus [AWG] ^{2) 4) 5)} | | | 3/0 | 3/0 | 3/0 |
| Max. input current (RMS) | $I_{L,MAX}$ [A] (380 V) | | 584 | 648 | 734 |
| | $I_{L,MAX}$ [A] (480 V) | | 526 | 581 | 668 |
| Max. cable cross-section to power [mm ²] ^{4) 5)} | | | 2 x 400 | 2 x 400 | 2 x 400 |
| | | | 3 x 150 | 3 x 150 | 3 x 150 |
| Max. cable cross-section to power [AWG] ^{2) 4) 5)} | | | 2 x 750 | 2 x 750 | 2 x 750 |
| | | | 3 x 350 | 3 x 350 | 3 x 350 |
| Min. cable cross-section to power [mm ²] ^{4) 5)} | | | 70 | 70 | 70 |
| Min. cable cross-section to power [AWG] ^{2) 4) 5)} | | | 3/0 | 3/0 | 3/0 |
| Max. pre-fuses (line) | | [-]/UL [A] ¹⁾ | 700/700 | 800/800 | 800/800 |
| Efficiency ³⁾ | | | 0.97 | 0.97 | 0.97 |
| Line contactor [Danfoss type] | | | CI 300EL | - | - |
| Weight IP 00/ | | | | | |
| Chassis [kg/lbs] | | | 515/1136 | 560/1235 | 585/1290 |
| Weight IP 20/ | | | | | |
| NEMA 1 [kg/lbs] | | | 630/1389 | 675/1488 | 700/1544 |
| Weight IP 54/ | | | | | |
| NEMA 12 [kg/lbs] | | | 640/1411 | 685/1510 | 710/1566 |
| Power loss at | | | | | |
| max. load [W] | | | 9450 | 10650 | 12000 |
| Enclosure | | | IP 00/Chassis/IP 20/NEMA 1/IP 54/NEMA 12 | | |


Installation

- For type of fuse, see section *Fuses*.
- American Wire Gauge.
- Measured using 30 m/100 ft shielded motor cables at rated load and rated frequency.
- Min. cable cross-section is the smallest cable cross-section allowed to be fitted on the terminals. Always comply with national and local regulations on min. cable cross-section. Max. cable cross section is the maximum possible cable cross section that can be fitted on the terminals.
- Connection stud 2 x M12/3 x M12.

■ Technical data, line supply 3 x 525 - 600 V

| According to international requirements | | VLT type | 8002 | 8003 | 8004 | 8005 | 8006 | 8008 | 8011 | |
|---|--|--------------------|----------|----------|----------|----------|----------|----------|----------|---|
|  | Output current $I_{VLT,N}$ [A] (550 V) | | 2.6 | 2.9 | 4.1 | 5.2 | 6.4 | 9.5 | 11.5 | |
| | $I_{VLT,MAX}$ (60 s) [A] (550 V) | | 2.9 | 3.2 | 4.5 | 5.7 | 7.0 | 10.5 | 12.7 | |
| | $I_{VLT,N}$ [A] (550 V) | | 2.4 | 2.7 | 3.9 | 4.9 | 6.1 | 9.0 | 11.0 | |
| | $I_{VLT,MAX}$ (60 s) [A] (575 V) | | 2.6 | 3.0 | 4.3 | 5.4 | 6.7 | 9.9 | 12.1 | |
| | Output $S_{VLT,N}$ [kVA] (550 V) | | 2.5 | 2.8 | 3.9 | 5.0 | 6.1 | 9.0 | 11.0 | |
| | $S_{VLT,N}$ [kVA] (575 V) | | 2.4 | 2.7 | 3.9 | 4.9 | 6.1 | 9.0 | 11.0 | |
| | Typical shaft output $P_{VLT,N}$ [kW] | | 1.1 | 1.5 | 2.2 | 3 | 4 | 5.5 | 7.5 | |
| | Typical shaft output $P_{VLT,N}$ [HP] | | 1.5 | 2 | 3 | 4 | 5 | 7.5 | 10 | |
| | Max. copper cable cross-section to motor and loadsharing | | | | | | | | | |
| | | [mm ²] | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 4 |
| | [AWG] ²⁾ | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 | |
| Rated Input | $I_{VLT,N}$ [A] (550 V) | 2.5 | 2.8 | 4.0 | 5.1 | 6.2 | 9.2 | 11.2 | | |
| Current | $I_{VLT,N}$ [A] (600 V) | 2.2 | 2.5 | 3.6 | 4.6 | 5.7 | 8.4 | 10.3 | | |
| Max.copper cable cross-section, power | | | | | | | | | | |
| | [mm ²] | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 4 | |
| | [AWG] ²⁾ | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 | |
| Max. prefuses (line) ¹⁾ [-]/UL [A] | | 3 | 4 | 5 | 6 | 8 | 10 | 15 | | |
| Efficiency | | 0.96 | | | | | | | | |
| Weight IP 20 / NEMA 1 | [kg/lbs] | 10.5/ 23 | 10.5/ 23 | 10.5/ 23 | 10.5/ 23 | 10.5/ 23 | 10.5/ 23 | 10.5/ 23 | 10.5/ 23 | |
| Estimated power loss at max. load (550 V) [W] | | 65 | 73 | 103 | 131 | 161 | 238 | 288 | | |
| Estimated power loss at max. load (600V) [W] | | 63 | 71 | 102 | 129 | 160 | 236 | 288 | | |
| Enclosure | | IP 20/NEMA 1 | | | | | | | | |





1. For type of fuse, see section *Fuses*.

2. American Wire Gauge (AWG).

3. Min. cable cross-section is the smallest cable cross-section allowed to be fitted into the terminals to comply with IP20. Always comply with national and local regulations on min. cable cross-section.

■ Technical data, line supply 3 x 525 - 600 V



| According to international requirements | | 8016 | 8022 | 8027 | 8032 | 8042 | 8052 | 8062 | 8072 |
|---|---------------------------|--------------|-----------|-----------|-----------|-----------|------------|------------|------------|
| Output current $I_{VLT,N}$ [A] (550 V) | | 18 | 23 | 28 | 34 | 43 | 54 | 65 | 81 |
| $I_{VLT,MAX}$ (60 s) [A] (550V) | | 20 | 25 | 31 | 37 | 47 | 59 | 72 | 89 |
| $I_{VLT,N}$ [A] (550 V) | | 17 | 22 | 27 | 32 | 41 | 52 | 62 | 77 |
| $I_{VLT,MAX}$ (60 s) [A] (575 V) | | 19 | 24 | 30 | 35 | 45 | 57 | 68 | 85 |
| Output | $S_{VLT,N}$ [kVA] (550 V) | 17 | 22 | 27 | 32 | 41 | 51 | 62 | 77 |
| | $S_{VLT,N}$ [kVA] (575 V) | 17 | 22 | 27 | 32 | 41 | 52 | 62 | 77 |
| Typical shaft output $P_{VLT,N}$ [kW] | | 11 | 15 | 18.5 | 22 | 30 | 37 | 45 | 55 |
| Typical shaft output $P_{VLT,N}$ [HP] | | 15 | 20 | 25 | 30 | 40 | 50 | 60 | 75 |
| Max. copper cable | | | | | | | | | |
| cross-section to motor | [mm ²] | 16 | 16 | 16 | 35 | 35 | 50 | 50 | 50 |
| and loadsharing ⁴⁾ | [AWG] ²⁾ | 6 | 6 | 6 | 2 | 2 | 1/0 | 1/0 | 1/0 |
| Min. cable | | | | | | | | | |
| cross-section to motor | [mm ²] | 0.5 | 0.5 | 0.5 | 10 | 10 | 16 | 16 | 16 |
| and loadsharing ³⁾ | [AWG] ²⁾ | 20 | 20 | 20 | 8 | 8 | 6 | 6 | 6 |
| Rated Input Current | | | | | | | | | |
| $I_{VLT,N}$ [A] (550 V) | | 18 | 22 | 27 | 33 | 42 | 53 | 63 | 79 |
| $I_{VLT,N}$ [A] (600 V) | | 16 | 21 | 25 | 30 | 38 | 49 | 38 | 72 |
| Max copper cable | [mm ²] | 16 | 16 | 16 | 35 | 35 | 50 | 50 | 50 |
| cross section, power ⁴⁾ | [AWG] ²⁾ | 6 | 6 | 6 | 2 | 2 | 1/0 | 1/0 | 1/0 |
| Max. prefuses (line) ¹⁾ [-/UL [A] | | 20 | 30 | 35 | 45 | 60 | 75 | 90 | 100 |
| Efficiency | | 0.96 | | | | | | | |
| Weight IP 20/NEMA 1 | [kg/lbs] | 23/ 51 | 23/ 51 | 23/ 51 | 30/ 66 | 30/ 66 | 48/ 106 | 48/ 106 | 48/ 106 |
| Estimated power loss at max. load (550 V) [W] | | 451 | 576 | 702 | 852 | 1077 | 1353 | 1628 | 2029 |
| Estimated power loss at max. load (600 V) [W] | | 446 | 576 | 707 | 838 | 1074 | 1362 | 1624 | 2016 |
| Enclosure | | IP 20/NEMA 1 | | | | | | | |


Installation

1. For type of fuse, see section *Fuses*.
2. American Wire Gauge (AWG).
3. Min. cable cross-section is the smallest cable cross-section allowed to be fitted into the terminals to comply with IP 20. Always comply with national and local regulations on min. cable cross-section.
4. Aluminium cables with cross-section above 35 mm² must be connected by use of an Al-Cu connector.

■ Technical data, line supply 3 x 525 - 600 V

| According to international requirements | | 8100 | 8125 | 8150 | 8200 | 8250 | 8300 |
|---|-------------------------|--------------------------------|---------|---------|-----------|-----------|-----------|
| Output current $I_{VLT,N}$ [A] (550 V) | | 104 | 131 | 151 | 201 | 253 | 289 |
| $I_{VLT,MAX}$ (60 s) [A] (550V) | | 114 | 144 | 166 | 221 | 278 | 318 |
| $I_{VLT,N}$ [A] (550 V) | | 99 | 125 | 144 | 192 | 242 | 289 |
| $I_{VLT,MAX}$ (60 s) [A] (575 V) | | 109 | 138 | 158 | 211 | 266 | 318 |
| Output $S_{VLT,N}$ [kVA] (550 V) | | 99 | 125 | 144 | 191 | 241 | 275 |
| $S_{VLT,N}$ [kVA] (575 V) | | 99 | 124 | 143 | 191 | 241 | 288 |
| Typical shaft output $P_{VLT,N}$ [kW] | | 75 | 90 | 110 | 132 | 160 | 200 |
| Typical shaft output $P_{VLT,N}$ [HP] | | 100 | 125 | 150 | 200 | 250 | 300 |
| Max. copper | | | | | | | |
| cable cross-section to motor and loadsharing ⁴⁾ | [mm ²] | 120 | 120 | 120 | 2x120 | 2x120 | 2x120 |
| | [AWG] ²⁾ | 4/0 | 4/0 | 4/0 | 2x4/0 | 2x4/0 | 2x4/0 |
| Max. aluminium cable cross-section to motor and loadsharing ⁴⁾ | [mm ²] | 185 | 185 | 185 | 2x185 | 2x185 | 2x185 |
| | [AWG] ²⁾ | 300 mcm | 300 mcm | 300 mcm | 2x300 mcm | 2x300 mcm | 2x300 mcm |
| Min. cable cross-section to motor and loadsharing ³⁾ | [mm ²] | 6 | 6 | 6 | 2x6 | 2x6 | 2x6 |
| | [AWG] ²⁾ | 8 | 8 | 8 | 2x8 | 2x8 | 2x8 |
| Rated Input Current | $I_{VLT,N}$ [A] (550 V) | 101 | 128 | 147 | 196 | 246 | 281 |
| | $I_{VLT,N}$ [A] (600 V) | 92 | 117 | 134 | 179 | 226 | 270 |
| Max copper cable cross section, power ⁴⁾ | [mm ²] | 120 | 120 | 120 | 2x120 | 2x120 | 2x120 |
| | [AWG] ²⁾ | 4/0 | 4/0 | 4/0 | 2x4/0 | 2x4/0 | 2x4/0 |
| Max. aluminium cable cross-section, power ⁴⁾ | [mm ²] | 185 | 185 | 185 | 2x185 | 2x185 | 2x185 |
| | [AWG] ²⁾ | 300 mcm | 300 mcm | 300 mcm | 2x300 mcm | 2x300 mcm | 2x300 mcm |
| Max. prefuses (line) ¹⁾ [-]/UL [A] | | 125 | 175 | 200 | 250 | 350 | 400 |
| Efficiency | | 0.96-0.97 | | | | | |
| Weight IP00 / Chassis | [kg] | 109 | 109 | 109 | 146 | 146 | 146 |
| | [lbs] | 240 | 240 | 240 | 322 | 322 | 322 |
| Weight IP20 / NEMA 1 | [kg] | 121 | 121 | 121 | 161 | 161 | 161 |
| | [lbs] | 267 | 267 | 267 | 355 | 355 | 355 |
| Estimated power (550 V) [W] | | 2605 | 3285 | 3785 | 5035 | 6340 | 7240 |
| loss at max. load (600 V) [W] | | 2560 | 3275 | 3775 | 5030 | 6340 | 7570 |
| Enclosure | | IP 00/Chassis and IP 20/NEMA 1 | | | | | |



1. For type of fuse, see section *Fuses*.
2. American Wire Gauge (AWG).
3. Min. cable cross-section is the smallest cable cross-section allowed to be fitted into the terminals to comply with IP20. Always comply with national and local regulations on min. cable cross-section.
4. Connection stud 1 x M8 / 2 x M8.

■ Fuses
UL compliance

To comply with UL/cUL approvals, pre-fuses according to the table below must be used.

200-240 V

| VLT | Bussmann | SIBA | Littel fuse | Ferraz-Shawmut |
|------------|----------|-------------|-------------|--------------------|
| 8006 | KTN-R30 | 5017906-032 | KLN-R30 | ATM-R30 or A2K-30R |
| 8008 | KTN-R50 | 5012406-050 | KLN-R50 | A2K-50R |
| 8011, 8016 | KTN-R60 | 5014006-063 | KLN-R60 | A2K-60R |
| 8022 | KTN-R80 | 5014006-080 | KLN-R80 | A2K-80R |
| 8027, 8032 | KTN-R125 | 2028220-125 | KLN-R125 | A2K-125R |
| 8042 | FWX-150 | 2028220-150 | L25S-150 | A25X-150 |
| 8052 | FWX-200 | 2028220-200 | L25S-200 | A25X-200 |
| 8062 | FWX-250 | 2028220-250 | L25S-250 | A25X-250 |

380-480 V

| | Bussmann | SIBA | Littel fuse | Ferraz-Shawmut |
|------------|----------|-------------|-------------|--------------------|
| 8006 | KTS-R20 | 5017906-020 | KLS-R20 | ATM-R20 or A6K-20R |
| 8008 | KTS-R25 | 5017906-025 | KLS-R25 | ATM-R25 or A6K-25R |
| 8011 | KTS-R30 | 5012406-032 | KLS-R30 | ATM-R30 or A6K-30R |
| 8016, 8022 | KTS-R40 | 5014006-040 | KLS-R40 | A6K-40R |
| 8027 | KTS-R50 | 5014006-050 | KLS-R50 | A6K-50R |
| 8032 | KTS-R60 | 5014006-063 | KLS-R60 | A6K-60R |
| 8042 | KTS-R80 | 2028220-100 | KLS-R80 | A6K-80R |
| 8052 | KTS-R100 | 2028220-125 | KLS-R100 | A6K-100R |
| 8062 | KTS-R125 | 2028220-125 | KLS-R125 | A6K-125R |
| 8072 | KTS-R150 | 2028220-160 | KLS-R150 | A6K-150R |
| 8102 | FWH-220 | 2028220-200 | L50S-225 | A50-P225 |
| 8122 | FWH-250 | 2028220-250 | L50S-250 | A50-P250 |
| 8152 | FWH-300 | 2028220-315 | L50S-300 | A50-P300 |
| 8202 | FWH-350 | 2028220-315 | L50S-350 | A50-P350 |
| 8252 | FWH-400 | 206xx32-400 | L50S-400 | A50-P400 |
| 8302 | FWH-500 | 206xx32-500 | L50S-500 | A50-P500 |
| 8352 | FWH-600 | 206xx32-600 | L50S-600 | A50-P600 |
| 8450 | FWH-700 | 206xx32-700 | L50S-700 | A50-P700 |
| 8500 | FWH-800 | 206xx32-800 | L50S-800 | A50-P800 |
| 8600 | FWH-800 | 206xx32-800 | L50S-800 | A50-P800 |

525-600 V

| | Bussmann | SIBA | Littel fuse | Ferraz-Shawmut |
|------|----------|-------------|-------------|----------------|
| 8002 | KTS-R3 | 5017906-004 | KLS-R003 | A6K-3R |
| 8003 | KTS-R4 | 5017906-004 | KLS-R004 | A6K-4R |
| 8004 | KTS-R5 | 5017906-005 | KLS-R005 | A6K-5R |
| 8005 | KTS-R6 | 5017906-006 | KLS-R006 | A6K-6R |
| 8006 | KTS-R8 | 5017906-008 | KLS-R008 | A6K-8R |
| 8008 | KTS-R10 | 5017906-010 | KLS-R010 | A6K-10R |
| 8011 | KTS-R15 | 5017906-016 | KLS-R015 | A6K-15R |
| 8016 | KTS-R20 | 5017906-020 | KLS-R020 | A6K-20R |
| 8022 | KTS-R30 | 5017906-030 | KLS-R030 | A6K-30R |
| 8027 | KTS-R35 | 5014006-040 | KLS-R035 | A6K-35R |
| 8032 | KTS-R45 | 5014006-050 | KLS-R045 | A6K-45R |
| 8042 | KTS-R60 | 5014006-063 | KLS-R060 | A6K-60R |
| 8052 | KTS-R75 | 5014006-080 | KLS-R075 | A6K-80R |
| 8062 | KTS-R90 | 5014006-100 | KLS-R090 | A6K-90R |
| 8072 | KTS-R100 | 5014006-100 | KLS-R100 | A6K-100R |
| 8100 | FWP-125A | 2018920-125 | L70S-125 | A70QS-125 |
| 8125 | FWP-175A | 2018920-180 | L70S-175 | A70QS-175 |
| 8150 | FWP-200A | 2018920-200 | L70S-200 | A70QS-200 |
| 8200 | FWP-250A | 2018920-250 | L70S-250 | A70QS-250 |
| 8250 | FWP-350A | 206XX32-350 | L70S-350 | A70QS-350 |
| 8300 | FWP-400A | 206xx32-400 | L70S-400 | A70QS-400 |

KTS-fuses from Bussmann may substitute KTN for 240 V drives.

FWH-fuses from Bussmann may substitute FWX for 240 V drives.

KLSR fuses from LITTEL FUSE may substitute KLNR fuses for 240 V drives.

L50S fuses from LITTEL FUSE may substitute L50S fuses for 240 V drives.

A6KR fuses from FERRAZ SHAWMUT may substitute A2KR for 240 V drives.

A50X fuses from FERRAZ SHAWMUT may substitute A25X for 240 V drives.

Non UL compliance

If UL/cUL is not to be complied with, we recommend the above mentioned fuses or:

| | | |
|---------------|-----------|---------|
| VLT 8006-8032 | 200-240 V | type gG |
| VLT 8042-8062 | 200-240 V | type gR |
| VLT 8006-8072 | 380-480 V | type gG |
| VLT 8102-8600 | 380-480 V | type gR |
| VLT 8002-8072 | 525-600 V | type gG |
| VLT 8100-8300 | 525-600 V | type gR |

Not following the recommendation may result in unnecessary damage of the drive in case of malfunction. Fuses must be designed for protection in a circuit capable of supplying a maximum of 100000 A_{rms} (symmetrical), 500 V/600 V maximum.

■ Mechanical dimensions

All the below listed measurements are in mm./in

| VLT type | A | B | C | a | b | aa/bb | Type | |
|----------------------------------|-----------|-----------|------------------------|-----------|-----------|---------------|---------------|---|
| IP 00/Chassis 200 - 240 V | | | | | | | | |
| 8042 - 8062 | 800/31.5 | 370/14.6 | 335/13.2 | 780/30.7 | 270/10.6 | 225/8.9 | B | |
| IP 00 380 - 480 V | | | | | | | | |
| 8152 - 8202 | 1046/41.2 | 408/16.1 | 375/14.8 ¹⁾ | 1001/39.4 | 304/12.0 | 225/8.9 | J | |
| 8252 - 8352 | 1327/52.2 | 408/16.1 | 375/14.8 ¹⁾ | 1282/50.5 | 304/12.0 | 225/8.9 | J | |
| 8450 - 8600 | 1896/74.6 | 1099/43.3 | 490/19.3 | 1847/72.7 | 1065/41.9 | 400/15.7 (aa) | I | |
| IP 20/NEMA 1 200 - 240 V | | | | | | | | |
| 8006 - 8011 | 560/22.0 | 242/9.5 | 260/10.2 | 540/21.3 | 200/7.9 | 200/7.9 | D | |
| 8016 - 8022 | 700/27.6 | 242/9.5 | 260/10.2 | 680/26.8 | 200/7.9 | 200/7.9 | D | |
| 8027 - 8032 | 800/31.5 | 308/12.1 | 296/11.7 | 780/30.7 | 270/10.6 | 200/7.9 | D | |
| 8042 - 8062 | 954/37.6 | 370/14.6 | 335/13.2 | 780/30.7 | 270/10.6 | 225/8.9 | E | |
| IP 20/NEMA 1 380 - 480 V | | | | | | | | |
| 8006 - 8011 | 395/15.6 | 220/8.7 | 200/7.9 | 384/15.1 | 200/7.9 | 100/3.9 | C | |
| 8016 - 8027 | 560/22.0 | 242/9.5 | 260/10.2 | 540/21.3 | 200/7.9 | 200/7.9 | D | |
| 8032 - 8042 | 700/27.6 | 242/9.5 | 260/10.2 | 680/26.8 | 200/7.9 | 200/7.9 | D | |
| 8052 - 8072 | 800/31.5 | 308/12.1 | 296/11.7 | 780/30.7 | 270/10.6 | 200/7.9 | D | |
| 8102 - 8122 | 800/31.5 | 370/14.6 | 335/13.2 | 780/30.7 | 330/13.0 | 225/8.9 | D | |
| 8450 - 8600 | 2010/79.1 | 1200/47.2 | 600/23.6 | - | - | 400/15.7 (aa) | H | |
| IP 21/NEMA 1 380-480 V | | | | | | | | |
| 8152 - 8202 | 1208/40.5 | 420/16.5 | 373/14.7 ¹⁾ | 1154/45.4 | 304/12.0 | 225/8.9 | J | |
| 8252 - 8352 | 1588/62.5 | 420/16.5 | 373/14.7 ¹⁾ | 1535/60.4 | 304/12.0 | 225/8.9 | J | |
| IP 54/NEMA 12 200 - 240 V | | | | | | | | |
| 8006 - 8011 | 810/31.9 | 350/13.8 | 280/11.0 | 70/2.8 | 560/22.0 | 326/12.8 | 200/7.9 | F |
| 8016 - 8032 | 940/37.0 | 400/15.7 | 280/11.0 | 70/2.8 | 690/27.2 | 375/14.8 | 200/7.9 | F |
| 8042 - 8062 | 937/36.9 | 495/9.5 | 421/16.6 | - | 830/32.7 | 374/14.8 | 225/8.9 | G |
| IP 54/NEMA 12 380 - 480 V | | | | | | | | |
| 8006 - 8011 | 530/20.9 | 282/11.1 | 195/7.7 | 85/3.3 | 330/13.0 | 258/10.2 | 100/3.9 | F |
| 8016 - 8032 | 810/31.9 | 350/13.8 | 280/11.0 | 70/2.8 | 560/22.0 | 326/12.8 | 200/7.9 | F |
| 8042 - 8072 | 940/37.0 | 400/15.7 | 280/11.0 | 70/2.8 | 690/27.2 | 375/14.8 | 200/7.9 | F |
| 8102 - 8122 | 940/37.0 | 400/15.7 | 360/14.2 | 70/2.8 | 690/27.2 | 375/14.8 | 225/8.9 | F |
| 8152 - 8202 | 1208/47.5 | 420/16.3 | 373/14.7 ¹⁾ | - | 1154/45.4 | 304/12.0 | 225/8.9 | J |
| 8252 - 8352 | 1588/62.5 | 420/16.3 | 373/14.7 ¹⁾ | - | 1535/60.4 | 304/12.0 | 225/8.9 | J |
| 8450 - 8600 | 2010/79.1 | 1200/47.2 | 600/23.6 | - | - | - | 400/15.7 (aa) | H |

Installation

1. With disconnect add 42 mm/1.7 in

aa: Minimum space above enclosure

bb: Minimum space below enclosure

■ Mechanical dimensions


All the below listed measurements are in mm./in

| VLT Type | A | B | C | a | b | aa/bb* | Type |
|---|------------|-----------|-----------|------------|-----------|-----------|------|
| IP 00/Chassis 525 - 600 V | | | | | | | |
| 8100 - 8150 | 800/31.55 | 370/14.57 | 335/13.19 | 780/30.71 | 270/10.63 | 250/9.84 | B |
| 8200 - 8300 | 1400/55.12 | 420/16.54 | 400/15.75 | 1380/54.33 | 350/13.78 | 300/11.81 | B |
| IP 20/NEMA 1 525 - 600 V | | | | | | | |
| 8002 - 8011 | 395/15.55 | 220/8.66 | 200/7.87 | 384/15.12 | 200/7.87 | 100/3.94 | C |
| 8016 - 8027 | 560/22.05 | 242/9.53 | 260/10.23 | 540/21.26 | 200/7.87 | 200/7.87 | D |
| 8032 - 8042 | 700/27.56 | 242/9.53 | 260/10.23 | 680/26.77 | 200/7.87 | 200/7.87 | D |
| 8052 - 8072 | 800/31.50 | 308/12.13 | 296/11.65 | 780/30.71 | 270/10.63 | 200/7.87 | D |
| 8100 - 8150 | 954/37.60 | 370/14.57 | 335/13.19 | 780/30.71 | 270/10.63 | 250/9.84 | E |
| 8200 - 8350 | 1554/61.22 | 420/16.54 | 400/15.75 | 1380/54.33 | 350/13.78 | 300/11.81 | E |
| Option for IP 00/Chassis VLT 8100 - 8300 525 - 600 V | | | | | | | |
| IP 20/NEMA 1 bottom cover | A1 | B1 | C1 | | | | |
| 8100 - 8150 | 175/6.89 | 370/14.57 | 335/13.19 | | | | |
| 8200 - 8300 | 175/6.89 | 420/16.54 | 400/15.75 | | | | |


*) aa: Minimum space above enclosure

bb: Minimum space below enclosure


■ Mechanical dimensions




Type B, IP00
With option and enclosure IP20




Type E, IP20




Type C, IP20



Type F, IP54



Type D, IP20




Type G, IP54


Installation

176FA224.10


■ Mechanical dimensions (cont.)



Type H, IP 20, IP 54



Type I, IP 00



Type J, IP 00, IP 21, IP 54


■ Mechanical installation



Please pay attention to the requirements that apply to integration and field mounting kit, see the below list. The information given in the list must be observed to avoid serious damage or injury, especially when installing large units.

The adjustable frequency drive *must* be installed vertically.

The adjustable frequency drive is cooled by means of air circulation. For the unit to be able to release its cooling air, the *minimum* distance over and below the unit must be as shown in the illustration below. To protect the unit from overheating, it must be ensured that the ambient temperature *does not rise above the max. temperature stated for the adjustable frequency drive and that the 24-hour average temperature is not exceeded*. The max. temperature and 24-hour average can be seen from the General Technical section. When installing the adjustable frequency drive on a non flat surface, i.e. a frame, please consult the instruction, MN.50.XX.YY. If the ambient temperature is in the range of 45° C - 55° C, derating of the adjustable frequency drive will be required in accordance with the diagram in the Design Guide. The service life of the adjustable frequency drive will be reduced if no allowance is made for the derating for ambient temperature.



All units require a minimum space above and below the enclosure.

Installation



■ Installation of VLT 8006-8352

All AFDs must be installed in a way that ensures proper cooling.

Cooling

Side by side/flange by flange


All AFDs can be mounted side by side/flange by flange.



| | d [mm/in] | Comments |
|-------------------------------|-----------|---|
| Compact (all enclosure types) | | |
| VLT 8006-8011, 380-480 V | 100/3.9 | Installation on a plane, vertical surface (no spacers) |
| VLT 8002-8011, 525-600 V | 100/3.9 | |
| VLT 8006-8032, 200-240 V | 200/7.9 | Installation on a plane, vertical surface (no spacers) |
| VLT 8016-8072 380-480 V | 200/7.9 | |
| VLT 8102-8122 380-480 V | 225/8.9 | |
| VLT 8016-8072 525-600 V | 200/7.9 | |
| VLT 8042-8062, 200-240 V | 225/8.9 | Installation on a plane, vertical surface (no spacers) |
| VLT 8100-8300, 525-600 V | 225/8.9 | |
| VLT 8152-8352, 380-480 V | 225/8.9 | Installation on a plane, vertical surface (spacers can be used). IP 54 filter mats must be changed when they are dirty. |

■ Installation of VLT 8450-8600 380-480 V Compact IP 00/Chassis, IP 20/NEMA 1 and IP 54/NEMA 12


Cooling



All units in the above-mentioned series require a minimum space of 400 mm (15.8 in) above the enclosure and must be installed on a plane floor. This applies to both IP 00/Chassis, IP 20/NEMA 1 and IP 54/NEMA 12 units.

Gaining access to VLT 8450-8600 requires a minimum space of 605 mm (23.8 in) in front of the AFD.

Side-by-side



All IP 00/Chassis, IP 20/NEMA 1 and IP 54/NEMA 12 units in the above-mentioned series can be installed side by side without any space between them, since these units do not require cooling on the sides.

Installation

■ IP 00 VLT 8450-8600 380-480 V

The IP 00/Chassis unit is designed for installation in a cabinet when installed according to the instructions

in the Installation Guide MG.56.AX.YY. Please note, that the same conditions as for NEMA 1/ IP20 and IP54/NEMA 12 must be fulfilled.

■ **General information about electrical installation**

■ **High voltage warning**



The voltage of the AFD is dangerous whenever the equipment is connected to line. Incorrect installation of the motor or the AFD may cause damage to the equipment, serious personal injury or death. Consequently, the instructions in this manual, as well as national and local safety regulations, must be complied with. Touching the electrical parts may be fatal - even after disconnection from line:

Using VLT 8006-8062, 200-240 V wait at least 15 minutes

Using VLT 8006-8072, 380-480 V wait at least 15 minutes

Using VLT 8102-8352, 380-480 V wait at least 20 minutes

Using VLT 8450-8600, 380-480 V wait at least 15 minutes

Using VLT 8002-8006, 525-600 V wait at least 4 minutes

Using VLT 8008-8027, 525-600 V wait at least 15 minutes

Using VLT 8032-8300, 525-600 V wait at least 30 minutes



NOTE

It is the user's or certified electrician's responsibility to ensure correct grounding and protection in accordance with applicable national and local codes and standards.

■ **Grounding**

The following basic issues need to be considered when installing an AFD.

- **Safety grounding:** Please note that the AFD has a high leakage current and must be grounded appropriately for safety reasons. Apply local safety regulations.
- **High-frequency grounding:** Keep the ground wire connections as short as possible.

Connect the different ground systems at the lowest possible conductor impedance. The lowest possible conductor impedance is obtained by keeping the conductor as short as possible and by using the greatest possible surface area. A flat conductor, for example, has a lower HF impedance than a round conductor for the same conductor cross-section $C_{V\text{ESS}}$.

If more than one device is installed in cabinets, the cabinet rear plate, which must be made of metal, should be used as a common ground reference plate. The metal cabinets of the different devices are mounted on the cabinet rear plate using the lowest possible HF impedance. This avoids having different HF voltages for the individual devices and avoids the risk of radio interference currents running in connection cables that may be used between the devices. The radio interference will have been reduced.

In order to obtain a low HF impedance, use the fastening bolts of the devices as HF connection to the rear plate. It is necessary to remove insulating paint or similar from the fastening points.

■ **Cables**

Control cables and the filtered line cable should be installed separate from the motor cables so as to avoid interference overcoupling. Normally, a distance of 204mm (8 in) will be sufficient, but it is recommended to keep the greatest possible distance wherever possible, especially where cables are installed in parallel over a substantial distance.

With respect to sensitive signal cables, such as telephone cables and data cables, the greatest possible distance is recommended with a minimum of 1m (3 ft) per 5m (15 ft) of power cable (line and motor cable). It must be pointed out that the necessary distance depends on the sensitivity of the installation and the signal cables, and that therefore no precise values can be stated.

If cable jaws are used, sensitive signal cables are not to be placed in the same cable jaws as the motor cable or brake cable.

If signal cables are to cross power cables, this should be done at an angle of 90 degrees.

Remember that all interference-filled in- or outgoing cables to/from a cabinet should be shielded/armored or filtered.

■ **Shielded/armored cables**

The shield must be a low HF-impedance shield. This is ensured by using a braided shield of copper, aluminium

or iron. Shield armor intended for mechanical protection, for example, is not suitable.

■ Extra protection with regard to indirect contact

ELCB relays, multiple protective grounding or grounding can be used as extra protection, provided that local safety regulations are complied with. In the case of an ground fault, a DC content may develop in the faulty current.

Never use ELCB relays, type A, since such relays are not suitable for DC fault currents.

If ELCB relays are used, this must be:

- Suitable for protecting equipment with a direct current content (DC) in the faulty current (3-phase bridge rectifier)
 - Suitable for power-up with short charging current to ground
 - Suitable for a high leakage current
-

■ RFI switch

Mains supply isolated from earth:

If the adjustable frequency drive is supplied from an isolated mains source (IT mains and grounded delta), the RFI switch can be turned off (OFF). In OFF position, the internal RFI capacities (filter capacitors) between the chassis and the intermediate circuit are cut off to avoid damage to the intermediate circuit and to reduce the earth capacity currents (according to IEC 61800-3).



NOTE

The RFI switch is not to be operated with mains connected to the unit. Check that the mains supply has been disconnected before operating the RFI switch.



NOTE


Open RFI switch is only allowed at factory set switching frequencies.



NOTE


The RFI switch disconnects the capacitors galvanically to ground.

The red switches are operated by means of e.g. a screwdriver. They are set in the OFF position when they are pulled out and in ON position when they are pushed in (see drawing below). Factory setting is ON.



Mains supply connected to earth:


The RFI switch must be in ON position in order for the adjustable frequency drive to comply with the EMC-standard.



Compact IP 20/NEMA 1

VLT 8006 - 8011 380 - 480 V

VLT 8002 - 8011 525 - 600 V



Compact IP 20/NEMA 1

VLT 8016 - 8027 380 - 480 V

VLT 8006 - 8011 200 - 240 V

VLT 8016 - 8027 525 - 600 V




Compact IP 20/NEMA 1

VLT 8032 - 8042 380 - 480 V


VLT 8016 - 8022 200 - 240 V

VLT 8032 - 8042 525 - 600 V



Compact IP 54/NEMA 12
VLT 8006 - 8011 380 - 480 V

Compact IP 20/NEMA 1
VLT 8052 - 8122 380 - 480 V
VLT 8027 - 8032 200 - 240 V
VLT 8052 - 8072 525 - 600 V



Compact IP 54/NEMA 12
VLT 8016 - 8032 380 - 480 V
VLT 8006 - 8011 200 - 240 V

Compact IP 54/NEMA 12
VLT 8102 - 8122 380 - 480 V



Compact IP 54/NEMA 12
VLT 8042 - 8072 380 - 480 V
VLT 8016 - 8032 200 - 240 V

■ High voltage test

A high voltage test can be carried out by short-circuiting terminals U, V, W, L₁, L₂ and L₃ and energizing by max. 2.5 kV DC for one second between this short-circuit and the chassis.


NOTE

The RFI switch must be closed (position ON) when high voltage tests are carried out. The line and motor connection must be interrupted in the case of high voltage tests of the total installation if the leakage currents are too high.

■ Heat emission from VLT 8000 AQUA

The tables in *General technical data* show the power loss P_{ϕ} (W) from VLT 8000 AQUA. The maximum cooling air temperature $t_{IN, MAX}$ is 40° C (104° F) at 100% load (of rated value).

■ Ventilation of integrated VLT 8000 AQUA

The quantity of air required for cooling AFD can be calculated as follows:

1. Add up the values of P for all the AFDs to be integrated in the same panel.
The highest cooling air temperature (t_{IN}) present must be lower than $t_{IN, MAX}$ 40° C (104° F).
The day/night average must be 5° C (9° F) lower.
The outlet temperature of the cooling air must not exceed: $t_{OUT, MAX}$ 45° C (113° F).
2. Calculate the permissible difference between the temperature of the cooling air (t_{IN}) and its outlet temperature (t_{OUT}):
 $\Delta t = 45° C (113° F) - t_{IN}$.
3. Calculate the required

$$quantity\ of\ air = \frac{\sum P_{\phi} \times 3.1}{\Delta t} m^3/h$$

Insert Δt in Kelvin

The outlet from the ventilation must be placed above the highest-mounted AFD.
Allowance must be made for the pressure loss across the filters and for the fact that the pressure is going to drop as the filters are choked.

■ EMC-correct electrical installation

525-600 V units do not comply with European EMC and Low Voltage Directives.

The following is a guideline to good engineering practice, when installing drives. Following these guidelines is advised, where compliance with EN 50081, EN 55011 or EN 61800-3 *First environment* is required. If the installation is in EN 61800-3 *Second environment*, then it is acceptable to deviate from these guidelines. It is however not recommended. See also *CE labelling*, *Emission* and *EMC test results* in this manual.

Good engineering practice to ensure EMC-correct electrical installation:

- Use only braided shielded/armored motor cables and braided shielded/armored control cables. The shield should provide a minimum coverage of 80%. The shield material must be metal, not limited to but typically copper, aluminum, steel or lead. There are no special requirements for the line cable.
- Installations using rigid metal conduits are not required to use shielded cable, but the motor cable must be installed in conduit separate from the control and line cables. Full connection of the conduit from the drive to the motor is required. The EMC performance of flexible conduits varies a lot and information from the manufacturer must be obtained.
- Connect the shield/armor/conduit to ground at both ends for motor cables as well as for control cables. See also *Grounding of braided shielded/armored control cables*.
- Avoid terminating the shield/armor with twisted ends (pigtailed). Such a termination increases the high frequency impedance of the shield, which reduces its effectiveness at high frequencies. Use low impedance cable clamps or EMC cable glands instead.
- It is important to have good electrical contact between the mounting plate on which the AFD is installed and the metal chassis of the AFD unit.
Exception:
 - IP54/NEMA 12 units designed for wall mounting
 - VLT 8152-8600 (380-480 V) IP20/NEMA 1
 - VLT 8042-8062 (200-240 V) IP20/NEMA 1


This however does not apply to IP54/NEMA 12 units as they are designed for wall mounting and VLT 8152-8600, 380-480 VAC and VLT 8042-8062, 200-240 VAC in IP20/NEMA 1 enclosure.

- Use starwashers and galvanically conductive installation plates to secure good electrical connections for IP00/Chassis and IP20/NEMA 1 installations.
- Avoid using unshielded/unarmored motor or control cables inside cabinets housing the drive(s), whenever this can be avoided.
- An uninterrupted high frequency connection between the AFD and the motor is required for IP54/NEMA 12 units.


The next illustration shows an example of an EMC-correct electrical installation of an IP 20/NEMA 1 AFD; the AFD has been installed in a cabinet (enclosure) together with an output contactor and is connected to a PLC which, in this example, is installed in a separate cabinet. For IP 54/NEMA 12 units, VLT 8152-8600 (380-480 V) and VLT 8042-8062 (200-240 V) units in IP20/NEMA 1 enclosures; shielded cables are connected by using EMC conduits to assure proper EMC performance. (See next illustration.)

Other ways of making the installation may give as good an EMC performance, provided the above engineering practice guidelines are followed.

Please note, that when the installation is not made according to these guidelines as well as when unshielded cables and control wires are used, some emission requirements are not complied with, although the immunity requirements are fulfilled.




Installation



■ Earthing/Grounding of shielded/armored control cables

Generally speaking, control cables must be shielded/armored and the shield must be connected by means of a cable clamp at both ends to the metal cabinet of the unit.

The drawing below indicates how correct earthing/grounding is carried out.



Correct earthing/grounding

Control cables and cables for serial communication must be fitted with cable clamps at both ends to ensure the best possible electrical contact.

Wrong earthing/grounding

Do not use twisted cable ends (pigtailed), since these increase the shield impedance at high frequencies.

Protection with respect to ground potential between PLC and AFD

If the ground potential between the AFD and the PLC (etc.) is different, electric noise may occur that will disturb the whole system. This problem can be solved by fitting an equalizing cable, to be placed next to the control cable. Minimum cable cross-section: 8 AWG.

For 50/60 Hz ground loops


If very long control cables are used, 50/60 Hz ground loops may occur that will disturb the whole system. This problem can be solved by connecting one end of the shield to via a ground 100nF capacitor (keeping leads short).

Cables for serial communication


Low-frequency noise currents between two AFD can be eliminated by connecting one end of the shield to terminal 61. This terminal is connected to ground via an internal RC link. It is recommended to use twisted-pair cables to reduce the differential mode interference between the conductors.

Installation


■ Electrical installation, enclosures



Compact IP 54/NEMA 12
VLT 8006-8011, 380-480 V





Compact IP 20/NEMA 1
VLT 8006-8032, 200-240 V
VLT 8016-8072, 380-480 V
VLT 8016-8072, 525-600 V





Compact IP 20/NEMA 1
VLT 8006-8011, 380-480 V
VLT 8002-8011, 525-600 V

VLT 8100-8150, 525-600 V



Compact IP 00/Chassis
VLT 8042-8062, 200-240 V
VLT 8100-8150, 525-600 V


Compact IP 54/NEMA 12
VLT 8006-8032, 200-240 V
VLT 8016-8072, 380-480 V




Compact IP 54/NEMA 12
VLT 8042-8062, 200-240 V

Compact IP 20/NEMA 1
VLT 8042-8062, 200-240 V


Installation




Compact IP 20/NEMA 1
VLT 8102-8122, 380-480 V




IP 00/Chassis
VLT 8200-8300, 525-600 V




Compact IP 54/NEMA 12
VLT 8102-8122, 380-480 V




Compact IP 20/NEMA 1
VLT 8200-8300, 525-600 V




IP 54/NEMA 12, IP 21/NEMA 1
VLT 8152-8352, 380-480 V



IP 54/NEMA 12, IP 21/NEMA 1 with disconnect
and main fuse
VLT 8152-8352, 380-480 V




IP 00/Chassis
VLT 8152-8352, 380-480 V




IP 00/Chassis with disconnect and main fuse
VLT 8152-8352, 380-480 V

Installation




Compact IP 00/Chassis, IP 20/NEMA 1,
and IP 54/NEMA 12
VLT 8450-8600, 380-480 V


■ Electrical installation, power cables



IP 20/NEMA 1
VLT 8006-8032, 200-240 V
VLT 8016-8122, 380-480 V
VLT 8016-8072, 525-600 V




Compact IP 20/NEMA 1, and IP 54/NEMA 12
VLT 8006-8011, 380-480 V
VLT 8002-8011, 525-600 V




IP 54/NEMA 12
VLT 8006-8032, 200-240 V
VLT 8016-8072, 380-480 V

Installation


■ Electrical installation, power cables




IP 00/Chassis and IP 20/NEMA 1
VLT 8042-8062, 200-240 V
VLT 8100-8150, 525-600 V



IP 54/NEMA 12
VLT 8042-8062, 200-240 V




IP 00/Chassis and IP 20/NEMA 1
VLT 8200-8300, 525-600 V




Compact IP 54 /NEMA 12
VLT 8102-8122, 380-480 V

■ Electrical installation, power cables



Compact IP 00/Chassis, IP 20/NEMA 1, and IP 54/NEMA 12
VLT 8450-8600 380-480 V without disconnectors and line fuses



Compact IP 00/Chassis, IP 20/NEMA 1, and IP 54/NEMA 12
VLT 8450-8600 380-480 V with disconnectors and line fuses

Installation


■ Use of EMC-correct cables

Braided shielded/armored cables are recommended to optimise EMC immunity of the control cables and the EMC emission from the motor cables.

The ability of a cable to reduce the in- and outgoing radiation of electric noise depends on the transfer impedance (Z_T). The shield of a cable is normally designed to reduce the transfer of electric noise; however, a shield with a lower transfer impedance (Z_T) value is more effective than a shield with a higher transfer impedance (Z_T).

Transfer impedance (Z_T) can be assessed on the basis of the following factors:

- The conductivity of the shield material.
- The contact resistance between the individual shield conductors.
- The shield coverage, i.e. the physical area of the cable covered by the shield - often stated as a percentage value.
- Shield type, i.e. braided or twisted pattern.



Aluminium-clad with copper wire.

Twisted copper wire or armoured steel wire cable.

Single-layer braided copper wire with varying percentage shield coverage. This is the typical Danfoss reference cable.

Double-layer braided copper wire.

Twin layer of braided copper wire with a magnetic, shielded/armored intermediate layer.

Cable that runs in copper tube or steel tube.

Lead cable with 1.1 mm wall thickness.

Transfer impedance (Z_T) is rarely stated by cable manufacturers, but it is often possible to estimate transfer impedance (Z_T) by assessing the physical design of the cable.

■ Tightening torque and screw sizes

The table shows the torque required when fitting terminals to the AFD. For VLT 8006-8032, 200-240 V, VLT 8006-8122, 380-480 and 525-600 V the cables must be fastened with screws. For VLT 8042-8062, 200-240 V and for VLT 8152-8600, 380-480 V, the cables must be fastened with bolts.

These figures apply to the following terminals:

| | |
|------------------------|--------------------------|
| Line terminals (Nos.) | 91, 92, 93 L1, L2, L3 |
| Motor terminals (Nos.) | 96, 97, 98 U, V, W |
| Ground terminal (Nos.) | 94, 95, 99 |

| VLT type | Tightening-up torque | Screw/bolt size | Allen key size |
|----------------------|--|------------------|----------------|
| 3 x 200-240 V | | | |
| VLT 8006-8011 | 16 in-lbs/1.8 Nm (IP 20) | M4 | |
| VLT 8006-8016 | 16 in-lbs/1.8 Nm (IP 54) | M4 | |
| VLT 8016-8027 | 26.6 in-lbs/3.0 Nm (IP 20) | M5 ³⁾ | 4 mm/0.16 in |
| VLT 8022-8027 | 26.6 in-lbs/3.0 Nm (IP 54) ²⁾ | M5 ³⁾ | 4 mm/0.16 in |
| VLT 8032 | 53 in-lbs/6.0 Nm | M6 ³⁾ | 5 mm/0.20 in |
| VLT 8042-8062 | 100 in-lbs/11.3 Nm | M8 (bolt) | |

| VLT type | Tightening-up torque | Screw/bolt size | Allen key size |
|----------------------|--|------------------|----------------|
| 3 x 380-480 V | | | |
| VLT 8006-8011 | 5.3 in-lbs/0.5-0.6 Nm | M3 | |
| VLT 8016-8027 | 16 in-lbs/1.8 Nm (IP 20) | M4 | |
| VLT 8016-8032 | 16 in-lbs/1.8 Nm (IP 54) | M4 | |
| VLT 8032-8052 | 26.6 in-lbs/3.0 Nm (IP 20) | M5 ³⁾ | 4 mm/0.16 in |
| VLT 8042-8052 | 26.6 in-lbs/3.0 Nm (IP 54) ²⁾ | M5 ³⁾ | 4 mm/0.16 in |
| VLT 8062-8072 | 53 in-lbs/6.0 Nm | M6 ³⁾ | 5 mm/0.20 in |
| VLT 8102-8122 | 133 in-lbs/15 Nm (IP 20) | M8 ³⁾ | 6 mm/0.24 in |
| | 213 in-lbs/24 Nm (IP 54) ¹⁾ | ³⁾ | 8 mm/0.31 in |
| VLT 8152-8352 | 168 in-lbs/19 Nm ⁴⁾ | M10 (bolt) | |
| VLT 8450-8600 | 372 in-lbs/42 Nm | M12 (bolt) | |

| VLT type | Tightening-up torque | Screw/bolt size | Allen key size |
|----------------------|----------------------------------|------------------|----------------|
| 3 x 525-600 V | | | |
| VLT 8002-8011 | 5.3 in-lbs/0.5-0.6 Nm | M3 | |
| VLT 8016-8027 | 16 in-lbs/1.8 Nm | M4 | |
| VLT 8032-8042 | 26.6 in-lbs/3.0 Nm ²⁾ | M5 ³⁾ | 4 mm/0.16 in |
| VLT 8052-8072 | 53 in-lbs/6.0 Nm | M6 ³⁾ | 5 mm/0.20 in |
| VLT 8100-8150 | 100 in-lbs/11.3 Nm | M8 | |
| VLT 8200-8300 | 100 in-lbs/11.3 Nm | M8 | |

1. Loadsharing terminals 14 Nm/M6, 5 mm/0.20 in Allen key
2. IP 54 units with RFI filter line terminals 6 Nm
3. Allen screws (hexagon)
4. Loadsharing terminals 84 in-lbs/9.5 Nm/M8 (bolt)

Installation

Line connection

Line must be connected to terminals 91, 92, 93.


Nos. 91, 92, 93

Line voltage 3 x 200-240 V

L1, L2, L3

Line voltage 3 x 380-480 V

Line voltage 3 x 525-600 V



NOTE

Check that the line voltage corresponds to the line voltage of the AFD, which can be seen from the nameplate.

See *Technical data* for correct sizing of cable cross-sections.



NOTE

It is the responsibility of the user or installer to ensure that proper grounding, branch circuit, and motor overload protection is in accordance with national and local electrical and safety regulations and codes.

Motor connection

The motor must be connected to terminals 96, 97, 98. Ground to terminal 94/95/99.

Nos.

96, 97, 98

Motor voltage 0-100 % of mains voltage

U, V, W

No. 94/95/99

Ground connection

See *Technical data* for correct sizing of cable cross-sections.

All types of three-phase asynchronous standard motors can be used with a VLT 8000 AQUA unit.



Small-size motors are normally star-connected. (220/380 V, Δ/Y). Large-size motors are delta-connected (380/660 V, Δ/Y). The correct connection and voltage can be read from the motor nameplate.



NOTE

In older motors without phase coil insulation, a LC filter should be fitted to the AFD output.

Direction of IEC motor rotation



The factory setting is for clockwise rotation with the VLT frequency transformer output connected as follows.


Terminal 96 connected to U-phase

Terminal 97 connected to V-phase

Terminal 98 connected to W-phase

The direction of rotation can be changed by switching two phases in the motor cable.

Parallel coupling of motors




VLT 8000 AQUA is able to control several motors connected in parallel. If the motors are to have different rpm values, the motors must have different rated rpm values. Motor rpm is changed simultaneously, which means that the ratio between the rated rpm values is maintained across the range.

The total current consumption of the motors is not to exceed the maximum rated output current $I_{VLT,N}$ for the AFD.

If it is necessary to break the shield to install a motor isolator or motor contactor, the shield must be continued at the lowest possible HF impedance.

Problems may arise at the start and at low rpm values if the motor sizes are widely different. This is because the relatively high ohmic resistance in small motors calls for a higher voltage at the start and at low rpm values.


In systems with motors connected in parallel, the electronic thermal relay (ETR) of the AFD cannot be used as motor protection for the individual motor. Consequently, additional motor protection is required, such as thermistors in ground motor (or individual thermal relays).

 **NOTE**
 Parameter 107 *Automatic Motor Adaptation, AMA* and *Automatic Energy Optimization, AEO* in parameter 101 *Torque characteristics* cannot be used motors are connected in parallel.

■ Motor cables

See *Technical data* for correct sizing of motor cable cross-section and length.

Always comply with national and local regulations on cable cross-sections.

 **NOTE**
 If an unshielded cable is used, some EMC requirements are not complied with, see *EMC test results*.

If the EMC specifications regarding emission are to be complied with, the motor cable must be shielded, unless otherwise stated for the RFI filter in question. It is important to keep the motor cable as short as possible so as to reduce the noise level and leakage currents to a minimum.

The motor cable shield must be connected to the metal cabinet of the AFD and to the metal cabinet of the motor. The shield connections are to be made with the biggest possible surface (cable clamp).

This is enabled by different installation devices in the different AFDs. Mounting with twisted shield ends (pigtailed) is to be avoided, since these spoil the shielding effect at higher frequencies.

■ Motor thermal protection

The electronic thermal relay in UL-approved AFD has received UL-approval for single motor protection, as long as parameter 117 *Motor thermal protection* has been set to ETR Trip and parameter 105 *Motor current, I_{VLT,N}* has been programmed for the rated motor current (can be read from the motor nameplate).

■ Ground connection

Since the leakage currents to ground may be higher than 3.5 mA, the AFD must always be grounded in accordance with applicable national and local regulations. In order to ensure good mechanical connection of the ground cable, its cable cross-section must be at least 8 AWG/10 mm². For added security, an RCD (Residual Current Device) may be installed. This ensures that the AFD will cut out if the leakage currents get too high. See RCD Instructions MI.66.AX.02.

■ Installation of 24 Volt external DC supply

Torque: 0.5 - 0.6 Nm
Screw size: M3

| No. | Function |
|----------------|--|
| 35 (-), 36 (+) | 24 V external DC supply (available with VLT 8152-8600 380-480 V only) |

24 V external DC supply can be used as low-voltage supply to the control card and any option cards installed. This enables full operation of the LCP (incl. parameter setting) without connection to line. Please note that a warning of low voltage will be given when 24 V DC has been connected; however, there will be no tripping. If 24 V external DC supply is connected or switched on at the same time as the line supply, a time of min. 200 msec. must be set in parameter 111, *Start delay*. A pre-fuse of min. 6 Amp, slow-blow, can be fitted to protect the external 24 V DC supply. The power consumption is 15-50 W, depending on the load on the control card.


NOTE

Use 24 V DC supply of type PELV to ensure correct galvanic isolation (type PELV) on the control terminals of the AFD.

■ DC bus connection

The DC bus terminal is used for DC back-up, with the intermediate circuit being supplied from an external DC source.

Terminal nos. **Nos. 88, 89**

Contact Danfoss if you require further information.

■ High-voltage relay

The cable for the high-voltage relay must be connected to terminals 01, 02, 03. The high-voltage relay is programmed in parameter 323, *Relay 1, output*.


| | |
|-------|---|
| No. 1 | Relay output 1 1+3 break, 1+2 make. Max. 240 V AC, 2 Amp. Min. 24 V DC, 10 mA or 24 V AC, 100 mA. |
|-------|---|

Max. cross-section: 4 mm² /10 AWG.
Torque: 0.5 Nm/5 in-lbs
Screw size: M3


■ Control card

All terminals for the control cables are located under the protective cover of the AFD.

The protective cover (see drawing below) can be removed by means of a pointed object (except IP54/NEMA 12 units) - a screwdriver or similar.



■ Electrical installation, control cables



Torque: 0.5 Nm (5 in-lbs)
Screw size: M3.

Generally speaking, control cables must be shielded/armored and the shield must be connected by means of a cable clamp at both ends to the metal cabinet of the unit (see *Earthing/Grounding of shielded (armoured control cables)*).

Normally, the shield must also be connected to the body of the controlling unit (follow the instructions for installation given for the unit in question).

If very long control cables are used, 50/60 Hz ground loops may occur that will disturb the whole system. This problem can be solved by

connecting one end of the shield to ground via a 100nF capacitor (keeping leads short).

■ Electrical installation, control cables

Torque: 0.5 Nm/5 in-lbs

Screw size: M3

See *Earthing/Grounding of shielded (armoured control cables)* for correct termination of control cables.

| | | | | | | | | | | | |
|------|------|------|------|-------------|------|------|------|------|--------------|------------|------------|
| 16 | 17 | 18 | 19 | 20 | 27 | 29 | 32 | 33 | 61 | 68 | 69 |
| □ | □ | □ | □ | □ | □ | □ | □ | □ | □ | □ | □ |
| D IN | D IN | D IN | D IN | COM D IN | D IN | D IN | D IN | D IN | COM RS485 | P RS485 | N RS485 |

| | | | | | | | | | | | |
|-------|----|-------------|----|--------------|-------|-------|-------------|------|------|-------------|------|
| 04 | 05 | 12 | 13 | 39 | 42 | 45 | 50 | 53 | 54 | 55 | 60 |
| □ | □ | □ | □ | □ | □ | □ | □ | □ | □ | □ | □ |
| RELAY | | +24V OUT | | COM A OUT | A OUT | A OUT | +10V OUT | A IN | A IN | COM A IN | A IN |

175HA379.10

| No. | Function |
|--------|--|
| 04, 05 | Relay output 2 can be used for indicating status and warnings. |
| 12, 13 | Voltage supply to digital inputs. For the 24 V DC to be used for digital inputs, switch 4 on the control card must be closed, position "on". |
| 16-33 | Digital inputs. See parameters 300-307 <i>Digital inputs</i> . |
| 20 | Common for digital inputs. |
| 39 | Common for analog/digital outputs. See <i>Examples of connection</i> . |
| 42, 45 | Analog/digital outputs for indicating frequency, reference, current and torque. See parameters 319-322 <i>Analoge/digital outputs</i> . |
| 50 | Supply voltage to potentiometer and thermistor 10 V DC. |
| 53, 54 | Analog voltage input, 0 - 10 V DC. |
| 55 | Common for analog inputs. |
| 60 | Analog current input 0/4-20 mA. See parameters 314-316 <i>Terminal 60</i> . |

Installation

61 Termination of serial communication. See *Earthing/Grounding of shielded (armoured control cables)*. This terminal is not normally to be used.


68, 69 RS 485 interface, serial communication. When multiple AFD's are connected to a communication bus, switches 2 and 3 on control card in the first and last units must be closed (position ON). For the remaining AFD's, switches 2 and 3 must be open (OFF). The factory setting is closed (position ON).


■ **Switches 1-4**

The dipswitch is located on the control card. It is used for serial communication and external DC supply. The switching position shown is the factory setting.



Switch 1 has no function.
 Switches 2 and 3 are used for terminating an RS 485 interface, serial communication. In the first and the last AFD, switches 2 and 3 must be ON. In the other AFD, switches 2 and 3 must be OFF.
 Switch 4 is used if an external 24 V DC supply is required for the control terminals. Switch 4 separates the common potential for the internal 24 V DC supply from the common potential of the external 24 V DC supply.

 **NOTE** Please note that when Switch 4 is in position "OFF", the external 24 V DC supply is galvanically isolated from the AFD.



Installation

Bus connection


The serial bus connection in accordance with the RS 485 (2-conductor) norm is connected to terminals 68/69 of the AFD (signals P and N). Signal P is the positive potential (TX+,RX+), while signal N is the negative potential (TX-,RX-).

If more than one AFD is to be connected to a given master, use parallel connections.

In order to avoid potential equalizing currents in the shield, the cable shield can be grounded via terminal 61, which is connected to the frame via an RC-link.

Bus termination

The bus must be terminated by a resistor network at both ends. For this purpose, set switches 2 and 3 on the control card for "ON".



■ Connection example VLT 8000 AQUA

The diagram below gives an example of a typical VLT 8000 AQUA installation.

The line supply is connected to terminals 91 (L1), 92 (L2) and 93 (L3), while the motor is connected to 96 (U), 97 (V) and 98 (W). These numbers can also be seen from the terminals of the AFD.


An external DC supply can be connected to terminals 88 and 89.

Analog inputs can be connected to terminals 53 [V], 54 [V] and 60 [mA]. These inputs can be programmed for either reference, feedback or thermistor. See *Analog inputs* in parameter group 300.

There are 8 digital inputs, which are controlled with 24 V DC. Terminals 16-19, 27, 29, 32, 33. These inputs can be programmed in accordance with the table in *Inputs and outputs 300-328*.

There are two analog/digital outputs (terminals 42 and 45), which can be programmed to show the present status or a process value, such as 0- f_{MAX} . Relay outputs 1 and 2 can be used for giving the present status or a warning.


On terminals 68 (P+) and 69 (N-) RS 485 interface, the AFD can be controlled and monitored via serial communication.



* These terminals can be programmed for other functions.


■ Connection examples

■ Single-pole start/stop




- Start/stop using terminal 18.
Parameter 302 = *Start* [1]
- Quick-stop using terminal 27.
Parameter 304 = *Coasting stop, inverse* [0]

■ Digital speed up/down




- Speed up and down using terminals 32 and 33.
Parameter 306 = *Speed up* [7]
Parameter 307 = *Speed down* [7]
Parameter 305 = *Freeze reference* [2]

■ Potentiometer reference




- Parameter 308 = *Reference* [1]
Parameter 309 = *Terminal 53, min. scaling*
Parameter 310 = *Terminal 53, max. scaling*

■ Run permissive




- Start permitted with terminal 16.
Parameter 300 = *Run permissive* [8].
- Start/stop with terminal 18.
Parameter 302 = *Start* [1].
- Quickstop with terminal 27.
Parameter 304 = *Coasting stop, inverse* [0].
- Activated peripheral equip
Parameter 323 = *Start command active* [13].

■ 2-zone regulation




- Parameter 308 = *Feedback* [2].
- Parameter 311 = *Feedback* [2].

■ Transmitter connection



- Parameter 314 = *Reference* [1]
- Parameter 315 = *Terminal 60, min. scaling*
- Parameter 316 = *Terminal 60, max. scaling*

■ 3-wire start/stop



- Stop inverse by means of terminal 32.
Parameter 306 = *Stop inverse*[14]
- Latched start using terminal 18.
Parameter 302 = *Latched start* [2]
- Jog by means of terminal 29.
Parameter 305 = *Jog* [12]

■ Control unit LCP


The front of the AFD features a control panel - LCP (Local Control Panel). This is a complete interface for operation and programming of the VLT 8000 AQUA. The control panel is detachable and can - as an alternative - be installed up to 3m/10 ft away from the AFD, e.g. on the front panel, by means of a mounting kit option.

The functions of the control panel can be divided into five groups:

1. Display
2. Keys for changing display mode
3. Keys for changing program parameters
4. Indicator lamps
5. Keys for local operation.

All data are indicated by means of a 4-line alpha-numeric display, which, in normal operation, is able to show 4 operating data values and 3 operating condition values continuously. During programming, all the information required for quick, effective parameter Setup of the AFD will be displayed. As a supplement to the display, there are three indicator lamps for voltage (ON), warning (WARNING) and alarm (ALARM),


respectively. All AFD parameter Setups can be changed immediately via the control panel, unless this function has been programmed to beLocked [1] via parameter 016 *Lock for data change* or via a digital input, parameters 300-307 *Lock for data change*.



Installation

■ Control keys for parameter setup

The control keys are divided into functions. This means that the keys between display and indicator lamps are used for parameter Setup, including selecting the display indication during normal operation.



DISPLAY MODE

[DISPLAY MODE] is used for selecting the indication mode of the display or when returning to the Display mode from either the Quick menu or the Extend menu mode.



[QUICK MENU] gives access to the parameters used for the Quick menu. It is possible to switch between the Quick menu and the Extend menu modes.



[EXTEND MENU] gives access to all parameters. It is possible to switch between the Extend menu and the Quick menu modes.



[CHANGE DATA] is used for changing a setting selected either in the Extend menu or the Quick menu mode.




[CANCEL] is used if a change of the selected parameter is not to be carried out.



[OK] is used for confirming a change of the parameter selected.




[+/-] is used for selecting parameters and for changing a chosen parameter. These keys are also used to change the local reference. In addition, the keys are used in Display mode to switch between operation variable readouts.



[<>] is used when selecting a parameter group and for moving the cursor when changing numerical values.

■ Indicator lamps

At the bottom of the control panel is a red alarm lamp and a yellow warning lamp, as well as a green voltage LED.



If certain threshold values are exceeded, the alarm and/ or warning lamp is activated, and a status or alarm text is displayed.




NOTE

The voltage indicator lamp is activated when the AFD receives voltage.

■ Local control

Underneath the indicator lamps are keys for local control.



[HAND START] is used if the AFD is to be controlled via the control unit. The AFD will start the motor, since a start command is given by means of [HAND START].

On the control terminals, the following control signals will still be active when [HAND START] is activated:

- Hand start - Off stop - Auto start
- Safety Interlock
- Reset
- Coasting stop inverse
- Reversing
- Setup select lsb - Setup select msb
- Jog
- Run permissive
- Lock for data change
- Stop command from serial communication



NOTE

If parameter 201 *Output frequency low limit* f_{MIN} is set to an output frequency greater than 0 Hz, the motor will start and ramp up to this frequency when [HAND START] is activated.



[OFF/STOP] is used for stopping the connected motor. Can be selected as Enable [1] or Disable [0] via parameter 013. If the stop function is activated, line 2 will flash.



[AUTO START] is used if the AFD is to be controlled via the control terminals and/or serial communication. When a start signal is active on the control terminals and/or the bus, the AFD will start.




NOTE

An active HAND-OFF-AUTO signal via the digital inputs will have higher priority than the control keys [HAND START]-[AUTO START].



[RESET] is used for resetting the AFD after an alarm (trip). Can be selected as *Enable* [1] or *Disable* [0] via parameter 015 *Reset on LCP*. See also *List of warnings and alarms*.



■ Display mode

In normal operation, any 4 different operating variables can be indicated continuously: 1.1 and 1.2 and 1.3 and 2. The present operating status or alarms and warnings that have arisen are shown in line 2 in the form of a number. In the case of alarms, the alarm in question will be shown in lines 3 and 4, accompanied by an explanatory note. Warnings will flash in line 2, with an explanatory note in line 1. In addition, the display shows the active Setup. The arrow indicates the direction of rotation; here the AFD has an active reversing signal. The arrow body disappears if a stop command is given or if the output frequency falls below 0.01 Hz. The bottom line gives the status of the AFD. The scroll list on the next page gives the operating data that can be shown for variable 2 in display mode. Changes are made via the [+/-] keys.

1st line
2nd line
3rd line
4th line



195NA113:10

■ Display mode, cont.

Three operating data values can be shown in the first display line, while one operating variable can be shown in the second display line. To be programmed via parameters 007, 008, 009 and 010 *Display read-out*.

- Status line (4th line):


The left part of the status line indicates the control element of the AFD that is active. AUTO means that control is via the control terminals, while HAND indicates that control is via the local keys on the control unit. OFF means that the AFD ignores all control commands and stops the motor.

The centre part of the status line indicates the reference element that is active. REMOTE means that the reference from the control terminals is active, while LOCAL indicates that the reference is determined via the [+/-] keys on the control panel.

The last part of the status line indicates the current status, for example "Running", "Stop" or "Alarm".

■ Display mode I

VLT 8000 AQUA offers different display modes depending on the mode selected for the AFD. Below is a display mode, in which the AFD is in Auto mode with remote reference at an output frequency of 40 Hz. In this display mode, reference and control are determined via the control terminals. The text in line 1 gives the operating variable shown in line 2.



175ZA683:10


Line 2 gives the current output frequency and the active Setup.

Line 4 says that the AFD is in Auto mode with remote reference, and that the motor is running.

Installation


■ **Display mode II:**

This display mode makes it possible to have three operating data values displayed at the same time in line 1. The operating data values are determined in parameters 007-010 *Display readout*.




■ **Display mode III:**

This display mode is active as long as the [DISPLAY MODE] key is kept depressed. In the first line, operating data names and units of operating data are displayed. In the second line, operating data 2 remains unchanged. When the key is released, the different operating data values are shown.




■ **Display mode IV:**

This display mode is only active in connection with local reference, see also *Reference handling*. In this display mode, the reference is determined via the [+/-] keys and control is carried out by means of the keys underneath the indicator lamps. The first line indicates the required reference. The third line gives the relative value of the present output frequency at any given time in relation to the maximum frequency. The display is in the form of a bar graph.



■ Navigation between display modes



Installation


175ZA697.10

■ Changing data

Regardless of whether a parameter has been selected under the Quick menu or the Extended menu, the procedure for changing data is the same. Pressing the [CHANGE DATA] key allows change of the selected parameter, and the underlining in line 4 will flash on the display.


The procedure for changing data depends on whether the selected parameter represents a numerical data value or a functional value.

If the chosen parameter represents a numeric data value, the first digit can be changed by means of the [+/-] keys. If the second digit is to be changed, first move the cursor by using the [<>] keys, then change the data value using the [+/-] keys.



The selected digit is indicated by a flashing cursor. The bottom display line gives the data value that will be entered (saved) when signing off by pressing the [OK] button. Use [CANCEL] to cancel the change.


If the selected parameter is a functional value, the selected text value can be changed by means of the [+/-] keys.




The functional value flashes until signing off by pressing the [OK] button. The functional value has now been selected. Use [CANCEL] to cancel the change.

■ **Infinitely variable change of numeric data value**

If the chosen parameter represents a numeric data value, a digit is first selected by means of the [\leftarrow] keys.



Then the chosen digit is changed infinitely by means of the [+/-] keys:



The chosen digit flashes. The bottom display line shows the data value that will be entered (saved) when signing off with [OK].

■ **Changing of data value, step-by-step**

Certain parameters can be changed both step by step and infinitely variably. This applies to *Motor power* (parameter 102), *Motor voltage* (parameter 103) and *Motor frequency* (parameter 104). This means that the parameters are changed both as a group of numeric data values and as numeric data values infinitely variably.

■ **Manual initialization**

Disconnect from line and hold the [DISPLAY MODE] + [CHANGE DATA] + [OK] keys down while at the same time reconnecting the line supply. Release the keys; the AFD has now been programmed for the factory setting.

The following parameters are not zeroed by means of manual initialization:

- Parameter 500, *Protocol*
- 600, *Operating hours*
- 601, *hours run*
- 602, *kWh counter*
- 603, *Number of power-ups*
- 604, *Number of overtemperatures*
- 605, *Number of overvoltages*

It is also possible to carry out initialization via parameter 620 *Operating mode*.

■ Quick Menu

The QUICK MENU key gives access to 12 of the most important setup parameters of the drive. After programming, the drive will, in many cases, be ready for operation. The 12 Quick Menu parameters are

shown in the table below. A complete description of the function is given in the parameter sections of this manual.

| Quick Menu Item Number | Parameter Name | Description |
|------------------------|-------------------------|--|
| 1 | 001 Language | Selects language used for all displays. |
| 2 | 102 Motor Power | Sets output characteristics of drive based on kW size of motor. |
| 3 | 103 Motor Voltage | Sets output characteristics of drive based on voltage of motor. |
| 4 | 104 Motor Frequency | Sets output characteristics of drive based on nominal frequency of motor. This is typically equal to line frequency. |
| 5 | 105 Motor Current | Sets output characteristics of drive based on nominal current in amps of motor. |
| 6 | 106 Motor Nominal Speed | Sets output characteristics of drive based on nominal full load speed of motor. |
| 7 | 201 Minimum Frequency | Sets minimum controlled frequency at which motor will run. |
| 8 | 202 Maximum Frequency | Sets maximum controlled frequency at which motor will run. |
| 9 | 206 Ramp Up Time | Sets time to accelerate motor from 0 Hz to nominal motor frequency set in Quick Menu Item 4. |
| 10 | 207 Ramp Down Time | Sets time to decelerate motor from nominal motor frequency set in Quick Menu Item 4 to 0 Hz. |
| 11 | 323 Relay 1 Function | Sets function of high voltage Form C relay. |
| 12 | 326 Relay 2 Function | Sets function of low voltage Form A relay. |

■ Parameter Data


Enter or change parameter data or settings in accordance with the following procedure.

1. Press Quick Menu key.
2. Use '+' and '-' keys to find parameter you choose to edit.
3. Press Change Data key.
4. Use '+' and '-' keys to select correct parameter setting. To move to a different digit within parameter, use < and > arrows. *Flashing cursor indicates digit selected to change.*
5. Press Cancel key to disregard change, or press OK key to accept change and enter new setting.

Assume parameter 206, *Ramp Up Time*, is set at 60 seconds. Change the ramp up time to 100 seconds in accordance with the following procedure.

1. Press Quick Menu key.
2. Press '+' key until you reach Parameter 206, *Ramp Up Time*.
3. Press Change Data key.
4. Press < key twice – hundreds digit will flash.
5. Press '+' key once to change hundreds digit to '1.'
6. Press > key to change to tens digit.
7. Press '-' key until '6' counts down to '0' and setting for *Ramp Up Time* reads '100 s.'
8. Press OK key to enter new value into drive controller.

Example of Changing Parameter Data



NOTE

Programming of extended parameters functions available through EXTENDED MENU key is done in accordance with same procedure as described for Quick Menu functions.

■ Programming


Using the [EXTEND MENU] key, it is possible to have access to all the parameters for the AFD.

Parameter 003 *Copying of Setups* enables copying from one Setup to another.

By means of parameter 004 *LCP copy*, all Setups can be transferred from one AFD to another by moving the control panel. First all parameter values are copied to the control panel. This can then be moved to another AFD, where all parameter values can be copied from the control unit to the AFD.

■ Operation and Display 001-017

This parameter group allows to set up parameters such as language, display readout and the possibility of making the function keys on the control unit inactive.

| 001 Language | |
|-------------------------|-----|
| (LANGUAGE) | |
| Value: | |
| ★English (ENGLISH) | [0] |
| German (DEUTSCH) | [1] |
| French (FRANCAIS) | [2] |
| Danish (DANSK) | [3] |
| Spanish (ESPAÑOL) | [4] |
| Italian (ITALIANO) | [5] |
| Swedish (SVENSKA) | [6] |
| Dutch (NEDERLANDS) | [7] |
| Portuguese (PORTUGUESA) | [8] |
| Finnish (SUOMI) | [9] |

State when delivered may vary from factory setting.

Function:

The choice in this parameter defines the language to be used on the display.

Description of choice:

There is a choice of the languages indicated.

002 Active Setup
(ACTIVE SETUP)
Value:

| | |
|-------------------------------|-----|
| Factory Setup (FACTORY SETUP) | [0] |
| ★Setup 1 (SETUP 1) | [1] |
| Setup 2 (SETUP 2) | [2] |
| Setup 3 (SETUP 3) | [3] |
| Setup 4 (SETUP 4) | [4] |
| MultiSetup (MULTI SETUP) | [5] |

Function:

The choice in this parameter defines the Setup number you want to control the functions of the AFD. All parameters can be programmed in four individual parameter Setups, Setup 1 - Setup 4.

In addition, a pre-programmed Setup called the Factory Setup exists. This only allows specific parameters to be changed.

Description of choice:

Factory Setup [0] contains the parameter values pre-set at the factory. Can be used as a data source if the other Setups are to be returned to a common state. In this case Factory Setup is selected as the active Setup. *Setups 1-4* [1]-[4] are four individual Setups that can be selected as required.

MultiSetup [5] is used if remote switching between different Setups is required. Terminals 16/17/29/32/33 and the serial communication port can be used for switching between Setups.


■ The Setup configuration

The drive has four Setups (parameter Setups) that can be programmed independently of each other. The active Setup can be selected in parameter 002 *Active Setup*. The active Setup number will be shown in the display under "Setup". It is also possible to set the AFD to Multi-Setup to allow switching of Setups with the digital inputs or serial communication.

Setup shifts can be used in systems where, one Setup is used during the day and another at night.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

Connection examples
Setup change



- Selection of Setup using terminals 32 and 33.
Parameter 306 = *Selection of Setup*, lsb [4]
Parameter 307 = *Selection of Setup*, msb [4]
Parameter 002 = *MultiSetup* [5].

003 Copying of Setups
(SETUP COPY)

Value:

| | |
|--|-----|
| ★No copying (NO COPY) | [0] |
| Copy active Setup to Setup 1 (COPY TO SETUP 1) | [1] |
| Copy active Setup to Setup 2 (COPY TO SETUP 2) | [2] |
| Copy active Setup to Setup 3 (COPY TO SETUP 3) | [3] |
| Copy active Setup to Setup 4 (COPY TO SETUP 4) | [4] |
| Copy active Setup to all (COPY TO ALL) | [5] |

Function:
A copy is made from the active Setup selected in parameter 002 *Active Setup* to the Setup or Setups selected in parameter 003 *Copying of Setups*.

NOTE
Copying is only possible in Stop mode (motor stopped on a Stop command).

Description of choice:
The copying starts when the required copying function has been selected and the [OK] key has been pressed. The display indicates when copying is in progress.

004 LCP copy

(LCP COPY)

Value:

| | |
|--|-----|
| ★No copying (NO COPY) | [0] |
| Upload all parameters (UPLOAD ALL PARAMET.) | [1] |
| Download all parameters (DOWNLOAD ALL PARAM.) | [2] |
| Download power-independent par. (DOWNLOAD SIZE INDEP.) | [3] |

Function:
Parameter 004 *LCP copy* is used if the integrated copying function of the control panel is to be used. This function is used if all parameter Setups are to be copied from one AFD to another by moving the control panel.

Description of choice:
Select *Upload all parameters* [1] if all parameter values are to be transmitted to the control panel. Select *Download all parameters* [2] if all transmitted parameter values are to be copied to the AFD on which the control panel has been mounted. Select *Download power-independent par.* [3] if only the power-independent parameters are to be downloaded. This is used if downloading to a AFD that has a different rated power than the one from where the parameter Setup originates.

NOTE
Uploading/Downloading can only be carried out in the Stop mode.

Setup of user-defined readout

Parameter 005 *Max. value of user-defined readout* and 006 *Unit for user-defined readout* allow users to design their own readout which can be seen if user-defined readout has been selected under display readout. The range is set in parameter 005 *Max. value of user-defined readout* and the unit is determined in parameter 006 *Unit for user-defined readout*. The choice of unit decides whether the ratio between the output frequency and the readout is a linear, square or cubed ratio.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

**005 Max. value of user-defined readout
(CUSTOM READOUT)**

Value:

0.01 - 999,999.99 ★ 100.00


Function:

This parameter allows a choice of the max. value of the user-defined readout. The value is calculated on the basis of the present motor frequency and the unit selected in parameter 006 *Unit for user-defined readout*. The programmed value is reached when the output frequency in parameter 202 *Output frequency high limit*, f_{MAX} is reached. The unit also decides whether the ratio between output frequency and readout is linear, square or cubed.

Description of choice:

Set the required value for max. output frequency.

Function:



**006 Unit for user-defined readout
(CUST. READ. UNIT)**

| | | | |
|----------------------------------|------|-----------------------------------|------|
| ★No unit ¹ | [0] | GPM ¹ | [21] |
| % ¹ | [1] | gal/s ¹ | [22] |
| rpm ¹ | [2] | gal/min ¹ | [23] |
| ppm ¹ | [3] | gal/h ¹ | [24] |
| pulse/s ¹ | [4] | lb/s ¹ | [25] |
| l/s ¹ | [5] | lb/min ¹ | [26] |
| l/min ¹ | [6] | lb/h ¹ | [27] |
| l/h ¹ | [7] | CFM ¹ | [28] |
| kg/s ¹ | [8] | ft ³ /s ¹ | [29] |
| kg/min ¹ | [9] | ft ³ /min ¹ | [30] |
| kg/h ¹ | [10] | ft ³ /h ¹ | [31] |
| m ³ /s ¹ | [11] | ft ³ /min ¹ | [32] |
| m ³ /min ¹ | [12] | ft/s ¹ | [33] |
| m ³ /h ¹ | [13] | in wg ² | [34] |
| m/s ¹ | [14] | ft wg ² | [35] |
| mbar ² | [15] | PSI ² | [36] |
| bar ² | [16] | lb/in ² | [37] |
| Pa ² | [17] | HP ³ | [38] |
| kPa ² | [18] | | |
| MWG ² | [19] | | |
| kW ³ | [20] | | |

Flow and speed units are marked with 1. Pressure units with 2, and power units with 3. See figure in next column.

Select a unit to be shown in the display in connection with parameter 005 *Max. value of user-defined readout*. If units such as flow or speed units are selected, the ratio between readout and output frequency will be a linear one. If pressure units are selected (bar, Pa, MWG, PSI, etc.), the ratio will be square. If power units (HP, HP) are selected, the ratio will be cubed. The value and the unit are shown in display mode whenever *User-defined readout* [10] has been selected in one of parameters 007-010 *Display readout*.

Description of choice:

Select the required unit for *User-defined readout*.

007 Large display readout

(LARGE READOUT)

Value:

| | |
|---|-----|
| Resulting reference [%] (REFERENCE [%]) | [1] |
| Resulting reference [unit] (REFERENCE [UNIT]) | [2] |
| ★Frequency [Hz] (FREQUENCY [HZ]) | [3] |
| % of maximum output frequency [%] (FREQUENCY [%]) | [4] |
| Motor current [A] (MOTOR CURRENT [A]) | [5] |
| Power [kW] (POWER [KW]) | [6] |
| Power [HP] (POWER [HP]) | [7] |
| Output energy [kWh] (ENERGI [UNIT]) | [8] |
| Hours run [Hours] (OURS RUN [H]) | [9] |
| User-defined readout [-] (CUSTOM READ.[UNITS]) | |

★ = factory setting. () = display text [] = value for use in communication via serial communication port

| | |
|--|------|
| | [10] |
| Setpoint 1 [unit] (SETPOINT 1 [UNITS]) | [11] |
| Setpoint 2 [unit] (SETPOINT 2 [UNITS]) | [12] |
| Feedback 1 (FEEDBACK 1 [UNITS]) | [13] |
| Feedback 2 (FEEDBACK 2 [UNITS]) | [14] |
| Feedback [unit] (FEEDBACK [UNITS]) | [15] |
| Motor voltage [V] (MOTOR VOLTAGE [V]) | [16] |
| DC link voltage [V] (DC VOLTAGE [V]) | [17] |
| Thermal load, motor [%] (THERM.MOTOR LOAD [%]) | [18] |
| Thermal load, VLT [%] (THERM.DRIVE LOAD [%]) | [19] |
| Digital input [Binary code] (DIGITAL INPUT [BIN]) | [20] |
| Analogue input 53 [V] (ANALOG INPUT 53 [V]) | [21] |
| Analogue input 54 [V] (ANALOG INPUT 54 [V]) | [22] |
| Analogue input 60 [mA] (ANALOG INPUT 60 [MA]) | [23] |
| Relay status [binary code] (RELAY STATUS) | [24] |
| Pulse reference [Hz] (PULSE REFERENCE [HZ]) | [25] |
| External reference [%] (EXT. REFERENCE [%]) | [26] |
| Heat sink temp. [°C] (HEATSINK TEMP [°C]) | [27] |
| Communication option card warning (COMM OPT WARN [HEX]) | [28] |
| LCP display text (FREE PROG.ARRAY) | [29] |
| Status word (STATUS WORD [HEX]) | [30] |
| Control word (CONTROL WORD [HEX]) | [31] |
| Alarm word (ALARM WORD [HEX]) | [32] |
| PID output [Hz] (PID OUTPUT [HZ]) | [33] |
| PID output [%] (PID OUTPUT [%]) | [34] |

Function:

This parameter allows a choice of the data value to be shown in the display, line 2, when the AFD is turned on. The data values will also be included in the display mode scroll-list. Parameters 008-010 *Small display readout* allow a choice of another three data values, shown in line 1. See the description of the *control unit*.

Description of choice:

No readout can only be selected in parameters 008-010 *Small display readout*.

Resulting reference [%] gives a percentage for the resulting reference in the range from *Minimum reference*, Ref_{MIN} to *Maximum reference*, Ref_{MAX}. See also *reference handling*.

Reference [unit] gives the resulting reference in Hz in *Open loop*. In *Closed loop*, the reference unit is selected in parameter 415 *Process units*.

Frequency [Hz] gives the output frequency from the AFD.

% of maximum output frequency [%] is the present output frequency as a percentage value of parameter 202 *Output frequency high limit*, f_{MAX}.

Motor current [A] states the phase current of the motor measured as effective value.

Power [kW] states the actual power consumed by the motor in kW.

Power [HP] states the actual power consumed by the motor in HP.

Output energy [kWh] states the energy consumed by the motor since the latest reset was made in parameter 618 *Reset of kWh* counter.

Hours run [Hours] states the number of hours that the motor has run since the latest reset in parameter 619 *Reset of hours-run* counter.

User -defined readout [-] is a user-defined value, calculated on the basis of the present output frequency and unit, as well as the scaling in parameter 005 *Max. value of user-defined readout*. Select unit in parameter 006 *Unit for user-defined readout*.

Setpoint 1 [unit] is the programmed setpoint value in parameter 418 *Setpoint 1*. The unit is decided in parameter 415 *Process units*. See also *Feedback handling*.

Setpoint 2 [unit] is the programmed setpoint value in parameter 419 *Setpoint 2*. The unit is decided in parameter 415 *Process units*.

Feedback 1 [unit] gives the signal value of the resulting feedback 1 (Term. 53). The unit is decided in parameter 415 *Process units*. See also *Feedback handling*.

Feedback 2 [unit] gives the signal value of the resulting feedback 2 (Term. 53). The unit is decided in parameter 415 *Process units*.

Feedback [unit] gives the resulting signal value using the unit/scaling selected in parameter 413 *Minimum feedback*, FB_{MIN}, 414 *Maximum feedback*, FB_{MAX} and 415 *Process units*.

Motor voltage [V] states the voltage supplied to the motor.

DC link voltage [V] states the intermediate circuit voltage in the AFD.

Thermal load, motor [%] states the calculated/estimated thermal load on the motor. 100% is the cut-out limit. See also parameter 117 *Motor thermal protection*.

Thermal load, VLT [%] states the calculated/estimated thermal load on the AFD. 100% is the cut-out limit.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

Digital input [Binary code] states the signal status from the 8 digital inputs (16, 17, 18, 19, 27, 29, 32 and 33). Terminal 16 corresponds to the bit at the far left. '0' = no signal, '1' = connected signal.

Analogue input 53 [V] states the voltage value on terminal 53.

Analogue input 54 [V] states the voltage value on terminal 54.

Analogue input 60 [mA] states the voltage value on terminal 60.

Relay status [binary code] indicates the status of each relay. The left (most significant) bit indicates relay 1 followed by 2 and 6 through 9. A "1" indicates the relay is active, a "0" indicates inactive. Parameter 007 uses an 8-bit word with the last two positions not used. Relays 6-9 are provided with the cascade controller and four relay option cards

Pulse reference [Hz] states a pulse frequency in Hz connected to terminal 17 or terminal 29.

External reference [%] gives the sum of the external references as a percentage (the sum of analogue/pulse/serial communication) in the range from *Minimum reference*, Ref_{MIN} to *Maximum reference*, Ref_{MAX}.

Heat sink temp. [°C] states the present heat sink temperature of the AFD. The cut-out limit is 90 ± 5°C; cutting back in occurs at 60 ± 5°C.

Communication option card warning [Hex] gives a warning word if there is a fault on the communication bus. This is only active if communication options have been installed. Without communication options, 0 Hex is displayed.

LCP display text shows the text programmed in parameter 533 *Display text 1* and 534 *Display text 2* via LCP or the serial communication port.

LCP procedure for entering text

After selecting *Display Text* in parameter 007, select display line parameter (533 or 534) and press the **CHANGE DATA** key. Enter text directly into the selected line by using **UP, DN & LEFT, RIGHT** arrow keys on the LCP. The UP and DN arrow keys scroll through the available characters. The Left and Right arrow keys move the cursor through the line of text. To lock in the text, press the **OK** key when the line of text is completed. The **CANCEL** key will cancel the text. The available characters are:
 A B C D E F G H I J K L M N O P Q R S T U V W X Y Z
 Æ Ø Å Ä Ö Ü É Ì Ù è . / - () 0 1 2 3 4 5 6 7 8 9 'space'
 'space' is the default value of parameter 533 & 534. To erase a character that has been entered, it must be replaced with 'space'.

Status word displays the actual drive status word (see parameter 608).

Control word displays the actual control word (see parameter 607).

Alarm word displays the actual alarm word.

PID output shows the calculated PID output in the display in either Hz [33] or percentage of max frequency [34].

008 Small display readout 1.1

(SMALL READOUT 1)

Value:

See parameter 007 *Large display readout*

★ Reference [Unit] [2]

Function:

This parameter enables a choice of the first of three data values to be shown on the display, line 1, position 1.

This is a useful function, i.a. when setting the PID regulator, in order to see how the process reacts to a change of reference.

For display read-outs, press the [DISPLAY MODE] button. Data option *LCP display text* [29] cannot be selected with *Small display readout*.

Description of choice:

There is a choice of 33 different data values, see parameter 007 *Large display readout*.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

009 Small display readout 1.2

(SMALL READOUT 2)

Value:

See parameter 007 *Large display readout*
 ★Motorcurrent [A] [5]

Function:

See the functional description for parameter 008 *Small display readout*. Data option *LCP display text* [29] cannot be selected with *Small display readout*.

Description of choice:

There is a choice of 33 different data values, see parameter 007 *Large display readout*.

010 Small display readout 1.3

(SMALL READOUT 3)

Value:

See parameter 007 *Large display readout*
 ★Power [kW] [6]

Function:

See the functional description for parameter 008 *Small data readout*. Data option *LCP display text* [29] cannot be selected with *Small display readout*.

Description of choice:

There is a choice of 33 different data values, see parameter 007 *Large display readout*.

011 Unit of local reference

(UNIT OF LOC REF)

Value:

Hz (HZ) [0]
 ★% of output frequency range (%) (% OF FMAX) [1]

Function:

This parameter decides the local reference unit.

Description of choice:

Choose the required unit for local reference.

012 Hand start on LCP

(HAND START BTTN)

Value:

Disable (DISABLE) [0]
 ★Enable (ENABLE) [1]

Function:

This parameter allows selection/deselection of the Hand start key on the control panel.

Description of choice:

If *Disable* [0] is selected in this parameter, the [HAND START] key will be inactive.

013 OFF/STOP on LCP

(STOP BUTTON)

Value:

Disable (DISABLE) [0]
 ★Enable (ENABLE) [1]

Function:

This parameter allows selection/deselection of the local stop key on the control panel.

Description of choice:

If *Disable* [0] is selected in this parameter, the [OFF/ STOP] key will be inactive.



NOTE

If *Disable* is selected, the motor cannot be stopped by means of the [OFF/STOP] key.

014 Auto start on LCP

(AUTO START BTTN)

Value:

Disable (DISABLE) [0]
 ★Enable (ENABLE) [1]

Function:

This parameter allows selection/deselection of the auto start key on the control panel.

Description of choice:

If *Disable* [0] is selected in this parameter, the [AUTO START] key will be inactive.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

015 Reset on LCP
(RESET BUTTON)
Value:

| | |
|-------------------|-----|
| Disable (DISABLE) | [0] |
| ★Enable (ENABLE) | [1] |

Function:

This parameter allows selection/deselection of the reset key on the control panel.

Description of choice:

If *Disable* [0] is selected in this parameter, the [RESET] key will be inactive.


NOTE

Only select *Disable* [0] if an external reset signal has been connected via the digital inputs.

Description of choice:

Auto restart [0] is selected if the AFD is to start up in the same start/stop condition as immediately before power to the AFD is cut off.

OFF/Stop [1] is selected if the AFD is to remain stopped when the line voltage is connected, until a start command is active. To restart, activate the key [HAND START] or [AUTO START] by using the control panel.


NOTE

If [HAND START] or [AUTO START] cannot be activated by the keys on the control panel (see parameter 012/014 *Hand/Auto start on LCP*) the motor will not be able to restart if *OFF/Stop* [1] is selected. If Handstart or Autostart has been programmed for activation via the digital inputs, the motor will not be able to restart if *OFF/Stop* [1] is selected.

016 Lock for data change
(DATA CHANGE LOCK)
Value:

| | |
|--------------------------|-----|
| ★Not locked (NOT LOCKED) | [0] |
| Locked (LOCKED) | [1] |

Function:

This parameter allows the control panel to be "locked", which means that it is not possible to carry out data modifications via the control unit.

Description of choice:

If *Locked* [1] is selected, data modifications in the parameters cannot be made, although it will still be possible to carry out data modifications via the bus. Parameters 007-010 *Display readout* can be changed via the control panel.

It is also possible to lock for data modifications in these parameters by means of a digital input, see parameters 300-307 *Digital inputs*.

017 Operating state at power up, local control
(POWER UP ACTION)
Value:

| | |
|------------------------------|-----|
| ★Auto restart (AUTO RESTART) | [0] |
| OFF/Stop (OFF/STOP) | [1] |

Function:

Setting of the desired operating mode when the line voltage is reconnected.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

■ **Load and motor 100-124**

This parameter group allows the configuration of regulation parameters and the choice of torque characteristics to which the AFD is to be adapted. The motor nameplate data must be set and automatic motor adaptation can be carried out. In addition, DC brake parameters can be set and the motor thermal protection can be activated.

■ **Configuration**

The selection of configuration and torque characteristics influences the parameters that can be seen in the display. If *Open loop* [0] is selected, all parameters relating to PID regulation will be hidden. Consequently, the user is only able to see the parameters that are of significance for a given application.

100 Configuration (CONFIG. MODE)

Value:

| | |
|---------------------------|-----|
| ★Open loop (OPEN LOOP) | [0] |
| Closed loop (CLOSED LOOP) | [1] |

Function:
This parameter is used for selecting the configuration to which the AFD is to be adapted.

Description of choice:
If *Open loop* [0] is selected, normal speed control is obtained (without feedback signal), i.e. if the reference is changed, the motor speed will change.
If *Closed loop* [1] is selected, the internal process regulator is activated to enable accurate regulation in relation to a given process signal.
The reference (setpoint) and the process signal (feedback) can be set to a process unit as programmed in parameter 415 *Process units*. See *Feedback handling*.

101 Torque characteristics (VT CHARACT)


Value:

| | |
|---|-----|
| ★Automatic Energy Optimization (AEO FUNCTION) | [0] |
| Constant Torque (CONSTANT TORQUE) | [1] |
| Variable Torque Low (VT LOW) | [2] |
| Variable Torque Medium (VT MED) | [3] |
| Variable Torque High (VT HIGH) | [4] |

Function:
This parameter allows a choice of whether the AFD operates with the controller adjusting the U/f curve automatically in response to the load, or whether variable or constant torque operation is selected.

Description of choice:
For variable torque loads such as centrifugal pumps and fans, the drive provides two operational modes. Automatic Energy Optimization enables the controller to dynamically adjust the U/f ratio in response to the motor load or speed changes to maximize motor and drive efficiency while reducing motor heat and noise.

The Variable Torque option provides low, medium and high levels of voltage as shown in the figure below (as a percentage of nominal motor voltage.) VT may be used with more than one motor connected to the output in parallel. Select the torque characteristic with the most reliable operation and the least energy consumption, motor heat and noise. The starting voltage can be selected in parameter 108, *VT Start Voltage*.



For constant torque loads such as conveyor belts, presses, mixers, screws and so forth, select *Constant Torque*. CT operation is achieved by maintaining a constant U/f ratio over the operating range.

★ = factory setting. () = display text [] = value for use in communication via serial communication port



NOTE

It is important that the values set in parameters 102-106 *Nameplate data* correspond to the nameplate data of the motor with respect to either star coupling Y or delta coupling Δ .

102 Motor power, $P_{M,N}$

(MOTOR POWER)

Value:

| | |
|--------------------|---------|
| 0.25 HP (0.25 KW) | [25] |
| 0.5 HP (0.37 KW) | [37] |
| 0.75 HP (0.55 KW) | [55] |
| 1 HP (0.75 KW) | [75] |
| 1.5 HP (1.10 KW) | [110] |
| 2 HP (1.50 KW) | [150] |
| 3 HP (2.20 KW) | [220] |
| 4 HP (3.00 KW) | [300] |
| 5 HP (4.00 KW) | [400] |
| 7.5 HP (5.50 KW) | [550] |
| 10 HP (7.50 KW) | [750] |
| 15 HP (11.00 KW) | [1100] |
| 20 HP (15.00 KW) | [1500] |
| 25 HP (18.50 KW) | [1850] |
| 30 HP (22.00 KW) | [2200] |
| 40 HP (30.00 KW) | [3000] |
| 50 HP (37.00 KW) | [3700] |
| 60 HP (45.00 KW) | [4500] |
| 75 HP (55.00 KW) | [5500] |
| 100 HP (75.00 KW) | [7500] |
| 125 HP (90.00 KW) | [9000] |
| 150 HP (110.00 KW) | [11000] |
| 200 HP (132.00 KW) | [13200] |
| 250 HP (160.00 KW) | [16000] |
| 300 HP (200.00 KW) | [20000] |
| 350 HP (250.00 KW) | [25000] |
| 400 HP (300.00 KW) | [30000] |
| 450 HP (315.00 KW) | [31500] |
| 500 HP (355.00 KW) | [35500] |
| 600 HP (400.00 KW) | [40000] |

★Depends on the unit

Function:

This is where to select the kW value $P_{M,N}$ that corresponds to the rated power of the motor. At the works, a rated kW value $P_{M,N}$ has been selected that depends on the type of unit.

Description of choice:

Select a value that equals the nameplate data on the motor. There are 4 possible undersizes or 1 oversize in comparison with the factory setting.

Also, alternatively it is possible to set the value of the motor power *infinitely variable* value, see the procedure for *infinitely variable change of numeric data value*.

103 Motor voltage, $U_{M,N}$

(MOTOR VOLTAGE)

Value:

| | |
|-------|-------|
| 200 V | [200] |
| 208 V | [208] |
| 220 V | [220] |
| 230 V | [230] |
| 240 V | [240] |
| 380 V | [380] |
| 400 V | [400] |
| 415 V | [415] |
| 440 V | [440] |
| 460 V | [460] |
| 480 V | [480] |
| 500 V | [500] |
| 550 V | [550] |
| 575 V | [575] |

★Depends on the unit

Function:

This is where the rated motor voltage $U_{M,N}$ is set for either star Y or delta Δ .

Description of choice:

Select a value that equals the nameplate data on the motor, regardless of the line voltage of the AFD. Furthermore, alternatively it is possible to set the value of the motor voltage *infinitely variably*. Also refer to the procedure for *infinitely variable change of numeric data value*.

104 Motor frequency, $f_{M,N}$
(MOTOR FREQUENCY)
Value:

- ▼ 50 Hz (50 HZ) [50]
- ★60 Hz (60 HZ) [60]
- ▼) Global factory setting different from North American factory setting.

Function:

Select the rated motor frequency $f_{M,N}$.

Description of choice:

Select a value that equals the nameplate data on the motor.

105 Motor current, $I_{M,N}$
(MOTOR CURRENT)
Value:

- 0.01 - $I_{VLT,MAX}$ A
- ★ Depends on the choice of motor.

Function:

The rated motor current $I_{M,N}$ forms part of the AFD calculations of torque and motor thermal protection. Set the motor current $I_{VLT,N}$, taking into account the star Y or delta Δ connected motor.

Description of choice:

Set a value that equals the nameplate data on the motor.


NOTE

It is important to enter the correct value, since this forms part of the V V C PLUS control feature.

106 Rated motor speed, $n_{M,N}$
(MOTOR NOM. SPEED)
Value:

- 100 - $f_{M,N} \times 60$ (max. 60000 rpm)
- ★ Depends on parameter 102 *Motor power, $P_{M,N}$* .

Function:

This sets the value that corresponds to the rated motor speed $n_{M,N}$, from the nameplate data.

Description of choice:

Choose a value that corresponds to the motor nameplate data.


NOTE

It is important to set the correct value, since this forms part of the V V C PLUS control feature. The max. value equals $f_{M,N} \times 60$. $f_{M,N}$ is set in parameter 104 *Motor frequency, $f_{M,N}$* .

107 Automatic motor adaptation, AMA
(AUTO MOTOR ADAPT)
Value:

- ★ Optimization disable (NO AMA) [0]
- Automatic adaptation (RUN AMA) [1]
- Limited AMA (RUN LIMITED AMA) [2]

Function:

Automatic motor adaptation is a test algorithm that measures the electrical motor parameters at motor standstill. This means that AMA itself does not supply any torque.

AMA is useful when commissioning systems, where the user wants to optimise the adjustment of the AFD to the motor applied. This feature is used where the factory setting does not match requirements of the motor.

For the best adjustment of the AFD, it is recommended to carry out AMA on a cold motor. It must be noted that repeated AMA runs may lead to a heating of the motor that will result in an increase of the stator resistance R_s . However, this is not normally critical.

It is possible via parameter 107 *Automatic motor adaptation, AMA* to choose whether a complete automatic motor adaptation *Automatic adaptation* [1] is to be carried out, or whether reduced automatic motor adaptation *Limited AMA* [2] is to be made.

It is possible to carry out the reduced test if a LC-filter has been placed between the AFD and the motor. If a total setting is required, the LC-filter can be removed and, after completion of the AMA, it can be reinstalled. In *Limited AMA* [2] there is no test of motor symmetry and of whether all motor phases have been connected. The following must be noted when the AMA function is used:

- For AMA to be able to determine the motor parameters optimally, the correct nameplate data for the motor connected to the AFD must be entered in parameters 102 to 106.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

- The duration of a total automatic motor adaptation varies from a few minutes to approx. 10 minutes for small motors, depending on the rating of the motor used (the time for a 7.5 HP motor, for example, is approx. 4 minutes).
- Alarms and warnings will be shown in the display if faults occur during motor adaptation.
- AMA can only be carried out if the rated motor current of the motor is min. 35% of the rated out-put current of the AFD.


NOTE

Some motors (such as motors with 6 or more poles) may be unable to run Automatic Adaptation. Limited AMA or use of parameters 123 and 124 is a procedure which can be effective in such cases since procedure measures motor's stator and effects of cable length. Multiple motor applications cannot use any form of AMA.

Description of choice:

Select *Automatic adaptation* [1] if the AFD is to carry out a complete automatic motor adaptation. Select *Limited AMA* [2] if an LC-filter has been placed between the AFD and the motor, or for six or more pole motors.

Procedure for automatic motor adaptation:

1. Set the motor parameters in accordance with the motor nameplate data given in parameters 102-106 *Nameplate data*.
2. Connect 24 V DC (possibly from terminal 12) to terminal 27 on the control card.
3. Select Automatic adaptation [1] or Limited AMA [2] in parameter 107 *Automatic motor adaptation, AMA*.
4. Start up the AFD or connect terminal 18 (start) to 24 V DC (possibly from terminal 12).

If the automatic motor adaptation is to be stopped:

1. Press the [OFF/STOP] key.

After a normal sequence, the display reads: AMA STOP

1. The AFD is now ready for operation.


NOTE

[RESET] key must be pressed after AMA is completed to save results into drive.

If there is a fault, the display reads: ALARM 22

1. Check for possible causes of the fault in accordance with the alarm message. See *list of warnings and alarms*.
2. Press the [RESET] key to clear fault.

If there is a warning, the display reads: WARNING 39-42

1. Check for possible causes of the fault in accordance with the warning. See *list of warnings and alarms*.
2. Press the [CHANGE DATA] key and select "Continue" if AMA is to continue despite the warning, or press the [OFF/STOP] key to stop the automatic motor adaptation.

108 Variable Torque Starting Voltage
(VT START VOLT)
Value:

0.0 - parameter 103 *Motor voltage, U_{M,N}*

★ depends on par. 103 *Motor voltage, U_{M,N}*

Function:

This parameter specifies the start-up voltage for VT characteristics at 0 Hz. It is also used for motors connected in parallel.

The start-up voltage represents a supplementary voltage input to the motor. By increasing the start-up voltage, motors receive a higher start-up torque. This is used especially for small motors (< 4.0 kW/5 HP) connected in parallel, as they have a higher stator resistance than motors above 5.5 kW/7.5 HP. This function is only active if *Variable torque* [1], [2] or [3] has been selected in parameter 101 *Torque characteristics*.

Description of choice:

Set the start-up voltage at 0 Hz. The maximum voltage depends on parameter 103 *Motor voltage, U_{M,N}*.

109 Resonance damping
(RESONANCE DAMP.)
Value:

0 - 500 %

★ 100 %

Function:

High-frequency electric resonance problems between the AFD and the motor can be eliminated by adjusting the resonance damping.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

Description of choice:

Adjust the damping percentage until the motor resonance has disappeared.

110 High break-away torque

(HIGH START TORQ.)

Value:

0.0 - 0.5 sec. ★ 0.0 sec.

Function:

In order to secure a high starting torque, the maximum torque for max. 0.5 sec. is allowed. However, the current is limited by the protection limit of the AFD. 0 sec. corresponds to no high break-away torque.

Description of choice:

Set the necessary time in which a high starting torque is desired.

111 Start delay

(START DELAY)

Value:

0.0 - 120.0 sec. ★ 0.0 sec.

Function:

This parameter enables a delay of the starting time after the conditions for start have been fulfilled. When the time has passed, the output frequency will start by ramping up to the reference.

Description of choice:

Set the desired time until acceleration is to begin.

112 Motor preheater

(MOTOR PREHEAT)

Value:

★Disable (DISABLE) [0]
Enable (ENABLE) [1]

Function:

The motor preheater ensures that no condensate develops in the motor at stop. This function can also be used to evaporate condensed water in the motor. The motor preheater is only active during stop.

Description of choice:

Select *Disable* [0] if this function is not required. Select *Enable* [1] to activate motor preheating. The DC current is set in parameter 113 *Motor preheater DC current*.

113 Motor preheater DC current

(PREHEAT DC-CURR.)

Value:

0 - 100 % ★ 50 %

The maximum value depends on the rated motor current, parameter 105 *Motor current*, $I_{M,N}$.

Function:

The motor can be preheated at stop by means of a DC current to prevent moisture from entering the motor.

Description of choice:

The motor can be preheated by means of a DC current. At 0%, the function is inactive; at a value higher than 0%, a DC current will be supplied to the motor at stop (0 Hz). This function can also be used to generate a holding torque.



If too high a DC current is supplied for too long, the motor can be damaged.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

■ DC braking

In DC braking, the motor receives a DC current that brings the shaft to a halt. Parameter 114 *DC braking current*, decides the DC braking current as a percentage of the rated motor current $I_{M,N}$. In parameter 115 *DC braking time*, the DC braking time is selected, and in parameter 116 *DC brake cut-in frequency*, the frequency is selected at which DC braking becomes active. If terminal 19 or 27 (parameter 303/304 *Digital input*) has been programmed to *DC braking inverse* and shifts from logic "1" to logic "0", the DC braking will be activated. When the start signal on terminal 18 changes from logic "1" to logic "0", the DC braking will be activated when the output frequency becomes lower than the brake coupling frequency.


NOTE

The DC brake is not to be used if the inertia of the motor shaft is more than 20 times the inertia of the motor itself.

114 DC braking current
(DC BRAKE CURRENT)
Value:

0 – $\frac{I_{VLT,MAX}}{I_{M,N}} \cdot 100$ [%] ★ 50 %

The maximum value depends on the rated motor current. If the DC braking current is active, the AFD has a switching frequency of 4 kHz.

Function:

This parameter is used for setting the DC braking current that is activated upon a stop when the DC brake frequency set in parameter 116, *DC brake cut-in frequency* has been reached, or if DC brake inverse is active via terminal 27 or via the serial communication port. The DC braking current will be active for the duration of the DC braking time set in parameter 115 *DC braking time*.

Description of choice:

To be set as a percentage value of the rated motor current $I_{M,N}$ set in parameter 105 Motor current, $I_{VLT,N}$. 100% DC braking current corresponds to $I_{M,N}$.



Make sure not to supply too high a braking current for too long. The motor will be damaged because of mechanical overload or the heat generated in the motor.

115 DC braking time
(DC BRAKE TIME)
Value:

0.0 - 60.0 sec. ★ OFF

Function:

This parameter is for setting the DC braking time for which the DC braking current (parameter 113) is to be active.

Description of choice:

Set the desired time.

116 DC brake cut-in frequency
(DC BRAKE CUT-IN)
Value:

0.0 (OFF) - par. 202
Output frequency high limit, f_{MAX} ★ OFF

Function:

This parameter is used for setting the DC brake cut-in frequency at which DC braking is to be activated in connection with a stop command.

Description of choice:

Set the desired frequency.

117 Motor thermal protection
(MOT. THERM PROTEC)
Value:

| | |
|---|------|
| No protection (NO PROTECTION) | [0] |
| Thermistor warning (THERMISTOR WARNING) | [1] |
| Thermistor trip (THERMISTOR FAULT) | [2] |
| ETR Warning 1 (ETR WARNING 1) | [3] |
| ★ETR Trip 1 (ETR TRIP 1) | [4] |
| ETR Warning 2 (ETR WARNING 2) | [5] |
| ETR Trip 2 (ETR TRIP 2) | [6] |
| ETR Warning 3 (ETR WARNING 3) | [7] |
| ETR Trip 3 (ETR TRIP 3) | [8] |
| ETR Warning 4 (ETR WARNING 4) | [9] |
| ETR Trip 4 (ETR TRIP 4) | [10] |

Function:

The AFD is able to monitor the motor temperature in two different ways:

★ = factory setting. () = display text [] = value for use in communication via serial communication port

- Via a thermistor sensor fitted to the motor. The thermistor is connected to one of the analog input terminals 53 and 54.
- Calculation of the thermal load (ETR - Electronic Thermal Relay), based on the current load and the time. This is compared with the rated motor current $I_{M,N}$ and the rated motor frequency $f_{M,N}$. The calculations made take into account the need for a lower load at lower speeds because of less cooling in the motor itself.

ETR functions 1-4 do not start calculating the load until there is a switch-over to the Setup in which they were selected. This enables the use of the ETR function, even where two or several motors alternate.

Description of choice:

Select *No protection* [0] if no warning or tripping is required when the motor is overloaded.


Select *Thermistor warning* [1] if a warning is desired when the connected thermistor gets too hot.

Select *Thermistor trip* [2] if cutting out (trip) is desired when the connected thermistor overheats.

Select *ETR Warning 1-4*, if a warning is to come up on the display when the motor is overloaded according to the calculations.

The AFD can also be programmed to give off a warning signal via one of the digital outputs.

Select *ETR Trip 1-4* if tripping is desired when the motor is overloaded according to the calculations.



NOTE

In UL / cUL applications ETR provides class 20 motor overload protection in accordance with National Electrical Code.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

118 Motor power factor (Cos ϕ)

(MOTOR PWR FACT)

Value:

0.50 - 0.99 ★ 0.75

Function:

This parameter calibrates and optimizes the AEO function for motors of different power factor (Cos ϕ).

Description of choice:

Motors having > 4 poles have a lower power factor which would restrict or prevent use of the AEO function for energy savings. This parameter allows the user to calibrate the AEO function to the power factor of the motor so that AEO can be used with motors of 6, 8, and 12 poles as well as 4 and 2 poles.

119 Load compensation at low speed

(LOAD COMP LO SPD)

Value:

0 - 300 % ★ 100 %

Function:


This parameter enables compensation of voltage in relation to load when the motor is running at low speed.

Description of choice:

Optimum U/f characteristics are obtained, i.e. compensation for the load at low speed. The frequency range within which *Load compensation at low speed* is active, depends on the motor size.

This function is active for:

| Motor size | Change-over |
|----------------------------------|-------------|
| 0.5 kW (.75 HP) - 7.5 kW (10 HP) | < 10 Hz |
| 11 kW (15 HP) - 45 kW (60 HP) | < 5 Hz |
| 55 kW (75 HP) - 355 kW (600 HP) | < 3-4 Hz |



120 Load compensation at high speed

(LOAD COMP HI SPD)

Value:

0 - 300 % ★ 100 %

Function:

This parameter enables compensation of voltage in relation to load when the motor is running at high speed.

Description of choice:

In *Load compensation at high speed* it is possible to compensate for the load from the frequency where *Load compensation at low speed* stopped working to max.frequency.

This function is active for:

| Motor size | Change-over |
|-----------------|-------------|
| 0.5 kW - 7.5 kW | >10 Hz |
| 11 kW - 45 kW | >5 Hz |
| 55 kW - 355 kW | >3-4 Hz |

121 Slip compensation

(SLIP COMPENSAT.)

Value:

-500 - 500 % ★ 100 %

Function:

Slip compensation is calculated automatically, i.e. on the basis of the rated motor speed $n_{M,N}$.

In parameter 121, slip compensation can be adjusted in detail, which compensates for tolerances in the value of $n_{M,N}$.

This function is not active together with *Variable torque* (parameter 101 - variable torque graphs),

★ = factory setting. () = display text [] = value for use in communication via serial communication port

Torque control, Speed feedback and Special motor characteristics.

V), a special ohm-meter should be used (Thomson bridge or similar). $R_S = 0.5 \times R_{\text{PHASE-to-PHASE}}$

Description of choice:

Enter a %-value of the rated motor frequency (parameter 104).

4. The factory settings of R_S , selected by the AFD itself on the basis of the motor nameplate data, are used.
-

122 Slip compensation time constant

(SLIP TIME CONST.)

Value:

0.05 - 5.00 sec. ★ 0.50 sec.

Function:

This parameter determines the slip compensation reaction speed.

Description of choice:

A high value results in slow reaction. Conversely, a low value results in quick reaction. If low-frequency resonance problems are encountered, the time set must be longer.

123 Stator resistance

(STATOR RESIST)

Value:

★ Depends on the choice of motor

Function:

After setting motor data in parameters 102-106, a number of adjustments of various parameters are made automatically, including the stator resistance R_S . A manually entered R_S must apply to a cold motor. The shaft performance can be improved by fine-tuning R_S and X_S , see procedure below.

Description of choice:

R_S can be set as follows:

1. Automatic motor adaptation, where the AFD actually tests the motor to determine this value. All compensations are reset to 100%.
2. The values are stated by the motor supplier.
3. The values are obtained by means of manual measurements:
 - R_S can be calculated by measuring the resistance $R_{\text{PHASE-to-PHASE}}$ between two phase terminals. If $R_{\text{PHASE-to-PHASE}}$ is lower than 1-2 ohm (typically motors > 4 (5.4 HP) - 5.5 kW (7.4 HP), 400

★ = factory setting. () = display text [] = value for use in communication via serial communication port

124 Stator reactance**(STATOR REACT.)****Value:**

★depends on the choice of motor

Function:

After setting motor data in parameters 102-106, a number of adjustments of various parameters are made automatically, including the stator resistance X_S . The shaft performance can be improved by fine-tuning R_S and X_S , see procedure below.

Description of choice:


X_S can be set as follows:

1. Automatic motor adaptation, where the AFD actually tests the motor to determine this value. All compensations are reset to 100%.
2. The values are stated by the motor supplier.
3. These values are obtained by means of manual measurements:
 - X_S can be calculated by connecting a motor to line and measuring the phase-to-phase voltage U_L as well as the idling current I .
Alternatively, these values can be recorded during operation in idle running state at the rated motor frequency $f_{M,N}$, slip compensation (par. 115) = 0% and load compensation at high speed (par. 114) = 100%.

$$X_S = \frac{U_L}{\sqrt{3} \cdot I \Phi}$$

4. The factory settings of X_S , selected by the AFD itself on the basis of the motor nameplate data, are used.
-

■ References and Limits 200-208



175HA334.10

In this parameter group, the frequency and reference range of the AFD are established. This parameter group also includes:

- Setting of ramp times
- Choice of four preset references
- Possibility of programming four bypass frequencies.
- Setting of maximum current to motor.
- Setting of warning limits for current, frequency, reference and feedback.

201 Output frequency low limit, f_{MIN}

(MIN. FREQUENCY)

Value:

0.0 - f_{MAX} ☆ 0.0 HZ

Function:

This is where to select the minimum output frequency.

Description of choice:

A value from 0.0 Hz to the *Output frequency high limit*, f_{MAX} frequency set in parameter 202 can be selected.

202 Output frequency high limit, f_{MAX}

(MAX. FREQUENCY)

Value:

f_{MIN} - 120 Hz

(par. 200 *Output frequency range*)

☆ 60 Hz/▼ 50 Hz

▼) Global factory setting different from North American factory setting.)

Function:

In this parameter, a maximum output frequency can be selected that corresponds to the highest speed at which the motor can be.



NOTE

The output frequency of the AFD can never assume a value higher than 1/10 of the switching frequency (parameter 407 *Switching frequency*).

Description of choice:

A value from f_{MIN} to the choice made in parameter 200 *Output frequency range* can be selected.

☆ = factory setting. () = display text [] = value for use in communication via serial communication port

■ Reference handling

Reference handling is shown in the block diagram underneath.

The block diagram shows how a change in a parameter can affect the resulting reference.

Parameters 203 to 205 *Reference handling, minimum and maximum reference* and parameter 210 *Reference type* define the way reference handling can be carried out. The mentioned parameters are active both in a closed and in an open loop.

Remote references are defined as:

- External references, such as analog inputs 53, 54 and 60, pulse reference via terminal 17/29 and reference from serial communication.
- Preset references.

The resulting reference can be shown in the display by selecting *Reference [%]* in parameters 007-010 *Display readout* and in the form of a unit by selecting *Resulting reference [unit]*. See the section on *Feedback handling* in connection with a closed loop.

The sum of the external references can be shown in the display as a percentage of the range from *Minimum reference, Ref_{MIN}* to *Maximum reference, Ref_{MAX}*. Select *External reference, % [25]* in parameters 007-010 *Display readout* if a readout is required.

It is possible to have both preset references and external references at the same time. In parameter 210 *Reference type* a choice is made of how the preset references are to be added to the external references.


Furthermore, an independent local reference exists, where the resulting reference is set by means of the [+/-] keys. If local reference has been selected, the output frequency range is limited by parameter 201 *Output frequency low limit, f_{MIN}* and parameter 202 *Output frequency high limit, f_{MAX}*.



NOTE

If the local reference is active, the VLT AFD will always be in *Open loop [0]*, regardless of the choice made in parameter 100 *Configuration*.

The unit of the local reference can be set either as Hz or as a percentage of the output frequency range. The unit is selected in parameter 011 *Unit of local reference*.



175HA375.14

★ = factory setting. () = display text [] = value for use in communication via serial communication port

203 Reference site

(REFERENCE SITE)

Value:

| | |
|--|-----|
| ★Hand/Auto linked reference (LINKED TO HAND/AUTO) | [0] |
| Remote reference (REMOTE) | [1] |
| Local reference (LOCAL) | [2] |

Function:

This parameter determines the location of the active reference. If *Hand/Auto linked reference* [0] is selected, the resulting reference will depend on whether the AFD is in Hand or Auto mode. The table shows which references are active when *Hand/Auto linked reference* [0], *Remote reference* [1] or *Local reference* [2] has been selected. The Hand mode or Auto mode can be selected via the control keys or via a digital input, parameters 300-307 *Digital inputs*.

| Reference handling | Hand mode | Auto mode |
|--------------------|--------------------|--------------------|
| Hand/Auto [0] | Local ref. active | Remote ref. active |
| Remote [1] | Remote ref. active | Remote ref. active |
| Local [2] | Local ref. active | Local ref. active |

Description of choice:

If *Hand/Auto linked reference* [0] is chosen, the motor speed in Hand mode will be decided by the local reference, while in Auto mode it depends on remote references and any setpoints selected.

If *Remote reference* [1] is selected, the motor speed will depend on remote references, regardless of whether Hand mode or Auto mode has been chosen.

If *Local reference* [2] is selected, the motor speed will only depend on the local reference set via the control panel, regardless of whether Hand mode or Auto mode has been selected.

204 Minimum reference, Ref_{MIN}

(MIN. REFERENCE)

Value:

Parameter 100 *Configuration = Open loop* [0].
0.000 - parameter 205 Ref_{MAX} ★ 0.000 Hz
Parameter 100 *Configuration = Closed loop* [1].
-Par. 413 *Minimum feedback*
- par. 205 Ref_{MAX} ★ 0.000

Function:

The *Minimum reference* gives the minimum value that can be assumed by the sum of all references.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

If *Closed loop* has been selected in parameter 100 *Configuration*, the minimum reference is limited by parameter 413 *Minimum feedback*.

Minimum reference is ignored when the local reference is active (parameter 203 *Reference site*). The unit for the reference can be seen from the following table:

| | Unit |
|---|----------|
| Par. 100 <i>Configuration = Open loop</i> | Hz |
| Par. 100 <i>Configuration = Closed loop</i> | Par. 415 |

Description of choice:

Minimum reference is set if the motor is to run at a minimum speed, regardless of whether the resulting reference is 0.

205 Maximum reference, Ref_{MAX}

(MAX. REFERENCE)

Value:

Parameter 100 *Configuration = Open loop* [0]
Parameter 204 Ref_{MIN} - 1000.000 Hz
★ 60 Hz/▼ 50 Hz
Parameter 100 *Configuration = Closed loop* [1]
Par. 204 Ref_{MIN}
- par. 414 *Maximum feedback* ★ 60 Hz/▼ 50 Hz
▼) Global factory setting different from North American factory setting).

Function:

The *Maximum reference* gives the maximum value that can be assumed by the sum of all references. If *Closed loop* [1] has been selected in parameter 100 *Configuration*, the maximum reference cannot be set above parameter 414 *Maximum feedback*. The *Maximum reference* is ignored when the local reference is active (parameter 203 *Reference site*).

The reference unit can be determined on the basis of the following table:

| Unit | |
|---|----------|
| Par. 100 <i>Configuration = Open loop</i> | Hz |
| Par. 100 <i>Configuration = Closed loop</i> | Par. 415 |

Description of choice:

Maximum reference is set if the motor speed is not to exceed the set value, regardless of whether the resulting reference is higher than *Maximum reference*.

206 Ramp-up time


(RAMP UP TIME)

Value:

1 - 3600 sec. ★ Depends on the unit

Function:

The ramp-up time is the acceleration time from 0 Hz to the rated motor frequency $f_{M,N}$ (parameter 104 *Motor frequency, $f_{M,N}$*). It is assumed that the output current does not reach the current limit (set in parameter 215 *Current limit I_{LIM}*).



Description of choice:

Program the desired ramp-up time.

207 Ramp-down time

(RAMP DOWN TIME)

Value:

1 - 3600 sec. ★ Depends on the unit

Function:

The ramp-down time is the deceleration time from the rated motor frequency $f_{M,N}$ (parameter 104 *Motor frequency, $f_{M,N}$*) to 0 Hz, provided there is no overvoltage in the inverter because of the motor acting as a generator.

Description of choice:

Program the desired ramp-down time.

208 Automatic ramp-down

(AUTO RAMPING)

Value:

Disable (DISABLE) [0]
 ★ Enable (ENABLE) [1]

Function:

This function ensures that the AFD does not trip during deceleration if the ramp-down time set is too

short. If, during deceleration, the AFD registers that the intermediate circuit voltage is higher than the max. value (see *list of warnings and alarms*), the AFD automatically extends the ramp-down time.



NOTE

If the function is chosen as *Enable* [1], the ramp time may be considerably extended in relation to the time set in parameter 207 *Ramp-down time*.

Description of choice:

Program this function as *Enable* [1] if the AFD periodically trips during ramp-down. If a quick ramp-down time has been programmed that may lead to a trip under special conditions, the function can be set to *Enable* [1] to avoid trips.

209 Jog frequency

(JOG FREQUENCY)

Value:

Par. 201 *Output frequency Low limit* - par. 202 *Output frequency high limit* ★ 10.0 HZ

Function:

The jog frequency f_{JOG} is the fixed output frequency at which the AFD is running when the jog function is activated.

Jog can be activated via the digital inputs.

Description of choice:

Set the desired frequency.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

■ Reference type

The example shows how the resulting reference is calculated when Preset references are used together with Sum and Relative in parameter 210 Reference type. See *Calculation of resulting reference*. See also the drawing in *Reference handling*.

The following parameters have been set:

| | |
|--|---------------|
| Par. 204 <i>Minimum reference:</i> | 10 Hz |
| Par. 205 <i>Maximum reference:</i> | 50 Hz |
| Par. 211 <i>Preset reference:</i> | 15% |
| Par. 308 <i>Terminal 53, analog input:</i> | Reference [1] |
| Par. 309 <i>Terminal 53, min. scaling:</i> | 0 V |
| Par. 310 <i>Terminal 53, max. scaling:</i> | 10 V |


When parameter 210 *Reference type* is set to Sum [0], one of the adjusted *Preset references* (par. 211-214) will be added to the external references as a percentage of the reference range. If terminal 53 is energized by an analog input voltage of 4 V, the resulting reference will be as follows:

| | |
|--|-----------|
| Par. 210 <i>Reference type</i> = Sum [0] | |
| Par. 204 <i>Minimum reference</i> | = 10.0 Hz |
| Reference contribution at 4 V | = 16.0 Hz |
| Par. 211 <i>Preset reference</i> | = 6.0 Hz |
| Resulting reference | = 32.0 Hz |

If parameter 210 *Reference type* is set to *Relative* [1], one of the adjusted *Preset references* (par. 211-214) will be totaled as a percentage of the sum of the present external references. If terminal 53 is energized by an analog input voltage of 4 V, the resulting reference will be as follows:

| | |
|--|-----------|
| Par. 210 <i>Reference type</i> = <i>Relative</i> [1] | |
| Par. 204 <i>Minimum reference</i> | = 10.0 Hz |
| Reference contribution at 4 V | = 16.0 Hz |
| Par. 211 <i>Preset reference</i> | = 2.4 Hz |
| Resulting reference | = 28.4 Hz |

The graph in the next column shows the resulting reference in relation to the external reference varied from 0-10 V. Parameter 210 *Reference type* has been programmed for *Sum* [0] and *Relative* [1], respectively. In addition, a graph is shown in which parameter 211 *Preset reference* 1 is programmed for 0%.



210 Reference type

(REF. FUNCTION)

Value:

| | |
|-----------------------------------|-----|
| ★Sum (SUM) | [0] |
| Relative (RELATIVE) | [1] |
| External/preset (EXTERNAL/PRESET) | [2] |

Function:

It is possible to define how the preset references are to be added to the other references. For this purpose, *Sum* or *Relative* is used. It is also possible - by using the *External/preset* function - to select whether a shift between external references and preset references is wanted. See *Reference handling*.

Description of choice:

If *Sum* [0] is selected, one of the adjusted preset references (parameters 211-214 *Preset reference*) is added to the other external references as a percentage of the reference range (Ref_{MIN}-Ref_{MAX}).
 If *Relative* [1] is selected, one of the adjusted preset references (parameters 211-214 *Preset reference*) is totaled as a percentage of the sum of the present external references.
 If *External/preset* [2] is selected, it is possible to shift between external references and preset references via terminal 16, 17, 29, 32 or 33 (parameter 300, 301, 305, 306 or 307 *Digital inputs*). Preset references will be a percentage value of the reference range. External reference is the sum of the analog references, pulse references and any references from serial communication.

★ = factory setting. () = display text [] = value for use in communication via serial communication port


NOTE

If *Sum* or *Relative* is selected, one of the preset references will always be active. If the preset references are to be without influence, they should be set to 0% (as in the factory setting) via the serial communication port.

211 Preset reference 1
(PRESET REF. 1)
212 Preset reference 2
(PRESET REF. 2)
213 Preset reference 3
(PRESET REF. 3)
214 Preset reference 4
(PRESET REF. 4)
Value:

-100.00 % - +100.00 % ★ 0.00%
of the reference range/external reference

Function:

Four different preset references can be programmed in parameters 211-214 *Preset reference*. The preset reference is stated as a percentage value of the reference range (Ref_{MIN} - Ref_{MAX}) or as a percentage of the other external references, depending on the choice made in parameter 210 *Reference type*. The choice between the preset references can be made by activating terminal 16, 17, 29, 32 or 33, cf. the table below.

| Terminal 17/29/33 preset ref. msb | Terminal 16/29/32 preset ref. lsb | |
|--------------------------------------|--------------------------------------|---------------|
| 0 | 0 | Preset ref. 1 |
| 0 | 1 | Preset ref. 2 |
| 1 | 0 | Preset ref. 3 |
| 1 | 1 | Preset ref. 4 |

Description of choice:

Set the required preset reference(s) that is/are to be the options.

215 Current limit, I_{LIM}
(CURRENT LIMIT)
Value:

0.1 - 1.1 × I_{VLT,N} ★ 1.0 × I_{VLT,N} [A]

Function:

This is where the maximum output current I_{LIM} is set. The factory setting corresponds to the rated output current. If the current limit is to be used as motor protection, the rated motor current must be set. If the current limit is set within the range of 1.0-1.1 × I_{VLT,N} (the rated output current of the AFD), the AFD can only handle a load intermittently, i.e. for short periods at a time. After the load has been higher than I_{VLT,N}, it must be ensured that for a period the load is lower than I_{VLT,N}. Please note that if the current limit is set to less than I_{VLT,N}, the acceleration torque will be reduced correspondingly.

Description of choice:

Set the required maximum output current I_{LIM}.

216 Frequency bypass, bandwidth
(FREQUENCY BYPASS B.W)
Value:

0 (OFF) - 100 Hz ★ Disable

Function:

Some systems call for some output frequencies to be avoided because of mechanical resonance problems in the system. These output frequencies can be programmed in parameters 217-220 *Frequency bypass*. In this parameter (216 *Frequency bypass, bandwidth*), a definition can be given of a bandwidth around each of these frequencies.

Description of choice:

The bypass bandwidth is equal to the programmed bandwidth frequency. This bandwidth will be centered around each bypass frequency.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

217 Frequency bypass 1

(BYPASS FREQ. 1)

218 Frequency bypass 2

(BYPASS FREQ. 2)

219 Frequency bypass 3

(BYPASS FREQ. 3)

220 Frequency bypass 4

(BYPASS FREQ. 4)

Value:

0 - 120 HZ ★ 120.0 Hz

Function:

Some systems call for some output frequencies to be avoided because of mechanical resonance problems in the system.

Description of choice:

Enter the frequencies to be avoided.
See also parameter 216 *Frequency bypass, bandwidth*.

221 Warning: Low current, I_{LOW}

(WARN. LOW CURR.)

Value:


0.0 - par. 222 *Warning: High current I_{HIGH}*, ★ 0.0A

Function:

When the motor current is below the limit, I_{LOW}, programmed in this parameter, the display shows a flashing CURRENT LOW, provided *Warning [1]* has been selected in parameter 409 *Function in case of no load*. The AFD will trip if parameter 409 *Function in case of no load* has been selected as *Trip [0]*. The warning functions in parameters 221-228 are not active during ramp-up after a start command, ramp-down after a stop command or while stopped. The warning functions are activated when the output frequency has reached the resulting reference. The signal outputs can be programmed to generate a warning signal via terminal 42 or 45 and via the relay outputs.

Description of choice:

The lower signal limit I_{LOW} must be programmed within the normal working range of the AFD.



222 Warning: High current, I_{HIGH}

(WARN. HIGH CURR.)

Value:

Parameter 221 - I_{VLT,MAX} ★ I_{VLT,MAX}

Function:

If the motor current is above the limit, I_{HIGH}, programmed in this parameter, the display shows a flashing CURRENT HIGH. The warning functions in parameters 221-228 are not active during ramp-up after a start command, ramp-down after a stop command or while stopped. The warning functions are activated when the output frequency has reached the resulting reference. The signal outputs can be programmed to generate a warning signal via terminal 42 or 45 and via the relay outputs.

Description of choice:

The upper signal limit of the motor frequency, f_{HIGH}, must be programmed within the normal working range of the AFD. See drawing at parameter 221 *Warning: Low current, I_{LOW}*.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

223 Warning: Low frequency, f_{LOW}
(WARN. LOW FREQ.)
Value:

0.0 - parameter 224 ★ 0.0 Hz

Function:

If the output frequency is below the limit, f_{LOW} , programmed in this parameter, the display will show a flashing FREQUENCY LOW.

The warning functions in parameters 221-228 are not active during ramp-up after a start command, ramp-down after a stop command or while stopped. The warning functions are activated when the output frequency has reached the selected reference.

The signal outputs can be programmed to generate a warning signal via terminal 42 or 45 and via the relay outputs.

Description of choice:

The lower signal limit of the motor frequency, f_{LOW} , must be programmed within the normal working range of the AFD. See drawing at parameter 221 *Warning: Low current, I_{LOW}* .

224 Warning: High frequency, f_{HIGH}
(WARN. HIGH FREQ.)
Value:

Par. 200 *Output frequency range* = 0-120 Hz [0].
parameter 223 - 120 Hz ★ 120.0 Hz

Function:

If the output frequency is above the limit, f_{HIGH} , programmed in this parameter, the display will show a flashing FREQUENCY HIGH.

The warning functions in parameters 221-228 are not active during ramp-up after a start command, ramp-down after a stop command or while stopped. The warning functions are activated when the output frequency has reached the selected reference. The signal outputs can be programmed to generate a warning signal via terminal 42 or 45 and via the relay outputs.

Description of choice:

The higher signal limit of the motor frequency, f_{HIGH} , must be programmed within the normal working

range of the AFD. See drawing at parameter 221 *Warning: Low current, I_{LOW}* .

225 Warning: Low reference, REF_{LOW}
(WARN. LOW REF.)
Value:

 -999,999.999 - REF_{HIGH} (par.226) ★ -999,999.999

Function:

When the remote reference lies under the limit, REF_{LOW} , programmed in this parameter, the display shows a flashing REFERENCE LOW.

The warning functions in parameters 221-228 are not active during ramp-up after a start command, ramp-down after a stop command or while stopped. The warning functions are activated when the output frequency has reached the selected reference. The signal outputs can be programmed to generate a warning signal via terminal 42 or 45 and via the relay outputs.

The reference limits in parameter 226 *Warning: High reference, Ref_{HIGH}* , and in parameter 225 *Warning: Low reference, Ref_{LOW}* , are only active when remote reference has been selected.

In *Open loop mode* the unit for the reference is Hz, while in *Closed loop mode* the unit is programmed in parameter 415 *Process units*.

Description of choice:

The lower signal limit, Ref_{LOW} , of the reference must be programmed within the normal working range of the AFD, provided parameter 100 *Configuration* has been programmed for *Open loop* [0]. In *Closed loop* [1] (parameter 100), Ref_{LOW} must be within the reference range programmed in parameters 204 and 205.

226 Warning: High reference, REF_{HIGH}
(WARN. HIGH REF.)
Value:
 REF_{LOW} (par. 225) - 999,999.999 ★ 999,999.999

Function:

If the resulting reference is above the limit, Ref_{HIGH} , programmed in this parameter, the display shows a flashing REFERENCE HIGH.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

The warning functions in parameters 221-228 are not active during ramp-up after a start command, ramp-down after a stop command or while stopped. The warning functions are activated when the output frequency has reached the resulting reference. The signal outputs can be programmed to generate a warning signal via terminal 42 or 45 and via the relay outputs.

The reference limits in parameter 226 *Warning: High reference*, Ref_{HIGH} , and in parameter 225 *Warning: Low reference*, Ref_{LOW} , are only active when remote reference has been selected. In *Open loop* the unit for the reference is Hz, while in *Closed loop* the unit is programmed in parameter 415 *Process units*.

Description of choice:

The upper signal limit, Ref_{HIGH} , of the reference must be programmed within the normal working range of the AFD, provided parameter 100 Configuration has been programmed for *Open loop* [0]. In *Closed loop* [1] (parameter 100), Ref_{HIGH} must be within the reference range programmed in parameters 204 and 205.

**227 Warning: Low feedback, FB_{LOW}
(WARN LOW FDBK)**
Value:

-999,999.999 - FB_{HIGH}
(parameter 228) ★ -999.999,999

Function:

If the feedback signal is below the limit, FB_{LOW} , programmed in this parameter, the display will show a flashing FEEDBACK LOW. The warning functions in parameters 221-228 are not active during ramp-up after a start command, ramp-down after a stop command or while stopped. The warning functions are activated when the output frequency has reached the selected reference. The signal outputs can be programmed to generate a warning signal via terminal 42 or 45 and via the relay outputs. In *Closed loop*, the unit for the feedback is programmed in parameter 415 *Process units*.

Description of choice:

Set the required value within the feedback range (parameter 413 *Minimum feedback*, FB_{MIN} , and 414 *Maximum feedback*, FB_{MAX}).

**228 Warning: High feedback, FB_{HIGH}
(WARN. HIGH FDBK)**
Value:

FB_{LOW}
(parameter 227) - 999,999.999 ★ 999.999,999

Function:

If the feedback signal is above the limit, FB_{HIGH} , programmed in this parameter, the display will show a flashing FEEDBACK HIGH. The warning functions in parameters 221-228 are not active during ramp-up after a start command, ramp-down after a stop command or while stopped. The warning functions are activated when the output frequency has reached the selected reference. The signal outputs can be programmed to generate a warning signal via terminal 42 or 45 and via the relay outputs. In *Closed loop*, the unit for the feedback is programmed in parameter 415 *Process units*.

Description of choice:

Set the required value within the feedback range (parameter 413 *Minimum feedback*, FB_{MIN} , and 414 *Maximum feedback*, FB_{MAX}).

★ = factory setting. () = display text [] = value for use in communication via serial communication port

229 Initial ramp

(INITIAL RAMP)

Value:


OFF/000.1s - 360.0 s ★ OFF

Function:

Allows the motor/equipment to be brought up to minimum speed (frequency) at a rate different than the normal Ramp-Up rate (param. 206).

Description of choice:

As an example, vertical pumps and other equipment often have a requirement to not operate below a minimum speed any longer than necessary. Damage and excessive wear can occur when operating below minimum speed (frequency) for too long a period of time. The Initial Ramp is used to quickly accelerate the motor/equipment to minimum speed at which point, the normal Ramp-Up rate (parameter 206) is made active. The range of adjustment of the Initial Ramp is from 000.1 second to 360.0 seconds; adjustable in 0.1 second increments. If this parameter is set to 000.0, OFF is displayed in this parameter, the Initial Ramp is not active, and the normal Ramp-Up is active.



■ Fill Mode

Fill Mode eliminates the occurrence of water hammer associated with the rapid exhausting of air from piping systems (such as Irrigation systems).

The AFD, set for Closed Loop operation uses an adjustable Fill Rate, a "Filled Pressure" setpoint, an operating pressure setpoint, and a pressure feedback.

Fill Mode is available when:

- The VLT 8000 AQUA drive is in **Closed Loop** mode (parameter 100).
- Parameter 230 is **not 0**
- Parameter 420 is set to **NORMAL**

After a start command, Fill Mode operation begins when the AFD reaches minimum frequency - set in parameter 201.

The "Filled" Setpoint - parameter 231 - is actually a setpoint limit. When minimum speed is reached, the pressure feedback is looked at, and the AFD begins to ramp to the "Filled" pressure setpoint at the rate established by Fill Rate parameter 230.

The Fill Rate - parameter 230 - is dimensioned in Units/Second. The Units will be the units selected in parameter 415.

When the pressure feedback equals the "Filled" Setpoint, the control transitions to the operating setpoint (Setpoint 1 - param. 418 or Setpoint 2 - param. 419) and continues operation in standard (normal) "closed loop" mode.


The value to use for the "Filled" Setpoint parameter 231, can be determined by:

1. Use the DISPLAY MODE key on the LCP to display **FEEDBACK 1**. **IMPORTANT!** Be sure that you have selected the UNITS in parameter 415 before this step.
2. Operate the VLT 8000 AQUA in **HAND** mode and slowly advance the speed to fill the pipe while being careful not to create a water hammer.
3. An observer at the end of the pipe must be able to report when the pipe is filled.
4. At that instant, stop the motor, and observe the value of pressure feedback (have the LCP display set to observe the feedback before starting).
5. The value of feedback in step 4) is the value to use in parameter 231 - "Filled" Setpoint.

The value to set in parameter 230 - Fill Rate can be supplied by the system engineer from proper calculation or from experience, or it can be determined experimentally by performing numerous fill mode sequences and either increasing or decreasing the value of this parameter to obtain the fastest fill without causing a water hammer.

The **Fill Mode** is also beneficial when bringing the motor to a stop as it prevents sudden changes in pressure and flow which could also cause a water hammer.

★ = factory setting. () = display text [] = value for use in communication via serial communication port



230 Fill Rate

(FILL RATE)

Value:

OFF/000000.001 - 999999.999 (units/s) - ★ OFF

Function:

Establishes the rate at which the pipe is filled.

Description of choice:

The dimension of this parameter is Units/Second. The Units will be the value selected in parameter 415. As an example, the Units could be Bar, or MPa, or PSI, etc. If Bar is the selected unit in parameter 415, then the number set in this parameter (230) would be dimensioned as Bar/Second. Changes to this parameter can be made in steps of .001 units.

231 Filled Setpoint

(FILLED SETPOINT)

Value:

Param. 413 - Param. 205 - ★ Param. 413

Function:


The value set in this parameter corresponds to the pressure that exists at the pressure sensor when the pipe is filled.

Description of choice:

The Units of this parameter correspond to the units selected in Parameter 415. The minimum value of this parameter is $F_{b_{min}}$ (param. 413). The maximum value for this parameter is Ref_{max} (param. 205). The setpoint can be changed in .01 steps.



★ = factory setting. () = display text [] = value for use in communication via serial communication port

Inputs and outputs 300-328



In this parameter group, the functions that relate to the input and output terminals of the AFD are defined. The digital inputs (terminals 16, 17, 18, 19, 27, 29, 32 and 33) are programmed in parameters 300-307.

The table below gives the options for programming the inputs. The digital inputs require a signal of 0 or 24 V DC. A signal lower than 5 V DC is a logic '0', while a signal higher than 10 V DC is a logic '1'. The terminals for the digital inputs can be connected to the internal 24 V DC supply, or an external 24 V DC supply can be connected. The drawings in the next column show one Setup using the internal 24 V DC supply and one Setup using an external 24 V DC supply.



Switch 4, which is located on the Dip switch control card,

is used for separating the common potential of the internal 24 V DC supply from the common potential of the external 24 V DC supply. See *Electrical installation*.

Please note that when Switch 4 is in the OFF position, the external 24 V DC supply is galvanically isolated from the AFD.

| Digital inputs | Terminal no. | 16 | 17 | 18 | 19 | 27 | 29 | 32 | 33 |
|----------------------------------|------------------------|------|------|------|-----|------|-------|------|------|
| | parameter | 300 | 301 | 302 | 303 | 304 | 305 | 306 | 307 |
| Value: | | | | | | | | | |
| No function | (NO OPERATION) | [0] | [0] | [0] | [0] | | [0] | [0]★ | [0]★ |
| Reset | (RESET) | [1]★ | [1] | | | | [1] | [1] | [1] |
| Coasting stop, inverse | (COAST INVERSE) | | | | | | [0]▼ | | |
| Reset and coasting stop, inverse | (RESET & COAST INVERS) | | | | | [1] | | | |
| Start | (START) | | | [1]★ | | | | | |
| Reversing | (REVERSE) | | | | | [1]★ | | | |
| Reverse and start | (START INVERSE) | | | | [2] | | | | |
| DC-braking, inverse | (DC BRAKE INVERSE) | | | | [3] | [2] | | | |
| Safety interlock | (SAFETY INTERLOCK) | | | | | [3]★ | | | |
| Freeze reference | (FREEZE REFERENCE) | [2] | [2]★ | | | | [2] | [2] | [2] |
| Freeze output | (FREEZE OUTPUT) | [3] | [3] | | | | [3] | [3] | [3] |
| Selection of Setup, lsb | (SETUP SELECT LSB) | [4] | | | | | [4] | [4] | |
| Selection of Setup, msb | (SETUP SELECT MSB) | | [4] | | | | [5] | | [4] |
| Preset reference, on | (PRESET REF. ON) | [5] | [5] | | | | [6] | [5] | [5] |
| Preset reference, lsb | (PRESET REF. LSB) | [6] | | | | | [7] | [6] | |
| Preset reference, msb | (PRESET REF. MSB) | | [6] | | | | [8] | | [6] |
| Speed down | (SPEED DOWN) | | [7] | | | | [9] | | [7] |
| Speed up | (SPEED UP) | [7] | | | | | [10] | [7] | |
| Run permissive | (RUN PERMISSIVE) | [8] | [8] | | | | [11] | [8] | [8] |
| Jog | (JOG) | [9] | [9] | | | | [12]★ | [9] | [9] |
| Data change lock | (PROGRAMMING LOCK) | [10] | [10] | | | | [13] | [10] | [10] |
| Pulse reference | (PULSE REFERENCE) | | [11] | | | | [14] | | |
| Pulse feedback | (PULSE FEEDBACK) | | | | | | | | [11] |
| Hand start | (HAND START) | [11] | [12] | | | | [15] | [11] | [12] |
| Auto start | (AUTO START) | [12] | [13] | | | | [16] | [12] | [13] |
| Latched start | (LATCHED START) | | | [2] | | | | | |
| Off stop | (OFF STOP) | | | | | | [17] | [13] | [14] |
| Stop inverse | (STOP INVERSE) | | | | | | [19] | [14] | [15] |

▼ Global default setting

Function:

In parameters 300-307 *Digital inputs* it is possible to choose between the different possible functions related

★ = factory setting. () = display text [] = value for use in communication via serial communication port

to the digital inputs (terminals 16-33). The functional options are given in the table on the previous page.

Description of choice:

No function is selected if the AFD is not to react to signals transmitted to the terminal.

Reset resets the AFD after an alarm; however, not all alarms can be reset (trip locked) cycling line power supply. See table in *List of warnings and alarms*. Reset will be activate on the rising edge of the signal.

Coasting stop, inverse is used to force the AFD to "release" the motor immediately. the output transistors are "turned off" to remove power to the motor, allowing it to coast to stop. Logic "0" implements this mode.

Reset and coasting stop, inverse is used for activating coasting stop at the same time as reset. Logic "0" implements coasting stop and reset. Reset will be activate on the falling edge of the signal.

DC braking, inverse is used for stopping the motor by energizing it with a DC current for a given time, see parameters 114-116 *DC brake*. Please note that this function is only active if the value of parameters 114 *DC brake current* and 115 *DC braking time* is different from 0. Logic '0' implements DC braking. See *DC braking*.

Safety interlock has the same function as *Coasting stop, inverse*, but *Safety interlock* generates the alarm message EXTERNAL FAULT on the display when terminal 27 is logic '0'. The alarm message will also be active via digital outputs 42/45 and relay outputs 1/2, if programmed for *Safety interlock*. The alarm can be reset using a digital input or the [OFF/STOP] key.

Start is selected if a start/stop command is required. Logic "1" = start, logic "0" = stop.

Reversing is used for changing the direction of rotation of the motor shaft. Logic "0" will not implement reversing. Logic "1" will implement reversing. The reversing signal only changes the direction of rotation; it does not activate the start function. It can not be used in *Closed loop*.

Reversing and start is used for start/stop and reversing using the same signal. A start signal via terminal 18 at the same time is not allowed. Is not active together with *Closed loop*.

Freeze reference freezes the present reference. The frozen reference can now only be changed by means of *Speed up* or *Speed down*. The frozen reference is saved after a stop command and in case of line failure.

Freeze output freezes the present output frequency (in Hz). The frozen output frequency can now only be changed by *Speed up* or *Speed down*.



NOTE

If Freeze output is active, the AFD cannot be stopped via terminal 18. The AFD can only be stopped when terminal 27 or terminal 19 has been programmed for *DC braking, inverse*.

Selection of Setup, Isb or **Selection of Setup, msb** enables a choice of one of the four Setups. However, this assumes that parameter 002 *Active Setup* has been set at *Multi Setup* [5].

| | Setup, msb | Setup, Isb |
|---------|------------|------------|
| Setup 1 | 0 | 0 |
| Setup 2 | 0 | 1 |
| Setup 3 | 1 | 0 |
| Setup 4 | 1 | 1 |

Preset reference, on is used for switching between remote reference and preset reference. This assumes that *Remote/preset* [2] has been selected in parameter 210 *Reference type*. Logic "0" = remote references active; logic "1" = one of the four preset references is active in accordance with the table on the next page.

Preset reference, Isb and **Preset reference, msb** enables a choice of one of the four preset references, in accordance with the table below.

| | Preset ref., msb | Preset ref., Isb |
|---------------|------------------|------------------|
| Preset ref. 1 | 0 | 0 |
| Preset ref. 2 | 0 | 1 |
| Preset ref. 3 | 1 | 0 |
| Preset ref. 4 | 1 | 1 |

Speed up and Speed down are selected if digital control of the up/down speed is desired. This function is only active if *Freeze reference* or *Freeze output* has been selected.

As long as there is a logic "1" on the terminal selected for *Speed up*, the reference or the output frequency will increase by the *Ramp-up time* set in parameter 206.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

As long as there is a logic "1" on the terminal selected for *Speed down*, the reference or the output frequency will decrease by the *Ramp-down time* set in parameter 207. Pulses (logic "1" minimum high for 3 ms and a minimum pause of 3 ms) will lead to a change of speed of 0.1% (reference) or 0.1 Hz (output frequency).

Example:

| | Terminal (16) | Terminal (17) | Freeze ref./ Freeze output |
|--------------------|------------------|------------------|-------------------------------|
| No speed change | 0 | 0 | 1 |
| Speed down | 0 | 1 | 1 |
| Speed up | 1 | 0 | 1 |
| Speed down | 1 | 1 | 1 |

The speed reference, frozen via the control panel, can be changed even if the AFD has stopped. In addition, the frozen reference will be remembered in case of a line failure.

Run permissive. There must be an active start signal via the terminal, where *Run permissive* has been programmed, before a start command can be accepted. *Run permissive* has a logic 'AND' function related to Start (terminal 18, parameter 302 *Terminal 18, Digital input*), which means that in order to start the motor, both conditions must be fulfilled. If *Run permissive* is programmed on several terminals, *Run permissive* must only be logic "1" on one of the terminals for the function to be carried out.

Jog is used to override the output frequency to the frequency set in parameter 209 *Jog frequency* and issue a start command. If local reference is active, the AFD will always be in *Open loop* [0], regardless of the selection made in parameter 100 *Configuration*. Jog is not active if a stop command has been given via terminal 27.

Data change lock is selected if data changes to parameters are not to be made via the control unit; however, it will still be possible to carry out data changes via the bus.

Pulse reference is selected if a pulse sequence (frequency) is selected as a reference signal. 0 Hz corresponds to Ref_{MIN} , parameter 204 *Minimum reference, Ref_{MIN}*. The frequency set in parameter 327 *Pulse reference, max. frequency* corresponds to parameter 205 *Maximum reference, Ref_{MAX}*.

Pulse feedback is selected if a pulse sequence (frequency) is selected as a feedback signal. Parameter 328 *Pulse feedback, max. frequency* is where the maximum frequency for pulse feedback is set.

Hand start is selected if the AFD is to be controlled by means of an external hand/off or H-O-A switch. A logic '1' (Hand start active) will mean that the AFD starts the motor. A logic "0" means that the connected motor stops. The AFD will then be in OFF/STOP mode, unless there is an active *Auto start signal*. See also the description in *Local control*.



NOTE

An active Hand and Auto signal via the digital inputs will have higher priority than the [HAND START]-[AUTO START] control keys.

Auto start is selected if the AFD is to be controlled via an external auto/off or H-O-A switch. A logic '1' will place the AFD in auto mode allowing a start signal on the control terminals or the serial communication port. If *Auto start* and *Hand start* are active at the same time on the control terminals, *Auto start* will have the highest priority. If *Auto start* and *Hand start* are not active, the connected motor will stop and the AFD will then be in OFF/STOP mode. See also the description in *Local control*.

Latched start will start the motor if a pulse is applied for a minimum of 3 ms, provided there is no stop command active. The motor will stop if *Stop Inverse* is briefly activated.

Off stop is used for stopping the connected motor. The stop will be affected in accordance with the selected ramp (par. 206 and 207).

Stop inverse is activated by interrupting the voltage to the terminal. This means that if the terminal has no voltage, the motor cannot run. The stop will be effected in accordance with the selected ramp (parameters 206 and 207).



None of the above-mentioned stop commands (start-disable) are to be used as disconnection switch in connection with repairs. Cut line instead.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

■ Analog inputs

Two analog inputs for voltage signals (terminals 53 and 54) are provided for reference and feedback signals. Furthermore, an analog input is available for a current signal (terminal 60). A thermistor can be connected to voltage input 53 or 54. The two analog voltage inputs can be scaled in the range of 0-10 V DC; the current input in the range of 0-20 mA.

The table below gives the possibilities for programming the analog inputs. Parameter 317 *Time out* and 318 *Function after time out* allow activation of a time-out function on all analog inputs. If the signal value of the reference or feedback signal connected to one of the analog input terminals drops to below 50% of the minimum scaling, a function will be activated after the time out determined in parameter 318, *Function after time out*.

| Analog inputs | terminal no. | 53(voltage) | 54(voltage) | 60(current) |
|---------------|----------------|-------------|-------------|-------------|
| | parameter | 308 | 311 | 314 |
| Value: | | | | |
| No operation | (NO OPERATION) | [0] | [0]★ | [0] |
| Reference | (REFERENCE) | [1]★ | [1] | [1] ★ |
| Feedback | (FEEDBACK) | [2] | [2] | [2] |
| Thermistor | (THERMISTOR) | [3] | [3] | |

308 Terminal 53, analog input voltage (AI [V] 53 FUNCT.)

Function:

This parameter is used to select the required function to be linked to terminal 53.


Description of choice:

No operation Is selected if the AFD is not to react to signals connected to the terminal.

Reference Is selected to enable change of reference by means of an analog reference signal. If reference signals are connected to several inputs, these reference signals must be added up.

Feedback If a feedback signal is connected, there is a choice of a voltage input (terminal 53 or 54) or a current input (terminal 60) as feedback. In the case of zone regulation, feedback signals must be selected as voltage inputs (terminals 53 and 54). See *Feedback handling*.

Thermistor Is selected if a thermistor integrated in the motor is to be able to stop the AFD in case of motor overtemperature. The cut-out value is 3 kohm. If a motor features a thermal switch instead, this can also be connected to the input. If motors run in parallel, the thermistors/thermal switches can be connected in series (total resistance < 3 kohm). Parameter 117 *Motor thermal protection* must be programmed for *Thermal warning* [1] or *Thermistor trip* [2], and the thermistor must be inserted between terminal 53 or 54 (analog voltage input) and terminal 50 (+10 V supply).



A motor thermistor connected to terminals 53/54 must be double isolated to obtain PELV.

Programming

★ = factory setting. () = display text [] = value for use in communication via serial communication port

309 Terminal 53, min. scaling
(AI 53 SCALE LOW)
Value:

0.0 - 10.0 V ★ 0.0 V
Function:

This parameter is used for setting the signal value that has to correspond to the minimum reference or the minimum feedback, parameter 204 *Minimum reference*, Ref_{MIN} /413 *Minimum feedback*, FB_{MIN} . See *Reference handling* or *Feedback handling*.

Description of choice:

Set the required voltage value.
 For reasons of accuracy, voltage losses in long signal lines can be compensated for.
 If the time-out function is to be applied (parameters 317 *Time out* and 318 *Function after time out*), the value must be set to > 1 V.

310 Terminal 53, max. scaling
(AI 53 SCALE HIGH)
Value:

0.0 - 10.0 V ★ 10.0 V
Function:

This parameter is used for setting the signal value that has to correspond to the maximum reference value or the maximum feedback, parameter 205 *Maximum reference*, Ref_{MAX} /414 *Maximum feedback*, FB_{MAX} . See *Reference handling* or *Feedback handling*.

Description of choice:

Set the required voltage value.
 For reasons of accuracy, voltage losses in long signal lines can be compensated for.

311 Terminal 54, analog input voltage
(AI [V] 54 FUNCT.)
Value:

See description of parameter 308. ★ No operation
Function:

This parameter chooses between the different functions available for the input, terminal 54.

Scaling of the input signal is done in parameter 312 *Terminal 54, min. scaling* and in parameter 313 *Terminal 54, max. scaling*.

Description of choice:

See description of parameter 308.
 For reasons of accuracy, voltage losses in long signal lines should be compensated for.

312 Terminal 54, min. scaling
(AI 54 SCALE LOW)
Value:

0.0 - 10.0 V ★ 0.0 V
Function:

This parameter is used for setting the signal value that corresponds to the minimum reference value or the minimum feedback, parameter 204 *Minimum reference*, Ref_{MIN} /413 *Minimum feedback*, FB_{MIN} . See *Reference handling* or *Feedback handling*.

Description of choice:

Set the required voltage value.
 For reasons of accuracy, voltage losses in long signal lines can be compensated for.
 If the time-out function is to be applied (parameters 317 *Time out* and 318 *Function after time out*), the value must be set to > 1 V.

313 Terminal 54, max. scaling
(AI 54 SCALE HIGH)
Value:

0.0 - 10.0 V ★ 10.0 V
Function:

This parameter is used for setting the signal value that corresponds to the maximum reference value or the maximum feedback, parameter 204 *Minimum reference*, Ref_{MIN} /414 *Maximum feedback*, FB_{MAX} . See *Reference handling* or *Feedback handling*.

Description of choice:

Set the required voltage value.
 For reasons of accuracy, voltage losses in long signal lines can be compensated for.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

314 Terminal 60, analog input current
(AI [MA] 60 FUNCT.)
Value:

See description of parameter 308. ★ Reference

Function:

This parameter allows a choice between the different functions available for the input, terminal 60. Scaling of the input signal is done in parameter 315 *Terminal 60, min. scaling* and in parameter 316 *Terminal 60, max. scaling*.

315 Terminal 60, min. scaling
(AI 60 SCALE LOW)
Value:

0.0 - 20.0 mA ★ 4.0 mA

Function:

This parameter determines the signal value that corresponds to the minimum reference or the minimum feedback, parameter 204 *Minimum reference*, $Ref_{MIN}/413$ *Minimum feedback*, FB_{MIN} . See *Reference handling* or *Feedback handling*.

Description of choice:

Set the required current value.
The time-out function is to be used (parameters 317 *Time out* and 318 *Function after time out*), the value must be set to > 2 mA.

316 Terminal 60, max. scaling
(AI 60 SCALE HIGH)
Value:

0.0 - 20.0 mA ★ 20.0 mA

Function:

This parameter determines the signal value that corresponds to the maximum reference value, parameter 205 *Maximum reference value*, Ref_{MAX} . See *Reference handling* or *Feedback handling*.

Description of choice:

Set the desired current value.

317 Time out
(LIVE ZERO TIME)
Value:

1 - 99 sec. ★ 10 sec.

Function:

If the signal value of the reference or feedback signal connected to one of the input terminals 53, 54 or 60 drops to below 50% of the minimum scaling during a period longer than the preset time, the function selected in parameter 318 *Function after time out* will be activated.

This function will only be active if, in parameter 309 or 312, a value has been selected for *terminals 53 and 54, min. scaling* that exceeds 1 V, or if, in parameter 315 *Terminal 60, min. scaling*, a value has been selected that exceeds 2 mA.

Description of choice:

Set the desired time.

318 Function after time out
(LIVE ZERO FUNCT.)
Value:

| | |
|---|-----|
| ★Off (NO FUNCTION) | [0] |
| Freeze output frequency (FREEZE OUTPUT FREQ.) | [1] |
| Stop (STOP) | [2] |
| Jog (JOG FREQUENCY) | [3] |
| Max. output frequency (MAX FREQUENCY) | [4] |
| Stop and trip (STOP AND TRIP) | [5] |

Function:

This is where to select the function to be activated after the end of the time-out period (parameter 317 *Time out*).

If a time-out function occurs at the same time as a bus time-out function (parameter 556 *Bus time interval function*), the time-out function in parameter 318 will be activated.

Description of choice:

The output frequency of the VLT AFD can be:

- frozen at the present value [1]
- overruled to stop [2]
- overruled to jog frequency [3]
- overruled to max. output frequency [4]
- overruled to stop with subsequent trip [5].

★ = factory setting. () = display text [] = value for use in communication via serial communication port

■ Analog/digital outputs

The two analog/digital outputs (terminals 42 and 45) can be programmed to show the present status or a process value such as 0 - f_{MAX} .

If the AFD is used as a digital output, it gives the present status by means of 0 or 24 V DC. If the analogue output is used for giving a process value, there is a choice of three types of output signals: 0-20 mA, 4-20 mA or 0-32000 pulses

(depending on the value set in parameter 322 *Terminal 45, output, pulse scaling*. If the output is used as a voltage output (0-10 V), a pull-down resistor of 470 Ω (max. 500 Ω) should be fitted to terminal 39 (common for analog/digital outputs). If the output is used as a current output, the resulting impedance of the connected equipment should not exceed 500 Ω .

| Outputs | terminal no. | 42 | 45 |
|--|--------------|-------|-------|
| | parameter | 319 | 321 |
| Value: | | | |
| No function (NO FUNCTION) | | [0] | [0] |
| Drive ready (READY) | | [1] | [1] |
| Standby (ENABLED & NO WARNING) | | [2] | [2] |
| Running (RUNNING) | | [3] | [3] |
| Running at ref. value (RUNNING AT REFERENCE) | | [4] | [4] |
| Running, no warning (RUNNING NO WARNING) | | [5] | [5] |
| Local reference active (DRIVE IN LOCAL REF.) | | [6] | [6] |
| Remote references active (DRIVE IN REMOTE REF.) | | [7] | [7] |
| Alarm (ALARM) | | [8] | [8] |
| Alarm or warning (ALARM OR WARNING) | | [9] | [9] |
| No alarm (NO ALARM) | | [10] | [10] |
| Current limit (CURRENT LIMIT) | | [11] | [11] |
| Safety interlock (SAFETY INTERLOCK) | | [12] | [12] |
| Start command active (START SIGNAL APPLIED) | | [13] | [13] |
| Reversing (REVERSE OPERATION) | | [14] | [14] |
| Thermal warning (THERMAL WARNING) | | [15] | [15] |
| Hand mode active (DRIVE IN HAND MODE) | | [16] | [16] |
| Auto mode active (DRIVE IN AUTO MODE) | | [17] | [17] |
| Sleep mode (SLEEP MODE) | | [18] | [18] |
| Output frequency lower than f_{LOW} parameter 223 (F OUT < F LOW) | | [19] | [19] |
| Output frequency higher than f_{HIGH} parameter 224 (F OUT > F HIGH) | | [20] | [20] |
| Out of frequency range (FREQ. RANGE WARN.) | | [21] | [21] |
| Output current lower than I_{LOW} parameter 221 (I OUT < I LOW) | | [22] | [22] |
| Output current higher than I_{HIGH} parameter 222 (I OUT > I HIGH) | | [23] | [23] |
| Out of current range (CURRENT RANGE WARN.) | | [24] | [24] |
| Out of feedback range (FEEDBACK RANGE WARN.) | | [25] | [25] |
| Out of reference range (REFERENCE RANGE WARN.) | | [26] | [26] |
| Relay 123 (RELAY 123) | | [27] | [27] |
| Mains imbalance (MAINS IMBALANCE) | | [28] | [28] |
| Output frequency, 0 - f_{MAX} 0-20 mA (OUT. FREQ. 0-20 mA) | | [29] | [29] |
| Output frequency, 0 - f_{MAX} 4-20 mA (OUT. FREQ. 4-20 mA) | | [30] | ★[30] |
| Output frequency (pulse sequence), 0 - f_{MAX} 0-32000 p (OUT. FREQ. PULSE) | | [31] | [31] |
| External reference, Ref_{MIN} - Ref_{MAX} 0-20 mA (EXT. REF. 0-20 mA) | | [32] | [32] |
| External reference, Ref_{MIN} - Ref_{MAX} 4-20 mA (EXTERNAL REF. 4-20 mA) | | [33] | [33] |
| External reference (pulse sequence), Ref_{MIN} - Ref_{MAX} 0-32000 p (EXTERNAL REF. PULSE) | | [34] | [34] |
| Feedback, FB_{MIN} - FB_{MAX} 0-20 mA (FEEDBACK 0-20 mA) | | [35] | [35] |
| Feedback, FB_{MIN} - FB_{MAX} 4-20 mA (FEEDBACK 4-20 mA) | | [36] | [36] |
| Feedback (pulse sequence), FB_{MIN} - FB_{MAX} 0 - 32000 p (FEEDBACK PULSE) | | [37] | [37] |
| Output current, 0 - I_{MAX} 0-20 mA (MOTOR CUR. 0- 20 mA) | | [38] | [38] |
| Output current, 0 - I_{MAX} 4-20 mA (MOTOR CUR. 4- 20 mA) | | ★[39] | [39] |
| Output current (pulse sequence), 0 - I_{MAX} 0 - 32000 p (MOTOR CUR. PULSE) | | [40] | [40] |
| Output power, 0 - P_{NOM} 0-20 mA (MOTOR POWER 0-20 mA) | | [41] | [41] |
| Output power, 0 - P_{NOM} 4-20 mA (MOTOR POWER 4-20 mA) | | [42] | [42] |
| Output power (pulse sequence), 0 - P_{NOM} 0- 32000 p (MOTOR POWER PULSE) | | [43] | [43] |
| Bus control, 0.0-100.0% 0-20 mA (BUS CONTROL 0-20 MA) | | [44] | [44] |
| Bus control, 0.0-100.0% 4-20 mA (BUS CONTROL 4-20 MA) | | [45] | [45] |
| Bus control (pulse sequence), 0.0-100.0% 0 - 32.000 Pulses (BUS CONTROL PULS) | | [46] | [46] |
| Motor alteration (MOTOR ALTERATION) | | [50] | [50] |

★ = factory setting. () = display text [] = value for use in communication via serial communication port

Function:

This output can act both as a digital or an analog output. If used as a digital output (data value [0]-[59]), a 0/24 V DC signal is transmitted; if used as an analogue output, either a 0-20 mA signal, a 4-20 mA signal or a pulse sequence of 0-32000 pulses is transmitted.

Description of choice:

No function Selected if the AFD is not to react to signals.

Drive ready The AFD control card receives a supply voltage and the AFD is ready for operation.

Stand by The AFD is ready for operation, but no start command has been given. No warning.

Running A start command has been given.

Running at ref. value Speed according to reference.

Running, no warning A start command has been given. No warning.

Local reference active The output is active when the motor is controlled by means of the local reference via the control unit.

Remote references active The output is active when the AFD is controlled by means of the remote references.

Alarm The output is activated by an alarm.

Alarm or warning The output is activated by an alarm or a warning.

No alarm The output is active when there is no alarm.

Current limit The output current is greater than the value programmed in parameter 215 *Current limit* I_{LIM} .

Safety interlock The output is active when terminal 27 is a logic '1' and Safety interlock has been selected on the input.

Start command active Is active when there is a start command or the output frequency is above 0.1 Hz.

Reversing There is 24 V DC on the output when the motor rotates counter-clockwise. When the motor rotates clockwise, the value is 0 V DC.

Thermal warning The temperature limit in either the motor, the AFD or a thermistor connected to an analogue input has been exceeded.

Hand mode active The output is active when the AFD is in Hand mode.

Auto mode active The output is active when the AFD is in Auto mode.

Sleep mode Active when the AFD is in Sleep mode.

Output frequency lower than f_{LOW} The output frequency is lower than the value set in parameter 223 *Warning: Low frequency, f_{LOW}* .

Output frequency higher than f_{HIGH} The output frequency is higher than the value set in parameter 224 *Warning: High frequency, f_{HIGH}* .

Out of frequency range The output frequency is outside the frequency range programmed in parameter 223 *Warning: Low frequency, f_{LOW}* and 224 *Warning: High frequency, f_{HIGH}* .

Output current lower I_{LOW} The output current is lower than the value set in parameter 221 *Warning: Low current, I_{LOW}* .

Output current higher than I_{HIGH} The output current is higher than the value set in parameter 222 *Warning: High current, I_{HIGH}* .

Out of current range The output current is outside the range programmed in parameter 221 *Warning: Low current, I_{LOW}* and 222 *Warning: High current, I_{HIGH}* .

Out of feedback range The feedback signal is outside the range programmed in parameter 227 *Warning: Low feedback, FB_{LOW}* and 228 *Warning: High feedback, FB_{HIGH}* .

Out of reference range The reference lies outside the range programmed in parameter 225 *Warning: Low reference, Ref_{LOW}* and 226 *Warning: High reference, Ref_{HIGH}* .

Relay 123 This function is only used when a profibus option card is installed.

Mains imbalance This output is activated at too high line imbalance or when a phase is missing in the line supply. Check the line voltage to the AFD.

0-f_{MAX} 0-20 mA and

0-f_{MAX} 4-20 mA and

★ = factory setting. () = display text [] = value for use in communication via serial communication port

0-f_{MAX} 0-32000 p, which generates an output signal proportional to the output frequency in the interval 0 - f_{MAX} (parameter 202 *Output frequency, high limit, f_{MAX}*).

External Ref_{MIN} - Ref_{MAX} 0-20 mA and
External Ref_{MIN} - Ref_{MAX} 4-20 mA and
External Ref_{MIN} - Ref_{MAX} 0-32000 p which generates an output signal proportional to the resulting reference value in the interval *Minimum reference, Ref_{MIN}* - *Maximum reference, Ref_{MAX}* (parameters 204/205).

FB_{MIN}-FB_{MAX} 0-20 mA and
FB_{MIN}-FB_{MAX} 4-20mA and
FB_{MIN}-FB_{MAX} 0-32000 p an output signal proportional to the reference value in the interval *Minimum feedback, FB_{MIN}* - *Maximum feedback, FB_{MAX}* (parameters 413/414) is obtained.

0 - I_{VLT,MAX} 0-20 mA and
0 - I_{VLT,MAX} 4-20 mA and
0 - I_{VLT,MAX} 0-32000 p, an output signal proportional to the output current in the interval 0 - I_{VLT,MAX} is obtained.

0 - p_{NOM} 0-20 mA and
0 - p_{NOM} 4-20 mA and
0 - p_{NOM} 0-32000 p, which generates an output signal proportional to the present output power. 20 mA corresponds to the value set in parameter 102 *Motor power, P_{M,N}*.

0.0 - 100.0% 0 - 20 mA and

0.0 - 100.0% 4 - 20 mA and

0.0 - 100.0% 0 - 32.000 pulses which generates an output signal proportional to the value (0.0-100.0%) received by serial communication. Writing from Serial communication is done to parameter 364 (terminal 42) and 365 (terminal 45). This function is limited to the following protocols: FC bus, Profibus, LonWorks FTP, DeviceNet, and Modbus RTU.

Motor alternation A relay or digital output can be used in conjunction with output contactors to alternate the AFD's output between motors based on an internal timer. See parameters 433 and 434 for further information and programming information.

320 Terminal 42, output, pulse scaling
(AO 42 PULS SCALE)
Value:


1 - 32000 Hz ★ 5000 Hz

Function:

This parameter allows scaling of the pulse output signal.

Description of choice:

Set the desired value.


321 Terminal 45, output
(AO 45 FUNCTION)
Value:

See description of parameter 319 *Terminal 42, Output*.

Function:

This output can function both as a digital or an analog output. When used as a digital output (data value [0]-[26]) it generates a 24 V (max. 40 mA) signal. For the analog outputs (data value [27] - [41]) there is a choice of 0-20 mA, 4-20 mA or a pulse sequence.

Description of choice:

See description of parameter 319 *Terminal 42, Output*.

322 Terminal 45, output, pulse scaling
(AO 45 PULS SCALE)
Value:

1 - 32000 Hz ★ 5000 Hz

Function:

This parameter allows scaling of the pulse output signal.



Description of choice:

Set the desired value.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

■ Relay outputs

Relay outputs Relay outputs 1 and 2 can be used to give the present status or a warning.



| Relay Outputs | terminal no. | 1 | 2 |
|--|--------------|-------|------|
| | parameter | 323 | 326 |
| Value: | | | |
| No function (NO FUNCTION) | | [0] | [0] |
| Ready signal (READY) | | [1] | [1] |
| Standby (STAND BY) | | [2] | [2] |
| Running (RUNNING) | | [3] | ★[3] |
| Running at ref. value (RUNNING AT REFERENCE) | | [4] | [4] |
| Running, no warning (RUNNING NO WARNING) | | [5] | [5] |
| Local reference active (DRIVE IN LOCAL REF) | | [6] | [6] |
| Remote references active (DRIVE IN REMOTE REF.) | | [7] | [7] |
| Alarm (ALARM) | | [8] | [8] |
| Alarm or warning (ALARM OR WARNING) | | [9] | [9] |
| No alarm (NO ALARM) | | ★[10] | [10] |
| Current limit (CURRENT LIMIT) | | [11] | [11] |
| Safety interlock (SAFETY INTERLOCK) | | [12] | [12] |
| Start command active (START SIGNAL APPLIED) | | [13] | [13] |
| Reversing (RUNNING IN REVERSE) | | [14] | [14] |
| Thermal warning (THERMAL WARNING) | | [15] | [15] |
| Hand mode active (DRIVE IN HAND MODE) | | [16] | [16] |
| Auto mode active (DRIVE IN AUTO MODE) | | [17] | [17] |
| Sleep mode (SLEEP MODE) | | [18] | [18] |
| Output frequency lower than f_{LOW} parameter 223 (F OUT < F LOW) | | [19] | [19] |
| Output frequency higher than f_{HIGH} parameter 224 (F OUT > F HIGH) | | [20] | [20] |
| Out of frequency range (FREQ RANGE WARN.) | | [21] | [21] |
| Output current lower than I_{LOW} parameter 221 (I OUT < I LOW) | | [22] | [22] |
| Output current higher than I_{HIGH} parameter 222 (I OUT > I HIGH) | | [23] | [23] |
| Out of current range (CURRENT RANGE WARN.) | | [24] | [24] |
| Out of feedback range (FEEDBACK RANGE WARN.) | | [25] | [25] |
| Out of reference range (REFERENCE RANGE WARN.) | | [26] | [26] |
| Relay 123 (RELAY 123) | | [27] | [27] |
| Mains imbalance (MAINS IMBALANCE) | | [28] | [28] |
| Control word 11/12 (CONTROL WORD 11/12) | | [29] | [29] |
| Motor alteration (MOTOR ALTERATION) | | [30] | [30] |

Function:

Description of choice:

See description of [0] - [28] in *Analog/digital outputs*.

Control word bit 11/12. Relay 1 and relay 2 can be activated via the serial communication. Bit 11 activates relay 1 and bit 12 activates relay 2.

If the parameter 556 *Bus time interval function* becomes active, relay 1 and relay 2 will become cut off if they are activated via the serial communication.

Motor Alteration. The output is controlled by a timer to activate alternate available run time between multiple motors.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

323 Relay 1, output function

(RELAY1 FUNCTION)

Function:

This output activates a relay switch. Relay switch 01 can be used for indicating status and warnings. The relay is activated when the conditions for the relevant data values have been fulfilled.

Activation/deactivation can be programmed in parameter 324 *Relay 1, ON delay* and parameter 325 *Relay 1, OFF delay*.

See *General technical data*.

Description of choice:

See data choice and connections in *Relay outputs*.

324 Relay 01, ON delay

(RELAY1 ON DELAY)

Value:

0 - 600 sec. ★ 0 sec.

Function:

This parameter allows a delay of the cut-in time of relay 1 (terminals 1-2).

Description of choice:

Enter the desired value.

325 Relay 01, OFF delay

(RELAY1 OFF DELAY)

Value:

0 - 600 sec. ★ 2 sec.

Function:

This parameter makes it possible to delay the cut-out time of relay 01 (terminals 1-2).

Description of choice:

Enter the desired value.

326 Relay 2, output function

(RELAY2 FUNCTION)

Value:

See functions of relay 2 on previous page.

Function:

This output activates a relay switch. Relay switch 2 can be used for indicating status and warnings. The relay is activated when the conditions for the relevant data values have been fulfilled.

See *General technical data*.

Description of choice:

See data choice and connections in *Relay outputs*.

327 Pulse reference, max. frequency

(PULSE REF. MAX)

Value:

100 - 65000 Hz at terminal 29 ★ 5000 Hz
 100 - 5000 Hz at terminal 17

Function:

This parameter is used to set the pulse value that must correspond to the maximum reference, parameter 205 *Maximum reference, Ref_{MAX}*.

The pulse reference signal can be connected via terminal 17 or 29.

Description of choice:

Set the required maximum pulse reference.

328 Pulse feedback, max. frequency

(PULSE FDBK MAX.)

Value:

100 - 65000 Hz at terminal 33 ★ 25000 Hz

Function:

This is where the pulse value that must correspond to the maximum feedback value is set. The pulse feedback signal is connected via terminal 33.

Description of choice:

Set the desired feedback value.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

364 Terminal 42, bus control**(CONTROL OUTPUT 42)****365 Terminal 45, bus control****(CONTROL OUTPUT 45)****Value:**

0.0 - 100 %


★ 0

Function:

Through serial communication, a value between 0.1 and 100.0 is written to the parameter.

The parameter is hidden and cannot be seen from the LCP.

■ Application functions 400-434



Includes this parameter group, the special functions of the AFD PID regulation, setting of the feedback range and the Setup of the Sleep mode function.

Additionally, this parameter group includes:

- Reset function.
- Flying start.
- Option of interference reduction method.
- Setup of any function upon loss of load, e.g. because of a damaged V-belt.
- Setting of switching frequency.
- Selection of process units.

**400 Reset function
(RESET FUNCTION)**

Value:

- | | |
|---|-----|
| ★ Manual reset (MANUAL RESET) | [0] |
| Automatic reset x 1 (AUTOMATIC X 1) | [1] |
| Automatic reset x 2 (AUTOMATIC X 2) | [2] |
| Automatic reset x 3 (AUTOMATIC X 3) | [3] |
| Automatic reset x 4 (AUTOMATIC X 4) | [4] |
| Automatic reset x 5 (AUTOMATIC X 5) | [5] |
| Automatic reset x 10 (AUTOMATIC X 10) | [6] |
| Automatic reset x 15 (AUTOMATIC X 15) | [7] |
| Automatic reset x 20 (AUTOMATIC X 20) | [8] |
| Infinite automatic reset (INFINITE AUTOMATIC) | [9] |

Function:

This parameter allows a choice of whether to reset and restart manually after a trip, or whether the AFD is to be reset and restarted automatically. In addition, there is a choice of the number of times the unit is to attempt a restart. The time between each reset attempt is set in parameter 401 *Automatic restart time*.

Description of choice:

If *Manual reset* [0] is selected, resetting must be effected via the "Reset" key or via a digital input. If the AFD is to carry out an automatic reset and restart after a trip, select data value [1]-[9].



The motor may start without warning.

**401 Automatic restart time
(AUTORESTART TIME)**

Value:

0 - 600 sec. ★ 10 sec.

Function:

This parameter allows setting of the time from tripping until the automatic reset function begins. It is assumed that automatic reset has been selected in parameter 400 *Reset function*.

Description of choice:

Set the desired time.

**402 Flying start
(FLYING START)**

Value:

- | | |
|---|-----|
| ★ Disable (DISABLE) | [0] |
| Enable (ENABLE) | [1] |
| DC brake and start (DC BRAKE AND START) | [3] |

Function:

This function makes it possible for the AFD to "catch" a spinning motor, which - e.g. because of a line failure - is no longer controlled by the AFD. This function is activated whenever a start command is active. For the VLT AFD to be able to "catch" the spinning motor, the motor speed must be lower than the frequency that corresponds to the frequency in parameter 202 *Output frequency high limit*, *f_{MAX}*.

Description of choice:

Select *Disable* [0] if this function is not required. Select *Enable* [1] if the AFD is to be able to "catch" and control a spinning motor. Select *DC brake and start* [2] if the VLT AFD is to brake the motor with DC braking, and then restart the motor. It is assumed that parameters 114-116 *DC braking* are enabled. In the case of a substantial "windmilling" effect (spinning motor), the AFD will not "catch" a spinning motor unless *DC brake and start* has been selected.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

■ Sleep mode

Sleep mode makes it possible to stop the motor when it is running at low speed, similar to a no load situation. If consumption in the system goes back up, the AFD will start the motor and supply the power required.



NOTE

Energy can be saved with this function, since the motor is only in operation when the system needs it.

Sleep mode is not active if *Local reference* or *Jog* has been selected

The function is active in both *Open loop* and *Closed loop*.

In parameter 403 *Sleep mode timer*, the Sleep mode is activated. In parameter 403 *Sleep mode timer*, a timer is set that determines how long the output frequency can be lower than the frequency set in parameter 404 *Sleep frequency*. When the timer runs out, the AFD will ramp down the motor to stop via parameter 207 *Ramp-down time*. If the output frequency rises above the frequency set in parameter 404 *Sleep frequency*, the timer is reset.

While the AFD has stopped the motor in sleep mode, a theoretical output frequency is calculated on the basis of the reference signal. When the theoretical output frequency rises above the frequency in parameter 405 *Wake up frequency*, the AFD will restart the motor and the output frequency will ramp up to the reference.


In systems with constant pressure regulation, it is advantageous to provide extra pressure to the system before the AFD stops the motor. This extends the time during which the AFD has stopped the motor and helps to avoid frequent starting and stopping of the motor, e.g. in the case of system leaks.

If 25% more pressure is required before the AFD stops the motor, parameter 406 *Boost setpoint* is set to 125%. Parameter 406 *Boost setpoint* is only active in *Closed loop*.



NOTE

In highly dynamic pumping processes, it is recommended to switch off the *Flying Start* function (parameter 402).



17501346.14

Programming

★ = factory setting. () = display text [] = value for use in communication via serial communication port

403 Sleep mode timer
(SLEEP MODE TIMER)
Value:

0 - 300 sec.(OFF) ★ OFF

Function:

This parameter enables the AFD to stop the motor if the load on the motor is minimal. The timer in parameter 403 *Sleep mode timer* starts when the output frequency drops below the frequency set in parameter 404 *Sleep frequency*. When the time set in the timer has expired, the AFD will turn off the motor. The AFD will restart the motor, when the theoretical output frequency exceeds the frequency in parameter 405 *Wake up frequency*.

Description of choice:

Select OFF if this function is not wanted. Set the threshold value that is to activate Sleep mode after the output frequency has fallen below parameter 404 *Sleep frequency*.

404 Sleep frequency
(SLEEP FREQUENCY)
Value:

 000,0 - par. 405 *Wake up frequency* ★ 0.0 Hz

Function:

When the output frequency falls below the preset value, the timer will start the time count set in parameter 403 *Sleep mode*. The present output frequency will follow the theoretical output frequency until f_{MIN} is reached.

Description of choice:

Set the required frequency.

405 Wake up frequency
(WAKEUP FREQUENCY)
Value:

 Par 404 *Sleep frequency* - par. 202 f_{MAX} ★ 50 Hz

Function:

When the theoretical output frequency exceeds the preset value, the AFD restarts the motor.

Description of choice:

Set the required frequency.

406 Boost setpoint
(BOOST SETPOINT)
Value:

1 - 200 % ★ 100 % of setpoint

Function:

This function can only be used if *Closed loop* has been selected in parameter 100. In systems with constant pressure regulation, it is advantageous to increase the pressure in the system before the AFD stops the motor. This extends the time during which the AFD stops the motor and helps to avoid frequent starting and stopping of the motor, e.g. in the case of leaks in the water supply system.

Description of choice:

Set the required *Boost setpoint* as a percentage of the resulting reference under normal operation. 100% corresponds to the reference without boost (supplement).

407 Switching frequency
(SWITCHING FREQ.)
Value:

Depends on the size of the unit.

Function:

The preset value determines the switching frequency of the inverter, provided *Fixed switching frequency* [1] has been selected in parameter 408 *Interference reduction method*. If the switching frequency is changed, this may help to minimise possible acoustic noise from the motor.


NOTE

The output frequency of the AFD can never assume a value higher than 1/10 of the switching frequency.

Description of choice:

When the motor is running, the switching frequency is adjusted in parameter 407 *Switching frequency*,

★ = factory setting. () = display text [] = value for use in communication via serial communication port

until the frequency has been achieved at which the motor is as quiet as possible.



NOTE

Switching frequencies higher than 4.5 kHz implement automatic derating of the maximum output of the AFD. See *Derating of high switching frequency*.

408 Interference reduction method (NOISE REDUCTION)

Value:

| | |
|---|-----|
| ★ASFM (ASFM) | [0] |
| Fixed switching frequency (FIXED SWITCHING FREQ.) | [1] |
| LC filter fitted (LC-FILTER CONNECTED) | [2] |

Function:

Used to select different methods for reducing the amount of acoustic interference from the motor.

Description of choice:

ASFM [0] guarantees that the maximum switching frequency, determined by parameter 407, is used at all times without derating of the AFD. This is done by monitoring the load.
Fixed switching frequency [1] makes it possible to set a fixed high/low switching frequency. This can generate the best result, as the switching frequency can be set to reduce acoustic noise in the motor. The switching frequency is adjusted in parameter 407 *Switching frequency*. *LC-filter fitted* [2] is to be used if an LC-filter is fitted between the AFD and the motor, as the AFD will otherwise not be able to protect the LC-filter.

409 Function in case of no load (FUNCT. LOW CURR.)

Value:

| | |
|--------------------|-----|
| Trip (TRIP) | [0] |
| ★Warning (WARNING) | [1] |

Function:

This function is activated when the output current goes below parameter 221 *Warning: Low current*.

Description of choice:

In the case of a *Trip* [1], the AFD will stop the motor.

If *Warning* [2] is selected, the AFD will give a warning if the output current drops below the threshold value in parameter 221 *Warning: Low current, I_{LOW}*.

410 Function at line failure (MAINS FAILURE)

Value:

| | |
|---|-----|
| ★Trip (TRIP) | [0] |
| Autoderate & warning (AUTODERATE & WARNING) | [1] |
| Warning (WARNING) | [2] |

Function:

Select the function which is to be activated if the line imbalance becomes too high or if a phase is missing.

Description of choice:

At *Trip* [0] the AFD will stop the motor within a few seconds (depending on drive size).
 If *Autoderate & warning* [1] is selected, the drive will export a warning and reduce the output current to 30 % of $I_{VLT,N}$ to maintain operation.
 At *Warning* [2] only a warning will be exported when a line failure occurs, but in severe cases, other extreme conditions might result in a trip.



NOTE

If *Warning* has been selected, the life expectancy of the drive will be reduced when the line failure persists.



NOTE

At phase loss the cooling fans cannot be powered and the AFD might trip on overheating. This applies to

IP 20/NEMA 1

- VLT 8042-8062, 200-240 V
- VLT 8152-8600, 380-480 V
- VLT 8100-8300, 525-600 V

IP 54

- VLT 8006-8062, 200-240 V
- VLT 8016-8600, 380-480 V
- VLT 8016-8300, 525-600 V

★ = factory setting. () = display text [] = value for use in communication via serial communication port

411 Function at overtemperature
(FUNCT. OVERTEMP)
Value:

| | |
|--|-----|
| ★ Trip (TRIP) | [0] |
| Autoderate & warning (AUTODERATE & WARNING) | [1] |

Function:

Select the function which is to be activated when the AFD is exposed to an overtemperature condition.

Description of choice:

At *Trip* [0] the AFD will stop the motor and export an alarm.

At *Autoderate & warning* [1] the AFD will first reduce the switching frequency to minimize internal losses. If the overtemperature condition persists, the AFD will reduce the output current until the heat sink temperature stabilizes. When the function is active, a warning will be exported.

412 Trip delay overcurrent, I_{LIM} ()
(OVERLOAD DELAY)
Value:

0 - 60 sec. (61=OFF) ★ 61 sec. (OFF)

Function:

When the AFD registers that the output current has reached the current limit I_{LIM} (parameter 215 *Current limit*) and stays there for the duration selected, a cut-out will be performed.

Description of choice:

Select for how long the AFD is to be able to keep up with the output current at the current limit I_{LIM} before it cuts out.

In OFF mode, parameter 412 *Trip delay overcurrent, I_{LIM}* is inactive, i.e. cut-outs are not performed.

413/414 *Minimum/Maximum feedback*, and the unit (°C, °F) in parameter 415 *Process units*.

413 Minimum feedback , FB_{MIN}
(MIN. FEEDBACK)
Value:

-999,999.999 - FB_{MAX} ★ 0.000

Function:

Parameters 413 *Minimum feedback, FB_{MIN}* and 414 *Maximum feedback, FB_{MAX}* are used to scale the display indication, thereby ensuring that it shows the feedback signal in a process unit proportionally to the signal at the input.

Description of choice:

Set the value to be shown on the display at minimum feedback signal value (par. 309, 312, 315 *Min. scaling*) on the selected feedback input (parameters 308/311/314 *Analog inputs*).

414 Maximum feedback, FB_{MAX}
(MAX. FEEDBACK)
Value:

FB_{MIN} - 999,999.999 ★ 100.000

Function:

See the description of par. 413 *Minimum feedback, FB_{MIN}* .

Description of choice:

Set the value to be shown on the display when maximum feedback (par. 310, 313, 316 *Max. scaling*) has been achieved at the selected feedback input (parameters 308/311/314 *Analog inputs*).

■ Feedback signals in open loop

Normally, feedback signals and thus feedback parameters are only used in *Closed loop operation*; in VLT 8000 AQUA units, however, the feedback parameters are also active in *Open loop* operation. In *Open loop mode*, the feedback parameters can be used to show a process value in the display. If the present temperature is to be displayed, the temperature range can be scaled in parameters

★ = factory setting. () = display text [] = value for use in communication via serial communication port

415 Units relating to closed loop
(REF. / FDBK. UNIT)

| | | | |
|---------------------|------|----------------------|------|
| No unit | [0] | °C | [21] |
| ★% | [1] | GPM | [22] |
| rpm | [2] | gal/s | [23] |
| ppm | [3] | gal/min | [24] |
| pulse/s | [4] | gal/h | [25] |
| l/s | [5] | lb/s | [26] |
| l/min | [6] | lb/min | [27] |
| l/h | [7] | lb/h | [28] |
| kg/s | [8] | CFM | [29] |
| kg/min | [9] | ft ³ /s | [30] |
| kg/h | [10] | ft ³ /min | [31] |
| m ³ /s | [11] | ft ³ /h | [32] |
| m ³ /min | [12] | ft/s | [33] |
| m ³ /h | [13] | in wg | [34] |
| m/s | [14] | ft wg | [35] |
| mbar | [15] | PSI | [36] |
| bar | [16] | lb/in ² | [37] |
| Pa | [17] | HP | [38] |
| KPa | [18] | °F | [39] |
| mWG | [19] | | |
| kW | [20] | | |

Function:

Selection of unit to be shown on the display. This unit will be used if *Reference [unit]* [2] or *Feedback [unit]* [3] has been selected in one of the parameters 007-010, as well as in the Display mode. In *Closed loop*, the unit is also used as a unit for *Minimum/Maximum reference* and *Minimum/ Maximum feedback*, as well as Setpoint 1 and Setpoint 2.

Description of choice:

Select the required unit for the reference/feed-back signal.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

■ PID for process control

The PID controller maintains a constant process condition (pressure, temperature, flow, etc.) and adjusts motor speed on the basis of a reference/setpoint and the feedback signal.

A transmitter supplies the PID controller with a feedback signal from the process to indicate its actual state. The feedback signal varies with the process load. This means that deviations occur between the reference/setpoint and the actual process state. Such deviations are evened out by the PID regulator, in that it regulates the output frequency up or down in relation to the deviation between the reference/setpoint and the feedback signal.

The integral PID regulator in VLT 8000 AQUA units have been optimised for use in water applications. This means that a number of specialised functions are available in VLT 8000 AQUA units.

Using the VLT 8000 AQUA, there is no need for extra modules to be installed. For example, only one required reference/setpoint and the handling of feedback need to be programmed.

There is a built in option for connecting two feed-back signals to the system.

Correction for voltage losses in long signal cables can be carried out when using a transmitter with a voltage output. This is done in parameter group 300 *Min./Max.scaling*.

Feedback

The feedback signal must be connected to a terminal on the AFD. Use the list below to decide which terminal to use and which parameters to program.

| <u>Feedback type</u> | <u>Terminal</u> | <u>Parameters</u> |
|----------------------|-----------------|-----------------------------------|
| Pulse | 33 | 307 |
| Voltage | 53, 54 | 308, 309, 310 or 311, 312, 313 |
| Current | 60 | 314, 315, 316 |
| Bus feedback 1 | 68+69 | 535 |
| Bus feedback 2 | 68+69 | 536 |

Please note that the feedback value in parameter 535/536 Bus feedback 1 and 2 can only be set via serial communication (not via the control unit).

Furthermore, the minimum and maximum feedback (parameters 413 and 414) must be set to a value in the process unit that corresponds to the minimum and maximum scaling value for signals connected to the terminal. The process unit is selected in parameter 415 *Process units*.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

Reference

In parameter 205 *Maximum reference*, Ref_{MAX} , a maximum reference that scales the sum of all references, i.e. the resulting reference, can be set. The *minimum reference* in parameter 204 indicates the smallest value that the resulting reference can assume. The reference range cannot exceed the feedback range. If *Preset references* are required, set these in parameters 211 to 214 *Preset reference*. See *Reference type*. See also *Reference handling*.

If a current signal is used as a feedback signal, voltage can be used as analog reference. Use the list below to decide which terminal to use and which parameters to program.

| <u>Reference type</u> | <u>Terminal</u> | <u>Parameters</u> |
|-----------------------|-----------------|-----------------------------------|
| Pulse | 17 or 29 | 301 or 305 |
| Voltage | 53 or 54 | 308, 309, 310 or 311, 312, 313 |
| Current | 60 | 314, 315, 316 |
| Preset reference | | 211, 212, 213, 214 |
| Setpoints | | 418, 419 |
| Bus reference | 68+69 | |

Please note that the bus reference can only be set via serial communication.



NOTE

Terminals that are not in use may preferably be set to *No function* [0].

Inverse regulation

Normal regulation means that the motor speed increases when the reference/setpoint is higher than the feedback signal. If there is a need for inverse regulation, in which the speed is reduced when the feedback signal is lower than the reference/setpoint, Inverse must be programmed in parameter 420 *PID normal/inverse control*.

Anti Windup

The process regulator is factory preset with an active anti-windup function. This function ensures that when either a frequency limit, current limit or voltage limit is reached, the integrator will be initialised for a frequency that corresponds to the present output frequency. This avoids integration on a deviation between the reference/setpoint and the actual state of the process, the controller of which is not possible by means of a speed change. This function can be disabled in parameter 421 *PID anti windup*.

Start-up conditions

In some applications, optimum setting of the process regulator will mean that it takes an excessive time for the required process state to be reached. In such applications it might be an advantage to fix an output frequency to which the AFD is to bring the motor before the process regulator is activated. This is done by programming a *PID start-up frequency* in parameter 422.

Differentiator gain limit

If there are very quick variations in a given application with respect to the reference/setpoint signal or the feedback signal, the deviation between reference/setpoint and the actual process state will quickly change. The differentiator may thus become too dominant. This is because it reacts to the deviation between the reference/setpoint and the actual process state. The quicker the deviation changes, the stronger the resulting differentiator frequency contribution. The differentiator frequency contribution can thus be limited to allow the setting of a reasonable differentiation time for slow changes and a suitable frequency contribution for quick changes. This is done in parameter 426, *PID Differentiator gain limit*.

Lowpass filter

If there are ripple currents/voltages on the feedback signal, these can be dampened by means of a built-in lowpass filter. Set a suitable lowpass filter time constant. This time constant represents the limit frequency of the ripples occurring on the feedback signal.

If the lowpass filter has been set to 0.1s, the limit frequency will be 10 RAD/sec., corresponding to $(10 / 2 \times \pi) = 1.6$ Hz. This means that all currents/voltages that vary by more than 1.6 oscillations per second will be removed by the filter.

In other words, regulation will only be carried out on a feedback signal that varies by a frequency of less than 1.6 Hz. Choose a suitable time constant in parameter 427, *PID Lowpass filter time*.

Optimisation of the process regulator

The basic settings have now been made; all that remains to be done is to optimize the proportional gain, the integration time and the differentiation time (parameters 423, 424 and 425). In most processes, this can be done by following the guidelines given below.

1. Start the motor.
2. Set parameter 423 *PID proportional gain* to 0.3 and increase it until the process shows that the feedback signal is unstable. Then reduce the value until the feedback signal has stabilised. Now lower the proportional gain by 40-60%.
3. Set parameter 424 *PID integration time* to 20 s and reduce the value until the process shows that the feedback signal is unstable. Increase the integration time until the feedback signal stabilizes, followed by an increase of 15-50%.
4. Parameter 425 *PID differentiation time* is only used in very fast-acting systems. The typical value is 1/4 of the value set in parameter 424 *PID Integration time*. The differentiator should only be used when the setting of the proportional gain and the integration time have been fully optimized.




NOTE

If necessary, start/stop can be activated a number of times in order to provoke an unstable feedback signal.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

■ PID overview

The block diagram below shows reference and setpoint in relation to the feedback signal.



As can be seen, the remote reference is totalled with setpoint 1 or setpoint 2. See also *Reference handling*. Which setpoint is to be totalled with the

remote reference depends on the selection made in parameter 417 *Feedback function*.

■ Feedback handling

The feedback handling can be seen from the block diagram on the next page.

The block diagram shows how and by which parameters the feedback handling can be affected. Options as feedback signals are: voltage, current, pulse and bus feedback signals. In zone regulation, feedback signals must be selected as voltage inputs (terminals 53 and 54). Please note that *Feedback 1* consists of bus feedback 1 (parameter 535) totalled with the feedback signal value of terminal 53. *Feedback 2* consists of bus feedback 2 (parameter 536) totalled with the feedback signal value of terminal 54.

In addition, the AFD has an integral calculator capable of converting a pressure signal into a "linear flow" feedback signal. This function is activated in parameter 416 *Feedback conversion*.

The parameters for feedback handling are active both in closed and open loop modes. In *open loop*, the present temperature can be displayed by connecting a temperature transmitter to a feedback input.

In a closed loop, there are - roughly speaking - three possibilities of using the integral PID regulator and set-point/ feedback handling:

1. 1 setpoint and 1 feedback

★ = factory setting. () = display text [] = value for use in communication via serial communication port

2. 1 setpoint and 2 feedbacks
3. 2 Setpoints and 2 feedbacks

1 setpoint and 1 feedback


If only 1 setpoint and 1 feedback signal are used, parameter 418 *Setpoint 1* will be added to the remote reference. The sum of the remote reference and *Setpoint 1* becomes the resulting reference, which will then be compared with the feedback signal.

1 setpoint and 2 feedbacks

Just like in the above situation, the remote reference is added to *Setpoint 1* in parameter 418. Depending on the feedback function selected in parameter 417 *Feedback function*, a calculation will be made of the feedback signal with which the sum of the references and the setpoint is to be compared. A description of the individual feedback functions is given in parameter 417 *Feedback function*.

2 Setpoints and 2 feedbacks

Used in 2-zone regulation, where the function selected in parameter 417 *Feedback function* calculates the setpoint to be added to the remote reference.



416 Feedback conversion (FEEDBACK CONV.)


Value:
 ★Linear (LINEAR) [0]
 Square root (SQUARE ROOT) [1]

Function:

In this parameter, a function is selected which converts a connected feedback signal from the process to a feedback value that equals the square root of the connected signal. This is used, e.g. where regulation of a flow (volume) is required on the basis of pressure as feedback signal (flow = constant x $\sqrt{\text{pressure}}$). This conversion makes it possible to set the reference in such a way that there is a linear connection between the reference and the flow required. See drawing in next column. Feedback conversion should not be used if 2-zone regulation in parameter 417 *Feedback function* has been selected.

Description of choice:

If *Linear* [0] is selected, the feedback signal and the feedback value will be proportional. If *Square root* [1] is selected, the AFD translates the feedback signal to a square root value.



417 Feedback function (2 FEEDBACK, CALC.)

- Value:**
- Minimum (MINIMUM) [0]
 - ★Maximum (MAXIMUM) [1]
 - Sum (SUM) [2]
 - Difference (DIFFERENCE) [3]
 - Average (AVERAGE) [4]
 - 2-zone minimum (2 ZONE MIN) [5]
 - 2-zone maximum (2 ZONE MAX) [6]
 - Feedback 1 only (FEEDBACK 1 ONLY) [7]
 - Feedback 2 only (FEEDBACK 2 ONLY) [8]

★ = factory setting. () = display text [] = value for use in communication via serial communication port

Function:

This parameter allows a choice between different calculation methods whenever two feedback signals are used.

Description of choice:

If *Minimum* [0] is selected, the AFD will compare *feedback 1* with *feedback 2* and regulate on the basis of the lower feedback value.

Feedback 1 = Sum of parameter 535 *Bus feedback 1* and the feedback signal value of terminal 53.

Feedback 2 = Sum of parameter 536 *Bus feedback 2* and the feedback signal value of terminal 54.

If *Maximum* [1] is selected, the AFD will compare *feedback 1* with *feedback 2* and regulate on the basis of the higher feedback value.

If *Sum* [2] is selected, the AFD will total *feedback 1* with *feedback 2*. Please note that the remote reference will be added to Setpoint 1.

If *Difference* [3] is selected, the AFD will subtract *feedback 1* from *feedback 2*.

If *Average* [4] is selected, the AFD will calculate the average of *feedback 1* and *feedback 2*. Please note that the remote reference will be added to the Setpoint 1.

If *2-zone minimum* [5] is selected, the AFD will calculate the difference between *Setpoint 1* and *feedback 1* as well as *Setpoint 2* and *feedback 2*. After this calculation, the AFD will use the larger difference.

A positive difference, i.e. a setpoint higher than the feedback, is always larger than a negative difference.

If the difference between *Setpoint 1* and *feedback 1* is the larger of the two, parameter 418 *Setpoint 1* will be added to the remote reference.

If the difference between *Setpoint 2* and *feedback 2* is the larger of the two, the remote reference will be added to the parameter 419 *Setpoint 2*.

If *2-zone maximum* [6] is selected, the AFD will calculate the difference between *Setpoint 1* and *feedback 1* as well as *Setpoint 2* and *feedback 2*. After the calculation, the AFD will use the smaller difference. A negative difference, i.e. one where the setpoint is lower than the feedback, is always smaller than a positive difference.

If the difference between *Setpoint 1* and *feedback 1* is the smaller of the two, the remote reference will be added to the parameter 418 *Setpoint 1*.

If the difference between *Setpoint 2* and *feedback 2* is the smaller of the two, the remote reference will be added to parameter 419 *Setpoint 2*.

If *Feedback 1 only* is selected, terminal 53 is read as the feedback signal and terminal 54 is ignored. The feedback from terminal 53 is directly associated with Setpoint 1.

If *Feedback 2 only* is selected, terminal 54 is read as the feedback signal and terminal 53 is ignored. The feedback from terminal 54 is directly associated with Setpoint 2.

418 Setpoint 1
(SETPOINT 1)
Value:
 $\text{Ref}_{\text{MIN}} - \text{Ref}_{\text{MAX}}$

★ 0.000

Function:

Setpoint 1 is used in closed loop as the reference to compare the feedback values with. See description of parameter 417 *Feedback function*. The setpoint can be offset with digital, analog or bus references, see *Reference handling*. Used in *Closed loop* [1] parameter 100 *Configuration*.

Description of choice:

Set the required value. The process unit is selected in parameter 415 *Process units*.

419 Setpoint 2
(SETPOINT 2)
Value:
 $\text{Ref}_{\text{MIN}} - \text{Ref}_{\text{MAX}}$

★ 0.000

Function:

Setpoint 2 is used in closed loop as the reference to compare the feedback values with. See description of parameter 417 *Feedbackfunction*.

The setpoint can be offset with digital, analog or bus signals, see *reference handling*.

Used in *Closed loop* [1] parameter 100 *Configuration* and only if *2-zone minimum/maximum* is selected in parameter 417 *Feedbackfunction*.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

Description of choice:

Set the required value. The process unit is selected in parameter 415 *Process units*.

**420 PID normal/inverse control
(PID NOR/INV. CTRL)**
Value:

★Normal (NORMAL) [0]
Inverse (INVERSE) [1]

Function:

It is possible to choose whether the process regulator is to increase/reduce the output frequency if there is a deviation between reference/setpoint and the actual process state.
Used in *Closed loop* [1] (parameter 100).

Description of choice:

If the AFD is to reduce the output frequency in case the feedback signal increases, select *Normal* [0].
If the AFD is to increase the output frequency in case the feedback signal increases, select *Inverse* [1].

**421 PID anti windup
(PID ANTI WINDUP)**
Value:

Off (DISABLE) [0]
★On (ENABLE) [1]

Function:

It is possible to choose whether the process regulator is to continue regulating on a deviation even if it is not possible to increase/reduce the output frequency.
Used in *Closed loop* [1] (parameter 100).

Description of choice:

The factory setting is *On* [1], which means that the integration link is adjusted to the actual output frequency if either the current limit, the voltage limit or the max./min. frequency has been reached. The process regulator will not be engaged again, until either the deviation is zero or its prefix has changed.
Select *Off* [0] if the integrator is to continue integrating to the deviation even if it is not possible to remove the deviation by regulation.


NOTE

If *Off* [0] is selected, it will mean that when the deviation changes its prefix, the integrator will first have to integrate down from the level obtained as a result of the former error, before any change to the output frequency occurs.

**422 PID start-up frequency
(PID START VALUE)**
Value:

$f_{MIN}-f_{MAX}$ (parameter 201 and 202) ★ 0 Hz

Function:

When the start signal comes, the AFD will react in the form of *Open loop* [0] following the ramp. Only when the programmed start frequency has been obtained, will it change over to *Closed loop* [1]. In addition, it is possible to set a frequency that corresponds to the speed at which the process normally runs, which will enable the required process conditions to be reached sooner.
Used in *Closed loop* [1] (parameter 100).

Description of choice:

Set the required start frequency.


NOTE

If the AFD is running at the current limit before the desired start frequency is obtained, the process regulator will not be activated. For the regulator to be activated anyway, the start frequency must be lowered to the required output frequency. This can be done during operation.


NOTE

PID start frequency is always applied in clockwise direction.

**423 PID proportional gain
(PID PROP. GAIN)**
Value:

0.00 - 10.00 ★ 0.01

Function:

The proportional gain indicates the number of times the deviation between the reference/setpoint and the feedback signal is to be applied.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

Used in *Closed loop* [1] (parameter 100).

Description of choice:

Quick regulation is obtained by a high gain, but if the gain is too high, the process may become unstable.

424 PID integration time

(PID INTEGR.TIME)

Value:

0.01 - 9999.00 sec. (OFF) ★ OFF

Function:

The integrator provides a constant change of the output frequency during constant error between the reference/setpoint and the feedback signal. The greater the error, the quicker the integrator frequency contribution will increase. The integration time is the time needed by the integrator to reach the same gain as the proportional gain for a given deviation.

Used in *Closed loop* [1] (parameter 100).

Description of choice:

Fast regulation is obtained in connection with a short integration time. However, this time may be too short, which means that the process may be destabilised as a result of overshings.

If the integral time is long, major deviations from the required set point may occur, since the process regulator will take a long time to regulate in relation to a given error.

425 PID differentiation time

(PID DIFF. TIME)

Value:

0.00 (OFF) - 10.00 sec. ★ OFF

Function:

The differentiator does not react to a constant error. It only contributes when the error changes. The quicker the error changes, the stronger the contribution from the differentiator will be. This influence is proportional to the speed by which the deviation changes.

Used in *Closed loop* [1] (parameter 100).

Description of choice:

Fast regulation can be obtained by means of a long differentiation time. However, this time may

be too long, which means that the process may be destabilised as a result of overshings.

426 PID differentiator gain limit

(PID DIFF. GAIN)

Value:

5.0 - 50.0 ★ 5.0

Function:

It is possible to set a limit for the differentiator gain. The differentiator gain will increase if there are fast changes, which is why it can be beneficial to limit this gain, thereby obtaining a pure differentiator gain at slow changes and a constant differentiator gain where quick changes to the deviation are made.

Used in *Closed loop* [1] (parameter 100).

Description of choice:

Select a limit to differentiator gain as required.

427 PID lowpass filter time

(PID FILTER TIME)

Value:

0.01 - 10.00 ★ 0.01

Function:

Oscillations on the feedback signal are dampened by the lowpass filter in order to reduce their impact on the process regulation. This can be an advantage if there is a lot of noise on the signal.

Used in *Closed loop* [1] (parameter 100).


Description of choice:

Select the desired time constant (τ). If a time constant (τ) of 0.1 s is programmed, the break frequency for the lowpass filter will be $1/0.1 = 10 \text{ RAD/sec.}$, corresponding to $(10/(2 \times \pi)) = 1.6 \text{ Hz.}$

The process regulator will thus only regulate a feedback signal that varies by a frequency lower than 1.6 Hz.

If the feedback signal varies by a higher frequency than 1.6 Hz, the Process regulator will not react.

★ = factory setting. () = display text [] = value for use in communication via serial communication port



433 Motor Alternation Time (MOTOR ALT. TIME)

Value:
 0 (OFF) - 999 hrs ★ OFF

Function:
 This is the time that sets the length of time between motor alternation events. When the time elapses, the relay selected in parameter 323 or 326 changes state and initiates the external control devices that disconnect the active motor and connect the alternate motor. (Contactors or Starters used to connect and disconnect the motors are supplied by others.)

The timer resets after completion of the alternation sequence.

Parameter 434 - Motor Alteration Function, selects the type of stop - Ramp or Coast.

Description of choice:
 Sets the time between motor alternation events.

434 Motor Alteration Function (MOTOR ALT. FUNCTION)

Value:
 ★Ramp (RAMP) [0]
 Coast (COAST) [1]

Function:
 When a motor is stopped after the duration set in parameter 433, *Motor alternation time* expires, the motor is commanded to either coast or ramp to a stop. If the motor is not running at the time of alteration, the relay simply changes state. If the motor is running at the time of alteration, a start command is sent following alteration. Motor Alteration is displayed on the drive control panel during alternation.

When *Coast* is selected, after coasting is initiated, a delay of 2 seconds occurs prior to the relay changing state. Ramp-down time is set in parameter 207.

Description of choice:
 Set the desired stop function.

483 Dynamic DC link compensation (DC LINK COMP.)

Value:
 Off [0]
 ★On [1]

Function:
 The AFD includes a feature, which ensures that the output voltage is independent of any voltage fluctuation in the DC link, e.g. caused by fast fluctuation in the line supply voltage. The benefit is a very steady torque on motor shaft (low torque ripple) under most line conditions.

Description of choice:
 In some cases this dynamic compensation can cause resonance's in the DC link and should then be disabled. Typical cases are where a line choke or a passive harmonic filter (e.g. filters AHF005/010) is mounted in the line supply to the AFD to suppress harmonics. Can also occur on line with low short circuit ratio.

★ = factory setting. () = display text [] = value for use in communication via serial communication port




NOTE

This is a hidden parameter. The only access is with the MCT 10 software tool.

■ Serial communication for FC protocol

195NA035.10



■ Protocols

As standard, all VLT 8000 AQUA units have a RS 485 port which enables a choice among four protocols.

- FC
- Profibus*
- Modbus RTU*
- DeviceNet*
- LonWorks*

* Please note that these are option cards with separate input terminals.

■ Telegram communication

Control and reply telegrams

The telegram communication in a master/slave system is controlled by the master. A maximum of 31 slaves can be connected to one master, unless a repeater is used. If a repeater is used, a maximum of 126 slaves can be connected to one master.


The master continuously sends telegrams addressed to the slaves and awaits reply telegrams from these. The response time of the slaves is max. 50 ms.

Only a slave that has received a faultless telegram addressed to that slave will response by sending a reply telegram.

Broadcast


A master can send the same telegram at the same time to all slaves connected to the bus. In such *broadcast* communication, the slave does not send a reply telegram to the master, provided the telegram has been correctly received. *Broadcast* communication is set up in the address format (ADR), see the next page. Contents of a character (byte)

Each transferred character begins with a start bit. Subsequently, 8 data-bits are transferred, corresponding to one byte. Each character is secured via a parity bit set to "1" when there is even parity (i.e. an even number of binary 1's in the 8 data-bits and the parity bit combined). A character ends with a stop bite and thus consists of a total of 11 bits.



■ Telegram build-up under FC protocol


Each telegram begins with a start character (STX) = 02 Hex, followed by a byte that gives the telegram length (LGE) and a byte that gives the VLT address (ADR). Then follows a number of data bytes (variable, depending on telegram type). The telegram ends with a data control byte (BCC).



Telegram times

The speed of communication between a master and a slave depends on the baud rate. The baud rate of the AFD must be the same as the baud rate of the master and is selected in parameter 502 *Baudrate*.


After a reply telegram from the slave, there must be a minimum pause of 2 characters (22 bits) before the master is able to send another telegram. At a baudrate of 9600 kbaud, there must be a minimum pause of 2.3 msec. After the master has completed the telegram, the response time of the slave back to the master will be max. 20 msec. and there will be a minimum pause of 2 characters.



Pause time, min.: 2 characters
 Response time, min.: 2 characters
 Response time, max.: 20 msec.

The time between individual characters in a telegram is not to exceed 2 characters and the telegram must be completed within 1.5 times the rated telegram time.

If the baudrate is 9600 kbaud and the telegram length is 16 baud, the telegram must be completed within 27.5 msec.



Telegram length (LGE)

The telegram length is the number of data bytes plus address byte ADR plus data control byte BCC.

Telegrams with 4 data bytes have a length of:

$LGE = 4 + 1 + 1 = 6$ bytes

Telegrams with 12 data bytes have a length of:

$LGE = 12 + 1 + 1 = 14$ bytes


Telegrams that contain text have a length of 10+n bytes. 10 is the fixed characters, while 'n' is variable (depending on the length of the text).

AFD address (ADR)

Two different address formats are used, in which the address range of the AFD is either from 1-31 or from 1-126.

1. Address format 1-31

The byte for this address range has the following profile:



Bit 7 = 0 (address format 1-31 active)

Bit 6 is not used


Bit 5 = 1: Broadcast, address bits (0-4), not used

Bit 5 = 0: No Broadcast

Bit 0-4 = AFD address 1-31

2. Address format 1-126

The byte for the 1-126 address range has the following profile:




- Bit 7 = 1 (address format 1-126 active)
- Bit 0-6 = AFD address 1-126
- Bit 0-6 = 0 Broadcast

The slave sends the address byte back to the master in the reply telegram in unchanged form.


Example:

A telegram is sent to AFD address 22 using address format 1-31:



Data control byte (BCC)

The data control byte can be explained by means of an example: Before the first byte of the telegram is received, the calculated check sum (BCS) is 0.



After the first byte (02H) has been received:

$$\begin{array}{r}
 \text{BCS} = \text{BCC EXOR "first byte"} \\
 \text{BCS} \qquad \qquad \qquad (\text{EXOR} = \text{exclusive-or gate}) \\
 \text{BCS} \qquad \qquad \qquad = 0\ 0\ 0\ 0\ 0\ 0\ 0\ 0\ (00\text{H}) \\
 \text{"first byte"} = \qquad \qquad \text{EXOR} \\
 \text{BCS} \qquad \qquad \qquad = 0\ 0\ 0\ 0\ 0\ 0\ 1\ 0\ (02\text{H}) \\
 \hline
 \text{BCC} \qquad \qquad \qquad = 0\ 0\ 0\ 0\ 0\ 0\ 1\ 0
 \end{array}$$


Each additional, subsequent byte is gated with BCS EXOR and results in a new BCC, such as:

$$\begin{array}{r}
 \text{BCS} \qquad \qquad \qquad = 0\ 0\ 0\ 0\ 0\ 0\ 1\ 0\ (02\text{H}) \\
 \text{EXOR} \\
 \text{"second byte"} = \qquad \qquad 1\ 1\ 0\ 1\ 0\ 1\ 1\ 0\ (D6\text{H}) \\
 \hline
 \text{BCC} \qquad \qquad \qquad = 1\ 1\ 0\ 1\ 0\ 1\ 0\ 0
 \end{array}$$


■ **Data character (byte)**

The build-up of data blocks depends on the type of telegram. There are three types of telegram and the telegram type applies to both control telegram (master slave) and reply telegram (slave master). The three types of telegram are the following:


1. Parameter block, used for transferring parameters between master and slave. The data block has 12 bytes (6 words) and also contains the process block.



2. Process block, built up as a data block with four bytes (2 words), covering:
 - Control word and reference value (from master to slave)
 - Status word and present output frequency (from slave to master).




3. Text block, used for reading or writing texts via the data block.



1. Parameter bytes

195NA046.10



Parameter commands and replies (AK) Bits no. 12-15 are used for transferring parameter commands from master to slave and the slave's processed reply back to the master.

Parameter commands → master slave:

| Bit no. | 15 | 14 | 13 | 12 | Parameter command |
|---------|----|----|----|----|---|
| | 0 | 0 | 0 | 0 | No command |
| | 0 | 0 | 0 | 1 | Read parameter value |
| | 0 | 0 | 1 | 0 | Write parameter value in RAM (word) |
| | 0 | 0 | 1 | 1 | Write parameter value in RAM (double word) |
| | 1 | 1 | 0 | 1 | Write parameter value in RAM and EEPROM (double word) |
| | 1 | 1 | 1 | 0 | Write parameter value in RAM and EEPROM (word) |
| | 1 | 1 | 1 | 1 | Read/write text |

Reply slave → master:

| Bit no. | 15 | 14 | 13 | 12 | Reply |
|---------|----|----|----|----|---|
| | 0 | 0 | 0 | 0 | No reply |
| | 0 | 0 | 0 | 1 | Parameter value transferred (word) |
| | 0 | 0 | 1 | 0 | Parameter value transferred (double word) |
| | 0 | 1 | 1 | 1 | Command cannot be executed |
| | 1 | 1 | 1 | 1 | Text transferred |

If the command cannot be carried out, the slave will send this reply (0111) *Command cannot be executed* and give the following error message in the parameter value (PWE):

| (reply 0111) | Error message |
|--------------|---|
| 0 | The parameter number used does not exist |
| 1 | There is no write access to the parameter called |
| 2 | The data value exceeds the parameter limits |
| 3 | The used sub-index does not exist |
| 4 | The parameter is not of the array type |
| 5 | The data type does not match the parameter called |
| 17 | Data change in the parameter called is not possible in the present mode of the VLT AFD. E.g. some parameters can only be changed when the motor has stopped |
| 130 | There is no bus access to the parameter called |
| 131 | Data change is not possible because factory Setup has been selected |

Parameter number PNU)

Bits no. 0-10 are used for transmitting parameter numbers. The function of a given parameter is defined in the parameter description in the *Programming* section.

Index




Index is used together with the parameter number for read/write access to parameters with an index, such as parameter 615 *Error code*. Index has 2 bytes - a lowbyte and a highbyte. However, only the lowbyte is used. See example on the following page.

Example - Index:


The first error code (index [1]) in parameter 615 Error code must be read.

PKE = 1267 Hex (read parameter 615 Error code).
IND = 0001 Hex - Index no. 1.



The VLT AFD will respond in the parameter value (PWE) block by means of an error code with a value from 1-99. See *List of warnings and alarms* to identify the error code.

Parameter value (PWE)




The parameter value block consists of 2 words (4 bytes) and its value depends on the command given (AK). If the master enquires about a parameter value, the PWE block contains no value. If a parameter value is to be changed by the master (write), the new value is entered in the PWE block and sent to the slave. If the slave responds to a parameter requirement (read command), the present parameter value is transferred in the PWE block and returned to the master. If a parameter does not contain a numerical value, but several data selection options, e.g. parameter 001 *Language*, where [0] is *English* and [1] is *Danish*, the data value is selected by writing the value in the PWE block. See example on the following page.

Via the serial communication it is only possible to read parameters with data type 9 (text string). In VLT 8000 AQUA, parameters 621-631 *Nameplate data* have data type 9. For example, it is possible in parameter 621 (Unit Type) to read the unit size and line voltage range.

When a text string is transferred (read), the telegram length is variable, since the texts have different lengths. The telegram length is stated in the 2nd byte of the telegram, called LGE.


In order to read a text via the PWE block, the parameter command (AK) must be set to 'F' Hex.

The index character is used to indicate whether the command in question is a read or write command. For a read command, the index must have the following format:



VLT 8000 AQUA has two parameters for which a text can be written: parameters 533 and 534 *Display text*, see the description of these under the parameter description. In order to write a text via the PWE block, the parameter command (AK) must be set to 'F' Hex.

For a write command, the index must have the following format:



Data types supported by the VLT AFD

| Datatype | Description |
|----------|-------------|
| 3 | Integer 16 |
| 4 | Integer 32 |
| 5 | Unsigned 8 |
| 6 | Unsigned 16 |
| 7 | Unsigned 32 |
| 9 | Text string |

Unsigned means there is no sign included in the telegram.

Example - Write a parameter value:

Parameter 202 *Output frequency high limit, f_{MAX}* is to be changed to 100 Hz. This value must be remembered after a power failure, so it is written in EEPROM.

PKE = E0CA Hex - Write to parameter 202
Output frequency high limit, f_{MAX}
 IND = 0000 Hex
 PWE_{HIGH} = 0000 Hex
 PWE_{LOW} = 03E8 Hex - Data value 1000,
 corresponding to 100 Hz, see
Conversion.

| | | | |
|--------|--------|---------------------|--------------------|
| E0CA H | 0000 H | 0000 H | 03E8 H |
| PKE | IND | PWE _{high} | PWE _{low} |

The reply from the slave to the master will be:

| | | | |
|--------|--------|---------------------|--------------------|
| 10CA H | 0000 H | 0000 H | 03E8 H |
| PKE | IND | PWE _{high} | PWE _{low} |

Example - Choice of a data value:

kW [20] is to be selected in parameter 415 *Process units*. This value must be remembered after a power failure, so it is written in EEPROM.

PKE = E19F Hex - Write to parameter 415
Process units
 IND = 0000 Hex
 PWE_{HIGH} = 0000 Hex
 PWE_{LOW} = 0014 Hex - Choose data choice kW
 [20]

| | | | |
|--------|--------|---------------------|--------------------|
| E19F H | 0000 H | 0000 H | 0014 H |
| PKE | IND | PWE _{high} | PWE _{low} |

Svaret fra slaven til masteren vil være:

| | | | |
|--------|--------|---------------------|--------------------|
| 119F H | 0000 H | 0000 H | 0014 H |
| PKE | IND | PWE _{high} | PWE _{low} |

Example - Read a parameter value:

The value in parameter 206 *Ramp-up time* is required. The master sends the following inquiry:

PKE = 10CE Hex - read parameter 206
Ramp-up time
 IND = 0000 Hex
 PWE_{HIGH} = 0000 Hex
 PWE_{LOW} = 0000 Hex

| | | | |
|--------|--------|---------------------|--------------------|
| 10CE H | 0000 H | 0000 H | 0000 H |
| PKE | IND | PWE _{high} | PWE _{low} |

If the parameter value in parameter 206 *Ramp-up time* is 10 seconds, the reply from the slave to the master will be as follows:

| | | | |
|--------|--------|---------------------|--------------------|
| 10CE H | 0000 H | 0000 H | 000A H |
| PKE | IND | PWE _{high} | PWE _{low} |

Conversion:

The different attributes for each parameter can be seen in the section on *factory settings*. Since a parameter value can only be transferred as a whole number, a conversion factor must be used to transfer decimals.

Example:

Parameter 201: minimum frequency, conversion factor 0.1. If parameter 201 is to be set to 10 Hz, a value of 100 must be transferred, since a conversion factor of 0.1 means that the transferred value will be multiplied by 0.1. A value of 100 will thus be understood as 10.0.

Conversion table:

| Conversion index | Conversion factor |
|------------------|-------------------|
| 74 | 3.6 |
| 2 | 100 |
| 1 | 10 |
| 0 | 1 |
| -1 | 0.1 |
| -2 | 0.01 |
| -3 | 0.001 |
| -4 | 0.0001 |

■ Process word

The process word block is divided into two blocks each of 16 bits, which always come in the sequence stated.


195NA066.10

| | |
|------|------|
| PCD1 | PCD2 |
|------|------|

| | PCD1 | PCD 2 |
|--------------------------------------|-----------------|---------------------------|
| Control telegram (master → slave) | Control word | Reference value |
| Reply telegram (slave → master) | Status word | Given output frequency |

■ Control word as per FC protocol

The control word is used for transmitting commands from a master (e.g. a PC) to a slave.



| Bit | Bit = 0 | Bit = 1 |
|-----|-------------------------|---------------------|
| 00 | | Preset ref. lsb |
| 01 | | Preset ref. msb |
| 02 | DC braking | |
| 03 | Coasting stop | |
| 04 | Quick stop | |
| 05 | Freeze output frequency | |
| 06 | Ramp stop | Start |
| 07 | | Reset |
| 08 | | Jog |
| 09 | No function | No function |
| 10 | Data not valid | Data valid |
| 11 | | Activate relay 1 |
| 12 | | Activate relay 2 |
| 13 | | Choice of setup lsb |
| 14 | | Choice of setup msb |
| 15 | | Reversing |

Bit 00/01:

Bits 00 and 01 are used for choosing between the four pre-programmed references (parameters 211- 214 *Preset reference*) in accordance with the following table:

| Preset ref. | Parameter | Bit 01 | Bit 00 |
|-------------|-----------|--------|--------|
| 1 | 211 | 0 | 0 |
| 2 | 212 | 0 | 1 |
| 3 | 213 | 1 | 0 |
| 4 | 214 | 1 | 1 |

 **NOTE**

Parameter 508 *Choice of preset reference* is used to choose how bits 00/01 are to be gated with the corresponding functions of the digital inputs.

Bit 02, DC BRAKE:

Bit 02 = 0 leads to DC braking and stop. Set braking current and duration in parameter 114 *DC braking current* and in parameter 115 *DC braking time*. Note: Parameter 504 *DC brake* is used for selecting how bit 02 is to be gated with the corresponding function of terminal 27.

Bit 03, Coasting stop:

Bit 03 = "0" means that the AFD immediately "lets go" of the motor (the output transistors are "turned off"), which means that the motor runs freely until it stops. Bit 03 = "1" means that the AFD is able to start the motor, provided the other conditions for starting are fulfilled. Note: In parameter 503 *Coasting stop* the choice is made of how bit 03 is to be gated with the corresponding function of terminal 27.

Bit 04, Quick stop:

Bit 04 = "0" leads to a stop in which the motor speed is ramped down to stop via parameter 207 *Ramp-down time*.

Bit 05, Freeze output frequency:

Bit 05 = "0" means that the given output frequency (in Hz) is frozen. The frozen output frequency can now only be changed via the digital inputs programmed for *Speed up* and *Speed down*.

 **NOTE**

If *Freeze output* is active, the AFD cannot be stopped via Bit 06 *Start* or via terminal 18. The AFD can only be stopped in the following ways:

- Bit 03 *Coasting stop*
- Terminal 27
- Bit 02 *DC braking*
- Terminal 19 programmed for *DC braking*

Bit 06, Ramp stop/start:

Bit 04 = "0" leads to a stop in which the motor speed is ramped down to stop via parameter 207 *Ramp-down time*.

Bit 06 = "1" means that the AFD is able to start the motor, provided the other conditions for starting are fulfilled. Note: In parameter 505 *Start a choice* is made of the way bit 06 *Ramp stop/start* is to be gated with the corresponding function of terminal 18.

Bit 07, Reset:

Bit 07 = "0" leads to no reset.

Bit 07 = "1" means that a trip is reset.

Reset is activated on the leading edge of the signal, i.e. at the change from logic '0' to logic '1'.

Bit 08, Jog:

Bit 08 = "1" means that the output frequency is determined by parameter 209 *Jog frequency*.

Bit 09, No function:

Bit 09 has no function.

Bit 10, Data not valid/Data valid:

Used for telling the AFD whether the control is to be used or ignored. Bit 10 = "0" means that the control word is ignored. Bit 10 = "1" means that the control word is used. This function is relevant because the control word is always contained in the telegram, regardless of the type of telegram used, i.e. it is possible to disconnect the control word if it is not to be used in connection with updating or reading of parameters.

Bit 11, Relay 1:

Bit 11 = "0": Relay 1 is not activated.

Bit 11 = "1": Relay 1 is activated, provided *Control word bits 11/12* has been selected in parameter 323 *Relay outputs*.

Bit 12, Relay 2:

Bit 12 = "0": Relay 2 is not activated.

Bit 12 = "1": Relay 2 is activated, provided *Control word bits 11/12* has been selected in parameter 326 *Relay outputs*.

NOTE

If the time-out period set in parameter 556 *Bus time interval function* is exceeded, relays 1 and 2 will lose their voltage if they have been activated via serial communication.

Bits 13/14, Choice of Setup:

Bits 13 and 14 are used to choose among the four menu Setups in accordance with the following table:

| Setup | Bit 14 | Bit 13 |
|-------|--------|--------|
| 1 | 0 | 0 |
| 2 | 0 | 1 |
| 3 | 1 | 0 |
| 4 | 1 | 1 |

This function is only possible if *Multi-setups* has been selected in parameter 004.

Note: In parameter 507 *Choice of Setup* a choice is made of the way bits 13/14 are to be gated with the corresponding function of the digital inputs.

Bit 15, No function/reversing:


Bit 15 = "0" leads to no reversing.

Bit 15 = "1" leads to reversing.

Please note that, in the factory setting, reversing has been selected as digital in parameter 506 *Reversing*, which means that bit 15 only leads to reversing, if *bus, logic or orlogic* and has been selected (however, *logic* and only together with terminal 19).

■ **Status word as per FC protocol**

The status word is used to inform the master (e.g. a PC) of the condition of the slave (VLT 8000 AQUA).



| Bit | Bit = 0 | Bit = 1 |
|-----|------------------------|--------------------------|
| 00 | Trip | Control ready |
| 01 | | Drive ready |
| 02 | | Stand by |
| 03 | No trip | Trip |
| 04 | Not in use | |
| 05 | Not in use | |
| 06 | Not in use | |
| 07 | No warning | Warning |
| 08 | Speed ≠ ref. | Speed = ref. |
| 09 | Local operation | Serial com. control |
| 10 | Out of frequency range | |
| 11 | | Running |
| 12 | No function | No function |
| 13 | | Voltage warning high/low |
| 14 | | Current limit |
| 15 | | Thermal warning |

Bit 00, Control ready:

Bit 00 = "1". The AFD is ready for operation.

Bit 00 = "0". The AFD has tripped.

Bit 01, Drive ready:

Bit 01 = "1". The AFD is ready for operation, but terminal 27 is a logic '0' and/or a *coasting command* has been received via serial communication.

Bit 02, Stand by:

Bit 02 = "1". The AFD is able to start the motor when a start command is given.

Bit 03, No trip/trip:

Bit 03 = "0" means that the VLT 8000 AQUA is not in an error state.

Bit 03 = "1" means that the VLT 8000 AQUA has tripped and needs a reset signal in order for operation to be resumed.

Bit 04, Not in use:

Bit 04 is not used in the status word.

Bit 05, Not in use:

Bit 05 is not used in the status word.

Bit 06, trip lock:

Bit 06 = "1" means that there is a trip lock.

Bit 07, No warning/warning:

Bit 07 = "0" means there is no warning. Bit 07 = "1" means a warning has occurred.

Bit 08, Speed \neq ref./speed = ref.:

Bit 08 = "0" means that the motor is running, but that the present speed is different from the preset speed reference. This may be the case, i.a. when the speed is ramped up/down at start/stop.

Bit 08 = "1" means that the present motor speed equals the preset speed reference.

Bit 09, Local operation/serial communication control:

Bit 09 = "0" means that OFF/STOP has been activated on the control unit, or that the VLT 8000 AQUA is in Hand mode. It is not possible to control the AFD via serial communication.

Bit 09 = "1" means that it is possible to control the AFD via serial communication.

Bit 10, Out of frequency range:

Bit 10 = "0" if the output frequency has reached the value in parameter 201 *Output frequency low limit* or parameter 202 *Output frequency high limit*. Bit 10 = "1" means that the output frequency is within the limits stated.

Bit 11, Not running/running:

Bit 11 = "0" means that the motor is not running.

Bit 11 = "1" means that the VLT 8000 AQUA has a start signal, or that the output frequency is greater than 0 Hz.

Bit 12, No function:

Bit 12 has no function.

Bit 13, Voltage warning high/low:

Bit 13 = "0" means that there is no voltage warning. Bit 13 = "1" means that the DC voltage of the VLT 8000

AQUA intermediate circuit is too low or too high. See the voltage limits in *Warnings and alarms*.

Bit 14, Current limit:


Bit 14 = "0" means that the output current is smaller than the value in parameter 215 *Current limit I_{LIM}*.

Bit 14 = "1" means that the output current is higher than the value in parameter 215 *Current limit I_{LIM}* and the AFD will trip after the time set in parameter 412 *Trip delay overcurrent, I_{LIM}* has passed.

Bit 15, Thermal warning:

Bit 15 = "0" means there is no thermal warning. Bit 15 = "1" means that the temperature limit has been exceeded either in the motor, in the AFD or from a thermistor connected to an analogue input.

■ **Serial communication reference**



The serial communication reference is transmitted to the AFD in the form of a 16-bit word. The value is transmitted as whole numbers

0 - ± 32767 (± 200 %).

16384 (4000 Hex) corresponds to 100 %.

The serial communication reference has the following format:

0-16384 (4000 Hex) - 0-100 % (par. 204 *Minimum ref.* - Par. 205 *Maximum ref.*).

It is possible to change the direction of rotation via the serial reference. This is done by converting the binary reference value to 2's complement. See example.

Example - control word and serial communication ref.:

The AFD must receive a start command, and the reference is to be set to 50 % (2000 Hex) of the reference range.

Control word = 047F Hex. Start command
Reference = 2000 Hex. 50 % reference

| | |
|--------------|-----------|
| 047F H | 2000 H |
| Control word | Reference |

The AFD is to receive a start command, and the reference is to be set to -50 % (-2000 Hex) of the reference range.


The reference value is first converted to the first complement; then 1 binary is added to get 2's complement:

| | |
|------------|----------------------------|
| 2000 Hex = | 0010 0000 0000 0000 binary |
| 1 | 1101 1111 1111 1111 binary |
| komplement | |
| = | |
| | + 1 binary |
| 2 | 1110 0000 0000 0000 binary |
| komplement | |
| = | |

Control word = 047F Hex. Start command
Reference = E000 Hex. -50 % reference

| | |
|--------------|-----------|
| 047F H | E000 H |
| Control word | Reference |

■ Present output frequency



The value of the present output frequency of the AFD at any given time is transmitted as a 16-bit word. The value is transmitted in the form of whole numbers 0 -± 32767 (±200 %). 16384 (4000 Hex) corresponds to 100 %.

The output frequency has the following format:

0-16384 (4000 Hex) \cong 0-100 % (Par. 201 *Output frequency low limit* - Par. 202 *Output frequency high limit*).

Example - Status word and present output frequency:

The master receives a status message from the AFD saying that the present output frequency is 50 % of the output frequency range.

Par. 201 *Output frequency low limit* = 0 Hz
Par. 202 *Output frequency high limit* = 50 Hz

Status word = 0F03 Hex. Status message
Output frequency = 2000 Hex. 50 % of the frequency range, corresponding to 25 Hz.

| | |
|-------------|------------------|
| 0F03 H | 2000 H |
| Status word | Output frequency |

Serial communication 500-556

In this parameter group, the serial communication of the AFD is set up.

In order to use serial communication, address and baudrate must always be set. In addition, such present operational data as reference, feedback and motor temperature can be read via serial communication.

**500 Protocol
(PROTOCOL)**
Value:

★FC protocol (FC PROTOKOL) [0]

**501 Address
(ADDRESS)**
Value:

Parameter 500
Protocol = FC protocol [0]
 0 - 126 ★ 1

Function:

In this parameter it is possible to allocate an address in a serial communication network to each AFD.

Description of choice:

The individual AFD must be given a unique address. If the number of units connected (AFD + master) exceeds 31, an amplifier (repeater) must be used. Parameter 501 *Address* cannot be chosen via serial communication, but must be set via the LCP control unit.

**502 Baudrate
(BAUDRATE)**
Value:

300 Baud (300 BAUD) [0]
 600 Baud (600 BAUD) [1]
 1200 Baud (1200 BAUD) [2]
 2400 Baud (2400 BAUD) [3]
 4800 Baud (4800 BAUD) [4]
 ★9600 Baud (9600 BAUD) [5]

Function:

In this parameter, the speed is programmed at which data is transmitted via serial communication. Baudrate is defined as the number of bits transmitted per second.

Description of choice:

The transmission speed of the AFD must be set at a value that corresponds to the transmission speed of the master. Parameter 502 *Baudrate* cannot be selected via serial communication; it must be set via the LCP control unit.

The data transmission time itself, which is determined by the baudrate selected, is only part of the total communication time.

**503 Coasting stop
(COASTING)**
Value:

Digital input (DIGITAL INPUT) [0]
 Serial communication (SERIAL PORT) [1]
 Logic and (LOGIC AND) [2]
 ★Logic or (LOGIC OR) [3]

Function:

In parameters 503-508, a choice can be made to control the AFD via the digital inputs and/ or via serial communication.

If *Serial communication* [1] is selected, the command in question can only be activated if a command is given via serial communication.

If *Logic and* [2] is selected, the function must in addition be activated via a digital input.

Description of choice:

The table below shows when the motor is running and is coasting when *Digital input* [0], *Serial communication* [1], *Logic and* [2] or *Logic or* [3] has been selected.


NOTE

Please note that terminal 27 and bit 03 of the control word are active in the case of logic '0'.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

| Digital input [0] | | | Serial communication [1] | | |
|-------------------|---|--------------|--------------------------|---|--------------|
| Serial | | com.Function | Serial | | com.Function |
| Kl. 27 | 0 | | Kl. 27 | 0 | |
| 0 | 0 | Coasting | 0 | 0 | Coasting |
| 0 | 1 | Coasting | 0 | 1 | Motor run. |
| 1 | 0 | Motor run. | 1 | 0 | Coasting |
| 1 | 1 | Motor run. | 1 | 1 | Motor run. |
| Logic and [2] | | | Logic or [3] | | |
| Serial | | com.Function | Serial | | com.Function |
| Kl. 27 | 0 | | Kl. 27 | 0 | |
| 0 | 0 | Coasting | 0 | 0 | Coasting |
| 0 | 1 | Motor run. | 0 | 1 | Coasting |
| 1 | 0 | Motor run. | 1 | 0 | Coasting |
| 1 | 1 | Motor run. | 1 | 1 | Motor run. |

504 DC brake

(DC BRAKE)

Value:

| | |
|------------------------------------|-----|
| Digital input (DIGITAL INPUT) | [0] |
| Serial communication (SERIAL PORT) | [1] |
| Logic and (LOGIC AND) | [2] |
| ★Logic or (LOGIC OR) | [3] |

Function:

See functional description under parameter 503 *Coasting*.

Description of choice:

The table below shows when the motor is running and is DC-braking when *Digital input* [0], *Serial communication* [1], *Logic and* [2] or *Logic or* [3] has been selected.



NOTE

Please note that *DC braking inverse* [3] via terminal 19, terminal 27 and bit 03 of the control word is active in the case of logic '0'.

| Digital input [0] | | | Serial communication [1] | | |
|-------------------|---|--------------|--------------------------|---|--------------|
| Serial | | com.Function | Serial | | com.Function |
| Term. 19/27 | 0 | | Term. 19/27 | 0 | |
| 0 | 0 | DC-brake | 0 | 0 | DC-brake |
| 0 | 1 | DC-brake | 0 | 1 | Motor run. |
| 1 | 0 | Motor run. | 1 | 0 | DC-brake |
| 1 | 1 | Motor run. | 1 | 1 | Motor run. |
| Logic and [2] | | | Logic or [3] | | |
| Serial | | com.Function | Serial | | com.Function |
| Term. 19/27 | 0 | | Term. 19/27 | 0 | |
| 0 | 0 | DC-brake | 0 | 0 | DC-brake |
| 0 | 1 | Motor run. | 0 | 1 | DC-brake |
| 1 | 0 | Motor run. | 1 | 0 | DC-brake |
| 1 | 1 | Motor run. | 1 | 1 | Motor run. |

★ = factory setting. () = display text [] = value for use in communication via serial communication port

505 Start

(START)

Value:

| | |
|------------------------------------|-----|
| Digital input (DIGITAL INPUT) | [0] |
| Serial communication (SERIAL PORT) | [1] |
| Logic and (LOGIC AND) | [2] |
| ★Logic or (LOGIC OR) | [3] |

Function:

See functional description under parameter 503 *Coasting*.

Description of choice:

The table below shows when the motor has stopped and gives the situations in which the AFD has a start command when *Digital input* [0], *Serial communication* [1], *Logic and* [2] or *Logic or* [3] has been selected.

| Digital input [0] | | | Serial communication [1] | | |
|-------------------|---|--------------|--------------------------|---|--------------|
| Serial | | com.Function | Serial | | com.Function |
| Kl. 18 | 0 | | Kl. 18 | 0 | |
| 0 | 0 | Stop | 0 | 0 | Stop |
| 0 | 1 | Stop | 0 | 1 | Start |
| 1 | 0 | Start | 1 | 0 | Stop |
| 1 | 1 | Start | 1 | 1 | Start |
| Logic and [2] | | | Logic or [3] | | |
| Serial | | com.Function | Serial | | com.Function |
| Kl. 18 | 0 | | Kl. 18 | 0 | |
| 0 | 0 | Stop | 0 | 0 | Stop |
| 0 | 1 | Stop | 0 | 1 | Start |
| 1 | 0 | Stop | 1 | 0 | Start |
| 1 | 1 | Start | 1 | 1 | Start |

506 Reversing

(REVERSING)

Value:

| | |
|------------------------------------|-----|
| ★Digital input (DIGITAL INPUT) | [0] |
| Serial communication (SERIAL PORT) | [1] |
| Logic and (LOGIC AND) | [2] |
| Logic or (LOGIC OR) | [3] |

Function:

See functional description under parameter 503 *Coasting*.

Description of choice:

The table below shows when the motor is running clockwise and anti-clockwise when *Digital input* [0], *Serial communication* [1], *Logic and* [2] or *Logic or* [3] has been selected.

| Digital input [0] | | | Serial communication [1] | | |
|-------------------|--------------|----------------|--------------------------|--------------|----------------|
| Kl.19 | com.Function | Serial | Kl.19 | com.Function | Serial |
| 0 | 0 | Clockwise | 0 | 0 | Clockwise |
| 0 | 1 | Clockwise | 0 | 1 | Counter-clock |
| 1 | 0 | Counter-clock. | 1 | 0 | Clockwise |
| 1 | 1 | Counter-clock. | 1 | 1 | Counter-clock. |
| Logic and [2] | | | Logic or [3] | | |
| Kl.19 | com.Function | Serial | Kl.19 | com.Function | Serial |
| 0 | 0 | Clockwise | 0 | 0 | Clockwise |
| 0 | 1 | Clockwise | 0 | 1 | Counter-clock. |
| 1 | 0 | Clockwise | 1 | 0 | Counter-clock. |
| 1 | 1 | Counter-clock. | 1 | 1 | Counter-clock. |

| Digital input [0] | | | | |
|-------------------|---------|-------------------|-------------------|---------------------------|
| Bus msb | Bus lsb | Setup/Pre-set msb | Setup/Pre-set lsb | Setup no. Preset ref. no. |
| 0 | 0 | 0 | 0 | 1 |
| 0 | 0 | 0 | 1 | 2 |
| 0 | 0 | 1 | 0 | 3 |
| 0 | 0 | 1 | 1 | 4 |
| 0 | 1 | 0 | 0 | 1 |
| 0 | 1 | 0 | 1 | 2 |
| 0 | 1 | 1 | 0 | 3 |
| 0 | 1 | 1 | 1 | 4 |
| 1 | 0 | 0 | 0 | 1 |
| 1 | 0 | 0 | 1 | 2 |
| 1 | 0 | 1 | 0 | 3 |
| 1 | 0 | 1 | 1 | 4 |
| 1 | 1 | 0 | 0 | 1 |
| 1 | 1 | 0 | 1 | 2 |
| 1 | 1 | 1 | 0 | 3 |
| 1 | 1 | 1 | 1 | 4 |

| Serial communication [1] | | | | |
|--------------------------|--------|-------------------|-------------------|---------------------------|
| Bus msb | Bus sb | Setup/Pre-set msb | Setup/Pre-set lsb | Setup no. Preset ref. no. |
| 0 | 0 | 0 | 0 | 1 |
| 0 | 0 | 0 | 1 | 1 |
| 0 | 0 | 1 | 0 | 1 |
| 0 | 0 | 1 | 1 | 1 |
| 0 | 1 | 0 | 0 | 2 |
| 0 | 1 | 0 | 1 | 2 |
| 0 | 1 | 1 | 0 | 2 |
| 0 | 1 | 1 | 1 | 2 |
| 1 | 0 | 0 | 0 | 3 |
| 1 | 0 | 0 | 1 | 3 |
| 1 | 0 | 1 | 0 | 3 |
| 1 | 0 | 1 | 1 | 3 |
| 1 | 1 | 0 | 0 | 4 |
| 1 | 1 | 0 | 1 | 4 |
| 1 | 1 | 1 | 0 | 4 |
| 1 | 1 | 1 | 1 | 4 |

507 Selection of Setup
(SELECTING OF SETUP)
508 Selection of preset reference
(SELECTING OF SPEED)
Value:

| | |
|------------------------------------|-----|
| Digital input (DIGITAL INPUT) | [0] |
| Serial communication (SERIAL PORT) | [1] |
| Logic and (LOGIC AND) | [2] |
| ★Logic or (LOGIC OR) | [3] |

Function:

See functional description under parameter 503 *Coasting*.

Description of choice:

The table below shows the Setup (parameter 002 *Active Setup*) that has been selected via *Digital input [0]*, *Serial communication [1]*, *Logic and [2]* or *Logic or [3]*.
The table also shows the preset reference (parameters 211-214 *Preset reference*) that has been selected via *Digital input [0]*, *Serial communication [1]*, *Logic and [2]* or *Logic or [3]*.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

| <i>Logic and [2]</i> | | | | |
|----------------------|---------|-------------------|-------------------|---------------------------|
| Bus msb | Bus lsb | Setup/Pre-set msb | Setup/Pre-set lsb | Setup no. Preset ref. no. |
| 0 | 0 | 0 | 0 | 1 |
| 0 | 0 | 0 | 1 | 1 |
| 0 | 0 | 1 | 0 | 1 |
| 0 | 0 | 1 | 1 | 1 |
| 0 | 1 | 0 | 0 | 1 |
| 0 | 1 | 0 | 1 | 2 |
| 0 | 1 | 1 | 0 | 1 |
| 0 | 1 | 1 | 1 | 2 |
| 1 | 0 | 0 | 0 | 1 |
| 1 | 0 | 0 | 1 | 1 |
| 1 | 0 | 1 | 0 | 3 |
| 1 | 0 | 1 | 1 | 3 |
| 1 | 1 | 0 | 0 | 1 |
| 1 | 1 | 0 | 1 | 2 |
| 1 | 1 | 1 | 0 | 3 |
| 1 | 1 | 1 | 1 | 4 |

| <i>Logic or [3]</i> | | | | |
|---------------------|---------|-------------------|-------------------|---------------------------|
| Bus msb | Bus lsb | Setup/Pre-set msb | Setup/Pre-set lsb | Setup no. Preset ref. no. |
| 0 | 0 | 0 | 0 | 1 |
| 0 | 0 | 0 | 1 | 2 |
| 0 | 0 | 1 | 0 | 3 |
| 0 | 0 | 1 | 1 | 4 |
| 0 | 1 | 0 | 0 | 2 |
| 0 | 1 | 0 | 1 | 2 |
| 0 | 1 | 1 | 0 | 4 |
| 0 | 1 | 1 | 1 | 4 |
| 1 | 0 | 0 | 0 | 3 |
| 1 | 0 | 0 | 1 | 4 |
| 1 | 0 | 1 | 0 | 3 |
| 1 | 0 | 1 | 1 | 4 |
| 1 | 1 | 0 | 0 | 4 |
| 1 | 1 | 0 | 1 | 4 |
| 1 | 1 | 1 | 0 | 4 |
| 1 | 1 | 1 | 1 | 4 |

★ = factory setting. () = display text [] = value for use in communication via serial communication port

509 - 532 Data read-out

| Value: | | | | |
|----------------------|----------------------------------|-----------------------------|-----------------|--------------------------|
| Parameter no. | Description | Display text | Unit | Updating interval |
| 509 | Resulting reference | (REFERENCE %) | % | 80 msec. |
| 510 | Resulting reference [unit] | (REFERENCE [UNIT]) | Hz, rpm | 80 msec. |
| 511 | Feedback [unit] | (FEEDBACK) | Par. 415 | 80 msec. |
| 512 | Frequency [Hz] | (FREQUENCY) | Hz | 80 msec. |
| 513 | User-defined read-out | (CUSTOM READOUT) | Hz x scaling | 80 msec. |
| 514 | Motor current [A] | (CURRENT) | Amp | 80 msec. |
| 515 | Power [kW] | (POWER KW) | kW | 80 msec. |
| 516 | Motor voltage [V] | (POWER HK) | HP | 80 msec. |
| 517 | Motor voltage [V] | (MOTOR VOLT) | V _{AC} | 80 msec. |
| 518 | DC link voltage [V] | (DC LINK VOLTAGE) | V _{DC} | 80 msec. |
| 519 | Thermal load, motor [%] | (MOTOR TEMPERATURE) | % | 80 msec. |
| 520 | Thermal load, VLT [%] | (VLT TEMPERATURE) | % | 80 msec. |
| 521 | Digital input | (DIGITAL INPUT) | Binary | 80 msec. |
| 522 | Terminal 53, analog input [V] | (TERMINAL 53, ANALOG INPUT) | Volt | 20 msec. |
| 523 | Terminal 54, analog input [V] | (TERMINAL 54, ANALOG INPUT) | Volt | 20 msec. |
| 524 | Terminal 60, analogue input [mA] | (TERMINAL 60, ANALOG INPUT) | mA | 20 msec. |
| 525 | Pulse reference [Hz] | (PULSE REFERENCE) | Hz | 20 msec. |
| 526 | External reference [%] | (EXTERNAL REFERENCE) | % | 20 msec. |
| 527 | Status word | (STATUS WORD HEX) | Hex | 20 msec. |
| 528 | Heat sink temperature [°C] | (HEAT SINK TEMP.) | °C | 1,2 sec. |
| 529 | Alarm word | (ALARM WORD, HEX) | Hex | 20 msec. |
| 530 | Control word | (VLT CONTROL WORD, HEX) | Hex | 2 msec. |
| 531 | Warning word | (WARN. WORD) | Hex | 20 msec. |
| 532 | Extended status word | (STATUS WORD) | Hex | 20 msec. |
| 537 | Relay status | (RELAY STATUS) | Binary | 80 msec. |

Function:

These parameters can be read out via the serial communication port and via the display. See also parameters 007-010 *Display read-out*.

Description of choice:
Resulting reference, parameter 509:

gives a percentage for the resulting reference in the range from *Minimum reference, Ref_{MIN}* to *Maximum reference, Ref_{MAX}*. See also *Reference handling*.

Resulting reference [unit], parameter 510:

gives the resulting reference by means of the unit Hz in *Open loop* (parameter 100). In *Closed loop*, the reference unit is selected in parameter 415 *Units with closed loop*.

Feedback [unit], parameter 511:

gives the resulting feedback value by means of the unit/scaling selected in parameters 413, 414 and 415. See also *Feedback handling*.

Frequency [Hz], parameter 512:

gives the output frequency from the AFD.

User-defined read-out, parameter 513:

gives a user-defined value calculated on the basis of the present output frequency and unit, as well as the scaling in selected in parameter 005 *Max. value of user-defined read-out*. The unit is selected in parameter 006 *Unit for user-defined read-out*.

Motor current [A], parameter 514:

Gives the motor phase current measured as an effective value.

Power [kW], parameter 515:

Gives the present power absorption of the motor in kW.

★ = factory setting. () = display text [] = value for use in communication via serial communication port

Power [HP], parameter 516:

Gives the present power absorption of the motor in HP.

Motor voltage, parameter 517:

Gives the voltage fed to the motor.

DC link voltage, parameter 518:

Gives the intermediate circuit voltage of the AFD.

Thermal load, motor [%], parameter 519:

Gives the calculated/estimated thermal load on the motor. 100 % is the cut-out limit. See also parameter 117 *Motor thermal protection*.

Thermal protection, VLT [%], parameter 520:

Gives the calculated/estimated thermal load on the AFD. 100 % is the cut-out limit.

Digital input, parameter 521:

Gives the signal status of the 8 inputs (16, 17, 18, 19, 27, 29, 32 and 33). Input 16 corresponds to the bit to the extreme left.

'0' = no signal, '1' = signal connected.

Terminal 53, analogue input [V], parameter 522:

Gives the voltage value of the signal on terminal 53.

Terminal 54, analogue input [V], parameter 523:

Gives the voltage value of the signal on terminal 54.

Terminal 60, analogue input [mA], parameter 524:

Gives the current value of the signal on terminal 60.

Pulse reference [Hz], parameter 525:

Gives a pulse frequency in Hz connected to one of the terminals 17 and 29.

External reference, parameter 526:

Gives the sum of external references as a percentage (sum of analog/pulse/serial communication) in the range from *Minimum reference, Ref_{MIN}* to *Maximum reference, Ref_{MAX}*.

Status word, parameter 527:

Gives the present status word of the AFD in Hex.

Heat sink temperature, parameter 528:

Gives the present heat sink temperature of the AFD. The cut-out limit is 90 ± 5 °C/9 °F, while cutting back in is effected at 60 ± 5 °C/9 °F.

Alarm word, parameter 529:

Gives a Hex code for the alarm on the AFD. See *Warning words 1+2 and Alarm word*.

Control word, parameter 530:

Gives the present control word of the AFD in Hex.

Warning word, parameter 531:

Indicates in Hex whether there is a warning on the AFD. See *Warning words 1+2 and Alarm word*.

Extended status word, parameter 532:

Indicates in Hex code whether there is a warning on the AFD. See *Warning words 1+2 and Alarm word*.

Relay status, parameter 537:

Indicates in binary code whether the output relays of the AFD are triggered or not.


★ = factory setting. () = display text [] = value for use in communication via serial communication port

533 Display text 1
(DISPLAY TEXT ARRAY 1)
Value:

Max. 20 characters [XXXXXXXXXXXXXXXXXXXXX]

Function:

Here, a text of max. 20 characters can be written that will be shown in display line 1, provided *LCP display text* [27] has been selected in parameter 007 *Large display read-out*. Example of display text.


Description of choice:

Write the required text via serial communication.

534 Display text 2
(DISPLAY TEXT ARRAY 2)
Value:

Max. 8 characters [XXXXXXXX]

Function:

Here, a text of max. 8 characters can be written that will be shown in display line 2, provided *LCP display text* [27] has been selected in parameter 007 *Large display read-out*.

Description of choice:

Write the required text via serial communication.

535 Bus feedback 1 Bus feedback 1
(BUS FEEDBACK1)
Value:

0 - 16384 decimal (0 - 4000 Hex) ★ 0

Function:

Via the serial communication port, this parameter allows writing of a bus feedback value which will then form part of the feedback handling (see Feedback handling). Bus feedback 1 will be added to any feedback value registered on terminal 53.

Description of choice:

Write the required bus feedback value via serial communication.

536 Bus feedback 2
(BUS FEEDBACK2)
Value:

0 - 16384 decimal (0 - 4000 Hex) ★ 0

Function:

Via serial communication, a bus feedback value could be written in this parameter that would subsequently become part of the feedback handling system (see *Feedback handling*). Bus feedback 2 will be added to any feedback value on terminal 54.

Description of choice:

Write the required bus feedback value via the serial communication.


NOTE

Parameters 555 *Bus time interval* and 556 *Bus time interval function* are only active when *FC protocol* [0] has been selected in parameter 500 *Protocol*.

555 Bus time interval
(BUS TIME INTERVAL)
Value:

1 - 65534 sec. ★ 60 sec.

Function:

In this parameter, the time is set which is expected to pass as a maximum between the receipt of two telegrams in a row. If this time is exceeded, the serial communication is assumed to have stopped and the required reaction is set in parameter 556 *Bus time interval function*.

Description of choice:

Set the required time.

556 Bus time interval function
(BUS TIME INTERVAL FUNCTION)
Value:

 ★ Off (OFF) [0]
 Freeze output (FREEZE OUTPUT) [1]

★ = factory setting. () = display text [] = value for use in communication via serial communication port

| | |
|---------------------------------------|-----|
| Stop (STOP) | [2] |
| Jogging (JOG FREQUENCY) | [3] |
| Max. output frequency (MAX FREQUENCY) | [4] |
| Stop and trip (STOP AND TRIP) | [5] |

Function:

In this parameter, the required reaction from the AFD is selected when the time set in parameter 555 *Bus time interval* has been exceeded.

Description of choice:

The output frequency of the AFD can be frozen at the present value at any given time, frozen at parameter 211 *Preset reference 1*, frozen at parameter 202 *Max. output frequency*, or stop and activate a cut-out.

■ Warning words 1+2 and Alarm word

Warning word, extended status word and alarm word are shown in Hex format on the display. If there is more than one warning or alarm, a sum of the total warnings or alarms will be shown.

The descriptions relating to the extended status word can be seen from in *Status word as per FC protocol*, and with respect to warning word, extended status word and alarm word, the descriptions can also be read out via the serial bus in parameter 531 *Warning word*, 532 *Extended status word* and 529 *Alarm word*.

| Hex code | Extended status word |
|----------|---|
| 00000001 | Overvoltage control active |
| 00000002 | Start delay |
| 00000004 | Sleep boost active |
| 00000008 | Sleep mode active |
| 00000010 | Automatic motor adaptation completed |
| 00000020 | Automatic motor adaptation running |
| 00000040 | Reversing and start |
| 00000080 | Ramp operation |
| 00000100 | Reversing |
| 00000200 | Speed = reference |
| 00000400 | Running |
| 00000800 | Local ref. = 0, Remote controlled ref. = 1 |
| 00001000 | OFF mode = 1 |
| 00002000 | Auto mode = 0, Hand mode = 1 |
| 00004000 | Start blocked |
| 00008000 | Start blocked signal missing |
| 00010000 | Freeze output |
| 00020000 | Freeze output blocked |
| 00040000 | Jogging |
| 00080000 | Jog blocked |
| 00100000 | Stand by |
| 00200000 | Stop |
| 00400000 | DC stop |
| 00800000 | Drive ready |
| 01000000 | Relay 123 active |
| 02000000 | Drive ready |
| 04000000 | Control ready |
| 08000000 | Start prevented |
| 10000000 | Profibus OFF3 active |
| 20000000 | Profibus OFF2 active |
| 40000000 | Profibus OFF1 active |
| 80000000 | Reserved |

| Hex code | Warning word |
|----------|---------------------------------|
| 00000001 | Reference high |
| 00000002 | Fault in EEPROM on control card |
| 00000004 | Fault in EEPROM on power card |
| 00000008 | HPFB bus timeout |
| 00000010 | Serial communication timeout |
| 00000020 | Overcurrent |
| 00000040 | Current limit |
| 00000080 | Motor thermistor |
| 00000100 | Motor overtemperature |
| 00000200 | Inverter overtemperature |
| 00000400 | Undervoltage |
| 00000800 | Overvoltage |
| 00001000 | Voltage warning low |
| 00002000 | Voltage warning high |
| 00004000 | Line failure |
| 00008000 | Live zero fault |
| 00010000 | Under 10 Volt (terminal 50) |
| 00020000 | Reference low |
| 00040000 | Feedback high |
| 00080000 | Feedback low |
| 00100000 | Output current high |
| 00200000 | Out of frequency range |
| 00400000 | Profibus communication fault |
| 00800000 | Output current low |
| 01000000 | Output frequency high |
| 02000000 | Output frequency low |
| 04000000 | AMA - motor too small |
| 08000000 | AMA - motor too big |
| 10000000 | AMA - check par. 102, 103, 105 |
| 20000000 | AMA - check par. 102, 104, 106 |
| 40000000 | Reserved |
| 80000000 | Reserved |

| Bit (Hex) | Alarm word |
|------------------|--------------------------------|
| 00000001 | Unknown fault |
| 00000002 | Trip locked |
| 00000004 | Auto-optimisation not OK |
| 00000008 | HPFB bus timeout |
| 00000010 | Serial communication timeout |
| 00000020 | ASIC fault |
| 00000040 | HPFP bus timeout |
| 00000080 | Standard bus timeout |
| 00000100 | Short-circuiting |
| 00000200 | Switchmode fault |
| 00000400 | Ground fault |
| 00000800 | Current limit |
| 00001000 | Overcurrent |
| 00002000 | Motor thermistor |
| 00004000 | Motor overheated |
| 00008000 | Inverter overheated |
| 00010000 | Undervoltage |
| 00020000 | Overvoltage |
| 00040000 | Line failure |
| 00080000 | Live zero fault |
| 00100000 | Heat sink temperature too high |
| 00200000 | Motor phase W missing |
| 00400000 | Motor phase V missing |
| 00800000 | Motor phase U missing |
| 01000000 | Profibus communication fault |
| 02000000 | Inverter fault |
| 04000000 | Output current low |
| 08000000 | Safety stop |
| 10000000 | Reserved |

■ Service functions 600-631

This parameter group contains functions such as operating data, data log and fault log.

It also has information on the nameplate data of the AFD. These service functions are very useful in connection with operating and fault analysis in an installation.

600-605 Operating data
Value:

| Parameter no. | Description | Display text | Unit | Range |
|---------------|------------------------|-------------------|-------|---------------|
| | Operating data: | | | |
| 600 | Operating hours | (OPERATING HOURS) | Hours | 0 - 130,000.0 |
| 601 | Hours run | (RUNNING HOURS) | Hours | 0 - 130,000.0 |
| 602 | kWh counter | (KWH COUNTER) | kWh | - |
| 603 | No. of cut-ins | (POWER UP'S) | Nos. | 0 - 9999 |
| 604 | No. of overtemps. | (OVER TEMP'S) | Nos. | 0 - 9999 |
| 605 | No. of overvoltages | (OVER VOLT'S) | Nos. | 0 - 9999 |

Function:

These parameters can be read out via the serial communication port, as well as via the display in the parameters.

Description of choice:
Parameter 600 Operating hours:

Gives the number of hours in which the AFD has been in operation. The value is saved every hour and when the power supply to the unit is cut off. This value cannot be reset.

Parameter 601 Hours run:

Gives the number of hours in which the motor has been in operation since being reset in parameter 619 *Reset of hours-run counter*. The value is saved every hour and when the power supply to the unit is cut off.

Parameter 602 kWh counter:

Gives the output power of the AFD. The calculation is based on the mean value in kWh over one hour. This value can be reset using parameter 618 *Reset of kWh counter*.

Parameter 603 No. of cut-ins:

Gives the number of cut-ins of supply voltage to the AFD.

Parameter 604 No. of overtemps:

Gives the number of overtemperature errors on the heat-sink of the AFD.

Parameter 605 No. of overvoltages:

Gives the number of overvoltages on the intermediate circuit voltage of the AFD. The count is only taken when Alarm 7 *Overvoltage* is active.

★ = factory setting. () = display text [] = value for use in communication via serial communication port


606 - 614 Data log

Value:

| Parameter no. | Description Data log: | Display text | Unit | Range |
|---------------|--------------------------|---------------------|----------|----------------------------|
| 606 | Digital input | (LOG: DIGITAL INP) | Decimal | 0 - 255 |
| 607 | Control word | (LOG: BUS COMMAND) | Decimal | 0 - 65535 |
| 608 | Status word | (LOG: BUS STAT WD) | Decimal | 0 - 65535 |
| 609 | Reference | (LOG: REFERENCE) | % | 0 - 100 |
| 610 | Feedback | (LOG: FEEDBACK) | Par. 414 | -999,999.999 - 999,999.999 |
| 611 | Output frequency | (LOG: MOTOR FREQ.) | Hz | 0.0 - 999.9 |
| 612 | Output voltage | (LOG: MOTOR VOLT) | Volt | 50 - 1000 |
| 613 | Output current | (LOG: MOTOR CURR.) | Amp | 0.0 - 999.9 |
| 614 | DC link voltage | (LOG: DC LINK VOLT) | Volt | 0.0 - 999.9 |

Function:

With these parameters, it is possible to see up to 20 saved values (data logs) - [1] being the most recent and [20] the oldest log. When a start command has been given, a new entry to the data log is made every 160 ms. If there is a trip or if the motor has stopped, the 20 latest data log entries will be saved and the values will be visible in the display. This is useful, in the case of service after a trip. The data log number is given in square brackets; [1]



Data logs [1]-[20] can be read by first pressing [CHANGE DATA], followed by the [+/-] keys to change data log numbers. Parameters 606-614 *Data log* can also be read out via the serial communication port.

Description of choice:

Parameter 606 Data log: Digital input:

This is where the latest log data are shown in decimal code, representing the status of the digital inputs. Translated into binary code, terminal 16 corresponds to the bit to the extreme left and to decimal code 128. Terminal 33 corresponds to the bit to the extreme right and to decimal code 1.

The table can be used, e.g., for converting a decimal number into a binary code. For example, digital 40 corresponds to binary 00101000. The nearest

★ = factory setting. () = display text [] = value for use in communication via serial communication port

smaller decimal number is 32, corresponding to a signal on terminal 18. 40-32 = 8, corresponds to the signal on terminal 27.

| | | | | | | | | |
|----------------|-----|----|----|----|----|----|----|----|
| Terminal | 16 | 17 | 18 | 19 | 27 | 29 | 32 | 33 |
| Decimal number | 128 | 64 | 32 | 16 | 8 | 4 | 2 | 1 |

Parameter 607 Data log: Control word:

This is where the latest log data are given in decimal code for the control word of the AFD. The control word read can only be changed via serial communication. The control work is read as a decimal number which is to be converted into hex.

Parameter 608 Data log: Status word:

This gives the latest log data in decimal code for the status word. The status word is read as a decimal number which is to be converted into hex.

Parameter 609 Data log: Reference:

This gives the latest log data for the resulting reference.

Parameter 610 Data log: Feedback:

This gives the latest log data for the feedback signal.

Parameter 611 Data log: Output frequency:

This gives the latest log data for the output frequency.

Parameter 612 Data log: Output voltage:

This gives the latest log data for the output voltage.

Parameter 613 Data log: Output current:

This gives the latest log data for the output current.

Parameter 614 Data log: DC-link voltage:

This gives the latest log data for the intermediate circuit voltage.

615 Fault log: Error code
(F. LOG: ERROR CODE)
Value:

[Index 1-10] Error Code: 0 - 99

Function:

This parameter makes it possible to see the reason why a trip (cut-out of the AFD) occurs.

10 [1-10] log values are stored.

The lowest log number [1] contains the latest/most recently saved data value; the highest log number [10] contains the oldest data value.

If there is a trip on the AFD, it is possible to see its cause, the time and possibly the values for output current or output voltage.

Description of choice:

Stated as an error code in which the number refers to a table in *List of warnings and alarms*.

The fault log is only reset after manual initialization. (See *Manual initialization*).

616 Fault log: Time
(F. LOG: TIME)
Value:

[Index 1-10] Hours: 0 - 130,000.0

Function:

This parameter makes it possible to see the total number of hours run in connection with the 10 latest trips.

10 [1-10] log values are stored. The lowest log number [1] contains the latest/most recently saved data value, while the highest log number [10] contains the oldest data value.

Description of choice:

The fault log is only reset after manual initialization. (See *Manual initialization*).

617 Fault log: Value
(F. LOG: VALUE)
Value:

[Index 1 - 10] Value: 0 - 9999

Function:

This parameter makes it possible to see the value at which a trip occurred. The unit of the value depends on the alarm active in parameter 615 *Fault log: Error code*.

Description of choice:

The fault log is only reset after manual initialization. (See *Manual initialization*).

618 Reset of kWh counter
(RESET KWH COUNT)
Value:

★No reset (DO NOT RESET) [0]
Reset (RESET COUNTER) [1]

Function:

Reset to zero of parameter 602 *kWh counter*.

Description of choice:

If Reset [1] has been selected and when the [OK] key is pressed, the kWh counter of the AFD is reset. This parameter cannot be selected via the serial port, RS 485.


NOTE

When the [OK] key has been activated, the reset has been carried out.

619 Reset of hours-run counter
(RESET RUN. HOUR)
Value:

★No reset (DO NOT RESET) [0]
Reset (RESET COUNTER) [1]

Function:

Reset to zero of parameter 601 *Hours-run*.

Description of choice:

If Reset [1] has been selected and when the [OK] key is pressed, parameter 601 *Hours-run* is reset. This parameter cannot be selected via the serial port, RS 485.

★ = factory setting. () = display text [] = value for use in communication via serial communication port



NOTE

When the [OK] key has been activated, the reset has been carried out.

620 Operating mode

(OPERATION MODE)

Value:

| | |
|--|-----|
| ★Normal function (NORMAL OPERATION) | [0] |
| Function with de-activated inverter (OPER. W/INVERT.DISAB) | [1] |
| Control card test (CONTROL CARD TEST) | [2] |
| Initialisation (INITIALIZE) | [3] |

Function:


In addition to its normal function, this parameter can be used for two different tests. Furthermore, it is possible to reset to the default factory settings for all Setups, except parameters 501 *Address*, 502 *Baud rate*, 600-605 *Operating data* and 615-617 *Fault log*.

Description of choice:

Normal function [0] is used for normal operation of the motor.
Function with de-activated inverter [1] is selected if control is desired over the influence of the control signal on the control card and its functions - without the motor shaft running.
Control card [2] is selected if control of the analog and digital inputs, analog and digital outputs, relay outputs and the control voltage of +10 V is desired. A test connector with internal connections is required for this test.

The test connector for the *Control card* [2] is set up as follows:

- connect 4-16-17-18-19-27-29-32-33;
- connect 5-12;
- connect 39-20-55;
- connect 42 - 60;
- connect 45-53-54.



Use the following procedure for the control card test:

1. Select *Control card test*.
2. Cut off the line supply and wait for the light in the display to go out.
3. Insert the test plug (see preceding column).
4. Connect to line.
5. The AFD expects the [OK] key to be pressed (the test cannot be run without LCP).
6. The AFD automatically tests the control card.
7. Remove the test connector and press the [OK] key when the AFD displays "TEST COMPLETED".
8. Parameter 620 *Operating mode* is automatically set to Normal function.

If the control card test fails, the AFD will display "TEST FAILED". Replace the control card.

Initialisation [3] is selected if the factory setting of the unit is to be generated without resetting parameters 501 *Address*, 502 *Baud rate*, 600-605 *Operating data* and 615-617 *Fault log*.

Procedure for initialisation:

1. Select Initialisation.
2. Press the [OK] key.
3. Cut off the line supply and wait for the light in the display to go out.
4. Connect to line.
5. Initialisation of all parameters will be carried out in all Setups with the exception of parameters 501 *Address*, 502 *Baud rate*, 600-605 *Operating data* and 615-617 *Fault log*.

Manual initialisation is another option. (See *Manual initialization*).

★ = factory setting. () = display text [] = value for use in communication via serial communication port

621 - 631 Nameplate
Value:

| Parameter nr. | Description Nameplate: | Display text |
|---------------|------------------------------------|--------------------|
| 621 | Unit type | (DRIVE TYPE) |
| 622 | Power component | (POWER SECTION) |
| 623 | VLT ordering no. | (ORDERING NO) |
| 624 | Software version no. | (SOFTWARE VERSION) |
| 625 | LCP identification no. | (LCP ID NO.) |
| 626 | Database identification no. | (PARAM DB ID) |
| 627 | Power component identification no. | (POWER UNIT DB ID) |
| 628 | Application option type | (APPLIC. OPTION) |
| 629 | Application option ordering no. | (APPLIC. ORDER NO) |
| 630 | Communication option type | (COM. OPTION) |
| 631 | Communication option ordering no. | (COM. ORDER NO) |

Function:

The main data for the unit can be read from parameters 621 to 631 *Nameplate* via the display or the serial communication port.

Description of choice:
Parameter 621 Nameplate: Unit type:

VLT type gives the unit size and line voltage.
Example: VLT 8008 380-480 V.

Parameter 622 Nameplate: Power component:

This gives the type of power card fitted to the AFD. Example: STANDARD.

Parameter 623 Nameplate: VLT ordering no.:

This gives the ordering number for the VLT type in question. Example: 175Z7805.

Parameter 624 Nameplate: Software version no.:

This gives the present software version number of the unit. Example: V 1.00.

Parameter 625 Nameplate: LCP identification no.:

This gives the identification number of the LCP of the unit. Example: ID 1.42 2 kB.

Parameter 626 Nameplate: Database identification no.:

This gives the identification number of the software's database. Example: ID 1.14.

Parameter 627 Nameplate: Power Nameplate: identification no.:

This gives the identification number of the database of the unit. Example: ID 1.15.

Parameter 628 Nameplate: Application option type:

This gives the type of application options fitted with the AFD.

Parameter 629 Nameplate: Application option ordering no.:

This gives the ordering number for the application option.

Parameter 630 Nameplate: Communication option type:

This gives the type of communication options fitted with the AFD.

Parameter 631 Nameplate: Communication option ordering no.:

This gives the ordering number for the communication option.

★ = factory setting. () = display text [] = value for use in communication via serial communication port



NOTE

Parameters 700-711 for the relay card are only activated if a relay option card is installed in the VLT 8000 AQUA.

700 Relay 6, function
(RELAY6 FUNCTION)

703 Relay 7, function
(RELAY7 FUNCTION)

706 Relay 8, function
(RELAY8 FUNCTION)

709 Relay 9, function
(RELAY9 FUNCTION)

Function:

This output activates a relay switch. Relay outputs 6/7/8/9 can be used for showing status and warnings. The relay is activated when the conditions for the relevant data values have been fulfilled. Relays 6, 7, 8, and 9 can be programmed with the same option as Relay 1. See parameter 323, Relay 1 *Output Functions*, for a description of functions to choose from.

Description of choice:

See data choice and connections in *Relay outputs*.

701 Relay 6, ON delay
(RELAY6 ON DELAY)

704 Relay 7, ON delay
(RELAY7 ON DELAY)

707 Relay 8, ON delay
(RELAY8 ON DELAY)

710 Relay 9, ON delay
(RELAY9 ON DELAY)

Value:

0 - 600 sec. ★ 0 sec.

Function:

This parameter allows a delay of the cut-in time of relays 6/7/8/9 (terminals 1-2).

Description of choice:

Enter the required value.

702 Relay 6, OFF delay

(RELAY6 OFF DELAY)

705 Relay 7, OFF delay

(RELAY7 OFF DELAY)

708 Relay 8, OFF delay

(RELAY8 OFF DELAY)

711 Relay 9, OFF delay

(RELAY9 OFF DELAY)

Value:

0 - 600 sec. ★ 0 sec.

Function:

This parameter is used to delay the cut-out time of relays 6/7/8/9 (terminals 1-2).

Description of choice:

Enter the required value.

■ Electrical installation of the relay card

The relays are connected as shown below.

Relay 6-9:



A-B make, A-C break

Max. 240 V AC, 2 Amp.

Max. cross-section: 1.5 mm² (AWG 28-16)

Torque: 0.22 - 0.25 Nm / 4.5 - 5 In lb


Screw size: M2



178M442.11

To achieve double isolation, the plastic foil must be mounted as shown in the drawing below.

★ = factory setting. () = display text [] = value for use in communication via serial communication port



175M475.10


■ **Status messages**

Status messages appear in the 4th line of the display - see example below.

The left part of the status line indicates the active type of control of the AFD.

The centre part of the status line indicates the active reference.

The last part of the status line gives the present status, e.g. "Running", "Stop" or "Stand by".



Auto mode (AUTO)

The AFD is in Auto mode, i.e. control is carried out via the control terminals and/or serial communication. See also *Auto start*.

Hand mode (HAND)

The AFD is in Hand mode, i.e. control is carried out via the control keys. See *Hand start*.

OFF (OFF)

OFF/STOP is activated either by means of the control key, or by the digital inputs *Hand start* and *Auto start* both being a logic "0". See also *OFF/STOP*

Local reference (LOCAL)

If LOCAL has been selected, the reference is set via the [+/-] keys on the control panel. See also *Display modes*.

Remote reference (REM.)

If REMOTE has been selected, the reference is set via the control terminals or via serial communication. See also *Display modes*.

Running (RUNNING)

The motor speed now corresponds to the resulting reference.

Ramp operation (RAMPING)

The output frequency is now changed in accordance with the preset ramps.

Auto-ramp (AUTO RAMP)

Parameter 208 *Automatic ramp-up/down* is enabled, i.e. the AFD is trying to avoid a trip from overvoltage by increasing its output frequency.

Sleep Boost (SLEEP .BST)

The boost function in parameter 406 *Boost setpoint* is enabled. This function is only possible in *Closed loop* operation.

Sleep mode (SLEEP)

The energy saving function in parameter 403 *Sleep mode timer* is enabled. This means that at present the motor has stopped, but that it will restart automatically when required.

Start delay (START DEL)

A start delay time has been programmed in parameter 111 *Start delay*. When the delay has passed, the output frequency will start by ramping up to the reference.

Run request (RUN REQ.)

A start command has been given, but the motor will be stopped until a Run permissive signal is received via a digital input.

Jogging (JOG)

Jog has been enabled via a digital input or via serial communication.

Jog request (JOG REQ.)

A JOG command has been given, but the motor will remain stopped until a *Run permissive* signal is received via a digital input.

Freeze output (FRZ.OUT.)

Freeze output has been enabled via a digital input.

Freeze output request (FRZ.REQ.)

All about VLT 8000 AQUA

A freeze output command has been given, but the motor will remain stopped until a Run permissive signal is received via a digital input.

Reversing and start (START F/R)

Reversing and start [2] on terminal 19 (parameter 303 *Digital inputs*) and *Start* [1] on terminal 18 (parameter 302 *Digital inputs*) are enabled at the same time. The motor will remain stopped until one of the signals becomes a logic '0'.

Automatic Motor Adaptation running (AMA RUN)

Automatic motor adaptation has been enabled in parameter 107 *Automatic Motor Adaptation, AMA*.

Automatic Motor Adaptation completed (AMA STOP)

Automatic motor adaptation has been completed. The AFD is now ready for operation after the *Reset* signal has been enabled. Please note that the motor will start after the AFD has received the *Reset* signal.

Stand by (STANDBY)

The AFD is able to start the motor when a start command is received.

Stop (STOP)

The motor has been stopped via a stop signal from a digital input, [OFF/STOP]-button or serial communication.

DC stop (DC STOP)

The DC brake in parameter 114-116 has been enabled.

DRIVE ready (UN. READY)

The AFD is ready for operation, but terminal 27 is a logic "0" and/or a *Coasting command* has been received via the serial communication.

Not ready (NOT READY)

The AFD is not ready for operation, because of a trip or because OFF1, OFF2 or OFF3 is a logic '0'.

Start disabled (START IN.)

This status will only be displayed if, in parameter 599 *Statemachine, Profidrive* [1] has been selected and OFF2 or OFF3 is a logic '0'.

Exceptions XXXX (EXCEPTIONS XXXX)

The microprocessor of the control card has stopped and the AFD is out of operation.

The cause may be noise on the line, motor or control cables, leading to a stop of the control card microprocessor.

Check for EMC-correct connection of these cables.

■ List of warnings and alarms

The table gives the different warnings and alarms and indicates whether the fault locks the AFD. After Trip locked, the line supply must be cut and the fault must be corrected. Reconnect the line supply and reset the AFD before being ready. A Trip can be reset manually in three ways

1. Via the control key [RESET]
2. Via a digital input
3. Via serial communication


In addition, an automatic reset may be selected in parameter 400 *Reset function*.

Wherever a cross is placed under both Warning and Alarm, this can mean that a warning precedes the alarm. It can also mean that it is possible to program whether a given fault is to result in a warning or an alarm. This is possible, e.g. in parameter 117 *Motor thermal protection*. After a trip, the motor will be coasting and on the AFD alarm and warning will flash. If the fault is removed, only the alarm will flash. After a reset, the AFD will be ready to start operation again.

| No. | Description | Warning | Alarm | Trip locked |
|-----|--|---------|-------|-------------|
| 1 | 10 Volts low (10 VOLT LOW) | X | | |
| 2 | Live zero fault (LIVE ZERO ERROR) | X | X | X |
| 4 | Mains imbalance (MAINS IMBALANCE) | X | | |
| 5 | Voltage warning high (DC LINK VOLTAGE HIGH) | X | | |
| 6 | Voltage warning low (DC LINK VOLTAGE LOW) | X | | |
| 7 | Overvoltage (DC LINK OVERVOLT) | X | X | |
| 8 | Undervoltage (DC LINK UNDERVOLT) | X | X | |
| 9 | Inverter overloaded (INVERTER TIME) | X | X | |
| 10 | Motor overloaded (MOTOR TIME) | X | X | |
| 11 | Motor thermistor (MOTOR THERMISTOR) | X | X | |
| 12 | Current limit (CURRENT LIMIT) | X | X | |
| 13 | Overcurrent (OVERCURRENT) | X | X | X |
| 14 | Ground fault (GROUND FAULT) | | X | X |
| 15 | Switch mode fault (SWITCH MODE FAULT) | | X | X |
| 16 | Short-circuit (CURR.SHORT CIRCUIT) | | X | X |
| 17 | Serial communication timeout (STD BUSTIMEOUT) | X | X | |
| 18 | HPFB bus timeout (HPFB TIMEOUT) | X | X | |
| 19 | Fault in EEprom on power card (EE ERROR POWER) | X | | |
| 20 | Fault in EEprom on control card (EE ERROR CONTROL) | X | | |
| 22 | Auto-optimisation not OK (AMA FAULT) | | X | |
| 29 | Heat-sink temperature too high (HEAT SINK OVERTEMP.) | | X | X |
| 30 | Motor phase U missing (MISSING MOT.PHASE U) | | X | |
| 31 | Motor phase V missing (MISSING MOT.PHASE V) | | X | |
| 32 | Motor phase W missing (MISSING MOT.PHASE W) | | X | |
| 34 | HBFB communication fault (HBFB COMM. FAULT) | X | X | |
| 37 | Inverter fault (GATE DRIVE FAULT) | | X | X |
| 39 | Check parameters 104 and 106 (CHECK P.104 & P.106) | X | | |
| 40 | Check parameters 103 and 105 (CHECK P.103 & P.106) | X | | |
| 41 | Motor too big (MOTOR TOO BIG) | X | | |
| 42 | Motor too small (MOTOR TOO SMALL) | X | | |
| 60 | Safety stop (EXTERNAL FAULT) | | X | |
| 61 | Output frequency low (FOUT < FLOW) | X | | |
| 62 | Output frequency high (FOUT > FHIGH) | X | | |
| 63 | Output current low (I MOTOR < I LOW) | X | X | |
| 64 | Output current high (I MOTOR > I HIGH) | X | | |
| 65 | Feedback low (FEEDBACK < FDB LOW) | X | | |
| 66 | Feedback high (FEEDBACK > FDB HIGH) | X | | |
| 67 | Reference low (REF. < REF. LOW) | X | | |
| 68 | Reference high (REF. > REF. HIGH) | X | | |
| 69 | Temperature auto derate (TEMP.AUTO DERATE) | X | | |
| 99 | Unknown fault (UNKNOWN ALARM) | | X | X |

■ Warnings

A warning will flash in line 2, while an explanation is given in line 1.



■ Alarms

If an alarm is given, the present alarm number will be shown in line 2. Lines 3 and 4 of the display will offer an explanation.



■ Warnings and alarms

WARNING 1

Under 10 V (10 VOLT LOW)

The 10 V voltage from terminal 50 on the control card is below 10 V.

Remove some of the load from terminal 50, as the 10 Volts supply is overloaded. Max. 17 mA/min. 590 Ω.

WARNING/ALARM 2

Live zero fault (LIVE ZERO ERROR)

The current or voltage signal on terminal 53, 54 or 60 is below 50% of the value preset in parameter 309, 312 and 315 *Terminal, min. scaling*.

WARNING/ALARM 4

Mains imbalance (MAINS IMBALANCE)

High imbalance or phase missing on the supply side. Check the supply voltage to the AFD.

WARNING 5

Voltage warning high (DC LINK VOLTAGE HIGH)

The intermediate circuit voltage (DC) is higher than *Voltage warning high*, see table below. The controls of the AFD are still enabled.

WARNING 6

Voltage warning low (DC LINK VOLTAGE LOW)

The intermediate circuit voltage (DC) is lower than *Voltage warning low*, see table below. The controls of the AFD are still enabled.

WARNING/ALARM 7

Overvoltage (DC LINK OVERVOLT)

If the intermediate circuit voltage (DC) is higher than the Overvoltage limit of the inverter (see table below), the AFD will trip after a fixed period. The length of this period depends on the unit.

Alarm/warning limits:

| VLT 8000 AQUA | 3 x 200 - 240 V | 3 x 380 - 480 V | 3 x 525 - 600 V |
|----------------------|-----------------|-----------------|-----------------|
| | [VDC] | [VDC] | [VDC] |
| Undervoltage | 211 | 402 | 557 |
| Voltage warning low | 222 | 423 | 585 |
| Voltage warning high | 384 | 762 | 943 |
| Overvoltage | 425 | 798 | 975 |

The voltages stated are the intermediate circuit voltage of the AFD with a tolerance of ± 5 %. The corresponding line voltage is the intermediate circuit voltage divided by 1.35.

WARNING/ALARM 8

Undervoltage (DC LINK UNDERVOLT)

If the intermediate circuit voltage (DC) drops below the *undervoltage limit* of the inverter, the

AFD will trip after a fixed period, the length of the period depending on the unit. Furthermore, the voltage will be stated in the display. Check whether the supply voltage matches the AFD, see *Technical data*.

WARNING/ALARM 9

Inverter overload (INVERTER TIME)

The electronic, thermal inverter protection reports that the AFD is about to cut out because of an over-load (too high current for too long). The counter for electronic, thermal inverter protection gives a warning at 98% and trips at 100%, while giving an alarm. The AFD cannot be reset until the counter is below 90%. The fault is that the AFD is overloaded by more than 100% for too long.

WARNING/ALARM 10

Motor overtemperature (MOTOR TIME)

According to the electronic thermal protection (ETR), the motor is too hot. Parameter 117 *Motor thermal protection* allows a choice of whether the AFD is to give a warning or an alarm when the *Motor thermal projection* reaches 100%. The fault is that the motor is overloaded by more than 100% of the preset, rated motor current for too long. Check that the motor parameters 102-106 have been set correctly.

WARNING/ALARM 11

Motor thermistor (MOTOR THERMISTOR)

The thermistor or the thermistor connection has been disconnected. Parameter 117 *Motor thermal protection* allows a choice of whether the AFD is to give a warning or an alarm. Check that the thermistor has been correctly connected between terminal 53 or 54 (analog voltage input) and terminal 50 (+ 10 V supply).

WARNING/ALARM 12

Current limit (CURRENT LIMIT)

The current is higher than the value in parameter 215 *Current limit I_{LIM}* and the AFD trips after the time set in parameter 412 *Trip delay overcurrent, I_{LIM}* has passed.

WARNING/ALARM 13

Overcurrent (OVER CURRENT)

The inverter peak current limit (approx. 200% of the rated current) has been exceeded. The warning will last approx. 1-2 seconds, following which the AFD will trip and give off an alarm. Turn off the AFD and check whether the motor shaft can be turned and whether the motor size matches the AFD.

ALARM: 14

Ground fault (GROUND FAULT)(GROUND FAULT)

There is a discharge from the output phases to ground, either in the cable between the AFD and the motor or in the motor itself. Turn off the AFD and remove the ground fault.

ALARM: 15

Switch mode fault (SWITCH MODE FAULT)

Fault in the switch mode power supply (internal ± 15 V supply). Contact your Danfoss supplier.

ALARM: 16

Short-circuiting (CURR. SHORT CIRCUIT)

There is short-circuiting on the motor terminals or in the motor itself. Cut off the line supply to the AFD and remove the short-circuit.

WARNING/ALARM 17

Serial communication timeout (STD BUSTIMEOUT)

There is no serial communication with the AFD. This warning will only be enabled if parameter 556 *Bus time interval function* has been set to a value different from OFF.

If parameter 556 *Bus time interval function* has been set to Stop and trip [5], the AFD will first give off an alarm, then ramp down and finally trip while giving off an alarm. It is possible to increase parameter 555 *Bus time interval*.

WARNING/ALARM 18

HPFB bus timeout (HPFB TIMEOUT)

There is no serial communication with the communication option card of the AFD.

The warning will only be enabled if parameter 804 *Bus time interval function* has been set to anything but OFF. If parameter 804 *Bus time interval function* has been set to *Stop and trip*, the AFD will first give off an alarm, then ramp down and finally trip while giving off an alarm. Parameter 803 *Bus time interval* could possibly be increased.

WARNING 19

Fault in the EEPROM on the power card (EE ERROR POWER)

There is a fault on the power card EEPROM. The AFD will continue to function, but is likely to fail at the next power-up. Contact your Danfoss supplier.

WARNING 20

Fault in the EEPROM on the control card (EE ERROR CONTROL)

There is a fault in the EEPROM on the control card. The AFD will continue to function, but is likely to fail at the next power-up. Contact your Danfoss supplier.

ALARM: 22

Auto-optimisation not OK (AMA FAULT)

A fault has been found during automatic motor adaptation. The text shown in the display indicates a fault message.

**NOTE**

AMA can only be carried out if there are no alarms during tuning.

CHECK 103, 105 [0]

Parameter 103 or 105 has a wrong setting. Correct the setting and start AMA all over.

LOW P.105 [1]

The motor is too small for AMA to be carried out. If AMA is to be enabled, the rated motor current (parameter 105) must be higher than 35% of the rated output current of the AFD.

ASYMMETRICAL IMPEDANCE [2]

AMA has detected an asymmetrical impedance in the motor connected to the system. The motor could be defective.

MOTOR TOO BIG [3]

The motor connected to the system is too big for AMA to be carried out. The setting in parameter 102 does not match the motor used.

MOTOR TOO SMALL [4]

The motor connected to the system is too small for AMA to be carried out. The setting in parameter 102 does not match the motor used.

TIME OUT [5]

AMA fails because of noisy measuring signals. Try to start AMA all over a number of times, until AMA is carried out. Please note that repeated AMA runs may heat the motor to a level where the stator resistance RS is increased. In most cases, however, this is not critical.

INTERRUPTED BY USER [6]

AMA has been interrupted by the user.

INTERNAL FAULT [7]

An internal fault has occurred in the AFD. Contact your Danfoss supplier.

LIMIT VALUE FAULT [8]

The parameter values found for the motor are outside the acceptable range within which the AFD is able to work.

MOTOR ROTATES [9]

The motor shaft rotates. Make sure that the load is not able to make the motor shaft rotate. Then start AMA all over.

ALARM 29**Heat sink temperature too high (HEAT SINK OVER TEMP.):**

If the enclosure is Chassis or NEMA 1, the cut-out temperature of the heat-sink is 90°C. If NEMA 12 is used, the cut-out temperature is 80°C.

The tolerance is $\pm 5^\circ\text{C}$. The temperature fault cannot be reset, until the temperature of the heat-sink is below 60°C.

The fault could be the following:

- Ambient temperature too high
- Too long motor cable
- Too high switching frequency.

ALARM: 30**Motor phase U missing (MISSING MOT.PHASE U):**

Motor phase U between AFD and motor is missing. Turn off the AFD and check motor phase U.

ALARM: 31
Motor phase V missing (MISSING MOT.PHASE V):

Motor phase V between AFD and motor is missing.
Turn off the AFD and check motor phase V.

ALARM: 32
Motor phase W missing (MISSING MOT.PHASE U):

Motor phase W between AFD and motor is missing.
Turn off the AFD and check motor phase W.

WARNING/ALARM: 34
HPFB communication fault (HPFB COMM. FAULT)

The serial communication on the communication option card is not working.

ALARM: 37
Inverter fault (GATE DRIVE FAULT):

IGBT or the power card is defective. Contact your Danfoss supplier.

Auto-optimization warnings 39-42

Automatic motor adaptation has stopped, since some parameters have probably been set wrongly, or the motor used is too big/small for AMA to be carried out. A choice must thus be made by pressing [CHANGE DATA] and choosing "Continue" + [OK] or "Stop" + [OK]. If parameters need to be changed, select "Stop"; start up AMA all over.

WARNING: 39
CHECK PAR. 104, 106

Parameters 104 *Motor frequency* $f_{M,N}$, or 106 *Rated motor speed* $n_{M,N}$, have probably not been set correctly. Check the setting and select "Continue" or [STOP].

WARNING: 40
CHECK PAR. 103, 105

Parameter 103 *Motor voltage*, $U_{M,N}$ or 105 *Motor current*, $I_{M,N}$ has not been set correctly. Correct the setting and restart AMA.

WARNING: 41
MOTOR TOO BIG (MOTOR TOO BIG)

The motor used is probably too big for AMA to be carried out. The setting in parameter 102 *Motor power*, $P_{M,N}$ may not match the motor. Check the motor and choose 'Continue' or [STOP].

WARNING: 42
MOTOR TOO SMALL (MOTOR TOO SMALL)

The motor used is probably too small for AMA to be carried out. The setting in parameter 102 *Motor power*, $P_{M,N}$ may not match the motor. Check the motor and select "Continue" or [STOP].

ALARM: 60
Safety stop (EXTERNAL FAULT)

Terminal 27 (parameter 304 *Digital inputs*) has been programmed for a *Safety interlock* [3] and is a logic "0".

WARNING: 61
Output frequency low (FOUT < FLOW)

The output frequency is lower than parameter 223
Warning: Low frequency, f_{LOW} .

WARNING: 62
Output frequency high (FOUT > FHIGH)

The output frequency is higher than parameter 224
Warning: High frequency, f_{HIGH} .

WARNING/ALARM: 63
Output current low (I MOTOR < I LOW)

The output current is lower than parameter 221
Warning: Low current, I_{LOW} . Select the required function in parameter 409 *Function in case of no load*.

WARNING: 64
Output current high (I MOTOR > I HIGH)

The output current is higher than parameter 222
Warning: High current, I_{HIGH} .

WARNING: 65
Feedback low (FEEDBACK < FDB LOW)

The resulting feedback value is lower than parameter 227
Warning: Low feedback, FB_{LOW} .

WARNING: 66
Feedback high (FEEDBACK > FDB HIGH)

The resulting feedback value is higher than parameter 228
Warning: High feedback, FB_{HIGH} .

WARNING: 67
Remote reference low (REF. < REF LOW)

The remote reference is lower than parameter 225
Warning: Low reference, REF_{LOW} .

WARNING: 68
Remote reference high (REF. > REF HIGH)

The remote reference is higher than parameter 226
Warning: High reference, REF_{HIGH} .

WARNING: 69

Temperature auto derate (TEMP.AUTO DERATE)

The heat sink temperature has exceeded the maximum value and the auto derating function (par. 411) is active. *Warning: Temp. Auto derate.*

WARNING: 99**Unknown fault (UNKNOWN ALARM)**

An unknown fault has occurred that cannot be processed by the software.
Contact your Danfoss supplier.

■ Special conditions**■ Aggressive environments**

In common with all electronic equipment, a AFD contains a large number of mechanical and electronic components, all of which are vulnerable to environmental effects to some extent.



The AFD should not therefore be installed in environments with airborne liquids, particles or gasses capable of affecting and damaging the elec-tronic components. Failure to take the necessary protective measures increases the risk of stoppages, thus reducing the life of the AFD.

Liquids can be carried through the air and condense in the AFD. In addition to this, liquids may cause corrosion of components and metal parts. Steam, oil and salt water may cause corrosion of components and metal parts. In such environments, equipment with enclosure rating IP54/NEMA 12 is recommended.

Airborne particles such as dust particles may cause mechanical, electrical or thermal failure in the AFD. A typical indicator of excessive levels of airborne particles is dust particles around the AFD fan. In very dusty environments, equipment with enclosure rating IP54/NEMA 12 or a cabinet for IP00/Chassis and IP20/NEMA 1 equipment is recommended.

In environments with high temperatures and humidity, corrosive gases such as sulphur, nitrogen and chlorine compounds will cause chemical processes on the AFD components. Such chemical reactions will rapidly affect and damage the electronic components.

In such environments, it is recommended that equipment is mounted in a cabinet with fresh air ventilation, keeping aggressive gases away from the AFD.

**NOTE**

Mounting AFD in aggressive environments will increase the risk of stoppages and furthermore considerably reduce the life of the drive.

Before the installation of the AFD, the ambient air should be checked for liquids, particles and gasses. This may be done by observing existing installations in this environment. Typical indicators of harmful airborne liquids are water or oil on metal parts, or corrosion of metal parts.

Excessive dust particle levels are often found on installation cabinets and existing electrical installations. One indicator of aggressive airborne gasses is blackening of copper rails and cable ends on existing installations.

■ Calculation of resulting reference

The calculation made below gives the resulting reference when parameter 210 *Reference type* is programmed for *Sum* [0] and *Relative* [1], respectively.

External reference is the sum of references from terminals 53, 54, 60 and serial communication. The sum of these can never exceed parameter 205 *Max. reference*. External reference can be calculated as follows:

$$\begin{aligned}
 \text{Ext. ref.} = & \frac{(\text{Par. 205 Max. ref.} - \text{Par. 204 Min. ref.}) \times \text{Ana. signal Term. 53 [V]}}{\text{Par. 310 Term. 53 Max. scaling} - \text{Par. 309 Term. 53 Min. scaling}} + \frac{(\text{Par. 205 Max. ref.} - \text{Par. 204 Min. ref.}) \times \text{Ana. signal Term. 54 [V]}}{\text{Par. 313 Term. 54 Max. scaling} - \text{Par. 312 Term. 54 Min. scaling}} + \\
 & \frac{(\text{Par. 205 Max. ref.} - \text{Par. 204 Min. ref.}) \times \text{Par. 314 Term. 60 [mA]}}{\text{Par. 316 Term. 60 Max. scaling} - \text{Par. 315 Term. 60 Min. scaling}} + \frac{\text{serial com. reference} \times (\text{Par. 205 Max. ref.} - \text{Par. 204 Min. ref.})}{16384 \text{ (4000 Hex)}}
 \end{aligned}$$

Par. 210 *Reference type* is programmed = *Sum* [0].

$$\text{Res. ref.} = \frac{(\text{Par. 205 Max. ref.} - \text{Par. 204 Min. ref.}) \times \text{Par. 211-214 Preset ref.}}{100} + \text{External ref.} + \text{Par. 204 Min. ref.} + \text{Par. 418/419 Setpoint}$$

(only in closed loop)

Par. 210 *Reference type* is programmed = *Relative* [1].

$$\text{Res.ref.} = \frac{\text{External reference} \times \text{Par. 211-214 Preset ref.}}{100} + \text{Par. 204 Min. ref.} + \text{Par. 418/419 Setpoint (only in closed loop)}$$

■ Galvanic isolation (PELV)*

PELV offers protection by way of extra low voltage. Protection against electric shock is considered to be ensured when the electrical supply is of the PELV type and the installation is made as described in local/national regulations on PELV supplies.

In VLT 8000 AQUA all control terminals as well as terminals 1-3 (AUX relay) are supplied from or in connection with extra low voltage (PELV).

Galvanic (ensured) isolation is obtained by fulfilling requirements concerning higher isolation and by providing the relevant creepage/clearance distances. These requirements are described in the EN 50178 standard.


The components that make up the electrical isolation, as described below, also comply with the requirements concerning higher isolation and the relevant test as described in EN 50178.

The galvanic isolation can be shown in three locations (see drawing below), namely:

1. Power supply (SMPS) incl. signal isolation of U_{DC} , indicating the intermediate current voltage.
2. Gate drive that runs the IGBTs (trigger transformers/opto-couplers).
3. Current transducers (Hall effect current transducers).

*) 525-600 V units do not meet PELV requirements.

A motor thermistor connected to terminals 53/54 must be double isolated to obtain PELV.



■ Ground leakage current

Ground leakage current is primarily caused by the capacitance between motor phases and the motor cable shield. See drawing on the following page. The size of the leakage current to the ground depends on the following factors, in order of priority:

1. Length of motor cable
2. Motor cable with or without shield
3. Switching frequency
4. RFI filter used or not
5. Motor grounded on site or not

The leakage current is of importance to safety during handling/operation of the AFD if (by mistake) the AFD has not been grounded.




NOTE
RCD

Since the leakage current is > 3.5 mA, reinforced earthing/grounding must be established, which is required if EN 50178 is to be complied with. Never use ELCB relays (type A) that are not suitable for DC fault currents from three-phase rectifier loads.

If ELCB relays are used, they must be:

- Suitable for protecting equipment with a direct current content (DC) in the fault current (3-phase bridge rectifier)
- Suitable for power-up with short pulse-shaped charging current to ground
- Suitable for a high leakage current (300 mA)



Leakage currents to ground

All about VLT 8000
AQUA

■ Extreme running conditionsShort circuit

VLT 8000 AQUA is protected against short circuits by means of current measurement in each of the three motor phases. A short circuit between two output phases will cause an overcurrent in the inverter. However, each transistor of the inverter will be turned off individually when the short circuit current exceeds the permitted value.

After 5-10 ms the driver card turns off the inverter and the AFD will display a fault code, although depending on impedance and motor frequency.

Ground fault

The inverter cuts out within 100 ms in case of an ground fault on a motor phase, although depending on impedance and motor frequency.

Switching on the output

Switching on the output between the motor and the AFD is fully permitted. It is not possible to damage VLT 8000 AQUA in any way by switching on the output. However, fault messages may appear.

Motor-generated overvoltage

The voltage in the intermediate circuit is increased when the motor acts as a generator. This occurs in two cases:

1. The load drives the motor (at constant output frequency from the AFD), i.e. the load generates energy.
2. During deceleration ("ramp-down") if the moment of inertia is high, the load is low and the ramp-down time is too short for the energy to be dissipated as a loss in the VLT AFD, the motor and the installation.

The control unit attempts to correct the ramp if possible. The inverter turns off to protect the transistors and the intermediate circuit capacitors when a certain voltage level is reached.

Line drop-out

During a line drop-out, VLT 8000 AQUA continues until the intermediate circuit voltage drops below the minimum stop level, which is typically 15% below VLT 8000 AQUA's lowest rated supply voltage.

The time before the inverter stops depends on the line voltage before the drop-out and on the motor load.

Static overload

When VLT 8000 AQUA is overloaded (the current limit in parameter 215 *Current limit*, I_{LIM} has been reached), the controls will reduce the output frequency in an attempt to reduce the load.

If the overload is excessive, a current may occur that makes the VLT AFD cut out after approx. 1.5 sec.

Operation within the current limit can be limited in time (0- 60 s) in parameter 412 *Trip delay overcurrent*, I_{LIM} .

■ Peak voltage on motor

When a transistor in the inverter is opened, the voltage across the motor increases by a dU/dt (dV/dt) ratio that depends on:

- the motor cable (type, cross-section, length shielded/armored or unshielded/unarmored)
- inductance

The natural induction causes an overshoot U_{PEAK} in the motor voltage before it stabilises itself at a level which depends on the voltage in the intermediate circuit.

The rise time and the peak voltage U_{PEAK} affect the service life of the motor. If the peak voltage is too high, motors without phase coil insulation are the ones that will primarily be affected. If the motor cable is short (a few feet), the rise time and peak voltage are lower.

As the length of motor cable increases, the rise time and peak voltage at the motor terminals increases.

Because small motors are more likely to be affected by rapid voltage changes, it is sometimes necessary to provide proper filter between the output of the AFD and the motor.

Data is measured using IEC 34-17.

VLT 8006 200 V, VLT 8006-8011 380-480 V

| Cable length | Line voltage | Rise time | Peak voltage |
|--------------|--------------|----------------|--------------|
| 50 m/165 ft | 380 V | 0.3 μ sec. | 850 V |
| 50 m/165 ft | 460 V | 0.4 μ sec. | 950 V |
| 150 m/500 ft | 380 V | 1.2 μ sec. | 1000 V |
| 150 m/500 ft | 460 V | 1.3 μ sec. | 1300 V |

VLT 8008-8027 200-240 V, VLT 8016-8122 380-480 V

| Cable length | Line voltage | Rise time | Peak voltage |
|--------------|--------------|----------------|--------------|
| 50 m/165 ft | 380 V | 0.1 μ sec. | 900 V |
| 150 m/500 ft | 380 V | 0.2 μ sec. | 1000 V |

VLT 8152-8352 380-480 V

| Cable length | Line voltage | Rise time | Peak voltage |
|--------------|--------------|----------------|--------------|
| 30 m/100 ft | 460 V | 0.2 μ sec. | 1148 V |

VLT 8042-8062 200-240 V

| Cable length | Line voltage | Rise time | Peak voltage |
|--------------|--------------|-------------------|--------------|
| 15 m/45 ft | 460 V | 670 V/ μ sec. | 815 V |
| 20 m/66 ft | 460 V | 620 V/ μ sec. | 915 V |

VLT 8450-8600 380-480 V

| Cable length | Line voltage | Rise time | Peak voltage |
|--------------|--------------|-------------------|--------------|
| 20 m/66 ft | 460 V | 620 V/ μ sec. | 760 V |

VLT 8002-8011 525-600 V

| Cable length | Line voltage | Rise time | Peak voltage | dU/dt |
|--------------|--------------|------------|--------------|--------------|
| 35 m/115 ft | 600 V | 0.36 µsec. | 1360 V | 3011 V/µsec. |

VLT 8016-8072 525-600 V

| Cable length | Line voltage | Rise time | Peak voltage | dU/dt |
|--------------|--------------|------------|--------------|--------------|
| 35 m/115 ft | 575 V | 0.38 µsec. | 1430 V | 2950 V/µsec. |

VLT 8100-8300 525-600 V

| Cable length | Line voltage | Rise time | Peak voltage | dU/dt |
|--------------|--------------|------------|--------------|--------------|
| 13 m/43 ft | 600 V | 0.80 µsec. | 1122 V | 1215 V/µsec. |

VLT 8100-8300 525-600 V

 IP20/NEMA 1 units: 75 dB(A)

■ Acoustic noise

The acoustic interference from the AFD comes from two sources:

1. DC intermediate circuit coils
2. Integral fan.

Below are the typical values measured at a distance of 1 meter/3 feet from the unit at full load:

VLT 8006 200 V, VLT 8006-8011 400 V

| | |
|---------------------|----------|
| IP20/NEMA 1 units: | 50 dB(A) |
| IP54/NEMA 12 units: | 62 dB(A) |

VLT 8008-8027 200 V, VLT 8016-8122 400 V

| | |
|---------------------|----------|
| IP20/NEMA 1 units: | 61 dB(A) |
| IP54/NEMA 12 units: | 66 dB(A) |

VLT 8042-8062 200-240 V

| | |
|---------------------|----------|
| IP20/NEMA 1 units: | 70 dB(A) |
| IP54/NEMA 12 units: | 65 dB(A) |

VLT 8152-8352 380-480 V

| | |
|--|----------|
| IP00/Chassis/IP21/NEMA 1/IP54/NEMA 12 units: | 74 dB(A) |
|--|----------|

VLT 8450-8600 380-480 V

| | |
|--------------------------|----------|
| IP00/Chassis units: | 71 dB(A) |
| IP20/NEMA 1/IP54/NEMA 12 | 82 dB(A) |

VLT 8002-8011 525-600 V

| | |
|--------------------|----------|
| IP20/NEMA 1 units: | 62 dB(A) |
|--------------------|----------|


VLT 8016-8072 525-600 V

| | |
|--------------------|----------|
| IP20/NEMA 1 units: | 66 dB(A) |
|--------------------|----------|

Derating for ambient temperature

The ambient temperature ($T_{AMB,MAX}$) is the maximum temperature allowed. The average ($T_{AMB,MAX}$) measured over 24 hours must be at least 5°C (9°F) lower.

If VLT 8000 AQUA is operated at temperatures above 45°C (113°F), a derating of the continuous output current is necessary.




Derating for air pressure

Below 1000m/3300 ft altitude no derating is necessary.

Above 1000m/3300 ft the ambient temperature (T_{AMB}) or max. output current ($I_{VLT,MAX}$) must be derated in accordance with the diagram below:

1. Derating of output current versus altitude at $T_{AMB} = \text{max. } 40^{\circ}\text{C}$ (113°F)
2. Derating of max. T_{AMB} versus altitude at 100% output current.



Switching on the input

Switching on the input depends on the line voltage in question.

The table states the waiting time between cut-ins.

| Line voltage | 380 V | 415 V | 460 V |
|--------------|-------|-------|-------|
| Waiting time | 48 s | 65 s | 89 s |

■ Derating for running at low speed

When a centrifugal pump or a fan is controlled by a VLT 8000 AQUA AFD, it is not necessary to reduce the output current at low speed because the load characteristic of the centrifugal pumps/fans, automatically ensures the necessary reduction.

For CT (Constant Torque) applications, consult motor manufacturer for motor derating guideline based upon operating load and duty cycle.

| Switching frequency [kHz] | Min. | Max. | Fact. |
|---------------------------|------|------|-------|
| VLT 8006-8032, 200 V | 3.0 | 14.0 | 4.5 |
| VLT 8042-8062, 200 V | 3.0 | 4.5 | 4.5 |
| VLT 8006-8011, 480 V | 3.0 | 10.0 | 4.5 |
| VLT 8016-8062, 480 V | 3.0 | 14.0 | 4.5 |
| VLT 8072-8122, 480 V | 3.0 | 4.5 | 4.5 |
| VLT 8152-8352, 480 V | 3.0 | 10.0 | 4.5 |
| VLT 8450-8600 480 V | 3.0 | 4.5 | 4.5 |
| VLT 8002-8011, 600 V | 4.5 | 7.0 | 4.5 |
| VLT 8016-8032, 600 V | 3.0 | 14.0 | 4.5 |
| VLT 8042-8062, 600 V | 3.0 | 10.0 | 4.5 |
| VLT 8072-8300, 600 V | 3.0 | 4.5 | 4.5 |

■ Derating for long motor cables or cables with larger cross-section

VLT 8000 AQUA has been tested using 300m (1000 ft) unshielded/unarmoured cable and 150m (~500 feet) shielded/armored cable.

VLT 8000 AQUA has been designed to work using a motor cable with a rated cross-section. Using motor cables with cross-section area greater than required for rated motor amps can increase cable capacitive leakage current to earth (ground). Total output current (motor amps + leakage amps) must not be allowed to exceed the rated VLT AFD output current value.

■ Derating for high switching frequency

A higher switching frequency (to be set in parameter 407 - *Switching frequency*) leads to higher losses in the electronics of the VLT AFD.

VLT 8000 AQUA has a pulse pattern in which it is possible to set the switching frequency from 3.0- 10.0/14.0 kHz.


The AFD will automatically derate the rated out-put current $I_{VLT,N}$, when the switching frequency exceeds 4.5 kHz.

In both cases, the reduction is carried out linearly, down to 60% of $I_{VLT,N}$.

The table gives the min., max. and factory-set switching frequencies for VLT 8000 AQUA units.

■ Motor thermal protection

The motor temperature is calculated on the basis of motor current, output frequency and time. See parameter 117, *Motor thermal protection*.



■ Vibration and shock

VLT 8000 AQUA has been tested according to a procedure based on the following standards:

- IEC 68-2-6: Vibration (sinusoidal) - 1970
- IEC 68-2-34: Random vibration broad-band - general requirements
- IEC 68-2-35: Random vibration broad-band - high reproducibility
- IEC 68-2-36: Random vibration broad-band - medium reproducibility

VLT 8000 AQUA complies with requirements that correspond to conditions when the unit is mounted on the walls and floors of production premises, as well as in panels bolted to walls or floors.


■ Air humidity

VLT 8000 AQUA has been designed to meet the IEC 68-2-3 standard, EN 50178 pkt. 9.4.2.2/DIN 40040, class E, at 40°C.

See specifications under *General technical data*.

■ Efficiency

To reduce energy consumption it is very important to optimize the efficiency of a system. The efficiency of each single element in the system should be as high as possible.



Efficiency of VLT 8000 AQUA (η_{VLT})

The load on the AFD has little effect on its efficiency. In general, the efficiency is the same at the rated motor frequency $f_{M,N}$, regardless of whether the motor supplies 100% of the rated shaft torque or only 75%, i.e. in case of part loads.

The efficiency declines a little when the switching frequency is set to a value of above 4 kHz (parameter 407 *Switching frequency*).

Efficiency of the motor (η_{MOTOR})

The efficiency of a motor connected to the AFD depends on the sine shape of the current. In general, the efficiency is just as good as with line operation. The efficiency of the motor depends on the type of motor.

In the range of 75-100% of the rated torque, the efficiency of the motor is practically constant, both when it is controlled by the AFD and when it runs directly on line.

In small motors, the influence from the U/f characteristic on efficiency is marginal; however, in motors from 15 HP and up, the advantages are significant.

In general, the switching frequency does not affect the efficiency of small motors. Motors from 15 HP

and up have their efficiency improved (1-2%). This is because the sine shape of the motor current is almost perfect at high switching frequency.

Efficiency of the system (η_{SYSTEM})

To calculate the system efficiency, the efficiency of VLT 8000 AQUA (VLT) is multiplied by the efficiency of the motor (η_{MOTOR}):

$$\eta_{\text{SYSTEM}} = \eta_{\text{VLT}} \times \eta_{\text{MOTOR}}$$

Based on the graph outlined above, it is possible to calculate the system efficiency at different speeds.

■ Line supply interference/harmonics

An AFD takes up a non-sinusoidal current from line, which increases the input current I_{RMS}. A non-sinusoidal current can be transformed by means of a Fourier analysis and split up into sine wave currents with different frequencies, i.e. different harmonic currents I_N with 50 Hz as the basic frequency:

| Harmonic currents | I ₁ | I ₅ | I ₇ |
|-------------------|----------------|----------------|----------------|
| Hz | 50 Hz | 250 Hz | 350 Hz |

The harmonics do not affect the power consumption directly, but increase the heat losses in the installation (transformer, cables). Consequently, in plants with a rather high percentage of rectifier load, it is important to maintain harmonic currents at a low level to avoid overload of the transformer and high temperature in the cables.

Harmonic currents compared to the RMS input current:


| | Input current |
|--------------------|---------------|
| I _{RMS} | 1.0 |
| I ₁ | 0.9 |
| I ₅ | 0.4 |
| I ₇ | 0.3 |
| I ₁₁₋₄₉ | <0.1 |

To ensure low, harmonic currents, VLT 8000 AQUA has intermediate circuit coils as standard. This normally reduces the input current I_{RMS} by 40%, down to 40-45% ThID.

In some cases, there is a need for further suppression (e.g. retrofit with AFDs). For this purpose Danfoss can offer two advanced harmonic filters AHF05 and AHF10, bringing the harmonic current down to around 5% and 10% respectively. For further details, see the operating instructions MG.80.BX.YY. For calculation of harmonic, Danfoss offers the software tool MCT31.

Some of the harmonic currents might disturb communication equipment connected to the same transformer or cause resonance in connection with power-factor correction batteries. VLT 8000 AQUA has been designed in accordance with the following standards:

- IEC 1000-3-2
- IEEE 519-1992
- IEC 22G/WG4
- EN 50178
- VDE 160, 5.3.1.1.2



The voltage distortion on the line supply depends on the size of the harmonic currents multiplied by the line impedance for the frequency in question. The total voltage distortion THD is calculated on the basis of the individual voltage harmonics using the following formula:

$$THD\% = \frac{\sqrt{U_5^2 + U_7^2 + \dots + U_N^2}}{U_1} \quad (U_N\% \text{ of } U)$$

■ Power factor

The power factor is the relation between I₁ and I_{RMS}.

The power factor for 3-phase control

$$= \frac{\sqrt{3} \times U \times I_1 \times \cos \varphi_1}{\sqrt{3} \times U \times I_{RMS}}$$

Power factor = $\frac{I_1 \times \cos \varphi_1}{I_{RMS}} = \frac{I_1}{I_{RMS}}$ since $\cos \varphi = 1$

The power factor indicates the extent to which the AFD imposes a load on the line supply.

The lower the power factor, the higher the I_{RMS} for the same HP performance.

In addition, a high power factor indicates that the different harmonic currents are low.

$$I_{RMS} = \sqrt{I_1^2 + I_5^2 + I_7^2 + \dots + I_n^2}$$

■ CE labelling**What is CE labelling?**

The purpose of CE labelling is to avoid technical obstacles to trade within EFTA and the EU. The EU has introduced the CE label as a simple way of showing whether a product complies with the relevant EU directives. The CE label says nothing about the specifications or quality of the product. AFDS are regulated by three EU directives:

The machinery directive (98/37/EEC)

All machines with critical moving parts are covered by the machinery directive, which came into force on 1 January 1995. Since an AFD is largely electrical, it does not fall under the machinery directive. However, if an AFD is supplied for use in a machine, we provide information on safety aspects relating to the AFD. We do this by means of a manufacturer's declaration.

The low-voltage directive (73/23/EEC)

AFDs must be CE labelled in accordance with the low-voltage directive, which came into force on 1 January 1997. The directive applies to all electrical equipment and appliances used in the 50 - 1000 Volt AC and the 75 - 1500 Volt DC voltage ranges. Danfoss CE labels in accordance with the directive and issues a declaration of conformity upon request.

The EMC directive (89/336/EEC)

EMC is short for electromagnetic compatibility. The presence of electromagnetic compatibility means that the mutual interference between different components/appliances is so small that the functioning of the appliances is not affected.

The EMC directive came into force on 1 January 1996. Danfoss CE labels in accordance with the directive and issues a declaration of conformity upon request. In order that EMC-correct installation can be carried out, this manual gives detailed instructions for installation. In addition, we specify the standards which our different products comply with. We offer the filters that can be seen from the specifications and provide other types of assistance to ensure the optimum EMC result.

In the great majority of cases, the AFD is used by professionals of the trade as a complex component forming part of a larger appliance, system or installation. It must be noted that the responsibility for the final EMC properties of the appliance, system or installation rests with the installer.

■ What is covered

The EU "Guidelines on the Application of Council Directive 89/336/EEC" outline three typical situations of using an AFD. For each of these situations, explanations are offered as to whether the situation in question is covered by the EMC directive and must be CE labelled.

1. The AFD is sold directly to the end-consumer. The AFD is for example sold to a DIY market. The end-consumer is a layman. He installs the AFD himself for use with a hobby machine, a kitchen appliance, etc. For such applications, the AFD must be CE labelled in accordance with the EMC directive.
 2. The AFD is sold for installation in a plant. The plant is built up by professionals of the trade. It could be a production plant or a heating/ventilation plant designed and installed by professionals of the trade. Neither the AFD nor the finished plant has to be CE labelled under the EMC directive. However, the unit must comply with the basic EMC requirements of the directive. The installer can ensure this by using components, appliances and systems that are CE labelled under the EMC directive.
 3. The AFD is sold as part of a complete system. The system is being marketed as complete. It could be e.g. an air-conditioning system. The complete system must be CE labelled in accordance with the EMC directive. The manufacturer who supplies the system can ensure CE labelling under the EMC directive either by using CE labelled components or by testing the EMC of the system. If he chooses to use only CE labelled components, he does not have to test the entire system.
-

■ Danfoss AFD and CE labeling

CE labelling is a positive feature when used for its original purpose, i.e. to facilitate trade within the EU and EFTA.

However, CE labelling may cover many different specifications. This means that it has to be checked what a given CE label specifically covers.

The specifications covered can in fact be widely different. That is why a CE label can give the installer a false feeling of security when using an AFD as a component in a system or an appliance.

We CE label our AFD in accordance with the low-voltage directive. This means that as long as the AFD is installed correctly, we guarantee that it complies with the low-voltage directive. We issue a declaration of conformity that confirms our CE labelling in accordance with the low-voltage directive.

The CE label also applies to the EMC directive, on condition that the instructions given in this manual for EMC-correct installation and filtering have been followed. On this basis, a declaration of conformity in accordance with the EMC directive is issued.

The manual gives detailed instructions for installation to ensure that your installation is EMC-correct. Furthermore, we specify which norms that are complied with by our different products.

We offer the filters that can be seen from the specifications and gladly provide other types of assistance that can help you obtain the best EMC result.

■ Compliance with EMC directive 89/336/EEC

In the great majority of cases, the AFD is used by professionals of the trade as a complex component forming part of a larger appliance, system or installation. It must be noted that the responsibility for the final EMC properties of the appliance, system or installation rests with the installer. As an aid to the installer, Danfoss has prepared EMC installation guidelines for the Power Drive System. The standards and test levels stated for Power Drive Systems are complied with, provided the right EMC-correct instructions for installation have been followed, see electrical installation.

EMC test results (Emission, Immunity)

The following test results have been obtained using a system with an AFD (with options if relevant), a shielded control cable, a control box with potentiometer, as well as a motor and motor cable.

| VLT 8006- 8011/ 380- 480V | Emission | | | | | |
|---|--|------------------------------|------------------------|--------------------------------------|------------------------|--|
| | Environment | Industrial environment | | Housing, trades and light industries | | |
| | Basic standard | EN 55011 Class A1 | | EN 55011 Class B | | EN 61800- 3 |
| Setup | Motor cable | Conducted 150 kHz- 30 MHz | Radiated 30 MHz- 1 GHz | Conducted 150 kHz- 30 MHz | Radiated 30 MHz- 1 GHz | Conducted/ radiated 150 kHz- 30 MHz |
| VLT 8000 with RFI filter option | 300 m unshielded/ unarmored | Yes ²⁾ | No | No | No | Yes/ No |
| | 50 m br. shielded/ armored (Bookstyle 20m) | Yes | Yes | Yes ⁴⁾ | No | Yes/ Yes |
| | 150m br. shielded/ armored | Yes | Yes | No | No | Yes/ Yes |
| VLT 8000 with RFI- filter (+ LC- module) | 300 m unshielded/ unarmored | Yes | No | No | No | Yes/ No |
| | 50 m br. shielded/ armored | Yes | Yes | Yes ⁴⁾ | No | Yes/ Yes |
| | 150m br. shielded/ armored | Yes | Yes | No | No | Yes/ Yes |

| VLT 8016- 8600/ 380- 480 V VLT 8006- 8062/ 200- 240 V | Emission | | | | |
|--|------------------------------|------------------------------|------------------------|--------------------------------------|------------------------|
| | Environment | Industrial environment | | Housing, trades and light industries | |
| | Basic standard | EN 55011 Class A1 | | EN 55011 Class B | |
| Setup | Motor cable | Conducted 150 kHz- 30 MHz | Radiated 30 MHz- 1 GHz | Conducted 150 kHz- 30 MHz | Radiated 30 MHz- 1 GHz |
| VLT 8000 w/ o RFI filter option | 300 unshielded/ unarmored | No | No | No | No |
| | 150 m br. shielded/ armored | No | Yes | No | No |
| VLT 8000 with RFI- module | 300 m unshielded / unarmored | Yes ^{1,2)} | No | No | No |
| | 50 m br. shielded/ armored | Yes | Yes | Yes ^{1, 3)} | No |
| | 150 m br. shielded/ armored | Yes | Yes | No | No |

1) Does not apply to VLT 8450 - 8600.

2) Depending on installation conditions

3) VLT 8042- 8062, 200- 240 V and VLT 8152-8302 with external filter

4) Does not apply to VLT 8011 (380-480 V)

In order to minimize the conducted noise to the line supply and the radiated noise from the AFD system, the motor cables should be as short as possible and the shield ends should be made in accordance with the section on electrical installation.



VLT® 8000 AQUA

■ EMC Immunity

In order to confirm immunity against interference from electrical phenomena, the following immunity test has been made on a system consisting of an AFD (with options, if relevant), a shielded/armored control cable and control box with potentiometer, motor cable and motor.

The tests were made in accordance with the following basic standards:

EN 61000-4-2 (IEC 1000-4-2): Electrostatic discharges (ESD)

Simulation of electrostatic discharges from human beings.

EN 61000-4-3 (IEC 1000-4-3): Incoming electromagnetic field radiation, amplitude modulated

Simulation of the effects of radar and radio communication equipment as well as mobile communications equipment.

EN 61000-4-4 (IEC 1000-4-4): Burst transients

Simulation of interference brought about by switching with a contactor, relays or similar devices.

EN 61000-4-5 (IEC 1000-4-5): Surge transients

Simulation of transients brought about e.g. by lightning that strikes near installations.

ENV 50204: Incoming electromagnetic field, pulse modulated

Simulation of the impact from GSM telephones.

ENV 61000-4-6: Cable-borne HF

Simulation of the effect of radio transmission equipment connected to supply cables.

VDE 0160 class W2 test pulse: Mains transients

Simulation of high-energy transients brought about by main fuse breakage, switching of power factor-correction capacitors, etc.

■ Immunity, continued

VLT 8006-8600 380-480 V, VLT 8006-8027 200-240 V

| Basic standard | Burst | | Surge | | ESD | Radiated electro- | Mains | RF common | Radiated radio |
|-----------------------------|---------------|---------|-----------------------|--|--------------------|-------------------|------------------------------------|---------------------|------------------|
| | IEC 1000-4-4 | | IEC 1000-4-5 | | 1000-4-2 | magnetic field | distortion | mode voltage | freq.elect.field |
| | | | | | | IEC 1000-4-3 | VDE 0160 | ENV 50141 | ENV 50140 |
| Acceptance criterion | B | B | | | B | A | | A | A |
| Port connection | CM | DM | CM | | - | - | CM | CM | |
| Line | OK | OK | - | | - | - | OK | OK | - |
| Motor | OK | - | - | | - | - | - | OK | - |
| Control lines | OK | - | OK | | - | - | - | OK | - |
| PROFIBUS option | OK | - | OK | | - | - | - | OK | - |
| Signal Interface<3 m | OK | - | - | | - | - | - | - | - |
| Enclosure | - | - | - | | OK | OK | - | - | OK |
| Load sharing | OK | - | - | | - | - | - | OK | - |
| Standard bus | OK | - | OK | | - | - | - | OK | - |
| Basic specifications | | | | | - | - | - | - | - |
| Line | 4 kV/5kHz/DCN | 2 kV/2Ω | 4 kV/12Ω | | - | - | 2,3 x U _N ²⁾ | 10 V _{RMS} | - |
| Motor | 4 kV/5kHz/CCC | - | - | | - | - | - | 10 V _{RMS} | - |
| Control lines | 2 kV/5kHz/CCC | - | 2 kV/2Ω ¹⁾ | | - | - | - | 10 V _{RMS} | - |
| PROFIBUS option | 2 kV/5kHz/CCC | - | 2 kV/2Ω ¹⁾ | | - | - | - | 10 V _{RMS} | - |
| Signal interface<3 m | 1 kV/5kHz/CCC | - | - | | - | - | - | 10 V _{RMS} | - |
| Enclosure | - | - | - | | 8 kV AD 6 kV CD | 10 V/m | - | - | - |
| Load sharing | 4 kV/5kHz/CCC | - | - | | - | - | - | 10 V _{RMS} | - |
| Standard bus | 2 kV/5kHz/CCC | - | 4 kV/2 ¹⁾ | | - | - | - | 10 V _{RMS} | - |

DM: Differential mode

CM: Common mode

CCC: Capacitive clamp coupling

DCN: Direct coupling network

1) Injection on cable shield

 2) 2.3 x U_N: max. test pulse 380 V_{AC}: Class 2/1250 V_{PEAK}, 415 V_{AC}: Class 1/1350 V_{PEAK}

■ Factory settings

| PNU # | Parameter description | Factory setting | Range | Changes during operation | 4-setup | Con-version index | Data type |
|-------|---|---------------------------------|-----------------------------|--------------------------|---------|-------------------|-----------|
| 001 | Language | English | | Yes | No | 0 | 5 |
| 002 | Active Setup | Setup 1 | | Yes | No | 0 | 5 |
| 003 | Copying of Setup | No copying | | No | No | 0 | 5 |
| 004 | LCP copy | No copying | | No | No | 0 | 5 |
| 005 | Max value of user-defined readout | 100.00 | 0 - 999.999,99 | Yes | Yes | -2 | 4 |
| 006 | Unit for user-defined readout | No unit | | Yes | Yes | 0 | 5 |
| 007 | Big display readout | Frequency, % of max. | | Yes | Yes | 0 | 5 |
| 008 | Small display readout 1.1 | Reference, Unit | | Yes | Yes | 0 | 5 |
| 009 | Small display readout 1.2 | Motor current, A | | Yes | Yes | 0 | 5 |
| 010 | Small display readout 1.3 | Power, HP | | Yes | Yes | 0 | 5 |
| 011 | Unit of local reference | Hz | | Yes | Yes | 0 | 5 |
| 012 | Hand start on LCP | Enable | | Yes | Yes | 0 | 5 |
| 013 | OFF/STOP on LCP | Enable | | Yes | Yes | 0 | 5 |
| 014 | Auto start on LCP | Enable | | Yes | Yes | 0 | 5 |
| 015 | Reset on LCP | Enable | | Yes | Yes | 0 | 5 |
| 016 | Lock for data change | Not locked | | Yes | Yes | 0 | 5 |
| 017 | Operating state at power-up, local control | Auto restart | | Yes | Yes | 0 | 5 |
| 100 | Configuration | Open loop | | No | Yes | 0 | 5 |
| 101 | Torque characteristics | Automatic Energy Optimisation | | No | Yes | 0 | 5 |
| 102 | Motor power P_{M,N} | Depends on the unit | 1.1-400 kW (1.5-600 HP) | No | Yes | 1 | 6 |
| 103 | Motor voltage, U_{M,N} | Depends on the unit | 208/480/575 V | No | Yes | 0 | 6 |
| 104 | Motor frequency, f_{M,N} | 60 Hz/▼ 50 Hz | 24-120 Hz | No | Yes | 0 | 6 |
| 105 | Motor current, I_{M,N} | Depends on the unit | 0.01 - I _{VLT,MAX} | No | Yes | -2 | 7 |
| 106 | Rated motor speed, n_{M,N} | Depends on par. 102 Motor power | 100-60000 rpm | No | Yes | 0 | 6 |
| 107 | Automatic motor adaptation.AMA | Optimisation disable | | No | No | 0 | 5 |
| 108 | VT start voltage | Depends on par. 103 | 0.0 - par. 103 | Yes | Yes | -1 | 6 |
| 109 | Resonance dampening | 100 % | 0 - 500 % | Yes | Yes | 0 | 6 |
| 110 | High brake-away torque | 0.0 sec. | 0.0 - 0.5 sec. | Yes | Yes | -1 | 5 |
| 111 | Start delay | 0.0 sec. | 0.0 - 120.0 sec. | Yes | Yes | -1 | 6 |
| 112 | Motor preheater | Disable | | Yes | Yes | 0 | 5 |
| 113 | Motor preheater DC current | 50 % | 0 - 100 % | Yes | Yes | 0 | 6 |
| 114 | DC braking current | 50 % | 0 - 100 % | Yes | Yes | 0 | 6 |
| 115 | DC braking time | OFF | 0.0 - 60.0 sec. | Yes | Yes | -1 | 6 |
| 116 | DC brake cut-in frequency | OFF | 0.0-par. 202 | Yes | Yes | -1 | 6 |
| 118 | Motor power factor | 0.75 | 0.50-0.99 | No | Yes | 0 | 6 |
| 117 | Motor thermal protection | ETR trip 1 | | Yes | Yes | 0 | 5 |
| 119 | Load compensation at low speed | 100 % | 0 - 300 % | Yes | Yes | 0 | 6 |
| 120 | Load compensation at high speed | 100 % | 0 - 300 % | Yes | Yes | 0 | 6 |
| 121 | Slip compensation | 100 % | -500 - 500 % | Yes | Yes | 0 | 3 |
| 122 | Slip compensation time constant | 0.50 sec. | 0.05 - 5.00 sec. | Yes | Yes | -2 | 6 |
| 123 | Stator resistance | Depends on the choice of motor | | No | Yes | -4 | 7 |
| 124 | Stator reactance | Depends on the choice of motor | | No | Yes | -2 | 7 |

▼) Global factory setting different from North American factory setting.

■ Factory settings

| PNU Parameter # description | Factory setting | Range | Changes during operation | 4-setup | Conversion index | Data type |
|---|----------------------------|--------------------------------------|--------------------------|---------|------------------|-----------|
| 201 Output frequency low limit, f_{MIN} | 0.0 Hz | 0.0 - f_{MAX} | Yes | Yes | -1 | 6 |
| 202 Output frequency, f_{MAX} | 60 Hz/▼ 50 Hz | f_{MIN} -120 Hz | Yes | Yes | -1 | 6 |
| 203 Reference site | Hand/Auto linked reference | | Yes | Yes | 0 | 5 |
| 204 Minimum Ref ence, Ref_{MIN} | 0.000 | 0.000-par. 100 | Yes | Yes | -3 | 4 |
| 205 Maximum Ref ence, Ref_{MAX} | 60 Hz/▼ 50 Hz | par. 100-999,999,999 | Yes | Yes | -3 | 4 |
| 206 Ramp-up time | Depends on the unit | 1 - 3600 | Yes | Yes | 0 | 7 |
| 207 Ramp-down time | Depends on the unit | 1 - 3600 | Yes | Yes | 0 | 7 |
| 208 Automatic ramp-up/down | Enable | | Yes | Yes | 0 | 5 |
| 209 Jog frequency | 10.0 Hz | 0.0 - par. 100 | Yes | Yes | -1 | 6 |
| 210 Reference type | Preset reference/▼ Sum | | Yes | Yes | 0 | 5 |
| 211 Preset Reference 1 | 0.00 % | -100.00 - 100.00 % | Yes | Yes | -2 | 3 |
| 212 Preset Reference 2 | 0.00 % | -100.00 - 100.00 % | Yes | Yes | -2 | 3 |
| 213 Preset Reference 3 | 0.00 % | -100.00 - 100.00 % | Yes | Yes | -2 | 3 |
| 214 Preset Reference 4 | 0.00 % | -100.00 - 100.00 % | Yes | Yes | -2 | 3 |
| 215 Current limit, I_{LM} | 1.0 x $I_{LT}[A]$ | 0,1-1,1 x $I_{LT}[A]$ | Yes | Yes | -1 | 6 |
| 216 Frequency bypass, bandwidth | 0 Hz | 0 - 100 Hz | Yes | Yes | 0 | 6 |
| 217 Frequency bypass 1 | 120 Hz | f_{MIN} -120 Hz | Yes | Yes | -1 | 6 |
| 218 Frequency bypass 2 | 120 Hz | f_{MIN} -120 Hz | Yes | Yes | -1 | 6 |
| 219 Frequency bypass 3 | 120 Hz | f_{MIN} -120 Hz | Yes | Yes | -1 | 6 |
| 220 Frequency bypass 4 | 120 Hz | f_{MIN} -120 Hz | Yes | Yes | -1 | 6 |
| 221 Warning: Low current, I_{LOW} | 0.0 A | 0.0 - par. 222 | Yes | Yes | -1 | 6 |
| 222 Warning: High current, I_{HIGH} | I_{LTMAX} | Par. 221 - I_{LTMAX} | Yes | Yes | -1 | 6 |
| 223 Warning: Low frequency f_{LOW} | 0.0 Hz | 0.0 - par. 224 | Yes | Yes | -1 | 6 |
| 224 Warning: High frequency f_{HIGH} | 120.0 Hz | Par. 223 - par. 202 (f_{MAX}) | Yes | Yes | -1 | 6 |
| 225 Warning: Low reference Ref_{LOW} | -999,999.999 | -999,999.999 - par. 226 | Yes | Yes | -3 | 4 |
| 226 Warning: Low reference High $High_{HIGH}$ | 999,999.999 | Par. 225 - 999,999.999 | Yes | Yes | -3 | 4 |
| 227 Warning: Low feedback FB_{LOW} | -999,999.999 | -999,999.999 - par. 228 | Yes | Yes | -3 | 4 |
| 228 Warning: High feedback FB_{HIGH} | 999,999.999 | Par. 227 - 999,999.999 | Yes | Yes | -3 | 4 |
| 229 Initial ramp | OFF | 000.1-360.0 s | No | Yes | -1 | 6 |
| 230 Fill rate | OFF | 000000.001- 999999.999 | Yes | Yes | -3 | 7 |
| 231 Filled setpoint | Par. 413 | Par. 413 to par. 205 | Yes | Yes | -3 | 4 |

▼) Global factory setting different from North American factory setting.

Changes during operation:

"Yes" means that the parameter can be changed, while the AFD is in operation. "No" means that the AFD must be stopped before a change can be made.

4-Setup:

"Yes" means that the parameter can be programmed individually in each of the four setups, i.e. the same parameter can have four different data values. "No" means that the data value will be the same in all four setups.

Conversion index:

This number refers to a conversion figure to be used when writing or reading to or from a VLT AFD by means of serial communication.

| Conversion index | Conversion factor |
|------------------|-------------------|
| 74 | 0.1 |
| 2 | 100 |
| 1 | 10 |
| 0 | 1 |
| -1 | 0.1 |
| -2 | 0.01 |
| -3 | 0.001 |
| -4 | 0.0001 |

Data type

Data type shows the type and length of the telegram.

| Data type | Description |
|-----------|-------------|
| 3 | Integer 16 |
| 4 | Integer 32 |
| 5 | Unsigned 8 |
| 6 | Unsigned 16 |
| 7 | Unsigned 32 |
| 9 | Text string |

■ Factory settings

| PNU # | Parameter description | Factory setting | Range | Changes during operation | 4-setup | Conversion index | Data type |
|-------|---|--|---------------------------|--------------------------|---------|------------------|-----------|
| 300 | Terminal 16 Digital input | Reset | | Yes | Yes | 0 | 5 |
| 301 | Terminal 17 Digital input | No operation | | Yes | Yes | 0 | 5 |
| 302 | Terminal 18 Digital input | Start | | Yes | Yes | 0 | 5 |
| 303 | Terminal 19 Digital input | Reversing | | Yes | Yes | 0 | 5 |
| 304 | Terminal 27 Digital input | Safety interlock/ ▼ Coasting stop, inverse | | Yes | Yes | 0 | 5 |
| 305 | Terminal 29 Digital input | Jog | | Yes | Yes | 0 | 5 |
| 306 | Terminal 32 Digital input | No operation | | Yes | Yes | 0 | 5 |
| 307 | Terminal 33 Digital input | No operation | | Yes | Yes | 0 | 5 |
| 308 | Terminal 53, analog input voltage | No operation | | Yes | Yes | 0 | 5 |
| 309 | Terminal 53, min. scaling | 0.0 V | 0.0 - 10.0 V | Yes | Yes | -1 | 5 |
| 310 | Terminal 53, max. scaling | 10.0 V | 0.0 - 10.0 V | Yes | Yes | -1 | 5 |
| 311 | Terminal 54, analog input voltage | No operation | | Yes | Yes | 0 | 5 |
| 312 | Terminal 54, min. scaling | 0.0 V | 0.0 - 10.0 V | Yes | Yes | -1 | 5 |
| 313 | Terminal 54, max. scaling | 10.0 V | 0.0 - 10.0 V | Yes | Yes | -1 | 5 |
| 314 | Terminal 60, analog input voltage | Reference | | Yes | Yes | 0 | 5 |
| 315 | Terminal 60, min. scaling | 4.0 mA | 0.0 - 20.0 mA | Yes | Yes | -4 | 5 |
| 316 | Terminal 60, max. scaling | 20.0 mA | 0.0 - 20.0 mA | Yes | Yes | -4 | 5 |
| 317 | Time out | 10 sec. | 1 - 99 sec. | Yes | Yes | 0 | 5 |
| 318 | Function after time out | Off | | Yes | Yes | 0 | 5 |
| 319 | Terminal 42, output | 0 - I _{MAX} 4-20 mA | | Yes | Yes | 0 | 5 |
| 320 | Terminal 42, output pulse scaling | | | Yes | Yes | 0 | 6 |
| 321 | Terminal 42, output | 0 - f _{MAX} 0-20 mA | | Yes | Yes | 0 | 5 |
| 322 | Terminal 45, output, pulse scaling | 5000 Hz | 1 - 32000 Hz | Yes | Yes | 0 | 6 |
| 323 | Relay 1, output function | No alarm | | Yes | Yes | 0 | 5 |
| 324 | Relay 01, ON delay | 0.00 sec. | 0 - 600 sec. | Yes | Yes | 0 | 6 |
| 325 | Relay 01, OFF delay | 2.00 sec. | 0 - 600 sec. | Yes | Yes | 0 | 6 |
| 326 | Relay 2, output function | Running | | Yes | Yes | 0 | 5 |
| 327 | Pulse reference, max frequency | 5000 Hz | Depends on input terminal | Yes | Yes | 0 | 6 |
| 328 | Pulse feedback, max. frequency | 25000 Hz | 0 - 65000 Hz | Yes | Yes | 0 | 6 |
| 364 | Terminal 42, bus control | 0 | 0.0 - 100 % | Yes | Yes | -1 | 6 |
| 365 | Terminal 45, bus control | 0 | 0.0 - 100 % | Yes | Yes | -1 | 6 |

▼) Coasting stop, inverse is global factory setting different from North American factory setting.

Changes during operation:

"Yes" means that the parameter can be changed, while the AFD is in operation. "No" means that the AFD must be stopped before a change can be made.

4-Setup:

"Yes" means that the parameter can be programmed individually in each of the four setups, i.e. the same parameter can have four different data values. "No" means that the data value will be the same in all four setups.

Conversion index:

This number refers to a conversion figure to be used when writing or reading to or from an AFD by means of serial communication.

| Conversion index | Conversion factor |
|------------------|-------------------|
| 74 | 0.1 |
| 2 | 100 |
| 1 | 10 |
| 0 | 1 |
| -1 | 0.1 |
| -2 | 0.01 |
| -3 | 0.001 |
| -4 | 0.0001 |

Data type:

Data type shows the type and length of the telegram.

| Data type | Description |
|-----------|-------------|
| 3 | Integer 16 |
| 4 | Integer 32 |
| 5 | Unsigned 8 |
| 6 | Unsigned 16 |
| 7 | Unsigned 32 |
| 9 | Text string |

■ Factory settings

| PNU # | Parameter description | Factory setting | Range | Changes during operation | 4-setup | Conversion index | Data type |
|-------|--|---------------------|---------------------------|--------------------------|---------|------------------|-----------|
| 400 | Reset function | Infinite Automatic | | Yes | Yes | 0 | 5 |
| 401 | Automatic restart time | 10 sec. | 0 - 600 sec. | Yes | Yes | 0 | 6 |
| 402 | Flying start | Enable | | Yes | Yes | -1 | 5 |
| 403 | Sleep mode timer | Off | 0 - 300 sec. | Yes | Yes | 0 | 6 |
| 404 | Sleep frequency | 0 Hz | f_{MIN} - Par. 405 | Yes | Yes | -1 | 6 |
| 405 | Wake up frequency | 60 Hz/▼ 50 Hz | Par. 404 - f_{MAX} | Yes | Yes | -1 | 6 |
| 406 | Boost setpoint | 100% | 1 - 200 % | Yes | Yes | 0 | 6 |
| 407 | Switching frequency | Depends on the unit | 3.0 - 14.0 kHz | Yes | Yes | 2 | 5 |
| 408 | Interference reduction method | ASFM | | Yes | Yes | 0 | 5 |
| 409 | Function in case of no load | Warning | | Yes | Yes | 0 | 5 |
| 410 | Function at line failure | Trip | | Yes | Yes | 0 | 5 |
| 411 | Function at overtemperature | Trip | | Yes | Yes | 0 | 5 |
| 412 | Trip delay overcurrent, I_{LM} | 60 sec | 0 - 60 sec. | Yes | Yes | 0 | 5 |
| 413 | Minimum feedback, FB_{MIN} | 0.000 | -999,999.999 - FB_{MIN} | Yes | Yes | -3 | 4 |
| 414 | Maximum feedback, FB_{MAX} | 100.000 | FB_{MIN} - 999,999.999 | Yes | Yes | -3 | 4 |
| 415 | Units relating to closed loop | % | | Yes | Yes | -1 | 5 |
| 416 | Feedback conversion | Linear | | Yes | Yes | 0 | 5 |
| 417 | Feedback calculation | Maximum | | Yes | Yes | 0 | 5 |
| 418 | Setpoint 1 | 0.000 | FB_{MIN} - FB_{MAX} | Yes | Yes | -3 | 4 |
| 419 | Setpoint 2 | 0.000 | FB_{MIN} - FB_{MAX} | Yes | Yes | -3 | 4 |
| 420 | PID normal/inverse control | Normal | | Yes | Yes | 0 | 5 |
| 421 | PID anti windup | On | | Yes | Yes | 0 | 5 |
| 422 | PID start-up frequency | 0 Hz | f_{MIN} - f_{MAX} | Yes | Yes | -1 | 6 |
| 423 | PID proportional gain | 0.01 | 0.00 - 10.00 | Yes | Yes | -2 | 6 |
| 424 | PID start-up frequency | Off | 0.01 - 9999.00 s. (Off) | Yes | Yes | -2 | 7 |
| 425 | PID differentiation time | Off | 0.0 (Off) - 10.00 sec. | Yes | Yes | -2 | 6 |
| 426 | PID differentiator gain limit | 5.0 | 5.0 - 50.0 | Yes | Yes | -1 | 6 |
| 427 | PID lowpass filter time | 0.01 | 0.01 - 10.00 | Yes | Yes | -2 | 6 |
| 433 | Motor alternation time | 0 (OFF) | 0 - 999 hrs | Yes | Yes | 0 | 6 |
| 434 | Motor alteration function | Ramp | Ramp/Coast | Yes | Yes | 0 | 6 |
| 483 | Dynamic DC link compensation | On | | No | No | 0 | 5 |

▼) Global factory setting different from North American factory setting

■ Factory settings

| PNU # | Parameter description | Factory setting | Range | Changes during operation | 4-setup | Con- ver- sion index | Data type |
|-------|---|-----------------|-----------------------|--------------------------|---------|-------------------------------|--------------|
| 500 | Protocol | FC | | Yes | Yes | 0 | 5 |
| 501 | Address | 001 | Depends on par.500 | Yes | No | 0 | 5 |
| 502 | Baudrate | 9600 BAUD | | Yes | No | 0 | 5 |
| 503 | Coasting | LOGIC OR | | Yes | Yes | 0 | 5 |
| 504 | DC-brake | LOGIC OR | | Yes | Yes | 0 | 5 |
| 506 | Start | LOGIC OR | | Yes | Yes | 0 | 5 |
| 506 | Reversing | DIGITAL INPUT | | Yes | Yes | 0 | 5 |
| 507 | Selection of Setup | LOGIC OR | | Yes | Yes | 0 | 5 |
| 508 | Selection of Preset Reference | LOGIC OR | | Yes | Yes | 0 | 5 |
| 509 | Data Read-out: Reference % | | | No | No | -1 | 3 |
| 510 | Data Read-out: Reference Unit | | | No | No | -3 | 4 |
| 511 | Data Read-out: Feedback | | | No | No | -3 | 4 |
| 512 | Data Read-out: Frequency | | | No | No | -1 | 6 |
| 513 | User Defined Read-out | | | No | No | -2 | 7 |
| 514 | Data Read-out: Current | | | No | No | -2 | 7 |
| 515 | Data Read-out: Power, kW | | | No | No | 1 | 7 |
| 516 | Data Read-out: Power, HP | | | No | No | -2 | 7 |
| 517 | Data Read-out: Motor Voltage | | | No | No | -1 | 6 |
| 518 | Data Read-out: DC Link Voltage | | | No | No | 0 | 6 |
| 519 | Data Read-out: Motor temp. | | | No | No | 0 | 5 |
| 520 | Data Read-out: VLT Temp. | | | No | No | 0 | 5 |
| 521 | Data Read-out: Digital Input | | | No | No | 0 | 5 |
| 522 | Data Read-out: Terminal 53, Analog Input | | | No | No | -1 | 3 |
| 523 | Data Read-out: Terminal 54, Analog Input | | | No | No | -1 | 3 |
| 524 | Data Read-out: Terminal 60 Analog Input | | | No | No | -4 | 3 |
| 525 | Data Read-out: Pulse reference | | | No | No | -1 | 7 |
| 526 | Data Read-out: External Reference % | | | No | No | -1 | 3 |
| 527 | Data Read-out: Status Word, Hex | | | No | No | 0 | 6 |
| 528 | Data Read-out: Heat Sink Temperatur | | | No | No | 0 | 5 |
| 529 | Data Read-out: Alarm Word, Hex | | | No | No | 0 | 7 |
| 530 | Data Read-out: Control Word, Hex | | | No | No | 0 | 6 |
| 531 | Data Read-out: Warning Word, Hex | | | No | No | 0 | 7 |
| 532 | Data Read-out: Extended Status Word, Hex | | | No | No | 0 | 7 |
| 533 | Display Text 1 | | | No | No | 0 | 9 |
| 534 | Display Text 2 | | | No | No | 0 | 9 |
| 535 | Bus Feedback 1 | 00000 | | No | No | 0 | 3 |
| 536 | Bus Feedback 2 | 00000 | | No | No | 0 | 3 |
| 537 | Data Read-out: Relay Status | | | No | No | 0 | 5 |
| 555 | Bus Time Interval | 60 sec. | 1 to 99 sec. | Yes | Yes | 0 | 5 |
| 556 | Bus Time Interval Function | NO FUNCTION | | Yes | Yes | 0 | 5 |

■ Factory settings

| PNU # | Parameter description | Factory setting | Range | Changes during operation | 4-setup | Conversion index | Data type |
|-------|--|-----------------|-------|--------------------------|---------|------------------|-----------|
| 600 | Operating data: Operating hours | | | No | No | 74 | 7 |
| 601 | Operating data: Hours run | | | No | No | 74 | 7 |
| 602 | Operating data: kWh counter | | | No | No | 1 | 7 |
| 603 | Operating data: No. of cut-ins | | | No | No | 0 | 6 |
| 604 | Operating data: No. of overtemps | | | No | No | 0 | 6 |
| 606 | Operating data: No. of overvoltages | | | No | No | 0 | 6 |
| 606 | Data log: Digital input | | | No | No | 0 | 5 |
| 607 | Data log: Control word | | | No | No | 0 | 5 |
| 608 | Data log: Status word | | | No | No | 0 | 6 |
| 609 | Data log: Reference | | | No | No | -1 | 3 |
| 610 | Data log: Feedback | | | No | No | -3 | 4 |
| 611 | Data log: Output frequency | | | No | No | -1 | 3 |
| 612 | Data log: Output voltage | | | No | No | -1 | 6 |
| 613 | Data log: r Output current | | | No | No | -2 | 3 |
| 614 | Data log: DC link voltage | | | No | No | 0 | 6 |
| 615 | Fault log: Error code | | | No | No | 0 | 5 |
| 616 | Fault log: Time | | | No | No | 0 | 7 |
| 617 | Fault log: Value | | | No | No | 0 | 3 |
| 618 | Reset of kWh counter | No reset | | Yes | No | 0 | 5 |
| 619 | Reset of hours-run counter | No reset | | Yes | No | 0 | 5 |
| 620 | Operating mode | Normal function | | Yes | No | 0 | 5 |
| 621 | Nameplate: Unit type | | | No | No | 0 | 9 |
| 622 | Nameplate: Power component | | | No | No | 0 | 9 |
| 623 | Nameplate: VLT ordering no. | | | No | No | 0 | 9 |
| 624 | Nameplate: Software version no. | | | No | No | 0 | 9 |
| 625 | Nameplate: LCP identification no. | | | No | No | 0 | 9 |
| 626 | Nameplate: Database identification no. | | | No | No | -2 | 9 |
| 627 | Nameplate: Power component identification no. | | | No | No | 0 | 9 |
| 628 | Nameplate: Application option type | | | No | No | 0 | 9 |
| 629 | Nameplate: Application option ordering no. | | | No | No | 0 | 9 |
| 630 | Nameplate: Communication option type | | | No | No | 0 | 9 |
| 631 | Nameplate: Communication option ordering no. | | | No | No | 0 | 9 |

Changes during operation:

"Yes" means that the parameter can be changed, while the AFD is in operation. "No" means that the AFD must be stopped before a change can be made.

4-Setup:

"Yes" means that the parameter can be programmed individually in each of the four setups, i.e. the same parameter can have four different data values. "No" means that the data value will be the same in all four setups.

Conversion index:

This number refers to a conversion figure to be used when writing or reading to or from a AFD by means of serial communication.

| Conversion index | Conversion factor |
|------------------|-------------------|
| 74 | 0.1 |
| 2 | 100 |
| 1 | 10 |
| 0 | 1 |
| -1 | 0.1 |
| -2 | 0.01 |
| -3 | 0.001 |
| -4 | 0.0001 |

Data type:

Data type shows the type and length of the telegram.

| Data type | Description |
|-----------|-------------|
| 3 | Integer 16 |
| 4 | Integer 32 |
| 5 | Unsigned 8 |
| 6 | Unsigned 16 |
| 7 | Unsigned 32 |
| 9 | Text string |

■ Option Card (for the four relay option card)

| PNU # | Parameter description | Factory setting | Range | Changes during operation | 4-setup | Con-version index | Data type |
|-------|---------------------------------|-----------------|---------------|--------------------------|---------|-------------------|-----------|
| 700 | Relay 6, Output Function | Running | | Yes | Yes | 0 | 5 |
| 701 | Relay 6, On Delay | 000 sec. | 0 to 600 sec. | Yes | Yes | -2 | 6 |
| 702 | Relay 6, Off Delay | 000 sec. | 0 to 600 sec. | Yes | Yes | -2 | 6 |
| 703 | Relay 7, Output Function | NO FUNCTION | | Yes | Yes | 0 | 5 |
| 704 | Relay 7, On Delay | 000 sec. | 0 to 600 sec. | Yes | Yes | -2 | 6 |
| 705 | Relay 7, Off Delay | 000 sec. | 0 to 600 sec. | Yes | Yes | -2 | 6 |
| 706 | Relay 8, Output Function | NO FUNCTION | | Yes | Yes | 0 | 5 |
| 707 | Relay 8, On Delay | 000 sec. | 0 to 600 sec. | Yes | Yes | -2 | 6 |
| 708 | Relay 8, Off Delay | 000 sec. | 0 to 600 sec. | Yes | Yes | -2 | 6 |
| 709 | Relay 9, Output Function | NO FUNCTION | | Yes | Yes | 0 | 5 |
| 710 | Relay 9, On Delay | 000 sec. | 0 to 600 sec. | Yes | Yes | -2 | 6 |
| 711 | Relay 9, Off Delay | 000 sec. | 0 to 600 sec. | Yes | Yes | -2 | 6 |

| | | | |
|--|-----|--|-------|
| A | | | |
| alarms | 173 | DC braking | 100 |
| analog inputs | 27 | Derating for air pressure | 185 |
| analog outputs: | 27 | Derating for ambient temperature | 185 |
| Address | 154 | Derating for high switching frequency | 186 |
| AEO - Automatic Energy Optimization..... | 29 | Digital inputs | 116 |
| AEO:..... | 5 | Digital inputs: | 5, 26 |
| AFD: | 5 | Digital outputs: | 27 |
| Aggressive environments | 179 | Digital speed up/down | 77 |
| Air humidity | 186 | Direction of IEC motor rotation | 70 |
| Alarm word..... | 162 | Display mode..... | 81 |
| Analog inputs..... | 119 | Display mode I | 81 |
| Analog inputs: | 5 | Display readout | 92 |
| Analog outputs: | 26 | Displaytext | 160 |
| Anti windup | 139 | | |
| Application functions | 128 | E | |
| Auto start on LCP | 93 | EMC test results | 192 |
| Automatic motor adjustment, AMA: | 26 | Earthing/Grounding of shielded/armored control cables | 59 |
| AWG:..... | 26 | Efficiency | 188 |
| | | Electrical installation,..... | 63 |
| B | | Electrical installation, | |
| Baud rate | 144 | Control cables..... | 73 |
| Baudrate..... | 154 | Electrical installation, enclosures..... | 108 |
| Broadcast | 143 | EMC Immunity | 194 |
| Bus connection | 72 | EMC-correct electrical installation | 56 |
| Bus feedback 1 | 160 | Enclosures | 61 |
| | | External 24 Volt DC supply (only available with VLT 8152-8600, | |
| C | | 380-480 V): | 28 |
| Cable lengths and cross-sections: | 28 | Externals:..... | 29 |
| Cables | 50 | Extra protection | 52 |
| CE labelling | 191 | Extreme running conditions | 182 |
| Change parameter data | 86 | | |
| Changing data | 84 | F | |
| Connection example..... | 132 | Factory settings..... | 196 |
| Control and reply telegrams | 143 | Faultlog | 166 |
| Control characteristics | 29 | FC protocol | 143 |
| Control keys | 79 | Feedback | 132 |
| Control principle | 29 | Flyingstart | 128 |
| Cooling..... | 47 | Frequencybypass | 110 |
| Copying of Setups | 89 | Function at line failure | 131 |
| Correct earthing/grounding | 59 | Function at overtemperature..... | 131 |
| | | | |
| D | | G | |
| Data character | 145 | Galvanic isolation (PELV)* | 180 |
| Data control byte | 145 | General technical data | 26 |
| Data log..... | 165 | Ground fault | 182 |
| Dataread-out | 158 | Ground fault (GROUND FAULT) | 175 |
| | | Ground leakage current..... | 181 |

ground potential107

H

Hand start118
 Hand start on LCP 93
 Hand/Auto linked reference107
 Harmonic filter20, 141
 Harmonic filters 20
 Heat emission 55
 High voltage test..... 55

I

Indicator lamps..... 80
 Initialization 85
 Initializing 27
 Inputs and outputs116

L

Low current111
 Language.....160
 LCP copy.....165
 LCP: 28
 Line drop-out182
 Line supply 26
 Line supply 3 x 380 - 480 V..... 33
 Load and motor..... 95
 Lock for data change..... 94
 Lowpass.....140

M

Mechanical installation 47
 Motor Alternation Time.....141
 Motor frequency 97
 Motor thermal protection100
 Motor-generated overvoltage182
 Motorcurrent..... 97
 Motorpower..... 95
 Motorvoltage 96

O

OFF/STOP on LCP..... 93
 Output data..... 26

P

Parallel coupling of motors 70

Parameter Data 86
 PC software..... 13
 Peak voltage on motor183
 PELV: 6
 Potentiometer reference 77
 Power factor190
 Preset reference110
 Programming 88
 Protection 29
 Protocols143
 Pulse feedback118
 Pulse input 27
 Pulse reference118
 Pulse scaling.....124

Q

Quick Menu 86

R

Ramp-down time108
 Ramp-uptime.....107
 RCD181
 Reference handling106
 Reference type109
 References and Limits105
 Relay outputs..... 28
 Relay01126
 Reset on LCP 93
 Resetfunction.....128
 Resulting reference.....180
 RFI switch 53
 Rotation..... 70
 RS 485 serial communication 28

S

screw sizes 69
 Safety regulations 7
 Serial communication.....143
 Service functions164
 Setpoint.....138
 Setup 88
 Setup configuration 88
 Setup of user-defined readout 89
 Shielded/armored cables 50
 Short circuit182
 Single-pole start/stop..... 77
 Sleep mode.....129

| | |
|-------------------------------|-----|
| Software version | 4 |
| Static overload | 182 |
| Status messages | 171 |
| Switches 1-4 | 74 |
| Switching frequency | 130 |
| Switching on the input | 185 |
| Switching on the output | 182 |

T

| | |
|---|------------|
| Technical data, line supply 3 x 200 - 240 V | 31, 32 |
| Technical data, line supply 3 x 525 - 600 V | 38, 39, 40 |
| Telegram build-up | 144 |
| Telegram communication | 143 |
| Telegram length | 144 |
| Tightening torque | 69 |
| Time out | 121 |
| Torque characteristics | 95 |
| Transmitter connection | 77 |
| Trip locked: | 28 |
| Type code ordering number string | 22 |

U

| | |
|---------------------------------|-----|
| Use of EMC-correct cables | 111 |
|---------------------------------|-----|

V

| | |
|-------------------|----|
| Ventilation | 55 |
| VFD: | 28 |

W

| | |
|--------------------------------|-----|
| Warning words | 162 |
| Warning: High reference | 112 |
| Warnings | 173 |
| Warnings and alarms | 173 |
| Wrong earthing/grounding | 59 |

2

| | |
|----------------------------------|----|
| 2-zone regulation | 77 |
| 24 Volt external DC supply | 72 |

5

| | |
|-----------------------------|----|
| 50/60 Hz ground loops | 59 |
|-----------------------------|----|