

Contents

■ How to Read this Design Guide	5
□ How to Read this Design Guide	5
□ Approvals	7
□ Symbols	7
□ Abbreviations	8
□ Definitions	8
□ Power Factor	13
■ Introduction to FC 300	15
□ Software Version	15
□ CE Conformity and Labeling	15
□ What Is Covered	16
□ Danfoss VLT Adjustable Frequency Drive and CE Labeling	16
□ Compliance with EMC Directive 89/336/EEC	17
□ Mechanical Build-Up	18
□ Air Humidity	19
□ Aggressive Environments	19
□ Vibration and Shock	20
□ Control Principle	20
□ FC 300 Controls	21
□ FC 301 vs. FC 302 Control Principle	22
□ Control Structure in VVC ^{plus}	23
□ Control Structure in Flux Sensorless	24
□ Control Structure in Flux with Motor Feedback	25
□ Local (Hand on) and Remote (Auto on) Control	26
□ Reference Handling	28
□ Scaling of References and Feedback	29
□ Analog Reference with Dead Band	30
□ Speed PID Control	34
□ The following parameters are relevant for the Speed Control	34
□ Process PID Control	37
□ Ziegler Nichols Tuning Method	41
□ Internal Current Control	42
□ Parameter Download	42
□ General Aspects of EMC Emissions	43
□ EMC Test Results (Emission, Immunity)	44
□ Required Compliance Levels	45
□ EMC Immunity	45
□ Galvanic Isolation (PELV)	47
□ Ground Leakage Current	47
□ Selection of Brake Resistor	48
□ Control with Brake Function	49
□ Control of Mechanical Brake	50
□ Smart Logic Controller	51
□ Extreme Running Conditions	52
□ Motor Thermal Protection	53
□ Safe Stop of FC 300	53
□ Safe Stop Operation	53

- **How to Select Your VLT** 55
 - Electrical Data 55
 - General Specifications 58
 - Efficiency 63
 - Acoustic Noise 64
 - Peak Voltage on Motor 64
 - Derating for Ambient Temperature 65
 - Derating for Air Pressure 65
 - Derating for Running at Low Speed 65
 - Derating for Installing Long Motor Cables or Cables with Larger Cross-Section 66
 - Temperature-Dependent Switch Frequency 66
 - Options and Accessories 67
 - Encoder Option MCB 102 67
 - Relay Option MCB 105 69
 - 24 V Back-Up Option (Option D) 71
 - Brake Resistors 71
 - Remote mounting Kit for LCP 72
 - IP 21/IP 4X/ TYPE 1 (NEMA 1) Enclosure Kit 72
 - LC Filters 72


- **How to Order** 73
 - Drive Configurator 73
 - Ordering Form Type Code 74
 - Ordering Numbers 77

- **How to Install** 83
 - Mechanical Installation 83
 - Accessory Bag 83
 - IP 21/Type 1 Enclosure Kit 84
 - Safety Requirements of Mechanical Installation 87
 - Field Mounting 87
 - Electrical Installation 88
 - Connection to Mains and Grounding 88
 - Motor connection 89
 - Motor Cables 90
 - Thermal Motor Protection 91
 - Electrical Installation of Motor Cables 92
 - Fuses 93
 - Access to control terminals 95
 - Electrical Installation, Control Terminals 95
 - Terminal 10, analog input voltage 96
 - Electrical Installation, Control Cables 97
 - Switches S201, S202, and S801 98
 - Tightening Torque 99
 - Final Set-Up and Test 99
 - Safe Stop Installation (FC 302 only) 101
 - Safe Stop Commissioning Test 102
 - Additional Connections 103
 - Load sharing 103
 - Installation of Load Sharing 103

□ Brake Connection Option	103
□ Relay connection	104
□ Relay Output	105
□ Parallel Connection of Motors	105
□ Direction of Motor Rotation	106
□ Installation of Brake Cable	106
□ Bus Connection	107
□ How to Connect a PC to the FC 300	107
□ The FC 300 Software Dialog	107
□ High Voltage Test	108
□ Safety Grounding	108
□ Electrical Installation - EMC Precautions	108
□ Use of EMC-Correct Cables	110
□ Grounding of Shielded/Armored Control Cables	111
□ Mains Supply Interference/Harmonics	112
□ Residual Current Device	113
■ Application Examples	115
□ Start/Stop	115
□ Pulse start/stop	115
□ Potentiometer Reference	116
□ Encoder Connection	116
□ Encoder Direction	117
□ Closed Loop Drive System	117
□ Programming of Torque Limit and Stop	118
□ Automatic Motor Adaptation (AMA)	118
□ Smart Logic Control	120
■ How to Program	123
□ The Graphical and Numerical FC 300 Local	123
□ How to Program on the Graphical Local Control Panel	123
□ Quick Transfer of Parameter Settings	127
□ Display Mode	128
□ Display Mode - Selection of Read-Outs	128
□ Parameter Set-Up	129
□ Quick Menu Key Functions	129
□ Main Menu Mode	130
□ Parameter Selection	131
□ Changing Data	131
□ Changing a Text Value	131
□ Changing a Group of Numeric Data Values	132
□ Infinitely Variable Change of Numeric Data Value	132
□ Changing of Data Value, Step-by-Step	133
□ Read-out and Programming of Indexed Parameters	133
□ How to Program on the Numerical Local Control Panel	134
□ Local Control Keys	135
□ Initialization to Default Settings	137
□ Parameter Selection - FC 300	138
□ Parameters: Operation and Display	139
□ Parameters: Load and Motor	148

□ Parameters: Brakes	159
□ Parameters: Reference/Ramps	162
□ Parameters: Limits/Warnings	171
□ Parameters: Digital In/Out	174
□ Parameters: Analog In/Out	183
□ Parameters: Controllers	187
□ Parameters: Communications and Options	190
□ Parameters: Profibus	194
□ Parameters: DeviceNet CAN Fieldbus	200
□ Parameters: Smart logic control	203
□ Parameters: Special functions	213
□ Parameters: Drive information	217
□ Parameters: Data readouts	222
□ Parameters: Motor Feedb.Option	227
□ Parameter lists	228
□ Protocols	243
□ Telegram Traffic	243
□ Telegram Structure	243
□ Data Character (byte)	245
□ Process Words	250
□ Control Word According to FC Profile (CTW)	251
□ Status Word According to FC Profile (STW)	254
□ Control Word according to PROFIdrive Profile (CTW)	256
□ Status Word According to PROFIdrive Profile (STW)	259
□ Serial Communication Reference	261
□ Present Output Frequency	262
□ Example 1: For Controlling the Drive and Reading Parameters	262
□ Example 2: Only for Controlling the Drive	263
□ Read Parameter Description Elements	263
□ Additional Text	269
■ Troubleshooting	271
□ Warnings/Alarm Messages	271
■ Index	279


How to Read this Design Guide



□ **How to Read this Design Guide**


This Design Guide will introduce all aspects of your FC 300.

Chapter 1, **How to Read this Design Guide**, introduces the design guide and provides information about the approvals, symbols, and abbreviations used in this manual.




Page divider for How to Read this Design Guide.

Chapter 2, **Introduction to FC 300**, provides information about available features and instructions on how to handle the FC 300 correctly.



Page divider for Introduction to FC 300.

Chapter 3, **How to Select Your VLT**, how to select the right FC 300 model for the application.




Page divider for How to Select Your VLT.

— How to Read this Design Guide —




Chapter 4, **How to Order**, supplies the information needed for ordering the FC 300.




Page divider for How to Order.

Chapter 5, **How to Install**, provides information about the mechanical and electrical installation.



Page divider for How to Install

Chapter 6, **Application Examples**, shows some typical applications.



Page divider for Application Examples

Chapter 7, **How to Program**, information on how to operate and program the FC 300 via the Local Control Panel.



Page divider for How to Program.

Chapter 8, **Troubleshooting**, guidance in solving problems that may occur when using FC 300.



Page divider for Troubleshooting.

Available literature for FC 300

- The VLT® AutomationDrive FC 300 Instruction Manual MG.33.AX.YY provides the necessary information for getting the drive up and running.
- The VLT® AutomationDrive FC 300 Design Guide MG.33.BX.YY entails all technical information about the drive and customer design and applications.
- The VLT® AutomationDrive FC 300 Profibus Instruction Manual MG.33.CX.YY provides the information required for controlling, monitoring, and programming the drive via a Profibus serial communication bus.

— How to Read this Design Guide —

- The VLT® AutomationDrive FC 300 DeviceNet Instruction Manual MG.33.DX.YY provides the information required for controlling, monitoring, and programming the drive via a DeviceNet serial communication bus.

Danfoss Drives technical literature is also available online at www.danfoss.com/BusinessAreas/DrivesSolutions/Documentations/Technical+Documentation.

□ **Approvals**



□ **Symbols**

Symbols used in this Design Guide.



NOTE

Indicates something to be noted by the reader.



Indicates a general warning.



Indicates a high-voltage warning.



Indicates default setting




Abbreviations

Alternating current	AC
American wire gauge	AWG
Ampere/AMP	A
Automatic Motor Adaptation	AMA
Current limit	I_{LIM}
Degrees Celsius	°C
Direct current	DC
Drive Dependent	D-TYPE
Electronic Thermistor Relay	ETR
Adjustable Frequency Drive	AFD
Gram	g
Hertz	Hz
Kilohertz	kHz
Local Control Panel	LCP
Meter	m
Milliampere	mA
Millisecond	ms
Minute	min
Motion Control Tool	MCT
Motor Type Dependent	M-TYPE
Nanofarad	nF
Newton meter	Nm
Nominal motor current	$I_{M,N}$
Nominal motor frequency	$f_{M,N}$
Nominal motor power	$P_{M,N}$
Nominal motor voltage	$U_{M,N}$
Parameter	par.
Rated Inverter Output Current	I_{INV}
Revolutions per minute	RPM
Second	s
Torque limit	T_{LIM}
Volt	V

Definitions**Drive:**D-TYPE

Size and type of the connected drive (dependencies).

 $I_{VLT,MAX}$

The maximum output current.

 $I_{VLT,N}$

The rated output current supplied by the adjustable frequency drive.

 $U_{VLT, MAX}$

The maximum output voltage.

— How to Read this Design Guide —

Input:Control command

You can start and stop the connected motor by means of LCP and the digital inputs.

Functions are divided into two groups.

Functions in group 1 have higher priority than functions in group 2.

Group 1	Reset, Coasting stop, Reset and Coasting stop, Quick-stop, DC braking, Stop and the "Off" key.
Group 2	Start, Pulse start, Reverse, Start reverse, Jog and Freeze output

**Motor:** f_{JOG}

The motor frequency when the jog function is activated (via digital terminals).

 f_M

The motor frequency.

 f_{MAX}

The maximum motor frequency.

 f_{MIN}

The minimum motor frequency.

 $f_{M,N}$

The rated motor frequency (nameplate data).

 I_M

The motor current.

 $I_{M,N}$

The rated motor current (nameplate data).

M-TYPE

Size and type of the connected motor (dependencies).

 $n_{M,N}$

The rated motor speed (nameplate data).

 $P_{M,N}$

The rated motor power (nameplate data).

 $T_{M,N}$

The rated torque (motor).

 U_M


The instantaneous motor voltage.

 $U_{M,N}$

The rated motor voltage (nameplate data).

— How to Read this Design Guide —

Break-away torque



η_{VLT}

The efficiency of the adjustable frequency drive is defined as the ratio between the power output and the power input.

Start-disable command

A stop command belonging to the group 1 control commands - see this group.

Stop command

See Control commands.

References:

Analog Reference

A signal transmitted to the analog inputs 53 or 54, can be voltage or current.

Binary Reference

A signal transmitted to the serial communication port.

Preset Reference

A defined preset reference to be set from -100% to +100% of the reference range. Selection of eight preset references via the digital terminals.

Pulse Reference

A pulse frequency signal transmitted to the digital inputs (terminal 29 or 33).

Ref_{MAX}

Determines the relationship between the reference input at 100% full scale value (typically 10 V, 20mA) and the resulting reference. The maximum reference value set in par. 3-03.

Ref_{MIN}

Determines the relationship between the reference input at 0% value (typically 0V, 0mA, 4mA) and the resulting reference. The minimum reference value set in par. 3-02.

Miscellaneous:

Analog Inputs

The analog inputs are used for controlling various functions of the adjustable frequency drive.

There are two types of analog inputs:

Current input, 0-20 mA and 4-20 mA

Voltage input, 0-10 V DC (FC 301)

Voltage input, -10 - +10 V DC (FC 302).

— How to Read this Design Guide —

Analog Outputs

The analog outputs can supply a signal of 0-20 mA, 4-20 mA, or a digital signal.

Automatic Motor Adaptation, AMA

AMA algorithm determines the electrical parameters for the connected motor at standstill.

Brake Resistor

The brake resistor is a module capable of absorbing the braking energy generated in regenerative braking. This regenerative braking energy increases the intermediate circuit voltage and a brake chopper ensures that the energy is transmitted to the brake resistor.

CT Characteristics

Constant torque characteristics used for all applications such as conveyor belts, displacement pumps, and cranes.

Digital Inputs

The digital inputs can be used for controlling various functions of the adjustable frequency drive.

Digital Outputs

The drive features two solid state outputs that can supply a 24 V DC (max. 40 mA) signal.

DSP

Digital Signal Processor.

Relay Outputs:

The FC 301 drive features one programmable Relay Output.

The FC 302 drive features two programmable Relay Outputs.

ETR

Electronic Thermal Relay is a thermal load calculation based on present load and time. Its purpose is to estimate the motor temperature.

Hiperface®

Hiperface® is a registered trademark of Stegmann.

Initializing

If initializing is carried out (par. 14-22), the adjustable frequency drive returns to the default setting.

Intermittent Duty Cycle

An intermittent duty rating refers to a sequence of duty cycles. Each cycle consists of an on-load and an off-load period. The operation can be either periodic duty or non-periodic duty.

LCP

The Local Control Panel (LCP) makes up a complete interface for control and programming of the FC 300 Series. The control panel is detachable and can be installed up to 9.8 ft (3 meters) from the adjustable frequency drive, i.e. in a front panel by means of the installation kit option.

lsb

Least significant bit.

MCM

Short for Mille Circular Mil, an American measuring unit for cable cross-section.

1 MCM \equiv 0.00079 in.² (0.5067 mm²).

msb

Most significant bit.



— How to Read this Design Guide —



Online/Offline Parameters

Changes to online parameters are activated immediately after the data value is changed. Changes to offline parameters are not activated until you enter [OK] on the LCP.

Process PID

The PID regulator maintains the desired speed, pressure, temperature, etc. by adjusting the output frequency to match the varying load.

Pulse Input/Incremental Encoder

An external, digital pulse transmitter used for feeding back information on motor speed. The encoder is used in applications where great accuracy in speed control is required.

RCD

Residual Current Device.

Set-up

You can save parameter settings in four set-ups. Change between the four parameter set-ups and edit one set-up while another set-up is active.

SFAVM

Switching pattern called Stator Flux oriented Asynchronous Vector Modulation (par. 14-00).

Slip Compensation

The adjustable frequency drive compensates for the motor slip by giving the frequency a supplement that follows the measured motor load keeping the motor speed almost constant..

Smart Logic Control (SLC)

The SLC is a sequence of user-defined actions executed when the associated user-defined events are evaluated as true by the SLC.

Thermistor:

A temperature-dependent resistor placed where the temperature is to be monitored (adjustable frequency drive or motor).

Trip

A state entered in fault situations, e.g. if the adjustable frequency drive is subject to an over-temperature or when the adjustable frequency drive is protecting the motor, process, or mechanism. Restart is prevented until the cause of the fault has disappeared and the trip state is cancelled by activating reset or, in some cases, by being programmed to reset automatically. Trip may not be used for personal safety.

Trip-Locked

A state entered in fault situations when the adjustable frequency drive is protecting itself and requiring physical intervention, e.g. if the adjustable frequency drive is subject to a short circuit on the output. A locked trip can only be cancelled by cutting off AC line, removing the cause of the fault, and reconnecting the adjustable frequency drive. Restart is prevented until the trip state is cancelled by activating reset or, in some cases, by being programmed to reset automatically. Trip may not be used for personal safety.

VT Characteristics

Variable torque characteristics used for pumps and fans.

VVC^{plus}

Compared with standard voltage/frequency ratio control, Voltage Vector Control (VVC^{plus}) improves the dynamics and the stability, both when the speed reference is changed and in relation to the load torque.

— How to Read this Design Guide —

60° AVM

Switching pattern called 60° A synchronous Vector Modulation (par. 14-00).

□ **Power Factor**

The power factor is the relation between I_1 and I_{RMS} .

$$\text{Power factor} = \frac{\sqrt{3} \times U \times I_1 \times \cos\varphi}{\sqrt{3} \times U \times I_{RMS}}$$

The power factor for 3-phase control:

$$= \frac{I_1 \times \cos\varphi_1}{I_{RMS}} = \frac{I_1}{I_{RMS}} \text{ since } \cos\varphi_1 = 1$$

The power factor indicates to what extent the adjustable frequency drive imposes a load on the mains supply.

The lower the power factor, the higher the I_{RMS} for the same HP/kW performance.

$$I_{RMS} = \sqrt{I_1^2 + I_5^2 + I_7^2 + \dots + I_n^2}$$


In addition, a high power factor indicates that the different harmonic currents are low. The FC 300 adjustable frequency drives' built-in DC coils produce a high power factor, which minimizes the imposed load on the mains supply.



— How to Read this Design Guide —



Introduction to FC 300



FC 300

Design Guide
Software version: 2.5x

130BA140.11

This Design Guide can be used for all FC 300 adjustable frequency drives (AFD) with software version 2.5x. The software version number can be seen from parameter 15-43.

□ **CE Conformity and Labeling**

What is CE Conformity and Labeling?

The purpose of CE labeling is to avoid technical trade obstacles within EFTA and the EU. The EU has introduced the CE label as a simple way of showing whether a product complies with the relevant EU directives. The CE label says nothing about the specifications or quality of the product. Adjustable frequency drives are regulated by three EU directives:

The machinery directive (98/37/EEC)

All machines with critical moving parts are covered by the machinery directive of January 1, 1995. Since an adjustable frequency drive is largely electrical, it does not fall under the machinery directive. However, if

— Introduction to FC 300 —

an adjustable frequency drive is supplied for use in a machine, we provide information on safety aspects relating to the adjustable frequency drive. We do this by means of a manufacturer's declaration.

The low-voltage directive (73/23/EEC)

Adjustable frequency drives must be CE-labeled in accordance with the low-voltage directive of January 1, 1997. The directive applies to all electrical equipment and appliances used in the 50 - 1000 V AC and the 75 - 1500 V DC voltage ranges. Danfoss CE-labels in accordance with the directive and issues a declaration of conformity upon request.

The EMC directive (89/336/EEC)

EMC is short for electromagnetic compatibility. The presence of electromagnetic compatibility means that the mutual interference between different components/appliances does not affect the way the appliances work. The EMC directive came into effect January 1, 1996. Danfoss CE-labels in accordance with the directive and issues a declaration of conformity upon request. To carry out EMC-correct installation, see the instructions in this Design Guide. In addition, we specify which standards our products comply with. We offer the filters presented in the specifications and provide other types of assistance to ensure the optimum EMC result.

The adjustable frequency drive is most often used by professionals of the trade as a complex component forming part of a larger appliance, system or installation. It must be noted that the responsibility for the final EMC properties of the appliance, system, or installation lies with the installer.



□ **What Is Covered**

The EU "Guidelines on the Application of Council Directive 89/336/EEC" outline three typical situations of using an adjustable frequency drive. See following for EMC coverage and CE labeling.

1. The adjustable frequency drive is sold directly to the end consumer. The adjustable frequency drive is for example sold to a DIY market. The end consumer is a layman. He installs the adjustable frequency drive himself for use with a hobby machine, a kitchen appliance, etc. For such applications, the adjustable frequency drive must be CE-labeled in accordance with the EMC directive.
2. The adjustable frequency drive is sold for installation in a plant. The plant is built up by professionals of the trade. It could be a production plant or a heating/ventilation plant designed and installed by professionals of the trade. Neither the adjustable frequency drive nor the finished plant must be CE-labeled under the EMC directive. However, the unit must comply with the basic EMC requirements of the directive. This is ensured by using components, appliances, and systems that are CE-labeled under the EMC directive.
3. The adjustable frequency drive is sold as part of a complete system. The system is being marketed as complete and could be e.g. an air conditioning system. The complete system must be CE-labeled in accordance with the EMC directive. The manufacturer can ensure CE labeling under the EMC directive either by using CE-labeled components or by testing the EMC of the system. If it chooses to use only CE-labeled components, it does not have to test the entire system.

□ **Danfoss VLT Adjustable Frequency Drive and CE Labeling**

CE labeling is a positive feature when used for its original purpose, i.e. to facilitate trade within the EU and EFTA.

However, CE labeling may cover many different specifications. Thus, you must check what a given CE label specifically covers.

The covered specifications can be very different and a CE label may therefore give the installer a false sense of security when using an adjustable frequency drive as a component in a system or an appliance.

Danfoss CE labels the adjustable frequency drives in accordance with the low-voltage directive. This means that if the adjustable frequency drive is installed correctly, we guarantee compliance

— Introduction to FC 300 —

with the low-voltage directive. Danfoss issues a declaration of conformity that confirms our CE labeling in accordance with the low-voltage directive.

The CE label also applies to the EMC directive provided that the instructions for EMC-correct installation and filtering are followed. On this basis, a declaration of conformity in accordance with the EMC directive is issued.

The Design Guide offers detailed instructions for installation to ensure EMC-correct installation. Furthermore, Danfoss specifies which our different products comply with.

Danfoss gladly provides other types of assistance that can help you obtain the best EMC result.

□ **Compliance with EMC Directive 89/336/EEC**

As mentioned, the adjustable frequency drive is mostly used by professionals of the trade as a complex component forming part of a larger appliance, system, or installation. It must be noted that the responsibility for the final EMC properties of the appliance, system, or installation lies with the installer. As an aid to the installer, Danfoss has prepared EMC installation guidelines for the Power Drive System. The standards and test levels stated for Power Drive Systems are complied with, provided that the EMC-correct instructions for installation are followed, see section *Electrical Installation*.



□ **Mechanical Build-Up**




Illustration of the mechanical build-up of FC 300. The exact unit dimensions are listed in the chapter *How to Install*.

— Introduction to FC 300 —

A	<p>Cold plate technology</p> <p>The adjustable frequency drive is built upon a very stable aluminum base integrated with the back panel. This provides high mechanical stability, efficient cooling, and the possibility of cold plate operation. The cold plate serves as a flat cooling surface on the adjustable frequency drive, where a majority of the heat dissipates from the electronics to an external cooling surface.</p>
B	<p>DC coil</p> <p>The built-in DC coil ensures low harmonic disturbance of the power supply according to IEC-1000-3-2.</p>
C	<p>Air-guiding shield</p> <p>The shield allows cold air to pass by the electronics only. The plastic air guide shield is enclosed in the package and is easily snapped in place. If the adjustable frequency drive is to operate as a cold plate drive, the air-guiding shield is inserted in the cooling channel through the bottom of the drive if it is snapped onto the fan. Thus, the amount of heat transferred to the surroundings via the cooling air from the fan is reduced.</p>
D	<p>Removable fan</p> <p>Like most of the elements, the fan can easily be removed for cleaning and remounted.</p>
E	<p>Safe Stop (FC 302 only)</p> <p>The adjustable frequency drive comes standard prepared for installations with the safe stop functionality for stop category 0 (EN 60204-1) with safety category 3 (EN 954-1). This feature prevents the drive from starting unintentionally.</p>
F	<p>Control terminals</p> <p>Spring-loaded cage clamps and screwless terminals contribute to reliability and facilitate easy commissioning and service.</p>
G	<p>Options</p> <p>Options for bus communication, I/O extension, etc. can be delivered extra or ordered built-in (and tested together with the drive) from the factory. Options mounted under the LCP are referred to as option Slot A (top) and option Slot B (bottom). Option C is mounted on the side of the drive, while option D is mounted underneath the control cable decoupling plate.</p>
H	<p>Local Control Panel</p> <p>The LCP 102 has a graphical user interface. Choose between 27 built-in languages (including Chinese) or have it customized with your own languages and phrases. Additionally a simple version, LCP 101, is available with an alpha-numeric display. The complete programming of FC 301 and FC 302 can be handled by both LCPs.</p>
J	<p>Hot-pluggable LCP</p> <p>The LCP can be plugged in or out during operation. Settings are easily transferred via the control panel from one drive to another or from a PC with the MCT-10 set-up software.</p>



□ **Air Humidity**

The adjustable frequency drive has been designed to meet the IEC/EN 60068-2-3 standard, EN 50178 pkt. 9.4.2.2 at 122 °F (50°C).

□ **Aggressive Environments**

An adjustable frequency drive contains a large number of mechanical and electronic components. All are to some extent vulnerable to environmental effects.

— Introduction to FC 300 —



The adjustable frequency drive should not be installed in environments with airborne liquids, particles, or gases capable of affecting and damaging the electronic components.

Failure to take the necessary protective measures increases the risk of stoppages, thus reducing the life of the adjustable frequency drive.

Liquids can be carried through the air and condense in the adjustable frequency drive and may cause corrosion of components and metal parts. Steam, oil, and salt water may cause corrosion of components and metal parts. In such environments, use equipment with enclosure rating IP 55. As an extra protection, coated printed circuit boards can be ordered as an option.

Airborne Particles such as dust may cause mechanical, electrical, or thermal failure in the adjustable frequency drive. A typical indicator of excessive levels of airborne particles is dust particles around the adjustable frequency drive fan. In very dusty environments, use equipment with enclosure rating IP 55 or a cabinet for IP 00/IP 20/TYPE 1 equipment.

In environments with high temperatures and humidity, corrosive gases such as sulfur, nitrogen, and chlorine compounds will cause chemical processes on the adjustable frequency drive components.

Such chemical reactions will rapidly affect and damage the electronic components. In such environments, mount the equipment in a cabinet with fresh air ventilation, keeping aggressive gases away from the adjustable frequency drive.

An extra protection in such areas is a coating of the printed circuit boards, which can be ordered as an option.



NOTE

Mounting adjustable frequency drives in aggressive environments increases the risk of stoppages and considerably reduces the life of the drive.

Before installing the adjustable frequency drive, check the ambient air for liquids, particles, and gases. This is done by observing existing installations in this environment. Typical indicators of harmful airborne liquids are water or oil on metal parts, or corrosion of metal parts.

Excessive dust particle levels are often found on installation cabinets and existing electrical installations. One indicator of aggressive airborne gases is blackening of copper rails and cable ends on existing installations.

□ **Vibration and Shock**

The adjustable frequency drive has been tested according to a procedure based on the shown standards:

IEC/EN 60068-2-6:	Vibration (sinusoidal) - 1970
IEC/EN 60068-2-64:	Vibration, broad-band random

The adjustable frequency drive complies with requirements that exist for units mounted on the walls and floors of production premises, as well as in panels bolted to walls or floors.

□ **Control Principle**

An adjustable frequency drive rectifies AC voltage from line into DC voltage, after which this DC voltage is converted into an AC current with a variable amplitude and frequency.

The motor is supplied with variable voltage / current and frequency, which enables infinitely variable speed control of three-phased, standard AC motors and permanent magnet synchronous motors.

— Introduction to FC 300 —

□ **FC 300 Controls**

The adjustable frequency drive is capable of controlling either the speed or the torque on the motor shaft. Setting par. 1-00 determines the type of control.

Speed control:

There are two types of speed control:

- Speed open loop control which does not require any feedback (sensorless).
- Speed closed-loop control in the form of PID control that requires speed feedback to an input. Properly optimized speed closed-loop control will have higher accuracy than speed open loop control.

Selects which input to use as speed PID feedback in par. 7-00.

Torque control (FC 302 only):

Torque control is part of the motor control and correct settings of motor parameters are very important. The accuracy and settling time of the torque control are determined from *Flux w motor feedb* (par. 1-01 *Motor Control Principle*).

- Flux sensorless offers superior performance in all four quadrants at motor frequencies above 10 Hz.
- Flux with encoder feedback offers superior performance in all four quadrants and at all motor speeds.

The "Flux w encoder feedb" mode requires that an encoder speed feedback signal is present. Select which input to use in par. 1-02.

Speed / torque reference:

The reference to these controls can either be a single reference or the sum of various references including relatively scaled references. The handling of references is explained in detail later in this section.




— Introduction to FC 300 —

□ **FC 301 vs. FC 302 Control Principle**

FC 301 is a general-purpose adjustable frequency drive for variable speed applications. The control principle is based on space Voltage Vector Control (VVC^{plus}).

FC 301 can handle asynchronous motors only.


The current sensing principle in FC 301 is based on sum current measurement in the DC link. The ground fault protection on the motor side is solved by a de-saturation circuit in the IGBTs.



FC 302 is a high-performance adjustable frequency drive for demanding applications. The adjustable frequency drive can handle various kinds of motor control principles such as U/ special motor mode, VVC^{plus} or Flux Vector motor control.

FC 302 is able to handle Permanent Magnet Synchronous Motors (Brushless servo motors) as well as normal squirrel cage asynchronous motors.


The current sensing principle in FC 302 actually senses the current in each motor phase. The advantage of having a current transducer in each phase is to have full ground failure protection.



— Introduction to FC 300 —

□ **Control Structure in VVC^{plus}**

Control structure in VVC^{plus} open loop and closed-loop configurations:



In the configuration shown in the illustration above, par. 1-01 *Motor Control Principle* is set to "VVC^{plus} [1]" and par. 1-00 is set to "Speed open loop [0]". The resulting reference from the reference handling system is received and fed through the ramp limitation and speed limitation before being sent to the motor control. The output of the motor control is then limited by the maximum frequency limit.


If par. 1-00 is set to "Speed closed-loop [1]", the resulting reference will be passed from the ramp limitation and speed limitation into a speed PID control. The Speed PID control parameters are located in the par. group 7-0*. The resulting reference from the Speed PID control is sent to the motor control limited by the frequency limit.

Select "Process [3]" in par. 1-00 to use the process PID control for closed-loop control of e.g. speed or pressure in the controlled application. The Process PID parameters are located in par. group 7-2* and 7-3*. *Process PID is not available in this software release.*

— Introduction to FC 300 —

□ **Control Structure in Flux Sensorless**

Control structure in Flux sensorless open loop and closed-loop configurations. (Only available in FC 302):




In the shown configuration, par. 1-01 *Motor Control Principle* is set to "Flux sensorless [2]" and par. 1-00 is set to "Speed open loop [0]". The resulting reference from the reference handling system is fed through the ramp and speed limitations as determined by the parameter settings indicated.

An estimated speed feedback is generated to the Speed PID to control the output frequency. The Speed PID must be set with its P, I, and D parameters (par. group 7-0*).

Select "Process [3]" in par. 1-00 to use the process PID control for closed-loop control of i.e. speed or pressure in the controlled application. The Process PID parameters are found in par. group 7-2* and 7-3*. *Process PID is not available in this software release.*

□ **Control Structure in Flux with Motor Feedback**

Control structure in Flux with motor feedback configuration (only available in FC 302):



In the shown configuration, par. 1-01 *Motor Control Principle* is set to "Flux w encoder feedb [3]" and par. 1-00 is set to "Speed closed loop [1]".

The motor control in this configuration relies on a feedback signal from an encoder mounted directly on the motor (set in par. 1-02 *Motor Shaft Encoder Source*).

Select "Speed closed-loop [1]" in par. 1-00 to use the resulting reference as an input for the Speed PID control. The Speed PID control parameters are located in par. group 7-0*.

Select "Torque [2]" in par. 1-00 to use the resulting reference directly as a torque reference. Torque control can only be selected in the *Flux with motor feedback* (par. 1-01 *Motor Control Principle*) configuration. When this mode has been selected, the reference will use the Nm unit. It requires no torque feedback, since the torque is calculated on the basis of the current measurement of the adjustable frequency drive. All parameters are selected automatically on the basis of the set motor parameters in connection with torque control.


Select "Process [3]" in par. 1-00 to use the process PID control for closed-loop control of e.g. speed or a process variable in the controlled application.

□ **Local (Hand on) and Remote (Auto on) Control**


The adjustable frequency drive can be operated manually via the local control panel (LCP) or remotely via analog and digital inputs and serial bus. If allowed in par. 0-40, 0-41, 0-42, and 0-43, it is possible to start and stop the adjustable frequency drive via the LCP using the [Off] and [Hand] keys. Alarms can be reset via the [RESET] key. After pressing [Hand on] key, the adjustable frequency drive goes into Hand mode and follows the Local reference that can be set using arrow key on the LCP.



After pressing the [Auto on] key, the adjustable frequency drive goes into Auto mode and follows the Remote reference. In this mode, it is possible to control the adjustable frequency drive via the digital inputs and various serial interfaces (RS-485, USB, or an optional serial communication bus). See more about starting, stopping, changing ramps and parameter set-ups, etc. in par. group 5-1* (digital inputs) or par. group 8-5* (serial communication).



Par. 3-13 *Reference Site* can be chosen to always select either *Local (Hand)* [2] or *Remote (Auto)* [1] reference regardless of whether the adjustable frequency drive is in *Auto mode* or *Hand mode*.



(Hand on) and Remote (Auto on) Control

Hand Off Auto LCP Keys	Reference Site Par. 3-13	Active Reference
Hand	Linked to Hand / Auto	Local
Hand -> Off	Linked to Hand / Auto	Local
Auto	Linked to Hand / Auto	Remote
Auto -> Off	Linked to Hand / Auto	Remote
All keys	Local	Local
All keys	Remote	Remote


The table shows under which conditions either the Local reference or the Remote reference is active. One of them is always active, but both cannot be active at the same time.

Par. 1-00 *Configuration Mode* determines what kind of application control principle (i.e. Speed, Torque or Process Control) is used when the Remote reference is active (see table above for the conditions).

Par. 1-05 *Local Mode Configuration* determines the kind of application control principle that is used when the Local reference is made active.

Reference handling

The reference handling system for calculating the Remote reference is shown in the illustration below.



— Introduction to FC 300 —

The Remote reference is calculated once every scan interval and initially consists of two parts:

1. X (the external reference) : A sum of up to four externally selected references, comprising any combination (determined by the setting of par. 3-15, 3-16 and 3-17) of a fixed preset reference (par. 3-10), variable analog references, variable digital pulse references, and various serial bus references in whatever unit the adjustable frequency drive is controlled ([Hz], [RPM], [Nm] etc.).
2. Y- (the relative reference): A sum of one fixed preset reference (par. 3-14) and one variable analog reference (par. 3-18) in [%].

The two parts are combined in the following calculation: $\text{Auto reference} = X + X * Y / 100\%$. The *Catch up / slow-down* function and the *Freeze reference* function can both be activated by digital inputs on the adjustable frequency drive. They are described in par. group 5-1*.

The scaling of analog references is described in par. groups 6-1* and 6-2*, and the scaling of digital pulse references is described in par. group 5-5*.

Reference limits and ranges are set in par. group 3-0*.

References and feedback can be scaled in physical units (i.e. RPM, Hz, °C) or simply in % relating to the values of par. 3-02 *Minimum Reference* and par. 3-03 *Maximum Reference*.



In this case, all analog and pulse inputs are scaled according to the following rules:

- When par. 3-00 *Reference Range* is [0] Min - Max, 0% reference equals 0 [unit], where unit can be any unit e.g. rpm, m/s, bar etc., 100% reference equals the Max (abs (par. 3-03 *Maximum Reference*), abs (par. 3-02 *Minimum Reference*)).
- When par. 3-00 *Reference Range*: [1] -Max - +Max, 0% reference equals 0 [unit], -100% reference equals -Max Reference, 100% reference equals Max Reference.

Bus references are scaled according to the following rules:


- When par. 3-00 *Reference Range* is [0] Min - Max. To obtain max resolution on the bus reference, the scaling on the bus is: 0% reference equals Min Reference, 100% reference equals Max reference.
- When par. 3-00 *Reference Range*: [1] -Max - +Max, -100% reference equals -Max Reference, 100% reference equals Max Reference.

Par. 3-00 *Reference Range*, 3-02 *Minimum Reference* and 3-03 *Maximum Reference* together define the allowed range of the sum of all references. The sum of all references is clamped when necessary. The relation between the resulting reference (after clamping) and the sum of all references is shown below.





— Introduction to FC 300 —

The value of par. 3-02 *Minimum Reference* can not be set to less than 0, unless par. 1-00 *Configuration Mode* is set to [3] *Process*. In this case, the subsequent relations between the resulting reference (after clamping) and the sum of all references are as shown to the right.



References and feedback are scaled from analog and pulse inputs in the same way. The only difference is that a reference above or below the specified minimum and maximum "endpoints" (P1 and P2 in the graph below) are clamped whereas a feedback above or below is not.



The endpoints P1 and P2 are defined by the following parameters, depending on which analog or pulse input is used



— Introduction to FC 300 —

	Analog 53 S201=OFF	Analog 53 S201=ON	Analog 54 S202=OFF	Analog 54 S202=ON	Pulse Input 29	Pulse Input 33
P1 = (Minimum input value, Minimum reference value)						
Minimum reference value	Par. 6-14	Par. 6-14	Par. 6-24	Par. 6-24	Par. 5-52	Par. 5-57
Minimum input value	Par. 6-10 [V]	Par. 6-12 [mA]	Par. 6-20 [V]	Par. 6-22 [mA]	Par. 5-50 [Hz]	Par. 5-55 [Hz]
P2 = (Maximum input value, Maximum reference value)						
Maximum reference value	Par. 6-15	Par. 6-15	Par. 6-25	Par. 6-25	Par. 5-53	Par. 5-58
Maximum input value	Par. 6-11 [V]	Par. 6-13 [mA]	Par. 6-21 [V]	Par. 6-23 [mA]	Par. 5-51 [Hz]	Par. 5-56 [Hz]

In some cases, the reference (in rare cases also the feedback) should have a Dead Band around zero (i.e. to make sure the machine is stopped when the reference is "near zero"). To make the dead band active and to set the amount of dead band, the following settings must be done:

- Either Minimum Reference Value (see table above for relevant parameter) or Maximum Reference Value must be zero. In other words; Either P1 or P2 must be on the X-axis in the graph below.
- And both points defining the scaling graph are in the same quadrant.

The size of the Dead Band is defined by either P1 or P2 as shown in the graph below.




Thus a reference endpoint of P1 = (0 V, 0 RPM) will not result in any dead band.

— Introduction to FC 300 —

Case 1: Positive Reference with Dead band, Digital input to trigger reverse


This Use Case shows how Reference input with limits inside Min - Max limits clamps.



— Introduction to FC 300 —


Use Case 2: Positive Reference with Dead band, Digital input to trigger reverse. Clamping rules.

This Use Case shows how Reference input with limits outside -Max - +Max limits clamps to the inputs low and high limits before addition to External reference. And how the External reference is clamped to -Max - +Max by the Reference algorithm.



— Introduction to FC 300 —

Use Case 3: Negative to positive reference with dead band, Sign determines the direction, -Max - +Max



— Introduction to FC 300 —

□ **Speed PID Control**

The table shows the control configurations where the Speed Control is active. To see where the Speed Control is active, please refer to the section about the Control Structure.

Par. 1-00 Configuration Mode	Par. 1-01 Motor Control Principle			
	U/f	VVCplus	Flux sensorless	Flux w motor feedb
[0] Speed open loop	Not Active	Not Active	ACTIVE	N.A.
[1] Speed closed-loop	N.A.	ACTIVE	N.A.	ACTIVE
[2] Torque	N.A.	N.A.	N.A.	Not Active
[3] Process open-loop	N.A.	Not Active	ACTIVE	ACTIVE

Note: "N.A." means that the specific mode is not available at all. "Not Active" means that the specific mode is available but the Speed Control is not active in that mode.

Note: The Speed Control PID will work under the default parameter setting, but tuning the parameters is highly recommended to optimize the motor control performance. The two Flux motor control principles are specially dependent on proper tuning to yield their full potential.

The following parameters are relevant for the Speed Control:

Parameter	Description of function
Speed PID Feedback Resource Par. 7-00	Select from which resource (i.e. analog or pulse input) the Speed PID should get its feedback
Speed PID Proportional Gain Par. 7-02	The higher the value, the quicker the control. However, too high a value may lead to oscillations.
Speed PID Integral Time Par. 7-03	Eliminates steady state speed error. Lower value means quick reaction. However, too low a value may lead to oscillations.
Speed PID Differentiation Time Par. 7-04	Provides a gain proportional to the rate of change of the feedback. A setting of zero disables the differentiator.
Speed PID Diff. Gain Limit Par. 7-05	If there are quick changes in reference or feedback in a given application - which means that the error changes swiftly - the differentiator may soon become too dominant. This is because it reacts to changes in the error. The quicker the error changes, the stronger the differentiator gain is. The differentiator gain can thus be limited to allow setting of the reasonable differentiation time for slow changes and a suitably quick gain for quick changes.
Speed PID Lowpass Filter Time Par. 7-06	A low-pass filter that dampens oscillations on the feedback signal and improves steady state performance. However, too large a filter time will deteriorate the dynamic performance of the Speed PID control.

— Introduction to FC 300 —


Below is given an example of how to program the Speed Control:

In this case, the Speed PID Control is used to maintain a constant motor speed regardless of the changing load on the motor.

The required motor speed is set via a potentiometer connected to terminal 53. The speed range is 0 - 1500, corresponding to 0 - 10V over the potentiometer.

Starting and stopping is controlled by a switch connected to terminal 18.


The Speed PID monitors the actual RPM of the motor by using a 24V (HTL) incremental encoder as feedback. The feedback sensor is an encoder (1024 pulses per revolution) connected to terminals 32 and 33.



— Introduction to FC 300 —

In the parameter list below, it is assumed that all other parameters and switches remain at their default setting.

The following must be programmed in the order shown - see explanation of settings in the section "How to Program."



Function	Par. no.	Setting
1) Make sure the motor runs properly. Do the following:		
Set the motor parameters using nameplate data	1-2*	As specified by motor nameplate
Have the VLT make an Automatic Motor Adaptation	1-29	[1] Enable complete AMA
2) Check that the motor is running and the encoder is attached properly. Do the following:		
Press the "Hand On" LCP key. Check that the motor is running and note in which direction it is turning (henceforth referred to as the "positive direction").		Set a positive reference.
Go to par. 16-20. Turn the motor slowly in the positive direction. It must be turned so slowly (only a few RPM) that it can be determined if the value in par. 16-20 is increasing or decreasing.	16-20	N.A. (read-only parameter) Note: An increasing value overflows at 65535 and starts again at 0.
If par. 16-20 is decreasing, then change the encoder direction in par. 5-71.	5-71	[1] Counter clockwise (if par. 16-20 is decreasing)
3) Make sure the drive limits are set to safe values		
Set acceptable limits for the references.	3-02	0 RPM (default)
	3-03	1500 RPM (default)
Check that the ramp settings are within drive capabilities and allowed application operating specifications.	3-41	3 sec. (default)
	3-42	3 sec. (default)
Set acceptable limits for the motor speed and frequency.	4-11	0 RPM (default)
	4-13	1500 RPM (default)
	4-19	60 Hz (default 132 Hz)
4) Configure the Speed Control and select the Motor Control principle		
Activation of Speed Control	1-00	[1] Speed closed-loop
Selection of Motor Control Principle	1-01	[3] Flux w motor feedb
5) Configure and scale the reference to the Speed Control		
Set up Analog Input 53 as a reference resource	3-15	Not necessary (default)
Scale Analog Input 53 0 RPM (0 V) to 1500 RPM (10V)	6-1*	Not necessary (default)
6) Configure the 24V HTL encoder signal as feedback for the Motor Control and the Speed Control		
Set up digital input 32 and 33 as encoder inputs	5-14	[0] No operation (default)
	5-15	
Choose terminal 32/33 as motor feedback	1-02	Not necessary (default)
Choose terminal 32/33 as Speed PID feedback	7-00	Not necessary (default)
7) Tune the Speed Control PID parameters		
Use the tuning guidelines when relevant or tune manually	7-0*	See the guidelines below
8) Finished!		
Save the parameter settings to the LCP for safekeeping	0-50	[1] All to LCP

The following tuning guidelines are relevant when using one of the Flux motor control principles in applications where the load is mainly inertial (with a low amount of friction).

The value of par. 7-02 Speed PID Proportional Gain is dependent on the combined inertia of the motor and load, and the selected bandwidth can be calculated using the following formula:

$$Par.7-02 = \frac{Total\ inertia\ [kgm^2] \times Par.1 - 25}{Par.1 - 20 \times 9550} \times Bandwidth\ [rad/s]$$

— Introduction to FC 300 —

Note: Par. 1-20 is the motor power in [kW] (i.e. enter '4' kW instead of '4000' W in the formula). A practical value for the Bandwidth is 20 rad/s. Check the result of the par. 7-02 calculation against the following formula (not required if you are using a high resolution feedback such as a SinCos or Resolver feedback):

$$Par.7-02_{MAXIMUM} = \frac{0.01 \times 4 \times Encoder\ Resolution \times par.7-06}{2 * \pi} \times MaxTorqueRipple [\%]$$

A good start value for par. 7-06 *Speed PID Lowpass Filter Time* is 5 ms (lower encoder resolution calls for a higher filter value). Typically a MaxTorqueRipple of 3 % is acceptable. For incremental encoders, the Encoder Resolution is found in either par. 5-70 (24V HTL on standard drive) or par. 17-11 (5V TTL on MCB102 Option).

Generally the practical maximum limit of par. 7-02 is determined by the encoder resolution and the feedback filter time but other factors in the application might limit par. 7-02 *Speed PID Proportional Gain* to a lower value.

To minimize overshoot, par. 7-03 *Speed PID Integral Time* could be set to approx. 2.5 s (varies with the application).

Par. 7-04 *Speed PID Differentiation Time* should be set to 0 until everything else is tuned. If necessary, finish the tuning by experimenting with small increments of this setting.

□ **Process PID Control**


The Process PID Control can be used to control application parameters that can be measured by a sensor (i.e. pressure, temperature, flow) and affected by the connected motor through a pump, fan or otherwise.

The table shows the control configurations where Process Control is possible. When a Flux Vector motor control principle is used, take care also to tune the Speed Control PID parameters. Refer to the section about the Control Structure to see where the Speed Control is active.



Par. 1-00 Configuration Mode	Par. 1-01 Motor Control Principle			
	U/f	VVCplus	Flux sensorless	Flux w motor feedb
[3] Process	N.A.	Process	Process & Speed	Process & Speed

Note: The Process Control PID will work under the default parameter setting, but tuning the parameters is highly recommended to optimize the application control performance. The two Flux motor control principles are specially dependent on proper Speed Control PID tuning (prior to tuning the Process Control PID) to yield their full potential.



Process PID Control diagram


— Introduction to FC 300 —

The following parameters are relevant for Process Control

Parameter	Description of function
Process CL Feedback 1 Resource Par. 7-20	Select from which resource (i.e. analog or pulse input) the Process PID should get its feedback
Process CL Feedback 2 Resource Par. 7-22	Optional: Determine if (and from where) the Process PID should get an additional feedback signal. If an additional feedback source is selected, the two feedback signals will be added together before being used in the Process PID Control.
Process PID Normal/inverse Control Par. 7-30	Under [0] Normal operation, the process control will respond with an increase of the motor speed if the feedback is getting lower than the reference. In the same situation, but under [1] Inverse operation, the process control will respond with a decreasing motor speed instead.
Process PID Anti Windup Par. 7-31	The anti-windup function ensures that when either a frequency limit or a torque limit is reached, the integrator will be set to a gain that corresponds to the actual frequency. This avoids integrating on an error that cannot in any case be compensated for by means of a speed change. This function can be disabled by selecting [0] "Off".
Process PID Controller Start Value Par. 7-32	In some applications, optimum setting of the process regulator will mean that it takes an excessive time for the desired process value to be reached. In such applications, it might be an advantage to fix a motor frequency to which the adjustable frequency drive is to bring the motor before the process regulator is activated. This is done by programming a Process PID Start Value (frequency) in this parameter.
Process PID Proportional Gain Par. 7-33	The higher the value, the quicker the control. However, too large a value may lead to oscillations.
Process PID Integral Time Par. 7-34	Eliminates steady state speed error. Lower value means quick reaction. However, too small a value may lead to oscillations.
Process PID Differentiation Time Par. 7-35	Provides a gain proportional to the rate of change of the feedback. A setting of zero disables the differentiator.
Process PID Differentiator Gain Limit Par. 7-36	If there are quick changes in reference or feedback in a given application - which means that the error changes swiftly - the differentiator may soon become too dominant. This is because it reacts to changes in the error. The quicker the error changes, the stronger the differentiator gain is. The differentiator gain can thus be limited to allow setting of the reasonable differentiation time for slow changes.
Process PID Feed Forward Factor Par. 7-38	In applications where there is a good (and approximately linear) correlation between the process reference and the motor speed necessary for obtaining that reference, the Feed Forward Factor can be used to achieve better dynamic performance of the Process PID Control.
Par. 5-54 (Pulse Filter Time Constant #29), Par. 5-59 (Pulse Filter Time Constant #33), Par. 6-16 (Terminal 53 Filter Time Constant), Par. 6-26 (Terminal 54 Filter Time Constant)	If there are oscillations in the current/voltage feedback signal, these can be damped by means of a low-pass filter. This time constant represents the frequency limit of the ripples occurring on the feedback signal. Example: If the low-pass filter has been set to 0.1s, the limit frequency will be 10 RAD/sec. (the reciprocal of 0.1 s), corresponding to $(10/(2 \times \pi)) = 1.6$ Hz. This will mean that all currents/voltages that vary by more than 1.6 oscillations per second will be removed by the filter. In other words, control will only be carried out on a feedback signal that varies by a frequency of less than 1.6 Hz. In other words, the low-pass filter improves steady state performance but selecting too large a filter time will deteriorate the dynamic performance of the Process PID Control.

— Introduction to FC 300 —

The following is an example of Process PID Control used in a ventilation system:




In a ventilation system, the temperature is to be settable from 23 - 95°F (- 5 - 35°C) with a potentiometer of 0-10 Volt. The set temperature must be kept constant, for which purpose the Process Control is to be used.

The control is of the inverse type, which means that when the temperature increases, the ventilation speed is increased as well, so as to generate more air. When the temperature drops, the speed is reduced. The transmitter used is a temperature sensor with a working range of 14 -104°F (-10-40°C), 4-20 mA. Min. / Max. speed 300 / 1500 RPM.



NOTE
The example shows a two-wire transmitter.



1. Start/Stop via switch connected to terminal 18.
2. Temperature reference via potentiometer (23 - 95°F (-5 - 35°C), 0-10 VDC) connected to terminal 53.
3. Temperature feedback via transmitter (14 -104°F (-10-40°C), 4-20 mA) connected to terminal 54. Switch S202 set to ON (current input).

— Introduction to FC 300 —



Function	Par. no.	Setting
1) Make sure the motor runs properly. Do the following:		
Set the motor parameters using nameplate data	1-2*	As specified by motor nameplate
Have the adjustable frequency drive make an Automatic Motor Adaptation	1-29	[1] Enable complete AMA
2) Check that the motor is running in the right direction.		
Press the "Hand On" LCP key. Check that the motor is running and note in which direction it is turning.		Set a positive reference.
If the motor was turning in the wrong direction, remove the motor plug and switch two of the motor phases.		
3) Make sure the adjustable frequency drive limits are set to safe values		
Check that the ramp settings are within capabilities of the adjustable frequency drive and allowed application operating specifications.	3-41	3 sec. (default)
	3-42	3 sec. (default)
Prohibit the motor from reversing if necessary	4-10	[0] Clockwise
Set acceptable limits for the motor speed and frequency	4-11	300 RPM
	4-13	1500 RPM (default)
	4-19	60 Hz (default 132 Hz)
4) Configure the reference to the Process Control		
Allow for an "asymmetrical" reference range by selecting the "Min - Max" Reference Range	3-00	[0] Min - Max
Select the appropriate reference unit	3-01	[13] °C
Set acceptable limits for the sum of all references	3-02	-5 °C
	3-03	35 °C
Set up Analog Input 53 as a reference resource	3-15	Not necessary (default)
5) Scale the analog inputs used for reference and feedback		
Scale the Analog Input 1 (terminal 53) that is used for the temperature reference via potentiometer (23 - 95°F/ -5 - 35°C, 0-10 VDC).	6-10	0 VDC
	6-11	10 VDC
	6-14	-5 °C
	6-15	35 °C
Scale the Analog Input 2 (terminal 54) that is used for the temperature feedback via transmitter (14-104°F/ -10 - 40°C, 4-20 mA)	6-22	4 mA
	6-23	20 mA
	6-24	-10 °C
	6-25	40 °C
6-26	0.001 s. (default)	
6) Configure the feedback to the Process Control		
Set up Analog Input 54 as a feedback resource	7-20	[2] Analog input 54
7) Tune the Process Control PID parameters		
Select inverse control.	7-30	[1] Inverse
Use the tuning guidelines when relevant or tune manually	7-3*	See the guidelines below
8) Finished!		
Save the parameter settings to the LCP for safekeeping	0-50	[1] All to LCP

— Introduction to FC 300 —

Optimization of the process regulator

The basic settings have now been made; all that needs to be done is to optimize the proportional gain, the integration time, and the differentiation time (par. 7-33, 7-34, 7-35). In most processes, this can be done by following the guidelines given below.

1. Start the motor
2. Set par. 7-33 (*Proportional Gain*) to 0.3 and increase it until the feedback signal again begins to vary continuously. Then reduce the value until the feedback signal has stabilized. Now lower the proportional gain by 40-60%.
3. Set par. 7-34 (*Integral Time*) to 20 sec. and reduce the value until the feedback signal again begins to vary continuously. Increase the integration time until the feedback signal stabilizes, followed by an increase of 15-50%.
4. Only use par. 7-35 for very fast-acting systems (differentiation time). The typical value is four times the set integral time. The differentiator should only be used when the setting of the proportional gain and the integral time has been fully optimized. Make sure that oscillations in the feedback signal are sufficiently damped by the low-pass filter on the feedback signal.



NOTE

If necessary, start/stop can be activated a number of times in order to provoke a variation of the feedback signal.

□ Ziegler Nichols Tuning Method

In order to tune the PID controls of the adjustable frequency drive, several tuning methods can be used. One approach is to use a technique which was developed in the 1950s but which has stood the test of time and is still used today. This method is known as the Ziegler Nichols tuning method and it can be considered "quick and dirty."



NOTE

The method described must not be used on applications that could be damaged by the oscillations created by marginally stable control settings.

The criteria for adjusting the parameters are based on evaluating the system at the limit of stability rather than on taking a step response. We increase the proportional gain until we observe continuous oscillations (as measured on the feedback), that is, until the system becomes marginally stable. The corresponding gain (called the ultimate gain) and the period of oscillation (also called the ultimate period) are determined as shown in Figure 1.




Figure 1: Marginally stable system

P_u should be measured when the amplitude of oscillation is quite small. Then we "back off" from this gain again, as shown in Table 1.



— Introduction to FC 300 —

Type of Control	Proportional Gain	Integral Time	Differentiation Time
PI-control	$0.45 * K_u$	$0.833 * P_u$	-
PID tight control	$0.6 * K_u$	$0.5 * P_u$	$0.125 * P_u$
PID some overshoot	$0.33 * K_u$	$0.5 * P_u$	$0.33 * P_u$

Table 1: Ziegler Nichols tuning for regulator, based on a stability boundary.

Experience has shown that the control setting according to the Ziegler Nichols rule provides a good closed-loop response for many systems. The process operator can perform final tuning of the control iteratively to yield satisfactory control.

Step-by-step:

Step 1: Select only Proportional Control, meaning that the Integral time is selected to the maximum value, while the differentiation time is selected to zero.

Step 2: Increase the value of the proportional gain until the point of instability is reached (sustained oscillations) and the critical value of gain, K_u , is reached.

Step 3: Measure the period of oscillation to obtain the critical time constant, P_u .

Step 4: Use the table above to calculate the necessary PID control parameters.

□ Internal Current Control

The adjustable frequency drive features an integral current limit control which is activated when the motor current, and thus the torque, is higher than the torque limits set in par. 4-16 and 4-17. When the adjustable frequency drive is at the current limit during motor operation or regenerative operation, the adjustable frequency drive will try to get below the preset torque limits as quickly as possible without losing control of the motor.



NOTE

While the current control is active, the adjustable frequency drive can *only* be stopped by means of a digital terminal if set to *Coast inverse* [2] or *Coast and reset inv.* [3]. Any signal on terminals 18 to 33 will *not* be active until the adjustable frequency drive is no longer near the current limit.

□ Parameter Download

Parameter download is possible via the following:

- PC Software MCT 10 tool - see how in *FC 300 PC Software Operating Instructions*.
- Fieldbus options - see how in *FC 300 Profibus Operating Instructions* or *FC 300 DeviceNet Operating Instructions*.
- LCP upload and download as described in par. group 0-5*.

— Introduction to FC 300 —

□ **General Aspects of EMC Emissions**


Electrical interference is usually conducted at frequencies in the range 150 kHz to 30 MHz. Airborne interference from the drive system in the range 30 MHz to 1 GHz is generated from the inverter, the motor cable, and the motor.

As shown in the illustration below, capacitive currents in the motor cable coupled with a high dV/dt from the motor voltage generate leakage currents.

The use of a shielded motor cable increases the leakage current (see illustration below) because shielded cables have higher capacitance to ground than non-shielded cables. If the leakage current is not filtered, it will cause greater interference on the mains in the radio frequency range below approx. 5 MHz. Since the leakage current (I_1) is carried back to the unit through the shield (I_3), there will in principle only be a small electromagnetic field (I_4) from the shielded motor cable according to the below figure.

The shield reduces the radiated interference but increases the low-frequency interference on the mains. The motor cable shield must be connected to the adjustable frequency drive enclosure as well as on the motor enclosure. This is best done by using integrated shield clamps so as to avoid twisted shield ends (pigtailed). These increase the shield impedance at higher frequencies, which reduces the shield effect and increases the leakage current (I_4).

If a shielded cable is used for Profibus, standard bus, relay, control cable, signal interface, and brake, the shield must be mounted on the enclosure at both ends. In some situations, however, it will be necessary to break the shield to avoid current loops.



If the shield is to be placed on a mounting plate for the adjustable frequency drive, the mounting plate must be made of metal, because the shield currents must be conveyed back to the unit. Moreover, ensure good electrical contact from the mounting plate through the mounting screws to the adjustable frequency drive chassis.

With respect to installation, it is generally less complicated to use non-shielded cables than shielded ones.



NOTE

When non-shielded cables are used, some emission requirements are not complied with, although the immunity requirements are observed.

In order to reduce the interference level from the entire system (unit + installation), make motor and brake cables as short as possible. Avoid placing cables with a sensitive signal level alongside motor and brake cables. Radio interference higher than 50 MHz (airborne) is especially generated by the control electronics.



EMC Test Results (Emission, Immunity)

The following test results have been obtained using a system with an adjustable frequency drive (with options if relevant), a shielded control cable, a control box with potentiometer, as well as a motor and motor cable.

FC 301/FC 302 200-240 V 380-500 V	Conducted emission			Radiated emission	
	Industrial environment		Housing, trades, and light industries	Industrial environment	Housing, trades, and light industries
Setup	EN 55011 Class A2	EN 55011 Class A1	EN 55011 Class B	EN 55011 Class A1	EN 55011 Class B
FC 301/FC 302 A2 0-5 HP (0-3.7 kW) 200-240 V 0-10 HP (0-7.5 kW) 380-500 V	16 ft (5 m)	No	No	No	No
FC 301 with integrated filter 0-5 HP (0-3.7 kW) 200-240 V 0-10 HP (0-7.5 kW) 380-500 V	33 ft (10 m)	33 ft (10 m)	33 ft (10 m)	33 ft (10 m)	No
FC 302 with integrated filter 0-5 HP (0-3.7 kW) 200-240 V 0-10 HP (0-7.5 kW) 380-500 V	130 ft (40 m)	130 ft (40 m)	No	130 ft (40 m)	No
FC 301 with integrated filter 0-5 HP (0-3.7 kW) 200-240 V 0-10 HP (0-7.5 kW) 380-500 V	130 ft (40 m)	130 ft (40 m)	130 ft (40 m)	130 ft (40 m)	No
FC 302 with integrated filter 0-5 HP (0-3.7 kW) 200-240 V 0-10 HP (0-7.5 kW) 380-500 V	490 ft (150 m)	490 ft (150 m)	No	490 ft (150 m)	No
FC 301 with integrated filter 0-5 HP (0-3.7 kW) 200-240 V 0-10 HP (0-7.5 kW) 380-500 V	No	No	No	No	No

— Introduction to FC 300 —

□ **Required Compliance Levels**

Standard / environment	Housing, trades, and light industries		Industrial environment	
	Conducted	Radiated	Conducted	Radiated
IEC 61000-6-3	Class B	Class B		
IEC 61000-6-4			Class A-1	Class A-1
EN 61800-3 (restricted)	Class B	Class B	Class A-2	Class A-2
EN 61800-3 (unrestricted)	Class A-1	Class A-1	Class A-2	Class A-2

- EN 55011: Threshold values and measuring methods for radio interference from industrial, scientific and medical (ISM) high-frequency equipment.
- Class A-1: Equipment used in an industrial environment.
- Class A-2: Equipment used in an industrial environment.
- Class B-1: Equipment used in areas with a public supply network (dwellings, commerce, and light industries).



□ **EMC Immunity**

In order to document immunity against electrical interference from electrical phenomena, the following immunity tests have been carried out on a system consisting of an adjustable frequency drive (with options, if relevant), a shielded control cable, and a control box with potentiometer, motor cable, and motor.

The tests were performed in accordance with the following basic standards:

- **EN 61000-4-2 (IEC 61000-4-2): Electrostatic discharges (ESD)**
Simulation of electrostatic discharges from human beings.
- **EN 61000-4-3 (IEC 61000-4-3): Incoming electromagnetic field radiation, amplitude modulated**
Simulation of the effects of radar and radio communication equipment as well as mobile communications.
- **EN 61000-4-4 (IEC 61000-4-4): Transients**
Simulation of interference brought about by switching with a contactor, relays, or similar devices.
- **EN 61000-4-5 (IEC 61000-4-5): Surge transients**
Simulation of transients brought about e.g. by lightning that strikes near installations.
- **EN 61000-4-6 (IEC 61000-4-6): RF Common mode**
Simulation of the effect from radio-transmitting equipment connected to connection cables.

See following EMC immunity form.



Immunity continued

FC 301/FC 302; 200-240 V, 380-500 V

Basic standard	Transient IEC 61000-4-4	Surge IEC 61000-4-5	ESD IEC 61000-4-2	Radiated electromagnetic field IEC 61000-4-3	RF common mode voltage IEC 61000-4-6
Acceptance criterion	B	B	B	A	A
Line	4 kV CM	2 kV/2 Ω DM 4 kV/12 Ω CM	—	—	10 V _{RMS}
Motor	4 kV CM	4 kV/2 Ω ¹⁾	—	—	10 V _{RMS}
Brake	4 kV CM	4 kV/2 Ω ¹⁾	—	—	10 V _{RMS}
Load sharing	4 kV CM	4 kV/2 Ω ¹⁾	—	—	10 V _{RMS}
Control lines	2 kV CM	2 kV/2 Ω ¹⁾	—	—	10 V _{RMS}
Standard bus	2 kV CM	2 kV/2 Ω ¹⁾	—	—	10 V _{RMS}
Relay lines	2 kV CM	2 kV/2 Ω ¹⁾	—	—	10 V _{RMS}
Application and Fieldbus options	2 kV CM	2 kV/2 Ω ¹⁾	—	—	10 V _{RMS}
LCP cable	2 kV CM	2 kV/2 Ω ¹⁾	—	—	10 V _{RMS}
External 24 V DC	2 kV CM	0.5 kV/2 Ω DM 1 kV/12 Ω CM	—	—	10 V _{RMS}
Enclosure	—	—	8 kV AD 6 kV CD	3 V/ft (10 V/m)	—

AD: Air Discharge
 CD: Contact Discharge
 CM: Common mode
 DM: Differential mode

1. Injection on cable shield.

— Introduction to FC 300 —

□ **Galvanic Isolation (PELV)**

PELV offers protection by way of extra low voltage. Protection against electric shock is ensured when the electrical supply is of the PELV type and the installation is made as described in local/national regulations on PELV supplies.


All control terminals and relay terminals 01-03/04-06 comply with PELV (Protective Extra Low Voltage) (Does not apply to 525-600 V units and at grounded Delta leg above 300 V).

Galvanic (ensured) isolation is obtained by fulfilling requirements for higher isolation and by providing the relevant creepage/clearance distances. These requirements are described in the EN 61800-5-1 standard.

The components that make up the electrical isolation, as described below, also comply with the requirements for higher isolation and the relevant test as described in EN 61800-5-1.

The PELV galvanic isolation can be shown in six locations (see illustration):

1. Power supply (SMPS) incl. signal isolation of U_{DC} , indicating the intermediate current voltage.
2. Gate drive that runs the IGBTs (trigger transformers/opto-couplers).
3. Current transducers.
4. Opto-coupler, brake module.
5. Internal inrush, RFI, and temperature measurement circuits.
6. Custom relays.



Galvanic isolation

The functional galvanic isolation (a and b on drawing) is for the 24 V backup option and for the RS-485 standard bus interface.

□ **Ground Leakage Current**



Warning:

Touching the electrical parts may be fatal - even after the equipment has been disconnected from the power supply.

Also make sure that other voltage inputs have been disconnected, such as load-sharing (linkage of DC intermediate circuit), as well as the motor connection for kinetic back-up.

Using VLT AutomationDrive FC 300 (at and below 7.5 kW): wait at least 2 minutes



— Introduction to FC 300 —



Leakage Current

The ground leakage current from the FC 300 exceeds 3.5 mA. To ensure that the ground cable has a good mechanical connection to the ground connection (terminal 95), the cable cross section must be at least 0.4 in² (10 mm²) or 2 rated ground wires terminated separately.

Residual Current Device

This product can cause a DC current in the protective conductor. Where a residual current device (RCD) is used for extra protection, only an RCD of Type B (time delayed) shall be used on the supply side of this product. See also RCD Application Note MN.90.GX.02.

Protective grounding of the adjustable frequency drive and the use of RCDs must always follow national and local regulations.




Selection of Brake Resistor

To select the right brake resistor, it is necessary to know how often to brake and by how much the power braking is effected.

The resistor intermittent duty (S5), which is often used by motor suppliers when stating the permissible load, is an indication of the duty cycle at which the resistor is working.

The intermittent duty cycle for the resistor is calculated as follows, in which T = cycle time in seconds and t_b is the braking time in seconds (of the cycle time): The max. permissible load on the brake resistor is stated as a peak power at a given intermittent duty cycle. Therefore, determine the peak power for the brake resistor and the resistor value.



$$\text{Dutycycle} = T_b/T$$

The max. permissible load on the brake resistor is stated as a peak power at a given ED. Therefore, determine the peak power for the brake resistor and the resistor value.

The shown example and formula apply to FC 302.

$$P_{PEAK} = P_{MOTOR} \times M_{BR(\%)} \times \eta_{MOTOR} \times \eta_{VLT} [W]$$

The brake resistance is calculated as shown:

$$R_{REC} = U_{DC}^2 / P_{PEAK}$$

As can be seen, the brake resistance depends on the intermediate circuit voltage (UDC). With FC 302 adjustable frequency drives with a line voltage of 3 x 200-240 V, the brake will be active at 390 V (UDC). If the adjustable frequency drive has a line voltage of 3 x 380-500

— Introduction to FC 300 —

V, the brake will be active at 810 V (UDC), and if the adjustable frequency drive has a line voltage of 3 x 525-600 V, the brake will be active at 943 V (UDC).



NOTE

Check that the brake resistor can cope with a voltage of 430 V, 850 V or 930 V - unless Danfoss brake resistors are used.

Danfoss recommends the brake resistance R_{REC} , i.e. one that guarantees that the adjustable frequency drive is able to brake at the highest braking torque (M_{br}) of 160%.

η_{motor} is typically at 0.90, while η_{VLT} is typically at 0.98.

For 200 V, 500 V, and 600 V adjustable frequency drives, R_{REC} at 160% braking torque is written as:

$$200V : R_{REC} = \frac{107780}{P_{MOTOR}} \quad [\Omega]$$

$$500V : R_{REC} = \frac{464923}{P_{MOTOR}} \quad [\Omega]$$

$$600V : R_{REC} = \frac{630137}{P_{MOTOR}} \quad [\Omega]$$



NOTE

The brake circuit resistance selected should not be higher than that recommended by Danfoss. If a brake resistor with a higher ohmic value is selected, the 160% braking torque may not be achieved because there is a risk that the adjustable frequency drive cuts out for safety reasons.



NOTE

If a short circuit in the brake transistor occurs, power dissipation in the brake resistor is only prevented by using a line switch or contactor to disconnect the AC line for the adjustable frequency drive. (The contactor can be controlled by the adjustable frequency drive).

□ **Control with Brake Function**

The brake is to limit the voltage in the intermediate circuit when the motor acts as a generator. This occurs, for example, when the load drives the motor and the power accumulates on the DC link. The brake is built up as a chopper circuit with the connection of an external brake resistor. Placing the brake resistor externally offers the following advantages:

- The brake resistor can be selected on the basis of the application in question.
- The brake energy is dissipated outside the control panel, i.e. where the energy can be utilized.
- The electronics of the adjustable frequency drive will not be overheated if the brake resistor is overloaded.

The brake is protected against short-circuiting of the brake resistor, and the brake transistor is monitored to ensure that short-circuiting of the transistor is detected. A relay/digital output can be used for protecting the brake resistor against overloading in connection with a fault in the adjustable frequency drive. In addition, the brake makes it possible to read out the momentary power and the mean power for the latest 120 seconds. The brake can also monitor the power energizing and make sure it does not exceed a limit selected in par. 2-12. In par. 2-13, select the function to carry out when the power transmitted to the brake resistor exceeds the limit set in par. 2-12.

Over-voltage Control (OVC) (excl. brake resistor) can be selected as an alternative brake function in par. 2-17. This function is active for all units. The function ensures that a trip can be avoided if the DC link voltage increases. This is done by increasing the output frequency to limit the voltage from the DC link. It is a very useful function, e.g. if the ramp-down time is too short since tripping of the adjustable frequency drive is avoided. In this situation, the ramp-down time is extended.




NOTE

Monitoring the brake power is not a safety function; a thermal switch is required for this purpose. The brake resistor circuit is not ground leakage protected.

□ **Control of Mechanical Brake**

For hoisting applications, it is necessary to be able to control an electromagnetic brake. For controlling the brake, a relay output (relay1 or relay2) or a programmed digital output (terminal 27 or 29) is required. Normally, this output must be closed for as long as the drive is unable to "hold" the motor, e.g. because of too big load. In par. 5-40 (Array parameter), par. 5-30, or par. 5-31 (digital output 27 or 29), select *mechanical brake control* [32] for applications with an electromagnetic brake.

When *mechanical brake control* [32] is selected, the mechanical brake relay is closed during start until the output current is above the level selected in par. 2-20 *Release Brake Current*. During stop, the mechanical brake will close when the speed is below the level selected in par. 2-21 *Activate Brake Speed [RPM]*. If the adjustable frequency drive is brought into an alarm condition, an overcurrent, or overvoltage situation, the mechanical brake immediately cuts in. This is also the case during safe stop.




□ Smart Logic Controller

The Smart Logic Controller (SLC) is essentially a sequence of user-defined actions (see par. 13-52) executed by the SLC when the associated user-defined *event* (see par. 13-51) is evaluated as TRUE by the SLC. *Events* and *actions* are each numbered and are linked together in pairs. This means that when *event [0]* is fulfilled (attains the value TRUE), *action [0]* is executed. After this, the conditions of *event [1]* will be evaluated and if found to be TRUE, *action [1]* will be executed and so on.

Only one *event* will be evaluated at any time. If an *event* is evaluated as FALSE, nothing happens (in the SLC) during the present scan interval and no other *events* will be evaluated. This means that when the SLC starts, it evaluates *event [0]* (and only *event [0]*) each scan interval. Only when *event [0]* is evaluated TRUE, the SLC executes *action [0]* and starts evaluating *event [1]*.

It is possible to program from 1 to 6 *events* and *actions*. When the last *event / action* has been executed, the sequence starts over again from *event [0] / action [0]*. The illustration shows an example with three *events / actions*:



Starting and stopping the SLC:

Starting and stopping the SLC can be done by selecting "On [1]" or "Off [0]" in par. 13-50. The SLC always starts in state 0 (where it evaluates *event [0]*). If the drive is stopped or coasted by any means (either via digital input, field bus or other), the SLC automatically stops. If the drive is started by any means (either via digital input, field bus or other), the SLC also starts (provided that "On [1]" is selected in par. 13-50).



□ Extreme Running Conditions

Short Circuit

The adjustable frequency drive is protected against short circuits by means of current measurement in each of the three motor phases. A short circuit between two output phases will cause an overcurrent in the inverter. However, each transistor of the inverter will be turned off individually when the short circuit current exceeds the permitted value.

To protect the drive against a short circuit at the load sharing and brake outputs, please see the design guidelines for these ports.

After 5-10 μ s, the gate driver turns off the inverter and the adjustable frequency drive displays a fault code, depending on current, impedance, and motor frequency.

Ground Fault

The inverter cuts out within a few μ s in case of a ground fault on a motor phase, depending on impedance and motor frequency.

Switching on the Output

Switching on the output between the motor and the adjustable frequency drive is fully permitted. You cannot damage the adjustable frequency drive in any way by switching on the output. However, fault messages may appear.

Motor-generated Overvoltage

The voltage in the intermediate circuit is increased when the motor acts as a generator. This occurs in the following cases:

1. The load drives the motor (at constant output frequency from the adjustable frequency drive), i.e. the load generates energy.
2. During deceleration ("ramp-down"), if the moment of inertia is high, the friction is low and the ramp-down time is too short for the energy to be dissipated as a loss in the adjustable frequency drive, the motor, and the installation.
3. Incorrect slip compensation setting may cause higher DC link voltage.

The control unit may attempt to correct the ramp if possible (par. 2-17 *Over-voltage Control*). The inverter turns off to protect the transistors and the intermediate circuit capacitors when a certain voltage level is reached.

See par. 2-10 and par. 2-17 to select the method used for controlling the intermediate circuit voltage level.

Line Drop-out

During a line drop-out, the adjustable frequency drive keeps running until the intermediate circuit voltage drops below the minimum stop level, which is typically 15% below the adjustable frequency drive's lowest rated supply voltage.

The line voltage before the drop-out and the motor load determine how long it takes for the inverter to coast.

Static Overload in VVC^{plus} mode

When the adjustable frequency drive is overloaded (the torque limit in par. 4-16/4-17 is reached), the control reduces the output frequency to reduce the load.


If the overload is excessive, a current may occur that makes the adjustable frequency drive cut out after approx. 5-10 s.

Operation within the torque limit is limited in time (0-60 s) in par. 14-25.

— Introduction to FC 300 —

□ **Motor Thermal Protection**

The motor temperature is calculated on the basis of motor current, output frequency, and time. See par. 1-90 in the chapter *How to Program*.



□ **Safe Stop of FC 300**

The adjustable frequency drive can perform the Designated Safety Function "Uncontrolled Stopping by removal of power" (as defined by draft IEC 61800-5-2) or Stop Category 0 (as defined in EN 60204-1). It is designed and approved suitable for the requirements of Safety Category 3 in EN 954-1. This functionality is called Safe Stop.

The Safe Stop function is activated by removing the voltage at Terminal 37 of the Safe Inverter. By connecting the Safe Inverter to external safety devices providing a safe delay, an installation for a safe Stop Category 1 can be obtained. The safe inverter can be used for asynchronous and synchronous motors.



Safe Stop activation (i.e. removal of 24 V DC voltage supply to terminal 37) does not provide electrical safety.

□ **Safe Stop Operation**

1. Activate the Safe Stop function by removing the 24 V DC voltage supply to the terminal 37.
2. After activation of Safe Stop, the adjustable frequency drive coasts (stops creating a rotational field in the motor).

The adjustable frequency drive is guaranteed not to restart creation of a rotational field by an internal fault (in accordance with Cat. 3 of EN 954-1).

After activation of Safe Stop, the FC 302 display will show the text "Safe Stop active". The associated help text says "Safe Stop has been activated. To resume normal operation, apply 24 V DC to terminal 37, then send Reset signal (via Bus, Digital I/O, or the [Reset] key)." This means that the Safe Stop has been activated, or that normal operation has not been resumed yet after a Safe Stop activation. NB: The requirements of EN 945-1 Category 3 are only fulfilled while 24 V DC supply to terminal 37 is removed or low.

In order to resume operation after activation of Safe Stop, first 24 V DC voltage must be reapplied to terminal 37 (text "Safe Stop active" is still displayed), second a Reset signal must be created (via bus, Digital I/O, or [Reset] key on inverter).



NOTE

The Safe Stop function of FC 302 can be used for asynchronous and synchronous motors. It may happen that two faults occur in the adjustable frequency drive's power semiconductor. When using synchronous motors, this may cause a residual rotation. The rotation can be calculated to $\text{Angle} = 360 / (\text{Number of Poles})$. The application using synchronous motors must take this into consideration and ensure that this is not a safety-critical issue. This situation is not relevant for asynchronous motors.



— Introduction to FC 300 —

**NOTE**

In order to use the Safe Stop functionality in conformance with the requirements of EN-954-1 Category 3, a number of conditions must be fulfilled by the installation of Safe Stop. Please see section *Safe Stop Installation* for further information.


**NOTE**

The adjustable frequency drive does not provide a safety-related protection against unintended or malicious voltage supply to terminal 37 and subsequent reset. Provide this protection via the interrupt device, at the application level, or at the organizational level.

For more information - see section *Safe Stop Installation*.



How to Select Your VLT



□ Electrical Data

□ Mains Supply 3 x 200 - 240 VAC



FC 301/FC 302		0.25	0.37	0.55	0.75	1.1	1.5	2.2	3	3.7	4	5.5	7.5	
Typical Shaft Output [HP, kW]														
Output current														
	Continuous (3 x 200-240 V) [A]	1.8	2.4	3.5	4.6	6.6	7.5	10.6	12.5	16.7	-	-	-	
	Intermittent (3 x 200-240 V) [A]	2.9	3.8	5.6	7.4	10.6	12.0	17.0	20.0	26.7	-	-	-	
	Continuous KVA (208 V AC) [KVA]	0.65	0.86	1.26	1.66	2.38	2.70	3.82	4.50	6.00	-	-	-	
	Max. cable size (mains, motor, brake) [AWG] ² [in. ²], [mm ²]	24 - 10 AWG 0.0003 - 0.006 in. ² (0.2 - 4 mm ²)										-	-	-
Max. input current														
	Continuous (3 x 200-240 V) [A]	1.6	2.2	3.2	4.1	5.9	6.8	9.5	11.3	15.0	-	-	-	
	Intermittent (3 x 200-240 V) [A]	2.6	3.5	5.1	6.6	9.4	10.9	15.2	18.1	24.0	-	-	-	
	Max. pre-fuses ¹ [A]	10	10	10	10	20	20	20	32	32	-	-	-	
	Environment													
	Estimated power loss at rated max. load [HP, kW]	58	66	79	94	119	147	178	228	274	-	-	-	
	Enclosure IP 20 Weight, enclosure IP20 [lb, kg]	4.7	4.7	4.8	4.8	4.9	4.9	4.9	6.6	6.6	-	-	-	
Efficiency	0.95	0.95	0.95	0.95	0.96	0.96	0.96	0.96	0.96	-	-	-		

1. For type of fuse see section *Fuses*.
2. American Wire Gauge.
3. Measured using 16 ft (5 m) shielded motor cables at rated load and rated frequency.

— How to Select Your VLT —



□ Mains Supply 3 x 380 - 500 VAC

FC 301/FC 302		0,25	0,37	0,55	0,75	1.1	1.5	2.2	3	3.7	4	5.5	7.5	
Typical Shaft Output [HP, kW]														
Output current														
	Continuous (3 x 380-440 V) [A]	-	1.3	1.8	2.4	3	4.1	5.6	7.2	-	10	13	16	
	Intermittent (3 x 380-440 V) [A]	-	2.1	2.9	3.8	4.8	6.6	9.0	11.5	-	16	20.8	25.6	
	Continuous (3 x 440-500 V) [A]	-	1.2	1.6	2.1	2.7	3.4	4.8	6.3	-	8.2	11	14.5	
	Intermittent (3 x 440-500 V) [A]	-	1.9	2.6	3.4	4.3	5.4	7.7	10.1	-	13.1	17.6	23.2	
	Continuous KVA (400 V AC) [KVA]	-	0.9	1.3	1.7	2.1	2.8	3.9	5.0	-	6.9	9.0	11.0	
	Continuous KVA (460 V AC) [KVA]	-	0.9	1.3	1.7	2.4	2.7	3.8	5.0	-	6.5	8.8	11.6	
	Max. cable size (mains, motor, brake) [AWG] ² [in. ²], [mm ²]	-	24 - 10 AWG						0.0003 - 0.006 in. ² (0.2 - 4 mm ²)					
									24 - 10 AWG					
									0.0003 - 0.006 in. ² (0.2 - 4 mm ²)					
									mm ²					
Max. input current														
	Continuous (3 x 380-440 V) [A]	-	1.2	1.6	2.2	2.7	3.7	5.0	6.5	-	9.0	11.7	14.4	
	Intermittent (3 x 380-440 V) [A]	-	1.9	2.6	3.5	4.3	5.9	8.0	10.4	-	14.4	18.7	23.0	
	Continuous (3 x 440-500 V) [A]	-	1.0	1.4	1.9	2.7	3.1	4.3	5.7	-	7.4	9.9	13.0	
	Intermittent (3 x 440-500 V) [A]	-	1.6	2.2	3.0	4.3	5.0	6.9	9.1	-	11.8	15.8	20.8	
	Max. pre-fuses ¹ [A]	-	10	10	10	10	10	20	20	-	20	32	32	
	Environment													
	Estimated power loss at rated max. load [HP, kW]	-	56	64	72	87	104	123	153	-	190	246	321	
	Enclosure IP 20													
	Weight, enclosure IP20 [lb, kg]	-	4.7	4.7	4.8	4.8	4.9	4.9	4.9	-	4.9	6.6	6.6	
	Efficiency	-	0.94	0.95	0.96	0.97	0.97	0.97	0.97	-	0.98	0.97	0.97	

1. For type of fuse see section *Fuses*.
2. American Wire Gauge.
3. Measured using 16 ft (5 m) shielded motor cables at rated load and rated frequency.

— How to Select Your VLT —

□ Mains Supply 3 x 525 - 600 VAC

FC 302		0.25	0.37	0.55	0.75	1.1	1.5	2.2	3	3.7	4	5.5	7.5	
Typical Shaft Output [HP, kW]														
Output current														
	Continuous (3 x 525-550 V) [A]	-	-	-	1.8	2.6	2.9	4.1	5.2	-	6.4	9.5	11.5	
	Intermittent (3 x 525-550 V) [A]	-	-	-	2.9	4.2	4.6	6.6	8.3	-	10.2	15.2	18.4	
	Continuous (3 x 525-600 V) [A]	-	-	-	1.7	2.4	2.7	3.9	4.9	-	6.1	9.0	11.0	
	Intermittent (3 x 525-600 V) [A]	-	-	-	2.7	3.8	4.3	6.2	7.8	-	9.8	14.4	17.6	
	Continuous KVA (525 V AC) [KVA]	-	-	-	1.7	2.5	2.8	3.9	5.0	-	6.1	9.0	11.0	
	Continuous KVA (575 V AC) [KVA]	-	-	-	1.7	2.4	2.7	3.9	4.9	-	6.1	9.0	11.0	
	Max. cable size (mains, motor, brake)	-	-	-	24 - 10 AWG					24 - 10 AWG				
	[AWG] ² [in. ²], [mm ²]	-	-	-	0.0003 - 0.006 in. ² (0.2 - 4 mm ²)					- 0.0003 - 0.006 in. ² (0.2 - 4 mm ²)				
	Max. input current													
		Continuous (3 x 525-600 V) [A]	-	-	-	1.7	2.4	2.7	4.1	5.2	-	5.8	8.6	10.4
Intermittent (3 x 525-600 V) [A]		-	-	-	2.7	3.8	4.3	6.6	8.3	-	9.3	13.8	16.6	
Max. pre-fuses ¹ [A]		-	-	-	10	10	10	20	20	-	20	32	32	
Environment														
Estimated power loss at rated max. load [HP, kW]		-	-	-	72	87	104	123	153	-	190	246	321	
Enclosure IP 20														
Weight, enclosure IP20 [lb, kg]		-	-	-	6.5	6.5	6.5	6.5	6.5	-	6.5	6.6	6.6	
Efficiency		-	-	-	0.97	0.97	0.97	0.97	0.97	-	0.97	0.97	0.97	



1. For type of fuse see section *Fuses*.
2. American Wire Gauge.
3. Measured using 16 ft (5 m) shielded motor cables at rated load and rated frequency.

— How to Select Your VLT —

□ **General Specifications**

Protection and Features:

- Electronic thermal motor protection against overload.
- Temperature monitoring of the heat sink ensures that adjustable frequency drive trips if the temperature reaches 203 °F ± 9 °F (95 °C ± 5 °C). An overload temperature cannot be reset until the temperature of the heat sink is below 158 °F ± 9 °F (70 °C ± 5 °C).
- The adjustable frequency drive is protected against short circuits on motor terminals U, V, W.
- If a mains phase is missing, the adjustable frequency drive trips or issues a warning.
- Monitoring of the intermediate circuit voltage ensures that the adjustable frequency drive trips if the intermediate circuit voltage is too low or too high.
- The adjustable frequency drive is protected against ground faults on motor terminals U, V, W.

Mains supply (L1, L2, L3):

Supply voltage	200-240 V ±10%
Supply voltage	FC 301: 380-480 V / FC 302: 380-500 V ±10%
Supply voltage	FC 302: 525-600 V ±10%
Supply frequency	50/60 Hz
Max. imbalance between mains phases	± 3.0 % of rated supply voltage
True Power Factor (λ)	0.90 nominal at rated load
Displacement Power Factor (cos φ) near unity	(> 0.98)
Switching on input supply L1, L2, L3	2 times/min.
Environment according to EN60664-1	overvoltage category III/pollution degree 2

The unit is suitable for use on a circuit capable of delivering not more than 100,000 RMS symmetrical Amperes, 240/500/600 V maximum.

Motor output (U, V, W):

Output voltage	0 - 100% of supply voltage
Output frequency	FC 301: 0.2 - 1000 Hz / FC 302: 0 - 1000 Hz
Switching on output	Unlimited
Ramp times	0.02 - 3600 sec.

Torque characteristics:

Starting torque (Constant torque)	160% for 1 min.*
Starting torque	180% up to 0.5 sec.*
Overload current (Constant torque)	160% for 1 min.*

**Percentage relates to FC 300's nominal current.*

Cable lengths and cross -sections:

Max. motor cable length, shielded/armored	FC 301: 150 ft (50 m) / FC 302: 500 ft (150 m)
Max. motor cable length, non-shielded/unarmored	FC 301: 250 ft (75 m) / FC 302: 1000 ft (300 m)
Max. cross-section to motor, mains, load sharing and brake (see section Electrical Data in the FC 300 Design Guide MG.33.BX.YY for more information), (0.34 HP - 10 HP / 0.25 kW - 7.5 kW)	0.006 in. ² (4 mm ²) / 10 AWG
Maximum cross-section to control wires, rigid wire	0.002 in. ² (1.5 mm ²)/16 AWG (2 x 0.001 in. ² (2 x 0.75 mm ²))
Maximum cross-section to control cables, flexible cable	0.0015 in. ² (1 mm ²)/18 AWG
Maximum cross-section to control cables, cable with enclosed core	0.0008 in. ² (0.5 mm ²)/20 AWG
Minimum cross-section to control wires	0.0004 in. ² (0.25 mm ²)



— How to Select Your VLT —

Cable lengths and RFI performance			
FC 30x	Filter	Supply voltage	RFI compliance at max. motor cable lengths
FC 301	With A2 filter	200 - 240 V / 380 - 500 V / 380 - 480 V	<16 ft (5 m) EN 55011 Group A2
FC 301	With A1/B	200 - 240 V / 380 - 480 V	<131 ft (40 m) EN 55011 Group A1 <33 ft (10 m) EN 55011 Group B
FC 302	With A1/B	200 - 240 V / 380 - 500 V	<492 ft (150 m) EN 55011 Group A1 <131 ft (40 m) EN 55011 Group B
FC 302	No RFI filter	550 - 600 V	Not compliant with EN 55011

In certain instances, shorten the motor cable to comply with EN 55011 A1 and EN 55011 B. Copper (140/167°F, 60/75°C) conductors recommended.

Aluminum conductors

Aluminum conductors are not recommended. Terminals can accept aluminum conductors but the conductor surface must be clean and the oxidation must be removed and sealed by neutral acid-free Vaseline grease before the conductor is connected.

Furthermore, the terminal screw must be retightened after two days due to the softness of the aluminum. It is crucial to keep the connection a gas-tight joint, otherwise the aluminum surface will oxidize again.



Digital inputs:

Programmable digital inputs	FC 301: 4 (5) / FC 302: 4 (6)
Terminal number	18, 19, 27 ¹⁾ , 29 ¹⁾ , 32, 33,
Logic	PNP or NPN
Voltage level	0 - 24 V DC
Voltage level, logic '0' PNP	< 5 V DC
Voltage level, logic '1' PNP	> 10 V DC
Voltage level, logic '0' NPN ²⁾	> 19 V DC
Voltage level, logic '1' NPN ²⁾	< 14 V DC
Maximum voltage on input	28 V DC
Input resistance, R _i	approx. 4 kΩ

Safe stop Terminal 37²⁾:

Terminal 37 is fixed PNP logic

Voltage level	0 - 24 V DC
Voltage level, logic '0' PNP	< 4 V DC
Voltage level, logic '1' PNP	>15 V DC
Nominal input current at 24 V	50 mA rms
Nominal input current at 15 V	80 mA rms
Input capacitance	400 nF

All digital inputs are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

1) Terminals 27 and 29 can also be programmed as output.

2) Except safe stop input Terminal 37.

3) Terminal 37 is only available in FC 302. It can only be used as safe stop input. Terminal 37 is suitable for category 3 installations according to EN 954-1 (safe stop according to category 0 EN 60204-1) as required by the EU Machinery Directive 98/37/EC. Terminal 37 and the Safe Stop function are designed in conformance with EN 60204-1, EN 50178, EN 61800-2, EN 61800-3, and EN 954-1. For correct and safe use of the Safe Stop function, follow the related information and instructions in the Design Guide.

— How to Select Your VLT —

Analog inputs:

Number of analog inputs	2
Terminal number	53, 54
Modes	Voltage or current
Mode select	Switch S201 and switch S202
Voltage mode	Switch S201/switch S202 = OFF (U)
Voltage level	FC 301: 0 to + 10 / FC 302: -10 to +10 V (scalable)
Input resistance, R_i	Approx. 10 k Ω
Max. voltage	± 20 V
Current mode	Switch S201/switch S202 = ON (I)
Current level	0/4 to 20 mA (scalable)
Input resistance, R_i	Approx. 200 Ω
Max. current	30 mA
Resolution for analog inputs	10 bit (+ sign)
Accuracy of analog inputs	Max. error 0.5% of full scale
Band width	FC 301: 20 Hz / FC 302: 100 Hz

The analog inputs are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Pulse/encoder inputs:

Programmable pulse/encoder inputs	2/1
Terminal number pulse/encoder	29, 33 ¹⁾ / 18, 32, 33 ²⁾
Max. frequency at terminal 18, 29, 32, 33	110 kHz (Push-pull driven)
Max. frequency at terminal 18, 29, 32, 33	5 kHz (open collector)
Min. frequency at terminal 18, 29, 32, 33	4 Hz
Voltage level	see section on digital input
Maximum voltage on input	28 V DC
Input resistance, R_i	approx. 4 k Ω
Pulse input accuracy (0.1 - 1 kHz)	Max. error: 0.1% of full scale
Encoder input accuracy (1 - 110 kHz)	Max. error: 0.05 % of full scale

The pulse and encoder inputs (terminals 18, 29, 32, 33) are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

1) Pulse inputs are 29 and 33

2) Encoder inputs: 18 = Z, 32 = A, and 33 = B

Analog output:

Number of programmable analog outputs	1
Terminal number	42
Current range at analog output	0/4 - 20 mA
Max. load to common at analog output	500 Ω
Accuracy on analog output	Max. error: 0.5% of full scale
Resolution on analog output	12 bit

The analog output is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Control card, RS 485 serial communication:

Terminal number	68 (TX+, RX+), 69 (TX-, RX-)
Terminal number 61	Common for terminals , 68 and 69

The RS 485 serial communication is functionally separated and galvanically isolated from the supplier voltage (PELV).

— How to Select Your VLT —

Digital output

Programmable digital/pulse outputs	2
Terminal number	27, 29 ¹⁾
Voltage level at digital/frequency output	0 - 24 V
Max. output current (sink or source)	40 mA
Max. load at digital/frequency output	1 kΩ
Max. load at digital/frequency output	10 nF
Minimum output frequency at frequency output	0 Hz
Maximum output frequency at frequency output	32 kHz
Accuracy on frequency output	Max. error: 0.1% of full scale
Resolution on frequency output	12 bit

1) Terminal 27 and 29 can also be programmed as input.

The digital output is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Control card, 24 V DC output:

Terminal number	12, 13
Max. load	FC 301: 130 mA / FC 302: 200 mA

The 24 V DC supply is galvanically isolated from the supply voltage (PELV), but has the same potential as the analog and digital inputs and outputs.

Relay outputs:

Programmable relay outputs	FC 301: 1 / FC 302: 2
Relay 01 Terminal number	1-3 (break), 1-2 (make)
Max. terminal load (AC-1) ¹⁾ on 1-3 (NC), 1-2 (NO) (Resistive load)	240 V AC, 2 A
Max. terminal load (AC-15) ¹⁾ (Inductive load @ cosφ 0.4)	240 V AC, 0.2 A
Max. terminal load (DC-1) ¹⁾ on 1-2 (NO), 1-3 (NC) (Resistive load)	60 V DC, 1A
Max. terminal load (DC-13) ¹⁾ (Inductive load)	24 V DC, 0.1A
Relay 02 (FC 302 only) Terminal number	4-6 (break), 4-5 (make)
Max. terminal load (AC-1) ¹⁾ on 4-5 (NO) (Resistive load)	400 V AC, 2 A
Max. terminal load (AC-15) ¹⁾ (Inductive load @ cosφ 0.4)	240 V AC, 0.2 A
Max. terminal load (DC-1) ¹⁾ on 4-5 (NC) (Resistive load)	80 V DC, 2 A
Max. terminal load (DC-13) ¹⁾ (Inductive load)	24 V DC, 0.1A
Max. terminal load (DC-1) ¹⁾ on 4-6 (NC) (Resistive load)	50 V DC, 2 A
Max. terminal load (DC-13) ¹⁾ (Inductive load)	24 V DC, 0.1 A
Min. terminal load on 1-3 (NC), 1-2 (NO), 4-6 (NC), 4-5 (NO)	24 V DC 10 mA, 24 V AC 20 mA
Environment according to EN 60664-1	overvoltage category III/pollution degree 2

1) IEC part 4 and 5

The relay contacts are galvanically isolated from the rest of the circuit by reinforced isolation (PELV).

Control card, 10 V DC output:

Terminal number	50
Output voltage	10.5 V ±0.5 V
Max. load	15 mA

The 10 V DC supply is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.



— How to Select Your VLT —

Control characteristics:

Resolution of output frequency at 0 - 1000 Hz	0.013 Hz
Repeat accuracy of <i>Precise start/stop</i> (terminals 18, 19)	FC 301: $\leq \pm 1$ ms / FC 302: $\leq \pm 0.1$ msec
System response time (terminals 18, 19, 27, 29, 32, 33)	FC 301: ≤ 20 ms / FC 302: ≤ 2 ms
Speed control range (open loop)	1:100 of synchronous speed
Speed control range (closed loop)	1:1000 of synchronous speed
Speed accuracy (open loop)	30 - 4000 rpm: Max. error of ± 8 rpm
Speed accuracy (closed loop)	0 - 6000 rpm: Max. error of ± 0.15 rpm

All control characteristics are based on a 4-pole asynchronous motor

Surroundings:

Enclosure	IP 20
Enclosure kit available	IP21/TYPE 1/IP 4X top
Vibration test	1.0 g
Max. relative humidity	5% - 95%(IEC 721-3-3; Class 3K3 (non-condensing) during operation
Aggressive environment (IEC 721-3-3), uncoated	class 3C2
Aggressive environment (IEC 721-3-3), coated	class 3C3
Ambient temperature	Max. 122 °F (50 °C) (24-hour average maximum 113 °F (45 °C))

Derating for high ambient temperature, see section on special conditions

Minimum ambient temperature during full-scale operation	32 °F (0 °C)
Minimum ambient temperature at reduced performance	14 °F (-10 °C)
Temperature during storage/transport	-13 - +149/158 °F (-25 - +65/70 °C)
Maximum altitude above sea level	3281 ft (1000 m)

Derating for high altitude, see section on special conditions

EMC standards, Emission	EN 61800-3, EN 61000-6-3/4, EN 55011, (EN 50081-1/2)
EMC standards, Immunity	EN 61800-3, EN 61000-6-1/2, EN 61000-4-2, EN 61000-4-3, EN 61000-4-4, EN 61000-4-5, EN 61000-4-6, (EN 50082-1/2)

See section on special conditions

Control card performance:

Scan interval	FC 301: 10 ms / FC 302: 1 ms
---------------------	------------------------------

Control card, USB serial communication:

USB standard	2 (low speed)
USB plug	USB type B "device" plug


Connection to PC is done via a standard host/device USB cable.
The USB connection is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.



— How to Select Your VLT —

□ **Efficiency**

To reduce energy consumption, it is very important to optimize the efficiency of a system. The efficiency of each single element in the system should be as high as possible.



Efficiency of FC 300 Series (η_{VLT})

The load on the adjustable frequency drive has little effect on its efficiency. In general, the efficiency is the same at the rated motor frequency $f_{M,N}$, even if the motor supplies 100% of the rated shaft torque or only 75%, i.e. partial loads.

This also means that the efficiency of the adjustable frequency drive does not change even if other U/f characteristics are chosen.

However, the U/f characteristics influence the efficiency of the motor.

There is a slight decline in efficiency when the switching frequency is set to a value above 5 kHz. The rate of efficiency will also be slightly reduced if the mains voltage is 500 V, or if the motor cable is longer than 100 ft (30 m).

Efficiency of the motor (η_{MOTOR})

The efficiency of a motor connected to the adjustable frequency drive depends on the sine shape of the current. In general, the efficiency is just as good as with mains operation. The efficiency of the motor depends on the type of motor.

In the range of 75-100% of the rated torque, the efficiency of the motor is practically constant, both when it is controlled by the adjustable frequency drive and when it runs directly on mains.

In small motors, the influence of the U/f characteristic on efficiency is marginal. However, in motors from 15 HP (11 kW) and up, the advantages are significant.

In general, the switching frequency does not affect the efficiency of small motors. Motors from 15 HP (11 kW) and up have their efficiency improved (1-2%). This is because the sine shape of the motor current is almost perfect at high switching frequency.

Efficiency of the system (η_{SYSTEM})

To calculate the system efficiency, the efficiency of FC 300 Series (η_{VLT}) is multiplied by the efficiency of the motor (η_{MOTOR}):

$$\eta_{SYSTEM} = \eta_{VLT} \times \eta_{MOTOR}$$

Estimate the efficiency of the system at different loads based on the graph above.



— How to Select Your VLT —

□ **Acoustic Noise**

The acoustic interference from the adjustable frequency drive comes from three sources:

1. DC intermediate circuit coils.
2. Integral fan.
3. RFI components.

The typical values measured at a distance of 3.3 ft (1 m) from the unit:

FC 301/ FC 302	
PK25-P7K5: 200-240 V, 380-500 V, 525-600V	IP20/IP21/IP4Xtop/Type 1 (NEMA 1)
Reduced fan speed	51 dB(A)
Full fan speed	60 dB(A)

□ **Peak Voltage on Motor**

When a transistor in the inverter is opened, the voltage across the motor increases by a dV/dt ratio depending on:

- the motor cable (type, cross-section, length shielded or non-shielded)
- inductance

The natural induction causes an overshoot U_{PEAK} in the motor voltage before it stabilizes itself at a level depending on the voltage in the intermediate circuit. The rise time and the peak voltage U_{PEAK} affect the service life of the motor. If the peak voltage is too high, especially motors without phase coil insulation are affected. If the motor cable is short (a few meters), the rise time and peak voltage are lower.

If the motor cable is long (328 ft / 100 m), the rise time and peak voltage increase.

If very small motors are used without phase coil insulation, connect an LC filter to the adjustable frequency drive.




— How to Select Your VLT —

□ **Special Conditions**

□ **Derating for Ambient Temperature**

The ambient temperature ($T_{AMB,MAX}$) is the maximum temperature allowed. The average ($T_{AMB,AVG}$) measured over 24 hours must be at least 9 °F (5 °C) lower.

If the adjustable frequency drive is operated at temperatures above 122 °F (50 °C), a derating of the continuous output current is necessary.




□ **Derating for Air Pressure**

Below 3000 ft (1000 m) altitude, no derating is necessary.

Above 3000 ft (1000 m), the ambient temperature (T_{AMB}) or max. output current ($I_{VLT,MAX}$) must be derated in accordance with the shown diagram:

1. Derating of output current versus altitude at $T_{AMB} = \text{max. } 122 \text{ } ^\circ\text{F} (50^\circ\text{C})$
2. Derating of max. T_{AMB} versus altitude at 100% output current.



□ **Derating for Running at Low Speed**

When a motor is connected to an adjustable frequency drive, it is necessary to check that the cooling of the motor is adequate.

At low RPM values, the motor fan is not able to supply the required volume of air for cooling. This problem occurs when the load torque is constant (e.g. a conveyor belt) across the regulating range. The reduced ventilation available determines the size of the torque that can be permitted under a continuous load.

If the motor is to run continuously at an RPM value lower than half the rated value, the motor must be supplied with additional air for cooling (or use a motor designed for this type of operation).

— How to Select Your VLT —

Instead of such extra cooling, the load level of the motor can be reduced e.g. by choosing a larger motor. However, the design of the adjustable frequency drive sets a limit to the motor size.

□ **Derating for Installing Long Motor Cables or Cables with Larger Cross-Section**


The adjustable frequency drive has been tested using 984 ft (300 m) non-shielded cable and 492 ft (150 m) shielded cable.

The adjustable frequency drive has been designed to work using a motor cable with a rated cross-section. If a cable with a larger cross-section is used, reduce the output current by 5% for every step the cross-section is increased.

(Increased cable cross-section leads to increased capacity to ground, and thus an increased ground leakage current).

□ **Temperature-Dependent Switch Frequency**

This function ensures the highest possible switch frequency without causing a thermal overload of the adjustable frequency drive. The internal temperature indicates whether the switch frequency can be based on the load, the ambient temperature, the supply voltage, and the cable length.



— How to Select Your VLT —

□ Options and Accessories

Danfoss offers a wide range of options and accessories for VLT AutomationDrive FC 300 Series.

□ Encoder Option MCB 102

The encoder module is used for interfacing feedback from motor or process. Parameter settings in group 17-xx

Used for:

- VVC plus closed-loop
- Flux Vector Speed control
- Flux Vector Torque control
- Permanent magnet motor with SinCos feedback (Hiperface®)

Incremental encoder: 5 V TTL type

SinCos Encoder: Stegmann/SICK (Hiperface®)


Selection of parameters in par. 17-1* and par. 1-02

When the encoder option kit is ordered separately, the kit includes:

- Encoder module MCB 102
- Enlarged LCP fixture and enlarged terminal cover

The encoder option does not support FC 302 adjustable frequency drives manufactured before week 50/2004.

Min. software version: 2.03 (par. 15-43)



130BA145.10




Installation of MCB 102:


- The power to the adjustable frequency drive must be disconnected.
- Remove the LCP, the terminal cover, and the cradle from the FC 30x.
- Fit the MCB 102 option in slot B.
- Connect the control cables and fasten the cables by the clamp to chassis.
- Fit the enlarged LCP fixture and enlarged terminal cover.
- Replace the LCP.
- Connect the power to the adjustable frequency drive.
- Select the encoder functions in par. 17-*
- See also description in chapter *Introduction to FC 300*, section *Speed PID Control*

— How to Select Your VLT —

Connector Designation X31	Incremental Encoder	SinCos Encoder Hiperface	Description
1	NC		24 V Output
2	NC		8 V Output
3	5 VCC		5 V Output
4	GND		GND
5	A input	+COS	A input
6	A inv input	REFCOS	A inv input
7	B input	+SIN	B input
8	B inv input	REFSIN	B inv input
9	Z input	+Data RS485	Z input OR +Data RS485
10	Z inv input	-Data RS485	Z input OR -Data RS485
11	NC	NC	Future use
12	NC	NC	Future use



5V incremental encoder



Hiperface encoder

Max. 5V on X31.5-12



— How to Select Your VLT —

□ **Relay Option MCB 105**

The MCB 105 option includes 3 pieces of SPDT contacts and must be fitted into option slot B.

Electrical Data:


Max terminal load (AC-1) ¹⁾ (Resistive load)	240 V AC 2A
Max terminal load (AC-15) ¹⁾ (Inductive load @ cosφ 0.4)	240 V AC 0.2 A
Max terminal load (DC-1) ¹⁾ (Resistive load)	24 V DC 1 A
Max terminal load (DC-13) ¹⁾ (Inductive load)	24 V DC 0.1 A
Min terminal load (DC)	5 V 10 mA
Max switching rate at rated load/min load	6 min ⁻¹ /20 sec ⁻¹

1) IEC 947 part 4 and 5

When the relay option kit is ordered separately, the kit includes:

- Relay Module MCB 105
- Enlarged LCP fixture and enlarged terminal cover
- Label for covering access to switches S201, S202, and S801
- Cable strips for fastening cables to relay module

The relay option does not support FC 302 adjustable frequency drives manufactured before week 50/2004.
Min. software version: 2.03 (par. 15-43).



IMPORTANT

1. The label **MUST** be placed on the LCP frame as shown (UL-approved).



Warning Dual supply





— How to Select Your VLT —

How to add the MCB 105 option:

- The power to the adjustable frequency drive must be disconnected.
- The power to the live part connections on relay terminals must be disconnected.
- Remove the LCP, the terminal cover, and the LCP fixture from the FC 30x.
- Fit the MCB 105 option in slot B.
- Connect the control cables and fasten the cables with the enclosed cable strips.
- Make sure the length of the stripped wire is correct (see the following drawing).
- Do not mix live parts (high voltage) with control signals (PELV).
- Fit the enlarged LCP fixture and enlarged terminal cover.
- Replace the LCP.
- Connect power to the adjustable frequency drive.
- Select the relay functions in par. 5-40 [6-8], 5-41 [6-8] and 5-42 [6-8].

NB (Array [6] is relay 7, array [7] is relay 8, and array [8] is relay 9)



Do not combine low voltage parts and PELV systems.

— How to Select Your VLT —

□ **24 V Back-Up Option (Option D)**

External 24 V DC Supply

An external 24 V DC supply can be installed for low-voltage supply to the control card and any option card installed. This enables full operation of the LCP (including the parameter setting) without connection to line.

External 24 V DC supply specification:

Input voltage range	24 V DC +15 % (max. 37 V in 10 s)
Max. input current	2.2 A
Max cable length	246 ft (75 m)
Input capacitance load	< 10 uF
Power-up delay	< 0.6 s


The inputs are protected.

Terminal numbers:

- Terminal 35: - external 24 V DC supply.
- Terminal 36: + external 24 V DC supply.

Follow these steps:

1. Remove the LCP or Blind Cover
2. Remove the Terminal Cover
3. Remove the Cable Decoupling Plate and the plastic cover underneath
4. Insert the 24 V DC Back-up External Supply Option in the Option Slot
5. Mount the Cable Decoupling Plate
6. Attach the Terminal Cover and the LCP or Blind Cover.



Connection to 24 V backup supplier.

□ **Brake Resistors**





Brake resistors are used in applications where high dynamics are needed or a high inertia load must be stopped. The brake resistor is used to remove the energy from the DC link in the adjustable frequency drive.

— How to Select Your VLT —

□ **Remote mounting Kit for LCP**

The Local Control Panel can be moved to the front of a cabinet by using the remote build-in kit. The enclosure is the IP 55. The fastening screws must be tightened with a torque of max. 1 Nm.

Technical data	
Enclosure:	IP 65 front
Max. cable length between VLT and unit:	9.8 ft (3 m)
Communication std:	RS-485



□ **IP 21/IP 4X/ TYPE 1 (NEMA 1) Enclosure Kit**

IP 20/IP 4X top/ TYPE 1 (NEMA 1) is an optional enclosure element available for IP 20 Compact units. If the enclosure kit is used, an IP 20 unit is upgraded to comply with enclosure IP 21/ 4X top/TYPE 1 (NEMA 1).

The IP 4X top can be applied to all standard IP 20 FC 30X variants.

For more information, see chapter *How to Install*.

□ **LC Filters**


When a motor is controlled by an adjustable frequency drive, resonance noise will be heard from the motor. This noise, which is the result of the design of the motor, arises every time an inverter switch in the adjustable frequency drive is activated. The frequency of the resonance noise thus corresponds to the switching frequency of the adjustable frequency drive.

For the FC 300 Series, Danfoss can supply an LC filter to dampen the acoustic motor noise.

The filter reduces the ramp-up time of the voltage, the peak load voltage U_{PEAK} and the ripple current ΔI to the motor, which means that current and voltage become almost sinusoidal. Consequently, the acoustic motor noise is reduced to a minimum.

The ripple current in the coils will also cause some noise. Solve the problem by integrating the filter into a cabinet or similar.

How to Order



□ Drive Configurator

It is possible to design an FC 300 adjustable frequency drive by using the ordering number system.

For the FC 300 Series, you can order standard and with integral options by sending a type-code string describing the product to the local Danfoss sales office, i.e.:

FC-302PK75T5E20H1BGCXXXSXXXXA0BXCXXXXD0

The meaning of the characters in the string can be located in the pages containing the ordering numbers in the chapter *How to Select Your VLT*. In the example above, a Profibus DP V1 and a 24 V backup option is included in the drive.

Ordering numbers for FC 300 standard variants can also be located in the chapter *How to Select Your VLT*.

From the internet-based product configurator, the Drive Configurator, you can configure the right drive for the right application and generate the type code string. If the variant has been ordered once before, the configurator will automatically generate an eight-digit sales number. The sales number can be delivered to your local sales office.


Furthermore, you can establish a project list with several products and send it to a Danfoss sales representative.

The Drive Configurator can be found on the global internet site: www.danfoss.com/drives.



— How to Order —

□ Ordering Form Type Code





1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39

FC-30 P T E H XXSXXXA B C D

130BA052.12

Typecode	Voltage				IP		RFI			Brake		Numeric			Coated		AC		Resv.	Resv.
	200-240V 3-phase	380-480V 3-phase	380-500V 3-phase	525-600V 3-phase	IP 20 / Chassis	IP 21/ Type 1	No RFI	RFI A1/B1	RFI (A2)	No chopper	Brake chopper	No LCP	LCP 101	Graphical LCP 102	Not coated PCB	Coated PCB	No line op- tion	Resv.		
Position	7-12	7-12	7-12	7-12	13-15	13-15	16-17	16-17	16-17	18	18	19	19	19	20	20	21	22	23	
0.25kW/ 0.33HP	PK25				X	X		X	X	X	X	X	X	X	X	X	X	X	X	
0.37kW/ 0.50HP	PK37	PK37	PK37		X	X		X	X	X	X	X	X	X	X	X	X	X	X	
0.55kW/ 0.75HP	PK55	PK55	PK55		X	X		X	X	X	X	X	X	X	X	X	X	X	X	
0.75kW/ 1.0HP	PK75	PK75	PK75		X	X		X	X	X	X	X	X	X	X	X	X	X	X	
1.1kW/ 1.5HP	P1K1	P1K1	P1K1		X	X		X	X	X	X	X	X	X	X	X	X	X	X	
1.5kW/ 2.0HP	P1K5	P1K5	P1K5		X	X		X	X	X	X	X	X	X	X	X	X	X	X	
2.2kW/ 3.0HP	P2K2	P2K2	P2K2		X	X		X	X	X	X	X	X	X	X	X	X	X	X	
3.0kW/ 4.0HP	P3K0	P3K0	P3K0		X	X		X	X	X	X	X	X	X	X	X	X	X	X	
3.7kW/ 5.0HP	P3K7				X	X		X	X	X	X	X	X	X	X	X	X	X	X	
4.0kW/ 5.5HP		P4K0	P4K0		X	X		X	X	X	X	X	X	X	X	X	X	X	X	
5.5kW/ 7.5HP		P5K5	P5K5		X	X		X	X	X	X	X	X	X	X	X	X	X	X	
7.5kW/ 10HP		P7K5	P7K5		X	X		X	X	X	X	X	X	X	X	X	X	X	X	
0.75kW/ 1.0HP				PK75	X	X	X			X	X	X	X	X	X	X	X	X	X	
1.1kW/ 1.5HP				P1K1	X	X	X			X	X	X	X	X	X	X	X	X	X	
1.5kW/ 2.0HP				P1K5	X	X	X			X	X	X	X	X	X	X	X	X	X	
2.2kW/ 3.0HP				P2K2	X	X	X			X	X	X	X	X	X	X	X	X	X	
3.0kW/ 4.0HP				P3K0	X	X	X			X	X	X	X	X	X	X	X	X	X	
4.0kW/ 5.5HP				P4K0	X	X	X			X	X	X	X	X	X	X	X	X	X	
5.5kW/ 7.5HP				P5K5	X	X	X			X	X	X	X	X	X	X	X	X	X	
7.5kW/ 10HP				P7K5	X	X	X			X	X	X	X	X	X	X	X	X	X	

Pos 6 select:
1 = FC 301
2 = FC 302

MG.33.B4.22 - VLT is a registered Danfoss trademark



— How to Order —

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39
FC-30						P			T		E		H									X	X	S	X	X	X	A	B	C					D			
130BA052.12																																						
Optional selections, 200-600 V																																						
Software: Position: 24-27																																						
SXXX Latest release - standard software																																						
Languages: Position: 28																																						
X Standard language pack																																						
A-options Position: 29-30																																						
AX No options																																						
A0 Profibus DP V1																																						
A4 DeviceNet																																						
B-options Position: 31-32																																						
BX No options																																						
B2 Encoder Option Module MCB 102																																						
B5 Relay Option Module MCB 105																																						
C1-options Position: 33-34																																						
CX No options																																						
C2-options Position: 35																																						
X No options																																						
C option software Position: 36-37																																						
XX Standard software																																						
D-options Position: 38-39																																						
DX No option																																						
D0 24V DC backup Option MCB 107																																						



□ Ordering Numbers

□ Ordering Numbers: Options and Accessories

Type	Description	Ordering no.	
Miscellaneous hardware			
IP 4X top/TYPE 1 (NEMA 1) kit	Enclosure, frame size B: IP21/IP 4X Top/TYPE 1 (NEMA 1)	130B1110	
IP 4X top/TYPE 1 (NEMA 1) kit	Enclosure, frame size C: IP21/IP 4X Top/TYPE 1 (NEMA 1)	130B1111	
IP 20 low	Top-frame, frame size B/C (w/o options space)	130B1007	
IP 20 high	Top-frame, frame size B/C (w/ options space)	130B1008	
Fan B	Fan, frame size B	130B1009	
Fan C	Fan, frame size C	130B1010	
IP 20 terminal cover low	Control terminal cover, frame size B/C (w/o options space)	130B1011	
IP 20 terminal cover high	Control terminal cover, frame size B/C (w/ options space)	130B1012	
Encoder conditioner	5 V TTL Linedriver / 24 V DC	175Z1929	
Accessory bag B	Accessory bag, frame size B	130B0509	
Accessory bag C	Accessory bag, frame size C	130B0510	
Profibus D-Sub 9	Connector kit for IP20	130B1112	
LCP			
LCP option	Graphical Local Control Panel (LCP)	130B1107	
LCP cable	Separate LCP cable, 9.8 ft (3 m)	175Z0929	
LCP kit	Remote mounting kit for LCP	130B1113	
Options for Slot A		Uncoated	Coated
Profibus option DP V0/V1		130B1100	130B1200
DeviceNet option		130B1102	130B1202
Option for Slot D			
24 VDC backup		130B1108	130B1208

Options can be ordered as factory built-in options, see ordering information.
 For information on fieldbus and application option compatibility with older software versions, please contact your Danfoss supplier.



— How to Order —

□ **Ordering Numbers: Brake Resistors, 200-240 VAC**

Standard brake resistors FC 301/ FC 302	10% duty cycle			40% duty cycle		
	Resistance, [ohm]	Power, [HP, kW]	Code No.	Resistance, [ohm]	Power, [HP, kW]	Code No.
PK25	210	-	175U1843	210	-	175U1943
PK37	210	-	175U1843	210	-	175U1943
PK55	145	-	175U1820	145	-	175U1920
PK75	145	0.065	175U1820	145	0.260	175U1920
P1K1	90	0.095	175U1821	90	0.430	175U1921
P1K5	65	0.250	175U1822	65	0.80	175U1922
P2K2	50	0.285	175U1823	50	1.00	175U1923
P3K0	35	0.430	175U1824	35	1.35	175U1924
P3K7	25	0.8	175U1825	25	3.00	175U1925

Ordering Numbers: Brake Resistors, 200-240 VAC

Flatpack brake resistors					
FC 301/ FC 302	Size	Motor [HP, kW]	Resistor [ohm]	Order number	Max. duty cycle [%]
PK25	-	-	-	-	-
PK37	-	-	-	-	-
PK55	-	-	-	-	-
PK75	0.75	150	150 Ω 100 W	175U1005	14.0
PK75	0.75	150	150 Ω 200 W	175U0989	40.0
P1K1	1.1	100	100 Ω 100 W	175U1006	8.0
P1K1	1.1	100	100 Ω 200 W	175U0991	20.0
P1K5	1.5	72	72 Ω 200 W	175U0992	16.0
P2K2	2.2	47	50 Ω 200 W	175U0993	9.0
P3K0	3	35	35 Ω 200 W	175U0994	5.5
P3K0	3	35	72 Ω 200 W	2 x 175U0992 ¹	12.0
P3K7	4	25	50 Ω 200 W	2 x 175U0993 ¹	11.0

1. Order 2 pieces.

Mounting angle for flatpack resistor 100 W 175U0011

Mounting angle for flatpack resistor 200 W 175U0009

— How to Order —

□ **Ordering Numbers: Brake Resistors, 380-500 VAC**

Standard brake resistors						
FC 301/ FC 302	10% duty cycle			40% duty cycle		
	Resistance, [ohm]	Power, [HP, kW]	Code No.	Resistance, [ohm]	Power, [HP, kW]	Code No.
PK37	620	0.065	175U1840	620	0.260	175U1940
PK55	620	0.065	175U1840	620	0.260	175U1940
PK75	620	0.065	175U1840	620	0.260	175U1940
P1K1	425	0.095	175U1841	425	0.430	175U1941
P1K5	310	0.250	175U1842	310	0.80	175U1942
P2K2	210	0.285	175U1843	210	1.35	175U1943
P3K0	150	0.430	175U1844	150	2.0	175U1944
P4K0	110	0.60	175U1845	110	2.4	175U1945
P5K5	80	0.85	175U1846	80	3.0	175U1946
P7K5	65	1.0	175U1847	65	4.5	175U1947

1. Order 2 pieces.

Ordering Numbers: Brake Resistors, 380-500 VAC					
Flatpack brake resistors					
FC 301/ FC 302	Motor [HP, kW]	Resistor, [ohm]	Size	Order number	Max. duty cycle, [%]
PK37	-	-	620 Ω 100 W	175U1001	-
PK55	-	-	620 Ω 100 W	175U1001	-
PK75	0.75	630	620 Ω 100 W	175U1001	14.0
PK75	0.75	630	620 Ω 200 W	175U0982	40.0
P1K1	1.1	430	430 Ω 100 W	175U1002	8.0
P1K1	1.1	430	430 Ω 200 W	175U0983	20.0
P1K5	1.5	320	310 Ω 200 W	175U0984	16.0
P2K2	2.2	215	210 Ω 200 W	175U0987	9.0
P3K0	3	150	150 Ω 200 W	175U0989	5.5
P3K0	3	150	300 Ω 200 W	2 x 175U0985 ¹	12.0
P5K5	4	120	240 Ω 200 W	2 x 175U0986 ¹	11.0
P5K5	5.5	82	160 Ω 200 W	2 x 175U0988 ¹	6.5
P7K5	7.5	65	130 Ω 200 W	2 x 175U0990 ¹	4.0

1. Order 2 pieces.

Mounting angle for flatpack resistor 100 W 175U0011

Mounting angle for flatpack resistor 200 W 175U0009



— How to Order —

□ **Ordering Numbers: Harmonic Filters**

Harmonic filters are used to reduce mains harmonics.

- AHF 010: 10% current distortion
- AHF 005: 5% current distortion

380-415V, 50Hz				
I _{AHF,N}	Typical Motor Used [kW]	Danfoss ordering number		FC 301/ FC 302
		AHF 005	AHF 010	
10 A	4, 5.5	175G6600	175G6622	P4K0, P5K5
19 A	7.5	175G6601	175G6623	P7K5

440-480V, 60Hz				
I _{AHF,N}	Typical Motor Used [HP]	Danfoss ordering number		FC 301/ FC 302
		AHF 005	AHF 010	
19 A	10, 15	175G6612	175G6634	P7K5

Matching the adjustable frequency drive and filter is pre-calculated based on 400V/480V and on a typical motor load (4 pole) and 160 % torque.

□ **Ordering Numbers: LC Filter Modules, 200-240 VAC**

Mains supply 3 x 200-240 V					
FC 301/ FC 302	LC filter enclosure	Rated current at 200 V	Max. torque at CT/VT	Max. output frequency	Ordering no.
PK25 - P1K5	Bookstyle IP 20	7.8 A	160%	120 Hz	175Z0825
P2K2 - P3K7	Bookstyle IP 20	15.2 A	160%	120 Hz	175Z0826
PK25 - P3K7	Compact IP 20	15.2 A	160%	120 Hz	175Z0832



NOTE

When using LC filters, the switching frequency must be minimum 4.5 kHz (see par. 14-01).

— How to Order —

□ **Ordering Numbers: LC Filter Modules, 380-500 VAC**

Mains supply 3 x 380 - 500 V					
FC 301/ FC 302	LC filter enclosure	Rated current at 400/500 V	Max. torque at CT/VT	Max. output frequency	Ordering no.
PK37-P3K0	Bookstyle IP 20	7.2 A / 6.3 A	160%	120 Hz	175Z0825
P4K0-P7K5	Bookstyle IP 20	16 A / 14.5 A	160%	120 Hz	175Z0826
PK37-P7K5	Compact IP 20	16 A / 14.5 A	160%	120 Hz	175Z0832

LC filters for FC 300, 525 - 600 V, please contact Danfoss.



NOTE


When using LC filters, the switching frequency must be minimum 4.5 kHz (see par. 14-01).



— How to Order —




How to Install



□ **Mechanical Installation**

□ **Accessory Bag**

Find the following parts included in the FC 300 Accessory Bag.



1 + 2 only available in units with brakechopper.





— How to Install —

□ **IP 21/Type 1 Enclosure Kit**

- A - Top cover
- B - Brim
- C - Base part
- D - Base cover
- E - Screw(s)


Place the top cover as shown. If an A or B option is used the brim must be fitted to cover the top inlet. Place the base part C at the bottom of the drive and use the clamps from the accessory bag to correctly fasten the cables. Holes for cable glands:

- Size A2: 2x PG16 (1/2") 3xPG21 (3/4")
- Size A3: 3xPG16 (1/2") 3xPG21 (3/4")



— How to Install —

Mechanical dimensions			
		Frame size A2	Frame size A3
		0.34-3.0 HP (0.25-2.2 kW) (200-240 V)	4.0-5.0 HP (3.0-3.7 kW) (200-240 V)
		0.5-5.4 HP (0.37-4.0 kW) (380-500 V)	7.4-10 HP (5.5-7.5 kW) (380-500 V)
			1.0-10 HP (0.75-7.5 kW) (550-600 V)
Height			
Height of back plate	A	10.6 in (268 mm)	10.6 in (268 mm)
Distance between mounting holes	a	10.1 in (257 mm)	10.1 in (257 mm)
Width			
Width of back plate	B	3.54 in (90 mm)	5.12 in (130 mm)
Distance between mounting holes	b	2.76 in (70 mm)	4.33 in (110 mm)
Depth			
From back plate to front	C	8.66 in (220 mm)	8.66 in (220 mm)
With option A/B		8.66 in (220 mm)	8.66 in (220 mm)
Without options		8.07 in (205 mm)	8.07 in (205 mm)
Screw holes			
	c	0.315 in (8.0 mm)	0.315 in (8.0 mm)
	d	ø 0.433 in (ø 11 mm)	ø 0.433 in (ø 11 mm)
	e	ø 0.217 in (ø 5.5 mm)	ø 0.217 in (ø 5.5 mm)
	f	0.256 in (6.5 mm)	0.256 in (6.5 mm)
Max weight		10.2 lb (4.9 kg)	14.6 lb (6.6 kg)



FC 300 IP20 - see table for mechanical dimensions.


IP 21/IP 4X/ TYPE 1 Enclosure Kit

The IP 21/IP 4X/ TYPE 1 enclosure kit consists of a sheet metal part and a plastic part. The sheet metal part serves as bonding plate for conduits and is attached to the bottom of the heat sink. The plastic part serves as protection from live parts on power plugs.



— How to Install —

Mechanical dimensions		Frame size A2	Frame size A3
Height	A	14.8 in (375 mm)	14.8 in (375 mm)
Width	B	3.54 in (90 mm)	5.12 in (130 mm)
Bottom depth from back plate to front	C	7.95 in (202 mm)	7.95 in (202 mm)
Top depth from back plate to front (w/o option)	D	8.15 in (207 mm)	8.15 in (207 mm)
Top depth from back plate to front (w/ option)	D	8.74 in (222 mm)	8.74 in (222 mm)



Mechanical dimensions of the IP 21/IP 4x/TYPE 1 enclosure kit

1. Drill holes in accordance with the measurements given.
2. You must provide screws suitable for the surface on which you want to mount the FC 300. Retighten all four screws.

FC 300 IP20 allows side-by-side installation. Because of the need for cooling, there must be a minimum of 4 in (100 mm) free air passage above and below the FC 300.



— How to Install —

□ Safety Requirements of Mechanical Installation

Pay attention to the requirements that apply to integration and field mounting kit. Observe the information in the list to avoid serious damage or injury, especially when installing large units.

The adjustable frequency drive is cooled by means of air circulation.

To protect the unit from overheating, it must be ensured that the ambient temperature *does not rise above the maximum temperature stated for the adjustable frequency drive* and that the 24-hour average temperature *is not exceeded*. Locate the maximum temperature and 24-hour average in the paragraph *Derating for Ambient Temperature*.

If the ambient temperature is in the range of 113 °F - 131 °F (45 °C - 55 °C), derating of the adjustable frequency drive will become relevant, see *Derating for Ambient Temperature*.

The service life of the adjustable frequency drive is reduced if derating for ambient temperature is not taken into account.

□ Field Mounting

Field mounting is only possible with IP 21/IP 4X top/TYPE 1 (NEMA 1) kits part installed.



— How to Install —

□ **Electrical Installation**



NOTE

Cables General

Always comply with national and local regulations on cable cross-sections.

□ **Connection to Mains and Grounding**




NOTE

The plug connector for power can be removed.

1. Make sure the FC 300 is properly grounded. Connect to ground connection (terminal 95). Use screw from the accessory bag.
2. Place plug connector 91, 92, 93 from the accessory bag onto the terminals labeled MAINS at the bottom of FC 300.
3. Connect mains wires to the mains plug connector.



The ground connection cable cross-section must be at least 0.015 in.² (10 mm²) or 2 rated mains wires terminated separately.



How to connect to mains and grounding.




NOTE

Check that mains voltage corresponds to the mains voltage of the FC 300 nameplate.



Do not connect 400-V units with RFI-filters to electrical supplies with a voltage between phase and ground of more than 440 V. For IT AC line and delta ground (grounded leg), AC line voltage may exceed 440 V between phase and ground.



Terminals for electrical source and grounding.

— How to Install —


□ **Motor connection**




NOTE

Motor cable must be shielded/armored. If an unshielded/unarmored cable is used, some EMC requirements are not complied with. For more information, see *EMC specifications*.

1. Fasten grounding plate to the bottom of FC 300 with screws and washers from the accessory bag.




2. Attach motor cable to terminals 96 (U), 97 (V), 98 (W).
3. Connect to ground connection (terminal 99) on decoupling plate with screws from the accessory bag.
4. Insert terminals 96 (U), 97 (V), 98 (W) and motor cable to terminals labelled MOTOR.
5. Fasten shielded cable to grounding plate with screws and washers from the accessory bag.



— How to Install —

No.	96	97	98	Motor voltage 0-100% of AC line voltage. 3 wires out of motor
	U	V	W	
	U1	V1	W1	6 wires out of motor, Delta connected
	W2	U2	V2	
	U1	V1	W1	6 wires out of motor, Star connected U2, V2, W2 to be interconnected separately (optional terminal block)
No.	99			
	PE			

All types of three-phase asynchronous standard motors can be connected to the FC 300. Normally, small motors are star-connected (230/400 V, Δ/ Y). Large motors are delta-connected (400/690 V, Δ/ Y). Refer to the motor nameplate for correct connection mode and voltage.



NOTE

In motors without phase insulation paper or other insulation reinforcement suitable for operation with voltage supply (such as an adjustable frequency drive), fit an LC filter on the output of the FC 300.

□ **Motor Cables**

See section *General Specifications* for correct dimensioning of motor cable cross-section and length. Always comply with national and local regulations on cable cross-section.


- Use a shielded/armored motor cable to comply with EMC emission specifications unless otherwise stated for the RFI filter used.
- Keep the motor cable as short as possible to reduce the noise level and leakage currents.
- Connect the motor cable shield to the grounding plate of the FC 300 and to the metal cabinet of the motor.
- Make the shield connections with the largest possible surface area (cable clamp). This is done by using the supplied installation devices in the FC 300.
- Avoid mounting with twisted shield ends (pigtailed), which will spoil high frequency shielding effects.
- If it is necessary to split the shield to install a motor isolator or motor relay, the shield must be continued with the lowest possible HF impedance.

— How to Install —


□ **Thermal Motor Protection**

Connection of thermal motor protection device (PTC or 'Klixon' NC switch):


Using a digital input and 24 V as power supply:
 Example: Adjustable frequency drive trips when motor temperature too high
 Parameter set-up:
 Par. 1-90 Thermistor trip [2]
 Par. 1-93 Digital Input [6]



Using a digital input and 10 V as power supply:
 Example: Adjustable frequency drive trips when motor temperature too high
 Parameter set-up:
 Par. 1-90 Thermistor trip [2]
 Par. 1-93 Digital Input [6]



Using an analog input and 10 V as power supply:
 Example: Adjustable frequency drive trips when motor temperature too high
 Parameter set-up:
 Par. 1-90 Thermistor trip [2]
 Par. 1-93 Analog Input 54 [2]
 (No reference source must be selected)



— How to Install —

□ **Electrical Installation of Motor Cables**



NOTE

If a non-shielded cable is used, some EMC requirements are not complied with.

The motor cable must be shielded in order to comply with the EMC specifications regarding emission, unless otherwise stated for the RFI filter. Keep the motor cable as short as possible to reduce the noise level and leakage currents to a minimum. Connect the motor cable shield to the metal cabinet of the adjustable frequency drive and to the metal cabinet of the motor. Make the shield connections with the largest possible surface (cable clamp). This is done by using different installation devices in the various adjustable frequency drives.

Shielding of cables

Avoid installation with twisted shield ends (pigtailed). They spoil the shielding effect at higher frequencies. If it is necessary to break the shield to install a motor isolator or motor contactor, the shield must be continued at the lowest possible HF impedance.

Cable length and cross-section

The adjustable frequency drive has been tested with a given length of cable and a given cross-section of that cable. If the cross-section is increased, the cable capacitance - and thus the leakage current - increases, and the cable length must be reduced correspondingly.

Switching frequency

When adjustable frequency drives are used together with LC filters to reduce the acoustic noise from a motor, the switching frequency must be set according to the LC filter instruction in *Par. 14-01*.

Aluminum conductors

Aluminum conductors are not recommended. Terminals can accept aluminum conductors but the conductor surface must be clean and the oxidation must be removed and sealed by neutral acid-free grease before the conductor is connected.

Furthermore, the terminal screw must be retightened after two days due to the softness of the aluminum. It is crucial to keep the connection a gas-tight joint, otherwise the aluminum surface will oxidize again.



— How to Install —

□ **Fuses**

Branch circuit protection:

In order to protect the installation against electrical and fire hazard, all branch circuits in an installation, switch gear, machines etc., must be short circuit- and overcurrent-protected according to the national/international regulations.

Short circuit protection:

The adjustable frequency drive must be protected against short circuit to avoid electrical or fire hazard. Danfoss recommends using the fuses mentioned below to protect service personnel and other equipment in case of an internal failure in the drive. The adjustable frequency drive provides full short circuit protection in case of a short circuit on the motor output.

Overcurrent protection:

Provide overload protection to avoid fire hazard due to overheating of the cables in the installation. The adjustable frequency drive is equipped with an internal overcurrent protection that can be used for upstream overload protection (UL-applications excluded). See par. 4-18. Moreover, fuses or circuit breakers can be used to provide the overcurrent protection in the installation. Overcurrent protection must always be carried out according to national regulations.

To comply with UL/cUL approvals, use pre-fuses according to the following tables.

200-240 V

FC 30X	Bussmann	Bussmann	Bussmann	SIBA	Littel fuse	Ferraz-Shawmut	Ferraz-Shawmut
	Type RK1	Type J	Type T	Type RK1	Type RK1	Type CC	Type RK1
K2-K75	KTN-R10	JKS-10	JJN-10	5017906-010	KLN-R10	ATM-R10	A2K-10R
1K1-2K2	KTN-R20	JKS-20	JJN-20	5017906-020	KLN-R20	ATM-R20	A2K-20R
3K0-3K7	KTN-R30	JKS-30	JJN-30	5012406-032	KLN-R30	ATM-R30	A2K-30R



— How to Install —

380-500 V, 525-600 V

FC 30X	Bussmann	Bussmann	Bussmann	SIBA	Littel fuse	Ferraz-Shawmut	Ferraz-Shawmut
	Type RK1	Type J	Type T	Type RK1	Type RK1	Type CC	Type RK1
K37-1K5	KTS-R10	JKS-10	JJS-10	5017906-010	KLS-R10	ATM-R10	A6K-10R
2K2-4K0	KTS-R20	JKS-20	JJS-20	5017906-020	KLS-R20	ATM-R20	A6K-20R
5K5-7K5	KTS-R30	JKS-30	JJS-30	5012406-032	KLS-R30	ATM-R30	A6K-30R

KTS fuses from Bussmann may substitute KTN for 240 V adjustable frequency drives.
 FWH fuses from Bussmann may substitute FWX for 240 V adjustable frequency drives.
 KLSR fuses from LITTEL FUSE may substitute KLNR fuses for 240 V adjustable frequency drives.
 L50S fuses from LITTEL FUSE may substitute L50S fuses for 240 V adjustable frequency drives.
 A6KR fuses from FERRAZ SHAWMUT may substitute A2KR for 240 V adjustable frequency drives.
 A50X fuses from FERRAZ SHAWMUT may substitute A25X for 240 V adjustable frequency drives.

Non-UL compliance

If UL/cUL is not to be complied with, we recommend using the following fuses, which will ensure compliance with EN50178:

In case of malfunction, not following the recommendation may result in unnecessary damage of the adjustable frequency drive. Fuses must be designed for protection in a circuit capable of supplying a maximum of 100,000 A_{rms} (symmetrical), 500 V maximum.

FC 30X	Max. fuse size	Voltage	Type
K25-K75	10A ¹⁾	200-240 V	type gG
1K1-2K2	20A ¹⁾	200-240 V	type gG
3K0-3K7	32A ¹⁾	200-240 V	type gG
K37-1K5	10A ¹⁾	380-500V	type gG
2K2-4K0	20A ¹⁾	380-500V	type gG
5K5-7K5	32A ¹⁾	380-500V	type gG

1) Max. fuses - see national/international regulations for selecting an applicable fuse size.



— How to Install —

□ **Access to control terminals**

All terminals to the control cables are located underneath the terminal cover on the front of the FC 300. Remove the terminal cover by means of a screwdriver (see illustration).





□ **Electrical Installation, Control Terminals**

1. Mount terminals from the accessory bag to the front of the FC 300.
2. Connect terminals 18, 27, and 37 to +24 V (terminal 12/13) with the control cable.

Default settings:


- 18 = start
- 27 = coast inverse
- 37 = safe stop inverse



NOTE

To mount the cable to the terminal:

1. Strip isolation of 0.35 - 0.4 in. (9-10 mm)
2. Insert a screwdriver in the square hole.
3. Insert the cable in the adjacent circular hole.
4. Remove the screwdriver. The cable is now mounted to the terminal.




— How to Install —



NOTE

To remove the cable from the terminal:


1. Insert a screwdriver in the square hole.
2. Pull out the cable.



□ **Terminal 10, analog input voltage**

Drawing reference numbers:

1. 10 pole plug digital I/O.
2. 3 pole plug RS485 Bus.
3. 6 pole analog I/O.
4. USB Connection.



Control terminals



— How to Install —

□ Electrical Installation, Control Cables




Diagram showing all electrical terminals. Terminal 37 is not included in FC 301.

Very long control cables and analog signals may in rare cases, depending on installation, result in 50/60 Hz ground loops due to noise from mains supply cables.

If this occurs, you may have to break the shield or insert a 100 nF capacitor between shield and chassis.

The digital and analog inputs and outputs must be connected separately to the FC 300 common inputs (terminal 20, 55, 39) to avoid ground currents from both groups affecting other groups. For example, switching on the digital input may disturb the analog input signal.



— How to Install —




NOTE

Control cables must be shielded/armored.

1. Use a clamp from the accessory bag to connect the shield to the FC 300 grounding plate for control cables.

See section entitled *Grounding of Shielded/Armored Control Cables* for the correct termination of control cables.



□ **Switches S201, S202, and S801**


Switches S201 (A53) and S202 (A54) are used to select a current (0-20 mA) or a voltage (-10 to 10 V) configuration of the analog input terminals 53 and 54 respectively.

Switch S801 (BUS TER.) can be used to enable termination on the RS-485 port (terminals 68 and 69).

See drawing *Diagram showing all electrical terminals* in section *Electrical Installation*.

Default setting:

- S201 (A53) = OFF (voltage input)
- S202 (A54) = OFF (voltage input)
- S801 (Bus termination) = OFF



— How to Install —

□ **Tightening torques**

Tighten power, electrical, brake, and ground terminals with the following torques:

FC 300	Connections	Torque (Nm)
	Motor, electrical supply, brake, DC Bus	2-3
	Ground, 24 DC	2-3
	Relay, DC filter feedback	0.5-0.6

□ **Final Set-Up and Test**


To test the set-up and ensure that the adjustable frequency drive is running, follow these steps.

Step 1. Locate the motor nameplate.



NOTE

The motor is either star- (Y) or delta-connected (Δ). This information is located on the motor nameplate data.



Step 2. Enter the motor nameplate data in this parameter list.

To access this list, first press the [QUICK MENU] key then select "Q2 Quick Setup".

1.	Motor Power [kW] or Motor Power [HP]	par. 1-20 par. 1-21
2.	Motor Voltage	par. 1-22
3.	Motor Frequency	par. 1-23
4.	Motor Current	par. 1-24
5.	Motor Nominal Speed	par. 1-25

Step 3. Activate the Automatic Motor Adaptation (AMA)

Performing an AMA will ensure optimum performance. The AMA measures the values from the motor model equivalent diagram.



— How to Install —

1. Connect terminal 37 to terminal 12.
2. Start the adjustable frequency drive and activate the AMA par. 1-29.
3. Choose between complete or reduced AMA. If an LC filter is mounted, run only the reduced AMA, or remove the LC filter during the AMA procedure.
4. Press the [OK] key. The display shows "Press [Hand on] to start".
5. Press the [Hand on] key. A progress bar indicates if the AMA is in progress.

Stop the AMA during operation

1. Press the [OFF] key - the adjustable frequency drive enters into alarm mode and the display shows that the AMA was terminated by the user.

Successful AMA

1. The display shows "Press [OK] to finish AMA".
2. Press the [OK] key to exit the AMA state.

Unsuccessful AMA

1. The adjustable frequency drive enters into alarm mode. A description of the alarm can be found in the *Troubleshooting* section.
2. "Report Value" in the [Alarm Log] shows the last measuring sequence carried out by the AMA, before the adjustable frequency drive entered alarm mode. This number along with the description of the alarm will assist you in troubleshooting. If you contact Danfoss Service, make sure to mention number and alarm description.



NOTE

Unsuccessful AMA is often caused by incorrectly registered motor nameplate data.

Step 4. Set speed limit and ramp time

Set up the desired limits for speed and ramp time.

Minimum Reference	par. 3-02
Maximum Reference	par. 3-03

Motor Speed Low Limit	par. 4-11 or 4-12
Motor Speed High Limit	par. 4-13 or 4-14

Ramp 1 Ramp-up Time [s]	par. 3-41
Ramp 1 Ramp-down Time [s]	par. 3-42




— How to Install —

□ **Safe Stop Installation (FC 302 only)**

To carry out an installation of a Category 0 Stop (EN60204) in conformance with Safety Category 3 (EN954-1), follow these instructions:

1. The bridge (jumper) between Terminal 37 and 24 V DC of FC 302 must be removed. Cutting or breaking the jumper is not sufficient. Remove it entirely to avoid short-circuiting. See jumper on illustration.
2. Connect terminal 37 to 24 V DC by a short-circuit protected cable. The 24 V DC voltage supply must be interruptible by an EN954-1 Category 3 circuit interrupt device. If the interrupt device and the adjustable frequency drive are placed in the same installation panel, you can use a regular cable instead of a protected one.
3. The FC 302 must be placed in an IP 54 enclosure.



Bridge jumper between terminal 37 and 24 VDC.

The illustration below shows a Stopping Category 0 (EN 60204-1) with safety Cat. 3 (EN 954-1). The circuit interrupt is caused by an opening door contact. The illustration also shows how to connect a non-safety related hardware coast.




Illustration of the essential aspects of an installation to achieve a Stopping Category 0 (EN 60204-1) with safety Cat. 3 (EN 954-1).

— How to Install —

□ Safe Stop Commissioning Test

After installation and before first operation, perform a commissioning test of an installation or application making use of FC 300 Safe Stop.

Moreover, perform the test after each modification of the installation or application of which the FC 300 Safe Stop is part.

The commissioning test:

1. Remove the 24 V DC voltage supply to terminal 37 by the interrupt device while the motor is driven by the FC 302 (i.e. mains supply is not interrupted). The test step is passed if the motor reacts with a coast and the mechanical brake (if connected) is activated.
2. Then send Reset signal (via Bus, Digital I/O, or [Reset] key). The test step is passed if the motor remains in the Safe Stop state, and the mechanical brake (if connected) remains activated.
3. Then reapply 24 V DC to terminal 37. The test step is passed if the motor remains in the coasting state, and the mechanical brake (if connected) remains activated.
4. Then send Reset signal (via Bus, Digital I/O, or [Reset] key). The test step is passed if the motor becomes operational again.
5. The commissioning test is passed if all four test steps are passed.




— How to Install —

□ **Additional Connections**

□ **Load sharing**

With load sharing you can connect several adjustable frequency drive's DC intermediate circuits if you extend the installation using extra fuses and AC coils (see illustration).



NOTE

Load sharing cables must be shielded/armoured. If an unshielded/unarmoured cable is used, some EMC requirements are not complied with.



Voltage levels of up to 975 V DC may occur between terminals 88 and 89.

No.	88	89	Loadsharing
	DC	DC +	

□ **Installation of Load Sharing**

The connection cable must be shielded and the maximum length from the adjustable frequency drive to the DC bar is 82 ft (25 m).



NOTE

Load sharing calls for extra equipment. For further information, see Load-sharing Instructions MI.50.NX.YY.

□ **Brake Connection Option**

The connection cable to the brake resistor must be shielded/armoured.

No.	81	82	Brake resistor
	R-	R+	terminals



1. Use cable clamps to connect the shield to the metal cabinet of the adjustable frequency drive and to the decoupling plate of the brake resistor.
2. Dimension the cross-section of the brake cable to match the brake current.

— How to Install —



NOTE

Voltages up to 975 V DC (@ 600 V AC) may occur between the terminals.




NOTE

If a short circuit in the brake resistor occurs, prevent power dissipation in the brake resistor by using a mains switch or contactor to disconnect the mains for the adjustable frequency drive. Only the adjustable frequency drive can control the contactor.

□ **Relay connection**

To set relay output, see parameter group 5-4* Relays.

No.	01 - 02	make (normally open)
	01 - 03	break (normally closed)
	04 - 05	make (normally open)
	04 - 06	break (normally closed)



Terminals for relay connection.



— How to Install —

□ **Relay Output**

Relay 1


- Terminal 01: common
- Terminal 02: normal open 240 V AC
- Terminal 03: normal closed 240 V AC

Relay 2

- Terminal 04: common
- Terminal 05: normal open 400 V AC
- Terminal 06: normal closed 240 V AC


Relay 1 and relay 2 are programmed in par. 5-40, 5-41, and 5-42.

Additional relay outputs by using option module MCB 105.



□ **Parallel Connection of Motors**

The adjustable frequency drive can control several motors connected in parallel. The total current consumption of the motors must not exceed the rated output current I_{INV} for the adjustable frequency drive. This is only recommended when VVC^{plus} is selected in par. 1-01.



Problems may arise at start and at low RPM values if motor sizes are widely different because small motors' relatively high ohmic resistance in the stator requires a higher voltage at start and to operate at low RPM values.



— How to Install —

The electronic thermal relay (ETR) of the adjustable frequency drive cannot be used as motor protection for the individual motor of systems with parallel-connected motors. Provide further motor protection by e.g. thermistors in each motor or individual thermal relays. (Circuit breakers are not suitable as protection).



NOTE


When motors are connected in parallel, par. 1-02 *Automatic motor adaptation (AMA)* cannot be used, and par. 1-01 *Torque characteristics* must be set to *Special motor characteristics*.

□ **Direction of Motor Rotation**

The default setting is clockwise rotation with the adjustable frequency drive output connected as follows.

- Terminal 96 connected to U-phase
- Terminal 97 connected to V-phase
- Terminal 98 connected to W-phase

The direction of motor rotation is changed by switching two phases in the motor cable.



□ **Installation of Brake Cable**

(Only for adjustable frequency drives ordered with brake chopper option).

The connection cable to the brake resistor must be shielded.

1. Connect the shield by means of cable clamps to the conductive back plate on the adjustable frequency drive and to the metal cabinet of the brake resistor.
2. Size the brake cable cross-section to match the brake torque.

No.	Function
81, 82	Brake resistor terminals

See Brake instructions, MI.90.FX.YY and MI.50.SX.YY for more information about safe installation.



NOTE

Voltages up to 960 V DC, depending on the supply voltage, may occur on the terminals.




— How to Install —

□ **Bus Connection**

One or more adjustable frequency drives can be connected to a controller (or master) using the RS-485 standardized interface. Terminal 68 is connected to the P signal (TX+, RX+), while terminal 69 is connected to the N signal (TX-,RX-).

If more than one adjustable frequency drive is connected to a master, use parallel connections.



In order to avoid potential equalizing currents in the shield, ground the cable shield via terminal 61, which is connected to the frame via an RC-link.


Bus termination

The RS-485 bus must be terminated by a resistor network at both ends. For this purpose, set switch S801 on the control card to "ON".

For more information, see the paragraph *Switches S201, S202, and S801*.

□ **How to Connect a PC to the FC 300**

To control the adjustable frequency drive from a PC, install the MCT 10 Setup Software. The PC is connected via a standard (host/device) USB cable, or via the RS-485 interface as shown in the section *Bus Connection* in the chapter *How to Program*.



USB connection.

□ **The FC 300 Software Dialog**

Data storage in PC via MCT 10 Set-Up Software:

1. Connect a PC to the unit via USB com port
2. MCT 10 Set-up Software
3. Choose "Read from drive"
4. Choose "Save as"

All parameters are now stored.

Data transfer from PC to drive via MCT 10 Set-Up Software:

1. Connect a PC to the unit via USB com port
2. MCT 10 Set-up Software
3. Choose "Open" - stored files will be shown
4. Open the appropriate file
5. Choose "Write to drive"

All parameters are now transferred to the drive.

A separate manual for MCT 10 Set-up Software is available.



— How to Install —

□ High Voltage Test

Carry out a high voltage test by short circuiting terminals U, V, W, L₁, L₂ and L₃. Energize by max. 2.15 kV DC for one second between this short circuit and the chassis.



NOTE

When running high voltage tests of the entire installation, interrupt the mains and motor connection if the leakage currents are too high.

□ Safety Grounding

The adjustable frequency drive has a high leakage current and must be grounded appropriately for safety reasons.



The ground leakage current from the adjustable frequency drive exceeds 3.5 mA. To ensure a good mechanical connection from the ground cable to the ground connection (terminal 95), the cable cross-section must be at least 0.015 in² (10 mm²) or 2 rated ground wires terminated separately.

□ Electrical Installation - EMC Precautions

The following is a guideline to good engineering practice when installing adjustable frequency drives. Follow these guidelines to comply with EN 61800-3 *First environment*. If the installation is in EN 61800-3 *Second environment*, i.e. industrial networks, or in an installation with its own transformer, deviation from these guidelines is allowed but not recommended. See also paragraphs *CE Labeling*, *General Aspects of EMC Emission* and *EMC Test Results*.

Good engineering practice to ensure EMC-correct electrical installation:


- Use only braided shielded/armored motor cables and braided shielded/armored control cables. The shield should provide a minimum coverage of 80%. The shield material must be metal, not limited to but typically copper, aluminum, steel or lead. There are no special requirements for the mains cable.
- Installations using rigid metal conduits are not required to use shielded cable, but the motor cable must be installed in conduit separate from the control and mains cables. Full connection of the conduit from the drive to the motor is required. The EMC performance of flexible conduits varies considerably and information from the manufacturer must be obtained.
- Connect the shield/armor/conduit to ground at both ends for motor cables as well as for control cables. In some cases, it is not possible to connect the shield in both ends. If so, connect the shield at the adjustable frequency drive. See also *Grounding of Braided Shielded/Armored Control Cables*.
- Avoid terminating the shield/armor with twisted ends (pigtails). It increases the high frequency impedance of the shield, which reduces its effectiveness at high frequencies. Use low-impedance cable clamps or EMC cable glands instead.
- Avoid using non-shielded/unarmored motor or control cables inside cabinets housing the drive(s), whenever this can be avoided.

Leave the shield as close to the connectors as possible.

The illustration shows an example of an EMC-correct electrical installation of an IP 20 adjustable frequency drive. The adjustable frequency drive is fitted in an installation cabinet with an output contactor and connected to a PLC, which is installed in a separate cabinet. Other ways of performing the installation may yield just as good EMC performance, provided the above guidelines for engineering practice are followed.

If the installation is not carried out according to the guidelines and if non-shielded cables and control wires are used, some emission requirements are not complied with, although the immunity requirements are fulfilled. See the paragraph *EMC test results*.

— How to Install —



EMC-correct electrical installation of an IP20 adjustable frequency drive.



— How to Install —

□ **Use of EMC-Correct Cables**

Danfoss recommends braided shielded/armored cables to optimize EMC immunity of the control cables and the EMC emission from the motor cables.


The ability of a cable to reduce the incoming and outgoing radiation of electric noise depends on the transfer impedance (Z_T). The shield of a cable is normally designed to reduce the transfer of electric noise; however, a shield with a lower transfer impedance (Z_T) value is more effective than a shield with a higher transfer impedance (Z_T).

Transfer impedance (Z_T) is rarely stated by cable manufacturers but it is often possible to estimate transfer impedance (Z_T) by assessing the physical design of the cable.

Transfer impedance (Z_T) can be assessed on the basis of the following factors:

- The conductivity of the shield material.
- The contact resistance between the individual shield conductors.
- The shield coverage, i.e. the physical area of the cable covered by the shield - often stated as a percentage value.
- Shield type, i.e. braided or twisted pattern.

- a. Aluminum-clad with copper wire.
- b. Twisted copper wire or armored steel wire cable.
- c. Single-layer braided copper wire with varying percentage shield coverage. This is the typical Danfoss reference cable.
- d. Double-layer braided copper wire.
- e. Twin layer of braided copper wire with a magnetic, shielded/armored intermediate layer.
- f. Cable that runs in copper tube or steel tube.
- g. Lead cable with 0.043 in. (1.1 mm) wall thickness.



— How to Install —

□ **Grounding of Shielded/Armored Control Cables**

Generally speaking, control cables must be braided shielded/armored and the shield must be connected by means of a cable clamp at both ends to the metal cabinet of the unit.

The drawing below indicates how correct grounding is carried out and what to do if in doubt.

a. **Correct grounding**

Control cables and cables for serial communication must be fitted with cable clamps at both ends to ensure the best possible electrical contact.

b. **Wrong grounding**

Do not use twisted cable ends (pigtailed). They increase the shield impedance at high frequencies.

c. **Protection with respect to ground potential between PLC and VLT**


If the ground potential between the adjustable frequency drive and the PLC (etc.) is different, electric noise may occur that will disturb the entire system. Solve this problem by fitting an equalizing cable, next to the control cable. Minimum cable cross-section: 0.025 in.² (16 mm²).

d. **For 50/60 Hz ground loops**

If very long control cables are used, 50/60 Hz ground loops may occur. Solve this problem by connecting one end of the shield to ground via a 100nF capacitor (keeping leads short).

e. **Cables for serial communication**

Eliminate low-frequency noise currents between two adjustable frequency drives by connecting one end of the shield to terminal 61. This terminal is connected to ground via an internal RC link. Use twisted-pair cables to reduce the differential mode interference between the conductors.




— How to Install —

□ **Mains Supply Interference/Harmonics**

An adjustable frequency drive takes up a non-sinusoidal current from mains, which increases the input current I_{RMS} . A non-sinusoidal current is transformed by means of a Fourier analysis and split up into sine wave currents with different frequencies, i.e. different harmonic currents I_N with 50 Hz as the basic frequency:

Harmonic currents	I_1	I_5	I_7
Hz	50 Hz	250 Hz	350 Hz

The harmonics do not affect the power consumption directly but increase the heat losses in the installation (transformer, cables). Consequently, in plants with a high percentage of rectifier load, maintain harmonic currents at a low level to avoid overload of the transformer and high temperature in the cables.



NOTE

Some of the harmonic currents might disturb communication equipment connected to the same transformer or cause resonance in connection with power-factor correction batteries.

Harmonic currents compared to the RMS input current:

	Input current
I_{RMS}	1.0
I_1	0.9
I_5	0.4
I_7	0.2
I_{11-49}	< 0.1

To ensure low harmonic currents, the adjustable frequency drive is equipped with intermediate circuit coils as standard. This normally reduces the input current I_{RMS} by 40%.

The voltage distortion on the mains supply depends on the size of the harmonic currents multiplied by the mains impedance for the frequency in question. The total voltage distortion THD is calculated on the basis of the individual voltage harmonics using this formula:

$$THD\% = \sqrt{U_5^2 + U_7^2 + \dots + U_N^2} \quad (U_N \text{ \% of } U)$$

— How to Install —

□ Residual Current Device

You can use RCD relays, multiple protective grounding or grounding as extra protection, provided that local safety regulations are complied with.

If a ground fault appears, a DC content may develop in the faulty current.


If RCD relays are used, you must observe local regulations. Relays must be suitable for protection of 3-phase equipment with a bridge rectifier and for a brief discharge on power-up; see section *Ground Leakage Current* for further information.



— How to Install —



Application Examples




□ **Start/Stop**

Terminal 18 = start/stop par. 5-10 [8] *Start*
 Terminal 27 = No operation par. 5-12 [0] *No operation* (Default *coast inverse*)
 Terminal 37 = coasting stop (safe)

Par. 5-10 *Digital Input = Start* (default)

Par. 5-12 *Digital Input = coast inverse* (default)




□ **Pulse start/stop**

Terminal 18 = latched start
 Terminal 27 = stop inverse

Par. 5 *Digital input = Pulse start -10*

Par. 5 *Digital input = Stop inverted -12*




— Application Examples —

□ **Potentiometer Reference**

Voltage reference via a potentiometer.


- Par. 3-15 Reference Resource 1 [1]
= Analog Input 53
- Par. 6-10 Terminal 53, Low Voltage = 0 Volt
- Par. 6-11 Terminal 53, High Voltage = 10 Volt
- Par. 6-14 Terminal 53, Low Ref./Feedb.
Value Value = 0 RPM
- Par. 6-15 Terminal 53, High Ref./Feedb.
Value Value = 1,500 RPM
- Switch S201 = OFF (U)



□ **Encoder Connection**

The purpose of this guideline is to ease the set-up of encoder connection to FC 302. Before setting up the encoder, the basic settings for a closed-loop speed control system will be shown.


Encoder Connection to FC 302



— Application Examples —

□ **Encoder Direction**


The direction of encoder is determined by which order the pulses are entering the drive.
Clockwise direction means channel A is 90 electrical degrees before channel B.
Counter Clockwise direction means channel B is 90 electrical degrees before A.
 The direction determined by looking into the shaft end.



□ **Closed Loop Drive System**

A drive system consist usually of more elements as:

- Motor
- Add (Gearbox)
- (Mechanical Brake)
- FC 302 AutomationDrive
- Encoder as feedback system
- Brake resistor for dynamic braking
- Transmission
- Load



Basic Set-up for FC 302 Closed Loop Speed Control

Applications demanding mechanical brake control will usually need a brake resistor.



— Application Examples —

□ Programming of Torque Limit and Stop

In applications with an external electromechanical brake, such as hoisting applications, it is possible to stop the adjustable frequency drive via a "standard" stop command and simultaneously activate the external electromechanical brake.


The example given below illustrates the programming of adjustable frequency drive connections. The external brake can be connected to relay 1 or 2, see paragraph *Control of Mechanical Brake*. Program terminal 27 to Coast, inverse [2] or Coast and Reset, inverse [3], and program terminal 29 to Torque limit & stop [27].

Description:

If a stop command is active via terminal 18 and the adjustable frequency drive is not at the torque limit, the motor ramps down to 0 Hz.

If the adjustable frequency drive is at the torque limit and a stop command is activated, terminal 42 Output (programmed to Torque limit and stop [27]) is activated. The signal to terminal 27 I changes from "logic 1" to "logic 0", and the motor starts to coast, thereby ensuring that the hoist stops even if the drive itself cannot handle the required torque (i.e. due to excessive overload).

- Start/stop via terminal 18.
Par. 5-10 *Start* [8].
- Quickstop via terminal 27.
Par. 5-12 *Coasting Stop, Inverse* [2].
- Terminal 29 Output
Par. 3-19 *Torque Limit & Stop* [27].
- Terminal 1 Relay output
Par. 5-40 *Mechanical Brake Control* [32].



□ Automatic Motor Adaptation (AMA)

AMA is a test algorithm which measures the electrical motor parameters at motor standstill. This means that AMA itself does not supply any torque.

AMA is useful when commissioning systems, where you want to optimize the adjustment of the adjustable frequency drive to the applied motor. This feature is particularly used where the default setting does not adequately cover the motor.

Par. 1-29 allows a choice of complete AMA with determination of all electrical motor parameters, or reduced AMA with determination of the stator resistance R_s only.

The duration of a total AMA varies from a few minutes on small motors to more than 15 minutes on large motors.

Limitations and preconditions:

- For the AMA to determine the motor parameters optimally, enter the correct motor nameplate data in par. 1-20 to 1-26.
- For the best adjustment of the adjustable frequency drive, carry out AMA on a cold motor. Repeated AMA runs may lead to a heating of the motor, which results in an increase of the stator resistance, R_s . Normally, this is not critical.
- AMA can only be carried out if the rated motor current is minimum 35% of the rated output current of the adjustable frequency drive. AMA can be carried out on up to one oversize motor.



— Application Examples —

- It is possible to carry out a reduced AMA test with an LC filter installed. Avoid carrying out a complete AMA with an LC filter. If an overall setting is required, remove the LC filter while running a total AMA. After completion of the AMA, reinsert the LC filter.
- If motors are coupled in parallel, use only reduced AMA if any.
- Avoid running a complete AMA when using synchronous motors. If synchronous motors are applied, run a reduced AMA.
- The adjustable frequency drive does not produce motor torque during an AMA. During an AMA, it is imperative that the application does not force the motor shaft to run, which is known to happen with e.g. windmilling in ventilation systems. This disturbs the AMA function.



— Application Examples —

□ **Smart Logic Control Programming 01**

New useful facility in FC 302 is the Smart Logic Control (SLC).


In applications where a PLC is generating a simple sequence the SLC may take over elementary tasks from the main control.

SLC is designed to act from event sent to or generated in the FC 302. The adjustable frequency drive will then perform the pre-programmed action.

□ **SLC Application Example**

One sequence 1:

Start - ramp-up - run at reference speed 2 sec - ramp-down and hold shaft until stop.



Set the ramping times in par. 3-41 and 3-42 to the desired times

$$t_{ramp} = \frac{t_{acc} * n_{norm}[par.1-25]}{\Delta ref[RPM]}$$

Set term 27 to *No operation* (par. 5-12)

Set Preset reference 0 to first preset speed (par. 3-10 [0]) in percentage of Max Reference speed (par. 3-03). Ex.: 60%

Set preset reference 1 to second preset speed (par. 1-10 [1] Ex.: 0 % (zero).

Set the timer 0 for constant running speed in par. 13-20 [0]. Ex.: 2 sec.

Set Event 0 in par. 13-51 [0] to *True* [1]

Set Event 1 in par. 13-51 [1] to *On Reference* [4]

Set Event 2 in par. 13-51 [2] to *SL Timeout 0* [30]

Set Event 3 in par. 13-51 [3] to *False* [0]

Set Action 0 in par. 13-52 [0] to *Select preset ref. 0* [10]


Set Action 1 in par. 13-52 [1] to *Start timer 0* [29]

Set Action 2 in par. 13-52 [2] to *Select preset ref. 1* [11]

Set Action 3 in par. 13-52 [3] to *No action* [1]



— Application Examples —




Set the Smart Logic Control in par. 13-00 to ON.

Start / stop command is applied on terminal 18. If stop signal is applied, the adjustable frequency drive will ramp down and go into free mode.

□ **Application Example**

Continuously sequencing 2:

Start - ramp-up - run at reference speed 0 in 2 sec - ramp-down to reference speed 1 - run at reference speed 1 in 3 sec - ramp-up to reference speed 0 and then continue sequencing until stop is applied.



Preparing for set-up:

Set the ramping times in par. 3-41 and 3-42 to the desired times

$$t_{ramp} = \frac{t_{acc} * n_{norm}[par.1-25]}{\Delta ref[RPM]}$$

Set term 27 to *No operation* (par. 5-12)

Set Preset reference 0 to first preset speed (par. 3-10 [0]) in percentage of Max Reference speed (par. 3-03). Ex.: 60%

Set Preset reference 1 to first preset speed (par. 3-10 [1]) in percentage of Max Reference speed (par. 3-03). Ex.: 10%

Set preset reference 1 to second preset speed (par. 1-10 [1] Ex.: 10 % (zero).



— Application Examples —

Set the timer 0 for constant running speed in par. 13-20 [0]. Ex.: 2 sec.

Set the timer 1 for constant running speed in par. 13-20 [1]. Ex.: 3 sec.

Set Event 0 in par. 13-51 [0] to *True* [1]

Set Event 1 in par. 13-51 [1] to *On Reference* [4]

Set Event 2 in par. 13-51 [2] to *SL Timeout 0* [30]

Set Event 3 in par. 13-51 [3] to *On Reference* [4]

Set Event 4 in par. 13-51 [4] to *SL Timeout* [30]

Set Action 0 in par. 13-52 [0] to *Select preset ref. 0* [10]

Set Action 1 in par. 13-52 [1] to *Start timer 0* [29]

Set Action 2 in par. 13-52 [2] to *Select preset ref. 1* [11]


Set Action 3 in par. 13-52 [3] to *Start timer 1* [30]

Set Action 4 in par. 13-52 [4] to *No action* [1]





How to Program



□ The Graphical and Numerical FC 300 Local

□ How to Program on the Graphical Local Control Panel

The following instructions are valid for the graphical LCP (LCP 102):


The control panel is divided into four functional groups:

1. Graphical display with Status lines.
2. Menu keys and LEDs - changing parameters and switching between display functions.
3. Navigation keys and LEDs.
4. Operation keys and LEDs.

All data is displayed in a graphical LCP display, which can show up to five items of operating data while displaying [Status].

Display lines:

- a. **Status line:** Status messages displaying icons and graphic.
- b. **Line 1-2:** Operator data lines displaying data defined or chosen by the user. By pressing the [Status] key, up to one extra line can be added.
- c. **Status line:** Status messages displaying text.



— How to Program —




The LCD display has back lighting and a total of 6 alpha-numeric lines. The display lines show the direction of rotation (arrow), the chosen Set-up as well as the programming Set-up. The display is divided into 3 sections:

Top section shows up to 2 measurements in normal operating status.

The top line in the **Middle section** shows up to 5 measurements with related units, regardless of status (except in the case of alarm/warning).

Bottom section always shows the state of the adjustable frequency drive in Status mode.



The Active Set-up (selected as the Active Set-up in par. 0-10) is shown. When programming another Set-up other than the Active Set-up, the number of the programmed Set-up appears to the right.

Display Contrast Adjustment

Press [status] and [▲] for darker display

Press [status] and [▼] for brighter display


Most FC 300 parameter set-ups can be changed immediately via the control panel, unless a password has been created via par. 0-60 *Main Menu Password* or via par. 0-65 *Quick Menu Password*.

LEDs:

If certain threshold values are exceeded, the alarm and/or warning LED light(s) up. A status and alarm text appear on the control panel.

The on LED is activated when the adjustable frequency drive receives line voltage or via a DC bus terminal or 24 V external supply. At the same time, the back light is on.


- Green LED/On: Control section is working.
- Yellow LED/Warn.: Indicates a warning.
- Flashing Red LED/Alarm: Indicates an alarm.



— How to Program —

LCP keys

The control keys are divided into functions. The keys below the display and LEDs are used for parameter Set-up, including choice of display indication during normal operation.



[Status] indicates the status of the adjustable frequency drive and/or the motor. You can choose between 3 different readouts by pressing the [Status] key:

5 line readouts, 4 line readouts or Smart Logic Control.

Use **[Status]** for selecting the mode of display or for changing back to Display mode from either the Quick Menu mode, the Main Menu mode or Alarm mode. Also use the [Status] key to toggle single or double readout mode.

[Quick Menus] allows quick access to different Quick Menus such as:

- My personal menu
- Quick setup
- Changes made
- Loggings

Use **[Quick Menus]** for programming the parameters belonging to the Quick Menu. It is possible to switch directly between Quick Menu mode and Main Menu mode.

[Main Menu] is used for programming all parameters.

It is possible to switch directly between Main Menu mode and Quick Menu mode.

Parameter shortcut can be carried out by pressing down the **[Main Menu]** key for 3 seconds.

The parameter shortcut allows direct access to any parameter.

[Alarm log] displays an Alarm list of the five latest alarms (numbered A1-A5). To obtain additional details about an alarm, use the arrow keys to maneuver to the alarm number and press [OK]. You will now receive information about the condition of your adjustable frequency drive right before entering the alarm mode.

[Back] takes you to the previous step or layer in the navigation structure.

[Cancel] annuls your last change or command as long as the display has not been changed.

[Info] supplies information about a command, parameter, or function in any display window. [Info] provides detailed information whenever help is needed.

Exit info mode by pressing either [Info], [Back], or [Cancel].




— How to Program —

Navigation Keys

The four navigation arrows are used to navigate between the different choices available in **[Quick Menu]**, **[Main Menu]** and **[Alarm log]**. Use the keys to move the cursor.

[OK] is used for choosing a parameter marked by the cursor and for enabling the change of a parameter.

Local Control Keys for local control are found at the bottom of the control panel.



[Hand on] enables control of the adjustable frequency drive via the LCP. **[Hand on]** also starts the motor, and it is now possible to enter the motor speed data by means of the arrow keys. The key can be selected as Enabled [1] or Disabled [0] via par. 0-40 *[Hand on] key on LCP*.

External stop signals activated by means of control signals or a serial bus will override a "start" command via the LCP.

The following control signals will still be active when **[Hand on]** is activated:

- **[Hand on]** - **[Off]** - **[Auto on]**
- Reset
- Coasting stop inverse
- Reverse
- Set-up select lsb - Set-up select msb
- Stop command from serial communication
- Quick stop
- DC brake

[Off] stops the connected motor. The key can be selected as Enabled [1] or Disabled [0] via par. 0-41 *[Off] key on LCP*. If no external stop function is selected and the **[Off]** key is inactive, the motor can be stopped by disconnecting the voltage.

[Auto on] enables the adjustable frequency drive to be controlled via the control terminals and/or serial communication. When a start signal is applied on the control terminals and/or the bus, the adjustable frequency drive will start. The key can be selected as Enabled [1] or Disabled [0] via par. 0-42 *[Auto on] key on LCP*.



NOTE

An active HAND-OFF-AUTO signal via the digital inputs has higher priority than the control keys **[Hand on]** - **[Auto on]**.


[Reset] is used for resetting the adjustable frequency drive after an alarm (trip). It can be selected as *Enabled* [1] or *Disabled* [0] via par. 0-43 *Reset Keys on LCP*.

The parameter shortcut can be carried out by holding down the **[Main Menu]** key for 3 seconds. The parameter shortcut allows direct access to any parameter.

— How to Program —

□ Quick Transfer of Parameter Settings

Once the setup of a drive is complete, it is recommended that the data is stored in the LCP or on a PC via MCT 10 Setup Software Tool.



Data storage in LCP:

1. Go to par. 0-50 LCP copy
2. Press the [OK] key
3. Select "All to LCP"
4. Press the [OK] key

All parameter settings are now stored in the LCP indicated by the progress bar. When 100% is reached, press [OK].



NOTE

Stop the unit before performing this operation.

It is now possible to connect the LCP to another adjustable frequency drive and copy the parameter settings to this adjustable frequency drive as well.

Data transfer from LCP to drive:

1. Go to par. 0-50 LCP copy
2. Press the [OK] key
3. Select "All from LCP"
4. Press the [OK] key

The parameter settings stored in the LCP are now transferred to the drive indicated by the progress bar. When 100% is reached, press [OK].



NOTE

Stop the unit before performing this operation.

— How to Program —



Display Mode

In normal operation, up to 5 different operating variables can be indicated continuously in the middle section: 1.1, 1.2, and 1.3 as well as 2 and 3.

Display Mode - Selection of Read-Outs

You can toggle between three status readout screens by pressing the [Status] key. Operating variables with different formatting are shown in each status screen - see below.

The table shows the measurements you can link to each of the operating variables. Define the links via par. 0-20, 0-21, 0-22, 0-23, and 0-24.

Each readout parameter selected in par. 0-20 to par. 0-24 has its own scale and digits after a possible decimal point. By larger numeric value of a parameter fewer digits are displayed after the decimal point.

Ex.: Current readout
5.25 A; 15.2 A 105 A.


Operating variable:	Unit:
Par. 16-00 Control Word	hex
Par. 16-01 Reference	[unit]
Par. 16-02 Reference	%
Par. 16-03 Status word	hex
Par. 16-04 Alarm word	hex
Par. 16-05 Warning word	hex
Par. 16-06 Extended status word	hex
Par. 16-10 Power	[kW]
Par. 16-11 Power	[HP]
Par. 16-12 Motor voltage	[V]
Par. 16-13 Frequency	[Hz]
Par. 16-14 Motor current	[A]
Par. 16-16 Torque	Nm
Par. 16-17 Speed	[RPM]
Par. 16-18 Motor thermal	%
Par. 16-20 Phase angle	
Par. 16-30 DC link voltage	V
Par. 16-32 Brake energy / s	kW
Par. 16-33 Brake energy / 2 min	kW
Par. 16-34 Heatsink temp.	C
Par. 16-35 Inverter thermal	%
Par. 16-36 InomVLT	A
Par. 16-37 ImaxVLT	A
Par. 16-38 SL controller state	
Par. 16-39 Control card temp.	C
Par. 16-50 External reference	
Par. 16-51 Pulse reference	
Par. 16-52 Feedback	[Unit]
Par. 16-60 Digital input	bin
Par. 16-61 Terminal 53 switch setting	V
Par. 16-62 Analog input 53	
Par. 16-63 Terminal 54 switch setting	V
Par. 16-64 Analog input 54	
Par. 16-65 Analog output 42	[mA]
Par. 16-66 Digital output	[bin]
Par. 16-67 Freq. input #29	[Hz]
Par. 16-68 Freq. input #33	[Hz]
Par. 16-69 Pulse output #27	[Hz]
Par. 16-70 Pulse output #29	[Hz]
Par. 16-80 Fieldbus CTW	hex
Par. 16-82 Fieldbus REF	hex
Par. 16-83 Fieldbus MAV	hex
Par. 16-84 Comm. option STW	hex
Par. 16-85 FC port CTW 1	hex
Par. 16-86 FC port REF 1	hex

Status screen I:

This readout state is standard after start-up or initialization.

Use [INFO] to obtain information about the measurement links to the displayed operating variables (1.1, 1.2, 1.3, 2, and 3).


See the operating variables shown in the screen in this illustration.



— How to Program —


Status screen II:

See the operating variables (1.1, 1.2, 1.3, and 2) shown in the screen in this illustration. In the example, Speed, Motor current, Motor power and Frequency are selected as variables in the first and second.



Status screen III:

This state displays the event and action of the Smart Logic Controller. For further information, see section *Smart Logic Controller*.




□ **Parameter Set-Up**

The FC 300 Series can be used for practically all assignments, which is why the number of parameters is quite large. The series offers a choice between two programming modes - a Main Menu and a Quick Menu mode. The former provides access to all parameters. The latter takes the user through a few parameters making it possible to start operating the adjustable frequency drive. Regardless of the mode of programming, you can change a parameter both in the Main Menu mode and in the Quick Menu mode.

□ **Quick Menu Key Functions**

Pressing [Quick Menus] The list indicates the different areas contained in the Quick menu. Select *My personal menu* to display the chosen personal parameters. These parameters are selected in par. 0-25 *My Personal Menu*. Up to 20 different parameters can be added in this menu.



Select *Quick setup* to go through a limited number of parameters to get the motor running almost optimally. The default setting for the other parameters considers the desired control functions and the configuration of signal inputs/outputs (control terminals).

Parameters are selected by using the arrow keys. The parameters in the following table are accessible.

— How to Program —



Parameter	Designation	Setting
0-01	Language	
1-20	Motor Power	[kW]
1-22	Motor Voltage	[V]
1-23	Motor Frequency	[Hz]
1-24	Motor Current	[A]
1-25	Motor Nominal Speed	[rpm]
5-12	Terminal 27 Digital Input	[0] No function*
3-02	Minimum Reference	[rpm]
3-03	Maximum Reference	[rpm]
3-41	Ramp 1 Ramp-up Time	[sec]
3-42	Ramp 1 Ramp-down Time	[sec]
3-13	Reference Site	
1-29	Automatic Motor Adaptation (AMA)	[1] Enable complete AMA

* If no connection in terminal 27 is selected, no connection to +24 V on terminal 27 necessary.


Select *Changes made* to get information about:

- the last 10 changes. Use the up/down navigation keys to scroll between the last 10 changed parameters.
- the changes made since default setting.

Select *Loggings* to get information about the display line readouts. The information is shown as graphs. Only display parameters selected in par. 0-20 and par. 0-24 can be viewed. It is possible to store up to 120 samples in the memory for later reference.

□ **Main Menu Mode**

Start the Main Menu mode by pressing the [Main Menu] key. The readout shown to the right appears on the display. The middle and bottom sections on the display show a list of parameter groups which can be chosen by toggling the up and down buttons.



Each parameter has a name and number which remain the same regardless of the programming mode. In the Main Menu mode, the parameters are divided into groups. The first digit of the parameter number (from the left) indicates the parameter group number.

All parameters can be changed in the Main Menu. However, depending on the choice of configuration (par. 1-00), some parameters can be "missing". E.g. open loop hides all the P.I.D. parameters, and other enabled options make more parameter groups visible.

— How to Program —

□ **Parameter Selection**


In the Main menu mode, the parameters are divided into groups. Select a parameter group by means of the navigation keys.

The following parameter groups are accessible:

Group no.	Parameter group:
0	Operation/Display
1	Load/Motor
2	Brakes
3	References/Ramps
4	Limits/Warnings
5	Digital In/Out
6	Analog In/Out
7	Controllers
8	Comm. and options
9	Profibus
10	CAN fieldbus
11	Reserved com. 1
12	Reserved com. 2
13	Prog. Features
14	Special functions
15	Drive information
16	Data readouts



After selecting a parameter group, choose a parameter by means of the navigation keys. The middle section on the display shows the parameter number and name as well as the selected parameter value.




□ **Changing Data**

The procedure for changing data is the same whether you select a parameter in the Quick menu or the Main menu mode. Press [OK] to change the selected parameter.

The procedure for changing data depends on whether the selected parameter represents a numerical data value or a text value.

□ **Changing a Text Value**

If the selected parameter is a text value, change the text value by means of the up/down navigation keys. The up key increases the value, and the down key decreases the value. Place the cursor on the value you want to save and press [OK].




— How to Program —




□ **Changing a Group of Numeric Data Values**

If the chosen parameter represents a numeric data value, change the chosen data value by means of the <> navigation keys as well as the up/down navigation keys. Use the <> navigation keys to move the cursor horizontally.




Use the up/down navigation keys to change the data value. The up key increases the data value, and the down key decreases the data value. Place the cursor on the value you want to save and press [OK].



□ **Infinitely Variable Change of Numeric Data Value**

If the chosen parameter represents a numeric data value, select a digit by means of the <> navigation keys.



Change the selected digit infinitely variably by means of the up/down navigation keys. The chosen digit is indicated by the cursor. Place the cursor on the digit you want to save and press [OK].



— How to Program —

□ Changing of Data Value, Step-by-Step

Certain parameters can be changed step-by-step or infinitely variably. This applies to *Motor Power* (par. 1-20), *Motor Voltage* (par. 1-22) and *Motor Frequency* (par. 1-23).

The parameters are changed both as a group of numeric data values and as numeric data values infinitely variably.

□ Read-out and Programming of Indexed Parameters

Parameters are indexed when placed in a rolling stack.

Par. 15-30 to 15-32 contain a fault log which can be read out. Choose a parameter, press [OK], and use the up/down navigation keys to scroll through the value log.

Use par. 3-10 as another example:

Choose the parameter, press [OK], and use the up/down navigation keys to scroll through the indexed values. To change the parameter value, select the indexed value and press [OK].

Change the value by using the up/down keys. Press [OK] to accept the new setting. Press [CANCEL] to abort. Press [Back] to leave the parameter.



— How to Program —

□ **How to Program on the Numerical Local Control Panel**

The following instructions are valid for the Numerical LCP (LCP 101).

The control panel is divided into four functional groups:

1. Numerical display.
2. Menu keys and LEDs - changing parameters and switching between display functions.
3. Navigation keys and LEDs.
4. Operation keys and LEDs.

Display line:

Status line: Status messages displaying icons and numeric value.

LEDs:

- Green LED/On: Indicates if control section is warning.
- Yellow LED/Wrn.: Indicates a warning.
- Flashing red LED/Alarm: Indicates an alarm.

LCP keys




[Menu] Select one of the following modes:

- Status
- Quick Setup
- Main Menu

Status Mode: Displays the status of the adjustable frequency drive or motor.

If an alarm occurs, the NLCP automatically switches to status mode.

A number of alarms can be displayed.



— How to Program —



Par. No.	Parameter Description	Unit
1-20	Motor Power	kW
1-22	Motor voltage	V
1-23	Motor Frequency	Hz
1-24	Motor Current	A
5-12	Terminal 27 Digital Input	[0] No function
3-02	Minimum Reference	rpm
3-03	Maximum Reference	rpm
3-41	Ramp 1 Ramp-up Time	sec
3-42	Ramp 1 Ramp-down Time	sec
3-13	Reference Site	
1-29	Automatic Motor Adaptation, AMA	[1] Enable complete AMA

Main Menu is used for programming all parameters. The parameter values can be changed using the up/down arrows when the value is flashing. Select Main Menu by pressing the [Menu] key a number of times.

Select the parameter group [xx-__] and press [OK]
 Select the parameter __-[xx] and press [OK]
 If the parameter is an array parameter, select the array number and press [OK]
 Select the desired data value and press [OK]


[Back] for stepping backwards

Arrow [^] [v] keys are used for maneuvering between commands and within parameters.



□ **Local Control Keys**

Keys for local control are found at the bottom of the control panel.




[Hand on] enables control of the adjustable frequency drive via the LCP. [Hand on] also starts the motor and it is now possible to enter the motor speed data by means of the arrow keys. The key can be selected as Enabled [1] or Disabled [0] via par. 0-40 [Hand on] Key on LCP.

External stop signals activated by means of control signals or a serial bus will override a "start" command via the LCP.

The following control signals will still be active when [Hand on] is activated:

- [Hand on] - [Off] - [Auto on]
- Reset
- Coasting stop inverse

— How to Program —

- 
- Reverse
 - Set-up select lsb - Set-up select msb
 - Stop command from serial communication
 - Quick stop
 - DC brake

[Off] stops the connected motor. The key can be selected as Enabled [1] or Disabled [0] via par. 0-41 *[Off] key on LCP*.

If no external stop function is selected and the [Off] key is inactive, the motor can be stopped by disconnecting the voltage.

[Auto on] enables the adjustable frequency drive to be controlled via the control terminals and/or serial communication. When a start signal is applied on the control terminals and/or the bus, the adjustable frequency drive will start. The key can be selected as Enabled [1] or Disabled [0] via par. 0-42 *[Auto on] Key on LCP*.

**NOTE**

An active HAND-OFF-AUTO signal via the digital inputs has higher priority than the control keys [Hand on] [Auto on].

[Reset] is used for resetting the adjustable frequency drive after an alarm (trip). It can be selected as Enabled [1] or Disabled [0] via par. 0-43 *Reset Key on LCP*.

— How to Program —

□ **Initialization to Default Settings**

Initialize the adjustable frequency drive to default settings in two ways:

Recommended initialization (via par. 14-22)

1. Select par. 14-22
2. Press [OK]
3. Select "Initialisation"
4. Press [OK]
5. Cut off the mains supply and wait until the display turns off.
6. Reconnect the mains supply - the adjustable frequency drive is now reset.

Par. 14-22 initializes everything except:	
14-50	<i>RFI 1</i>
8-30	<i>Protocol</i>
8-31	<i>Address</i>
8-32	<i>Baud Rate</i>
8-35	<i>Minimum Response Delay</i>
8-36	<i>Max Response Delay</i>
8-37	<i>Max Inter-char Delay</i>
15-00 to 15-05	<i>Operating data</i>
15-20 to 15-22	<i>Historic log</i>
15-30 to 15-32	<i>Fault log</i>

Manual initialization

1. Disconnect from mains and wait until the display turns off.
2. Press [Status] - [Main Menu] - [OK] at the same time:
3. Reconnect mains supply while pressing the keys.
4. Release the keys after 5 s.
5. The adjustable frequency drive is now programmed according to default settings.

This parameter initializes everything except:	
15-00	<i>Operating Hours</i>
15-03	<i>Power-ups</i>
15-04	<i>Over temps</i>
15-05	<i>Over volts</i>



NOTE

When you carry out manual initialization, you also reset serial communication and fault log settings.





□ Parameter Selection

Parameters for FC 300 are grouped into various parameter groups to easily select the correct parameters for optimized operation of the adjustable frequency drive.

0-xx Operation and display parameters

- Basic settings, set-up handling
- Display and Local Control Panel parameters for choosing readouts, setting up selections, and copying functions

1-xx Load and motor parameters, including all load- and motor-related parameters

2-xx Brake parameters

- DC brake
- Dynamic brake (resistor brake)
- Mechanical brake
- Over-voltage control

3-xx References and ramping parameters includes DigiPot function

4-xx Limits and warnings; setting of limits and warning parameters

5-xx Digital inputs and outputs, including relay controls

6-xx Analog inputs and outputs

7-xx Controls; setting parameters for speed and process control

8-xx Communication and option parameters for setting of FC RS-485 and FC USB port parameters.

9-xx Profibus parameters

10-xx DeviceNet and CAN Fieldbus parameters

13-xx Smart Logic Control parameters

14-xx Special function parameters

15-xx Drive information parameters

16-xx Readout parameters

17-xx Encoder option parameters

□ Parameters: Operation and Display

□ 0-0* Basic Settings

0-01 Language

Option:

*English UK (ENGLISH)	[0]
German (DEUTSCH)	[1]
French (FRANCAIS)	[2]
Danish (DANSK)	[3]
Spanish (ESPAÑOL)	[4]
Italian (ITALIANO)	[5]
Chinese (CHINESE)	[10]
Finnish (FINNISH)	[20]
English US (ENGLISH US)	[22]
Greek (GREEK)	[27]
Portuguese (PORTUGUESE)	[28]
Slovenian (SLOVENIAN)	[36]
Korean (KOREAN)	[39]
Japanese (JAPANESE)	[40]
Turkish (TURKISH)	[41]
Traditional Chinese	[42]
Bulgarian	[43]
Serbian	[44]
Romanian (ROMANIAN)	[45]
Hungarian (HUNGARIAN)	[46]
Czech	[47]
Polish (POLISH)	[48]
Russian	[49]
Thai	[50]
Bahasa Indonesian (BAHASA INDONESIA)	[51]

Function:

Defines the language to be used in display.

The adjustable frequency drive can be delivered with 4 various language packages. English and German are included in all packages. English cannot be erased or manipulated.

0-02 Motor Speed Unit

Option:

*RPM	[0]
Hz	[1]

Function:

Defines the parameters for motor speed (i.e. references, feedbacks, limits) displayed in terms of shaft speed (in RPM) or the output frequency

to the motor (Hz). This parameter cannot be adjusted while the motor is running.

0-03 Regional Settings

Option:

*International	[0]
US	[1]

Function:

Select *International* [0] to set the unit of par.1-20 *Motor Power* in kW and the default setting of par. 1-23 to 50 Hz. Select "[1] US" to set the unit of par. 1-21 *Motor Power* in HP and the default value of par. 1-23 to 60 Hz. Par. 0-03 cannot be adjusted while the motor is running.

0-04 Operating State at Power-up (Hand)

Option:

Resume	[0]
*Forced stop, use saved reference	[1]
Forced stop, reference = 0	[2]

Function:

Sets the operating mode when mains voltage is reconnected after power down in Hand (local) operation.

Select *Resume* [0] to start up the drive with the same local reference and the same start/stop conditions (applied by [START/STOP]) as before the drive was switched off.

Use *Forced stop, use saved reference* [1] to stop the drive until mains voltage reappears and until you press [START]. After the start command, set the local reference.

Select *Forced stop, set reference to 0* [2] to stop the drive until mains voltage reappears. Local reference is reset.

□ 0-1* Set-Up Handling

0-10 Active Set-up

Option:

Factory setup	[0]
*Set-up 1	[1]
Set-up 2	[2]
Set-up 3	[3]
Set-up 4	[4]
Multi set-up	[9]

* default setting () display text [] value for use in communication via serial communication port



— How to Program —



Function:

Defines the Set-up number to control the functions of the drive.

All parameters are programmed in four individual parameter Set-ups, Set-up 1 - Set-up 4. Open loop and closed-loop function can only be changed with a stop signal applied. The Default Set-up cannot be modified.

Default Set-up [0] contains the data set at Danfoss. Can be used as a data source if the other Set-ups are to be returned to a known state. Par. 0-50 and par. 0-06 allow copying from one Set-up to another or to all the other Set-ups. *Set-ups 1-4* are individual Set-ups, which can be selected individually. *Multi Set-up* [9] is used by remote-selection between Set-ups. Use digital inputs and the serial communication port for switching between Set-ups.

Apply a stop signal when switching between Set-ups where parameters marked as "not changeable during operation" have different values. To make sure that parameters marked as "not changeable during operation" are never set differently in two Set-ups, you should link the two Set-ups together via par. 0-12. Parameters that are "not changeable during operation" are marked FALSE in the parameter lists in the section *Parameter Lists*.

0-11 Edit Set-up

Option:

Factory setup	[0]
*Set-up 1	[1]
Set-up 2	[2]
Set-up 3	[3]
Set-up 4	[4]
Active Set-up	[9]

Function:

Selects *Editing Set-up*. Editing is done via the active Set-up or one of the inactive Set-ups. Selects the Set-up in which to program (change of data) during operation (applies both via the control panel and via the serial communication port). You can program the 4 Set-ups independently of the active Set-up (selected in par. 0-10). *Factory Set-up* [0] contains default data and can be used as a data source to return the other Set-ups to a known state. *Set-ups 1-4* are individual Set-ups and can be used as required. They can be programmed freely, regardless of the active Set-up.

0-12 This Set-up Linked to

Option:

*Setup 1	[1]
Setup 2	[2]
Setup 3	[3]
Setup 4	[4]

Function:


Apply a stop signal when switching between set-ups where parameters marked as "not changeable during operation" have different values. To make sure that parameters marked as "not changeable during operation" are never set differently in two set-ups, link the two set-ups together. The adjustable frequency drive will automatically synchronize the parameter values. Parameters that are not changeable during operation are marked FALSE in the section *Parameter Lists*.

The link set-up feature is used by Multi setup in par. 0-10. Multi setup is used to shift from one setup to another during operation (i.e. when the motor is running). Some parameters must have the same value during the transition - these are the parameters which are listed as "FALSE" under the column "Change during operation" in the parameters lists.

Par. 0-12 *This Set-up Linked to* ensures that the "Change during operation = FALSE" parameters are synchronized in the linked set-up. Select which parameter the link is selected to in par. 0-12. An example: Multi setup between Setup 1 and Setup 2; Usually the programming is finished in Setup 1 first and then need to make sure that Setup 1 and Setup 2 are synchronized (or "linked"). There are two ways: 1. Change the Edit Set-up to 2 in par. 0-11 and set par. 0-12 to *Setup 1*. This will start the linking (synchronizing) process.


* default setting () display text [] value for use in communication via serial communication port

— How to Program —



OR

2. While still in Setup 1; copy Setup 1 to Setup 2. Then set par. 0-12 to Setup 2. This will start the linking process.



After the linking process, par. 0-13 *Readout: Linked Set-ups* will read {1,2} to indicate that all "Change during operation = FALSE" parameters are now the same in Setup 1 and Setup 2. If a change of a "Change during operation = FALSE" parameter e.g. par. 1-30 *Stator Resistance (Rs)* in Setup 2 it will also be changed automatically in Setup 1. Switching between Setup 1 and Setup 2 during operation is now possible.

0-13 Readout: Linked Set-ups

Array [5]

Range:

0 - 255 N/A *0 N/A

Function:

A readout of all the set-ups linked together by means of par. 0-12. The parameter has one index for each parameter set-up. Each set-up shows the set-up bitset linked to that particular set-up.



Example where set-up 1 and 2 are linked:

Index	LCP value
0	{0}
1	{1,2}
2	{1,2}
3	{3}
4	{4}

0-14 Readout: Edit Set-ups / Channel

Range:

0 - FFF.FFF.FFF *AAA.AAA.AAA

Function:

This parameter shows the setting of parameter 0-11, as set by the different communication channels. When the number is read out in hex, as it is in the LCP, each number represents one channel. Numbers 1-4 represent a setup number, "F" means factory setting, and "A" means active setup. The channels are, from right to left, LCP, FC-bus, USB, HPFB1-5. Example: The number AAAAAA21h means that the FC bus selected set-up 2 in parameter 0-11, the LCP selected set-up 1, and all others uses the active set-up.

□ **0-2* LCP Display**

0-20 Display Line 1.1 Small

None	[0]
Profibus Warning Word	[953]
Readout Transmit Error Counter	[1005]
Readout Receive Error Counter	[1006]
Readout Bus Off Counter	[1007]
Warning Parameter	[1013]
Running Hours	[1501]
kWh Counter	[1502]
Control Word	[1600]
Reference [Unit]	[1601]
Reference %	[1602]
Status Word	[1603]

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

Main Actual Value [Unit]	[1604]	PCD 7 Write to MCO	[3407]
Main Actual Value [Unit]	[1605]	PCD 8 Write to MCO	[3408]
Custom Readout	[1609]	PCD 9 Write to MCO	[3409]
Power [kW]	[1610]	PCD 10 Write to MCO	[3410]
Power [hp]	[1611]	PCD 1 Read from MCO	[3421]
Motor voltage	[1612]	PCD 2 Read from MCO	[3422]
Frequency	[1613]	PCD 3 Read from MCO	[3423]
Motor Current	[1614]	PCD 4 Read from MCO	[3424]
Frequency [%]	[1615]	PCD 5 Read from MCO	[3425]
Torque	[1616]	PCD 6 Read from MCO	[3426]
* Speed [RPM]	[1617]	PCD 7 Read from MCO	[3427]
Motor Thermal	[1618]	PCD 8 Read from MCO	[3428]
KTY Sensor Temperature	[1619]	PCD 9 Read from MCO	[3429]
Motor Angle	[1620]	PCD 10 Read from MCO	[3430]
Phase Angle	[1621]	Digital Inputs	[3440]
DC Link Voltage	[1630]	Digital Outputs	[3441]
Brake Energy /s	[1632]	Actual Position	[3450]
Brake Energy /2 min	[1633]	Commanded Position	[3451]
Heatsink Temp.	[1634]	Actual Master Position	[3452]
Inverter Thermal	[1635]	Slave Index Position	[3453]
Inv. Nom. Current	[1636]	Master Index Position	[3454]
Inv. Max. Current	[1637]	Curve Position	[3455]
SL Controller State	[1638]	Track Error	[3456]
Control Card Temp.	[1639]	Synchronizing Error	[3457]
External Reference	[1650]	Actual Velocity	[3458]
Pulse Reference	[1651]	Actual Master Velocity	[3459]
Feedback [Unit]	[1652]	Synchronizing Status	[3460]
Digi Pot Reference	[1653]	Axis Status	[3461]
Digital Input	[1660]	Program Status	[3462]
Terminal 53 Switch Setting	[1661]	Idle Time	[9913]
Analog Input 53	[1662]	Paramdb Requests in Queue	[9914]
Terminal 54 Switch Setting	[1663]		
Analog Input 54	[1664]		
Analog Output 42 [mA]	[1665]		
Digital Output [bin]	[1666]		
Freq. Input #29 [Hz]	[1667]		
Freq. Input #33 [Hz]	[1668]		
Pulse Output #27 [Hz]	[1669]		
Pulse Output #29 [Hz]	[1670]		
Relay Output [bin]	[1671]		
Counter A	[1672]		
Counter B	[1673]		
Fieldbus CTW 1	[1680]		
Fieldbus REF 1	[1682]		
Comm. Option Status	[1684]		
FC Port CTW 1	[1685]		
FC Port REF 1	[1686]		
Alarm Word	[1690]		
Alarm Word 2	[1691]		
Warning Word	[1692]		
Warning Word 2	[1693]		
Ext. Status Word	[1694]		
Ext. Status Word 2	[1695]		
PCD 1 Write to MCO	[3401]		
PCD 2 Write to MCO	[3402]		
PCD 3 Write to MCO	[3403]		
PCD 4 Write to MCO	[3404]		
PCD 5 Write to MCO	[3405]		
PCD 6 Write to MCO	[3406]		

Function:

- None [0]** No display value chosen
- Control Word [1600]** Displays the present control word
- Reference [Unit] [1601]** displays the status value of terminals 53 or 54 using the unit stated on the basis of configuration in par. 1-00 (RPM or Nm).
- Reference % [1602]** displays the total reference (sum of digital/analog/preset/bus/freeze ref./catch up and slow-down).
- Status Word [binary] [1603]** Displays the present status word
- Alarm Word [1604]** indicates one or several alarms in a Hex code.
- Warning Word [1605]** indicates one or more warnings in a Hex code.
- Extended Status Word [1606]** [Hex] indicates one or more status states in a Hex code.
- Power [kW] [1610]** states the actual power consumed by the motor in kW.
- Power [hp] [1611]** states the actual power consumed by the motor in HP.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

Motor Voltage [V] [1612] states the voltage supplied to the motor.

Frequency [Hz] [1613] gives the motor frequency, i.e. the output frequency from the adjustable frequency drive.

Motor Current [A] [1614] states the phase current of the motor measured as effective value.

Torque [%] [1616] gives the current motor load in relation to the rated motor torque.

Speed [RPM] [1617] Displays the speed in RPM (revolutions per minute) i.e. the motor shaft speed in closed-loop.

Motor Thermal [1618] states the calculated/estimated thermal load on the motor.

DC Link Voltage [V] [1630] states the intermediate circuit voltage in the adjustable frequency drive.

Brake Energy /s [1632] states the present braking torque transferred to an external brake resistor. Stated as an instantaneous value.

Brake Energy /2 min [1633] states the braking torque transferred to an external brake resistor. The mean power is calculated continuously for the latest 120 seconds.

Heatsink Temp. [°C] [1634] states the present heatsink temperature of the adjustable frequency drive. The cut-out limit is $203 \pm 9^{\circ}\text{F}$ ($95 \pm 5^{\circ}\text{C}$); cutting back in occurs at $158 \pm 9^{\circ}\text{F}$ ($70 \pm 5^{\circ}\text{C}$).

Inverter Thermal [1635] returns the percentage load of the inverters.

Inv. Nom. Current [1636] The nominal current of the adjustable frequency drive.

Inv. Max. Current [1637] The maximum current of the adjustable frequency drive.

SL Controller State [1638] returns the state of the event executed by the control.

Control Card Temp. [1639] returns the temperature on the control card.

External Reference [1650] [%] gives the sum of the external reference as a percentage (the sum of analog/pulse/bus).

Pulse Reference [1651] [Hz] states the frequency in Hz connected to the programmed digital inputs (18, 19 or 32, 33).

Feedback [Unit] [1652] returns the reference value from programmed digital input(s).

Digital Input [1660] states the signal states from the 6 digital terminals (18, 19, 27, 29, 32 and 33). Input 18 corresponds to the bit at the far left. "0" = signal low; "1" = signal high.

Terminal 53 Switch Setting [1661] returns the setting of input terminal 53.

Current = 0; Voltage = 1.

Analog Input 53 [1662] returns the actual value on input 53 either as reference or protection value.

Terminal 54 Switch Setting [1663] returns the setting of input terminal 54.

Current = 0; Voltage = 1.

Analog Input 54 [1664] returns the actual value on input 54 either as reference or protection value.

Analog Output 42 [mA] [1665] returns the actual value in mA on output 42. Selection of shown value is set in par. 6-50.

Digital Output [bin] [1666] returns the bin value of all digital outputs.

Freq. Input #29 [Hz] [1667] returns the actual value of the frequency applied on terminal 29 as an impulse input.

Freq. Input #33 [Hz] [1668] returns the actual value of the frequency applied on terminal 33 as an impulse input.

Pulse output #27 [Hz] [1669] returns the actual value of impulses applied to terminal 27 in digital output mode.

Pulse output #29 [Hz] [1670] returns the actual value of impulses applied to terminal 29 in digital output mode.

Fieldbus CTW 1 [1680] Control word (CTW) received from the Bus-Master.

Fieldbus status word1 signal [1681] Status word (STW) sent to the Bus-Master.

Fieldbus REF 1 [1682] Main reference value sent with control word from the Bus-Master.

Fieldbus speed actual value A signal [1683] Main actual value sent with the Status word to the Bus Master.

Comm. Option Status [binary] [1684] Extended serial comm. bus option status word.

FC Port CTW 1 [1685] Control word (CTW) received from the Bus-Master.

FC Port REF 1 [1686] Status word (STW) sent to the Bus-Master.

0-21 Display Line 1.2 Small

Option:

*Motor Current [A] [1614]

Options are the same as in par. 0-20.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



0-22 Display Line 1.3 Small

*Power [kW] [1610]

0-23 Display Line 2 Large

* Frequency [Hz] [1613]

0-24 Display Line 3 Large

*Reference % [1602]

Option:

None	[0]
Control Word	[1600]
Reference [Unit]	[1601]
Reference %	[1602]
Status Word [binary]	[1603]
Alarm Word	[1604]
Warning Word	[1605]
Extended Status Word	[1606]
Power [kW]	[1610]
Power [hp]	[1611]
Motor Voltage [V]	[1612]
Frequency [Hz]	[1613]
Motor Current [A]	[1614]
Torque [%]	[1616]
Speed [RPM]	[1617]
Motor thermal	[1618]
DC Link Voltage [V]	[1630]
BrakeEnergy/s	[1632]
Heatsink Temperature [°C]	[1634]
Inverter thermal	[1635]
InomVLT	[1636]
ImaxVLT	[1637]
Condition controller state	[1638]
Data read-out: Control Card Temperature	[1639]
External Reference [%]	[1650]
Feedback [Unit]	[1652]
Digital Input	[1660]
Terminal 53 Switch Setting	[1661]
Analog Input 53	[1662]
Terminal 54 Switch Setting	[1663]
Analog Input 54	[1664]
Analog Output 42 [mA]	[1665]
Digital Output [bin]	[1666]
Frequency input #29 [Hz]	[1667]
Frequency input #33 [Hz]	[1668]
Pulse output #27 [Hz]	[1669]
Pulse output #29 [Hz]	[1670]
Pulse output #29 [Hz]	[1670]
Fieldbus control word1 signal	[1680]
Fieldbus status word1 signal	[1681]
Fieldbus speed setpoint A signal	[1682]

Fieldbus speed actual value A signal	[1683]
Communication Option Status Word	[1684]
[binary]	
FC port control word1 signal	[1685]
FC port speed setpoint A signal	[1686]

Function:

None [0] No display value chosen
Control Word [1600] Displays the present control word
Reference [Unit] [1601] displays the status value of terminals 53 or 54 using the unit stated on the basis of configuration in P.1-00 (RPM or Nm).
Reference % [1602] displays the total reference (sum of digital/analog/preset/bus/freeze ref./catch up and slow-down).
Status Word [binary] [1603] Displays the present status word
Alarm Word [1604] indicates one or several alarms in a Hex code.
Warning Word [1605] indicates one or more warnings in a Hex code.
Extended Status Word [1606] [Hex] indicates one or more status states in a Hex code.
Power [kW] [1610] states the actual power consumed by the motor in kW.
Power [hp] [1611] states the actual power consumed by the motor in HP.
Motor Voltage [V] [1612] states the voltage supplied to the motor.
Frequency [Hz] [1613] gives the motor frequency, i.e. the output frequency from the adjustable frequency drive.
Motor Current [A] [1614] states the phase current of the motor measured as effective value.
Torque [%] [1616] gives the current motor load in relation to the rated motor torque.
Speed [RPM] [1617] Display the speed in RPM (revolutions per minute) i.e. the crankshaft speed in closed loop.
Motor thermal [1618] states the calculated/es-
 timated thermal load on the motor.
DC Link Voltage [V] [1630] states the intermediate circuit voltage in the adjustable frequency drive.
BrakeEnergy/s [1632] states the present brake power transferred to an external brake resistor. Stated as an instantaneous value.
BrakeEnergy/2 min [1633] states the brake power transferred to an external brake resistor.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

The mean power is calculated continuously for the latest 120 seconds.

Heatsink Temperature [°C] [1634] states the present heat sink temperature of the adjustable frequency drive. The cut-out limit is 203 ± 9 °F (95 ± 5 °C); cutting back in occurs at 158 ± 9 °F (70 ± 5 °C).

Inverter thermal [1635] returns the percentage load of the inverters.

InomVLT [1636] The nominal current of the adjustable frequency drive.

ImaxVLT [1637] The maximum current of the adjustable frequency drive.

Condition controller state [1638] returns the state of the event executed by the controller.

Data read-out: Control Card Temperature [1639] returns the temperature on control card.

External Reference [1650] [%] gives the sum of the external reference as a percentage (the sum of analog/pulse/bus).

Pulse Reference [1651] [Hz] states the frequency in Hz connected to the programmed digital inputs (18, 19 or 32, 33).

Feedback [Unit] [1652] returns the reference value from programmed digital input(s).

Digital Input [1660] states the signal states from the 6 digital terminals (18, 19, 27, 29, 32 and 33) Input 18 corresponds to the bit at the far left. "0" = signal low; "1" = signal high.

Terminal 53 Switch Setting [1661] returns the setting of input terminal 53. Current = 0; Voltage = 1.

Analog Input 53 [1662] returns the actual value on input 53 either as reference or protection value.

Terminal 54 Switch Setting [1663] returns the setting of input terminal 54. Current = 0; Voltage = 1.

Analog Input 54 [1664] returns the actual value on input 54 either as reference or protection value.

Analog Output 42 [mA] [1665] returns the actual value in mA on output 42. Selection of shown value is set in par. 06-50.

Digital Output [bin] [1666] returns the bin value of all digital outputs.

Frequency input #29 [Hz] [1667] returns the actual value of the frequency applied on terminal 29 as an impulse input.

Frequency input #33 [Hz] [1668] returns the actual value of the frequency applied on terminal 33 as an impulse input.

Pulse output #27 [Hz] [1669] returns the actual value of impulses applied to terminal 27 in digital output mode.

Pulse output #29 [Hz] [1670] returns the actual value of impulses applied to terminal 29 in digital output mode.

Fieldbus control word1 signal [1680] Control word (CTW) received from the Bus Master.

Fieldbus status word1 signal [1681] Status word (STW) sent to the Bus Master.

Fieldbus speed setpoint A signal [1682] Main reference value sent with control word from the Bus Master.

Fieldbus speed actual value A signal [1683] Main actual value send with the Status word to the Bus Master.

Communication Option Status Word [binary] [1684] Extended fieldbus comm. option status word.

FC port control word1 signal [1685] Control word (CTW) received from the Bus Master.

FC port speed setpoint A signal [1686] Status word (STW) sent to the Bus Master.



0-25 My Personal Menu

Array [20]

Range:

0 - 9999

Function:

Defines the parameters to include in the Q1 Personal Menu accessible via [Quick Menu] on the LCP. Add up to 20 parameters in the Q1 Personal Menu. The parameters are listed in the Q1 Personal Menu in the order programmed in this array parameter. Delete parameters by setting the value to "0000".

□ **0-4* LCP Keypad**

0-40 [Hand on] Key on LCP

Option:

Disabled	[0]
*Enabled	[1]
Password	[2]

Function:

Select *Disabled* [0] to avoid accidental start of the drive in Hand mode. Select *Password* [2] to avoid unauthorized start in Hand mode. Set

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



the password in par. 0-62 or par. 0-64 if par. 0-40 is included in the Quick menu.

0-41 [Off] Key on LCP

Option:	
Disabled	[0]
*Enabled	[1]
Password	[2]

Function:

Press [Off] and select *Disabled* [0] to avoid accidental drive stop. Press [Off] and select *Password* [2] to avoid unauthorized stop. Set the password in par. 0-62 or par. 0-64 if par. 0-40 is included in the Quick menu.

0-42 [Auto on] Key on LCP

Option:	
Disabled	[0]
*Enabled	[1]
Password	[2]

Function:

Press [Auto on] and select *Disabled* [0] to avoid accidental drive start in Auto mode. Press [Auto on] and select *Password* [2] to avoid unauthorized start in Auto mode. Set the password in par. 0-62 or par. 0-64 if par. 0-40 is included in the Quick menu.

0-43 [Reset] Key on LCP

Option:	
Disabled	[0]
*Enabled	[1]
Password	[2]

Function:

Press [Reset] and select *Disabled* [0] to avoid accidental alarm reset. Press [Reset] and select *Password* [2] to avoid unauthorized resetting. Set the password in par. 0-62 or par. 0-64 if par. 0-40 is included in the Quick menu.

□ **0-5* Copy / Save**

0-50 LCP Copy

Option:	
*No copy	[0]
Transfer to LCP all parameters	[1]
Transfer from LCP all parameters	[2]
Transfer from LCP size indep. parameters	[3]

Function:

Select Transfer to LCP all parameters [1] to copy all parameters in all set-ups from the drive memory to the LCP memory. Select Transfer from LCP all parameters [2] to copy all parameters in all set-ups from the LCP memory to the drive memory. Select Transfer from LCP size indep. parameters [3] to copy only the parameters that are independent of the motor size. The latter selection can be used to program several drives with the same function without disturbing motor data which are already set.

0-51 Set-up Copy

Option:	
*No copy	[0]
Copy to set-up 1	[1]
Copy to set-up 2	[2]
Copy to set-up 3	[3]
Copy to set-up 4	[4]
Copy to all	[9]

Function:

Select Copy to set-up 1 [1] to copy all parameters in the currently edited set-up (set in par. 0-11) to set-up 1. Make the same choice in the other parameters. Select Copy to all [9] to make all parameters in all set-ups to the parameters in the currently edited set-up.

□ **0-6* Password**

0-60 Main Menu Password

Range:	
0 - 9999	*100

Function:

Defines the password used for accessing the Main Menu. If par. 0-62 is set to *Full access* [0], this parameter is ignored.

0-61 Access to Main Menu w/o Password

Option:	
*Full access	[0]
Read only	[1]
No access	[2]

Function:

Select *Full access* [0] to disable the password in par. 0-60. Select *Read only* [1] to block unauthorized editing of Main Menu parameters.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

Select *No access* [2] to block unauthorized viewing and editing of Main Menu parameters.

0-65 Quick Menu Password

Range:

0 - 9999 * 200

Function:

Defines the password be used to access the Quick Menu. If par. 0-66 is set to *Full access* [0], this parameter is ignored.

0-66 Access to Quick Menu w/o Password

Option:

* Full access	[0]
Read only	[1]
No access	[2]

Function:

Select *Full access* [0] to disable the password in par. 0-64. Select *Read only* [1] to block unauthorized editing of Quick Menu parameters. Select *No access* [2] to block unauthorized viewing and editing of Quick Menu parameters.



* default setting () display text [] value for use in communication via serial communication port



□ **Parameters: Load and Motor**

□ **1-0* General Settings**

1-00 Configuration Mode

Option:

*Speed open loop	[0]
Speed closed-loop	[1]
Torque	[2]

Function:

Speed control, open loop: Enables speed control (without feedback signal from motor) with automatic slip compensation for almost constant speed at varying loads. Compensations are active, but can be disabled in the *Load / Motor* parameter group.
Speed control, closed loop: Enables encoder feedback from motor. Obtain full holding torque at 0 RPM.
Increased speed accuracy: Provide a feedback signal and set the speed PID controller.
Torque control, speed feedback: Connect the encoder speed feedback signal to the encoder input. Only possible with "Flux with encoder feedback", par. 1-01.

1-01 Motor Control Principle

Option:

U/f	[0]
VVC ^{plus}	[1]
Flux sensorless	[2]
Flux w/ motor feedback	[3]

Function:

Determines which motor control principle to employ. [0] U/f is special motor mode. Used for special motor applications as parallel connected motors. Generally, the best shaft performance is obtained in the two Flux Vector control modes Flux w/ encoder feedback [3] and Flux sensorless [2]. Most applications, however, are easily handled using a Voltage Vector control mode VVC^{plus} [1]. The main benefit of VVC^{plus} operation is a simpler motor model. Par. 1-01 cannot be adjusted while the motor is running.

1-02 Flux Motor Feedback Source

Option:

*24 V encoder	[1]
MCB 102	[2]

Function:

24 V encoder [1] is an A and B channel encoder. The encoder can be connected to the digital inputs terminals 32/33 only. MCB 102 [2] is selection of encoder module. Par. 1-02 cannot be adjusted while the motor is running.

1-03 Torque Characteristics

Option:

*Constant torque	[0]
Variable torque	[1]
Auto Energy Optim.	[2]

Function:

Select the demanded torque characteristic. AEO and VT are different kinds of energy-saving operation.

Constant torque [0]: The motor shaft output will provide constant torque by variable speed control.
 Variable Torque [1]: The motor shaft output will provide a variable torque by variable speed control. Set variable torque level in par. 14-40.
 Automatic Energy Optimizing function [2]: Automatically adjusts the optimized energy consumption by setting par. 14-41 and par. 14-42

1-05 Local Mode Configuration

Option:

Speed open-loop	[0]
Speed closed-loop	[1]
*As conf. mode P. 1-00	[2]

Function:

Select which application configuration mode (par. 1-00) to use when a Local (LCP) Reference is active. A Local Reference can only be active if par. 3-13 is [0] or [2]. By default the Local Reference is only active in Hand Mode.

□ **1-1***

1-10 Motor Construction

Option:

*Asynchron	[0]
PM, non salient SPM	[1]

Function:

Motor construction can either be asynchronous or permanent magnet (PM) motor.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ **1-2* Motor Data**

1-20 Motor Power [kW]

Range:

0.50 - 10 HP (0.37-7.5 kW) [Motor type dependent]

Function:

The value should equal the nameplate data on the connected motor. The default value corresponds to the nominal rated output of the unit.



NOTE

Changing the value in this parameter affects the setting of other parameters. Par. 1-20 cannot be changed while

the motor is running.

1-21 Motor Power [HP]

Range:

0.5-10 HP [M-TYPE]

Function:

The value should equal the nameplate data on the connected motor. The default setting corresponds to the nominal rated output of the unit.

1-22 Motor Voltage

Range:

200-500 V [Motor type dependent]

Function:

The value should equal the nameplate data on the connected motor. The default value corresponds to the nominal rated output of the unit.



NOTE

Changing the value in this parameter affects the setting of other parameters. Par. 1-22 cannot be changed while

the motor is running.

1-23 Motor Frequency

Option:

*50 Hz (50 HZ) [50]
 60 Hz (60 HZ) [60]
 Min - Max motor frequency: 20 - 300 Hz

Function:

Select the stated value from the motor name plate. Alternatively, set the value for motor frequency to be infinitely variable. If a value different from 50 Hz or 60 Hz is selected, it is necessary to correct par. 1-50 to 1-54. For 87 Hz operation with 230/400 V motors, set the name plate data for 230 V/50 Hz. Adapt par. 2-02 *Output speed high limit* and par. 2-05 *Maximum reference* to the 87 Hz application.



NOTE

Changing the value in this parameter affects the setting of other parameters. Par. 1-23 cannot be changed while the motor is running.



NOTE

If a delta connection is used, select the rated motor frequency for the delta connection.

1-24 Motor Current

Range:

Motor type dependent.

Function:

The value should equal the nameplate data on the connected motor. Data is used for calculating torque, motor protection, etc.



NOTE

Changing the value in this parameter affects the setting of other parameters. Par. 1-24 cannot be changed while the motor is running.

1-25 Motor Nominal Speed

Range:

100. - 60000. RPM *ExpressionLimitRPM

Function:

The value should equal the name plate data on the connected motor. The data is used for calculating motor compensations.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

1-26 Motor Cont. Rated Torque

Range:

1.0 - 10000.0 Nm *5.0 Nm

Function:

Parameter open when par. 1-10 = [1]
PM, non salient SPM.

The value should equal the nameplate data on the connected motor. The default value corresponds to the nominal rated output of the unit. Par. 1-26 cannot be adjusted while the motor is running.

1-29 Automatic Motor Adaptation (AMA)

Option:

- *OFF [0]
- Enable complete AMA [1]
- Enable reduced AMA [2]

Function:

If the AMA function is used, the adjustable frequency drive automatically sets the necessary motor parameters (par. 1-30 to par. 1-35) with the motor stationary. AMA ensures optimum use of the motor. For the best adaptation of the adjustable frequency drive, run AMA on a cold motor. Select *Enable complete AMA*, if the adjustable frequency drive is to carry out AMA of the stator resistance R_s , the rotor resistance R_r , the stator leakage reactance x_1 , the rotor leakage reactance X_2 and the main reactance X_h .

Select *Reduced AMA* if a reduced test is to be carried out, in which only the stator resistance R_s in the system is determined.

AMA cannot be carried out while the motor is running.

AMA cannot be carried out on permanent magnet motors.

Activate the AMA function by pressing [Hand on] after selecting [1] or [2]. See also section *Automatic Motor Adaptation*. After a normal sequence, the display will read, "Press [OK] to finish AMA." After pressing the [OK] key, the adjustable frequency drive is now ready for operation.



NOTE

It is important to set motor par. 1-2* correctly, since these form part of the AMA algorithm. For optimum dynamic motor performance, an AMA must be carried out. It may take up to 10 min, depending on the power rating of the motor.



NOTE

Avoid externally generating torque during AMA.




NOTE

If one of the settings in par. 1-2* is changed, par. 1-30 to 1-39 will return to default setting.

□ **1-3* Advanced Motor Data**

The motor data in par. 1-30 - par. 1-39 must be matching the specific motor, in order for the motor to run properly. Default settings are figures based on common motor parameter values from normal standard motors. If the motor parameters are not set correctly, it may cause a malfunction of the drive system.

If the motor data is not known it is recommended to perform an AMA (Automatic Motor Adaptation). See section *Automatic Motor Adaptation*. The AMA sequence will adjust all motor parameters except the moment of inertia of the rotor.



Motor equivalent diagram for an asynchronous motor

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

**1-30 Stator Resistance (Rs)****Option:**

Ohm Depending on motor data.

Function:

Sets the stator resistance value for the motor control. Do not attempt to change par. 1-30 while the motor is running.

1-31 Rotor Resistance (Rr)**Option:**

Ohm Depending on motor data.

Function:

A manually entered Rotor resistance, R_r must apply to a cold motor. Improve shaft performance by fine-tuning R_r . Do not attempt to change par. 1-31 while the motor is running.

R_2' can be set as follows:

1. AMA: The adjustable frequency drive measures the value on the motor. All compensations are reset to 100%.
2. The motor supplier states the value.
3. The default settings of R_2' are used. The adjustable frequency drive selects the setting on the basis of the motor nameplate data.

1-33 Stator Leakage Reactance (X1)**Option:**

Ohm Depending on motor data.

Function:

Sets the stator leakage reactance of the motor. Do not attempt to change par. 1-33 while the motor is running.

X_1 can be set as follows:

1. AMA: The adjustable frequency drive measures the value on the motor.
2. The motor supplier states the value.
3. The default setting of X_1 is used. The adjustable frequency drive selects the setting on the basis of the motor nameplate data.

1-34 Rotor Leakage Reactance (X2)**Option:**

Ohm Depending on motor data.

Function:

Sets the rotor leakage reactance of the motor. Do not attempt to change par. 1-34 while the motor is running.

X_2 can be set as follows:

1. AMA: The adjustable frequency drive determines the value on the motor to determine.
2. The motor supplier states the value.
3. The default setting of X_2 is used. The adjustable frequency drive selects the setting on the basis of the motor nameplate data.

1-35 Main Reactance (Xh)**Option:**

Ohm Depending on motor data.

Function:

Sets the main reactance of the motor. Do not attempt to change par. 1-34 while the motor is running.

X_h can be set as follows:

1. AMA: The adjustable frequency drive measures the value on the motor.
2. The motor supplier states the value.
3. The default setting of X_h is used. The adjustable frequency drive selects the setting on the basis of the motor nameplate data.

1-36 Iron Loss Resistance (Rfe)**Range:**

1 - 10.000 Ω *10.000Ω

Function:

Sets the equivalent of the R_{Fe} to compensate for iron losses in the motor. Do not attempt to change par. 1-35 while the motor is running. The function is switched off if 10.000 Ω is chosen. The iron loss parameter is especially important in torque control applications. If R_{Fe} is unknown, leave par. 1-36 on default setting.

— How to Program —



1-37 d-axis Inductance (Ld)

Range:

0.0 - 1000.0 mH *0.0 mH

Function:

Set the value of the d-axis inductance. This parameter is only active when par. 1-10 has the value [1] PM motor (Permanent Magnet Motor). See the permanent magnet motor data sheet.

1-39 Motor Poles

Option:

Depends on motor type
Value 2 - 100 poles *4-polemotor

Function:

Sets the motor pole number.

Poles	~n _n @ 50 Hz	~n _n @60 Hz
2	2700 - 2880	3250 - 3460
4	1350 - 1450	1625 - 1730
6	700 - 960	840 - 1153

The table shows the normal speed range for various motor types. Define motors designed for other frequencies separately. The stated value must be, even as the figure refers to the motor's number of poles (not a pair of poles). The drive carries out the initial setting of par. 1-39 based on par. 1-23 and par. 1-25.

1-40 Back EMF at 1000 RPM

Range:

10 - 1000 V *500 V

Function:

Set the nominal back EMF for the motor running at 1000 RPM.

This parameter is only active when par. 1-10 has the value [1] PM motor (Permanent Magnet Motor).

1-41 Motor Angle Offset

Range:

0 - 65535 N/A *0 N/A

Function:

Enter the correct offset angle between the PM motor and the index position (single-turn) of the attached encoder / resolver. The value range of 0 - 65535 corresponds to 0 - 2 * pi (radians). Hint: After

drive start-up, apply DC-hold and enter the value of par. 16-20 Motor Angle in this parameter.

This parameter is only active when par. 1-10 has the value [1] PM motor (Permanent Magnet Motor).

□ **1-5* Load Indep. Setting**


1-50 Motor Magnetization at Zero Speed

Range:

0 - 300 % *100%

Function:

Is used along with par. 1-51 to obtain a different thermal load on the motor when running at low speed. Enter a value which is a percentage of the rated magnetizing current. A setting too low may cause a reduced torque on the crankshaft.



1-51 Min Speed Normal Magnetizing [RPM]

Range:

0 - 10 RPM *1RPM

Function:

Is used along with par. 1-50. See drawing in par. 1-50. Set the required frequency (for normal magnetizing current). If the frequency is set lower than the motor slip frequency, par. 1-50 and par. 1-51 are of no significance.

1-52 Min Speed Normal Magnetizing [Hz]

Range:

0 - 10 Hz *0 Hz

Function:

Is used along with par. 1-50. See drawing in par. 1-50. Set the required frequency (for normal magnetising current). If the frequency is set lower than the motor slip frequency, par. 1-50 and par. 1-51 are inactive.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —




1-53 Model Shift Frequency

Range:
4.0 - 50.0 Hz *6.7 Hz

Function:
Flux Model shift


With this parameter it is possible to make an adjustment of the shifting point where FC 302 changes the FLUX model. Useful in some sensitive speed and torque control applications.



Speed closed-loop or Torque par. 1-00 = [1] or [2] and Flux w/motor feedback par. 1-01 = [3]

Function Variable current - Flux mode -Sensorless

Par. 1-00 *Speed open loop mode* [0] and par. 1-01 *Flux sensorless* [2]: In speed open loop in flux mode, the speed must be determined from the current measurement. Below $n_{norm} \times 0.1$, the drive is working from a variable current model. Above $n_{norm} \times 0.125$, the drive is working from the FLUX model in the adjustable frequency drive.



Speed open loop par. 1-00 = [0] Flux sensorless par. 1-01 = [2]

Par. 1-53 cannot be adjusted while the motor is running.

1-55 U/f Characteristic - U


Range:
0.0 - max. motor voltage *Expression limit V

Function:
This parameter is an array parameter [0-5] and is only accessible when par. 1-01 is set to U/f [0]. Set the voltage at each frequency point to manually form a U/f-characteristic matching the motor. The frequency points are defined in par 1-56.

1-56 U/f Characteristic - F

Range:
0.0 - max. motor frequency *Expression limit Hz

Function:
This parameter is an array parameter [0-5] and is only accessible when par. 1-01 is set to U/f [0]. Set the frequency points to manually form a U/f-characteristic matching the motor. The voltage at each point is defined in par. 1-55.



1-6* Load Depend. Setting

1-60 Low Speed Load Compensation

Range:
-300 - 300% *100%


Function:
Enables compensation of voltage in relation to load when the motor is running at low speed. Optimum U/f characteristic is obtained. The

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

frequency range within which this parameter is active, depends on the motor size.

Motor size: 0.34 - 10 HP (0.25 kW - 7.5 kW) Change over: < 10 Hz



1-61 High Speed Load Compensation

Range:
-300 - 300% *100%

Function:
Enables compensation of voltage in relation to load when the motor is running at high speed. Optimum U/f characteristic is obtained. The frequency range within which this parameter is active, depends on the motor size.

Motor size	Changeover
0.34 - 10 HP (0.25 kW - 7.5 kW)	> 10 Hz

1-62 Slip Compensation

Range:
-500 - 500 % *100%

Function:
Slip compensation is calculated automatically, i.e. on the basis of the rated motor speed $n_{M,N}$. In par. 1-62, slip compensation is adjusted in detail, which compensates for tolerances in the value of $n_{M,N}$. This function is not active along with *Torque Characteristics* (par. 1-03), *Speed closed loop*, *Torque control*, *Speed feedback*, and *Special motor characteristics*.

Enter a %-value of the rated motor frequency (par. 1-23).

1-63 Slip Compensation Time Constant

Range:
0.05 - 5.00 s *0.10s

Function:
Determines the slip compensation reaction speed. A high value results in slow reaction. On the other hand, a low value results in quick reaction. If you encounter low-frequency resonance problems, the set time must be longer.

1-64 Resonance Dampening

Range:
0 - 500 % *100%

Function:
Setting par. 1-64 and par. 1-65 can eliminate high-frequency resonance problems. For less resonance oscillation, the value of par. 1-64 must be increased.

1-65 Resonance Dampening Time Constant

Range:
5 - 50 msec. *5 msec.

Function:
Setting par. 1-64 and par. 1-65 can eliminate high-frequency resonance problems. Choose the time constant that provides the best dampening.

1-66 Min. Current at Low Speed

Range:
0 - Variable Limit % *100%

Function:
Is enabled when par. 1-00 = *SPEED OPEN LOOP* only. The drive runs with constant current through motor below 10 Hz. When speed is above 10 Hz, the motor flux model in the drive controls the motor. Par. 4-16 and / or par. 4-17 automatically adjusts par. 1-66. The parameter with the highest value adjusts par. 1-66. The current setting in par. 1-66 is composed of the torque generating current and the magnetizing current.

Example: Par. 4-16 *Torque Limit for Motor Mode* is set to 100% and par. 4-17 *Torque Limit for Generating Mode* is set to 60%.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

Par. 1-66 automatically sets to about 127%, depending on the motor size.

1-67 Load Type

Option:

- *Passive load [0]
- Active load [1]

Function:

Select *passive load* [0] for conveyers, fan and pump applications. Select *active load* [1] for hoisting applications. When *active load* [1] is selected, set min. current at low speed (par. 1-66) to a level which corresponds to maximum torque.

1-68 Minimum Inertia

Range:

0 - Variable Limit *Depending on motor data

Function:

Set the minimum moment of inertia of the mechanical system.

Par. 1-68 and par. 1-69 are used for pre-adjustment of the Proportional Gain in the speed control (par. 7-02).

1-69 Maximum Inertia

Range:

0 - Variable Limit *Depending on motor data

Function:

Set the maximum moment of inertia of the mechanical system.

□ **1-7* Start Adjustments**

1-71 Start Delay

Range:

0.0 - 10.0 s *0.0s

Function:

Enables a delay of the starting time. The adjustable frequency drive begins with the start function selected in par. 1-72. Set the start delay time until acceleration is to begin.

1-72 Start Function

Option:

- DC hold/delay time [0]
- DC Brake/delay time [1]
- *Coast/delay time [2]

- Start speed/ current clockwise operation [3]
- Horizontal operation [4]
- VVC^{plus}/Flux clockwise [5]

Function:

Selects the start function during start delay (par. 1-71).
 Select *DC hold/delay time* [0] to energize the motor with a DC holding current (par. 2-00) in the start delay time.
 Select *DC brake/delay time* [1] to energize the motor with a DC braking current (par. 2-01) during start delay time.
 Select *Coast/delay time* [2] to release the shaft-coasted drive during the start delay time (inverter off).
 Select *Start speed/current clockwise* [3] to connect the function described in par. 1-74 and par. 1-76 in the start delay time. Regardless of the value applied by the reference signal, the output speed applies the setting of the start speed in par. 1-74 and the output current corresponds to the setting of the start current in par. 1-76. This function is typically used in hoisting applications without counterweight and especially in applications with a one-armature motor, where the start is clockwise, followed by rotation in the reference direction.
 Select *Horizontal operation* [4] to obtain the function described in par. 1-74 and par. 1-76 during the start delay time. The motor rotates in the reference direction. If the reference signal equals zero (0), par. 1-74 *Start speed* is ignored and the output speed equals zero (0). The output current corresponds to the setting of the start current in par. 1-76 *Start current*.
 Select *VVC^{plus}/Flux clockwise* [5] for the function described in par. 1-74 only (*Start speed in the start delay time*). The start current is automatically calculated.
 This function only uses the start speed in the start delay time. Regardless of the value set by the reference signal, the output speed equals the setting of the start speed in par. 1-74. *Start speed/current clockwise* [3] and *VVC^{plus}/Flux clockwise* [5] are typically used in hoisting applications. *Start speed/current in reference direction* [4] is particularly used in applications with counterweight and horizontal movement.



* default setting () display text [] value for use in communication via serial communication port

— How to Program —



1-73 Flying Start [RPM]

Option:

- *Off (DISABLED) [0]
- On (ENABLED) [1]

Function:

This function makes it possible to "catch" a spinning motor which is spinning freely because of a line drop-out.

Select *Disabled* if this function is not required. Select *Enabled* if the adjustable frequency drive is to be able to "catch" and control a spinning motor. When par. 1-73 is enabled, par. 1-71 and 1-72 have no function. Flying start is active in VVC+ mode only.



NOTE

It is recommended not to use this function in hoisting applications.

1-74 Start Speed [RPM]

Range:

0 - 600 RPM *0RPM

Function:

Sets the desired motor start speed. The motor output speed "leaps" to the set value. This parameter can be used e.g. for hoist applications (cone armature motors). Set the start function in par. 1-72 to [3], [4] or [5], and set a start delay time in par. 1-71. A reference signal must be present.

1-75 Start Speed [Hz]

Range:

0 - 500 Hz *0 Hz

Function:

Sets a start speed. After the start signal, the output speed adjusts to the set value. This parameter can be used e.g. for hoist applications (cone rotor motors). Set the start function in par. 1-72 to [3], [4] or [5], and set a start delay time in par. 1-71. A reference signal must be present.

1-76 Start Current

Range:

0.00 - par. 16-36 A *0.00A

Function:

Some motors, such as cone rotor motors, need extra current/starting speed (boost) to disengage the mechanical brake. For this purpose use par. 1-74 and par. 1-76. Set the required value to disengage the mechanical brake. Set the start function in par. 1-72 to [3] or [4], and set a start delay time in par. 1-71. A reference signal must be present.

□ **1-8* Stop Adjustments**

1-80 Function at Stop

Option:

- *Coast [0]
- DC hold [1]
- Motor check [2]
- Pre-magnetizing [3]

Function:

Selects the drive function after a stop command or after the speed is ramped down to the settings in par. 1-81.

Select *Coasting* [0] to leave the motor in free mode. Activate *DC hold* [1] DC holding current (par. 2-00). Select *Motor check* [2] to check if a motor has been connected.

Select *Pre-magnetizing* [3] to build up a magnetic field while the motor is stopped. The motor can now produce a quick torque build-up at start.

1-81 Min Speed for Function at Stop [RPM]

Range:

0 - 300 RPM *0RPM

Function:

Sets the speed at which to activate *Function at stop* (par. 1-80).

1-82 Min Speed for Function at Stop [Hz]

Range:

0.0 - 500 Hz *0.0 Hz

Function:

Set the frequency at which the function to activate function at stop is selected in par. 1-80.

□ **1-9* Motor Temperature**

1-90 Motor Thermal Protection

Option:

- *No protection [0]

* default setting () display text [] value for use in communication via serial communication port

— How to Program —




- Thermistor warning [1]
- Thermistor trip [2]
- ETR warning 1 [3]
- ETR trip 1 [4]
- ETR warning 2 [5]
- ETR trip 2 [6]
- ETR warning 3 [7]
- ETR trip 3 [8]
- ETR warning 4 [9]
- ETR trip 4 [10]

Function:


The adjustable frequency drive determines the motor temperature for motor protection in two different ways:

- Via a thermistor sensor connected to one of the analog inputs, terminals 53 or 54 (par. 1-93).
- Via calculation of the thermal load, based on the actual load and time. The calculation is compared with the rated motor current $I_{M,N}$ and the rated motor frequency $f_{M,N}$. The calculations estimate the need for a lower load at lower speed due to less cooling from the incorporated fan.

If the motor is overloaded, select *No protection* if no warning or tripping is required. Select *Thermistor warning* to receive a warning when the connected thermistor in the motor switches off. Select *Thermistor trip* if you want the adjustable frequency drive to cut out (trip) when the connected thermistor in the motor switches off. Select thermistor (PTC sensor) if you want a thermistor integrated in the motor (for winding protection) to stop the adjustable frequency drive in case of motor overheating. The cut-out value is > 3 k.



Select *ETR Warning 1-4* to receive a warning on the display when the motor is overloaded. Select *ETR Trip 1-4* to have the adjustable frequency drive trip when the motor is overloaded. It is possible to program a warning signal via one of the digital outputs. The signal appears in case of a warning and if the adjustable frequency drive trips (thermal warning). ETR (Electronic Terminal Relay) functions 1-4 will not calculate the load until the unit is switched to the set-up where they were selected. For the North American market: The ETR functions provide Class 20 motor overload protection in accordance with NEC.




1-91 Motor External Fan

Option:

- *No [0]
- Yes [1]

Function:

Select whether to apply an external motor fan (external ventilation), indicating unnecessary derating at low speed. If you select Yes [1], the graph below is followed if the motor speed is lower. If the motor speed is higher, the time still derates as if no fan is installed.



* default setting () display text [] value for use in communication via serial communication port

— How to Program —

You cannot change par. 1-91 while the motor is running.

1-93 Thermistor Source
Option:

*None	[0]
Analog input 53	[1]
Analog input 54	[2]

Function:

Selects the analog input used for connecting the Thermistor (PTC sensor). Do not attempt to change par. 1-93 while the motor is running. An analog input cannot be selected if the analog input is already in use as a reference resource (selected in par. 3-15, 3-16 or 3-17).

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ **Parameters: Brakes**

□ **2-0* DC Brake**

2-00 DC Hold Current

Range:
0 - 100% *50 %

Function:
Holds the motor function (holding torque) or preheats the motor. You cannot use this parameter if *DC hold* [1] is selected in par. 1-72 or par. 1-80. Set the *Holding current* as a percentage value in relation to the rated motor current $I_{M,N}$ (par. 1-24). 100% DC holding current corresponds to $I_{M,N}$.

$$(OFF) - \frac{I_{FC302.norm}}{I_{motor.norm}} * 100\%$$

NOTE
The maximum value depends on the rated motor current.

Avoid 100 % current for too long. It may damage the motor.

2-01 DC Brake Current

Range:
0 - 160 % *50%

Function:
Applies DC brake current on a stop command. Activate the function by reaching the set speed in par. 2-03, by activating the DC Brake Inverse function on one of digital inputs, or via the serial communication port. The braking current is active during the time period set in par. 2-02. Set the current as a percentage value of the rated motor current $I_{M,N}$ (par. 1-24). 100% DC braking current corresponds to $I_{M,N}$.

$$(OFF) - \frac{I_{FC302.norm}}{I_{motor.norm}} * 100\%$$

NOTE
The maximum value depends on the rated motor current.

Avoid 100 % current for too long. It can damage the motor.

2-02 DC Braking Time

Range:
0.0 - 60.0 s. *10.0s.

Function:
Sets the active DC braking time for the DC braking current (par. 2-01).

2-03 DC Brake Cut-In Speed

Range:
0 - par. 4-13 RPM *ORPM

Function:
Sets the active brake cut-in speed for the DC braking current (par. 2-01) in connection with a stop command.

□ **2-1* Brake Energy Funct.**

2-10 Brake Function

Option:
*Off [0]
Resistor brake [1]

Function:
The default setting is *Off* [0]. Use *Resistor brake* [1] to program the adjustable frequency drive for connecting a brake resistor. Connecting a brake resistor allows a higher DC link voltage during braking (generating operation). The *Resistor brake* [1] function is only active in adjustable frequency drives with an integral dynamic brake.

Select *Resistor brake* [1] if a brake resistor is part of the system.

2-11 Brake Resistor (ohm)

Option:
Ohm Dependson unit size.

Function:
This parameter is only active in adjustable frequency drives with an integral dynamic brake.
Set the brake resistor value in ohm. This value is used for monitoring the power to the brake resistor. Select this function in par. 2-13.



* default setting () display text [] value for use in communication via serial communication port

— How to Program —



2-12 Brake Power Limit(kW)

Range:

0.001 - Variable Limit kW *kW

Function:

This parameter is only active in adjustable frequency drives with an integral dynamic brake.

The monitoring limit is a product of the maximum duty cycle (120 sec.) and the maximum power of the brake resistor at that duty cycle. See the formula below.

For 200 - 240 V units: $P_{resistor} = \frac{397^2 * dutytime}{R * 120}$

For 380 - 500 V units $P_{resistor} = \frac{822^2 * dutytime}{R * 120}$

For 575 - 600 V units $P_{resistor} = \frac{985^2 * dutytime}{R * 120}$

2-13 Brake Power Monitoring

Option:

*Off	[0]
Warning	[1]
Trip	[2]
Warning and Trip	[3]

Function:

This parameter is only active in adjustable frequency drives with an integral dynamic brake.

Allows monitoring of the power to the brake resistor. The power is calculated on the basis of the resistor ohm value (par. 2-11), the DC link voltage, and the resistor duty time. If the power transmitted over 120 s exceeds 100% of the monitoring limit (par. 2-12) and *Warning* [1] is selected, a warning appears on the display. The warning disappears if the power goes below 80%. If the calculated power exceeds 100% of the monitoring limit and *Trip* [2] is selected in par. 2-13 *Power Monitoring*, the adjustable frequency drive trips and displays an alarm. If power monitoring is set to *Off* [0] or *Warning* [1], the brake function remains active, even if the monitoring limit is exceeded. This may lead to thermal overload of the resistor. It is also possible to have a warning via a relay/digital outputs. The measuring accuracy of the power monitoring depends on the accuracy of the resistance of the resistor (better than ± 20%).

2-15 Brake Check

Option:

*Off	[0]
Warning	[1]
Trip	[2]
Trip and Stop	[3]

Function:

This parameter is only active in adjustable frequency drives with an integral dynamic brake.

Enables the integration of a test and monitor function, which displays a warning or an alarm. On power-up, the functions is tested for disconnection of the brake resistor. The test is carried out during braking. Testing for disconnection of the IGBT, however, is carried out when there is no braking. A warning or trip disconnects the brake function. The testing sequence is as follows:

1. The DC link ripple amplitude is measured for 300 ms without braking.
2. The DC link ripple amplitude is measured for 300 ms with the brake turned on.
3. If the DC link ripple amplitude while braking is lower than the DC link ripple amplitude before braking + 1 %. Brake check failed, return a warning or alarm.
4. If the DC link ripple amplitude while braking is higher than the DC link ripple amplitude before braking + 1 %. Brake check OK

Select *Off* [0]. This function still monitors whether the brake resistor and the brake IGBT short circuit during operation. If so, a warning appears. Select *Warning* [1] to monitor the brake resistor and brake IGBT for to short circuiting. During power-up, disconnection of the brake resistor is checked.



NOTE

Remove a warning arisen in connection with *Off* [0] or *Warning* [1] by cycling the mains supply. The fault must be corrected first. With *Off* [0] or *Warning* [1], the adjustable frequency drive keeps running even if a fault is located. In the case of *Trip* [2], the adjustable frequency drive cuts out while displaying an alarm (trip locked). This happens if the brake resistor is short circuited, is disconnected, or if the brake IGBT is short circuited.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



2-17 Over-voltage Control

Option:

*Disabled	[0]
Enabled (not at stop)	[1]
Enabled	[2]

Function:

The Over-voltage Control is selected to reduce the risk for the drive to trip by an overvoltage on the DC link caused by generative power from the load. *Enabled (not at stop)*, means that OVC is active except when stopping with a stop signal applied.

□ **2-2* Mechanical Brake**

For hoisting applications, you must control an electromagnetic brake. To control the brake, a relay output (relay 01 or relay 02) or a programmed digital output (terminal 27 or 29) is required. Normally, this output must be closed during the time when the drive is unable to "hold" the motor, e.g. because of too high load. Select *Mechanical Brake Control* [32] for applications with an electromagnetic brake in par. 5-40 (Array parameter), par. 5-30, or par. 5-31 (digital output 27 or 29). When selecting *Mechanical brake control* [32], the mechanical brake is closed during start until the output current is above the level selected in par. 2-20 *Release Brake Current*. During stop, the mechanical brake activates when the speed is below the level selected in par. 2-21 *Activate Brake Speed [RPM]*. If the adjustable frequency drive enters into an alarm condition or an overcurrent or overvoltage situation, the mechanical brake immediately cuts in. This is also the case during safe stop.

2-20 Release Brake Current

Range:

0.00 - par. 4-51 A	* 0.00A
--------------------	---------

Function:
Set the motor current for release of the mechanical brake, if a start condition is present.

2-21 Activate Brake Speed [RPM]

Range:

0 - par. 4-53 RPM	* 0RPM
-------------------	--------

Function:
Set the motor speed for activating the mechanical brake, if a stop condition is present.

2-22 Activate Brake Speed [Hz]

Range:

0 - Max. speed	* 0 Hz
----------------	--------


Function:
Set the motor frequency for activating the mechanical brake, if a stop condition is present.

2-23 Activate Brake Delay

Range:

0.0 - 5.0 s	* 0.0s
-------------	--------

Function:
Sets the brake delay time of the coast after ramp-down time. The shaft is held at zero speed with full holding torque. Ensure that the mechanical brake has locked the load before the motor enters coast mode. See section *Mechanical Brake*.



* default setting () display text [] value for use in communication via serial communication port

— How to Program —



□ **Parameters: Reference/Ramps**

□ **3-0* Reference Limits**

3-00 Reference Range

Option:

- *Min. - Max [0]
- Max - +Max [1]

Function:

Settings for the reference signal and the feedback signal. They can both be positive or positive and negative. The minimum limit may have a negative value, unless *Speed control, closed loop* is selected (par. 1-00).

3-01 Reference/Feedback Unit


Option:

- None [0]
- *% [1]
- RPM [2]
- Hz [3]
- Nm [4]
- bar [5]
- Pa [6]
- PPM [7]
- CYCLE/min [8]
- PULSE/s [9]
- UNITS/s [10]
- UNITS/min [11]
- UNITS/h [12]
- °C [13]
- F [14]
- m³/s [15]
- m³/min [16]
- m³/h [17]
- t/min [23]
- t/h [24]
- m [25]
- m/s [26]
- m/min [27]
- in wg [29]
- gal/s [30]
- gal/min [31]
- gal/h [32]
- lb/s [36]
- lb/min [37]
- lb/h [38]
- lb ft [39]
- ft/s [40]

- ft/min [41]
- l/s [45]
- l/min [46]
- l/h [47]
- kg/s [50]
- kg/min [51]
- kg/h [52]
- ft³/s [55]
- ft³/min [56]
- ft³/h [57]

Function:

Select one of the units in par. 3-01 used in the Process PID Control.



3-02 Minimum Reference

Range:

-100000.000 - par. 3-03 *0.000 Unit

Function:

The Minimum Reference gives the minimum value obtained by the sum of all references. Minimum Reference is only active when par. 3-00 is set to *Min. - Max* [0].
 Speed control, closed loop: RPM
 Torque control, speed feedback: Nm.
 Process control unit in par. 3-01.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



3-03 Maximum Reference

Option:
 MinReference (par. 3-02) - 100000.000
*1500.000

Function:
 The *Maximum reference* is the highest value obtained by the sum of all references. The unit follows the choice of configuration in par. 1-00.
 Speed control, closed loop: RPM
 Torque control, speed feedback: Nm

□ **3-1* References**

3-10 Preset Reference

Array [8]

Range:
 -100.00 - 100.00 % *0.00%

Function:
 Eight different preset references (0-7) can be programmed via array programming. The preset reference is stated as a percentage of the value Maximum Reference (par. 3-03) or as a percentage of the other external references. If a Minimum Reference 0 (Par. 3-02) is programmed, the preset reference as a percentage is calculated on the basis of the difference between Maximum Reference and Minimum Reference. Afterwards, the value is added to Minimum Reference. Select *Preset ref enable* on the matching digital inputs when using preset references.

3-12 Catch up/slow-down Value

Range:
 0.00 - 100.00% *0.00%

Function:
 Enables entering a percentage value (relative) which is either added to or deducted from the actual reference. If *Catch up* is selected via one of the digital inputs (par. 5-10 to par. 5-15), the percentage (relative) value is added to the total reference. If *Slow down* is selected via one of the digital inputs (par. 5-10 to par. 5-15), the percentage (relative) value is deducted from the total reference.

3-13 Reference Site

Option:


*Linked to Hand / Auto	[0]
Remote	[1]
Local	[2]

Function:
 Decides which resulting reference is active. If *Linked to Hand / Auto* [0] is selected, the resulting reference depends on whether the drive is in Hand or Auto mode. In Hand mode the local reference is used, and in Auto mode the remote reference is used. Select *Remote* [1] to use the remote reference in both Hand mode and Auto mode. Select *Local* [2] to use the local reference in both Hand mode and Auto mode (par. 3-14) Preset Relative Reference.

3-14 Preset Relative Reference

Range:
 -100.00 - 10000.00 % * 0.00%

Function:
 Defines a fixed value (in %) added to the variable value (defined in par. 3-18 and called Y in the illustration below). This sum (Y) is multiplied with the actual reference (called X in the illustration below) and the result is added to the actual reference ($X+X*Y/100$).



3-15 Reference Resource 1

Option:

No function	[0]
*Analog input 53	[1]
Analog input 54	[2]
Frequency input 29	[7]
Frequency input 33	[8]
Local bus reference	[11]
Digital pot.meter	[20]

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



Function:

Adding up to three different reference signals to compose the actual reference. Defines what reference input should be treated as the source of the first reference signal. Par. 3-15 cannot be adjusted while the motor is running.

3-16 Reference Resource 2

Option:

No function	[0]
Analog input 53	[1]
Analog input 54	[2]
Frequency input 29	[7]
Frequency input 33	[8]
Local bus reference	[11]
*Digital pot.meter	[20]

Function:

Up to three different reference signals can be added to compose the actual reference. Defines what reference input should be treated as the source of the second reference signal. Par. 3-16 cannot be adjusted while the motor is running.

3-17 Reference Resource 3

Option:

No function	[0]
Analog input 53	[1]
Analog input 54	[2]
Frequency input 29	[7]
Frequency input 33	[8]
*Local bus reference	[11]
Digital pot.meter	[20]

Function:

Up to three different reference signals can be added to compose the actual reference. Defines what reference input should be treated as the source of the third reference signal. Par. 3-17 cannot be adjusted while the motor is running.

3-18 Relative Scaling Reference Resource


Option:

*No function	[0]
Analog input 53	[1]
Analog input 54	[2]
Frequency input 29	[7]

Frequency input 33	[8]
Local bus reference	[11]
Digital pot.meter	[20]

Function:

Defines that the input is treated as the source of the relative reference. This reference (in %) is added to the fixed value from par. 3-14. The sum (called Y in the illustration below) is multiplied with the actual reference (called X below) and the result is added to the actual reference ($X+X*Y/100$).



Par. 3-18 cannot be adjusted while the motor is running.

3-19 Jog Speed [RPM]

Range:

0 - par. 4-13 RPM *200RPM

Function:

The jog speed n_{JOG} is a fixed output speed. The adjustable frequency drive runs at this speed when the jog function is active.

□ **3-4* Ramp 1**

3-40 Ramp 1 Type

Option:


*Linear	[0]
---------	-----

Function:

Selects the desired ramp type, depending on requirements for acceleration/deceleration.

* default setting () display text [] value for use in communication via serial communication port


— How to Program —



3-41 Ramp 1 Ramp-up Time

Range:
0.01 - 3600.00 s *ExpressionLimits

Function:
The ramp-up time is the acceleration time from 0 RPM to the rated motor speed n_{M,N} (par. 1-23), provided that the output current does not reach the torque limit (set in par. 4-16). The value 0.00 corresponds to 0.01 s in speed mode.



$$Par. 3 - 41 = \frac{t_{acc} * n_{norm} [par. 1 - 25]}{\Delta ref [RPM]} [s]$$

3-42 Ramp 1 Ramp-down Time

Range:
0.01 - 3600.00 s *ExpressionLimits

Function:
The ramp-down time is the deceleration time from the rated motor speed n_{M,N} (par. 1-23) to 0 RPM, provided that there is no over-voltage in the inverter due to regenerative operation of the motor, or if the

generated current reaches the torque limit (set in par. 4-17). The value 0.00 corresponds to 0.01 s in speed mode. See ramp-up time in par. 3-41

$$Par. 3 - 42 = \frac{t_{acc} * n_{norm} [par. 1 - 25]}{\Delta ref [RPM]} [s]$$

3-45 Ramp 1 S-ramp Ratio at Accel. Start

Range:
1 - 99% *50%

Function:
Set the period of the total ramp-up time (par. 3-41) where the acceleration torque is growing smoothly. A large percentage minimizes torque jerks.

3-46 Ramp 1 S-ramp Ratio at Accel. End

Range:
1 - 99% *50%

Function:
Set the period of the total ramp-up time (par. 3-41) where the acceleration torque is declining smoothly. A large percentage minimizes torque jerks.

3-47 Ramp 1 S-ramp Ratio at Decel. Start

Range:
1 - 99% *50%

Function:
Set the period of the total ramp-down time (par. 3-42) where the deceleration torque is growing smoothly. A large percentage minimizes torque jerks.

3-48 Ramp 1 S-ramp Ratio at Decel. End

Range:
1 - 99% *50%

Function:
Set the period of the total ramp-down time (par. 3-42) where the deceleration torque is declining smoothly. A large percentage minimizes torque jerks.

□ **3-5* Ramp 2**

3-50 Ramp 2 Type

Option:
*Linear [0]

* default setting () display text [] value for use in communication via serial communication port




— How to Program —



Function:

Selects the desired ramp type, depending on requirements for acceleration/deceleration.




3-51 Ramp 2 Ramp-up Time

Range:

0.01 - 3600.00 s *s

Function:

The ramp-up time is the acceleration time from 0 RPM to the rated motor speed $n_{M,N}$ (par. 1-23). The output current must not reach the torque limit (set in par. 4-16). The value 0.00 corresponds to 0.01 sec. in speed mode.



$$Par.3 - 51 = \frac{t_{acc} * n_{norm} [par.1 - 25]}{\Delta ref [RPM]} [sec]$$

3-52 Ramp 2 Ramp-down Time

Range:

0.01 - 3600.00 s. *s

Function:

The ramp-down time is the deceleration time from the rated motor speed $n_{M,N}$ (par. 1-23) to 0 RPM. There must be no overvoltage in the inverter because of regenerative operation of the motor, nor can the generated current reach the torque limit (set in par. 4-17). The value 0.00 corresponds to 0.01 s in speed mode. See ramp in par. 3-51.

$$Par.3 - 52 = \frac{t_{dec} * n_{norm} [par.1 - 25]}{\Delta ref [RPM]} [sec]$$

3-55 Ramp 2 S-ramp Ratio at Accel. Start

Range:

1 - 99% *50%

Function:

Set the period of the total ramp-up time (par. 3-51) where the acceleration torque is growing smoothly. A large percentage minimizes torque jerks.

3-56 Ramp 2 S-ramp Ratio at Accel. End

Range:

1 - 99% *50%

Function:

Set the period of the total ram-up time (par. 3-51) where the acceleration torque is declining smoothly. A large percentage minimizes torque jerks.

3-57 Ramp 2 S-ramp Ratio at Decel. Start

Range:

1 - 99% *50%

Function:

Set the period of the total ramp-down time (par. 3-52) where the deceleration torque is growing smoothly. A large percentage minimizes torque jerks.

3-58 Ramp 2 S-ramp Ratio at Decel. End

Range:

1 - 99% *50%

Function:

Set the period of the total ramp-down time (par. 3-52) where the deceleration torque is declining smoothly. A large percentage minimizes torque jerks.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ 3-6* Ramp 3


3-60 Ramp 3 Type

Option:

*Linear [0]

Function:

Selects the desired ramp type, depending on requirements for acceleration/deceleration.




3-61 Ramp 3 Ramp-up Time

Range:

0.01 - 3600.00 s *s

Function:

The ramp-up time is the acceleration time from 0 RPM to the rated motor speed $n_{M,N}$ (par. 1-23). The output current cannot reach the torque limit (set in par. 4-16). The value 0.00 corresponds to 0.01 s in speed mode.



$$Par.3 - 61 = \frac{t_{acc} * n_{norm} [par.1 - 25]}{\Delta ref [RPM]} [sec]$$

3-62 Ramp 3 Ramp-down Time

Range:

0.01 - 3600.00 s *s

Function:

The ramp-down time is the deceleration time from the rated motor speed $n_{M,N}$ (par. 1-23) to 0 RPM. There can be no overvoltage in the inverter due to regenerative operation of the motor. Nor can the generated current reach the torque limit (set in par. 4-17). The value 0.00 corresponds to 0.01 s in speed mode. See ramp in par. 3-61.

$$Par.3 - 62 = \frac{t_{dec} * n_{norm} [par.1 - 25]}{\Delta ref [RPM]} [sec]$$

3-65 Ramp 3 S-ramp Ratio at Accel. Start

Range:

1 - 99% *50%

Function:

Set the period of the total ramp-up time (par. 3-61) where the acceleration torque is growing smoothly. A large percentage minimizes torque jerks.

3-66 Ramp 3 S-ramp Ratio at Accel. End

Range:

1 - 99% *50%

Function:

Set the period of the total ramp-up time (par. 3-61) where the acceleration torque is declining smoothly. A large percentage minimizes torque jerks.

3-67 Ramp 3 S-ramp Ratio at Decel. Start

Range:

1 - 99% *50%

Function:

Set the period of the total ramp-down time (par. 3-62) where the deceleration torque is growing smoothly. A large percentage minimizes torque jerks.

3-68 Ramp 3 S-ramp Ratio at Decel. End

Range:

1 - 99% *50%

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



Function:

Set the period of the total ramp-down time (par. 3-62) where the deceleration torque is declining smoothly. A large percentage minimizes torque jerks.

□ **3-7* Ramp 4**


3-70 Ramp 4 Type

Option:

*Linear [0]

Function:

Selects the desired ramp type, depending on requirements for acceleration/deceleration.




3-71 Ramp 4 Ramp-up Time

Range:

0.01 - 3600.00 s *s

Function:

The ramp-up time is the acceleration time from 0 RPM to the rated motor speed $n_{M,N}$ (par. 1-23). The output current cannot reach the torque limit (set in par. 4-16). The value 0.00 corresponds to 0.01 s in speed mode.



$$Par.3 - 71 = \frac{t_{acc} * n_{norm} [par.1 - 25]}{\Delta ref [RPM]} [sec]$$

3-72 Ramp 4 Ramp-down Time

Range:

0.01 - 3600.00 s *s

Function:

The ramp-down time is the deceleration time from the rated motor speed $n_{M,N}$ (par. 1-23) to 0 RPM. There can be no overvoltage in the inverter due to regenerative operation of the motor. Nor can the generated current reach the torque limit (set in par. 4-17). The value 0.00 corresponds to 0.01 s in speed mode. See ramp in par. 3-71.

$$Par.3 - 72 = \frac{t_{dec} * n_{norm} [par.1 - 25]}{\Delta ref [RPM]} [sec]$$

3-75 Ramp 4 S-ramp Ratio at Accel. Start

Range:

1 - 99% *50%

Function:

Set the period of the total ramp-up time (par. 3-71) where the acceleration torque is growing smoothly. A large percentage minimizes torque jerks.

3-76 Ramp 4 S-ramp Ratio at Accel. End

Range:

1 - 99% *50%

Function:

Set the period of the total ramp-up time (par. 3-71) where the acceleration torque is declining smoothly. A large percentage minimizes torque jerks.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



3-77 Ramp 4 S-ramp Ratio at Decel. Start

Range:

1 - 99% *50%

Function:

Set the period of the total ramp-down time (par. 3-72) where the deceleration torque is growing smoothly. A large percentage minimizes torque jerks.

3-78 Ramp 4 S-ramp Ratio at Decel. End

Range:

1 - 99% *50%

Function:

Set the period of the total ramp-down time (par. 3-72) where the deceleration torque is declining smoothly. A large percentage minimizes torque jerks.

□ **3-8* Other Ramps**


3-80 Jog Ramp Time

Range:

0.01 - 3600.00 s *s

Function:

The jog ramp time is the acceleration/deceleration time from 0 RPM to the rated motor frequency $n_{M,N}$ par. 1-25. The output current cannot be higher than the torque limit (set in par. 4-16). The jog ramp time starts when you activate a jog signal via the control panel, a programmed digital input, or the serial communication port.



$$Par.3 - 80 = \frac{t_{jog} * n_{norm} [par.1 - 25]}{\Delta jog \ speed [par.3 - 19]} [sec]$$


3-81 Quick Stop Ramp Time

Range:

0.01 - 3600.00 s *s

Function:

The ramp-down time is the deceleration time from the rated motor speed to 0 RPM. No overvoltage can arise in the inverter due to generating operation of the motor. Nor can the generated current be higher than the torque limit (set in par. 4-17). Quick-stop is activated by means of a signal on a programmed digital input, or via the serial communication port.



$$Par.3 - 81 = \frac{t_{Qstop} * n_{norm} [par.1 - 25]}{\Delta jog \ ref [RPM]} [sec]$$

□ **3-9* Digital Pot.Meter**

This function allows the user to increase or decrease the resulting reference by activating digital inputs

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



setup as either INCREASE, DECREASE or CLEAR. Minimum one input must be set up as INCREASE respectively DECREASE to make it active.

3-90 Step Size

Range:

0.01 - 200.00% *0.01%

Function:

If INCREASE/DECREASE is activated for less than 400 msec, the resulting reference will be increased/decreased by the amount set in par. 3-90 Step Size.

3-91 Ramp Time

Range:

0.01 - 3600.00 s *1.00s

Function:

If INCREASE / DECREASE is activated for more than 400 msec, the resulting reference will be ramped up / down according to this ramp time. The ramp time is defined as the time it will take to change the resulting reference from 0 % to 100 %.

3-92 Power Restore

Option:

*Off [0]
On [1]

Function:

When set to Off [0], the Digital Potentiometer reference will be reset to 0% after power-up. If set to On [1], the last Digital Potentiometer reference will be restored at power-up.

3-93 Maximum Limit

Range:

0 - 200 % *100%

Function:

Set the maximum value that the Digital Potentiometer reference is allowed to attain. This is advisable if the Digital Potentiometer is only meant for fine tuning of the resulting reference.

3-94 Minimum Limit

Range:

-200 - 200 % *-100%

Function:

Set the minimum value that the Digital Potentiometer reference is allowed to attain. This is advisable if the Digital Potentiometer is only meant for fine tuning of the resulting reference.



3-95 Ramp Delay

Range:

0.000 - 3600.00 s *1.000s

Function:

Adjust the delay before the adjustable frequency drive starts to ramp the reference. With a delay of 0 ms, the reference starts to ramp as soon as the INCREASE / DECREASE goes high.



* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ **Parameters: Limits/Warnings**

□ **4-1* Motor Limits**

4-10 Motor Speed Direction

Option:

- Clockwise [0]
- Counterclockwise [1]
- Both directions [2]

Function:

Prevents undesired reverse. Furthermore, the maximum output speed is selected regardless of other parameter settings. It is not possible to set this parameter while the motor is running.

4-11 Motor Speed Low Limit [RPM]

Range:

0 - par. 4-13 RPM * 0RPM

Function:

It is possible to have the *Minimum Motor Speed Limit* correspond to the minimum motor speed. Minimum speed cannot exceed the maximum speed in par. 4-13. If "Both directions" is selected in par. 4-10, minimum speed is not used.

4-13 Motor Speed High Limit [RPM]

Range:

Par. 4-11 - Variable Limit RPM * 3600 RPM

Function:

It is possible to have the maximum motor speed correspond to the highest motor speed.


4-16 Torque Limit Motor Mode

Range:

0.0 - Variable Limit % * 160.0 %

Function:

Sets the torque limit for motor operation. The torque limit is active in the speed range up to the rated motor speed (par. 1-25). To protect the motor from reaching the stalling torque, the default setting is 1.6 x the rated motor torque (calculated value). If a setting in par. 1-00 to par. 1-26 is changed, par. 4-16 to 4-18 are not automatically reset to the default settings.



! Changing par. 4-16 *Torque Limit Motor Mode* when par. 1-00 is set to *SPEED OPEN LOOP* [0], par. 1-66 *Min Current at Low Speed* is automatically readjusted. If par. 2-21 > par. 2-36, a potential risk for motor stalling occurs.

4-17 Torque Limit Generator Mode

Range:

0.0 - Variable Limit % * 160.0 %

Function:

Sets the torque limit for generator mode operation. The torque limit is active in the speed range up to the rated motor speed (par. 1-25). See illustration for par. 4-16 as well as par. 14-25 for further details.

4-18 Current Limit

Range:

0.0 - Variable Limit % * 160.0 %

Function:

Sets the current limit for motor operation. To protect the motor from reaching the stalling torque, the default setting is 1.6 x the rated motor torque (calculated value). If a setting in par. 1-00 to par. 1-26 is changed, par. 4-16 to par. 4-18 are not automatically reset to the default settings.

4-19 Max Output Frequency

Option:

0.0 - Hz * 132.0 Hz

Function:


Provides a final limit on the drive output frequency for improved safety in applications where it is necessary to avoid accidental overspeeding. This limit is final in all configurations (independent of the setting in par. 1-00).

□ **4-5* Adj. Warnings**

Warnings are shown on display, programmed output or serial bus.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



4-50 Warning Current Low

Range:

0.00 - par. 4-51 A *0.00A

Function:

When the motor current is below this limit, I_{LOW} , the display reads CURRENT LOW. You can program the signal outputs to produce a status signal on terminal 27 or 29 as well as on relay output 01 or 02.

4-51 Warning Current High

Range:

Par. 4-50 - par. 16-37 A *par. 16-37 A

Function:

If the motor current exceeds this limit (I_{HIGH}), the display reads CURRENT HIGH. You can program the signal outputs to produce a status signal on terminal 27 or 29 and on relay output 01 or 02.

4-52 Warning Speed Low

Range:

0 - par. 4-53 RPM *0RPM

Function:

When the motor speed is below the limit, n_{LOW} the display reads SPEED LOW. You can program the signal outputs to produce a status signal on terminal 27 or 29 and on relay output 01 or 02. Program the lower signal limit of the motor speed, n_{LOW} , within the normal working range of the adjustable frequency drive. See drawing.

4-53 Warning Speed High

Range:

Par. 4-52 - par. 4-13 RPM * par. 4-13 RPM

Function:

When the motor speed is above the limit, n_{HIGH} , the display reads SPEED HIGH. You can program the signal outputs to produce a status signal on terminal 27 or 29 and on relay output 01 or 02. Program the upper signal limit of the motor speed, n_{HIGH} , within the normal working range of the adjustable frequency drive.

4-54 Warning Reference Low

Range:

-999999.999 - 999999.999 * -999999.999

Function:

If the actual reference is below this limit, the display indicates Ref Low. The signal outputs can be programmed to produce a status signal on the digital outputs and the relay outputs.

4-55 Warning Reference High

Range:

-999999.999 - 999999.999 * 999999.999

Function:

If the actual reference exceeds this limit, the display indicates Ref High. The signal outputs can be programmed to produce a status signal on the digital outputs and the relay outputs.

4-56 Warning Feedback Low

Range:

-999999.999 - 999999.999 * -999999.999

Function:

If the feedback is below this limit, the display indicates Feedb Low. The signal outputs can be programmed to produce a status signal on the digital outputs and the relay outputs.

4-57 Warning Feedback High

Range:

-999999.999 - 999999.999 * 999999.999

Function:

If the feedback exceeds this limit, the display indicates Feedb High. The signal outputs can be

* default setting () display text [] value for use in communication via serial communication port

programmed to produce a status signal on the digital outputs and the relay outputs.



4-58 Missing Motor Phase Function

Option:

*Off	[0]
On	[1]

Function:

Selects monitoring of the motor phases. If *On* is selected, the adjustable frequency drive reacts on a missing motor phase and displays an alarm. If *Off* is selected, no alarm is returned if a motor phase is missing. If the motor runs on only two phases, it can be damaged/overheated. Thus, do not change the missing motor phase function *On*. This parameter cannot be changed while the motor is running.

□ **4-6* Speed Bypass**

4-60 Bypass Speed From [RPM]

Array [4]

Range:

0 - par. 4-13 RPM * 0 RPM

Function:

Some systems call for avoiding certain output frequencies / speed due to resonance problems in the system. Enter the frequencies / speed you want to avoid.

4-62 Bypass Speed to [RPM]

Array [4]

Range:

0 - par. 4-13 RPM * 0RPM

Function:

Some systems call for avoiding certain output frequencies / speed due to resonance problems in the system. Enter the frequencies / speed you want to avoid.

* default setting () display text [] value for use in communication via serial communication port



□ **Parameters: Digital In/Out**

□ **5-0* Digital I/O Mode**

5-00 Digital I/O Mode

Option:

*PNP	[0]
NPN	[1]

Function:

The digital inputs and programmed digital outputs are pre-programmable for operation either in PNP or NPN systems. PNP systems are pulled down to GND. Action is on positive going pulses (↑). NPN systems are pulled up to + 24 V (internal in the drive). Action is on negative going pulse (↓). You cannot set the parameter while the motor is running.

5-01 Terminal 27 Mode

Option:

*Input	[0]
Output	[1]

Function:

Selects terminal 27 as either a digital input or output. Default setting is the Input function. You cannot set this parameter while the motor is running.

5-02 Terminal 29 Mode

Option:

*Input	[0]
Output	[1]

Function:

Selects terminal 29 as either a digital input or output. Default setting is the Input function. You cannot set the parameter while the motor is running.

□ **5-1* Digital Inputs**

Parameters for configuring the input functions for the input terminals.

The digital inputs are used for selecting various functions in the adjustable frequency drive. All digital inputs can be set to the following functions:

No operation	[0]
Reset	[1]
Coast inverse	[2]
Coast and reset inv.	[3]
Quick stop inverse	[4]
DC brake inverse	[5]
Stop inverse	[6]
Start	[8]
Latched start	[9]
Reverse	[10]
Start reverse	[11]
Enable start forward	[12]
Enable start reverse	[13]
Jog	[14]
Preset ref bit 0	[16]
Preset ref bit 1	[17]
Preset ref bit 2	[18]
Freeze reference	[19]
Freeze output	[20]
Speed up	[21]
Slow	[22]
Set-up select bit 0	[23]
Set-up select bit 1	[24]
Catch up	[28]
Slow-down	[29]
Pulse input	[32]
Ramp bit 0	[34]
Ramp bit 1	[35]
Mains failure inverse	[36]
DigiPot increase	[55]
DigiPot decrease	[56]
DigiPot clear	[57]
Reset Counter A	[62]
Reset Counter B	[65]

Functions dedicated to only one digital input are stated in the corresponding parameter.

You can program all digital inputs to these functions:

- **No operation [0]:** The adjustable frequency drive does not react to signals transmitted to the terminal.
- **Reset [1]:** Resets the adjustable frequency drive after a TRIP/ALARM. Not all alarms can be reset.
- **Coast inverse [2]** (Default Digital input 27): Coasting stop, inverted input (NC). The adjustable frequency drive leaves the motor in free mode. Logic "0" => coasting stop.
- **Coast and reset inv. [3]:** Reset and coasting stop inverted input (NC). The adjustable frequency drive leaves the motor in free mode and resets the drive. Logic "0" => coasting stop and reset
- **Quick stop inverse [4]:** Inverted input (NC). Generates a stop in accordance with

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

the quick stop ramp time (par. 3-81). When the motor stops, the shaft is in free mode. Logic "0" => Quick stop.

- **DC brake inverse [5]:** Inverted input for DC braking (NC). Stops the motor by energizing it with a DC current for a certain time period. See par. 2-01 to par. 2-03. The function is only active when the value in par. 2-02 is different from 0. Logic "0" => DC braking.
- **Stop inverse [6]:** Stop inverted function. Generates a stop function when the selected terminal goes from logical level "1" to "0". The stop is performed according to the selected ramp time (par. 3-42, par. 3-52, par. 3-62, par. 3-72).



NOTE

When the adjustable frequency drive is at the torque limit and has received a stop command, it may not stop by

itself. To ensure that the adjustable frequency drive stops, configure a digital output to "Torque limit stop [27]" and connect this digital output to a digital input that is configured as coast.

- **Start [8]** (Default Digital input 18): Select start for a start/stop command. Logic "1" = start, logic "0" = stop.
- **Latched start [9]:** The motor starts if a pulse is applied for min. 2 ms. The motor stops if you activate Stop inverse.
- **Reverse [10]:** (Default Digital input 19). Changes the direction of motor shaft rotation. Select Logic "1" to reverse. The reverse signal only changes the direction of rotation. It does not activate the start function. Select both directions in par. 4-10. The function is not active in Torque control, speed feedback.
- **Start reverse [11]:** Used for start/stop and for reversing on the same wire. Signals on start are not allowed at the same time.
- **Enable start forward [12]:** Is used if the motor shaft is only to rotate clockwise at start.
- **Enable start reverse [13]:** Is used if the motor shaft is only to rotate counterclockwise at start.
- **Jog [14]** (Default Digital input 29): Is used for shifting between external reference and preset reference. You must select External/preset [2] in par. 2-14. Logic "0" = external references active; Logic "1" = one of the four references is active according to the table below

- **Preset ref bit 0 [16]:** Preset ref. bit 0,1, and 2 enable a choice between one of the eight preset references according to the table below.
- **Preset ref bit 1 [17]:** Same as Preset ref bit 0 [16].
- **Out of feedback range [18]:** The feedback range is set in par. 4-56 and 4-57.

Preset ref. bit	2	1	0
Preset ref. 0	0	0	0
Preset ref. 1	0	0	1
Preset ref. 2	0	1	0
Preset ref. 3	0	1	1
Preset ref. 4	1	0	0
Preset ref. 5	1	0	1
Preset ref. 6	1	1	0
Preset ref. 7	1	1	1

- **Freeze reference [19]:** Freezes the actual reference. The frozen reference is now the point of enable/condition for Speed up and Slow to be used. If Speed up/Slow is used, the speed change always follows ramp 2 (par. 3-51 and 3-52) in the range 0 - par. 3-03.
- **Freeze output [20]:** Freezes the actual motor frequency (Hz). The frozen motor frequency is now the point of enable/condition for Speed up and Slow to be used. If Speed up/Slow is used, the speed change always follows ramp 2 (par. 3-51 and 3-52) in the range 0 - par. 1-23.



NOTE

If Freeze output is active, you cannot stop the adjustable frequency drive via a low "start [13]" signal. Stop the adjustable frequency drive via a terminal programmed for Coast inverse [2] or Coast and reset inv.

- **Speed up [21]:** Select Speed up and Slow if digital control of the up/down speed is desired (motor potentiometer). Activate this function by selecting either Freeze reference or Freeze output. When Speed up is activated for less than 400 msec., the resulting reference will be increased by 0.1 %. If Speed up is activated for more than 400 msec., the resulting reference will ramp according to Ramp 2 (par. 3-41).

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



	Slow-down	Catch up
Unchanged speed	0	0
Reduced by %-value	1	0
Increased by %-value	0	1
Reduced by %-value	1	1

- **Slow-down [29]:** Same as Catch up [28].
- **Pulse input [32]:** Select Pulse input if you use a pulse sequence as either reference or feedback. Scaling is done in par. group 5-5*.
- **Ramp bit 0 [34]**
- **Ramp bit 1 [35]**
- **Mains failure inverse [36]:** Is selected to activate par. 14-10 *Mains Failure*. Mains failure inverse is active in the Logic "0" situation.
- **DigiPot Increase [55]:** Uses the input as an INCREASE signal to the Digital Potentiometer function described in parameter group 3-9*
- **DigiPot decrease [56]:** Uses the input as a DECREASE signal to the Digital Potentiometer function described in parameter group 3-9*
- **DigiPot clear [57]:** Uses the input to CLEAR the Digital Potentiometer reference described in parameter group 3-9*
- **Counter A (up) [60]:** (Terminal 29 or 33 only) Input for increment counting in the SLC counter.
- **Counter A (down) [61]:** (Terminal 29 or 33 only) Input for decrement counting in the SLC counter.
- **Reset Counter A [62]:** Input for reset of counter A.
- **Counter B (up) [63]:** (Terminal 29 or 33 only) Input for increment counting in the SLC counter.
- **Counter B (down) [64]:** (Terminal 29 or 33 only) Input for decrement counting in the SLC counter.
- **Reset Counter B [65]:** Input for reset of counter B.
- **Slow [22]:** Same as Speed up [21].
- **Set-up select bit 0 [23] :** Selection of Set-up, bit 0 and bit 1 allows you to choose between one of the four set-ups. You must set par. 0-10 to Multi setup.
- **Set-up select bit 1 [24]** (Default Digital input 32): Same as Set-up select bit 0 [23].
- **Catch up [28]:** Select Catch up/Slow-down to increase or reduce the reference value (set in par. 3-12).

5-10 Terminal 18 Digital Input

- * Start [8]

Function:

5-11 Terminal 19 Digital Input

- * Reverse [10]

5-12 Terminal 27 Digital Input

- * Coast inverse [2]

5-13 Terminal 29 Digital Input

Option:

- * Jog [14]
- Counter A (up) [60]
- Counter A (down) [61]
- Counter B (up) [63]
- Counter B (down) [64]

Function:

Options [60], [61], [63] and [64] are additional functions. Counter function is used in Smart Logic Control functions.

This parameter is only available in FC 302.

5-14 Terminal 32 Digital Input

Option:

- * No operation [0]
- Counter A (up) [60]
- Counter A (down) [61]
- Counter B (up) [63]
- Counter B (down) [64]

Function:

Option [60], [61], [63] and [64] are additional functions. Counter function is used in Smart Logic Control functions.

5-15 Terminal 33 Digital Input

- * No operation [0]

□ **5-3* Digital Outputs**

The 2 solid state digital outputs are common for terminals 27 and 29. Set the I/O function for terminal 27 in par. 5-01, and set the I/O function for terminal 29 in par. 5-02. These parameters cannot be set while running.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



No operation	[0]
Control ready	[1]
Drive ready	[2]
Drive ready / remote	[3]
Enable / no warning	[4]
VLT running	[5]
Running / no warning	[6]
Run in rnge, no warn	[7]
Run on ref., no warn.	[8]
Alarm	[9]
Alarm or warning	[10]
At torque limit	[11]
Out of current range	[12]
Below current, low	[13]
Above current, high	[14]
Out of speed range	[15]
Below speed, low	[16]
Above speed, high	[17]
Thermal warning	[21]
Ready, no thrm warn	[22]
Rmte rdy, no th wrn	[23]
Ready, voltage OK	[24]
Reverse	[25]
Bus OK	[26]
Torque limit stop	[27]
Brake, no warning	[28]
Brake ready, no fault	[29]
Brake fault (IGBT)	[30]
Relay 123	[31]
Mech. brake control	[32]
Safe stop active	[33]
Comparator 0	[60]
Comparator 1	[61]
Comparator 2	[62]
Comparator 3	[63]
Logic Rule 0	[70]
Logic Rule 1	[71]
Logic Rule 2	[72]
Logic Rule 3	[73]
SL digital output A	[80]
SL digital output B	[81]
SL digital output C	[82]
SL digital output D	[83]
SL digital output E	[84]
SL digital output F	[85]
Local ref. active	[120]
Remote ref. active	[121]
No alarm	[122]
Start cmd. active	[123]
Running reverse	[124]
Drive in hand mode	[125]
Drive in auto mode	[126]

- **No operation [0]**: Default for all digital outputs and relay outputs
- **Control ready [1]**: The control board receives supply voltage.
- **Drive ready [2]**: The adjustable frequency drive is ready for operation and applies a supply signal on the control board.
- **Drive ready / remote [3]**: The adjustable frequency drive is ready for operation and is in Auto on mode.
- **Enable / no warning [4]**: The adjustable frequency drive is ready for use. No start or stop command has been given (start/disable). There are no warnings.
- **VLT running [5]**: The motor is running.
- **Running / no warning [6]**: The output speed is higher than the speed set in par. 1-81. The motor is running and there are no warnings.
- **Run in rnge, no warn [7]**: Runs within the programmed current/speed ranges set in par. 4-50 to par. 4-53.
- **Run on ref., no warn. [8]**: Mechanical speed according to reference.
- **Alarm [9]**: An alarm activates the output.
- **Alarm or warning [10]**: An alarm or warning activates the output.
- **At torque limit [11]**: The torque limit set in par. 4-16 or par. 1-17 is exceeded.
- **Out of current range [12]**: The motor current is outside the range set in par. 4-18.
- **Below current, low [13]**: The motor current is lower than set in par. 4-50.
- **Above current, high [14]**: The motor current is higher than set in par. 4-51.
- **Out of speed range [15]**
- **Below speed, low [16]**: The output speed is lower than set in par. 4-52.
- **Above speed, high [17]**: The output speed is higher than set in par. 4-53.
- **Thermal warning [21]**: Thermal warning is on when the temperature is above limit in the motor, the adjustable frequency drive, the brake resistor, or the thermistor.
- **Ready, no thrm warn [22]**: The adjustable frequency drive is ready for operation and there is no overtemperature warning.
- **Rmte rdy, no th wrn [23]**: The adjustable frequency drive is ready for operation

You can program the digital outputs to these functions:

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

and is in Auto on mode. There is no overtemperature warning.

- **Ready, voltage OK [24]:** The adjustable frequency drive is ready for operation and the line voltage is within the specified voltage range (see section *General Specifications*).
- **Reverse [25]:** Reverse. Logic "1" = relay activated, 24 V DC when CW rotation of the motor. Logic "0" = relay not activated, no signal, when CCW rotation of the motor.
- **Bus OK [26]:** Active communication (no timeout) via the serial communication port.
- **Torque limit stop [27]:** Is used when performing a coasting stop and in torque limit condition. If the adjustable frequency drive has received a stop signal and is at the torque limit, the signal is Logic "0".
- **Brake, no warning [28]:** The brake is active and there are no warnings.
- **Brake ready, no fault [29]:** The brake is ready for operation and there are no faults.
- **Brake fault (IGBT) [30]:** The output is Logic "1" when the brake IGBT is short-circuited. Use this function to protect the adjustable frequency drive if there is a fault on the brake modules. Use the output/relay to cut out the line voltage from the adjustable frequency drive.
- **Relay 123 [31]:** If Fieldbus profile [0] is selected in par. 5-12, the relay is activated. If OFF1, OFF2, or OFF3 (bit in the control word) is Logic "1".
- **Mech. brake control [32]:** Enables control of an external mechanical brake, see description in the section *Control of Mechanical Brake*, and par. group 2-2*
- **Safe stop active [33]:** Indicates that the safe stop on terminal 37 has been activated.
- **Comparator 0 [60]:** See par. group 13-1*. If Comparator 0 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
- **Comparator 1 [61]:** See par. group 13-1*. If Comparator 1 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
- **Comparator 2 [62]:** See par. group 13-1*. If Comparator 2 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
- **Comparator 3 [63]:** See par. group 13-1*. If Comparator 3 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
- **Logic rule 0 [70]:** See par. group 13-4*. If Logic rule 0 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
- **Logic rule 1 [71]:** See par. group 13-4*. If Logic rule 1 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
- **Logic rule 2 [72]:** See par. group 13-4*. If Logic rule 2 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
- **Logic rule 3 [73]:** See par. group 13-4*. If Logic rule 3 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
- **SL digital output A [80]:** See par. 13-52 *SL Controller Action*. The input will go high whenever the SL Controller Action [38] "Set dig. out. A high" is executed. The input will go low whenever the SL Controller Action [32] "Set dig. out. A low" is executed.
- **SL digital output B [81]:** See par. 13-52 *SL Controller Action*. The input will go high whenever the SL Controller Action [39] "Set dig. out. A high" is executed. The input will go low whenever the SL Controller Action [33] "Set dig. out. A low" is executed.
- **SL digital output C [82]:** See par. 13-52 *SL Controller Action*. The input will go high whenever the SL Controller Action [40] "Set dig. out. A high" is executed. The input will go low whenever the SL Controller Action [34] "Set dig. out. A low" is executed.
- **SL digital output D [83]:** See par. 13-52 *SL Controller Action*. The input will go high whenever the SL Controller Action [41] "Set dig. out. A high" is executed. The input will go low whenever the SL Controller Action [35] "Set dig. out. A low" is executed.
- **SL digital output E [84]:** See par. 13-52 *SL Controller Action*. The input will go high whenever the SL Controller Action [42] "Set dig. out. A high" is executed. The input will go low whenever the SL Controller Action [36] "Set dig. out. A low" is executed.
- **SL digital output F [85]:** See par. 13-52 *SL Controller Action*. The input will go high whenever the SL Controller Action [43] "Set dig. out. A high" is executed. The input will go low whenever the SL Controller Action [37] "Set dig. out. A low" is executed.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

- **Local ref. active [120]:** The output will be high if par. 3-13 *Reference Site* = [2] "Local" or when par. 3-13 *Reference Site* = [0] "Linked to Hand / Auto" at the same time as the LCP is in Hand on mode.
- **Remote ref. active [121]:** The output will be high if par. 3-13 *Reference Site* = [1] "Remote" or when par. 3-13 *Reference Site* = [0] Linked to Hand / Auto at the same time as the LCP is in Auto on mode.
- **No alarm [122]:** The output goes high when no alarm is present.
- **Start cmd. active [123]:** The output goes high whenever there is an active Start command (i.e. via digital input bus connection or [Hand on] or [Auto on], and no Stop or Start command is active.
- **Running reverse [124]:** The output is high whenever the drive is running counterclockwise (the logical product of the status bits "running" AND "reverse").
- **Drive in hand mode [125]:** The output goes high whenever the drive is in Hand on mode (as indicated by the LED above [Hand on]).
- **Drive in auto mode [126]:** The output goes high whenever the drive is in Hand on mode (as indicated by the LED above [Auto on]).

5-30 Terminal 27 Digital Output

* No operation [0]

5-31 Terminal 29 digital Output

* No operation [0]

□ **5-4* Relays**

5-40 Function Relay

Array [8] (Relay 1 [0], Relay 2 [1])

Control word bit 11 [36]

Control word bit 12 [37]

Par. 5-40 holds the same options as par. 5-30 including option 36 and 37.

Function:

- **Control word bit 11 [36]:** Bit 11 in the control word controls relay 01. See section *Control Word According to FC Profile (CTW)*. This option only applies for par. 5-40.

* default setting () display text [] value for use in communication via serial communication port

- **Control word bit 12 [37]:** Bit 12 in the control word controls relay 02. See section *Control Word According to FC Profile (CTW)*.

Selecting between 2 internal mechanical relays is an array function.

Ex. par. 5-4* → 'OK' → Function Relay → 'OK' → [0] → 'OK' → *select function*

Relay no. 1 has array no [0]. Relay no. 2 has array no [1].

When relay option MCB 105 is fitted in the drive, the following selection of relays take place:

Relay 7 -> Par. 5-40 [6]

Relay 8 -> Par. 5-40 [7]

Relay 9 -> Par. 5-40 [8]

Relay functions are selected from the same list as for solid state output functions. See par. 5-3*.

5-41 On Delay, Relay

Array [2] (Relay 01 [0], Relay 02 [1])

Range:

0.00 - 600.00 s *0.00s

Function:

Allows a delay of the cut-in time of the relays. Select between 2 internal mechanical relays in an array function. See par. 5-40.

5-42 Off Delay, Relay

Array [2] (Relay 01 [0], Relay 02 [1])

Range:

0.00 - 600.00 s. *0.00s.

Function:


Enables a delay of the relay cut-out time. Select between 2 internal mechanical relays in an array function. See par. 5-40

□ **5-5* Pulse Input**

The pulse input parameters are used to select an appropriate window for impulse reference area. Input terminal 29 or 33 acts as a frequency reference input. Set par. 5-13 or par 5-15 to "Pulse input" [32]. If terminal 29 is used as input, par. 5-01 must be selected to "Input" [0].



— How to Program —



5-50 Term. 29 Low Frequency

Range:

100 - 110000 Hz *100Hz

Function:

Sets the low frequency referring to low reference value in par. 5-52 to correspond to the crankshaft speed. This parameter is only available in FC 302.

5-51 Term. 29 High Frequency

Range:

100 - 110000 Hz *100Hz

Function:

Set the high frequency referring to high reference value in par. 5-53 to correspond to the crankshaft speed.

5-52 Term. 29 Low Ref./Feedb. Value

Range:

-1000000.000 - par. 5-53 * 0.000

Function:

Sets the lowest reference value [RPM] for the crankshaft speed and the lowest feedback value. Select terminal 29 as a digital output (par. 5-02 = "Output" [1] and par. 5-13 = applicable value).

5-53 Term. 29 High Ref./Feedb. Value

Range:

Par. 5-52 - 1000000.000 *1500.000

Function:

Sets the highest reference value [RPM] for the crankshaft speed and the highest feedback value.

Select terminal 29 as a digital output (par. 5-02 = "Output" [1] and par. 5-13 = applicable value)

5-54 Pulse Filter Time Constant #29

Range:

1 - 1000 ms *100ms

Function:

The low-pass filter reduces the influence on and dampens oscillations on the feedback signal from the control. This is an advantage, e.g. if there is a great amount of noise in the system. It is not possible to set this parameter while the motor is running.

5-55 Term. 33 Low Frequency

Range:

100 - 110000 Hz *100Hz

Function:

Sets the low frequency referring to low reference value in par. 5-57 to correspond to the crankshaft speed.

5-56 Term. 33 High Frequency

Range:

100 - 110000 Hz *100Hz

Function:

Sets the high frequency referring to high reference value in par. 5-58 to correspond to the crankshaft speed.

5-57 Term. 33 Low Ref./Feedb. Value

Range:

-100000.000 - par. 5-58) *0.000

Function:

Sets the lowest reference value [RPM] for the crankshaft speed.

5-58 Term. 33 High Ref./Feedb. Value

Range:

Par. 5-57 - 100000.000 *1500.000

Function:

Sets the highest reference value [RPM] for the crankshaft speed.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



5-59 Pulse Filter Time Constant #33

Range:


1 - 1000 ms * 100ms

Function:

The low-pass filter reduces the influence on and dampens oscillations on the feedback signal from the control. This is an advantage, e.g. if there is a great amount of noise in the system. You cannot set this parameter while the motor is running.

□ **5-6* Pulse Outputs**

The pulse outputs are designated to terminals 27 or 29. Select terminal 27 in par. 5-01 and terminal 29 in par. 5-02.



5-60 Terminal 27 Pulse Output Variable

Option:

- * No operation [0]
- MCO controlled [51]
- Output frequency [100]
- Reference [101]
- Feedback [102]
- Motor current [103]
- Torque relative to limit [104]
- Torque relative to rated [105]
- Power [106]
- Speed [107]
- Torque [108]

Function:

Selects the variable for the chosen readout on terminal 29. It is not possible to set the parameter while the motor is running.

5-62 Pulse Output Maximum Frequency #27

Range:

0 - 32000 Hz * 5000Hz

Function:

Sets the maximum frequency on terminal 27 referring to output variable in par. 5-60. You cannot set the parameter while the motor is running.

5-63 Terminal 29 Pulse Output Variable

Option:

- * No operation [0]
- MCO controlled [51]
- Output frequency [100]
- Reference [101]
- Feedback [102]
- Motor current [103]
- Torque relative to limit [104]
- Torque relative to rated [105]
- Power [106]
- Speed [107]
- Torque [108]

Function:

Selects the variable for the chosen readout on terminal 29. It is not possible to set the parameter while the motor is running.

5-65 Pulse Output Maximum Frequency #29

Range:

0 - 32000 Hz * 5000Hz

Function:


Sets the maximum frequency on terminal 29 referring to output variable in par. 5-63. You cannot set the parameter while the motor is running.

□ **5-7* 24 V Encoder Input**

You can connect a 24 V encoder to terminal 13 (24 V DC supply), terminal 32 (Channel A), terminal 33 (Channel B), and terminal 20 (GND). The digital inputs 32/33 are active for encoder inputs when you select Flux w/ encoder feedback (par. 1-01). The encoder used is a dual channel (A and B) 24 V type. Max input frequency: 110 kHz.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



related to the encoder shaft and the denominator is related to the driving shaft.

Example: Speed on the encoder shaft = 1000 RPM and speed on the driving shaft is 3000 RPM:

Par. 5-72 = 1000 and par. 5-73 = 3000, or par. 5-72 = 1 and par. 5-73 = 3.

Par 5-72 cannot be adjusted while the motor is running.

If the motor control principle is 'Flux w encoder feedback' (par. 1-01 [3]), the gear ratio between motor and encoder must be 1:1. (No gear).

5-73 Term 32/33 Gear Denominator

Range:

1.0 - 60000 N/A

*1 N/A

Function:

Sets the denominator value for a gear ratio between encoder and driving shaft. The denominator is related to the driving shaft. See also par. 5-72.

Par. 5-73 cannot be adjusted while the motor is running.

5-70 Term 32/33 Pulses per Revolution

Range:

128 - 4096 PPR

*1024PPR

Function:

Sets the encoder pulses per revolution on the crankshaft. Read the correct value from the encoder. It is not possible to set the parameter while the motor is running.

5-71 Term 32/33 Encoder Direction

Option:

- *Clockwise [0]
- Counterclockwise [1]

Function:

Changes the detected encoder direction (revolution) without changing the wires to the encoder. Select Clockwise when A channel is 90° (electrical degrees) before channel B by clockwise rotation of the encoder shaft. Select Counterclockwise when A channel is 90° (electrical degrees) after channel B by clockwise rotation of the encoder shaft. You cannot set the parameter while the motor is running.

5-72 Term 32/33 Gear Numerator

Range:

1.0 - 60000 N/A

*1 N/A

Function:

Sets the nominator value for a gear ratio between encoder and driving shaft. The nominator is

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ **Parameters: Analog In/Out**

□ **6-0* Analog I/O Mode**

FC 300 is equipped with 2 analog inputs: Terminal 53 and 54. The analog inputs on FC 302 are designed for free selection of either voltage (-10V - +10V) or current input (0/4 - 20 mA).



NOTE

Thermistors are connected either to an analog or a digital input.

6-00 Live Zero Timeout Time

Range:

1 - 99 s * 10s

Function:

Is active when A53 (SW201) and /or A54 (SW202) is/are in the position ON (the analog inputs are selected to current inputs). If the reference signal value connected to the selected current input falls below 50% of the value set in par. 6-12 or par. 6-22 for a period longer than the time set in par. 6-00, the function selected in par. 6-01 is activated.

6-01 Live Zero Timeout Function

Option:

- *Off [0]
- Freeze Output [1]
- Stop [2]
- Jogging [3]
- Max. speed [4]
- Stop and trip [5]


Function:

Activates the function if the input signal on terminal 53 or 54 drops below 2 mA, provided that par. 6-12 or 6.22 is set higher than 2 mA, and that the time for timeout in par. 6-00 is exceeded. If more timeouts occur at the same time, the adjustable frequency drive makes the following priority of the time-out function:

1. *Live Zero Time-out Function* par. 6-01
2. *Encoder Loss Function* par. 5-74
3. *Control-word Time-out Function* par. 8-04.
The output frequency of the adjustable frequency drive can be:
 - frozen at the present value
 - overruled to jog speed

- overruled to max. speed
- overruled to stop with subsequent trip
- overruled to Set-up 8.
It is not possible to set the parameter while the motor is running.

□ **6-1* Analog Input 1**



6-10 Terminal 53 Low Voltage

Range:

0.0 - par. 6-11 * 0.0V

Function:

Sets the analog input scaling value to correspond to the minimum reference value (set in par. 3-02).

6-11 Terminal 53 High Voltage

Range:

Par. 6-10 to 10.0 V * 10.0V

Function:

Sets the analog input scaling value to correspond to the maximum reference value (set in par. 3-03).

6-12 Terminal 53 Low Current

Range:

0.0 to par. 6-13 mA * 0.0mA

Function:

Determines the value of the reference signal to correspond to the minimum reference value (set in par. 3-02). If the Time-out function of par. 6-01 is activated, the value must be set at >2 mA.

* default setting () display text [] value for use in communication via serial communication port



— How to Program —



6-13 Terminal 53 High Current

Range:

Par. 6-12 to - 20.0 mA * 20.0 mA

Function:

Sets the value of the reference signal to correspond to the maximum reference value (set in par. 3-03).

6-14 Terminal 53 Low Ref./Feedb. Value

Range:

-100000.000 to par. 6-15 * 0.000 Unit

Function:

Sets the analog input scaling to correspond to the minimum reference feedback value (set in par. 3-01).

6-15 Terminal 53 High Ref./Feedb. Value

Range:

Par. 6-14 to 100000.000 * 1500.000 Unit

Function:

Sets the analog input scaling value to correspond to the maximum reference feedback value (set in par. 3-01).

6-16 Terminal 53 Filter Time Constant

Range:

0.001 - 10.000 s * 0.001s

Function:

A 1st order digital low-pass filter time constant for suppressing electrical noise on terminal 53. You cannot set the parameter while the motor is running.

□ **6-2* Analog Input 2**

6-20 Terminal 54 Low Voltage

Range:

0.0 - par. 6-21 * 0.0V

Function:

Sets the analog input scaling value to correspond to the minimum reference value (set in par. 3-02). See also section *Reference Handling*.

6-21 Terminal 54 High Voltage

Range:

Par. 6-20 to 10.0 V * 10.0V

Function:

Sets the analog input scaling value to correspond to the maximum reference value (set in par. 3-03).

6-22 Terminal 54 Low Current

Range:

0.0 to par. 6-23 mA * 0.0mA

Function:

Determines the value of the reference signal to correspond to the minimum reference value (set in par. 3-02). If the Time-out function of par. 6-01 is activated, set the value at >2 mA.

6-23 Terminal 54 High Current

Range:

Par. 6-12 to - 20.0 mA * 20.0 mA

Function:

Sets the value of the reference signal to correspond to the maximum reference value (set in par. 3-03).

6-24 Terminal 54 Low Ref./Feedb. Value

Range:

-100000.000 to par. 6-25 * 0.000 Unit

Function:

Sets the analog input scaling value to correspond to the minimum reference feedback value (set in par. 3-01).

6-25 Terminal 54 high ref./feedb. value

Range:

Par. 6-24 to 100000.000 * 1500.000 Unit

Function:

Sets the analog input scaling value to correspond to the maximum reference feedback value (set in par. 3-01).

6-26 Terminal 54 Filter Time Constant

Range:

0.001 - 10.000 s * 0.001s

Function:

A 1st order digital low-pass filter time constant for suppressing electrical noise on terminal 53. You cannot set the parameter while the motor is running.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ **6-5* Analog Output 1**

Analog outputs are current outputs: 0/4 - 20 mA. Common terminal (terminal 39) is the same terminal and electrical potential for analog common and digital common connection. Resolution on analog output is 12 bit.



6-50 Terminal 42 Output

Option:

No operation	[0]
MCO controlled	[51]
Output frequency (0 - 1000 Hz), 0...20mA	[100]
Output frequency (0 - 1000 Hz), 4...20 mA	[101]
Reference (Ref min-max), 0...20 mA	[102]
Reference (Ref min-max), 4...20 mA	[103]
Feedback (FB min-max), 0...20 mA	[104]
Feedback (FB min-max), 4...20 mA	[105]
Motor current (0-Imax), 0...20 mA	[106]
Motor current (0-Imax), 4...20 mA	[107]
Torque relative to limit 0-Tlim, 0...20 mA	[108]
Torque relative to limit 0-Tlim, 4...20 mA	[109]
Torque relative to rated 0-Tnom, 0...20 mA	[110]
Torque relative to rated 0-Tnom, 4...20 mA	[111]
Power (0-Pnom), 0...20 mA	[112]
Power (0-Pnom), 4...20 mA	[113]
Speed (0-Speedmax), 0...20 mA	[114]
Speed (0-Speedmax), 4...20 mA	[115]
Torque (+/-160% torque), 0-20 mA	[116]
Torque (+/-160% torque), 4-20 mA	[117]
Output freq. 4-20mA	[130]
Reference 4-20mA	[131]
Feedback 4-20mA	[132]
Motor cur. 4-20mA	[133]
Torque % lim. 4-20mA	[134]
Torque % nom 4-20mA	[135]
Power 4-20mA	[136]
Speed 4-20mA	[137]
Torque 4-20mA	[138]


6-51 Terminal 42 Output Min Scale

Range:

000 - 100% *0%

Function:

Scales the minimum output of the selected analog signal on terminal 42. Scale the minimum value as a percentage of the maximum signal value, i.e. 0mA (or 0 Hz) is desired at 25% of the maximum output value, and 25% is programmed. The value can never be higher than the corresponding setting in par. 6-52 if value is below 100%.



6-52 Terminal 42 Output Max Scale

Range:

000 - 500% *100%

Function:


Scales the maximum output of the selected analog signal on terminal 42. Set the value to the desired maximum value of the current signal output. Scale the output to give a lower current than 20 mA at full scale or 20 mA at an output below 100% of the maximum signal value. If 20 mA is the desired output current at a value between 0 - 100% of the full-scale output, program the percentage value in the parameter, i.e. 50% = 20 mA. If a current between 4 and 20 mA is desired at maximum output (100%), calculate the percentage value as follows:

$$20 \text{ mA} / \text{desired maximum current} * 100\%$$

$$\text{i.e. } 10 \text{ mA} = \frac{20}{10} * 100 = 200\%$$

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



* default setting () display text [] value for use in communication via serial communication port

□ **Parameters: Controllers**

□ **7-0* Speed PID Ctrl.**

7-00 Speed PID Feedback Source

Option:

* Motor feedb. P1-02	[0]
24V encoder	[1]
MCB 102	[2]

Function:

Selection of encoder for closed-loop feedback. Par. 7-00 cannot be adjusted while the motor is running.

7-02 Speed PID ProportionalGain

Range:

0.000 - 1.000 * 0.015

Function:

Indicates how many times to amplify the error (deviation between the feedback signal and the setpoint). It is used with *Speed control, closed loop*, and *Speed control, open loop* (par. 1-00). Quick control is obtained at high amplification. If the amplification is too high, the process may become unstable.

7-03 Speed PID Integral Time

Range:

2.0 - 20000.0 ms * 8.0ms

Function:

Determines how long the internal PID controller takes to correct the error. The greater the error, the quicker the gain increases. The integral time causes a delay of the signal and therefore a dampening effect. It is used together with *Speed control, closed loop* and *Speed control, open loop Flux control* (par. 1-00). Obtain quick control through a short integral time. However, if this time is too short, the process becomes unstable. If the integral time is long, major deviations from the required reference may occur, since the process regulator takes long to regulate if an error has occurred.

7-04 Speed PID Differentiation Time

Range:

0.0 - 200.0 ms * 30.0ms

Function:

The differentiator does not react to a constant error. It only provides a gain if the error changes. The quicker the error changes, the stronger the gain from the differentiator. The gain is proportional to the speed at which errors change. It is used together with *Speed control, closed loop* (par. 1-00).

7-05 Speed PID Diff Gain Limit

Range:

1.000 - 20.000 * 5.000

Function:

It is possible to set a limit for the gain provided by the differentiator. Since the D-gain increases at higher frequencies, limiting the gain may be useful. Thus you can obtain a pure D-link at low frequencies and a constant D-link at higher frequencies. It is used with *Speed Control, Closed Loop* (par. 1-00).

7-06 Speed PID Lowpass Filter Time

Range:

1.0 - 100.0 ms * 10.0ms


Function:

The low-pass filter reduces the influence on control and dampens oscillations on the feedback signal. This is an advantage, e.g. if there is a great amount of noise in the system. See illustration. It is used with *Speed control, closed loop* and *Torque control, speed feedback* (par. 1-00). If a time constant ($\hat{\delta}$) e.g. of 100 ms is programmed, the cut-off frequency for the low-pass filter will be $1/0.1 = 10 \text{ RAD/sec.}$, corresponding to $(10/2 \times \pi) = 1.6 \text{ Hz}$. The PID regulator only regulates a feedback signal that varies by a frequency of less than 1.6 Hz. If the feedback signal varies by a higher frequency than 1.6 Hz, the PID regulator does not react.



* default setting () display text [] value for use in communication via serial communication port

— How to Program —



□ **7-2* Process Ctrl. Feedb.**

Select which resources should be used for feedback to the Process PID Control and how this feedback should be handled.

7-20 Process CL Feedback 1 Resource

Option:

- *No function [0]
- Analog input 53 [1]
- Analog input 54 [2]
- Frequency input 29 [3]
- Frequency input 33 [4]

Function:

It is possible to add up to two different feedback signals to compose the actual feedback. This parameter defines which input on the frequency converter should be treated as the source of the first feedback signal.

7-22 Process CL Feedback 2 Resource

Option:

- *No function [0]
- Analog input 53 [1]
- Analog input 54 [2]
- Frequency input 29 [3]
- Frequency input 33 [4]

Function:

It is possible to add up to two different feedback signals to compose the actual feedback. This parameter defines which input on the adjustable frequency drive should be treated as the source of the first feedback signal.

□ **7-3* Process PID Ctrl.**

Parameters for configuring the Process PID control.

7-30 Process PID Normal/Inverse Control

Option:

- *Normal [0]
- Inverse [1]

Function:

It is possible to choose whether the process control is to increase/reduce the output frequency. This is done by having a difference between the reference signal and the feedback signal.

7-31 Process PID Anti Windup

Option:

- *Off [0]
- On [1]

Function:

It is possible to select whether the process control is to continue regulating on an error even if it is not possible to increase/reduce the output frequency.

7-32 Process PID Start Speed

Range:

0 - 6000 RPM *0 RPM

Function:

When the start signal is given, the adjustable frequency drive will react with a *Speed control, open loop* following the ramp. Only when the programmed start speed has been obtained will it change to *Process control*.

7-33 Process PID Proportional Gain

Range:

0.00 - 10.00 N/A *0.01 N/A

Function:

The proportional gain indicates the number of times the error between the set point and the feedback signal is to be applied.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

**7-34 Process PID Integral Time****Range:**

0.01 - 10000.00 *10000.00 s

Function:

The integrator provides an increasing gain at a constant error between the setpoint and the feedback signal. The integral time needed by the integrator to reach the same gain as the proportional gain.

7-35 Process PID Differentiation Time**Range:**

0.00 - 10.00 s *0.00 s

Function:

The differentiator does not react to a constant error. It only provides a gain when the error changes. The quicker the error changes, the stronger the gain from the differentiator.

7-36 Process PID Differentiation Gain Limit**Range:**

1.0 - 50.0 N/A *5.0 N/A

Function:

Set a limit for the differentiator gain (DG). The DG will increase if there are fast changes. Limit the DG to obtain a pure differentiator gain at slow changes and a constant differentiator gain where quick changes occur.

7-38 Process PID Feed Forward Factor**Range:**

0 - 500% *0%

Function:

The FF factor sends a large or small part of the reference signal around the PID control. In this way, the PID control only affects part of the control signal. Any change of this parameter will thus have an effect on the motor speed. The FF factor provides high dynamics when changing the setpoint and less overshoot.

Par. 7-38 is active when par. 1-00 *Configuration Mode* is set to [3] Process open-loop

7-39 On Reference Bandwidth**Range:**

0 - 200% *5%

Function:

When the PID Control Error (the difference between the reference and the feedback) is less than the set value of this parameter, the On Reference status bit is high (1).

* default setting () display text [] value for use in communication via serial communication port



□ Parameters: Communications and Options

□ 8-0* General Settings

8-01 Control Site

Option:

*Digital and ctrl. word [2]	[0]
Digital only	[1]
Control word only	[2]

Function:

Specifies the control as either *Digital* inputs, *Control* word, or both. This parameter overrules the settings in par. 8-50 to 8-56.

8-02 Control Word Source

Option:

*FC RS-485	[0]
FC USB	[1]
Option A	[2]

Function:

Specifies the source of the control word, serial interface, or installed option. During initial power-up, the adjustable frequency drive automatically sets this parameter to *Option A* if it detects if a valid bus option installed in this slot. If the option is removed, the adjustable frequency drive detects a change in the configuration and sets par. 8-02 back to default setting *FC RS-485*. The adjustable frequency drive trips. If an option is installed after initial power-up, the setting of par. 8-02 does not change but the drive will trip and display: *Alarm 67 Option Change*.

8-03 Control Word Timeout Time

Range:

0.1 - 18000.0 s *1.0s

Function:

Sets the maximum time expected to pass between the reception of two consecutive telegrams. If this time is exceeded, it indicates that serial communication has stopped. The function selected in par. 8-04 will then be carried out.

8-04 Control Word Timeout Function

Option:

*Off	[0]
Freeze Output	[1]

Stop	[2]
Jogging	[3]
Max. Speed	[4]
Stop and trip	[5]
Select set-up 1	[7]
Select set-up 2	[8]
Select set-up 3	[9]
Select set-up 4	[10]

Function:

A valid control word triggers the timeout counter. Acyclic DP V1 does not trigger the timeout counter. The *time-out* function is activated if the control word is not updated within the time specified in par. 8-03 *Control Word Time-out Time*.

- *Off*: Control via serial bus (Fieldbus or standard) resumes and uses the most recent control word.
- *Freeze output frequency*: Freeze output frequency until communication resumes.
- *Stop with auto restart*: Stop with auto restart when communication resumes.
- *Output frequency = JOG freq.:* The motor runs at JOG frequency until communication resumes.
- *Output frequency = Max. freq.:* The motor runs at maximum frequency until communication resumes.
- *Stop with trip*: The motor stops. You need to reset the adjustable frequency drive, see explanation above.

Select set-up x:

This type of timeout function is used for changing set-up on a control word timeout. If communication resumes causing the timeout situation to disappear, par. 8-05 *End-of-time-out Function* defines whether to resume the set-up used before the time-out or to hold the set-up endorsed by the time-out function.

Note that the following parameters have to be configured for the set-up change to occur on a timeout. Par. 0-10 *Active set-up* has to be set to *Multi set-up* along with the relevant linking set in par. 0-12 *This Set-up Linked To*.

8-05 End-of-Timeout Function

Option:

*Hold set-up	[0]
Resume set-up	[1]

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



Function:

Defines the action after receiving a valid control word upon a timeout. This only applies if set-up 1-4 has been selected in par. 8-04.

Hold: The drive holds the set-up selected in par. 8-04 and displays a warning, until par. 8-06 toggles. Then the drive resumes its original set-up.

Resume: The drive resumes the original set-up.

8-06 Reset Control Word Timeout

Option:

- * Do not reset [0]
- Do reset [1]

Function:

Used for returning the drive to the original set-up after a Control word timeout. When setting the value to "Do Reset" [1], it returns to "Do not reset" [0].

8-07 Diagnosis Trigger

Option:

- * Disable [0]
- Trigger on alarms [1]
- Trigger alarms/warn. [2]

Function:

Enables and controls the drive diagnostic function and permits expansion of the diagnostic data to 24 byte.

- *Disable:* Extended diagnostic data are not sent even if they appear in the adjustable frequency drive
- *Trigger on alarms:* Extended diagnostic data are sent when one or more alarms appear in alarm par. 16-04 or 9-53.
- *Trigger alarms/warn:* Extended diagnostic data are sent if one or more alarms/warnings appear in alarm par. 16-04, 9-53, or warning parameter 16-05.

The content of the extended diagnostic frame is as follows:

Byte	Content	Description
0 - 5	Standard DP Diagnostic Data	Standard DP Diagnostic Data
6	PDU length xx	Header of extended diagnostic data
7	Status type = 0x81	Header of extended diagnostic data
8	Slot = 0	Header of extended diagnostic data
9	Status info = 0	Header of extended diagnostic data
10 - 13	VLT par. 16-05	VLT warning word
14 - 17	VLT par. 16-06	VLT status word
18 - 21	VLT par. 16-04	VLT alarm word
22 - 23	VLT par. 9-53	Communication warning word (Profibus)

Enabling diagnostics may cause increased bus traffic. Diagnostic functions are not supported by all fieldbus types.

□ **8-1* Ctrl. Word Settings**

8-10 Control Word Profile

Option:

- * FC profile [0]
- PROFIdrive profile [1]
- ODVA [5]
- CANopen [7]

Function:

Selects the interpretation of the control and status words. The installed option in slot A determines the valid selection.

□ **8-3* FC Port Settings**

8-30 Protocol

Option:

- * FC [0]
- FC MC [1]

Function:

Protocol selection for the FC (standard) port.

8-31 Address

Range:

1 - 126 *1

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



Function:

Address selection for the FC (standard) port.
Valid range: 1 - 126.

8-32 FC Port Baud Rate

Option:

2400 Baud	[0]
4800 Baud	[1]
*9600 Baud	[2]
19200 Baud	[3]
38400 Baud	[4]
115200 Baud	[7]

Function:

Baud rate selection for the FC (standard) port.

8-35 Minimum Response Delay

Range:

1 - 500 ms *10ms

Function:

Specifies a minimum delay time between receiving a request and transmitting a response. This is used for overcoming modem turnaround delays.

8-36 Max Response Delay

Range:

1 - 10000 ms *5000ms

Function:

Specifies a maximum allowed delay time between transmitting a request and expecting a response. Exceeding this delay causes control word timeout.

8-37 Max Inter-Char Delay

Range:

0 - 30 ms *25ms

Function:

Maximum waiting time between two received bytes. It ensures timeout, if transmission is interrupted.

Note: This is only enforced when the FC MC protocol is selected in par. 8-30.

□ **8-5* Digital/Bus**

8-50 Coasting Select

Option:

Digital input	[0]
Bus	[1]
Logic AND	[2]

*Logic OR [3]

Function:

Allows a choice between controlling the coasting function via the terminals (digital input) and/or via the bus.



NOTE

This parameter is active only when par. 8-01 *Control Site* is set to [0] *Digital and control word*.

8-51 Quick Stop Select

Option:

Digital input	[0]
Bus	[1]
Logic AND	[2]
*Logic OR	[3]

Function:

Allows a choice between controlling the Quick stop function via the terminals (digital input) and/or via the bus.



NOTE

This parameter is active only when par. 8-01 *Control Site* is set to [0] *Digital and control word*.

8-52 DC Brake Select

Option:

Digital input	[0]
Bus	[1]
Logic AND	[2]
*Logic OR	[3]

Function:

Allows a choice between controlling the DC brake via the terminals (digital input) and/or via the bus.



NOTE

This parameter is active only when par. 8-01 *Control Site* is set to [0] *Digital and control word*.

8-53 Start Select

Option:

Digital input	[0]
Bus	[1]
Logic AND	[2]
*Logic OR	[3]

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



Function:

Choose between controlling the drive via the terminals (digital input) and/or via the bus. If you select *Bus*, you can only activate the Start command if it is transmitted via the serial communication port or fieldbus option. If you select *Logic AND*, you must also activate the command via one of the digital inputs. If you select *Logic OR*, you can also activate the Start command via one of the digital inputs.



NOTE

This parameter is active only when par. 8-01 *Control Site* is set to [0] *Digital and control word*.

8-54 Reverse Select

Option:

Digital input	[0]
Bus	[1]
Logic AND	[2]
*Logic OR	[3]

Function:

Choose between controlling the drive via the terminals (digital input) and/or via the bus. If you select *Bus*, you can only activate the Reversing command if it is transmitted via the serial communication port or fieldbus option. If you select *Logic AND*, you must also activate the command via one of the digital inputs. If you select *Logic OR*, you can also activate the Reversing command via one of the digital inputs.



NOTE

This parameter is active only when par. 8-01 *Control Site* is set to [0] *Digital and control word*.

8-55 Set-up Select

Option:

Digital input	[0]
Bus	[1]
Logic AND	[2]
*Logic OR	[3]

Function:

Choose between controlling the drive via the terminals (digital input) and/or via the bus. If you select *Bus*, you can only activate Selection of Setup if it is transmitted via the serial

communication port or fieldbus option. If you select *Logic AND*, you must also activate the command via one of the digital inputs. If you select *Logic OR*, you can also activate the Set-up command via one of the digital inputs.



NOTE

This parameter is active only when par. 8-01 *Control Site* is set to [0] *Digital and control word*.

8-56 Preset Reference Select

Option:

Digital input	[0]
Bus	[1]
Logic AND	[2]
*Logic OR	[3]

Function:

Choose between controlling the drive via the terminals (digital input) and/or via the bus. If you select *Bus*, you can only activate the Preset Reference command if it is transmitted via the serial communication port or fieldbus option. If you select *Logic AND*, you must also activate the command via one of the digital inputs. If you select *Logic OR*, you can also activate the Preset Reference command via one of the digital inputs.



NOTE

This parameter is active only when par. 8-01 *Control Site* is set to [0] *Digital and control word*.

□ **8-9* Bus Jog**

8-90 Bus Jog 1 Speed

Range:

0 - par. 4-13 RPM *100RPM

Function:

Sets a fixed speed (jog) activated via the serial port or bus option.

8-91 Bus Jog 2 Speed

Range:

0 - par. 4-13 RPM *200RPM

Function:

Sets a fixed speed (jog) activated via the serial port or bus option

* default setting () display text [] value for use in communication via serial communication port



Parameters: Profibus

9-00 Setpoint

Range:

0 - 65535 * 0
No LCP access

Function:

Receives reference from a Master Class 2. If the control priority is set to Master Class 2, the drive reference is taken from this parameter, whereas the cyclical reference will be ignored.

9-07 Actual Value

Range:

0 - 65535 * 0
No LCP access

Function:

Delivers the MAV for a Master Class 2. The parameter is only valid if the control priority is set to Master Class 2.

9-15 PCD Write Configuration

Array [10]

Option:

- None
- 3-02 Minimum Reference
- 3-03 Maximum Reference
- 3-12 Catch Up/Slow Down Value
- 3-41 Ramp 1 Ramp Up Time
- 3-42 Ramp 1 Ramp Down Time
- 3-51 Ramp 2 Ramp Up Time
- 3-52 Ramp 2 Ramp Down Time
- 3-80 Jog Ramp Time
- 3-81 Quick Stop Ramp Time
- 4-11 Motor Speed Low Limit [RPM]
- 4-13 Motor Speed High Limit [RPM]
- 4-16 Torque Limit Motor Mode
- 4-17 Torque Limit Generator Mode
- 8-90 Bus Jog 1 Speed
- 8-91 Bus Jog 2 Speed
- 16-80 Fieldbus CTW 1
- 16-82 Fieldbus REF 1

Function:

Assigns different parameters to PCD 3 to 10 of the PPOs (the number of PCDs depends on the PPO

type). The values in PCD 3 to 10 are written to the selected parameters as data values.

9-16 PCD Read Configuration

Array [10]

Option:

- None
- 16-00 Control Word
- 16-01 Reference [Unit]
- 16-02 Reference %
- 16-03 Status Word
- 16-05 Main Actual Value [%]
- 16-10 Power [kW]
- 16-11 Power [hp]
- 16-12 Motor Voltage
- 16-13 Frequency
- 16-14 Motor Current
- 16-16 Torque
- 16-17 Speed [RPM]
- 16-18 Motor Thermal
- 16-19 KTY Sensor Temperature
- 16-20 Phase Angle
- 16-30 DC Link Voltage
- 16-32 Brake Energy / s
- 16-33 Brake Energy / 2 min
- 16-34 Heatsink Temp.
- 16-35 Inverter Thermal
- 16-38 SL Controller State
- 16-39 Controlcard Temp.
- 16-50 External Reference
- 16-51 Pulse Reference
- 16-52 Feedback [Unit]
- 16-53 Digi Pot Reference
- 16-60 Digital Input
- 16-61 Terminal 53 Switch Setting
- 16-62 Analog Input 53
- 16-63 Terminal 54 Switch Setting
- 16-64 Analog Input 54
- 16-65 Analog Output 42 [mA]
- 16-66 Digital Output [bin]
- 16-67 Freq. Input #29 [Hz]
- 16-68 Freq. Input #33 [Hz]
- 16-69 Pulse Output #27 [Hz]
- 16-70 Pulse Output #29 [Hz]
- 16-84 Comm Option STW [Binary]
- 16-85 FC port CTW 1 Signal
- 16-90 Alarm Word
- 16-91 Alarm Word 2

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



- 16-92 Warning Word
- 16-93 Warning Word 2
- 16-94 Extended Status Word
- 16-95 Extended Status Word 2

Function:

Assigns different parameters to PCD 3 to 10 of the PPOs (the number of PCDs depends on the PPO type). PCD 3 to 10 holds the actual data value of the selected parameters.

9-18 Node Address

Range:

0 - 126 * 126

Function:

Sets the station address. It is also possible to set it on a hardware switch. Set the address in par. 9-18 only if the hardware switch is set to 126 or 127. The parameter displays the actual setting of the switch when setting the hardware switch to >0 and <126. Power-up or updating par. 9-72 changes par. 9-18.

9-22 Telegram Selection

Option:

Standard telegram 1	[1]
PPO 1	[101]
PPO 2	[102]
PPO 3	[103]
PPO 4	[104]
PPO 5	[105]
PPO 6	[106]
PPO 7	[107]
* PPO 8	[108]

Function:

Instead of using par. 9-15 and 9-16 to define profibus telegrams freely, use standard telegrams defined by the profibus profile. Standard Telegram 1 equals PPO type 3. This parameter is automatically set to the according value (PPO type) when the drive is configured by a PLC.

9-23 Parameters for Signals

Array [1000]

Option:

- None
- 3-02 Minimum Reference
- 3-03 Maximum Reference

- 3-12 Catch Up/Slow Down Value
- 3-41 Ramp 1 Ramp Up Time
- 3-42 Ramp 1 Ramp Down Time
- 3-51 Ramp 2 Ramp Up Time
- 3-52 Ramp 2 Ramp Down Time
- 3-80 Jog Ramp Time
- 3-81 Quick Stop Ramp Rime
- 4-11 Motor Speed Low Limit
- 4-13 Motor Speed High Limit
- 4-16 Torque Limit Motor Mode
- 4-17 Torque Limit Generator Mode
- 8-90 Bus Jog 1 Speed
- 8-91 Bus Jog 2 Speed
- 16-00 Control Word
- 16-01 Reference [Unit]
- 16-02 Reference %
- 16-03 Status Word
- 16-05 Main Actual Value [%]
- 16-10 Power [kW]
- 16-11 Power [hp]
- 16-12 Motor Voltage
- 16-13 Frequency
- 16-14 Motor Current
- 16-16 Torque
- 16-17 Speed [RPM]
- 16-18 Motor Thermal
- 16-19 KTY Sensor Temperature
- 16-20 Phase Angle
- 16-30 DC Link Voltage
- 16-32 Brake Energy / s
- 16-33 Brake Energy / 2 Min
- 16-34 Heatsink Temp.
- 16-35 Inverter Thermal
- 16-38 SL Controller State
- 16-39 Controlcard Temp.
- 16-50 External Reference
- 16-51 Pulse Reference
- 16-52 Feedback [Unit]
- 16-53 Digi Pot Reference
- 16-60 Digital Input
- 16-61 Terminal 53 Switch Setting
- 16-62 Analog Input 53
- 16-63 Terminal 53 Switch Setting
- 16-64 Analog Input 54
- 16-65 Analog Output 42 [mA]
- 16-66 Digital Output [bin]
- 16-67 Freq. Input #29 [Hz]
- 16-68 Freq. Input #33 [Hz]
- 16-69 Pulse Output #27 [Hz]
- 16-70 Pulse Output #29 [Hz]

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



- 16-80 Fieldbus CTW 1
- 16-82 Fieldbus REF 1
- 16-84 Comm Option STW
- 16-85 FC Port CTW 1
- 16-90 Alarm Word
- 16-91 Alarm Word 2
- 16-92 Warning Word
- 16-93 Warning Word 2
- 16-94 Extended Status Word
- 16-95 Extended Status Word 2

Function:

Contains a list of signals that can be entered in par. 9-15 and 9-16. Furthermore, it automatically sets the parameters to meet the most common requirements.

9-27 Parameter Edit

Option:

- Disabled [0]
- *Enabled [1]

Function:

You can edit parameters via Profibus, the standard RS-485 Interface, or the LCP. Disable editing via Profibus with this parameter.

9-28 Process Control

Option:

- Disable [0]
- *Enable cyclic master [1]

Function:

Process control (setting of Control Word, speed reference, and process data) is possible via either Profibus or the standard RS-485 Interface but not both at the same time. Local control is always possible via the LCP. Control via process control is possible with either terminals or bus depending on the setting of par. 8-50 to 8-56.

- Disable: Disables process control via Profibus, and enables process control via standard RS-485.
- Enable cyclic master: Enables process control via Profibus Master Class 1, and disables process control via standard RS-485 bus or Master class 2.

9-44 Fault Message Counter

Range:

0 - 65535 N/A *0 N/A

Function:

Indicates the number of alarms presently stored in par. 9-47. The buffer capacity is maximum eight error events.

9-45 Fault Code

Range:

0 - 0 N/A *0 N/A

Function:

This parameter contains the alarm word from all alarm messages occurred. The buffer capacity is maximum eight error events.

9-47 Fault Number

Range:

0 - 0 N/A *0 N/A

Function:

This parameter contains the alarm number (e.g. 2 for live zero error, 4 for line phase loss) that occurs for an event. The buffer capacity is maximum eight error events.

9-52 Fault Situation Counter

Range:

0 - 1000 N/A *0 N/A

Function:

This parameter contains the number of events presently stored since last reset/power-up. Par. 9-52 is incremented for every event (by AOC or Profibus option).

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



9-53 Profibus Warning Word

Option:

Bit:	Meaning:
0	Connection with DP master is not
1	Timeout action active
2	FDL (Field-bus Data link Layer) is not ok
3	Clear data command received
4	Actual value is not updated
5	baud rate search
6	PROFIBUS ASIC is not transmitting
7	Initializing of PROFIBUS is not ok
8	drive is tripped
9	internal CAN error
10	wrong ID sent by PLC
11	Internal error occurred
12	not configured
13	clear command received
14	warning 34 active

Option:

Read only
Array [10]

Index	Content	Value
[0]	manufacturer	128 (for Danfoss)
[1]	device type	1
[2]	version	xyyy
[3]	firmware date year	yyyy
[4]	firmware date month	ddmm
[5]	no. of axes	variable
[6]	vendor specific :PB Version	xyyy
[7]	vendor-specific : Database Version	xyyy
[8]	vendor-specific : AOC Version	xyyy
[9]	vendor-specific : MOC Version	xyyy

Function:

Displays Profibus communication warnings.

9-63 Actual Baud Rate

Option:

Read-only	
9.6 kbit/s	[0]
19.2 kbit/s	[1]
93.75 kbit/s	[2]
187.5 kbit/s	[3]
500 kbit/s	[4]
1500 kbit/s	[6]
3000 kbit/s	[7]
6000 kbit/s	[8]
12000 kbit/s	[9]
31.25 kbit/s	[10]
45.45 kbit/s	[11]
No baud rate found	[255]

Function:

Displays the actual PROFIBUS baud rate. The Profibus Master automatically sets the baud rate.

9-64 Device Identification

Array [10]

Function:

The device identification parameter. The data type is "Array[n] of Unsigned16". The assignment of the first subindexes is defined and shown in the table above.

9-65 Profile Number

Option:

Read only
0 - 0 * 0

Function:

Contains the profile identification. Byte 1 contains the profile number and byte 2 the version number of the profile.

9-71 Save Data Values

Option:

*Off [0]
Store edit setup [1]
Store all set-ups [2]

Function:

Parameter values changed via Profibus are not automatically stored into non-volatile memory. Use this parameter to activate a function that stores all parameter values in the EEPROM. Thus, you retain changed parameter values at power-down.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



- [0] Off: The store function is inactive.
- [1] Store edit set-up: All parameter values in the set-up selected in par. 9-70 are stored in the EEPROM. The value returns to [0] Off when all values are stored.
- [2] Store all set-ups: All parameter values for all set-ups are stored in the EEPROM. The value returns to [0] Off when all parameter values are stored.

9-70 Edit Set-up

Option:

Factory setup	[0]
*Setup 1	[1]
*Setup 2	[2]
*Setup 3	[3]
*Setup 4	[4]
Active setup	[9]

Function:
 Edit set-up. Editing can either follow the active set-up selection (par. 0-10) or be fixed at a set-up number. This parameter is unique for LCP and buses.

9-72 Drive Reset

Option:

*No action	[0]
Power-on reset	[1]
Power-on reset prep	[2]
Comm. option reset	[3]

Function:
 Resets the drive (as for power-cycle). The drive disappears from the bus, which might cause a communication error from the master.

9-80 Defined Parameters (1)

Array [1000]

Option:

No LCP access	
Read-only	
0 - 9999	*0

Function:
 Holds a list of all the defined drive parameters available for Profibus.

9-81 Defined Parameters (2)

Array [1000]

Option:

No LCP access	
Read-only	
0 - 9999	*0

Function:
 Holds a list of all the defined drive parameters available for Profibus.

9-82 Defined Parameters (3)

Array [1000]

Option:

No LCP access	
Read-only	
0 - 9999	*0

Function:
 Holds a list of all the defined drive parameters available for Profibus.

9-83 Defined Parameters (4)

Array [1000]

Option:

No LCP access	
Read-only	
0 - 9999	*0

Function:
 Holds a list of all the defined drive parameters available for Profibus.

9-90 Changed Parameters (1)

Array [1000]

Option:

No LCP access	
Read-only	
0 - 9999	*0

Function:
 Holds a list of all the drive parameters deviating from default setting.

* default setting () display text [] value for use in communication via serial communication port

**9-91 Changed Parameters (2)**

Array [1000]

Option:

No LCP access

Read-only

0 - 9999 *0

Function:

Holds a list of all the drive parameters deviating from default setting.

9-92 Changed Parameters (3)

Array [1000]

Option:

No LCP access

Read-only

0 - 9999 *0

Function:

Holds a list of all the drive parameters deviating from default setting.

9-93 Changed Parameters (4)

Array [1000]

Option:

No LCP access

Read-only

0 - 9999 *0

Function:

Holds a list of all the drive parameters deviating from default setting.

* default setting () display text [] value for use in communication via serial communication port



□ **Parameters: DeviceNet CAN Fieldbus**

□ **10-0* Common Settings**

10-00 CAN Protocol

Option:
 *DeviceNet [1]

Function:
 Selection of CAN protocol.

10-01 Baud Rate Select

Option:
 *125 Kbps [20]
 250 Kbps [21]
 500 Kbps [22]

Function:
 Selection of the DeviceNet transmission speed. The selection must correspond to the transmission speed of the master and the other DeviceNet nodes.

10-02 MAC ID

Option:
 0 - 127 N/A *63 N/A

Function:
 Selection of station address. Every station connected to the same DeviceNet network must have an unambiguous address.

10-05 Readout Transmit Error Counter

Range:
 0 - 255 *0

Function:
 A readout of the Transmit Error Counter of the CAN controller since the last power-up.

10-06 Readout Receive Error Counter

Range:
 0 - 255 *0

Function:
 Displays the Receive Error Counter of the CAN controller since the last power-up.

10-07 Readout Bus Off Counter

Range:
 0 - 1000 *0

Function:

Displays the number of Bus Off events since the last power-up.

□ **10-1* DeviceNet**

10-10 Process Data Type Selection

Option:
 Instance 100/150 [0]
 Instance 101/151 [1]
 Instance 20/70 [2]
 Instance 21/71 [3]

Function:

Permits selection of 6 different Instances for data transmission. Instances 100/150 and 101/151 are Danfoss-specific. Instance 20/70, 21/71, 22/72, and 23/73 are ODVA-specific AC Drive profiles. A change to this parameter is not executed until the next power-up.

10-11 Process Data Config Write

Option:
 None [0]
 Minimum reference par. 3-02
 Maximum reference par. 3-03
 Catch up/slow down value par. 3-12
 Ramp 1 ramp up time par. 3-41
 Ramp 1 ramp down time par. 3-42
 Ramp 2 ramp up time par. 3-51
 Ramp 2 ramp down time par. 3-52
 Jog ramp time par. 3-80
 Quick stop ramp time par. 3-81
 Motor speed low limit par. 4-11 [RPM]
 Motor speed high limit par. 4-13 [RPM]
 Torque limit motor mode par. 4-16
 Torque limit generator mode par. 4-17
 Bus Jog 1 Speed par. 8-90
 Bus Jog 2 Speed par. 8-91
 Fieldbus CTW 1 par. 16-80
 Fieldbus REF 1 par. 16-82

Function:

Used for the pre-defined I/O assembly Instances. Only 2 elements [1,2] of this array are used. All elements are set to 0 as default.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



10-12 Process Data Config Read

Option:

- None [10]
- Control Word par. 16-00
- Reference [Unit] par. 16-01
- Reference % par. 16-02
- Status Word par. 16-03
- Power [kW] par. 16-10
- Power [hp] par. 16-11
- Motor Voltage par. 16-12
- Frequency par. 16-13
- Motor Current par. 16-14
- Torque par. 16-16
- Speed [RPM] par. 16-17
- Motor thermal par. 16-18
- KTY sensor temperature par. 16-19
- Phase angle par. 16-20
- DC Link Voltage par. 16-30
- BrakeEnergy/s par. 16-30
- BrakeEnergy/2 min par. 16-33
- Heatsink temp. par. 16-34
- Inverter thermal par. 16-35
- SL Controller State par. 16-38
- Controlcard temp. par. 16-39
- External Reference par. 16-50
- Pulse Reference par. 16-51
- Feedback [Unit] par. 16-52
- External Reference par. 16-53
- Terminal 53 Switch Setting par. 16-63
- Analog Input 53 par. 16-62
- Terminal 54 Switch Setting par. 16-63
- Analog Input 54 par. 16-64
- Analog Output 42 [mA] par. 16-65
- Digital Output [bin] par. 16-66
- Freq. input #29 [Hz] par. 16-67
- Freq. input #33 [Hz] par. 16-68
- Pulse output #27 [Hz] par. 16-69
- Pulse output #29 [Hz] par. 16-70
- Comm Option STW par. 16-84
- FC port CTW 1 par. 16-85
- Alarm Word par. 16-90
- Alarm Word 2 par. 16-91
- Warning Word par. 16-92
- Warning Word 2 par. 16-93
- Extended Status Word par. 16-94
- Extended Status Word 2 par. 16-95

Function:

Used for the pre-defined I/O assembly Instances. Only 2 elements [1,2] of this array are used. All elements are set to 0 as default.

10-13 Warning Parameter

Range:

0 - 63 *63

Function:

Reads out warning messages via standard bus or DeviceNet. This parameter is not available via LCP but you can see the warning message by choosing Com warning word as display readout. One bit is assigned to every warning (see manual for list).

Bit:	Meaning:
0	Bus not active
1	Explicit connection timeout
2	I/O connection
3	Retry limit reached
4	Actual is not updated
5	CAN bus off
6	I/O send error
7	Initialization error
8	No bus supply
9	Bus off
10	Error passive
11	Error warning
12	Duplicate MAC ID Error
13	RX queue overrun
14	TX queue overrun
15	CAN overrun

10-14 Net Reference

Option:

- Read-only from LCP.
- *Off [0]
- On [1]

Function:

Enables selection of reference source in Instance 21/71 and 20/70.
 - Off: Enables reference via analog/digital inputs.
 - On: Enables reference via the bus.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



10-15 Net Control

Option:

Read-only from LCP.

- *Off [0]
- On [1]

Function:

Enables selection of control source in Instance 21/71 and 20-70.

- Off: Enables control via analog/digital inputs.
- On: Enables control via the bus.

□ **10-2* COS Filters**

10-20 COS Filter 1

Range:

0 - 65535 *65535

Function:

Sets up the filter mask for the status word. When operating in COS (Change-Of-State), you can filter out bits in the status word that should not be sent if they change.

10-21 COS Filter 2

Range:

0 - 65535 *65535

Function:

Sets up the filter mask for the Main Actual Value. When operating in COS (Change-Of-State), you can filter out bits in the Main actual value that should not be sent if they change.

10-22 COS Filter 3

Range:

0 - 65535 *65535

Function:

Sets up the filter mask for PCD 3. When operating in COS (Change-Of-State), you can filter out bits in PCD 3 that should not be sent if they change.

10-23 COS Filter 4

Range:

0 - 65535 *65535

Function:

Sets up the filter mask for PCD 4. When operating in COS (Change-Of-State), you can filter out bits in PCD 4 that should not be sent if they change.

□ **10-3* Parameter Access**

10-30 Array Index

Range:

0 - 65536 *0

Function:

This parameter is used for accessing indexed parameters.

10-31 Store Data Values

Option:

- *Off [0]
- Store edit setup [1]
- Store all setups [2]

Function:

Par. 10-31 is used to activate storing of data in non-volatile memory.

10-32 Devicenet Revision

Range:

0 - 65535 N/A *0 N/A

Function:

Par. 10-32 is used for EDS file creation.

10-33 Store Always

Option:

- *Off [0]
- On [1]

Function:

This parameter selects if data parameters received on DeviceNet should be stored in EEPROM as default.

10-39 Devicenet F Parameters

Array [1000]

Option:

- No LCP access
- 0 - 0 *0

Function:

This parameter is used to configure the drive via Devicenet and build the EDS file.


* default setting () display text [] value for use in communication via serial communication port

□ **Parameters: Smart logic control**

□ **13-** Prog. Features**

The Smart Logic Controller (SLC) is essentially a sequence of user-defined actions (see par. 13-52) executed by the SLC when the associated user-defined *event* (see par. 13-51) is evaluated as TRUE by the SLC. *Events* and *actions* are each numbered and are linked together in pairs. This means that when *event [0]* is fulfilled (attains the value TRUE), *action [0]* is executed. After this, the conditions of *event [1]* will be evaluated and if evaluated TRUE, *action [1]* will be executed and so on.

Only one *event* will be evaluated at any time. If an *event* is evaluated as FALSE, nothing happens (in the SLC) during the current scan interval and no other *events* will be evaluated. This means that when the SLC starts, it evaluates *event [0]* (and only *event [0]*) each scan interval. Only when *event [0]* is evaluated TRUE will the SLC execute *action [0]* and start evaluating *event [1]*. It is possible to program from 1 to 6 *events* and *actions*. When the last event / action has been executed, the sequence starts over again from *event [0]* / *action [0]*. The illustration shows an example with three events / actions :



Starting and stopping the SLC:

Starting and stopping the SLC can be done by selecting "On [1]" or "Off [0]" in par. 13-50. The SLC always starts in state 0 (where it evaluates *event[0]*). If the drive is stopped or coasted by any means (either via digital input, field bus or other), the SLC automatically stops. If the drive is started by any means (either via digital input,

field bus or other), the SLC also starts (provided that "On [1]" is selected in par. 13-50).

□ **13-0* SLC Settings**

The settings are used for activating, deactivating and resetting the Smart Logic Control.

13-50 SL Controller Mode

Option:

*Off	[0]
On	[1]

Function:

Select *On* [1] to enable the Smart Logic Controller to start when a start command is present (i.e. via a digital input).

13-01 Start Event

Option:

FALSE	[0]
TRUE	[1]
Running	[2]
In range	[3]
On reference	[4]
Torque limit	[5]
Current limit	[6]
Out of current range	[7]
Below I low	[8]
Above I high	[9]
Below speed low	[11]
Above speed high	[12]
Out of feedb. range	[13]
Below feedb. low	[14]
Above feedb. high	[15]
Thermal warning	[16]
Mains out of range	[17]
Reverse	[18]
Warning	[19]
Alarm (trip)	[20]
Alarm (trip lock)	[21]
Comparator 0	[22]
Comparator 1	[23]
Comparator 2	[24]
Comparator 3	[25]
Logic rule 0	[26]
Logic rule 1	[27]
Logic rule 2	[28]
Logic rule 3	[29]
Digital input DI18	[33]
Digital input DI19	[34]
Digital input DI27	[35]

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

Digital input DI29	[36]
Digital input DI32	[37]
Digital input DI33	[38]
Start command	[39]
Drive stopped	[40]

Function:

The list describes the available Boolean (TRUE or FALSE) input for use in the selected logic rule.

- *False [0] (default setting) - enters the fixed value of FALSE in the logic rule.
- True [1] - enters the fixed value TRUE in the logic rule.
- Running [2] - see par. 5-13 for further description.
- In range [3] - see par. 5-31 for further description.
- On reference [4] - see par. 5-31 for further description.
- Torque limit [5] - see par. 5-31 for further description.
- Current limit [6] - see par. 5-31 for further description.
- Out of current range [7] - see par. 5-31 for further description.
- Below I low [8] - see par. 5-31 for further description.
- Above I high [9] - see par. 5-31 for further description.
- Below frequency low [11] - see par. 5-31 for further description.
- Above frequency high [12] - see par. 5-31 for further description.
- Thermal warning [16] - see par. 5-31 for further description.
- Mains out of range [17] - see par. 5-31 for further description.
- Reverse [18] - see par. 5-31 for further description.
- Warning [19] - see par. 5-31 for further description.
- Alarm (trip) [20] - see par. 5-31 for further description.
- Alarm (trip lock) [21] - see par. 5-31 for further description.
- Comparator 0 [22] - use the result of comparator 0 in the logic rule.
- Comparator 1 [23] - use the result of comparator 1 in the logic rule.
- Comparator 2 [24] - use the result of comparator 2 in the logic rule.
- Comparator 3 [25] - use the result of comparator 3 in the logic rule.
- Logic rule 0 [26] - use the result of logic rule 0 in the logic rule.
- Logic rule 1 [27] - use the result of logic rule 1 in the logic rule.
- Logic rule 2 [28] - use the result of logic rule 2 in the logic rule.
- Logic rule 3 [29] - use the result of logic rule 3 in the logic rule.
- Digital input DI18 [33] - use the value of DI18 in the logic rule (High = TRUE).
- Digital input DI19 [34] - use the value of DI19 in the logic rule (High = TRUE).
- Digital input DI27 [35] - use the value of DI27 in the logic rule (High = TRUE).
- Digital input DI29 [36] - use the value of DI29 in the logic rule (High = TRUE).
- Digital input DI32 [37] - use the value of DI32 in the logic rule (High = TRUE).
- Digital input DI33 [38] - use the value of DI33 in the logic rule (High = TRUE).

13-02 Stop Event**Option:**

FALSE	[0]
TRUE	[1]
Running	[2]
In range	[3]
On reference	[4]
Torque limit	[5]
Current limit	[6]
Out of current range	[7]
Below I low	[8]
Above I high	[9]
Below speed low	[11]
Above speed high	[12]
Out of feedb. range	[13]
Below feedb. low	[14]
Above feedb. high	[15]
Thermal warning	[16]
Mains out of range	[17]
Reverse	[18]
Warning	[19]
Alarm (trip)	[20]
Alarm (trip lock)	[21]
Comparator 0	[22]

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



Comparator 1	[23]
Comparator 2	[24]
Comparator 3	[25]
Logic rule 0	[26]
Logic rule 1	[27]
Logic rule 2	[28]
Logic rule 3	[29]
SL Timeout 0	[30]
SL Timeout 1	[31]
SL Timeout 2	[32]
Digital input DI18	[33]
Digital input DI19	[34]
Digital input DI27	[35]
Digital input DI29	[36]
Digital input DI32	[37]
Digital input DI33	[38]
Start command	[39]
Drive stopped	[40]

Function:

The list describes which Boolean input is to define to stop/deactivate the Smart Logic Control.

- *False [0] (default setting) - enters the fixed value of FALSE in the logic rule.
- True [1] - enters the fixed value TRUE in the logic rule.
- Running [2] - see par. 5-13 for further description.
- In range [3] - see par. 5-31 for further description.
- On reference [4] - see par. 5-31 for further description.
- Torque limit [5] - see par. 5-31 for further description.
- Current limit [6] - see par. 5-31 for further description.
- Out of current range [7] - see par. 5-31 for further description.
- Below I low [8] - see par. 5-31 for further description.
- Above I high [9] - see par. 5-31 for further description.
- Below frequency low [11] - see par. 5-31 for further description.
- Above frequency high [12] - see par. 5-31 for further description.
- Thermal warning [16] - see par. 5-31 for further description.
- Mains out of range [17] - see par. 5-31 for further description.

- Reverse [18] - see par. 5-31 for further description.
- Warning [19] - see par. 5-31 for further description.
- Alarm (trip) [20] - see par. 5-31 for further description.
- Alarm (trip lock) [21] - see par. 5-31 for further description.
- Comparator 0 [22] - use the result of comparator 0 in the logic rule.
- Comparator 1 [23] - use the result of comparator 1 in the logic rule.
- Comparator 2 [24] - use the result of comparator 2 in the logic rule.
- Comparator 3 [25] - use the result of comparator 3 in the logic rule.
- Logic rule 0 [26] - use the result of logic rule 0 in the logic rule.
- Logic rule 1 [27] - use the result of logic rule 1 in the logic rule.
- Logic rule 2 [28] - use the result of logic rule 2 in the logic rule.
- Logic rule 3 [29] - use the result of logic rule 3 in the logic rule.
- Digital input DI18 [33] - use the value of DI18 in the logic rule (High = TRUE).
- Digital input DI19 [34] - use the value of DI19 in the logic rule (High = TRUE).
- Digital input DI27 [35] - use the value of DI27 in the logic rule (High = TRUE).
- Digital input DI29 [36] - use the value of DI29 in the logic rule (High = TRUE).
- Digital input DI32 [37] - use the value of DI32 in the logic rule (High = TRUE).
- Digital input DI33 [38] - use the value of DI33 in the logic rule (High = TRUE).

13-03 Reset SLC

Option:

*Do not reset SLC	[0]
Reset SLC	[1]

Function:

Par. 13-03 resets all group 13 parameters (13-*) to default settings.

□ **13-1* Comparators**

Used for comparing continuous variables (i.e. output frequency, output current, analog input etc.) with a fixed preset value. Comparators are evaluated once in each scan interval. You can use the result

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



(TRUE or FALSE) directly to define an event (see par. 13-51), or as Boolean input in a logic rule (see par. 13-40, 13-42, or 13-44). All parameters in this parameter group are array parameters with index 0-3. Select index 0 to program Comparator 0, index 1 to program Comparator 1, and so on.

13-10 Comparator Operand

Array [4]

Option:

*DISABLED	[0]
Reference	[1]
Feedback	[2]
Motor speed	[3]
Motor current	[4]
Motor torque	[5]
Motor power	[6]
Motor voltage	[7]
DC-link voltage	[8]
Motor temperature	[9]
VLT temperature	[10]
Heat sink temperature	[11]
Analog input AI53	[12]
Analog input AI54	[13]
Analog input AIFB10	[14]
Analog input AIS24V	[15]
Analog input AICCT	[17]
Pulse input FI29	[18]
Pulse input FI33	[19]

Function:

Selects the variable monitored by the comparator. The available selection below:

- *DISABLED [0] (factory setting) - the output from the comparator is always FALSE.
- Reference [1] - see par. 16-01 for further description.
- Feedback [2] - see par. 16-52 for further description.
- Motor speed [3] - see par. 16-17 for further description.
- Motor current [4] - see par. 16-14 for further description.
- Motor torque [5] - see par. 16-16 for further description.
- Motor power [6] - see par. 16-10 for further description.

- Motor voltage [7] - see par. 16-12 for further description.
- DC-link voltage [8] - see par. 16-30 for further description.
- Motor temperature [9] - see par. 16-18 for further description.
- VLT temperature [10] - see par. 16-35 for further description.
- Heat sink temperature [11] - see par. 16-34 for further description.
- Analog input AI53 [12] - see par. 16-62 for further description.
- Analog input AI54 [13] - see par. 16-64 for further description.
- Analog input AIFB10 [14] - value of internal 10V supply [V].
- Analog input AIS24V [15] - value of internal 24V supply [V]
- Analog input AICCT [17] - control card temperature [°C].
- Pulse input FI29 [18] - see par. 16-67 for further description.
- Pulse input FI33 [19] - see par. 16-68 for further description.

13-11 Comparator Operator

Array [4]

Option:

<	[0]
*≈	[1]
>	[2]

Function:

Selects the operator used in the comparison. If you select < [0], the result of the evaluation is TRUE, if the variable selected in par. 13-10 is smaller than the fixed value in par. 13-12. The result is FALSE, if the variable selected in par. 13-10 is greater than the fixed value in par. 13-12. If you select > [2] instead, the logic is inverted. If you select ≈ [1], the evaluation is TRUE, if the variable selected in par. 13-10 is approximately equal to the fixed value in par. 13-12.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



13-12 Comparator Value

Array [4]

Range:

-100000.000 - 100000.000 *0.000

Function:

Selects the "trigger level" for the variable monitored by this comparator.

□ **13-2* Timers**

You can use the result (TRUE or FALSE) from *timers* directly to define an *event* (see par. 13-51), or as Boolean input in a *logic rule* (see par. 13-40, 13-42 or 13-44). A timer is only FALSE when started by an action (i.e. "Start timer 1 [29]") until the timer value entered in this parameter is elapsed. Then it becomes TRUE again. All parameters in this parameter group are array parameters with index 0-2. Select index 0 to program Timer 0, index 1 to program Timer 1, and so on.

13-20 SL Controller Timer

Array [3]

Range:

0.00 - 3600.00 s *0.00s

Function:

The value defines the duration of the FALSE output from the programmed timer. A timer is only FALSE if it is started by an action (i.e. *Start timer 1 [29]*) and until the entered timer value is elapsed.

□ **13-4* Logic Rules**

Combines up to three Boolean inputs (TRUE / FALSE inputs) from timers, comparators, digital inputs, status bits, and events using AND, OR, NOT logic operators. Select Boolean inputs for the calculation in par. 13-40, 13-42, and 13-44. Define the operators used to logically combine the selected inputs in par. 13-41 and 13-43.

Priority of calculation

The results of par. 13-40, 13-41, and 13-42 are calculated first. The outcome (TRUE / FALSE) of this calculation is combined with the settings of par. 13-43 and 13-44, yielding the final result (TRUE / FALSE) of the logical rule.

13-40 Logic Rule Boolean 1

Array [4]

Option:

- *False [0]
- True [1]
- Running [2]
- In range [3]
- On reference [4]
- Torque limit [5]
- Current limit [6]
- Out of current range [7]
- Below I low [8]
- Above I high [9]
- Below speed low [11]
- Above speed high [12]
- Thermal warning [16]
- Mains voltage out of range [17]
- Reversing [18]
- Warning [19]
- Alarm (trip) [20]
- Alarm (trip lock) [21]
- Comparator 0 [22]
- Comparator 1 [23]
- Comparator 2 [24]
- Comparator 3 [25]
- Logic rule 0 [26]
- Logic rule 1 [27]
- Logic rule 2 [28]
- Logic rule 3 [29]
- Time-out 0 [30]
- Time-out 1 [31]
- Time-out 2 [32]
- Digital input DI18 [33]
- Digital input DI19 [34]
- Digital input DI27 [35]
- Digital input DI29 [36]
- Digital input DI32 [37]
- Digital input DI33 [38]

Function:

The list describes the available Boolean (TRUE or FALSE) input for use in the selected logic rule.

- *False [0] (default setting) - enters the fixed value of FALSE in the logic rule.
- True [1] - enters the fixed value TRUE in the logic rule.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



- Running [2] - see par. 5-13 for further description.
- In range [3] - see par. 5-31 for further description.
- On reference [4] - see par. 5-31 for further description.
- Torque limit [5] - see par. 5-31 for further description.
- Current limit [6] - see par. 5-31 for further description.
- Out of current range [7] - see par. 5-31 for further description.
- Below I low [8] - see par. 5-31 for further description.
- Above I high [9] - see par. 5-31 for further description.
- Below frequency low [11] - see par. 5-31 for further description.
- Above frequency high [12] - see par. 5-31 for further description.
- Thermal warning [16] - see par. 5-31 for further description.
- Mains voltage out of range [17] - see par. 5-31 for further description.
- Reversing [18] - see par. 5-31 for further description.
- Warning [19] - see par. 5-31 for further description.
- Alarm (trip) [20] - see par. 5-31 for further description.
- Alarm (trip lock) [21] - see par. 5-31 for further description.
- Comparator 0 [22] - use the result of comparator 0 in the logic rule.
- Comparator 1 [23] - use the result of comparator 1 in the logic rule.
- Comparator 2 [24] - use the result of comparator 2 in the logic rule.
- Comparator 3 [25] - use the result of comparator 3 in the logic rule.
- Logic rule 0 [26] - use the result of logic rule 0 in the logic rule.
- Logic rule 1 [27] - use the result of logic rule 1 in the logic rule.
- Logic rule 2 [28] - use the result of logic rule 2 in the logic rule.
- Logic rule 3 [29] - use the result of logic rule 3 in the logic rule.
- Time-out 0 [30] - use the result of timer 0 in the logic rule.

- Time-out 1 [31] - use the result of timer 1 in the logic rule.
- Time-out 2 [32] - use the result of timer 2 in the logic rule.
- Digital input DI18 [33] - use the value of DI18 in the logic rule (High = TRUE).
- Digital input DI19 [34] - use the value of DI19 in the logic rule (High = TRUE).
- Digital input DI27 [35] - use the value of DI27 in the logic rule (High = TRUE).
- Digital input DI29 [36] - use the value of DI29 in the logic rule (High = TRUE).
- Digital input DI32 [37] - use the value of DI32 in the logic rule (High = TRUE).
- Digital input DI33 [38] - use the value of DI33 in the logic rule (High = TRUE).

13-41 Logic Rule Operator 1

Array [4]

Option:

* Disabled	[0]
And	[1]
Or	[2]
And not	[3]
Or not	[4]
Not and	[5]
Not or	[6]
Not and not	[7]
Not or not	[8]

Function:

Selects the logical operator to use on the Boolean inputs from par. 13-40 and 13-42. [13 -XX] signifies the Boolean input of par. 13-*

- DISABLED [0] - select this option to ignore par. 13-42, 13-43, and 13-44.
- AND [1] - evaluates the expression [13-40] AND [13-42].
- OR [2] - evaluates the expression [13-40] OR [13-42].
- AND NOT [3] - evaluates the expression [13-40] AND NOT [13-42].
- OR NOT [4] - evaluates the expression [13-40] OR NOT [13-42].
- NOT AND [5] - evaluates the expression NOT [13-40] AND [13-42].
- NOT OR [6] - evaluates the expression NOT [13-40] OR [13-42].

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

- NOT AND NOT [7] - evaluates the expression NOT [13-40] AND NOT [13-42].
- NOT OR NOT [8] - evaluates the expression NOT [13-40] OR NOT [13-42].

13-42 Logic Rule Boolean 2

Array [4]

Option:

*False	[0]
True	[1]
Running	[2]
In range	[3]
On reference	[4]
Torque limit	[5]
Current limit	[6]
Out of current range	[7]
Below I low	[8]
Above I high	[9]
Below speed low	[11]
Above speed high	[12]
Thermal warning	[16]
Mains voltage out of range	[17]
Reversing	[18]
Warning	[19]
Alarm (trip)	[20]
Alarm (trip lock)	[21]
Comparator 0	[22]
Comparator 1	[23]
Comparator 2	[24]
Comparator 3	[25]
Logic rule 0	[26]
Logic rule 1	[27]
Logic rule 2	[28]
Logic rule 3	[29]
Time-out 0	[30]
Time-out 1	[31]
Time-out 2	[32]
Digital input DI18	[33]
Digital input DI19	[34]
Digital input DI27	[35]
Digital input DI29	[36]
Digital input DI32	[37]
Digital input DI33	[38]

Function:

Same as in par. 13-40.

13-43 Logic Rule Operator 2

Array [4]

Option:

*Disabled	[0]
And	[1]
Or	[2]
And not	[3]
Or not	[4]
Not and	[5]
Not or	[6]
Not and not	[7]
Not or not	[8]

Function:

Selects the logical to be use on the Boolean input calculated in par. 13-40, 13-41, and 13-42, and the Boolean input coming from par. 13-42.

- [13-44] signifies the Boolean input of par. 13-44.
- [13-40/13-42] signifies the Boolean input calculated in par. 13-40, 13-41, and 13-42.
- *DISABLED* [0] (factory setting) - select this option to ignore par. 13-44.
- *AND* [1] - evaluates the expression [13-40/13-42] AND [13-44].
- *OR* [2] - evaluates the expression [13-40/13-42] OR [13-44].
- *AND NOT* [3] - evaluates the expression [13-40/13-42] AND NOT [13-44].
- *OR NOT* [4] - evaluates the expression [13-40/13-42] OR NOT [13-44].
- *NOT AND* [5] - evaluates the expression NOT [13-40/13-42] AND [13-44].
- *NOT OR* [6] - evaluates the expression NOT [13-40/13-42] OR [13-44].
- *NOT AND NOT* [7] - evaluates the expression NOT [13-40/13-42] AND NOT [13-44].
- evaluates *AND NOT* [13-44].
- *NOT OR NOT* [8] - evaluates the expression NOT [13-40/13-42] OR NOT [13-44].



* default setting () display text [] value for use in communication via serial communication port

— How to Program —



13-44 Logic Rule Boolean 3

Array [4]

Option:

*False	[0]
True	[1]
Running	[2]
In range	[3]
On reference	[4]
Torque limit	[5]
Current limit	[6]
Out of current range	[7]
Below I low	[8]
Above I high	[9]
Below speed low	[11]
Above speed high	[12]
Thermal warning	[16]
Mains voltage out of range	[17]
Reversing	[18]
Warning	[19]
Alarm (trip)	[20]
Alarm (trip lock)	[21]
Comparator 0	[22]
Comparator 1	[23]
Comparator 2	[24]
Comparator 3	[25]
Logic rule 0	[26]
Logic rule 1	[27]
Logic rule 2	[28]
Logic rule 3	[29]
Time-out 0	[30]
Time-out 1	[31]
Time-out 2	[32]
Digital input DI18	[33]
Digital input DI19	[34]
Digital input DI27	[35]
Digital input DI29	[36]
Digital input DI32	[37]
Digital input DI33	[38]

Function:

Same as in par. 13-40.

□ **13-5* Smart Logic Controller**

13-51 SL Controller Event

Array [6]

Option:

*False	[0]
---------------	-----

*** default setting () display text [] value for use in communication via serial communication port**

True	[1]
Running	[2]
In range	[3]
On reference	[4]
Torque limit	[5]
Current limit	[6]
Out of current range	[7]
Below I low	[8]
Above I high	[9]
Below speed low	[11]
Above speed high	[12]
Thermal warning	[16]
Mains voltage out of range	[17]
Reversing	[18]
Warning	[19]
Alarm (trip)	[20]
Alarm (trip lock)	[21]
Comparator 0	[22]
Comparator 1	[23]
Comparator 2	[24]
Comparator 3	[25]
Logic rule 0	[26]
Logic rule 1	[27]
Logic rule 2	[28]
Logic rule 3	[29]
Time-out 0	[30]
Time-out 1	[31]
Time-out 2	[32]
Digital input DI18	[33]
Digital input DI19	[34]
Digital input DI27	[35]
Digital input DI29	[36]
Digital input DI32	[37]
Digital input DI33	[38]

Function:

Selects the Boolean input (TRUE or FALSE) to define this event.

- *False [0] - enters the fixed value FALSE in the event.
- True [1] - enters the fixed value TRUE in the event.
- Running [2] - see par. 5-31 for further description.
- In range [3] - see par. 5-31 for further description.
- On reference [4] - see par. 5-31 for further description.

— How to Program —

- Torque limit [5] - see par. 5-31 for further description.
- Current limit [6] - see par. 5-31 for further description.
- Out of current range [7] - see par. 5-31 for further description.
- Above I low [8] - see par. 5-31 for further description.
- Below I high [9] - see par. 5-31 for further description.
- Above frequency low [11] - see par. 5-31 for further description.
- Below frequency high [12] - see par. 5-31 for further description.
- Thermal warning [16] - see par. 5-31 for further description.
- Mains voltage out of range [17] - see par. 5-31 for further description.
- Reversing [18] - see par. 5-31 for further description.
- Warning [19] - see par. 5-31 for further description.
- Alarm (trip) [20] - see par. 5-31 for further description.
- Alarm (trip lock) [21] - see par. 5-31 for further description.
- Comparator 0 [22] - use the result of comparator 0 in the event.
- Comparator 1 [23] - use the result of comparator 1 in the event.
- Comparator 2 [24] - use the result of comparator 2 in the event.
- Comparator 3 [25] - use the result of comparator 3 in the event.
- Logic rule 0 [26] - use the result of logic rule 0 in the event.
- Logic rule 1 [27] - use the result of logic rule 1 in the event.
- Logic rule 2 [28] - use the result of logic rule 2 in the event.
- Logic rule 3 [29] - use the result of logic rule 3 in the event.
- Time-out 0 [30] - use the result of timer 0 in the event.
- Time-out 1 [31] - use the result of timer 1 in the event.
- Time-out 2 [32] - use the result of timer 2 in the event.
- Digital input DI18 [33] - use the value of DI18 in the event (High = TRUE).

- Digital input DI19 [34] - use the value of DI19 in the event (High = TRUE)
- Digital input DI27 [35] - use the value of DI27 in the event (High = TRUE).
- Digital input DI29 [36] - use the value of DI29 in the event (High = TRUE).
- Digital input DI32 [37] - use the value of DI32 in the event (High = TRUE).
- Digital input DI33 [38] - use the value of DI33 in the event (High = TRUE).



13-52 SL Controller Action

Array [6]

Option:

* Disabled	[0]
No action	[1]
Select set-up 0	[2]
Select set-up 1	[3]
Select set-up 2	[4]
Select set-up 3	[5]
Select preset reference 0	[10]
Select preset reference 1	[11]
Select preset reference 2	[12]
Select preset reference 3	[13]
Select preset reference 4	[14]
Select preset reference 5	[15]
Select preset reference 6	[16]
Select preset reference 7	[17]
Select ramp 1	[18]
Select ramp 2	[19]
Select ramp 3	[20]
Select ramp 4	[21]
Run	[22]
Run reverse	[23]
Stop	[24]
Qstop	[25]
Dcstop	[26]
Coast	[27]
Freeze output	[28]
Start timer 0	[29]
Start timer 1	[30]
Start timer 2	[31]
Set digital output A low	[32]
Set digital output B low	[33]
Set digital output C low	[34]
Set digital output D low	[35]
Set digital output E low	[36]
Set digital output F low	[37]

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

Set digital output A high	[38]
Set digital output B high	[39]
Set digital output C high	[40]
Set digital output D high	[41]
Set digital output E high	[42]
Set digital output F high	[43]

Function:

Actions are executed when the corresponding event (defined in par. 13-51) is evaluated as true. The following list of actions is available for selection.

- **DISABLED* [0]
- *No action* [1]
- Select *set-up 1* [2] - changes the active set-up (par. 0-10) to "1".
- Select *set-up 2* [3] - changes the active set-up (par. 0-10) to "2".
- Select *set-up 3* [4] - changes the active set-up (par. 0-10) to "3".
- Select *set-up 4* [5] - changes the active set-up (par. 0-10) to "4". If you change the set-up, it will merge with other set-up commands coming from either the digital inputs or via a fieldbus.
- Select *preset reference 0* [10] - selects preset reference 0.
- Select *preset reference 1* [11] - selects preset reference 1.
- Select *preset reference 2* [12] - selects preset reference 2.
- Select *preset reference 3* [13] - selects preset reference 3.
- Select *preset reference 4* [14] - selects preset reference 4.
- Select *preset reference 5* [15] - selects preset reference 5.
- Select *preset reference 6* [16] - selects preset reference 6.
- Select *preset reference 7* [17] - selects preset reference 7. If you change the active preset reference, it will merge with other preset reference commands coming from either the digital inputs or via a fieldbus.
- Select *ramp 1* [18] - selects ramp 1.
- Select *ramp 2* [19] - selects ramp 2.
- Select *ramp 3* [20] - selects ramp 3.
- Select *ramp 4* [21] - selects ramp 4.
- *Run* [22] - issues a start command to the drive.
- *Run reverse* [23] - issues a start reverse command to the drive.
- *Stop* [24] - issues a stop command to the drive.
- *Qstop* [25] - issues a quick stop command to the drive.
- *Dcstop* [26] - issues a DC stop command to the drive.
- *Coast* [27] - the drive coasts immediately. All stop commands including the coast command stop the SLC.
- *Freeze output* [28] - freezes the output frequency of the drive.
- *Start timer 0* [29] - starts timer 0, see par. 13-20 for further description.
- *Start timer 1* [30] - starts timer 1, see par. 13-20 for further description.
- *Start timer 2* [31] - starts timer 2, see par. 13-20 for further description.
- Set *digital output A low* [32] - any output with "digital output 1" selected is low (open).
- Set *digital output B low* [33] - any output with "digital output 2" selected is low (off).
- Set *digital output C low* [34] - any output with "digital output 3" selected is low (off).
- Set *digital output D low* [35] - any output with "digital output 4" selected is low (off).
- Set *digital output E low* [36] - any output with "digital output 5" selected is low (off).
- Set *digital output F low* [37] - any output with "digital output 6" selected is low (off).
- Set *digital output A high* [38] - any output with "digital output 1" selected is high (closed).
- Set *digital output B high* [39] - any output with "digital output 2" selected is high (closed).
- Set *digital output C high* [40] - any output with "digital output 3" selected is high (closed).
- Set *digital output D high* [41] - any output with "digital output 4" selected is high (closed).
- Set *digital output E high* [42] - any output with "digital output 5" selected is high (closed).
- Set *digital output F high* [43] - any output with "digital output 6" selected is high (closed).

* default setting () display text [] value for use in communication via serial communication port

□ **Parameters: Special functions**

□ **14-0* Inverter Switching**

14-00 Switching Pattern

Option:

60 AVM	[0]
*SFAVM	[1]

Function:

Choose between two different switching patterns: 60° AVM and SFAVM.

14-01 Switching Frequency

Option:

*5.0 kHz	[5]
----------	-----

Function:

Determines the inverter switching frequency. If you change the switching frequency, acoustic noise from the motor is minimized.



NOTE

The output frequency value of the adjustable frequency drive can never be a value higher than 1/10 of the switching frequency.

When the motor is running, adjust the switching frequency in par. 4-11 until the motor is as noiseless as possible. See also par. 14-00 and the section *Derating*.



NOTE

Switching frequencies higher than 5.0 kHz lead to automatic derating of the maximum output of the adjustable frequency drive.

14-03 Overmodulation

Option:

*Off	[0]
On	[1]

Function:

Allows connection of the overmodulation function for the output voltage. *Off* means no overmodulation of the output voltage, and means that torque ripple on the crankshaft is avoided. This feature may be useful e.g. on grinding machines.

On will allow an output voltage greater than the mains voltage (up to 15%).

14-04 PWM Random

Option:

*Off	[0]
On	[1]

Function:

You can transform the audible switching motor noise from a clear ring tone into a less discernable "white" noise by slightly altering (at random) the synchronization of the pulse width modulated output phases.

□ **14-1* Mains On/Off**

14-10 Mains Failure

Option:

*No function	[0]
Controlled alarm suppression	[5]

Function:

Informs the unit of what to do if mains voltage drops below the limit set in par. 14-11. Select **No function* [0] (default setting) if the function is not required.

Controlled alarm suppression [5] - suppress the "undervoltage alarm" and "undervoltage warning"

14-11 Mains Voltage at Mains Fault

Range:

180 - 600 V	*342V
-------------	-------

Function:

Defines the AC voltage level of the selected function in par. 14-10.

14-12 Function at Mains Imbalance

Option:

*Trip	[0]
Warning	[1]

Function:

Select to trip the drive or issue a warning if the drive detects a severe mains imbalance. Operation under severe mains imbalance conditions reduces the life of the unit. It is severe if the drive is operated continuously near nominal load (i.e. running a pump or fan near full speed).



* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ 14-2* Trip Reset

14-20 Reset Mode

Option:

*Manual reset	[0]
Automatic reset x 1	[1]
Automatic reset x 2	[2]
Automatic reset x 3	[3]
Automatic reset x 4	[4]
Automatic reset x 5	[5]
Automatic reset x 6	[6]
Automatic reset x 7	[7]
Automatic reset x 8	[8]
Automatic reset x 9	[9]
Automatic reset x 10	[10]
Automatic reset x 15	[11]
Automatic reset x 20	[12]
Infinite Automatic Reset	[13]

Function:

Selects the reset function after tripping. Upon reset, you can restart the adjustable frequency drive. If you select *Manual reset* [0], carry out reset via [RESET] or via the digital inputs. If you want the adjustable frequency drive to carry out an automatic reset (1-10 times) after tripping, select *data value* [1]-[10].



NOTE

If the number of AUTOMATIC RESETS is reached within 10 minutes, the adjustable frequency drive enters *Manual reset* [0] mode. When a *Manual reset* is performed, the parameter setting is back in force. If the number of AUTOMATIC RESETS is *not* reached within 10 minutes, the internal AUTOMATIC RESET counter is reset. Also, if a *Manual reset* is performed, the internal AUTOMATIC RESET counter is reset.



The motor may start without warning.

14-21 Automatic Restart Time

Range:

0 - 600 s *10s

Function:

Sets the time from tripping until the automatic reset function begins. Select automatic reset in par. 14-20 to program the parameter. Set the desired time.

* default setting () display text [] value for use in communication via serial communication port

14-22 Operation Mode

Option:

*Normal operation	[0]
Control card test	[1]
Initialization	[2]

Function:

Used for two different tests in addition to its normal function. You can also initialize all parameters (except par. 15-03, 15-04 and 15-05). This function is not active until you turn off mains supply to the adjustable frequency drive and then turn it on again. Select *Normal operation* [0] for normal operation with the motor in the selected application. Select *Control card test* [1] to test the analog and digital inputs and outputs and the +10 V control voltage. The test requires a test connector with internal connections.

Use the following procedure for the control card test:

1. Select Control card test.
2. Cut off the mains supply and wait for the light in the display to go out.
3. Set switches S201 (A53) and S202 (A54) = "ON" / I.
4. Insert the test plug (see below).
5. Connect to mains.
6. Carry out various tests.
7. The result is written on the LCP and the drive moves into an infinite loop.
8. Par. 14-22 is automatically set to *Normal operation*.

Carry out a power cycle to start up in *Normal operation* after a control card test.

If the test is OK:


LCP readout:
Control Card OK.
Cut off mains supply and remove the test plug. The green LED on the Control Card is turned on.

If the test fails:

LCP readout:
Control Card I/O failure. Replace the unit or Control card. The red LED on the Control Card is turned on.

Test plugs (connect the following terminals to each other): 18 - 27 - 32; 19 - 29 - 33; 42 - 53 - 54

— How to Program —



Select *Initialization* [2] to reset all parameter values to default setting, (except par. 15-03, 15-04, and 15-05). The drive resets during the next power-up. The parameter also resets to default setting *Normal operation* [0].

14-25 Trip Delay at Torque Limit

Option:
0 - 60 s * 60 s

Function:
When the adjustable frequency drive registers that the output torque has reached the torque limits (par. 4-16 and 4-17) a warning is shown. If this warning is continuously present as long as specified in this parameter, the adjustable frequency drive trips. The feature is disabled by setting the parameter to 60 s = OFF. However, the thermal VLT monitoring is still active.

□ **14-3* Current Limit Ctrl.**

The FC 300 Series features an integral current limit regulator which is activated when the motor current, and thus the torque, is higher than the torque limits set in par. 4-16 and 4-17. When the drive is at the current limit during motor operation or regenerative operation, the adjustable frequency drive will try to get below the preset torque limits as quickly as possible without losing control of the motor. While the current regulator is active, the adjustable frequency drive can only be stopped using any digital input set to *Coast inverse* [2] or *Coast and*

reset inv. [3]. Any signal on terminals 18 to 33 will not be active until the adjustable frequency drive is no longer near the current limit. By using a digital input set to *Coast inverse* [2] or *Coast and reset inv.* [3], the motor does not use the ramp-down time, since the drive is coasted. If a quick stop is necessary, use the mechanical brake control function along with an external electromechanical brake attached to the application.



14-30 Current Lim Cont, Proportional Gain

Option:
0 - 500 % * 100 %

Function:
Controls the proportional gain of the current limit controller. Setting it to a higher value makes it react faster. A setting too high leads to controller instability.

14-31 Current Lim Contr, Integration Time

Option:
0.002 - 2.000 s * 0.020 s

Function:
Controls the current limit controller integration time. Setting it to a lower value makes it react faster. A setting too low leads to controller instability.

□ **14-4* Energy Optimizing**

This group contains parameters for adjusting the energy optimization level in both Variable Torque (VT) and Automatic Energy Optimization (AEO) mode.

14-40 VT Level

Range:
40 - 90% * 66%

Function:
Sets the level of motor magnetization at low speed. A low value results in less energy loss in the motor. Note that the consequence is reduced load capability. Par. 14-40 cannot be adjusted while the motor is running.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



14-41 AEO Minimum Magnetization

Range:

40 - 75% *40%

Function:

Sets the minimum allowable magnetization for AEO. A low value results in less energy loss in the motor. Note that the consequence can be reduced resistance against sudden load changes.

14-42 Minimum AEO Frequency

Range:

5 - 40 Hz *10 Hz

Function:

Sets the minimum frequency at which the Automatic Energy Optimization (AEO) is active.

14-43 Motor Cos-Phi

Range:

0.40 - 0.95 N/A *0.66 N/A

Function:

The Cos(phi) setpoint is automatically set for optimum AEO performance. This parameter should normally not be altered, however, it may in some situations be necessary to fine-tune.

□ **14-5* Environment**

14-50 RFI 1

Option:

Off [0]
*On [1]

Function:

If the drive is supplied from an isolated mains source (IT mains), select *Off* [0]. In this mode, the internal RFI capacities (filter capacitors) between chassis and the intermediate circuit are cut off to avoid damage to the intermediate circuit and to reduce the ground capacity currents (according to IEC 61800-3). Select *On* [1] to comply with EMC standards.

14-52 Fan Control

Option:

*Auto [0]
On 50% [1]
On 75% [2]
On 100% [3]

Function:

Sets the desired continuous speed of internal fan.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ **Parameters: Drive information**

□ **15-0* Operating Data**

15-00 Operating Hours

Range:

0 - 2147483647 h * 0h

Function:

Indicates how long the adjustable frequency drive has run. The value is saved when the unit is turned off.

15-01 Running Hours

Range:

0 - 2147483647 h * 0h

Function:

Indicates how many hours the motor has run. Reset counter in par. 15-07. The value is saved when the unit is turned off.

15-02 kWh Counter

Range:

0 - 2147483647 kWh * 0kWh

Function:

States the power consumption from mains in kWh as a mean value over one hour. Reset counter: Par. 15-06.

15-03 Power-ups

Range:

0 - 2147483647 * 0

Function:

States the number of power-ups to the adjustable frequency drive.

15-04 Over Temps

Range:

0 - 65535 * 0

Function:

States the number of temperature faults on the adjustable frequency drive.

15-05 Over Volts

Range:

0 - 65535 * 0

Function:

States the number of overvoltages on the adjustable frequency drive.

15-06 Reset kWh Counter

Option:

*Do not reset	[0]
Reset counter	[1]

Function:

Reset to zero of kWh hour counter (par. 15-02). Reset the kWh counter by selecting *Reset* [1] and pressing [OK]. You cannot select this parameter via the serial port, RS-485.



NOTE

The reset is carried out by pressing [OK].

15-07 Reset Running Hours Counter

Option:

*Do not reset	[0]
Reset counter	[1]

Function:

Resets the running hours counter to zero (par. 15-01). Reset the running hours counter by selecting *Reset* [1] and pressing [OK]. You cannot select this parameter via the serial port, RS-485.

□ **15-1* Data Log Settings**

The Data Log enables continuous logging of up to 4 data sources (par. 15-10) at individual rates (par. 15-11). A trigger event (par. 15-12) and window (par. 15-14) are used to start and stop the logging conditionally.

15-10 Logging Source

Array [4]

Option:

None
 16-00 Control Word
 16-01 Reference [Unit]
 16-02 Reference %
 16-03 Status Word
 16-10 Power [kW]
 16-11 Power [hp]
 16-12 Motor voltage

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



- 16-13 Frequency
- 16-14 Motor Current
- 16-16 Torque
- 16-17 Speed [RPM]
- 16-18 Motor Thermal
- 16-30 DC Link Voltage
- 16-32 Brake Energy / s
- 16-33 Brake Energy / 2 min
- 16-34 Heatsink Temp.
- 16-35 Inverter Thermal
- 16-50 External Reference
- 16-51 Pulse Reference
- 16-52 Feedback [Unit]
- 16-60 Digital Input
- 16-62 Analog Input 53
- 16-64 Analog Input 54
- 16-65 Analog Output 42 [mA]
- 16-66 Digital Output [bin]
- 16-90 Alarm Word
- 16-92 Warning Word
- 16-94 Ext. Status Word

- Above feedb. high [15]
- Thermal warning [16]
- Mains out of range [17]
- Reverse [18]
- Warning [19]
- Alarm (trip) [20]
- Alarm (trip lock) [21]
- Comparator 0 [22]
- Comparator 1 [23]
- Comparator 2 [24]
- Comparator 3 [25]
- Logic rule 0 [26]
- Logic rule 1 [27]
- Logic rule 2 [28]
- Logic rule 3 [29]
- Digital input DI18 [33]
- Digital input DI19 [34]
- Digital input DI27 [35]
- Digital input DI29 [36]
- Digital input DI32 [37]
- Digital input DI33 [38]

Function:

This parameter selects which variable is logged.

15-11 Logging Interval

Range:

1 - 86400000 ms *1 ms

Function:

Select the interval in milliseconds between each sampling of the variable.

15-12 Trigger Event

Option:

FALSE	[0]
TRUE	[1]
Running	[2]
In range	[3]
On reference	[4]
Torque limit	[5]
Current limit	[6]
Out of current range	[7]
Below I low	[8]
Above I high	[9]
Out of speed range	[10]
Below speed low	[11]
Above speed high	[12]
Out of feedb. range	[13]
Below feedb. low	[14]

Function:

Select the trigger event. If the event occurs, a window is applied to freeze the log. After that, it contains a specified number of samples before and after the occurrence of the trigger event (par. 15-14).

15-13 Logging Mode

Option:

*Log always	[0]
Log once on trigger	[1]

Function:

Select if the logging is continuous (Log always) or conditionally started and stopped (Log once on trigger) (par. 15-12 and 15-14).

15-14 Samples Before Trigger

Range:

0 - 100 N/A *50 N/A

Function:

Specify the percentage of all samples that are logged before the trigger event.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ **15-2* Historic Log**

It is possible to view up to 50 data logs, via these array parameters. [0] is the latest log and [49] the oldest. A data log is made every time an *event* occurs (not to be confused with SLC events). *Events* in this context are defined as a change in one of the following areas:

1. Digital input
2. Digital outputs (not monitored in this SW release)
3. Warning word
4. Alarm word
5. Status word
6. Control word
7. Extended status word

Events are logged with value, and time stamp in msec. The time interval between two events depends on how often *events* occur (maximum once every scan time). Data logging is continuous but if an alarm occurs, the log is saved and the values are available on the display. This is useful, e.g. when carrying out service after a trip. You can read out this parameter via the serial communication port or via the display.

15-20 Historic Log: Event

Array [50]

Range:
0 - 255 *0

Function:
Shows the occurred type of event.

15-21 Historic Log: Value

Array [50]

Range:
0 - 2147483647 * 0

Function:
Shows the value of the logged event. Interpret the event values according to this table:

Digital input	Decimal value. See par. 16-60 for description after converting to binary value.
Digital outputs (not monitored in this SW release)	Decimal value. See par. 16-66 for description after converting to binary value.
Warning word	Decimal value. See par. 16-05 for description.
Alarm word	Decimal value. See par. 16-04 for description.
Status word	Decimal value. See par. 16-03 for description after converting to binary value.
Control word	Decimal value. See par. 16-00 for description.
Extended status word	Decimal value. See par. 16-94 for description.



15-22 Historic Log: Time

Array [50]

Range:
0 - 2147483647 *0

Function:
Shows when the logged event occurred. Time is measured in ms.

□ **15-3* Fault Log**

Array parameters: See up to 10 fault logs via these parameters. [0] is the latest log and [9] the oldest. The error codes, values, and time stamp are available.

15-30 Fault Log: Error Code

Array [10]

Range:
0 - 255 * 0

Function:
Locate the meaning of the error code in section *Troubleshooting*.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



15-31 Fault Log: Value

Array [10]

Range:

-32767 - 32767 * 0

Function:

Describes the error and is mostly used in combination with alarm 38 "internal fault".

15-32 Fault Log: Time

Array [10]

Range:

0 - 2147483647 *0

Function:

Shows when the logged event occurred. Time is measured in s.

□ **15-4* Drive Identification**

15-40 FC Type

Function:

FC type. The readout is equal to the FC 300 Series power field of the type code definition (characters 1-6).

15-41 Power Section

Function:

FC type. The readout equals the FC 300 Series power field of the type code definition (characters 7-10).

15-42 Voltage

Function:

FC type. The readout equals the FC 300 Series power field of the type code definition (characters 11-12).

15-43 Software Version

Function:

Displays the combined SW version (or "package version") consisting of power SW and control SW.

15-44 Ordered Typecode String

Function:

Shows the type code string used for re-ordering the drive in its original configuration.

15-45 Actual Typecode String

Function:

Shows the actual typecode string.

15-46 Adj Freq Dr Ordering No.

Function:

Shows the 8-digit ordering number used for re-ordering the drive in its original configuration.

15-47 Power Card Ordering No.

Function:

Shows the power card ordering number.

15-48 LCP ID Num.

Function:

Shows the LCP ID number.

15-49 SW ID Control Card

Function:

Shows the control card software version number.

15-50 SW ID Power Card

Function:

Shows the power card software version number.

15-51 Adj Freq Dr Serial No.

Function:

Shows the drive serial number.

15-53 Power Card Serial Number

Function:

Shows the power card serial number.

□ **15-6* Option Ident.**

15-60 Option Mounted

Function:

Shows the type code string for the option (AX if no option) and the translation i.e. "No option".

15-61 Option SW Version

Function:

Shows the option slot A software version.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



15-62 Option Ordering No

Function:

Shows the option slot A ordering number.

15-63 Option Serial No

Function:

Shows the option slot A serial number.

15-70 Option in Slot A

Function:

Shows the type code string for the options (CXXXX if no option) and the translation i.e. "No option".

15-71 Slot A Option SW Version

Function:

Shows the option slot C software version.

15-72 Option in Slot B

Function:

Shows the option slot C ordering number.

15-73 Slot B Option SW Version

Function:

Shows the option slot C serial number.

15-74 Option in Slot C

Function:

Shows the typecode string for the options (CXXXX if no option) and the translation i.e. *No option*.

15-75 Slot C Option SW Version

Function:

Shows the type code string for the option (DX if no option) and the translation i.e. "No option".

□ **15-9* Parameter Info**

15-92 Defined Parameters

Array [1000]

Range:

0 - 9999 *0

Function:

Contains a list of all defined parameters in the drive. The list ends with 0.

15-93 Modified Parameters

Array [1000]

Range:

0 - 9999 *0

Function:

Contains a list of the parameters that are changed compared to default setting. The list ends with 0. The list is updated regularly, so a change might not be reflected until after 30s.

15-99 Parameter Metadata

Array [23]

Option:

0 - 9999 *0

Function:

For use by MCT10.

* default setting () display text [] value for use in communication via serial communication port



Parameters: Data readouts

16-0* General Status

16-00 Control Word

Range:

0 - 0 *0

Function:

Gives the present reference value applied on impulse or analog basis in the unit resulting from the choice of configuration in par. 01-00 (Hz, Nm or RPM).

16-01 Reference [Unit]

Range:

-999999.000 - 999999.000 *0.000

Function:

Shows the present value of reference value applied on impulse or analog basis in the unit as a result of the configuration made in par. 01-00 (Hz, Nm or RPM).

16-02 Reference %

Range:

-200.0 - 200.0 % *0.0%

Function:

The value shown corresponds to the total reference (sum of digital/analog/preset/bus/freeze ref./catch up and slow-down).

No	Descriptions	Hex	Warning	Alarm	Trip	Trip Lock
0		00000001				
1		00000002				
2		00000004				
3		00000008				
4		00000010				
5		00000020				
6		00000040				
7		00000080				
8		00000100				
9		00000200				
10		00000400				
11		00000800				
12		00001000				
13		00002000				
14		00004000				
15		00008000				
16		00010000				
17		00020000				
18		00040000				
19		00080000				
20		00100000				

21	00200000
22	00400000
23	00800000
24	01000000
25	02000000
26	04000000
27	08000000
28	10000000
29	20000000
30	40000000
31	80000000

16-03 Status Word

Range:

0 - 0 *0

Function:

Returns the status word sent from the drive via the serial communication port in hex code.

16-05 Main Actual Value [%]

Option:

0 - 0 N/A *N/A

Function:

Two-byte word sent with the Status word to the Bus Master reporting the main actual value. Please refer to the VLT® AutomationDrive FC 300 Profibus Operating Instructions MG.33.CX.YY for detailed description.

16-1* Motor Status

16-10 Power [kW]

Range:

0.0 - 1000.0 kW *0.0kW

Function:

The value shown is calculated on the basis of the actual motor voltage and motor current. The value is filtered. Thus, approx. 1.3 s may pass from when an input changes value until the data readout values change.

16-11 Power [hp]

Range:

0.00 - 1000.00 hp *0.00hp

Function:

The value shown is calculated on the basis of the actual motor voltage and motor current. The value is indicated in the unit of horsepower. The value is filtered. Thus, approx. 1.3 seconds may

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

pass from when an input changes value until the data readout changes values.

16-12 Motor voltage

Range:

0.0 - 6000.0 V *0.0V

Function:

A calculated value used for controlling the motor.

16-13 Frequency

Range:

0.0 - 6500.0 Hz *0.0Hz

Function:

The shown value corresponds to the actual motor frequency (without resonance dampening).

16-14 Motor Current

Range:

0.00 - 0.00 A *0.00A

Function:

The shown value corresponds to the given motor current measured as a mean value IRMS. The value is filtered. Thus, approx. 1.3 s may pass from when an input changes value until the data readout values change.

16-15 Frequency [%]

Range:

0.00 - 0.00 % *0.00%

Function:

A two-byte word reporting the actual motor frequency (without resonance damping) as a percentage (scale 0000-4000 Hex) of par. 4-19 *Max. Output Frequency*. Set par. 9-16 index 1 to have it sent with the Status Word instead of the MAV.

16-16 Torque

Range:

-3000.0 - 3000.0 Nm *0.0Nm

Function:

Shows the torque value with sign, applied to the crankshaft. There is not exact linearity between 160% motor current and torque in relation to the rated torque. Some motors supply more torque than this. Consequently, the min. value and the max value will depend on the max. motor current as

well as the motor used. The value is filtered. Thus, approx. 1.3 seconds may pass from when an input changes value until the data readout values change.

16-17 Speed [RPM]

Range:

0 - 0 RPM *0 RPM

Function:

The value corresponds to the actual motor RPM. The motor RPM is estimated in open loop or closed-loop process control. It is measured in speed closed loop modes.

16-18 Motor Thermal

Range:

0 - 0 % *0 %

Function:

States the calculated/estimated thermal load on the motor. The cut-out limit is 100%. The basis is ETR function (set in par.1-40).

16-20 Motor Angle

Range:

0 - 65535 *0

Function:

The current encoder/resolver angle offset relative to the index position. The value range of 0-65535 corresponds to 0-2*pi (radians).

□ **16-3* Drive Status**

16-30 DC Link Voltage

Range:

0 - 10000 V *0V

Function:

Shows a measured value. The value is filtered. Thus, approx. 1.3 s may pass from when an input value changes until the data readout changes values.

16-32 Brake Energy /s

Range:

0.000 - 0.000 kW *0.000kW

Function:

Returns the brake power transmitted to an external brake resistor. Stated as an instantaneous value.



* default setting () display text [] value for use in communication via serial communication port

— How to Program —



16-33 Brake Energy /2 min

Range:

0.000 - 0.000 kW *0.000kW

Function:

Returns the brake power transmitted to an external brake resistor. The mean power is calculated on an average basis for the latest 120 s.

16-34 Heatsink Temp.

Range:

0 - 0 °C *0°C

Function:

States the drive heat sink temperature. The cut-out limit is 90 ± 5 °C (194 ± 9 °F), while the unit cuts back in at 60 ± 5 °C (140 ± 9 °F).

16-35 Inverter Thermal

Range:

0 - 0 % *0 %

Function:

Returns the percentage load of the inverters.

16-36 Inv. Nom. Current

Range:

0.01 - 100.00 A * A

Function:

The value should equal the nameplate data on the connected motor. The data is used for calculation of torque, motor protection etc. Changing the value in this parameter affects the setting of other parameters.

16-37 Inv. Max. Current

Range:

0.01 - 100.00 A *A

Function:

The value should equal the nameplate data on the connected motor. The data is used for calculation of torque, motor protection etc. Changing the value in this parameter affects the setting of other parameters.

16-38 SL Controller State

Range:

0 - 0 *0

Function:

Returns the state of which event the controller is going to execute.

16-39 Control Card Temp.

Range:

0 - 0 °C *0°C

Function:

Returns the temperature on the control card in degree °C.

16-40 Logging Buffer Full

Option:

*No	[0]
Yes	[1]

Function:

Returns if the Data Log is full (see par. 15-1). The log will never fill when Logging Mode (see par. 15-13) is set to Log always.

□ **16-5* Ref. & Feedb.**

16-50 External Reference

Range:

0.0 - 0.0 *0.0

Function:

Returns the total reference sum of digital/ana-log/preset/bus/freeze ref./catch up and slow-down.

16-51 Pulse Reference

Range:

0.0 - 0.0 *0.0

Function:

Returns the reference value from programmed digital input(s). The readout can also be the impulses from an incremental encoder.

16-52 Feedback [Unit]

Range:

0.0 - 0.0 *0.0

Function:

Gives the resulting feedback value by means of the unit/scaling selected in par. 3-00, 3-01, 3-02 and 3-03.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



16-53 Digi Pot Reference

Range:

0.0 - 0.0 *0.0

Function:

The contribution of the Digital Potentiometer to the actual reference.

□ **16-6* Inputs and Outputs**

16-60 Digital Input

Range:

0 - 0 *0

Function:

Returns the signal states from the active digital inputs. Input 18 corresponds to the bit at the far left. "0" = no signal, "1" = connected signal.

16-61 Terminal 53 Switch Setting

Option:

Current	[0]
Voltage	[1]

Function:

Returns the setting of input terminal 53. Current = 0; Voltage = 1.

16-62 Analog Input 53

Range:

0.000 - 0.000 *0.000

Function:

Returns the actual value on input 53 either as reference or protection value.

16-63 Terminal 54 Switch Setting

Option:

Current	[0]
Voltage	[1]

Function:

Returns the setting of input terminal 54. Current = 0; Voltage = 1.

16-64 Analog Input 54

Range:

0.000 - 0.000 *0.000

Function:

Returns the actual value on input 54 either as reference or protection value.

16-65 Analog Output 42 [mA]

Range:

0.000 - 0.000 *0.000

Function:

Returns the actual value in mA on output 42. Select the shown value in par. 06-50.

16-66 Digital Output [bin]

Range:

0 - 0 *0

Function:

Returns the bin value of all digital outputs.

16-67 Freq. Input #29 [Hz]

Range:

0 - 0 *0

Function:

Returns the actual frequency rate on terminal 29.

16-68 Freq. Input #33 [Hz]

Range:

0 - 0 *0

Function:

Returns the actual value of the frequency applied on terminal 29 as an impulse input.

16-69 Pulse Output #27 [Hz]

Range:

0 - 0 *0

Function:

Returns the actual value of impulses applied to terminal 27 in digital output mode.

16-70 Pulse Output #29 [Hz]

Range:

0 - 0 *0

Function:

Returns the actual value of impulses applied to terminal 29 in digital output mode.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



16-71 Relay Output [bin]

Range:

0 - 31 *0

Function:

Set out the setting of all relays.

16-72 Counter A

Range:

0 - 0 *0

Function:

The present value of Counter A. Counters are useful as a comparator operand (par. 13-10). The value can be reset or changed either via digital inputs (parameter group 5-1*) or by using a SLC action (par. 13-52).

16-73 Counter B

Range:

0 - 0 *0

Function:

The present value of Counter B. Counters are useful as a comparator operand (par. 13-10). The value can be reset or changed either via digital inputs (parameter group 5-1*) or by using a SLC action (par. 13-52).

□ **16-8* Fieldbus & FC Port**

16-80 Fieldbus CTW 1

Range:

0 - 65535 *0

Function:

Two-byte Control word (CTW) received from the Bus Master. Interpretation of the control word depends on the installed bus option and the chosen control word profile (par. 8-10). For more information - see specific fieldbus manual.

16-82 Fieldbus REF 1

Function:

Two-byte word sent with the control word form the Bus Master to set the reference value. For more information - see specific fieldbus manual.

16-84 Comm. Option Status

Range:

0 - 0 *0

Function:

Extended fieldbus comm. option status word. For more information - see specific fieldbus manual.

16-85 FC Port CTW 1

Range:

0 - 0 *0

Function:

Two-byte Control word (CTW) received from the Bus Master. Interpretation of the control word depends on the installed bus option and the chosen control word profile (par. 8-10).

16-86 FC Port REF 1

Range:

0 - 0 *0

Function:

Two-byte status word (STW) sent to the Bus Master. Interpretation of the status word depends on the installed bus option and chosen control word profile (par. 8-10).

□ **16-9* Diagnosis Read-Out**

16-90 Alarm Word

Range:

0 - 4294967295 *0

Function:

Returns the alarm word sent via the serial communication port in hex code.

16-92 Warning Word

Range:

0 - 4294967295 *0

Function:

Returns the warning word sent via the serial communication port in hex code.

* default setting () display text [] value for use in communication via serial communication port

□ **Parameters: Motor Feedb.Option**

□ **17-** Motor Feedb. Option**

Additional parameters to configure the Encoder (MCB102) or the Resolver (MCB103) Feedback Option.

□ **17-1* Inc. Enc. Interface**

Configures the incremental interface of the MCB102 option. Note that both the incremental and absolute interfaces are active at the same time.

17-10 Signal Type

Option:

*TTL (5V, RS422)	[1]
SinCos	[2]

Function:

Select the type of the incremental track (A/B channels) of the encoder in use. Consult your encoder data sheet. Select *None* if the encoder is absolute only.
Par. 17-10 cannot be adjusted while the motor is running.

17-11 Resolution (PPR)

Range:

10 - 10000	*1024
------------	-------

Function:

Set the resolution of the incremental track, i.e. the number of pulses or periods per revolution.
Par. 17-11 cannot be adjusted while the motor is running.

□ **17-2* Abs. Enc. Interface**

Configures the absolute interface of the MCB102 option. Note that both the incremental and absolute interfaces are active at the same time.

17-20 Protocol Selection

Option:

*None	[0]
HIPERFACE	[1]

Function:

Select the absolute encoder data interface. Select *None* if the encoder is incremental only.
Par. 17-20 cannot be adjusted while the motor is running.

17-21 Resolution (Positions/Rev)

Option:

512	[512]
1024	[1024]
2048	[2048]
4096	[4096]
8192	[8192]
16384	[16384]
*32768	[32768]

Function:

Set the resolution of the absolute encoder, i.e. the number of counts per revolution.
Par. 17-21 cannot be adjusted while the motor is running.

17-34 HIPERFACE Baud rate

Option:

600	[0]
1200	[1]
2400	[2]
4800	[3]
*9600	[4]
19200	[5]
38400	[6]

Function:

Enter the baudrate of the attached encoder.
Par. 17-34 cannot be adjusted while the motor is running.

17-60 Encoder Positive Direction

Option:

*Clockwise	[0]
Counterclockwise	[1]

Function:

Changes the detected encoder direction (revolution) without changing the wires to the encoder. Select Clockwise when A channel is 90° (electrical degrees) before channel B by clockwise rotation of the encoder shaft. Select Counterclockwise when A channel is 90° (electrical degrees) after channel B by clockwise rotation of the encoder shaft. Par. 17-60 cannot be changed while the motor is running.



* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ **Parameter lists**

Changes during operation

"TRUE" means that the parameter can be changed while the adjustable frequency drive is in operation and "FALSE" means that the it must be stopped before a change can be made.

4-Set-up

"All set-up": the parameter can be set individually in each of the four set-ups, i. e. one single parameter can have four different data values.

"1 set-up": data value will be the same in all set-ups.

Conversion index

This number refers to a conversion figure used when writing or reading by means of an adjustable frequency drive.

Conv. index	100	67	6	5	4	3	2	1	0	-1	-2	-3	-4	-5	-6
Conv. factor	1	1/60	1000000	100000	10000	1000	100	10	1	0.1	0.01	0.001	0.0001	0.00001	0.000001

Data type	Description	Type
2	Integer 8	Int8
3	Integer 16	Int16
4	Integer 32	Int32
5	Unsigned 8	UInt8
6	Unsigned 16	UInt16
7	Unsigned 32	UInt32
9	Visible String	VisStr
33	Normalized value 2 bytes	N2
35	Bit sequence of 16 Boolean variables	V2
54	Time difference w/o date	TimD

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ **0-** Operation/Display**



Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
0-0* Basic settings						
0-01	Language	[0] English	1 set-up	TRUE	-	Uint8
0-04	Operating state at Power-up (Hand)	[1] Forced stop, ref=old	All set-ups	TRUE	-	Uint8
0-1* Set-up handling						
0-10	Active set-up	[1] Setup 1	1 set-up	TRUE	-	Uint8
0-11	Edit set-up	[1] Setup 1	All set-ups	TRUE	-	Uint8
0-12	This set-up linked to	[1] Setup 1	All set-ups	FALSE	-	Uint8
0-13	Readout: Linked set-ups	0	All set-ups	FALSE	0	Uint16
0-14	Readout: Edit set-ups / channel	0	All set-ups	TRUE	0	Uint32
0-2* LCP Display						
0-20	Display line 1.1 small	[1617] Speed (RPM)	All set-ups	TRUE	-	Uint16
0-21	Display line 1.2 small	[1614] Motor current	All set-ups	TRUE	-	Uint16
0-22	Display line 1.3 small	[1610] Power (kW)	All set-ups	TRUE	-	Uint16
0-23	Display line 2 large	[1613] Frequency	All set-ups	TRUE	-	Uint16
0-24	Display line 3 large	[1602] Reference %	All set-ups	TRUE	-	Uint16
0-25	My personal menu	User dependent	1 set-up	TRUE	0	Uint16
0-4* LCP keypad						
0-40	[Hand on] key on LCP	[1] Enabled	All set-ups	TRUE	-	Uint8
0-41	[Off] key on LCP	[1] Enabled	All set-ups	TRUE	-	Uint8
0-42	[Auto on] key on LCP	[1] Enabled	All set-ups	TRUE	-	Uint8
0-43	[Reset] key on LCP	[1] Enabled	All set-ups	TRUE	-	Uint8
0-5* Copy/Save						
0-50	LCP copy	[0] No copy	All set-ups	FALSE	-	Uint8
0-51	Set-up copy	[0] No copy	All set-ups	FALSE	-	Uint8
0-6* Password						
0-60	Main menu password	100	1 set-up	TRUE	0	Uint16
0-61	Access to main menu w/o password	[0] Full access	1 set-up	TRUE	-	Uint8
0-64	Quick menu password	200	1 set-up	TRUE	0	Uint16
0-66	Access to quick menu w/o password	[0] Full access	1 set-up	TRUE	-	Uint8

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ 1-** Load/Motor



Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
1-0* General settings						
1-00	Configuration mode	[0] Speed open loop	All set-ups	FALSE	-	Uint8
1-01	Motor control principle	[1] VVCplus	All set-ups	FALSE	-	Uint8
1-2* Motor data						
1-20	Motor power [HP]	Drive dependent	All set-ups	FALSE	1	Uint32
1-22	Motor voltage	Drive dependent	All set-ups	FALSE	0	Uint16
1-23	Motor frequency	Drive dependent	All set-ups	FALSE	0	Uint16
1-24	Motor current	Drive dependent	All set-ups	FALSE	-2	Uint16
1-25	Motor nominal speed	Drive dependent	All set-ups	FALSE	67	Uint16
1-29	Automatic motor adaptation(AMA)	[0] Off	All set-ups	FALSE	-	Uint8
1-3* Advanced motor data						
1-30	Stator resistance (Rs)	Motor dependent	All set-ups	FALSE	-4	Uint32
1-31	Rotor resistance (Rr)	Motor dependent	All set-ups	FALSE	-4	Uint32
1-33	Stator leakage reactance (X1)	Motor dependent	All set-ups	FALSE	-4	Uint32
1-34	Rotor leakage reactance (X2)	Motor dependent	All set-ups	FALSE	-4	Uint32
1-35	Main reactance (Xh)	Motor dependent	All set-ups	FALSE	-4	Uint32
1-36	Iron loss resistance (Rfe)	Motor dependent	All set-ups	FALSE	-3	Uint32
1-39	Motor poles	Motor dependent	All set-ups	FALSE	0	Uint8
1-5* Load indep. setting						
1-50	Motor magnetizing at zero speed	100 %	All set-ups	TRUE	0	Uint16
1-51	Min speed normal magnetizing [RPM]	1 RPM	All set-ups	TRUE	67	Uint8
1-6* Load depen. setting						
1-60	Low speed load compensation	100 %	All set-ups	TRUE	0	Int16
1-61	High speed load compensation	100 %	All set-ups	TRUE	0	Int16
1-62	Slip compensation	100 %	All set-ups	TRUE	0	Int16
1-63	Slip compensation time constant	0.10 s	All set-ups	TRUE	-2	Uint16
1-64	Resonance dampening	100 %	All set-ups	TRUE	0	Uint16
1-65	Resonance dampening time constant	5 ms	All set-ups	TRUE	-3	Uint8
1-66	Min. current at low speed	100 %	All set-ups	TRUE	0	Uint8
1-67	Load type	[0] Passive load	All set-ups	TRUE	-	Uint8
1-68	Minimum inertia	Drive dependent	All set-ups	FALSE	-4	Uint32
1-69	Maximum inertia	Drive dependent	All set-ups	FALSE	-4	Uint32
1-7* Start adjustments						
1-71	Start delay	0.0 s	All set-ups	TRUE	-1	Uint8
1-72	Start function	[2] Coast/delay time	All set-ups	TRUE	-	Uint8
1-74	Start speed [RPM]	0 RPM	All set-ups	TRUE	67	Uint16
1-76	Start current	0.00 A	All set-ups	TRUE	-2	Uint16
1-8* Stop adjustments						
1-80	Function at stop	[0] Coast	All set-ups	TRUE	-	Uint8
1-81	Min speed for function at stop [RPM]	0 RPM	All set-ups	TRUE	67	Uint16
1-9* Motor temperature						
1-90	Motor thermal protection	[0] No protection	All set-ups	TRUE	-	Uint8
1-91	Motor external fan	[0] No	All set-ups	TRUE	-	Uint16
1-93	Thermistor source	[0] None	All set-ups	FALSE	-	Uint8

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ **2-** Brakes**



Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
2-0* DC-brake						
2-00	DC hold current	50 %	All set-ups	TRUE	0	Uint8
2-01	DC brake current	50 %	All set-ups	TRUE	0	Uint16
2-02	DC braking time	10.0 s	All set-ups	TRUE	-1	Uint16
2-03	DC brake cut-in speed	0 RPM	All set-ups	TRUE	67	Uint16
2-1* Brake energy funct.						
2-10	Brake and over-voltage functions	[0] Off	All set-ups	TRUE	-	Uint8
2-11	Brake resistor (ohm)	Drive dependent	All set-ups	TRUE	0	Uint16
2-12	Brake power limit (kW)	Drive dependent	All set-ups	TRUE	0	Uint32
2-13	Brake power monitoring	[0] Off	All set-ups	TRUE	-	Uint8
2-15	Brake check	[0] Off	All set-ups	TRUE	-	Uint8
2-2* Mechanical brake						
2-20	Release brake current	0.00 A	All set-ups	TRUE	-2	Uint16
2-21	Activate brake speed [RPM]	0 RPM	All set-ups	TRUE	67	Uint16
2-23	Activate brake delay	0.0 s	All set-ups	TRUE	-1	Uint8

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ 3-** Reference / Ramps



Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
3-0* Reference limits						
3-00	Reference range	[0] Min - Max	All set-ups	TRUE	-	Uint8
3-03	Maximum reference	1500.000 Unit	All set-ups	TRUE	-3	Int32
3-1* References						
3-10	Preset reference	0.00 %	All set-ups	TRUE	-2	Int16
3-12	Catch up/slow down value	0.00 %	All set-ups	TRUE	-2	Int16
3-13	Reference site	[0] Linked to Hand / Auto	All set-ups	FALSE	-	Uint8
3-14	Preset relative reference	0.00 %	All set-ups	TRUE	-2	Int32
3-15	Reference resource 1	[1] Analog input 53	All set-ups	FALSE	-	Uint8
3-16	Reference resource 2	[2] Analog input 54	All set-ups	FALSE	-	Uint8
3-17	Reference resource 3	[11] Local bus reference	All set-ups	FALSE	-	Uint8
3-18	Relative scaling reference resource	[0] No function	All set-ups	FALSE	-	Uint8
3-19	Jog speed	25 RPM	All set-ups	TRUE	67	Uint16
3-4* Ramp 1						
3-40	Ramp 1 type	[0] Linear	All set-ups	TRUE	-	Uint8
3-41	Ramp 1 ramp up time	Drive dependent	All set-ups	TRUE	-2	Uint32
3-42	Ramp 1 ramp down time	Drive dependent	All set-ups	TRUE	-2	Uint32
3-5* Ramp 2						
3-50	Ramp 2 type	[0] Linear	All set-ups	TRUE	-	Uint8
3-51	Ramp 2 ramp up time	Drive dependent	All set-ups	TRUE	-2	Uint32
3-52	Ramp 2 ramp down time	Drive dependent	All set-ups	TRUE	-2	Uint32
3-6* Ramp 3						
3-60	Ramp 3 type	[0] Linear	All set-ups	TRUE	-	Uint8
3-61	Ramp 3 ramp up time	Drive dependent	All set-ups	TRUE	-2	Uint32
3-62	Ramp 3 ramp down time	Drive dependent	All set-ups	TRUE	-2	Uint32
3-7* Ramp 4						
3-70	Ramp 4 type	[0] Linear	All set-ups	TRUE	-	Uint8
3-71	Ramp 4 ramp up time	Drive dependent	All set-ups	TRUE	-2	Uint32
3-72	Ramp 4 ramp down time	Drive dependent	All set-ups	TRUE	-2	Uint32
3-8* Other ramps						
3-80	Jog ramp time	Drive dependent	All set-ups	TRUE	-2	Uint32
3-81	Quick stop ramp time	Drive dependent	1 set-up	TRUE	-2	Uint32
3-9* Digital Pot.Meter						
3-90	Step Size	0.01 %	All set-ups	FALSE	-2	Uint16
3-91	Ramp Time	1.00 s	All set-ups	FALSE	-2	Uint32
3-92	Power Restore	[0] Off	All set-ups	FALSE	-	Uint8
3-93	Limit	100 %	All set-ups	FALSE	0	Uint16

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ **4-** Limits / Warnings**



Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
4-1* Motor limits						
4-10	Motor speed direction	[2] Both directions	All set-ups	FALSE	-	Uint8
4-11	Motor speed low limit [RPM]	0 RPM	All set-ups	TRUE	67	Uint16
4-13	Motor speed high limit [RPM]	3600 RPM	All set-ups	TRUE	67	Uint16
4-16	Torque limit motor mode	160.0 %	All set-ups	TRUE	-1	Uint16
4-17	Torque limit generator mode	160.0 %	All set-ups	TRUE	-1	Uint16
4-18	Current limit	160.0 %	All set-ups	TRUE	-1	Uint16
4-19	Max output frequency	132.0 Hz	All set-ups	FALSE	-1	Uint16
4-5* Adj. warnings						
4-50	Warning current low	0.00 A	All set-ups	TRUE	-2	Uint16
4-51	Warning current high	Par. 16-37	All set-ups	TRUE	-2	Uint16
4-52	Warning speed low	0 RPM	All set-ups	TRUE	67	Uint16
4-53	Warning speed high	Par. 4-13	All set-ups	TRUE	67	Uint16
4-58	Missing motor phase function	[0] Off	All set-ups	FALSE	-	Uint8
4-6* Speed bypass						
4-60	Bypass speed from [RPM]	0 RPM	All set-ups	TRUE	67	Uint16
4-62	Bypass speed to [RPM]	0 RPM	All set-ups	TRUE	67	Uint16

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ 5-** Digital In/Out



Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
5-0* Digital IO mode						
5-00	Digital I/O mode	[0] PNP	All set-ups	FALSE	-	Uint8
5-01	Terminal 27 mode	[0] Input	All set-ups	FALSE	-	Uint8
5-02	Terminal 29 mode	[0] Input	All set-ups	FALSE	-	Uint8
5-1* Digital inputs						
5-10	Terminal 18 digital input	[8] Start	All set-ups	TRUE	-	Uint8
5-11	Terminal 19 digital input	[10] Reverse	All set-ups	TRUE	-	Uint8
5-12	Terminal 27 digital input	[2] Coast inverse	All set-ups	TRUE	-	Uint8
5-13	Terminal 29 digital input	[14] Jog	All set-ups	TRUE	-	Uint8
5-14	Terminal 32 digital input	[24] Set-up select bit 1	All set-ups	TRUE	-	Uint8
5-15	Terminal 33 digital input	[23] Set-up select bit 0	All set-ups	TRUE	-	Uint8
5-3* Digital outputs						
5-30	Terminal 27 digital output	[0] No operation	All set-ups	TRUE	-	Uint8
5-31	Terminal 29 digital output	[0] No operation	All set-ups	TRUE	-	Uint8
5-4* Relays						
5-40	Function relay	[0] No operation	All set-ups	TRUE	-	Uint8
5-41	On delay, relay	0.01 s	All set-ups	TRUE	-2	Uint16
5-42	Off delay, relay	0.01 s	All set-ups	TRUE	-2	Uint16
5-5* Pulse input						
5-50	Term. 29 low frequency	100 Hz	All set-ups	TRUE	0	Uint32
5-51	Term. 29 high frequency	100 Hz	All set-ups	TRUE	0	Uint32
5-52	Term. 29 low ref./feedb. value	0.000 Unit	All set-ups	TRUE	-3	Int32
5-53	Term. 29 high ref./feedb. value	1500.000 Unit	All set-ups	TRUE	-3	Int32
5-54	Pulse filter time constant #29	100 ms	All set-ups	FALSE	-3	Uint16
5-55	Term. 33 low frequency	100 Hz	All set-ups	TRUE	0	Uint32
5-56	Term. 33 high frequency	100 Hz	All set-ups	TRUE	0	Uint32
5-57	Term. 33 low ref./feedb. value	0.000 Unit	All set-ups	TRUE	-3	Int32
5-58	Term. 33 high ref./feedb. value	1500.000 Unit	All set-ups	TRUE	-3	Int32
5-59	Pulse filter time constant #33	100 ms	All set-ups	FALSE	-3	Uint16
5-6* Pulse output						
5-60	Terminal 27 pulse output variable	[0] No operation	All set-ups	FALSE	-	Uint8
5-62	Pulse output maximum frequency #27	5000 Hz	All set-ups	FALSE	0	Uint32
5-63	Terminal 29 pulse output variable	[0] No operation	All set-ups	FALSE	-	Uint8
5-65	Pulse output maximum frequency #29	5000 Hz	All set-ups	FALSE	0	Uint32
5-7* 24V encoder input						
5-70	Term 32/33 encoder resolution	1024	All set-ups	FALSE	0	Uint16
5-71	Term 32/33 encoder direction	[0] Clockwise	All set-ups	FALSE	-	Uint8

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ **6-** Analog In/Out**

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
6-0* Analog IO mode						
6-00	Live zero Timeout Time	10 s	All set-ups	TRUE	0	Uint8
6-01	Live zero Timeout Function	[0] Off	All set-ups	TRUE	-	Uint8
6-1* Analog input 1						
6-10	Terminal 53 low voltage	0.07 V	All set-ups	TRUE	-2	Int16
6-11	Terminal 53 high voltage	10.00 V	All set-ups	TRUE	-2	Int16
6-12	Terminal 53 low current	0.14 mA	All set-ups	TRUE	-5	Int16
6-13	Terminal 53 high current	20.00 mA	All set-ups	TRUE	-5	Int16
6-14	Terminal 53 low ref./feedb. value	0.000 Unit	All set-ups	TRUE	-3	Int32
6-15	Terminal 53 high ref./feedb. value	1500.000 Unit	All set-ups	TRUE	-3	Int32
6-16	Terminal 53 filter time constant	0.001 s	All set-ups	FALSE	-3	Uint16
6-2* Analog input 2						
6-20	Terminal 54 low voltage	0.07 V	All set-ups	TRUE	-2	Int16
6-21	Terminal 54 high voltage	10.00 V	All set-ups	TRUE	-2	Int16
6-22	Terminal 54 low current	0.14 mA	All set-ups	TRUE	-5	Int16
6-23	Terminal 54 high current	20.00 mA	All set-ups	TRUE	-5	Int16
6-24	Terminal 54 low ref./feedb. value	0.000 Unit	All set-ups	TRUE	-3	Int32
6-25	Terminal 54 high ref./feedb. value	1500.000 Unit	All set-ups	TRUE	-3	Int32
6-26	Terminal 54 filter time constant	0.001 s	All set-ups	FALSE	-3	Uint16
6-5* Analog output 1						
6-50	Terminal 42 output	[0] No operation	All set-ups	TRUE	-	Uint8
6-51	Terminal 42 output min scale	0.00 %	All set-ups	TRUE	-2	Int16
6-52	Terminal 42 output max scale	100.00 %	All set-ups	TRUE	-2	Int16

□ **7-** Controllers**

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
7-0* Speed PID ctrl.						
7-02	Speed PID proportional gain	0.015	All set-ups	TRUE	-3	Uint16
7-03	Speed PID Integral Time	Drive dependent	All set-ups	TRUE	-4	Uint32
7-04	Speed PID differentiation time	Drive dependent	All set-ups	TRUE	-4	Uint16
7-05	Speed PID diff. gain Limit	5.0	All set-ups	TRUE	-1	Uint16
7-06	Speed PID lowpass filter time	10.0 ms	All set-ups	TRUE	-4	Uint16

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ **8-** Comm. and options**



Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
8-0* General settings						
8-00	Enabled options	[1] All	All set-ups	FALSE	-	Uint8
8-01	Control site	[0] Digital and ctrl.word	All set-ups	TRUE	-	Uint8
8-02	Controlword source	[0] FC RS485	All set-ups	TRUE	-	Uint8
8-03	Controlword Timeout Time	1.0 s	1 set-up	TRUE	-1	Uint32
8-04	Controlword Timeout Function	[0] Off	1 set-up	FALSE	-	Uint8
8-05	End-of-timeout function	[1] Resume set-up	1 set-up	TRUE	-	Uint8
8-06	Reset Controlword Timeout	[0] Do not reset	All set-ups	TRUE	-	Uint8
8-07	Diagnosis trigger	[0] Disable	2 set-ups	FALSE	-	Uint8
8-1* Ctrl. word settings						
8-10	Control word profile	[0] FC profile	All set-ups	TRUE	-	Uint8
8-3* FC Port settings						
8-30	Protocol	[0] FC	1 set-up	FALSE	-	Uint8
8-31	Address	1	1 set-up	FALSE	0	Uint8
8-32	FC port baudrate	[2] 9600 Baud	1 set-up	FALSE	-	Uint8
8-35	Minimum response delay	10 ms	All set-ups	FALSE	-3	Uint16
8-36	Max response delay	5000 ms	1 set-up	FALSE	-3	Uint16
8-37	Max inter-char delay	25 ms	1 set-up	FALSE	-3	Uint16
8-5* Digital/Bus						
8-50	Coasting select	[3] Logic OR	All set-ups	TRUE	-	Uint8
8-51	Quick stop select	[3] Logic OR	All set-ups	TRUE	-	Uint8
8-52	DC Brake select	[3] Logic OR	All set-ups	TRUE	-	Uint8
8-53	Start select	[3] Logic OR	All set-ups	TRUE	-	Uint8
8-54	Reverse select	[3] Logic OR	All set-ups	TRUE	-	Uint8
8-55	Set-up select	[3] Logic OR	All set-ups	TRUE	-	Uint8
8-56	Preset reference select	[3] Logic OR	All set-ups	TRUE	-	Uint8
8-9* Bus jog						
8-90	Bus Jog 1 Speed	100 RPM	All set-ups	TRUE	67	Uint16
8-91	Bus Jog 2 Speed	200 RPM	All set-ups	TRUE	67	Uint16

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ 9-** Profibus



Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
9-00	Setpoint	0	All setups	TRUE	0	Uint16
9-07	Actual Value	0	All setups	FALSE	0	Uint16
9-15	PCD write configuration	0	1 setup	TRUE	-	Uint16
9-16	PCD read configuration	0	1 setup	TRUE	-	Uint16
9-18	Node address	126	1 setup	TRUE	0	Uint8
9-22	Telegram selection	[1] Standard telegram 1	1 setup	TRUE	-	Uint8
9-23	Parameters for signals	0	All setups	TRUE	-	Uint16
9-27	Parameter edit	[1] Enabled	1 setup	FALSE	-	Uint16
9-28	Process control	[1] Enable cyclic master	1 setup	FALSE	-	Uint8
9-53	Profibus Warning Word	0	All setups	TRUE	0	V2
9-63	Actual baud rate	[255] No baud rate found	All setups	TRUE	-	Uint8
9-64	Device Identification	0	All setups	TRUE	0	Uint16
9-65	Profile number	0	All setups	TRUE	0	Uint8
9-67	Control word 1	0	All setups	TRUE	0	V2
9-68	Status word 1	0	All setups	TRUE	0	V2
9-71	Save Data Values	[0] Off	All setups	TRUE	-	Uint8
9-72	Drive Reset	[0] No action	1 setup	FALSE	-	Uint8
9-80	Defined parameters (1)	0	All setups	FALSE	0	Uint16
9-81	Defined parameters (2)	0	All setups	FALSE	0	Uint16
9-82	Defined parameters (3)	0	All setups	FALSE	0	Uint16
9-83	Defined parameters (4)	0	All setups	FALSE	0	Uint16
9-90	Changed parameters (1)	0	All setups	FALSE	0	Uint16
9-91	Changed parameters (2)	0	All setups	FALSE	0	Uint16
9-92	Changed parameters (3)	0	All setups	FALSE	0	Uint16
9-93	Changed parameters (4)	0	All setups	FALSE	0	Uint16

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ 10-** CAN fieldbus



Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
10-0* Common settings						
10-00	CAN protocol	[1] Device Net	All set-ups	FALSE	-	Uint8
10-01	Baudrate select	[20] 125 Kbps	All set-ups	FALSE	-	Uint8
10-02	MAC ID	63	All set-ups	FALSE	0	Uint8
10-05	Readout Transmit Error Counter	0	All set-ups	TRUE	0	Uint8
10-06	Readout Receive Error Counter	0	All set-ups	TRUE	0	Uint8
10-07	Readout Bus Off Counter	0	All set-ups	TRUE	0	Uint16
10-1* DeviceNet						
10-10	Process data type selection	App. dependent	1 set-up	TRUE	-	Uint8
10-11	Process Data Config Write	0	All set-ups	FALSE	0	Uint8
10-12	Process Data Config Read	0	All set-ups	FALSE	0	Uint8
10-13	Warning Parameter	63	All set-ups	FALSE	0	Uint8
10-14	Net Reference	[0] Off	All set-ups	TRUE	-	Uint8
10-15	Net Control	[0] Off	All set-ups	TRUE	-	Uint8
10-2* COS filters						
10-20	COS Filter 1	65535	All set-ups	FALSE	0	Uint16
10-21	COS Filter 2	65535	All set-ups	FALSE	0	Uint16
10-22	COS Filter 3	65535	All set-ups	FALSE	0	Uint16
10-23	COS Filter 4	65535	All set-ups	FALSE	0	Uint16
10-3* Parameter access						
10-30	Parameter Data Types	[0] Errata 1	All set-ups	TRUE	-	Uint8
10-31	Array index	0	All set-ups	TRUE	0	Uint16
10-39	Devicenet F parameters	0	All set-ups	TRUE	0	Uint32

□ 13-** Smart logic control

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
13-1* Comparators						
13-10	Comparator Operand	[0] DISABLED	2 set-ups	FALSE	-	Uint8
13-11	Comparator Operator	[1] ≈	2 set-ups	FALSE	-	Uint8
13-12	Comparator Value	0.000	2 set-ups	FALSE	-3	Int32
13-2* Timers						
13-20	SL control timer	0.000 s	1 set-up	FALSE	-3	TimD
13-4* Logic rules						
13-40	Logic Rule Boolean 1	[0] False	2 set-ups	FALSE	-	Uint8
13-41	Logic Rule Operator 1	[0] DISABLED	2 set-ups	FALSE	-	Uint8
13-42	Logic Rule Boolean 2	[0] False	2 set-ups	FALSE	-	Uint8
13-43	Logic Rule Operator 2	[0] DISABLED	2 set-ups	FALSE	-	Uint8
13-44	Logic Rule Boolean 3	[0] False	2 set-ups	FALSE	-	Uint8
13-5* Smart logic ctrl.						
13-50	SL control mode	[0] Off	2 set-ups	FALSE	-	Uint8
13-51	SL control event	[0] False	2 set-ups	FALSE	-	Uint8
13-52	SL control action	[0] DISABLED	2 set-ups	FALSE	-	Uint8

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ **14-** Special functions**

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
14-0* Inverter switching						
14-00	Switching Pattern	[1] SFAVM	All set-ups	FALSE	-	Uint8
14-01	Switching Frequency	[5] 5.0 kHz	All set-ups	FALSE	-	Uint8
14-03	Overmodulation	[0] Off	All set-ups	FALSE	-	Uint8
14-04	PWM random	[0] Off	All set-ups	FALSE	-	Uint8
14-1* Electrical power On/Off						
14-10	Electrical failure	[0] No function	All set-ups	FALSE	-	Uint8
14-11	Electrical Voltage at Electrical Fault	342 V	All set-ups	TRUE	0	Uint16
14-12	Function at Electrical Imbalance	[0] Trip	All set-ups	TRUE	-	Uint8
14-2* Trip reset						
14-20	Reset mode	[0] Manual reset	All set-ups	TRUE	-	Uint8
14-21	Automatic restart time	10 s	All set-ups	TRUE	0	Uint16
14-22	Operation mode	[0] Normal operation	All set-ups	TRUE	-	Uint8
14-25	Trip delay at torque limit	60 s = Off	All set-ups	FALSE	0	Uint8
14-29	Service code	0	All set-ups	FALSE	0	Int32
14-3* Current limit ctrl.						
14-30	Current lim cont, Proportional Gain	100 %	All set-ups	FALSE	0	Uint16
14-31	Current lim contr, Integration Time	0.020 s	All set-ups	FALSE	-3	Uint16
14-5* Environment						
14-50	RFI 1	[1] On	1 set-up	FALSE	-	Uint8



* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ **15-** Drive information**



Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
15-0* Operating Data						
15-00	Operating hours	0 h	All set-ups	FALSE	74	Uint32
15-01	Running hours	0 h	All set-ups	FALSE	74	Uint32
15-02	kWh counter	0, kWh	All set-ups	FALSE	75	Uint32
15-03	Power up's	0	All set-ups	FALSE	0	Uint32
15-04	Over temp's	0	All set-ups	FALSE	0	Uint16
15-05	Over volt's	0	All set-ups	FALSE	0	Uint16
15-06	Reset of kWh counter	[0] Do not reset	All set-ups	FALSE	-	Uint8
15-07	Reset running hours counter	[0] Do not reset	All set-ups	FALSE	-	Uint8
15-2* Historic Log						
15-20	Historic log: Event	0	All set-ups	FALSE	0	Uint8
15-21	Historic log: Value	0	All set-ups	FALSE	0	Uint32
15-22	Historic log: Time	0 ms	All set-ups	FALSE	-3	Uint32
15-3* Fault Log						
15-30	Fault log: Error code	0	All set-ups	FALSE	0	Uint8
15-31	Fault log: Value	0	All set-ups	FALSE	0	Int16
15-32	Fault log: Time	0 s	All set-ups	FALSE	0	Uint32
15-4* Drive identification						
15-40	FC type	0	All set-ups	FALSE	0	VisStr[6]
15-41	Power section	0	All set-ups	FALSE	0	VisStr[20]
15-42	Voltage	0	All set-ups	FALSE	0	VisStr[20]
15-43	Software version	0	All set-ups	FALSE	0	VisStr[5]
15-44	Ordered typecode string	0	All set-ups	FALSE	0	VisStr[40]
15-45	Actual typecode string	0	All set-ups	FALSE	0	VisStr[40]
15-46	Drive ordering no	0	All set-ups	FALSE	0	VisStr[8]
15-47	Power card ordering no	0	All set-ups	FALSE	0	VisStr[8]
15-48	LCP Id no	0	All set-ups	FALSE	0	VisStr[20]
15-49	SW id control card	0	All set-ups	FALSE	0	VisStr[20]
15-50	SW id power card	0	All set-ups	FALSE	0	VisStr[20]
15-51	Drive serial number	0	All set-ups	FALSE	0	VisStr[10]
15-53	Power card serial number	0	All set-ups	FALSE	0	VisStr[19]
15-6* Option ident						
15-60	Option in slot A	0	All set-ups	FALSE	0	VisStr[30]
15-61	Slot A option SWversion	0	All set-ups	FALSE	0	VisStr[20]
15-62	Slot A ordering no	0	All set-ups	FALSE	0	VisStr[8]
15-63	Slot A option serial number	0	All set-ups	FALSE	0	VisStr[10]
15-65	Option in slot B	0	All set-ups	FALSE	0	VisStr[30]
15-66	Slot B option SWversion	0	All set-ups	FALSE	0	VisStr[20]
15-67	Slot B ordering no	0	All set-ups	FALSE	0	VisStr[8]
15-68	Slot B option serial number	0	All set-ups	FALSE	0	VisStr[10]
15-70	Option in slot C	0	All set-ups	FALSE	0	VisStr[30]
15-71	Slot C option SWversion	0	All set-ups	FALSE	0	VisStr[20]
15-72	Slot C ordering no	0	All set-ups	FALSE	0	VisStr[8]
15-73	Slot C option serial number	0	All set-ups	FALSE	0	VisStr[10]
15-75	Option in slot D	0	All set-ups	FALSE	0	VisStr[30]
15-9* Parameter info						
15-92	Defined parameters	0	All set-ups	FALSE	0	Uint16
15-93	Modified parameters	0	All set-ups	FALSE	0	Uint16
15-99	Parameter metadata	0	All set-ups	FALSE	0	Uint16

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ 16-** Data readouts



Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
16-0* General status						
16-00	Control Word	0	All set-ups	FALSE	0	V2
16-01	Reference [Unit]	0.000 Unit	All set-ups	FALSE	-3	Int32
16-02	Reference %	0.0 %	All set-ups	FALSE	-1	Int16
16-03	Status word	0	All set-ups	FALSE	0	V2
16-05	Main actual value [%]	0	All set-ups	FALSE	0	N2
16-1* Motor status						
16-10	Power [kW]	0.0 kW	All set-ups	FALSE	2	Uint32
16-11	Power [hp]	0.00 hp	All set-ups	FALSE	-2	Uint32
16-12	Motor voltage	0.0 V	All set-ups	FALSE	-1	Uint16
16-13	Frequency	0.0 Hz	All set-ups	FALSE	-1	Uint16
16-14	Motor current	0.00 A	All set-ups	FALSE	-2	Uint32
16-16	Torque	0.0 Nm	All set-ups	FALSE	-1	Int16
16-17	Speed [RPM]	0 RPM	All set-ups	FALSE	67	Int32
16-18	Motor thermal	0 %	All set-ups	FALSE	0	Uint8
16-3* Drive status						
16-30	DC link Voltage	0 V	All set-ups	FALSE	0	Uint16
16-32	Brake energy /s	0.0 HP	All set-ups	FALSE	0	Uint32
16-33	Brake energy /2 min	0.0 HP	All set-ups	FALSE	0	Uint32
16-34	Heatsink temp.	0 °C	All set-ups	FALSE	100	Uint8
16-35	Inverter thermal	0 %	All set-ups	FALSE	0	Uint8
16-36	InomVLT	Drive dependent	All set-ups	FALSE	-2	Uint16
16-37	ImaxVLT	Drive dependent	All set-ups	FALSE	-2	Uint16
16-38	SL controller state	0	All set-ups	FALSE	0	Uint8
16-39	Controlcard temp.	0 °C	All set-ups	FALSE	100	Uint8
16-5* Ref. & feedb.						
16-50	External reference	0.0	All set-ups	FALSE	-1	Int16
16-51	Pulse reference	0.0	All set-ups	FALSE	-1	Uint32
16-52	Feedback [Unit]	0.000	All set-ups	FALSE	-3	Int32
16-6* Inputs & outputs						
16-60	Digital input	0	All set-ups	FALSE	0	Uint16
16-61	Terminal 53 switch setting	[0] Current	All set-ups	FALSE	-	Uint8
16-62	Analog input 53	0.000	All set-ups	FALSE	-3	Int32
16-63	Terminal 54 switch setting	[0] Current	All set-ups	FALSE	-	Uint8
16-64	Analog input 54	0.000	All set-ups	FALSE	-3	Int32
16-65	Analog output 42 [mA]	0.000	All set-ups	FALSE	-3	Int16
16-66	Digital output [bin]	0	All set-ups	FALSE	0	Int16
16-67	Freq. input #29 [Hz]	0	All set-ups	FALSE	0	Int32
16-68	Freq. input #33 [Hz]	0	All set-ups	FALSE	0	Int32
16-69	Pulse output #27 [Hz]	0	All set-ups	FALSE	0	Int32
16-70	Pulse output #29 [Hz]	0	All set-ups	FALSE	0	Int32
16-8* Fieldbus & FC port						
16-80	Fieldbus CTW 1	0	All set-ups	FALSE	0	V2
16-82	Fieldbus REF 1	0	All set-ups	FALSE	0	N2
16-84	Comm. option STW	0	All set-ups	FALSE	0	V2
16-85	FC port CTW 1	0	All set-ups	FALSE	0	V2
16-86	FC port REF 1	0	All set-ups	FALSE	0	N2
16-9* Diagnosis Readout						
16-90	Alarm word	0	All set-ups	FALSE	0	Uint32
16-92	Warning word	0	All set-ups	FALSE	0	Uint32
16-94	Extended status word	0	All set-ups	FALSE	0	Uint32

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ **17-** Motor Feedb.Option**




Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
17-1* Inc. Enc. Interface							
17-10	Signal Type	[1] TTL (5V, RS422)	All set-ups		FALSE	-	Uint8
17-11	Resolution (PPR)	1024 N/A	All set-ups		FALSE	0	Uint16
17-2* Abs. Enc. Interface							
17-20	Protocol Selection	[0] None	All set-ups		FALSE	-	Uint8
17-21	Resolution (Positions/Rev)	[32768] 32768	All set-ups		FALSE	-	Uint16
17-34	HIPERFACE Baud rate	[4] 9600	All set-ups		FALSE	-	Uint8
17-6* Monitoring and App.							
17-60	Encoder Positive Direction	[0] Clockwise	All set-ups		FALSE	-	Uint8

* default setting () display text [] value for use in communication via serial communication port

□ Serial communication via RS 485 Interface

□ Protocols

Master-slave communication.



□ Telegram Traffic

Control and response telegrams

The master controls telegram traffic in a master-slave system. You can connect a maximum of 31 slaves to a master unless you use repeaters. If so, you can connect a maximum of 126 slaves to a master.

The master constantly sends telegrams addressed to the slaves and waits for their response telegrams. The slave response time is maximum 50 ms.


A slave can only send a response telegram if it has received an error-free telegram addressed to itself.

Broadcast

A master can send the same telegram simultaneously to all slaves connected to the bus. During this broadcast communication, the slave does not send any response telegrams to the master on whether the telegram is correctly received. Broadcast communication is set up in address format (ADR), see *Telegram structure*.


Content of a character (byte)

Each character transferred begins with a start bit. Then 8 data bits are transferred, corresponding to a byte. Each character is secured via a parity bit, which is set to "1" when it reaches parity (i.e. when there is an equal number of 1's in the 8 data bits and the parity bit in total). A character is completed by a stop bit, thus consisting of 11 bits in all.



□ Telegram Structure

Each telegram begins with a start character (STX) = 02 Hex, followed by a byte denoting the telegram length (LGE) and a byte denoting the adjustable frequency drive address (ADR). A number of data bytes (variable, depending on the type of telegram) follow. The telegram is completed by a data control byte (BCC).




* default setting () display text [] value for use in communication via serial communication port

— How to Program —

Telegram timing


The communication speed between a master and a slave depends on the baud rate. The adjustable frequency drive's baud rate must be the same as the master's baud rate (selected in par. 8-32 *FC Port Baud Rate*).



After a response telegram from the slave, make sure there is a pause of at least 2 characters (22 bits) before the master sends a new telegram. At a baud rate of 9600 baud, make sure there is a pause of at least 2.3 ms. When the master has completed the telegram, the slave's response time to the master is maximum of 20 ms. There is a pause of at least 2 characters.

- Pause time, min: 2 characters
- Response time, min: 2 characters
- Response time, max: 20 ms

The time between the individual characters in a telegram may not exceed 2 characters, and the telegram must be completed within 1.5 x nominal telegram time. At a baud rate of 9600 baud and a telegram length of 16 bytes, the telegram is completed after 27.5 ms.



Telegram length (LGE)

The telegram length is the number of data bytes plus the address byte ADR and the data control byte BCC.

The length of telegrams with 4 data bytes is: $LGE = 4 + 1 + 1 = 6$ bytes

The length of telegrams with 12 data bytes is: $LGE = 12 + 1 + 1 = 14$ bytes

The length of telegrams containing texts is 10+n bytes. 10 represents the fixed characters, while the "n" is variable (depending on the length of the text).

Adjustable frequency drive address (ADR)

Two different address formats are used. The adjustable frequency drive's address range is either 1-31 or 1-126.

1. Address format 1-31

The byte for address range 1-31 has the shown profile:


Bit 7 = 0 (address format 1-31 active)

Bit 6 is not used

Bit 5 = 1: Broadcast, address bits (0-4) are not used

Bit 5 = 0: No Broadcast

Bit 0-4 = Adjustable frequency drive address 1-31



* default setting () display text [] value for use in communication via serial communication port

— How to Program —

2. Address format 1-126



The byte for address range 1 - 126 has the shown profile:

- Bit 7 = 1 (address format 1-126 active)
- Bit 0-6 = Adjustable frequency drive address 1-126
- Bit 0-6 = 0 Broadcast

The slave returns the address byte unchanged to the master in the response telegram.

Example:

Writing to adjustable frequency drive address 22 (16H) with address format 1-31:




Data control byte (BCC)

The data control byte is explained in this example: Before the first byte in the telegram is received, the Calculated CheckSum (BCS) is 0.

When the first byte (02H) is received:

BCS = BCC EXOR "first byte"
(EXOR = exclusive-or)

Each subsequent byte gates with BCS EXOR and produces a new BCC, e.g.:




BCS	= 0 0 0 0 0 0 0 0 (00 H)
	EXOR
1. byte	= 0 0 0 0 0 1 0 (02H)
BCC	= 0 0 0 0 0 1 0 (02H)

BCS	= 0 0 0 0 0 1 0 (02H)
	EXOR
2nd byte	= 1 1 0 1 0 1 1 0 (D6H)
BCC	= 1 1 0 1 0 1 0 0 (D4H)

□ **Data Character (byte)**

The structure of data blocks depends on the type of telegram. There are three telegram types, and the type applies for both control telegrams (master=>slave) and response telegrams (slave=>master). The three types of telegram are:

Parameter block: Used to transfer parameters between master and slave. The data block is made up of 12 bytes (6 words) and also contains the process block.




* default setting () display text [] value for use in communication via serial communication port

— How to Program —




Process block: Made up of a data block of four bytes (2 words) and contains:


- Control word and reference value (from master to slave)
- Status word and present output frequency (from slave to master)



Text block is used to read or write texts via the data block.



Parameter commands and responses (AK)



* default setting () display text [] value for use in communication via serial communication port

— How to Program —

Bits no. 12-15 transfers parameter commands from master to slave and returns processed slave responses to the master.



Parameter commands master=>slave				
Bit no.		Parameter command		
15	14	13	12	
0	0	0	0	No command
0	0	0	1	Read parameter value
0	0	1	0	Write parameter value in RAM (word)
0	0	1	1	Write parameter value in RAM (double word)
1	1	0	1	Write parameter value in RAM and EEprom (double word)
1	1	1	0	Write parameter value in RAM and EEprom (word)
1	1	1	1	Read/write text

Response slave=>master				
Bit no.		Response		
15	14	13	12	
0	0	0	0	No response
0	0	0	1	Parameter value transferred (word)
0	0	1	0	Parameter value transferred (double word)
0	1	1	1	Command cannot be performed
1	1	1	1	Text transferred

If the command cannot be performed, the slave sends this response: 0111 *Command cannot be performed* and issues the following fault report in the parameter value (PWE):

Response (0111)	Fault Report
0	The parameter number used does not exist
1	There is no write access to the defined parameter
2	Data value exceeds the parameter's limits
3	The sub index used does not exist
4	The parameter is not the array type
5	The data type does not match the defined parameter
17	Data change in the defined parameter is not possible in the adjustable frequency drive's present mode. Certain parameters can only be changed when the motor is turned off
130	There is no bus access to the defined parameter
131	Data change is not possible because factory Setup is selected

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



Parameter number (PNU)

Bits no. 0-10 transfers parameter numbers. The relevant parameter's function is defined in the parameter description in the chapter *How to Program*.

Index

Index is used together with the parameter number to read/write-access parameters with an index, e.g. par. 15-30 *Error code*. The index consists of 2 bytes - one lowbyte and one highbyte. Only the lowbyte is used as an index.


Example - Index:

The first error code (index [1]) in par. 15-30 *Error Code* must be read.

PKE = 15 FA Hex (read par. 15-30 *Error Code*.)


IND = 0001 Hex - Index no. 1.

The adjustable frequency drive responds in the parameter value block (PWE) with a fault code value from 1 - 99. See *Summary of Warnings and Alarms* to identify the fault code.



Parameter value (PWE)

The parameter value block consists of 2 words (4 bytes), and the value depends on the defined command (AK). If the master prompts for a parameter value, the PWE block does not contain a value.



If you want the master to change a parameter value (write), the new value is written in the PWE block and sent to the slave.

If the slave responds to a parameter request (read command), the present parameter value in the PWE block is transferred and returned to the master.


If a parameter contains not a numerical value but several data options, e.g. par. -001 *Language* where [0] corresponds to *English*, and [4] corresponds to *Danish*, select the data value by entering the value in the PWE block. See *Example - Selecting a data value*.

Via serial communication, it is only possible to read parameters that have data type 9 (text string). Par. 15-40 to 15-33 *Drive Identification* is data type 9. For example, you can read the unit size and mains voltage range in par. 15-40 *FC Type*.

When a text string is transferred (read), the length of the telegram is variable, and the texts are of different lengths. The telegram length is defined in the telegram's second byte, known as LGE.

To read a text via the PWE block, set the parameter command (AK) to "F" Hex.


The index character indicates if the command is read or write. In a read command, the index must have the shown format:



* default setting () display text [] value for use in communication via serial communication port

— How to Program —

Some adjustable frequency drives have parameters in which you can write a text. To write a text via the PWE block, set the parameter command (AK) to "F" Hex. For a write command, the text must have the shown format:



Data types supported by adjustable frequency drive:


Unsigned means that there is no operational sign in the telegram.

Data types	Description
3	Integer 16
4	Integer 32
5	Unsigned 8
6	Unsigned 16
7	Unsigned 32
9	Text string
10	Byte string
13	Time difference
33	Reserved
35	Bit sequence


Example - Write a parameter value:

Change par. 4-14 *Motor Speed High Limit* to 100 Hz. After a mains failure, recall the value to write it in EEPROM.

- PKE = E19E Hex - Write for par. 4-14 *Motor Speed High Limit*
- IND = 0000 Hex
- PWE_{HIGH} = 0000 Hex
- PWE_{LOW} = 03E8 Hex - Data value 1000, corresponding to 100 Hz, see conversion.



The response from the slave to the master will be:



* default setting () display text [] value for use in communication via serial communication port

— How to Program —



Example - Reading a parameter value:

Requires a value in par. 3-41 Ramp 1 Up Time.

The master sends the following request:

PKE = 1155 Hex - read par. 3-41 Ramp 1 Up Time
 IND = 0000 Hex
 PWE_{HIGH} = 0000 Hex
 PWE_{LOW} = 0000 Hex

If the value in par. 3-41 Ramp 1 Up Time is 10 s, the response from the slave to the master is:



Conversion:

The various attributes of each parameter are displayed in section *Factory Settings*. A parameter value is only transferred as a whole number. Thus, use a conversion factor to transfer decimals.


Example:

Par. 4-12 Motor Speed, Low Limit has a conversion factor of 0.1. If you wish to preset the minimum frequency to 10 Hz, transfer the value 100. A conversion factor of 0.1 means that the value transferred is multiplied by 0.1. The value 100 is thus perceived as 10.0.

Conversion table	
Conversion index	Conversion factor
74	0.1
2	100
1	10
0	1
-1	0.1
-2	0.01
-3	0.001
-4	0.0001
-5	0.00001

□ **Process Words**

The block of process words is divided into two blocks of 16 bits, which always occur in the defined sequence.



	PCD 1	PCD 2
Control telegram (master=>slave)	Control word	Reference value
Control telegram (slave=>master)	Status word	Present outp. frequency

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ **Control Word According to FC Profile (CTW)**

To select FC protocol in the control word, set par. 8-10 Control word profile to FC protocol [0]. The control sends commands from a master (PLC or PC) to a slave (adjustable frequency drive).

Master => slave				
1	2	3	10
CTW	MRV	PCD	PCD
		PCD read/write		



Explanation of the Control Bits

Bit	Bit value = 0	Bit value = 1
00	Reference value	external selection lsb
01	Reference value	external selection msb
02	DC brake	Ramp
03	Coasting	No coasting
04	Quick stop	Ramp
05	Freeze output	use ramp
06	Ramp stop	Start
07	No function	Reset
08	No function	Jog
09	Ramp 1	Ramp 2
10	Data not valid	Data valid
11	Relay 01 open	Relay 01 active
12	Relay 02 open	Relay 02 active
13	Parameter set-up	selection lsb
14	Parameter set-up	selection msb
15	No function	Reverse

Bits 00/01

Use bits 00 and 01 to choose between the four reference values, which are pre-programmed in par. 3-10 *Preset reference* according to the shown table:



NOTE

Make a selection in par. 8-56 *Preset Reference Select* to define how Bit 00/01 gates with the corresponding

function on the digital inputs.

Programmed ref. value	Par.	Bit 01	Bit 00
1	3-10 [0]	0	0
2	3-10 [1]	0	1
3	3-10 [2]	1	0
4	3-10 [3]	1	1

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

Bit 02, DC brake:

Bit 02 = "0": DC braking and stop. Set braking current and duration in par. 2-01 *DC Brake Current* and 2-02 *DC Braking Time*. Bit 02 = "1" leads to ramping.

Bit 03, Coasting:

Bit 03 = "0": The adjustable frequency drive immediately "lets go" of the motor, (the output transistors are "shut off") and it coasts to a standstill. Bit 03 = "1": The adjustable frequency drive starts the motor if the other starting conditions are met.



NOTE

Make a selection in par. 8-50 *Coasting Select* to define how Bit 03 gates with the corresponding function on a digital input.

Bit 04, Quick stop:

Bit 04 = "0": Makes the motor speed ramp down to stop (set in par. 3-81 *Quick Stop Ramp Time*).

Bit 05, Freeze output frequency:

Bit 05 = "0": The present output frequency (in Hz) freezes. Change the frozen output frequency only by means of the digital inputs (par. 5-10 to 5-15) programmed to Speed up and Speed down.



NOTE

If Freeze output is active, the adjustable frequency drive can only be stopped by the following:

- Bit 03 Coasting stop
- Bit 02 DC braking
- Digital input (par. 5-10 to 5-15) programmed to DC braking, Coasting stop, or Reset and coasting stop.

Bit 06, Ramp stop/start:

Bit 06 = "0": Causes a stop and makes the motor speed ramp down to stop via the selected ramp down par.

Bit 06 = "1": Permits the adjustable frequency drive to start the motor, if the other starting conditions are met.



NOTE

Make a selection in par. 8-53 *Start Select* to define how Bit 06 Ramp stop/start gates with the corresponding function on a digital input.

Bit 07, Reset: Bit 07 = "0": No reset. Bit 07 = "1": Resets a trip. Reset is activated on the signal's leading edge, i.e. when changing from logic "0" to logic "1".

Bit 08, Jog:

Bit 08 = "1": The output frequency is determined by par. 3-19 *Jog speed*.

Bit 09, Selection of ramp 1/2:

Bit 09 = "0": Ramp 1 is active (par. 3-40 to 3-47). Bit 09 = "1": Ramp 2 (par. 3-50 to 3-57) is active.

Bit 10, Data not valid/Data valid:

Tell the adjustable frequency drive whether to use or ignore the control word. Bit 10 = "0": The control word is ignored. Bit 10 = "1": The control word is used. This function is relevant because the telegram always contains the control word, regardless of the telegram type. Thus, it is possible to turn off the control word and not use it when updating or reading parameters.

Bit 11, Relay 01:

Bit 11 = "0": Relay not activated. Bit 11 = "1": Relay 01 activated provided that Control word bit 11 is chosen in par. 5-40.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

Bit 12, Relay 02:

Bit 12 = "0": Relay 2 is not activated. Bit 12 = "1": Relay 02 is activated provided that Control word bit 12 is chosen in par. 5-40.

Bit 13/14, Selection of set-up:

Use bits 13 and 14 to choose from the four menu set-ups according to the shown table. The function is only possible when Multi Set-Ups is selected in par. 0-10 *Active Set-Up*.

Set-up	Bit 14	Bit 13
1	0	0
2	0	1
3	1	0
4	1	1



NOTE

Make a selection in par. 8-55 *Set-up select* to define how Bit 13/14 gates with the corresponding function on the digital inputs.

Bit 15 Reverse:

Bit 15 = "0": No reverse Bit 15 = "1": Reverse. In the default setting, reverse is set to digital in par. 8-54 *Reversing select*. Bit 15 causes reverse only when Ser. communication, Logic or or Logic and is selected.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ **Status Word According to FC Profile (STW)**

The status word informs the master (e.g. a PC) of the slave (adjustable frequency drive) operation mode.

Slave => master				
1	2	3	10
STW	MAV	PCD	PCD
		PCD read/write		

Explanation of the Status Bits

Bit	Bit value = 0	Bit value = 1
00	Control not ready	Control ready
01	Drive not ready	Drive ready
02	Coasting	Enable
03	No error	Trip
04	No error	Error (no trip)
05	Reserved	-
06	No error	Triplock
07	No warning	Warning
08	Speed ≠ reference	Speed = reference
09	Local operation	Bus control
10	Out of frequency limit	Frequency limit OK
11	No operation	In operation
12	Drive OK	Stopped, autostart
13	Voltage OK	Voltage exceeded
14	Torque OK	Torque exceeded
15	Timer OK	Timer exceeded

Bit 00, Control not ready/ready:

Bit 00 = "0": The adjustable frequency drive trips. Bit 00 = "1": The adjustable frequency drive controls are ready but the power component does not necessarily receive any power supply (in case of external 24 V supply to controls).

Bit 01, Drive ready:

Bit 01 = "1": The adjustable frequency drive is ready for operation but the coasting command is active via the digital inputs or via serial communication.

Bit 02, Coasting stop:

Bit 02 = "0": The adjustable frequency drive releases the motor. Bit 02 = "1": The adjustable frequency drive starts the motor with a start command.

Bit 03, No error/trip:

Bit 03 = "0" : The adjustable frequency drive is not in fault mode. Bit 03 = "1": The adjustable frequency drive trips. To re-establish operation, enter [Reset].

Bit 04, No error/error (no trip):

Bit 04 = "0": The adjustable frequency drive is not in fault mode. Bit 04 = "1": The adjustable frequency drive shows an error but does not trip.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

Bit 05, Not used:

Bit 05 is not used in the status word.

Bit 06, No error / triplock:

Bit 06 = "0": The adjustable frequency drive is not in fault mode. Bit 06 = "1": The adjustable frequency drive is tripped and locked.

Bit 07, No warning/warning:

Bit 07 = "0": There are no warnings. Bit 07 = "1": A warning has occurred.

Bit 08, Speed ≠ reference/speed = reference:

Bit 08 = "0": The motor is running but the present speed is different from the preset speed reference. This might be the case e.g. when the speed ramps up/down during start/stop. Bit 08 = "1": The motor speed matches the preset speed reference.

Bit 09, Local operation/bus control:

Bit 09 = "0": [STOP/RESET] is activate on the control unit or Local control in par. 3-13 *Reference site* is selected. You cannot control the adjustable frequency drive via serial communication. Bit 09 = "1": It is possible to control the adjustable frequency drive via the fieldbus/ serial communication.

Bit 10, Out of frequency limit:

Bit 10 = "0": The output frequency has reached the value in par. 4-11 *Motor speed low limit* or par. 4-13 *Motor speed high limit*. Bit 10 = "1": The output frequency is within the defined limits.

Bit 11, No operation/in operation:

Bit 11 = "0": The motor is not running. Bit 11 = "1": The adjustable frequency drive has a start signal or the output frequency is greater than 0 Hz.

Bit 12, Drive OK/stopped, autostart:

Bit 12 = "0": There is no temporary overheating in the inverter. Bit 12 = "1": The inverter stops because of overheating but the unit does not trip and will resume operation once the overheating stops.

Bit 13, Voltage OK/limit exceeded:

Bit 13 = "0": There are no voltage warnings. Bit 13 = "1": The DC voltage in the adjustable frequency drive's intermediate circuit is too low or too high.

Bit 14, Torque OK/limit exceeded:

Bit 14 = "0": The motor current is lower than the torque limit selected in par. 4-18 *Current Limit*. Bit 14 = "1": The torque limit in par. 4-18 *Current Limit* is exceeded.

Bit 15, Timer OK/limit exceeded:

Bit 15 = "0": The timers for motor thermal protection and VLT thermal protection are not exceeded 100%. Bit 15 = "1": One of the timers exceeds 100%.



— How to Program —

□ **Control Word according to PROFIdrive Profile (CTW)**

The Control word is used to send commands from a master (e.g. a PC) to a slave.

Master => slave				
1	2	3	10
CTW	MRV	PCD	PCD
		PCD read/write		

Explanation of the Control Bits

Bit	Bit value = 0	Bit value = 1
00	OFF 1	ON 1
01	OFF 2	ON 2
02	OFF 3	ON 3
03	Coasting	No coasting
04	Quick stop	Ramp
05	Hold frequency output.	Use ramp
06	Ramp stop	Start
07	No function	Reset
08	Jog 1 OFF	Jog 1 ON
09	Jog 2 OFF	Jog 2 ON
10	Data invalid	Data valid
11	No function	Slow down
12	No function	Catch up
13	Selection set-up 1 (lsb)	Selection set-up 1 (lsb)
14	Selection set-up 2 (lsb)	Selection set-up 2 (lsb)
15	No function	Reverse

Bit 00, OFF 1/ON 1:

Normal ramp stop uses the ramp times of the actual selected ramp. Bit 00 = "0": Stops and activates the output relay 1 or 2, if the output frequency is 0 Hz and if Relay 123 is selected in par. 5-40. Bit 00 = "1": The adjustable frequency drive starts if the other start conditions are met.

Bit 01, OFF 2/ON 2

Bit 01 = "0": Coasting stop and activation of the output relay 1 or 2 occurs if the output frequency is 0 Hz and if Relay 123 is selected in par. 5-40. Bit 01 = "1": The adjustable frequency drive starts if the other start conditions are met.

Bit 02, OFF 3/ON 3

A quick stop uses the ramp time of par. 2-12. Bit 02 = "0": A quick stop and activation of the output relay 1 or 2 occurs if the output frequency is 0 Hz and if Relay 123 is selected in par. 5-40. Bit 02 = "1": The adjustable frequency drive starts if the other start conditions are met.

Bit 03, Coasting/No coasting

Bit 03 = "0": Leads to a stop. Bit 03 = "1": The adjustable frequency drive starts if the other start conditions are met.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

**NOTE**

The selection in par. 8-50 *Coasting Select* determines how bit 03 links with the corresponding function of the digital inputs.

Bit 04, Quick stop/Ramp

Quick stop uses the ramp time of par. 3-81. Bit 04 = "0": A quick stop occurs. Bit 04 = "1": The adjustable frequency drive starts if the other start conditions are met.

**NOTE**

The selection in par. 5-51 *Quick Stop Select* determines how bit 04 links with the corresponding function of the digital inputs.

Bit 05, Hold frequency output/Use ramp

Bit 05 = "0": Maintains the current output frequency even if the reference value is modified.

Bit 05 = "1": The adjustable frequency drive performs its regulating function again. Operation occurs according to the respective reference value.

Bit 06, Ramp stop/Start

Normal ramp stop uses the selected ramp times of the actual ramp. In addition, activation of the output relay 01 or 04 if the output frequency is 0 Hz if Relay 123 is selected in par. 5-40. Bit 06 = "0": Leads to a stop. Bit 06 = "1": The adjustable frequency drive starts if the other start conditions are met.

**NOTE**

The selection in par. 8-53 determines how bit 06 links with the corresponding function of the digital inputs.

Bit 07, No function/Reset

Reset after switching off. Acknowledges event in fault buffer. Bit 07 = "0": No reset occurs. A reset occurs after switching off, when there is a slope change of bit 07 to "1".

Bit 08, Jog 1 OFF/ON

Activation of the pre-programmed speed in par. 8-90 *Bus Jog 1 speed*. JOG 1 is only possible if bit 04 = "0" and bit 00 - 03 = "1".

Bit 09, Jog 2 OFF/ON

Activation of the pre-programmed speed in par. 8-91 *Bus Jog 2 Speed*. JOG 2 is only possible if bit 04 = "0" and bit 00 - 03 = "1". If both JOG 1 and JOG 2 are activated (bit 08 and 09 = "1"), JOG 3 is selected. Thus, the speed (set in par. 8-92) is used.

Bit 10, Data invalid/valid

Notifies the adjustable frequency drive if the process data channel (PCD) should respond to modifications by the master (bit 10 = 1) or not.

Bit 11, No function/Slow down

Reduces the speed reference value by the amount given in par. 3-12 *Catch Up/Slow Down Value*. Bit 11 = "0": The reference value is not modified. Bit 11 = "1": The reference value is reduced.

Bit 12, No function/Catch up

Increases the speed reference value by the amount given in par. 3-12 *Catch Up/Slow Down Value*. Bit 12 = "0": The reference value is not modified. Bit 12 = "1": The reference value is increased. If both slowing down and accelerating are activated (bit 11 and 12 = "1"), slowing down has priority. Thus, the speed reference value is reduced.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

Bits 13/14, Set-up selection

Choose between the four parameter set-ups via bits 13 and 14 according to the shown table:
 The function is only possible if you choose Multi Set-up in par. 0-10. The selection in par. 8-55 *Set-up Select* determines how bits 13 and 14 link with the corresponding function of the digital inputs. When the motor is running, you can only change the set-up if it is linked.

Set-up	Bit 13	Bit 14
1	0	0
2	1	0
3	0	1
4	1	1

Bit 15, No function/Reverse

Reverse of the motor rotational direction. Bit 15 = "0": No reverse. Bit 15 = "1": Reverse. The reverse in the default setting in par. 8-54 *Reversing Select* is "Logic OR". Bit 15 causes a reverse only when "Bus", "Logic OR", or "Logic AND" is selected ("Logic AND" only in connection with terminal 9, however).



NOTE

Unless otherwise indicated, the control word bit links with the corresponding digital input function as a logic "OR".

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ **Status Word According to PROFIdrive Profile (STW)**

The Status word is used to notify a master (e.g. a PC) about the status of a slave.

Slave => master				
1	2	3	10
STW	MAV	PCD	PCD
		PCD read/write		



Explanation of the Status Bits

Bit	Bit value = 0	Bit value = 1
00	Control not ready	Control ready
01	Drive not ready	Drive ready
02	Coasting	Enable
03	No error	Trip
04	OFF 2	ON 2
05	OFF 3	ON 3
06	Start possible	Start not possible
07	No warning	Warning
08	Speed ≠ reference	Speed = reference
09	Local operation	Bus control
10	Out of frequency limit	Frequency limit
11	No operation	In operation
12	Drive OK	Stopped, autostart
13	Voltage OK	Voltage exceeded
14	Torque OK	Torque exceeded
15	Timer OK	Timer exceeded

Bit 00, Control not ready/ready

Bit 00 = "0": Bit 00, 01, or 02 of the Control word is "0" (OFF 1, OFF 2 or OFF 3) - or the adjustable frequency drive switches off (trips). Bit 00 = "1": The adjustable frequency drive control is ready but there is not necessarily a power supply (in the event of external 24 V supply of the control system).

Bit 01, VLT not ready/ready

Same significance as bit 00 but with power unit supply. The adjustable frequency drive is ready when it receives the necessary start signals.

Bit 02, Coasting/Enable

Bit 02 = "0": Bit 00, 01, or 02 of the Control word is "0" (OFF 1, OFF 2, or OFF 3 or coasting) - or the adjustable frequency drive switches off (trips). Bit 02 = "1": Bit 00, 01, or 02 of the Control word is "1" - the adjustable frequency drive does not trip.

Bit 03, No error/Trip

Bit 03 = "0": No error in the adjustable frequency drive. Bit 03 = "1": The adjustable frequency drive trips and requires. Press [Reset] to restart.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

Bit 04, ON 2/OFF 2

Bit 04 = "0": Bit 01 of the Control word is "0". Bit 04 = "1": Bit 01 of the Control word is "1".

Bit 05, ON 3/OFF 3

Bit 05 = "0": Bit 02 of the Control word is "0". Bit 05 = "1": Bit 02 of the Control word is "1".

Bit 06, Start possible/Start not possible

Bit 06 is always "0" if you select FC Drive in par. 8-10. If you select PROFIdrive in par. 8-10, bit 06 is "1" after a switch-off acknowledgement, after activation of OFF2 or OFF3, and after switching on mains voltage. Start is not possible. The adjustable frequency drive is reset with bit 00 of the Control word set to "0" and bit 01, 02, and 10 set to "1".

Bit 07, No warning/Warning

Bit 07 = "0": No unusual situation. Bit 07 = "1": There is an unusual status in the adjustable frequency drive. For more information about warnings - see the *FC 300 Profibus Operating Instructions*.

Bit 08, Speed ≠ reference / Speed = reference:

Bit 08 = "0": The motor speed deviates from the set speed reference value. This occurs e.g. when the speed is changed during start/stop through ramp-up/down. Bit 08 = "1": The motor speed corresponds to the set speed reference value.

Bit 09, Local operation/Bus control

Bit 09 = "0": Indicates that the adjustable frequency drive is stopped via [Stop] or that Local is selected in par. 0-02. Bit 09 = "1": The adjustable frequency drive is controlled through the serial interface.

Bit 10, Out of frequency limit/Frequency limit OK

Bit 10 = "0": The output frequency is outside the limits set in par. 4-11 and par. 4-13 (Warnings: Motor speed low or high limit). Bit 10 = "1": The output frequency is within the indicated limits.

Bit 11, No operation/Operation

Bit 11 = "0": The motor is not running. Bit 11 = "1": A start signal is active or the output frequency is higher than 0 Hz.

Bit 12, Drive OK/Stopped, autostart

Bit 12 = "0": No temporary overloading of the inverter. Bit 12 = "1": The inverter stops due to overload. However, the adjustable frequency drive is not switched off (tripped) and will restart after the overloading stops.

Bit 13, Voltage OK/Voltage exceeded

Bit 13 = "0": The adjustable frequency drive voltage limits are not exceeded. Bit 13 = "1": The direct voltage in the drive intermediate circuit is too low or too high.

Bit 14, Torque OK/Torque exceeded

Bit 14 = "0": The motor current is below the moment limit selected in par. 4-18. Bit 14 = "1": The torque limit selected in par. 4-18 is exceeded.

Bit 15, Timer OK/Timer exceeded


Bit 15 = "0": The timers for the thermal motor protection and adjustable frequency drive thermal protection have not exceeded 100%. Bit 15 = "1": One of the timers has exceeded 100%.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ **Serial Communication Reference**

The serial communication reference is transferred to the adjustable frequency drive as a 16-bit word. The value is transferred in whole numbers 0 - ±32767 (±200%). 16384 (4000 Hex) corresponds to 100%.




The serial communication reference has the following format: 0-16384 (4000 Hex) \cong 0-100% (par. 3-02 *Minimum Ref.* to par. 3-03 *Maximum Ref.*).

It is possible to change the direction of rotation via the serial reference. This is done by converting the binary reference value to 2' complement. See example.

Example - Control word and serial communication ref.:


The adjustable frequency drive receives a start command and the reference is set to 50% (2000 Hex) of the reference range. Control word = 047F Hex => Start command. Reference = 2000 Hex => 50% reference.



The adjustable frequency drive receives a start command and the reference is set to -50% (-2000 Hex) of the reference range. The reference value is first converted to 1' complement, and then 1 is added in binary fashion to obtain 2' complement:

2000 Hex	0010 0000 0000 0000 0000
1' complement	1101 1111 1111 1111 1111
	+ 1
2' complement	1110 0000 0000 0000 0000

Control word = 047F Hex => Start command. Reference = E000 Hex => -50% reference.




* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ **Present Output Frequency**

The value of the adjustable frequency drive's present output frequency is transferred as a 16-bit word. The value is transferred as whole numbers 0 - ±32767 (±200%).
16384 (4000 Hex) corresponds to 100%.


Output frequency has this format:
0-16384 (4000 Hex) \cong 0-100% (Par. 4-12 *Motor Speed Low Limit* - par. 4-14 *Motor Speed High Limit*).



Example - Status word and current output frequency:

The adjustable frequency drive informs the master that the current output frequency is 50% of the output frequency range.
Par. 4-12 *Motor speed low limit* = 0 Hz
Par. 4-14 *Motor speed high limit* = 50 Hz

Status word = 0F03 Hex.
Output frequency = 2000 Hex => 50% of the frequency range, corresponding to 25 Hz.



□ **Example 1: For Controlling the Drive and Reading Parameters**

This telegram reads par. 16-14 *Motor Current*.

Telegram to the adjustable frequency drive:

stx	lge	adr	pke	ind	pwe, high	pwe, low	pcd 1	pcd 2	bcc
02	0E	01	6 4E	00 00	00 00	00 00	00 00	00 00	45

All numbers are in hex format.

The response from the adjustable frequency drive corresponds to the command above but *pwe,high* and *pwe,low* contain the actual value of par. 16-14 multiplied by 100. If the actual output current is 5.24 A, the value from the adjustable frequency drive is 524.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

Response from the adjustable frequency drive:

stx	lge	adr	pke	ind	pwe, high	pwe, low	pcd 1	pcd 2	bcc
02	0E	01	6 4E	00 00	00 00	02 0C	06 07	00 00	4A

All numbers are in hex format.

Pcd 1 and *pcd 2* from example 2 can be used and added to the example. Thus, it is possible to control the drive and read the current at the same time.

□ **Example 2: Only for Controlling the Drive**

This telegram sets the control word to 047C Hex (Start command) with a speed reference of 2000 Hex (50%).



NOTE

Par. 8-10 is set to FC Profile.

Telegram to the adjustable frequency drive:
All numbers are in hex format.

stx	lge	adr	pcd 1	pcd 2	bcc
02	06	04	04 7C	20 00	58

The adjustable frequency drive supplies information about the drive status after receiving the command. By resending the command, the *pcd1* changes to a new status.

Response from the adjustable frequency drive:

All numbers are in hex format.

stx	lge	adr	pcd 1	pcd 2	bcc
02	06	04	06 07	00 00	01

□ **Read Parameter Description Elements**

Read the characteristics of a parameter (e.g. *Name, Default value, conversion, etc.*) with *Read Parameter Description Elements*.

The table shows the available parameter description elements:

Index	Description
1	Basic characteristics
2	No. of elements (array types)
4	Unit of measure
6	Name
7	Lower limit
8	Upper limit
20	Default value
21	Additional characteristics

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

In the following example, *Read Parameter Description Elements* is chosen on par. 0-01 *Language*, and the requested element is index 1 *Basic characteristics*.

Basis characteristics (index 1):

The Basic characteristics command is split up in two parts representing basic behavior and data type. The Basic characteristics return a 16-bit value to the master in PWE_{LOW}.

The basic behavior indicates whether e.g. text is available or the parameter is an array as single bit information in the high byte of PWE_{LOW}.

The data type part indicates if a parameter is signed 16, unsigned 32 in the low byte of PWE_{LOW}.

PWE high basic behavior:

Bit	Description
15	Active parameter
14	Array
13	Parameter value can only be reset
12	Parameter value different from factory setting
11	Text available
10	Additional text available
9	Read-only
8	Upper and lower limit not relevant
0-7	Data type

Active parameter is only active when communicating through Profibus.

Array means that the parameter is an array.

If bit 13 is true, the parameter can only be reset, not written to.

If bit 12 is true, the parameter value is different from the factory setting.

Bit 11 indicates that text is available.

Bit 10 indicates that additional text is available. E.g. par. 0-01, *Language*, contains text for index field 0, *English*, and for index field 1, *German*.

If bit 9 is true, the parameter value is read-only and cannot be changed.

If bit 8 is true, upper and lower limits of the parameter value are not relevant.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

PWE_{LOW} datatype

Dec.	Data type
3	Signed 16
4	Signed 32
5	Unsigned 8
6	Unsigned 16
7	Unsigned 32
9	Visible string
10	Byte string
13	Time difference
33	Reserved
35	Bit sequence



Example

In this example, the master reads the Basic characteristics of par. 0-01, *Language*. The following telegram must be sent to the adjustable frequency drive:

STX	LGE	ADR	PKE	IND	PWE _{HIGH}	PWE _{LOW}	PCD1	PCD2	BCC
02	0E	01	40 01	00 01	00 00	00 00	XX XX	XX XX	XX

- STX = 02 Start byte
- LGE = 0E Length of remaining telegram
- ADR = Sends the adjustable frequency drive on Address 1, Danfoss format
- PKE = 4001; 4 in the PKE field indicates a *Read Parameter Description* and 01 indicates par. 0-01, *Language*
- IND = 0001; 1 indicates that *Basic characteristics* are required.

The response from the adjustable frequency drive is:

STX	LGE	ADR	PKE	IND	PWE _{HIGH}	PWE _{LOW}	PCD1	PCD2	BCC
02	0E	01	30 01	00 01	00 00	04 05	XX XX	XX XX	XX

- STX = 02 Start byte
- IND = 0001; 1 indicates that *Basic characteristics* are sent
- PKE = 3001: 3 in the PKE field indicates *Parameter Description Element Transferred*, 01 indicates par. 0-01.
- PWE_{LOW} = 0405; 04 indicates that Basic behavior as bit 10 corresponds to *Additional text*. 05 is the data type which corresponds to *Unsigned 8*.

No of elements (index 2):

This function indicates the Number of elements (array) of a parameter. The answer to the master will be in PWE_{LOW}.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



Conversion and Unit of measurement (index 4):

The Conversion and unit of measurement command indicates the conversion of a parameter and the unit of measurement. The answer to the master is in PWE_{LOW}. The conversion index is in the high byte of PWE_{LOW} and the unit index is in the low byte of PWE_{LOW}. Conversion index is signed 8 and unit index is unsigned 8, see the tables.

Conversion index	Conversion factor
0	1
1	10
2	100
3	1000
-1	0.1
-2	0.01
-3	0.001
67	1/60
74	3600
75	3600000
100	1

The unit index defines the "Unit of measure". The conversion index defines how the value should be scaled to get the basic representation of the "Unit of measure". Basic representation is where conversion index equals "0".

Example:

A parameter has a "unit index" of 9 and a "conversion index" of 2. The raw (integer) value read is 23. This means that we have a parameter of the unit "Power" and the raw value should be multiplied by 10 to the power of 2 and the unit is W. $23 \times 10^2 = 2300 \text{ W}$

Unit index	Unit of measure	Designation	Conversion index
0	Dimensionless		0
4	Time	s	0
		h	74
8	Energy	J	0
		kWh	
9	Power	W	0
		kW	3
11	Speed	1/s	0
		1/min (RPM)	67
16	Torque	Nm	0
17	Temperature	K	0
		°C	100
21	Voltage	V	0
22	Current	A	0
24	Ratio	%	0
27	Relative change	%	0
28	Frequency	Hz	0
54	Time difference w/o date indication	ms	1*

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



*

Bit	8	7	6	5	4	3	2	1	
Byte 1	2 ³¹	2 ³⁰	2 ²⁹	2 ²⁸	2 ²⁷	2 ²⁶	2 ²⁵	2 ²⁴	ms
Byte 2	2 ²³	2 ²²	2 ²¹	2 ²⁰	2 ¹⁹	2 ¹⁸	2 ¹⁷	2 ¹⁶	
Byte 3	2 ¹⁵	2 ¹⁴	2 ¹³	2 ¹²	2 ¹¹	2 ¹⁰	2 ⁹	2 ⁸	
Byte 4	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰	

Name (index 6):

The Name returns a string value in ASCII format, containing the name of the parameter.

Example:

In this example, the master reads the name of par. 0-01, *Language*.

The following telegram must be sent to the adjustable frequency drive:

STX	LGE	ADR	PKE	IND	PWE _{HIGH}	PWE _{LOW}	PCD1	PCD2	BCC
02	0E	01	40 01	00 06	00 00	00 00	XX XX	XX XX	XX

- STX = 02 Start byte
- LGE = 0E Length of remaining telegram
- ADR = Sends the adjustable frequency drive on Address 1, Danfoss format
- PKE = 4001; 4 in the PKE field indicates a *Read Parameter Description* and 01 indicates par. 0-01, *Language*
- IND = 0006; 6 indicates that *Names* is required.

The response from the adjustable frequency drive will be:

STX	LGE	ADR	PKE	IND	PVA	PCD1	PCD2	BCC
02	12	01	30 01	00 06	4C41 4E47 5541 4745	XXXX	XXXX	XX

- PKE = 3001; 3 are the response for *Name* and 01 indicates the par. 0-01, *Language*
- IND = 00 06; 06 indicates that *Name* is sent.
- PVA = 4C 41 4E 47 55 41 47 45
L A N G U A G E

The parameter value channel is now set up to a visible string which returns an ASCII character for each letter in the parameter name.

Lower limit (index 7):

The Lower limit returns the minimum allowed value of a parameter. The data type of Lower limit is the same as for the parameter itself.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



Upper limit (index 8):

The Upper limit returns the maximum allowed value of a parameter. The data type of Upper limit is the same as for the parameter itself.

Default value (index 20):

The Default value returns the default value of a parameter, which is the factory setting. The data type of Default value is the same as for the parameter itself.

Additional characteristics (index 21):

The command can be used for getting additional information on a parameter, e.g. *No bus Access, Power Unit dependency, etc.* The Additional characteristics returns an answer in PWE_{LOW}. If a bit is logic "1", the condition is true according to the table below:

Bit	Description
0	Special Default Value
1	Special Upper Limit
2	Special Lower Limit
7	LCP Access LSB
8	LCP Access MSB
9	NoBusAccess
10	Std Bus Read Only
11	Profibus Read Only
13	ChangeRunning
15	PowerUnitDependency

If one of bit 0 *Special Default Value*, bit 1 *Special Upper Limit* or bit 2 *Special Lower Limit* is true, the parameter has power unit-depending values.

Bit 7 and 8 indicate the attributes for the LCP access, see table.

Bit 8	Bit 7	Description
0	0	No access
0	1	Read-only
1	0	Read/write
1	1	Write with lock

Bit 9 indicates *No bus Access*.

Bits 10 and 11 indicate that this parameter can only be read over the bus.

If bit 13 is true, the parameter cannot be changed while running.

If bit 15 is true, the parameter depends on the power unit.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —

□ **Additional Text**

With this feature, it is possible to read additional text if bit 10, *Additional text available*, is true in Basic characteristics.

To read out additional text, the parameter command (PKE) must be set to F hex, see *Databytes*.

The index field is used for pointing out which element to read. Valid indexes are in the range of 1 through 254. The index must be calculated according to the following equation:

$$\text{Index} = \text{Parameter value} + 1 \text{ (see table below).}$$

Value	Index	Text
0	1	English
1	2	Deutsch
2	3	Français
3	4	Dansk
4	5	Espanol
5	6	Italiano



Example:

In this example, the Master reads additional text in par. 0-01, *Language*. The telegram is set up to read data value [0] (*English*). You must send the following telegram to the adjustable frequency drive:

STX	LGE	ADR	PKE	IND	PWE _{HIGH}	PWE _{LOW}	PCD1	PCD2	BCC
02	0E	01	F0 01	00 01	00 00	00 00	XX XX	XX XX	XX

- STX = 02 Start byte
- LGE = 0E Length of the remaining telegram
- ADR = Send the VLT adjustable frequency drive on Address 1, Danfoss format
- PKE = F001; F in the PKE field indicates a *Read text* and 01 indicates par. 0-01, *Language*.
- IND = 0001; 1 indicates that text to parameter value [0] is required

The response from the adjustable frequency drive is:

STX	LGE	ADR	PKE	IND	PVA	PCD1	PCD2	BCC
02	11	01	F0 01	00 01	45 4E 47 4C 49 53 48	XX XX	XX XX	XX

- PKE = F001; F is the response for *Text transfer* and 01 indicates par. 0-01, *Language*.
- IND = 0001; 1 indicates that index [1] is sent
- PVA = 45 4E 47 4C 49 53 48
E N G L I S H

The parameter value channel is now set up to a visible string, which returns an ASCII character for each letter in the index name.

* default setting () display text [] value for use in communication via serial communication port

— How to Program —



* default setting () display text [] value for use in communication via serial communication port

Troubleshooting



□ Warnings/Alarm Messages

A warning or an alarm icon appears in the display as well as a text string describing the problem. A warning is shown on the display until the fault has been corrected, while an alarm will continue to flash on the LED until you activate the [RESET] key. The table (next page) shows the various warnings and alarms, and whether the fault locks the FC 300. After an *Alarm/Trip locked*, cut off the line supply and correct the fault. Reconnect line supply. The FC 300 is now unlocked. The *Alarm/Trip* can be reset manually in three ways:

1. Via the operating key [RESET] on the LCP.
2. Via a digital input.
3. Via serial communication/optional bus.

You can also choose an automatic reset in par. 14-20 *Reset Mode*. When an X appears in both warning and alarm, it means that either a warning comes before an alarm or that you can define whether a warning or an alarm appears for a given fault. For example, this is possible in par. 1-90 *Motor Thermal Protection*. After an alarm/trip, the motor will remain coasted, and alarm and warning will flash on the FC 300. If the fault disappears, only the alarm will flash.



NOTE

After a manual reset via the [RESET] key on the LCP, it is necessary to push the [AUTO ON] key to restart the motor!

— Troubleshooting —

Alarm/Warning code list

No.	Description	Warning	Alarm/Trip	Alarm/Trip locked
1	10 V low	X		
2	Live zero error	(X)	(X)	
3	No motor	X		
4	Mains phs. loss	X	X	X
5	DC voltage high	X		
6	DC voltage low	X		
7	DC overvolt	X	X	
8	DC undervolt	X	X	
9	Inverter overld	X	X	
10	Motor ETR over temperature	X	X	
11	Motor thermistor over temperature	X	X	
12	Torque limit	X	X	
13	Overcurrent	X	X	X
14	Ground fault	X	X	X
16	Short Circuit		X	X
17	Ctrl. word TO	(X)	(X)	
25	Brake resistor	X		
26	Brake overload	X	X	
27	Brake IGBT	X	X	
28	Brake check	X	X	
29	Power card over temp	X	X	X
30	U phase loss		X	X
31	V phase loss		X	X
32	W phase loss		X	X
33	Soft-charge fault		X	X
34	Fieldbus fault	X	X	
38	Internal fault		X	X
47	24 V supply low	X	X	X
48	1.8V supply low		X	X
49	Speed limit	X		
50	AMA calibration		X	
51	AMA Unom,Inom		X	
52	AMA low Inom		X	
53	AMA big motor		X	
54	AMA small mot		X	
55	AMA parameter out of range		X	
56	AMA interrupt		X	
57	AMA timeout		X	
58	AMA internal	X	X	
59	Current limit	X		
61	Encoder loss	(X)	(X)	
62	Output freq. lim	X		
63	Mech. brake low		X	
64	Voltage Limit	X		
65	Ctrl. card temp	X	X	X
66	Low temp	X		
67	Option change		X	
68	Safe Stop		X	
80	Drive initialized		X	
(X)	Dependent on parameter			

LED indication

Warning	yellow
Alarm	flashing red
Trip locked	yellow and red

— Troubleshooting —

Description of Alarm Word, Warning Word, and extended Status Word					
Alarm Word	Extended Status Word				
Bit	Hex	Dec	AlarmWord	WarningWord	ExtendedStatusWord
0	00000001	1	Brake check	Brake check	Ramping
1	00000002	2	Pwr. card temp	Pwr. card temp	AMA running
2	00000004	4	Ground Fault	Ground Fault	Start CW/CCW
3	00000008	8	Ctrl.card temp	Ctrl.card temp	Slow-down
4	00000010	16	Ctrl. word TO	Ctrl. word TO	Catch up
5	00000020	32	Overcurrent	Overcurrent	Feedback High
6	00000040	64	Torque limit	Torque limit	Feedback Low
7	00000080	128	Thrmstr overld	Thrmstr overld	Output Current High
8	00000100	256	Motor ETR over	Motor ETR over	Output Current Low
9	00000200	512	Inverter overld.	Inverter overld.	Output Freq High
10	00000400	1024	DC undervolt	DC undervolt	Output Freq Low
11	00000800	2048	DC overvolt	DC overvolt	Brake Check OK
12	00001000	4096	Short Circuit	DC voltage low	Braking Max
13	00002000	8192	Inrush fault	DC voltage high	Braking
14	00004000	16384	Mains phs. loss	Mains phs. loss	Out of speed range
15	00008000	32768	AMA Not OK	No motor	OVC Active
16	00010000	65536	Live zero error	Live zero error	
17	00020000	131072	Internal fault	10V low	
18	00040000	262144	Brake overload	Brake overload	
19	00080000	524288	U phase loss	Brake resistor	
20	00100000	1048576	V phase loss	Brake IGBT	
21	00200000	2097152	W phase loss	Speed limit	
22	00400000	4194304	Fieldbus fault	Fieldbus fault	
23	00800000	8388608	24 V supply low	24V supply low	
24	01000000	16777216	Mains failure	Mains failure	
25	02000000	33554432	1.8V supply low	Current limit	
26	04000000	67108864	Brake resistor	Low temp.	
27	08000000	134217728	Brake IGBT	Voltage limit	
28	10000000	268435456	Option change	Unused	
29	20000000	536870912	Drive initialized	Unused	
30	40000000	1073741824	Safe Stop	Unused	
31	80000000	2147483648	Mech. brake low	Warning Word 2	
				(Extended Status Word)	



The alarm words, warning words, and extended status words can be read out via serial bus or optional fieldbus for diagnosis. See also par. 16-90, 16-92, and 16-94.

WARNING 1

10 Volts low:

The 10 V voltage from terminal 50 on the control card is below 10 V.
Remove some of the load from terminal 50, as the 10 V supply is overloaded. Max. 15 mA or minimum 590 Ω.

WARNING/ALARM 2

Live zero error:

The signal on terminal 53 or 54 is less than 50% of the value set in par. 6-10, 6-12, 6-20, or 6-22 respectively.

WARNING/ALARM 3

No motor:

No motor has been connected to the output of the adjustable frequency drive.

WARNING/ALARM 4

Mains phase loss:

A phase is missing on the supply side, or the mains voltage imbalance is too high.

— Troubleshooting —

This message also appears in case of a fault in the input rectifier on the adjustable frequency drive. Check the supply voltage and supply currents to the adjustable frequency drive.

WARNING 5

DC link voltage high:

The intermediate circuit voltage (DC) is higher than the overvoltage limit of the control system. The adjustable frequency drive is still active.

WARNING 6

DC link voltage low

The intermediate circuit voltage (DC) is below the undervoltage limit of the control system. The adjustable frequency drive is still active.

WARNING/ALARM 7

DC over voltage:

If the intermediate circuit voltage exceeds the limit, the adjustable frequency drive trips after a time. Possible corrections:

- Connect a brake resistor
- Extend the ramp time
- Activate functions in par. 2-10
- Increase par. 14-26

Connect a brake resistor. Extend the ramp time

Alarm/warning limits:			
FC 300 Series	3 x 200 - 240 V	3 x 380 - 500 V	3 x 525 - 600 V
	[VDC]	[VDC]	[VDC]
Undervoltage	185	373	532
Voltage warning low	205	410	585
Voltage warning high (w/o brake - w/brake)	390/405	810/840	943/965
Overvoltage	410	855	975

The voltages stated are the intermediate circuit voltage of the FC 300 with a tolerance of ± 5 %. The corresponding mains voltage is the intermediate circuit voltage (DC-link) divided by 1.35

WARNING/ALARM 8

DC under voltage:

If the intermediate circuit voltage (DC) drops below the "voltage warning low" limit (see table above), the adjustable frequency drive checks if 24 V backup supply is connected.

If no 24 V backup supply is connected, the adjustable frequency drive trips after a given time depending on the unit.

To check whether the supply voltage matches the adjustable frequency drive, see *General Specifications*.

WARNING/ALARM 9

Inverter overloaded:

The adjustable frequency drive is about to cut out because of an overload (too high current for too long). The counter for electronic thermal inverter protection gives a warning at 98% and trips at 100%, while giving an alarm. You cannot reset the adjustable frequency drive until the counter is below 90%.

The fault is that the adjustable frequency drive is overloaded by more than 100% for too long.

WARNING/ALARM 10

Motor ETR over temperature:

According to the electronic thermal protection (ETR), the motor is too hot. It is possible to select whether the adjustable frequency drive provides a warning or an alarm when the counter reaches 100% in par. 1-90. The fault is that the motor is overloaded by more than 100% for too long. Check that the motor par. 1-24 is set correctly.

WARNING/ALARM 11

Motor thermistor over temp:

The thermistor or the thermistor connection is disconnected. Choose whether the adjustable frequency drive should provide a warning or an alarm when the counter reaches 100% in par. 1-90. Check that the thermistor is connected correctly between terminal 53 or 54 (analog voltage input) and terminal 50 (+ 10 Volts supply), or between terminal 18 or 19 (digital input PNP only) and terminal 50. If a KTY sensor is used, check for correct connection between terminal 54 and 55.

— Troubleshooting —

WARNING/ALARM 12**Torque limit:**

The torque is higher than the value in par. 4-16 (in motor operation) or the torque is higher than the value in par. 4-17 (in regenerative operation).

WARNING/ALARM 13**Over Current:**

The inverter peak current limit (approx. 200% of the rated current) is exceeded. The warning will last approx. 8-12 sec., then the adjustable frequency drive trips and issues an alarm. Turn off the adjustable frequency drive and check if the crankshaft can be turned and if the motor size matches the adjustable frequency drive.

If extended mechanical brake control is selected, trip can be reset externally.

ALARM 14**Ground fault:**

There is a discharge from the output phases to ground, either in the cable between the adjustable frequency drive and the motor or in the motor itself. Turn off the adjustable frequency drive and remove the ground fault.

ALARM 16**Short-circuit:**

There is short circuiting in the motor or on the motor terminals. Turn off the adjustable frequency drive and remove the short circuit.

WARNING/ALARM 17**Control word timeout:**

There is no communication to the adjustable frequency drive.

The warning will only be active when par. 8-04 is NOT set to *OFF*.

If par. 8-04 is set to *Stop* and *Trip*, a warning appears and the adjustable frequency drive ramps down until it trips, while giving an alarm. par. 8-03 *Control word Timeout Time* could possibly be increased.

WARNING 25**Brake resistor short circuited:**

The brake resistor is monitored during operation. If it short circuits, the brake function is disconnected and the warning appears. The adjustable frequency drive still works, but without the brake function.

Turn off the adjustable frequency drive and replace the brake resistor (see par. 2-15 *Brake Check*).

ALARM/WARNING 26**Brake resistor power limit:**

The power transmitted to the brake resistor is calculated as a percentage, as a mean value over the last 120 s, on the basis of the resistance value of the brake resistor (par. 2-11) and the intermediate circuit voltage. The warning is active when the dissipated braking energy is higher than 90%. If *Trip* [2] has been selected in par. 2-13, the adjustable frequency drive cuts out and issues this alarm when the dissipated braking energy is higher than 100%.

WARNING 27**Brake chopper fault:**

The brake transistor is monitored during operation and if it short circuits, the brake function disconnects and the warning comes up. The adjustable frequency drive is still able to run, but since the brake transistor has short circuited, substantial power is transmitted to the brake resistor, even if it is inactive. Turn off the adjustable frequency drive and remove the brake resistor.



Warning: There is a risk of substantial power being transmitted to the brake resistor if the brake transistor is short circuited.

ALARM/WARNING 28**Brake check failed:**

Brake resistor fault: the brake resistor is not connected/working.

ALARM 29**Drive over temperature:**

If the enclosure is IP 20 or IP 21/TYP 1 (NEMA 1), the cut-out temperature of the heat sink is 203 °F ±9 °F (95 °C ±5 °C). The temperature fault cannot be reset until the temperature of the heat sink is below 158 °F (70 °C).

The fault could be:

- Ambient temperature too high
- Too long motor cable



— Troubleshooting —

ALARM 30**Motor phase U missing:**

Motor phase U between the adjustable frequency drive and the motor is missing.

Turn off the adjustable frequency drive and check motor phase U.

ALARM 31**Motor phase V missing:**

Motor phase V between the adjustable frequency drive and the motor is missing.

Turn off the adjustable frequency drive and check motor phase V.

ALARM 32**Motor phase W missing:**

Motor phase W between the adjustable frequency drive and the motor is missing.

Turn off the adjustable frequency drive and check motor phase W.

ALARM 33**Inrush fault:**

Too many power-ups have occurred within a short time period. See the chapter *General Specifications* for the allowed number of power-ups within one minute.

WARNING/ALARM 34**Fieldbus communication fault:**

The fieldbus on the communication option card is not working.

WARNING 35**Out of frequency range:**

This warning is active if the output frequency has reached its *Warning speed low* (par. 4-52) or *Warning speed high* (par. 4-53). If the adjustable frequency drive is in *Process control, closed loop* (par. 1-00), the warning is active in the display. If the adjustable frequency drive is not in this mode, bit 008000 *Out of frequency range* in extended status word is active but there is no warning in the display.

ALARM 38**Internal fault:**

Contact your Danfoss supplier.

WARNING 47**24 V supply low:**

The external 24 V DC backup power supply may be overloaded, otherwise contact your Danfoss supplier.

WARNING 48**1.8 V supply low:**

Contact your Danfoss supplier.

WARNING 49**Speed limit:**

Contact your Danfoss supplier.

ALARM 50**AMA calibration failed:**

Contact your Danfoss supplier.

ALARM 51**AMA check Unom and Inom:**

The setting of motor voltage, motor current, and motor power is presumably wrong. Check the settings.

ALARM 52**AMA low Inom:**

The motor current is too low. Check the settings.

ALARM 53**AMA motor too big:**

The motor is too big for the AMA to be carried out.

ALARM 54**AMA motor too small:**

The motor is too small for the AMA to be carried out.

ALARM 55**AMA par. out of range:**

The par. values found from the motor are outside the acceptable range.

ALARM 56**AMA interrupted by user:**

The AMA has been interrupted by the user.

ALARM 57**AMA timeout:**

Try to start the AMA again a number of times, until the AMA is carried out. Please note that repeated runs may heat the motor to a level where the resistance R_s and R_r is increased. In most cases, however, this is not critical.

ALARM 58**AMA internal fault:**

Contact your Danfoss supplier.

WARNING 59**Current limit:**

Contact your Danfoss supplier.

WARNING 61**Encoder loss:**

Contact your Danfoss supplier.

WARNING 62

Output Frequency at Maximum Limit:

The output frequency is higher than the value set in par. 4-19

ALARM 63

Mechanical Brake Low:

The actual motor current has not exceeded the "release brake" current within the "Start delay" time window.

WARNING 64

Voltage Limit:

The load and speed combination demands a motor voltage higher than the actual DC link voltage.

WARNING/ALARM/TRIP 65

Control Card Over Temperature:

Control card over temperature: The cut-out temperature of the control card is 176 °F (80 °C).

WARNING 66

Heatsink Temperature Low:

The heat sink temperature is measured as 0° C. This could indicate that the temperature sensor is defect and thus the fan speed is increased to the maximum in case the power part or control card is very hot.

ALARM 67

Option Configuration has Changed:

One or more options has either been added or removed since the last power-down.

ALARM 68

Safe Stop Activated:

Safe Stop has been activated. To resume normal operation, apply 24 V DC to terminal 37, then send a reset signal (via Bus, Digital I/O, or by pressing [RESET]).

ALARM 80

Drive Initialized to Default Value:

Parameter settings are initialized to default setting after a manual (three-finger) reset.





Index

A

Abbreviations	8
Access to control terminals	95
Access to Quick Menu w/o Password	147
Acoustic Noise	64
Active Set-up	139
Additional characteristics	268
Additional Text	269
Address	243, 244
ADR	243
Aggressive Environments.....	19
Air Humidity	19
Air-guiding shield	19
Alarm Messages.....	271
Alarm word	128, 191
Alarm/Trip.....	271
Alarm/Trip locked	271
AMA	118
Analog input	10
Analog input	96
Analog Inputs	10, 59
Analog output	60
Analog Reference	30
Automatic Motor Adaptation	118
Automatic Motor Adaptation (AMA).....	99, 150
Automatic reset	271

B

Back EMF at 1000 RPM.....	152
Basic characteristics.....	264
Baud Rate	137, 244
Brake Check	160
Brake Connection Option	103
Brake control	275
Brake Current	161
Brake Function	49
Brake power	50, 160, 160
Brake Power Monitoring	160
Brake Resistor	48
Brake resistors	71, 78
Braking energy	11
Braking Time	252
Break-away torque	10
Bus Jog 2 Speed	193

C

cable clamps	108
control cables.....	108
Cable clamp	111
Cable lengths and cross-sections	58
Cable lengths and RFI performance	59
Catch up.....	176
Catch up / slow-down	28
Catch Up/Slow Down Value	257
Catch up/slow-down Value	163
Changing a Group of Numeric Data Values	132
Changing a Text Value	131
Changing Data	131
Changing of Data Value.....	133
Clockwise.....	155, 155, 171, 182, 227
Clockwise rotation	106
Coast.....	155
Coasting	9, 115, 126, 192, 252, 254, 257, 259
Coasting stop	256
Cold plate	19
Communication option	276
Configuration Mode.....	148
Connection to Mains.....	88
Control cables	98
Control card performance	62
Control card, +10 V DC output:	61
Control card, 24 V DC output	61
Control card, USB serial communication.....	62
Control characteristics	62
Control Terminals	95
Control Word	251, 256
Control Word Timeout Function	190
Conversion and unit of measurement	266
Cooling	19, 65, 157
Counterclockwise	171
Current Lim Cont, Proportional Gain.....	215

D

direction of motor rotation	106
D-axis Inductance (Ld)	151
D-gain	187
Data Character (byte).....	245
DC brake	155, 159, 192, 252
DC Braking Time	159

— Index —

DC coil	19	Frequency	223, 262
DC hold	155, 155, 156, 159	Function at Stop	156
DC link	159, 160, 274	Fuses	93
DC Link Voltage	223		
Dead Band	30		
Default Settings	137, 228	G	
Default value	268	grounding	111
Definitions	8	Galvanic Isolation (PELV)	47
Derating for Air Pressure	65	General warning	7
Derating for Ambient Temperature	65	Graphical display	123
Derating for Running at Low Speed	65	Ground connection	88
DeviceNet	7, 77	Ground Leakage Current	47, 108
Digital inputs:	59	Grounding of Shielded/Armored Control Cables	111
Display line 1.3 Small	143	Grounding plate	89
Display line 2 large	144		
Display Mode	128	H	
Display Mode - Selection of Read-Outs	128	Harmonic filters	80
Drive Configurator	73	Heat sink	85
Dynamic brake	159	Heatsink Temp	224
		High Voltage Test	108
E		Hot-pluggable LCP	19
Efficiency	63		
Electrical Installation	92, 95, 97	I	
Electrical Installation - EMC Precautions	108	Incremental encoder	224
Electromechanical brake	118	Indexed Parameters	133
Electronic Terminal Relay	157	Infinitely Variable Change of Numeric Data Value	132
EMC Test Results	44	Initialization	137
Encoder feedback	21	Intermediate circuit	49, 52, 64, 64, 216, 274
Encoder Positive Direction	227	Internal Current Control	42
Encoder pulses	182	Iron Loss Resistance (Rfe)	151
End-of-Timeout Function	190	IT mains	216
Equalizing cable,	111		
ETR	106, 157, 223, 274	J	
External 24 V DC supply	71	Jog	9, 252, 257
External reference	28, 224	Jog Ramp Time	169
Extreme Running Conditions	52	Jog Speed [RPM]	164
F		K	
Fault Log: Error Code	219	KTY sensor	274
Fault Log: Time	220	KWh Counter	217
Fault Log: Value	220		
FC Profile	251	L	
Flux	24, 25	Local Control Panel	123
Flying Start	155		
Freeze output	9, 190, 252		
Freeze reference	28		
Freq. Input #29 [Hz]	225		
Freq. Input #33 [Hz]	225		

— Index —

Lower limit	267
Language	139
LC filter	72, 90
LC Filters	72
LCP	9, 11, 26, 72, 127, 134
LCP 101	19
LCP 102	19, 123
LCP Copy	146
LCP ID Num.	220
Leakage Current	48
LEDs	123, 124
Load sharing	103
Load Type	155
Local (Hand on) and Remote (Auto on) Control	26
Local Control Keys	135
Local reference	139

M

Mechanical dimensions	85
motor nameplate	99
Main Menu	129
Main Menu mode	125, 130
Main reactance	150
Main Reactance (Xh)	151
Mains Failure	213
Mains plug connector	88
Mains supply	13, 55, 57
Mains supply (L1, L2, L3)	58
Mains Supply Interference	112
Mains Voltage at Mains Fault	213
Max Output Frequency	171
Maximum Inertia	155
Maximum Limit	170
Mechanical Brake	50, 161
Mechanical dimensions	86
Mechanical Installation	84
Min Speed for Function at Stop [Hz]	156
Min Speed for Function at Stop [RPM]	156
Minimum Inertia	155
Minimum Limit	170
Missing Motor Phase Function	173
Moment of inertia	52
Motor Angle Offset	152
Motor Cables	90
Motor cables	108
Motor connection	89
Motor Cont. Rated Torque	150
Motor Current	149
Motor Feedback	25, 148

Motor Frequency	149
Motor Nominal Speed	149
Motor output	58
Motor parameters	25, 118
Motor phases	52, 173
Motor Poles	152
Motor Power [HP]	149
Motor Power [kW]	149
Motor protection	58, 106, 157
Motor Rotation	106
Motor Speed Unit	139
Motor Thermal Protection	53, 156, 255
Motor voltage	64, 149, 223

N

Name	267
Nameplate data	99, 99
Non-UL compliance	94
Number of elements	265
Numerical Local Control Panel	134

O

Operating Hours	217
Operating mode	139
Operating State at Power-up (Hand)	139
Operation Mode	214
Ordering Form Type Code	74
Ordering numbers	73
Ordering Numbers: Brake Resistors	78
Ordering Numbers: Harmonic Filters	80
Ordering Numbers: LC Filter Modules	80
Ordering Numbers: Options and Accessories	77
Output data (U, V, W)	58
Output frequency	61
Output speed	155
Over-voltage Control	160

P

Parameter Selection	131
Parameter Set-Up	129
Passive load	155
Peak Voltage	64
PLC	111
Potentiometer Reference	116
Power Factor	13
Power Restore	170

— Index —

Power-ups.....	217
Pre-magnetizing	156
Preheat	159
Preset Reference.....	163
Preset Reference Select.....	193
Process PID Control	37
Profibus.....	6, 77
Profibus Warning Word.....	196
PROFIdrive Profile	256
Programming of Torque Limit and Stop	118
ProportionalGain	187
Protection	20, 47, 48, 93
Protection and Features	58
Protocols	243
Pulse Reference	224
Pulse start/stop	115
Pulse/encoder inputs	60

Q

Quick Menu	125, 129
Quick Menu mode.....	125, 129
Quick Menu Password	147
Quick Menus	125
Quick Stop Ramp Time.....	169
Quick Stop Select	192
Quick Transfer of Parameter Settings	127

R

Ramp 1 Ramp-down Time.....	165
Ramp 1 Ramp-up Time	165
Ramp 1 Type.....	164
Ramp 2 Ramp-down Time.....	166
Ramp 3 Ramp-down Time.....	167
Ramp 3 Ramp-up Time	167
Ramp 4 Ramp-down Time.....	168
Ramp Delay	170
Ramp Time.....	170
Rated motor speed	9
RCD	12, 48
Read Parameter Description Elements	263
Reference Handling	28
Reference Resource 1	163
Regional Settings	139
Relative Scaling Reference Resource	164
Relay connection.....	104
Relay outputs.....	61, 177
Reset.....	126
Reset Control Word Timeout	191

Reset kWh Counter	217
Reset Mode	214
Residual Current Device	48
Rise time	64
Rotor Leakage Reactance (X2)	151
Rotor Resistance (Rr)	151

S

shielded/armored	98
Step-by-Step	133
Safe Stop.....	19, 53
Safe Stop Installation	101
Safety Grounding	108
Scaling of References and Feedback.....	29
Serial communication	10, 62, 111, 261
Side-by-side installation	86
Smart Logic Controller	51, 203
Software versions.....	77
Speed control, closed loop	148
Speed control, open loop	148
Speed PID.....	21, 23
Speed PID Control	34
Speed PID Lowpass Filter Time.....	187
Start Delay	155, 155
Start Function	155, 155
Start Speed [Hz].....	156
Start Speed [RPM].....	156
Start/Stop.....	115
Stator leakage reactance.....	150
Stator Leakage Reactance (X1)	151
Stator Resistance (Rs)	151
Status.....	125
Status messages.....	123
Status Word	254, 259
Step Size	170
Surroundings	62
Switches S201, S202, and S801	98
Switching Frequency	213

T

Telegram Structure	243
Telegram Traffic	243
Temperature-Dependent Switch Frequency	66
Term 32/33 Encoder Direction	182
Term 32/33 Gear Denominator.....	182
Term 32/33 Gear Numerator.....	182
Term. 29 Low Frequency	180
Terminal 10	96

— Index —

Terminal 37	53
Terminal 53 High Current.....	184
Terminal 53 Low Current	183
Terminal 54 High Current.....	184
Terminal 54 Low Current	184
Thermal load	152, 223
Thermal motor protection	91
Thermistor	12, 157
This Set-up Linked to	140
Tightening torques	99
Torque characteristics.....	58
Torque control.....	21
Torque limit	166, 168, 169
Torque Limit Generator Mode	171
Trip Delay at Torque Limit	215

U

Upper limit	268
USB Connection	96
Use of EMC-Correct Cables.....	110

V

Variable torque.....	148
Vibration and Shock	20
Voltage level	59
VVC ^{plus}	12, 23, 148

W

Warning Word	226
Warnings	271

2

24 V encoder	148
--------------------	-----

4

485 V DC.....	60
---------------	----

[

[Reset] Key on LCP	146
--------------------------	-----