

Danfoss PLUS+1 WS Telematics Drivers

Release Notes

This file contains important supplementary and late-breaking information that may not appear in the main product documentation. We recommend that you read this file in its entirety.

Risk Reduction

This file contains important supplementary and late-breaking information that may not appear in the main product documentation. We recommend that you read this file in its entirety.

Fixes to known issues in the tool will only be made in the latest version; previous versions will not be patched. Known issues that remain in the release are described in the section Important Advisory - Potential User Issues.

It is recommended to always use the latest released version to benefit from the latest improvements. If another version than the latest released version is used, carefully read the What Is Fixed sections for all later releases to understand what known risks that exists and need to be addressed.

For more details on risk reduction, see chapter Risk Reduction in PLUS+1 GUIDE User Manual.

System requirements

	Service Tool Minimum	GUIDE Minimum	GUIDE/Service Tool Recommended
CPU*	1.5 GHz, 32-bit (x86), 1 core, 2008 or later		3.0 GHz, 64-bit (x64), 4 cores, 2012 or later
OS	32-bit Windows 7		64-bit Windows 7/8/8.1/10
UAC	Local Administrator Access		
RAM	1 GB		3 GB
HD	>1 GB Free, HDD		>2 GB Free, SSD
Resolution	1024 x 768		1920 x 1080
Email	For license registration		
PDF	Any recent standards compliant pdf reader		
XML	MSXML 4.0 Service Pack 2 (Microsoft XML Core Services)		
.Net	N/A	Version 4 (Full) is needed for PLC code support in GUIDE	

* The CPU should be intended for at least laptop use. Processors designed for netbooks, tablets or similar are not recommended.

VERSION 1.0.13 (August 2016)

-New Features and Functionality

[F00376] **Feature Extension:** Display Network Mode
- The network mode is now displayed in the status dialog.

[F00377] **Feature Extension:** Miniature Map
- A miniature map is now displayed in the connection status window.

-What is Fixed

[P100003841] The connection status dialog now displays the correct device speed.

[P100003573] The speed and altitude is now shown as 'Unknown' when not available.

[P100003556] The device was reported as 'Busy' after a failed connection attempt.

[P100003554] Some error descriptions have been improved.

[P100003442] The connection was not reported as lost in certain situations.

Product Information on the Web

For technical support, visit the Danfoss support pages:

powersolutions.danfoss.com/Products/MobileElectronics/PLUS1Guide/PLUS1GuideSupport/index.htm

Telephone support:

North America: 1.888.50PLUS1 (+1-888-507-5871)

Europe: +46 476-569 06

Email support: plus+1helpdesk@danfoss.com

PLUS+1 Forum: <http://www.plus1forum.danfoss.com/index.php>

Please report all suggested enhancements and great ideas to:

PLUS+1 Help desk

Please report all defects to:

PLUS+1 Help desk

Many thanks for all of your support.

The System Development Tools Team.

Disclaimer

The Danfoss Software License Agreement completely defines the licensed use of this software. Information in this document is provided in connection with Danfoss PLUS+1 GUIDE tool set. No license, express or implied, to any intellectual property rights is granted by this document. Danfoss disclaims all warranties and liabilities for the use of this document and the information contained herein and assumes no responsibility for any errors, which may appear in this document, nor does Danfoss make a commitment to update the information contained herein. Danfoss reserves the right to make changes to this document at any time, without notice.

Copyright

©2004-2016 Danfoss. All rights reserved.

Third party trademarks and brand names are the property of their respective owners.

Previous Release Notes

Release notes dating back to 1.0.10 follow:

VERSION 1.0.12 (September 2015)

-New Features and Functionality

- [F00315] **Feature Extension:** Change device mode
- It is now possible to change device mode for devices in the login dialog.
 - Press the "Change Mode" button to set an "Online" device to "Online (DLM)" and vice versa.
- [F00318] **Feature Extension:** Device list sorting
- It is now possible to sort the device list in the login dialog.
 - Click the device list column headers to sort the list according to the clicked column.

-What is Fixed

- [P100003314] Occasional download issues have been fixed. Remember to use at least Service Tool version 7.1.11 for optimal performance.
- [P100003416] The gateway driver would occasionally crash the Service Tool when closing the connection.
- [P100003420] Some error descriptions have been improved.

VERSION 1.0.11 (May 2015)

-What is Fixed

- [P100003343] The port validation in the login dialog is now updated with the correct address.
- [P100003347] Occasional download issues have been fixed. Please use Service Tool version 7.1.11 for optimal performance.
- [P100003409] An issue where the download failed when downloading an application with a different node number to an SC controller have been fixed.

VERSION 1.0.10

-New Features and Functionality (see the User Manual for more detailed information)

[F00243] **Feature:** First version of the RP1210 drivers for WS Telematics