






























Installation guide – Spare parts and accessories

Repair kit | Code number 027F3150

PM, MRV, size 5 to 25 | MEV, PMFH, PMFL, sizes 80-1 to 80-7



1  = Alu.  Total no. = 1	2  = Fibre  Total no. = 4	3   Total no. = 3	4  = Alu.  Total no. = 1	5  = Alu.  Total no. = 1	6  = Fibre  Total no. = 1
7  = Fibre  Total no. = 2	8  = Fibre  Total no. = 1	9  = Alu.  Total no. = 1	10*  = Alu.  Total no. = 1	11   Total no. = 1	12   Total no. = 1
13   Total no. = 1	14   Total no. = 1				

* The spare part is included in the package but is not used for PM, MRV 5 to 25 or MEV, PMFH, PMFL 80-1 to 80-7