



# Instructions


## Access box - 084B2071




084R9502



R11JR452



DANFOSS  
AB4B2168.10



DANFOSS  
AB4B1022.12


Det er vigtigt, at installationen af datakommunikationskablet udføres korrekt.  
Se separat litteratur nr. RC.OX.A...

It is important that the installation of the data communication cable be done correctly.  
Cf. separate literature No. RC.OX.A...


Bitte beachten, dass die Installation des Datenkommunikationskabels korrekt vorgenommen wird.  
Siehe separate Literatur Nr. RC.OX.A...

Il est très important que l'installation du câble de transmission soit effectuée correctement.  
Se reporter au document spécifique RC.OX.A...

**l < 3 m**




DANFOSS  
AB4B1585.10




DANFOSS  
AB4B1386.11

**l > 3 m**

1)




DANFOSS  
AB4B1587.10




5 V d.c. ±5%  
100 mA

DANFOSS  
AB4B1588.11

2)



DANFOSS  
AB4B1589.10



5 V d.c. ±5%  
100 mA

R =  
120 ohm  
1400 ohm  
1400 ohm

DANFOSS  
AB4B1584.15