

# Installation guide


## Solenoid valve

### Type EV210B


032R9272

032R9272


**A**




**B**




**1**




**2**




**3**



**4**



**5**



**6**

