

















Installation guide – Spare parts and accessories

Overhaul kit | Code number 148B6152
SVA-S/L, SVA-ST/LT, SVA-HS, sizes 25-40



<p>1</p> <p> = Nylon</p> <p> $\varnothing 37 \text{ mm}$ $\varnothing 1.46''$</p> <p>Total no. = 1</p>	<p>2</p> <p> = Alu.</p> <p> $\varnothing 19 \text{ mm}$ $\varnothing 0.75''$</p> <p>Total no. = 1</p>	<p>3</p> <p></p> <p> $\varnothing 31 \text{ mm}$ $\varnothing 1.22''$ $\varnothing 41 \text{ mm}$ $\varnothing 1.61''$</p> <p>Total no. = 1</p>	<p>4</p> <p></p> <p> $\varnothing 37 \text{ mm}$ $\varnothing 1.46''$</p> <p>Total no. = 1</p>	<p>5</p> <p> = Fibre</p> <p> $\varnothing 54 \text{ mm}$ $\varnothing 2.13''$</p> <p>Total no. = 1</p>
<p>7</p> <p> $\varnothing 28 \text{ mm}$ $\varnothing 1.1''$</p> <p>Total no. = 1</p>	<p>9</p> <p> M4</p> <p>Total no. = 1</p>	<p>10</p> <p> $\varnothing 3 \text{ mm}$ $\varnothing 0.118''$</p> <p>Total no. = 14</p>	<p>11</p> <p> $\varnothing 40 \text{ mm}$ $\varnothing 1.57''$</p> <p>Total no. = 1</p>	<p>12</p> <p></p> <p>Total no. = 1</p>

NOTE: When replacing the packing gland (pos. 7) in SVA-S/L, SVA-ST/LT or SVA-HS the aluminium gasket (pos. 2) is needed.