



DIRECT CONNECT ANTENNA

100473



Installation and servicing of Danfoss Turbocor® compressors by qualified and product trained personnel only. Follow these instructions and sound refrigeration/electrical/servicing practices relating to installation, commissioning, maintenance, and service.

<p>Consult the appropriate Danfoss LLC Service Manual on www.turbocoroem.com for detailed service instructions.</p>	<p>Never power compressor without covers in place and secured.</p> <p>Removing the mains input cover will expose you to a voltage hazard of up to 575V. Ensure the mains input power is off and locked out before removing cover.</p> <p>Before removing top cover, wait at least 20 minutes after isolating AC power to allow the high voltage capacitors to discharge.</p>	<p>Always wear appropriately rated safety equipment when working around equipment and/or components energized with high voltage.</p> <p>This equipment contains hazardous voltages that can cause serious injury or death.</p>	<p>Recover all refrigerant from compressor in accordance with local codes and ensure pressure is fully vented before the removal of refrigerant containing components.</p>
--	---	---	---

1 - Introduction




Figure 1 – Direct Connect Antenna

This kit contains the Direct Connect Antenna to be used with the Gateway.

These instructions contain the basic steps regarding the installation of the antenna. It is highly recommended to also reference the detailed instructions in our Gateway Installation and Operation Manual when installing the antenna. The manual will provide further illustrations and details that will assist the installer with the necessary information to complete the installation.

We have made the **Gateway Installation and Operation Manual** available to anyone. To access the manual, you may scan the applicable QR code below or you may go to our website at www.turbocoroem.com. At the bottom of the page there is a Section named "Categories" that includes various menus including one for Manuals.

Refer to the applicable QR code below to download the Gateway Installation and Operation Manual.

English



Chinese



2 - Gateway Installation

1. Install the Antenna.





Figure 2 - Antenna Installation

3 - Kit Contents

NOTE: Any part numbers included in the kit contents are internal part numbers only. Please refer to our Spare Parts Manuals for any kit part numbers.

KIT	100473	
QTY	Part(s) Description	Picture(s)
2	ANTENNA, DIRECT CONNECT	



4 - List of Changes

Revision	Date	Description of Change
A	5/11/2023	New

Danfoss LLC can accept no responsibility for possible errors in catalogues, brochures, and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.