# **KIT** Cable Harness Soft Start SCR Gate Cable

# 100059 & 100059-1.

Installation and servicing of Danfoss Turbocor® compressors by qualified and product trained personnel only. Follow these instructions and sound refrigeration/electrical/servicing practices relating to installation, commissioning, maintenance and service.							
Consult the appropriate Danfoss LLC Service Manual on www.turbocoroem.com for detailed service instructions.	Never power compressor without covers in place and secured. Removing the mains input cover will expose you to a voltage hazard of up to 575V. Ensure the mains input power is off and locked out before removing cover. Before removing top cover, wait at least 20 minutes after isolating AC power to allow the high voltage capacitors to discharge.	appropriately rated safety equipment when working around equipment and/or components energized with high voltage. This equipment contains hazardous voltages that can cause serious injury or death.	Recover all refrigerant from compressor in accordance with local codes and ensure pressure is fully vented before the removal of refrigerant containing components.				

# 1 - Introduction:

CABLE HARNESS SOFT START SCR GATE CABLE replacement.

This kit contains the Soft Start SCR Gate Cable.

#### Please refer to our Service Manual for the replacement instructions.

We have made the **TTS/TGS/TTH/TGH Service Manual** available to anyone. To access the manual, you may scan the applicable QR code below or you may go to our website at <u>www.turbocoroem.com</u>. At the top of the page there is a pull-down menu called "Quick Links." Click this menu and select the appropriate service manual.

Refer to the applicable QR code below to download the TTS/TGS/TTH/TGH Service Manual.







### 2 - General Information:

Isolate compressor power as described in Section "Electrical Isolation of the Compressor" of the Service Manual (M-SV-001) prior to performing any service procedures

# 3 - Kit Contents:

Kit numk	ers Compressor Models		
100059	Rev F and earlier compressors with the Closed-Tip Soft Start		
QTY	Part(s) Description		
1	CABLE HARNESS SOFT START SCR GATE		

Kit numk	ers Compressor Mode	els		
100059-	-1 All Rev H compressors and those that have			
	the Open-Top Soft	t Start		
QTY	Part(s) Description		Picture(s)	
1	CABLE HARNESS SOFT START SCR GATE			

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.