



PLUS+1 Display Function Block Library

70081507v210

Revision History

This file contains important supplementary and late-breaking information that may not appear in the main product documentation. We recommend that you read this file in its entirety.

Version 2.10 (December 2019)

What is Included

- PLUS+1 GUIDE® Function Blocks (In SDL)
- User Manuals (In SDL)

What is New

- Moved the DP6xx legacy function blocks to a sub folder DP6xxLX.
- New Screen_Menu function blocks have been added to support menu creation and navigation for all display applications.

Known issues

- The DP6xxLX HWD files (v100) do not support reading from multiple application logs within one application.

Minimum Requirements

- PLUS+1 GUIDE 11.1 or greater
- DP6xxLX Function Blocks require Hardware and HWD files that support the "Read Array from Application Log" and "Write Array to File" symbols.

Version 2.00 (June 2016)

What is Included

- PLUS+1 GUIDE® Function Blocks (In SDL)
- User Manual (In SDL)

What is New

- Support for Professional Licensing.

Known issues

- The DP6xxLX HWD files (v100) do not support reading from multiple application logs within one application.

Minimum Requirements

- PLUS+1 GUIDE 8.1 or greater
- Hardware and HWD files that support the "Read Array from Application Log" and "Write Array to File" symbols.
- PLUS+1 GUIDE 8.1 or greater
- Hardware and HWD files that support the "Read Array from Application Log" and "Write Array to File" symbols.

Version 1.00 (June 2012)

What is Included

- PLUS+1 GUIDE® Function Blocks (In SDL)
- User Manual (In SDL)

What is New

- 2 New function blocks to support transferring data from the onboard Application Log to an external USB memory storage device.
 - Read_AppLog
 - Write_USB

Known issues

- The currently released DP6xxLX HWD files (v100) do not support reading from multiple application logs within one application.

Minimum Requirements

- PLUS+1 GUIDE 5.1 or greater
- Hardware and HWD files that support the "Read Array from Application Log" and "Write Array to File" symbols.

Support

Web

<https://www.danfoss.com/en/products/software/dps/plus1-software-services-support-and-training/plus1-support-and-services/>

Telephone

North America: Toll free number 1-888-50PLUS1 (1-888-507-5871)

Europe: +46 476-569 06

E-mail

plus1helpdesk@danfoss.com

Terms of Use

The Danfoss Software License Agreement completely defines the licensed use of this software.

Information in this document is provided in connection with Danfoss PLUS+1 Tool set. No license, express or implied, to any intellectual property rights is granted by this document.

Danfoss disclaims all warranties and liabilities for the use of this document and the information contained herein and assumes no responsibility for any errors, which may appear in this document, nor does Danfoss make a commitment to update the information contained herein. Danfoss reserves the right to make changes to this document at any time, without notice.

Copyright

© 2019 Danfoss, Inc. All rights reserved.

Third party trademarks and brand names are the property of their respective owners.