



PLUS+1[®] Compliance Digital Displacement Pump HWD 70512290v100

Revision History

This file contains important supplementary and late-breaking information that may not appear in the main product documentation. We recommend that you read this file in its entirety.

Version 1.00 (September 2021)

What is Included

- PLUS+1 GUIDE Function Block (In HWD)
- PLUS+1 Service Tool Advanced Parameter Pages (In HWD)
- User Manual (In HWD)
- Recommended Machine Startup Procedures (In HWD)

What is New

This is a new software package to support the Digital Displacement Pump. It includes logic to control the services on the device and receive feedback information from the device.

Known issues

- None

Minimum Requirements

- PLUS+1 GUIDE 11.1 or greater
- PLUS+1 Service Tool 11.1 or greater

Support

Web

<https://www.danfoss.com/en/products/dps/software/software-and-tools/plus1-software/#tab-support>

Create a PLUS+1 Helpdesk Case

<http://plus1helpdesk.danfoss.com/>

Terms of Use

The Danfoss Software License Agreement completely defines the licensed use of this software.

Information in this document is provided in connection with Danfoss PLUS+1 Tool set. No license, express or implied, to any intellectual property rights is granted by this document.

Danfoss disclaims all warranties and liabilities for the use of this document and the information contained herein and assumes no responsibility for any errors, which may appear in this document, nor does Danfoss make a commitment to update the information contained herein. Danfoss reserves the right to make changes to this document at any time, without notice.

Copyright

© 2021 Danfoss, Inc. All rights reserved.

Third party trademarks and brand names are the property of their respective owners.