WIRE COLOR SCHEME TERMINAL IDENTIFICATION BLACK - LINE VOLTAGE X - DRIVE TERMINAL RED - AC CONTROL WHITE - AC GROUNDED - CUSTOMER TERMINAL CIRCUIT CONDUCTOR
BLUE - DC CONTROL GREEN - CHASSIS GROUND EARTH GROUND EARTH GROUND GRN / \* AC MOTOR 1  $\mathcal{T}$ OL1 (SEE NOTES 6) 4T1 (L1) M2 (T1) 2T1 \*CUSTOMER (L1) | (T1) 3L1 (U1) (U2) 4L1 | F16A| 5L1 | L1/R/91 1T1 (L1) <u>T1</u> VLT INPUT SUPPLIED T1/U/96 -TF18AT-POWER ADJUSTABLE FREQUENCY 1T2 (L2) T2 BLK 2L2 (L2) (T2) 3L2 (V1) (V2) 4L2 (F16B) 5L2 L2/S/92 4T2 (L2) (T2) FEEDER L2 --ó | ò--^` -[F18B]}-3 PH, 208V, T2/V/97 (L3) (L3) (X3) 3L3 (W1) (W2) 4L3 (F16C) 5L3 L3/T/93 DRIVE 1T3 (L3) T3 CIRCUIT BLK 2L3 4T3 (L3) (T3) PROTECTION ۸\_ن T3/W/98 -TF18CT-(AFD) 60Hz (SEE NOTE 3) CB1 INPUT DRIVE INPUT FUSES CIRCUIT \*AC MOTOR 2 REACTOR BREAKER (SEE NOTES 6) (L1) (T1) (L2) (T2) OL2 3T1 (L1) T1 3T2 (L2) T2 EARTH GROUND GRN [F19A] (T2 T3 F19B 3T3 (L3) (L3) (T3) -[F19C] H2 H3 H4) 163 RED X3 100 WHT F12 115VAC 250V (12) 5 (11) TS1 HEATER (SET: 65° F) CR6 167 (1)-2)FAN 1 (SET: 80° F) (9) (5) (23) (24) TB2 TS1 TO SHEET 2 TO SHEET 2

## WARNING!

THE FOLLOWING TABLE LISTS THE PARAMETERS THAT ARE SET DIFFERENT FROM THE DRIVE DEFAULT SETTINGS. ADDITIONAL PARAMETER SETTINGS MAY BE REQUIRED FOR YOUR APPLICATION.

## NOTES:

- 1. \* INDICATES COMPONENTS NOT SUPPLIED BY MANUFACTURER.
- 2. REFER TO THE INSTALLATION AND OPERATION MANUAL FOR DRIVE FUNCTIONS AND PARAMETER SETTINGS.
- 3. FEEDER CIRCUIT PROTECTION, INPUT POWER AND MOTOR WRING MUST BE SELECTED IN ACCORDANCE WITH THE N.E.C., ANY APPLICATION LOCAL CODES AND THE LOAD CURRENT RATING.
- 4. REPLACE JUMPER 'J1' WITH NORMALLY CLOSED SAFETY INTERLOCK CONTACT AS NECESSARY. CONTACT MUST BE RATED 1/4 HP @ 120VAC MINIMUM.
- 5. PANEL MAY REQUIRE DERATING, CONSULT DRIVE MANUAL OR FACTORY FOR FOLLOWING CONDITIONS:
- 5.1. HIGHER SWITCHING FREQUENCY THAN DRIVE DEFAULT
- 5.2. HIGHER THAN PANEL LISTED AMBIENT TEMPERATURES
- 5.3. ELEVATION ABOVE 3300 FEET (1000 METERS)
- 5.4. LONG MOTOR LEAD LENGTHS
- 6. WHEN MOTOR OVERLOADS SIZES ARE DIFFERENT, MOTOR 1 WILL BE THE LARGER OF THE TWO MOTORS

## DRIVE PARAMETER SETTINGS

PARAMETER #	NAME	SETTING	VALUE	
0-02	MOTOR SPEED UNIT	1	HZ	
0-03	REGIONAL SETTINGS	1	NORTH AMERICA	
1-03	-03 TORQUE CHAR. 1 VARIABL		VARIABLE TORQUE	
5-02	TERMINAL 29 TYPE	29 TYPE 1 OUTPUT		
5-11	TERMINAL 19	52	RUN PERMISSIVE	
5-31	TERMINAL 29	5	RUNNING	
5-40[0]	RELAY 1	160	NO ALARM	
5-40[1]	RELAY 2	AY 2 167 START COMMAND		
14-20	RESET MODE	13	INFINITE AUTO REST	

В			- NOTICE - THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF DANFOSS DRIVES.	DRN	NAME		EMA 3R,208V,3C	- Lu
А	SP10119	11/10	IT IS LOANED BY DANFOSS DRIVES SUBJECT TO THE CONDITIONS THAT IT AND THE INFORMATION EMBODIED THEREIN SHALL BE USED ONLY FOR RECORD AND REFERENCE PURPOSES, SHALL NOT BE USED OR CAUSED TO BE USED IN ANY WAY PREJUDICIAL TO THE INTERESTS OF DANFOSS DRIVES, SHALL NOT BE REPRODUCED OR COPIED IN WHOLE OR IN PART, OR DISCLOSED	DIM	,MAIN CB ,DRIVE FUSE		Janjuos	
DR	SP10076	09/10		apr D <i>TM</i>	,3MB2,IR,DUAL MOTOR,1 FAN MODEL SIZE A DWG 1 0 5 0 0 1 4			
REV	ECN	DATE	TO ANYONE WITHOUT THE DIRECT WRITTEN PERMISSION OF DANFOSS DRIVES AND SHALL BE RETURNED UPON REQUEST.		MODEL	VLT	page $1$ of $2$ Size $A$ No. 18	5BUZ14

