TERMINAL IDENTIFICATION

X - DRIVE TERMINAL

X - CUSTOMER TERMINAL

EARTH GROUND EARTH GROUND H* AC MOTOR 4T1 (L1) M2 (T1) 2T1 L1 (L1) (T1) 1L1 BLK [F15A] 2L1 (U1) (U2) 4L1 (F16A) 5L1 (L1/R/91 VLT T1/U/96 (V1) (V2) 4L2 |F16B| 5L2 |L2/S/92 ADJUSTABLE FREQUENCY 4T2 (L2) (T2) (L2) T2 FEEDER L2 (L2) (T2) 1L2 BLK | F15B| 2L2 T2/V/97 3 PH. (W1) (W2) 4L3 [F16C] 5L3 L2/5/92 L3/T/93 DRIVE CIRCUIT L3 (L3) (T3) 1L3 BLK |F15C|| 2L3 4T3 (L3) (T3) 480V, PROTECTION T3/W/98 (AFD) 60Hz (SEE NOTE 3) INPUT DRIVE INPUT FUSES MAIN DISCONNECT FUSES REACTOR EARTH GROUND GRN (L1) (T1) (L2) (T2) (L3) (T3) 163 RED X2 F12 115VAC HEATER (SET: 65° F) (12) 5 (11) TS1 CR6 167 7)FAN 1 (SET: 80°F) TB2 TO SHEET 2 TO SHEET 2

WARNING!

THE FOLLOWING TABLE LISTS THE PARAMETERS THAT ARE SET DIFFERENT FROM THE DRIVE DEFAULT SETTINGS. ADDITIONAL PARAMETER SETTINGS MAY BE REQUIRED FOR YOUR APPLICATION.

NOTES:

1. * INDICATES COMPONENTS NOT SUPPLIED BY MANUFACTURER.

- 2. REFER TO THE INSTALLATION AND OPERATION MANUAL FOR DRIVE FUNCTIONS AND PARAMETER SETTINGS.
- 3. FEEDER CIRCUIT PROTECTION, INPUT POWER AND MOTOR WIRING MUST BE SELECTED IN ACCORDANCE WITH THE N.E.C., ANY APPLICATION LOCAL CODES AND THE LOAD CURRENT RATING.
- 4. REPLACE JUMPER 'J1' WITH NORMALLY CLOSED SAFETY INTERLOCK CONTACT AS NECESSARY. CONTACT MUST BE RATED 1/4 HP @ 120VAC MINIMUM.
- 5. PANEL MAY REQUIRE DERATING, CONSULT DRIVE MANUAL OR FACTORY FOR FOLLOWING CONDITIONS:
- 5.1. HIGHER SWITCHING FREQUENCY THAN DRIVE DEFAULT
- 5.2. HIGHER THAN PANEL LISTED AMBIENT TEMPERATURES
- 5.3. ELEVATION ABOVE 3300 FEET (1000 METERS)
- 5.4. LONG MOTOR LEAD LENGTHS

DRIVE PARAMETER SETTINGS

PARAMETER #	NAME	SETTING	VALUE	
0-02	MOTOR SPEED UNIT	1	HZ	
0-03	REGIONAL SETTINGS	1	NORTH AMERICA	
1-03	TORQUE CHAR.	3	AUTO ENERGY OPTIM VT	
5-02	TERMINAL 29 TYPE	1	OUTPUT	
5-31	TERMINAL 29	5	RUNNING	
14-20	RESET MODE	13	INFINITE AUTO REST	

В		
А	SP10119	11/10
DR	SP10076	09/10
REV	ECN	DATE

- NOTICE
THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF DANFOSS DRIVES.
IT IS LOANED BY DANFOSS DRIVES SUBJECT TO THE CONDITIONS THAT IT AND
THE INFORMATION EMBODIED THEREIN SHALL BE USED ONLY FOR RECORD
AND REFERENCE PURPOSES, SHALL NOT BE USED OR CAUSED TO BE USED
IN ANY WAY PREJUDICIAL TO THE INTERESTS OF DANFOSS DRIVES, SHALL
NOT BE REPRODUCED OR COPIED IN WHOLE OR IN PART, OR DISCLOSED
TO ANYONE WITHOUT THE DIRECT WRITTEN PERMISSION OF DANFOSS DRIVES
AND SHALL BE RETURNED UPON REQUEST.

drn *D TM*

DTM

APR

NAME NEMA 3R,480V,2C , MAIN DISC, MAIN & DRIVE FUSE

,3MB1,IR,SINGLE MOTOR,1 FAN

Danford

MODEL VLT PAGE <u>1</u> OF <u>2</u>

L OF <u>Z</u>

DWG 185B0501

WIRE COLOR SCHEME
BLACK - LINE VOLTAGE
RED - AC CONTROL
WHITE - AC GROUNDED

WHITE - AC GROUNDED CIRCUIT CONDUCTOR BLUE - DC CONTROL GREEN - CHASSIS GROUND

TERMINAL IDENTIFCATION

X - DRIVE TERMINAL


CUSTOMER TERMINAL


CUSTOMER DRY CONTACT RATINGS

RELAY	CONTACT RATING		
CR1, CR6	5A @ 120VAC 1/10 HP @ 120VAC		
M2, M3	10A @ 120/240VAC		

CONTACT SEQUENCE CHART FOR S1 X INDICATES CONTACT CLOSED

X INDICATES CONTACT CLUSED				
POSITION				
CONTACT	DRIVE	OFF	BYPASS	
13-14			Χ	
23-24	X			





В		
Α	SP10119	11/10
DR	SP10076	09/10
REV	ECN	DATE

- NOTICE
THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF DANFOSS DRIVES.
IT IS LOANED BY DANFOSS DRIVES SUBJECT TO THE CONDITIONS THAT IT AND
THE INFORMATION EMBODIED THEREIN SHALL BE USED ONLY FOR RECORD
AND REFERENCE PURPOSES, SHALL NOT BE USED OR CAUSED TO BE USED
IN ANY WAY PREJUDICIAL TO THE INTERESTS OF DANFOSS DRIVES, SHALL
NOT BE REPRODUCED OR COPIED IN WHOLE OR IN PART, OR DISCLOSED
TO ANYONE WITHOUT THE DIRECT WRITTEN PERMISSION OF DANFOSS DRIVES
AND SHALL BE RETURNED UPON REQUEST.

ORN	NAME		Ν
D TM	,	MAIN	D
		,3MB	1 1
A D D		, 01010	١,١

DTM

NEMA 3R,480V,2C MAIN DISC, MAIN & DRIVE FUSE ,3MB1,IR,SINGLE MOTOR,1 FAN



MODEL VLT PAGE 2 OF 2 SIZE A DWG 1858050