

NOTES:

1. * INDICATES COMPONENTS NOT SUPPLIED BY MANUFACTURER.

2. REFER TO THE INSTALLATION AND OPERATION MANUAL FOR DRIVE FUNCTIONS AND PARAMETER SETTINGS.

3. FEEDER CIRCUIT PROTECTION, INPUT POWER AND MOTOR WIRING MUST BE SELECTED IN ACCORDANCE WITH THE N.E.C., ANY APPLICATION LOCAL CODES AND THE LOAD CURRENT RATING.

4. REPLACE JUMPER 'J1' WITH NORMALLY CLOSED SAFETY INTERLOCK CONTACT AS NECESSARY. CONTACT MUST BE RATED 1/4 HP @ 120VAC MINIMUM.

5. PANEL MAY REQUIRE DERATING, CONSULT DRIVE MANUAL OR FACTORY FOR FOLLOWING CONDITIONS:

5.1. HIGHER SWITCHING FREQUENCY THAN DRIVE DEFAULT

5.2. HIGHER THAN PANEL LISTED AMBIENT TEMPERATURES

5.3. ELEVATION ABOVE 3300 FEET (1000 METERS)

5.4. LONG MOTOR LEAD LENGTHS

DRIVE PARAMETER SETTINGS

| PARAMETER # | NAME | SETTING | VALUE HZ NORTH AMERICA | |
|-------------|-------------------|---------|------------------------------|--|
| 0-02 | MOTOR SPEED UNIT | 1 | | |
| 0-03 | REGIONAL SETTINGS | 1 | | |
| 1-03 | TORQUE CHAR. | 3 | AUTO ENERGY OPTIM VT | |
| 5-02 | TERMINAL 29 TYPE | 1 | OUTPUT | |
| 5-31 | TERMINAL 29 | 5 | RUNNING | |
| 14-20 | RESET MODE | 13 | INFINITE AUTO REST | |
| | | | | |
| | | | | |

THE FOLLOWING TABLE LISTS THE PARAMETERS THAT ARE SET DIFFERENT FROM THE DRIVE DEFAULT SETTINGS. ADDITIONAL PARAMETER SETTINGS MAY BE REQUIRED FOR YOUR APPLICATION.

| В | | | -NOTICE- | DRN | NAME NEMA 3R,208V,3C | | THE TRANE COMPANY | |
|-----|---------|-------|---|--------------------------|----------------------|--------------------------------------|---------------------------|--------------------------------------|
| А | SP10119 | 11/10 | THIS DRAWING IS PROPRIETARY AND SHALL NOT BE COPIED OR ITS CONTENTS DISCLOSED TO OUTSIDE PARTIES WITHOUT THE WRITTEN CONSENT OF THE TRANE COMPANY | DIM ,MAIN CB ,DRIVE FUSE | | | * | A DIVISION OF AMERICAN STANDARD INC. |
| DR | SP10076 | 09/10 | | APR | MODEL | ,3MB,SINGLE MOTOR,2 FAN AMERICAN 317 | | |
| REV | ECN | DATE | | D TM | IMIODEL | TR200 | PAGE 1 OF 2 SIZE A NO. 18 | 5583384 |

