

A

B

C

D

E

F

A

B

C

D

E

F




DISPLAY

-T1  
/2.6:B



VLT FC302 I/O CARD



-K2  
/5.7:E  
Static Start/stop command  
Statisch Start/Stopfbefehl

\* Set point  
Sollwert

Drive signal start active  
FU Signal Start aktiv

Parameter list

Parameter	Description Beschreibung	Value Wert
5-40	Ready	2
5-12	Without function	0

\* Current input, 0-20mA and 4-20mA  
Stromeingang, 0-20 mA und 4-20 mA  
Voltage input, -10 - +10 V DC  
Spannungseingang -10 - +10 V DC

5

7