WIRE COLOR SCHEME TERMINAL IDENTIFICATION BLACK - LINE VOLTAGE RED - AC CONTROL X - DRIVE TERMINAL WHITE - AC GROUNDED - CUSTOMER TERMINAL CIRCUIT CONDUCTOR BLUE - DC CONTROL GREEN - CHASSIS GROUND EARTH GROUND EARTH GROUND GRN / \neg 4T1 (L1) M2 4T2 (L2) (T2) 2T1 * AC MOTOR 1 *CUSTOMER L1 (L1) (T1) 1L1 BLK (F15A) 2L1 5L1 L1/R/91 VLT (L1) (T1) 1T1 (L1) T1 INPUT SUPPLIED T1/U/96 [F16A] F16B 5L2 POWER ADJUSTABLE FREQUENCY (L2) (T2) 1T2 (L2) T2 L2 (L2) (T2) 1L2 BLK F15B 2L2 2T2 FEEDER 3L2 T2/V/97 3 PH, 600V, L2/S/92 DRIVE L3 (L3) (T3) 1L3 BLK ||F15C|| 2L3 |F16B| 5L3 | L2/3/92 | |F16C| 5L3 | L3/T/93 2T3 (L3) (T3) 1T3 (L3) T3 CIRCUIT 3L3 4T3 (L3) (T3) T3/W/98 PROTECTION (AFD) 60Hz (SEE NOTE 3) DRIVE INPUT FUSES DRIVE MAIN MAIN DISCONNECT DISCONNECT FUSES (L1) (T1) (L2) (T2) (L1) (T1) 3T1 (L1) T1 (L2) (T2) 3T2 (L2) T2 *AC MOTOR 2 EARTH GROUND GRN (L3) (T3) (L3) (T3) 3T3 (L3) 163 RED 100 WHT -| F12 |-X2 X3 250V 115VAC T2 3<u>—</u> (12) 5 (11) TS1 HEATER (SET: 65° F) (12) (4) CR6 167 (SET: 80° F) (9) (5) (23) (24) TB2 TS1 TO SHEET 2 TO SHEET 2

WARNING! THE FOLLOWING TABLE LISTS THE PARAMETERS THAT ARE SET DIFFERENT FROM THE DRIVE DEFAULT SETTINGS. ADDITIONAL PARAMETER SETTINGS MAY BE REQUIRED

FOR YOUR APPLICATION.

DRIVE PARAMETER SETTINGS

PARAMETER #	NAME	SETTING	VALUE	
0-02	MOTOR SPEED UNIT	1	HZ	
0-03	REGIONAL SETTINGS	1	NORTH AMERICA	
1-03	TORQUE CHAR.	3	AUTO ENERGY OPTIM VT	
5-02	TERMINAL 29 TYPE	1	OUTPUT	
5-11	TERMINAL 19	52	RUN PERMISSIVE	
5-31	TERMINAL 29	5	RUNNING	
5-40[0]	RELAY 1	160	NO ALARM	
5-40[1]	RELAY 2	167	START COMMAND	
14-20	RESET MODE	13	INFINITE AUTO REST	

NOTES:

- 1. * INDICATES COMPONENTS NOT SUPPLIED BY MANUFACTURER.
- 2. REFER TO THE INSTALLATION AND OPERATION MANUAL FOR DRIVE FUNCTIONS AND PARAMETER SETTINGS.
 3. FEEDER CIRCUIT PROTECTION, INPUT POWER AND MOTOR WIRING MUST BE SELECTED IN ACCORDANCE WITH

THE N.E.C., ANY APPLICATION LOCAL CODES AND THE LOAD CURRENT RATING.

- 4. REPLACE JUMPER 'J1' WITH NORMALLY CLOSED SAFETY INTERLOCK CONTACT AS NECESSARY. CONTACT MUST BE RATED 1/4 HP @ 120VAC MINIMUM.
- 5. PANEL MAY REQUIRE DERATING, CONSULT DRIVE MANUAL OR FACTORY FOR FOLLOWING CONDITIONS:
- 5.1. HIGHER SWITCHING FREQUENCY THAN DRIVE DEFAULT
- 5.2. HIGHER THAN PANEL LISTED AMBIENT TEMPERATURES
- 5.3. ELEVATION ABOVE 3300 FEET (1000 METERS)
- 5.4. LONG MOTOR LEAD LENGTHS

В		THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF DANFOSS DRIVES.	DRN O TAA		EMA 3R,600V,2C	- Les
А	SP10119	11/10 IT IS LOANED BY DANFOSS DRIVES SUBJECT TO THE CONDITIONS THAT IT AND THE INFORMATION EMBODIED THEREIN SHALL BE USED ONLY FOR RECORD AND REFERENCE PURPOSES, SHALL NOT BE USED OR CAUSED TO BE USED	D TM		/E DISC, MAIN & DRIVE FUSE FACT MOTOR SELECT.1 FAN	Janjuos
DR	SP10076	09/10 IN ANY WAY PREJUDICIAL TO THE INTERESTS OF DANFOSS DRIVES, SHALL NOT BE REPRODUCED OR COPIED IN WHOLE OR IN PART, OR DISCLOSED	APR	MODEL	SIZE A DWC A C	
REV	ECN	DATE TO ANYONE WITHOUT THE DIRECT WRITTEN PERMISSION OF DANFOSS DRIVES AND SHALL BE RETURNED UPON REQUEST.	D TM	VLT	PAGE 1 OF 2 SIZE \bigwedge NO. 1 \bigotimes	32R0806

