WIRE COLOR SCHEME TERMINAL IDENTIFICATION BLACK - LINE VOLTAGE RED - AC CONTROL X - DRIVE TERMINAL WHITE - AC GROUNDED - CUSTOMER TERMINAL CIRCUIT CONDUCTOR BLUE - DC CONTROL GREEN - CHASSIS GROUND EARTH GROUND EARTH GROUND \neg * AC MOTOR 1 4T1 (L1) M2 4T2 (L2) (T2) 2T1 *CUSTOMER L1_(L1) (T1) BLK 2L1 5L1 L1/R/91 VLT (L1) (T1) 1T1 (L1) T1 INPUT SUPPLIED T1/U/96 -[F16B] 5L2 [F16A] POWER ADJUSTABLE FREQUENCY (L2) (T2) 1T2 (L2) T2 (L2) (T2) 3L2 2T2 FEEDER L2 (L2) (T2) BLK 2L2 T2/V/97 3 PH, 600V, L2/S/92 DRIVE |F16B| 5L3 | L2/3/92 | |F16C| 5L3 | L3/T/93 2T3 (L3) (T3) 1T3 (L3) T3 CIRCUIT L3 (L3) (T3) BLK 2L3 (L3) (T3) 3L3 4T3 (L3) (T3) PROTECTION T3/W/98 (AFD) 60Hz (SEE NOTE 3) DRIVE INPUT FUSES DISCONNECT (L1) (T1) (L2) (T2) (L1) (T1) 3T1 (L1) T1 (L2) (T2) 3T2 (L2) T2 *AC MOTOR 2 EARTH GROUND GRN (L3) (T3) (L3) (T3) 3T3 (L3) 163 RED 100 WHT -| F12 | X2 X3 115VAC T2 HEATER (SET: 65° F) (12) (4) (12) 5 (11) TS1 CR6 167 (9) (5) 2)FAN 1 (SET: 80°F) (23) (24) TB2 TS1 TO SHEET 2 TO SHEET 2

WARNING!

THE FOLLOWING TABLE LISTS THE PARAMETERS THAT ARE SET DIFFERENT FROM THE DRIVE DEFAULT SETTINGS. ADDITIONAL PARAMETER SETTINGS MAY BE REQUIRED FOR YOUR APPLICATION.

NOTES:

- 1. * INDICATES COMPONENTS NOT SUPPLIED BY MANUFACTURER.
- 2. REFER TO THE INSTALLATION AND OPERATION MANUAL FOR DRIVE FUNCTIONS AND PARAMETER SETTINGS.
- 3. FEEDER CIRCUIT PROTECTION, INPUT POWER AND MOTOR WRING MUST BE SELECTED IN ACCORDANCE WITH THE N.E.C., ANY APPLICATION LOCAL CODES AND THE LOAD CURRENT RATING.
- 4. REPLACE JUMPER 'J1' WITH NORMALLY CLOSED SAFETY INTERLOCK CONTACT AS NECESSARY. CONTACT MUST BE RATED 1/4 HP @ 120VAC MINIMUM.
- 5. PANEL MAY REQUIRE DERATING, CONSULT DRIVE MANUAL OR FACTORY FOR FOLLOWING CONDITIONS:
- 5.1. HIGHER SWITCHING FREQUENCY THAN DRIVE DEFAULT
- 5.2. HIGHER THAN PANEL LISTED AMBIENT TEMPERATURES
- 5.3. ELEVATION ABOVE 3300 FEET (1000 METERS)
- 5.4. LONG MOTOR LEAD LENGTHS

DRIVE PARAMETER SETTINGS

| PARAMETER # | NAME | SETTING | VALUE | | |
|-------------|-------------------|---------|----------------------|--|--|
| 0-02 | MOTOR SPEED UNIT | 1 | HZ | | |
| 0-03 | REGIONAL SETTINGS | 1 | NORTH AMERICA | | |
| 1-03 | TORQUE CHAR. | 3 | AUTO ENERGY OPTIM VT | | |
| 5-02 | TERMINAL 29 TYPE | 1 | OUTPUT | | |
| 5-11 | TERMINAL 19 | 52 | RUN PERMISSIVE | | |
| 5-31 | TERMINAL 29 | 5 | RUNNING | | |
| 5-40[0] | RELAY 1 | 160 | NO ALARM | | |
| 5-40[1] | RELAY 2 | 167 | START COMMAND | | |
| 14-20 | RESET MODE | 13 | INFINITE AUTO REST | | |

| В | | | - NOTICE - THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF DANFOSS DRIVES. | DRN | NAME | NI | EMA 3R,600V,3C | | The less |
|-----|---------|-------|---|------|---|-----|------------------------------|---------|------------|
| А | SP10119 | 11/10 | IT IS LOANED BY DANFOSS DRIVES SUBJECT TO THE CONDITIONS THAT IT AND THE INFORMATION EMBODIED THEREIN SHALL BE USED ONLY FOR RECORD AND REFERENCE PURPOSES, SHALL NOT BE USED OR CAUSED TO BE USED IN ANY WAY PREJUDICIAL TO THE INTERESTS OF DANFOSS DRIVES, SHALL NOT BE REPRODUCED OR COPIED IN WHOLE OR IN PART, OR DISCLOSED TO ANYONE WITHOUT THE DIRECT WRITTEN PERMISSION OF DANFOSS DRIVES AND SHALL BE RETURNED UPON REQUEST. | D TM | ,MAIN FUSE DISC, DRIVE FUSE .3MB2.CONTACT MOTOR SFLECT.1 FAN | | | | Janjose |
| DR | SP10076 | 09/10 | | APR | , cm22, comment monor care and a | | | , | |
| REV | ECN | DATE | | D TM | MODEL | VLT | PAGE <u>1</u> OF <u>2</u> SI | ZE A D' | % 185B0860 |

