WIRE COLOR SCHEME TERMINAL IDENTIFICATION BLACK - LINE VOLTAGE - DRIVE TERMINAL RED - AC CONTROL WHITE - AC GROUNDED - CUSTOMER TERMINAL CIRCUIT CONDUCTOR BLUE - DC CONTROL GREEN - CHASSIS GROUND EARTH GROUND EARTH GROUND GRN / * AC MOTOR 1 HOL1 (SEE NOTES 6) 4T1 (L1) M2 (T1) 2T1 *CUSTOMER 1T1 (L1) X T1 L1 (L1) (T1) 1L1 BLK (F15A) 2L1 5L1 VLT INPUT SUPPLIED T1/U/96 [F16A] L1/R/91 -TF18AT POWER L2 (L2) (T2) 1L2 BLK |F15B| 2L2 ADJUSTABLE FREQUENCY (L2) (T2) 3L2 5L2 4T2 (L2) (T2) 1T2 (L2) T2 FEEDER [F16B] -[[F18B]]-3 PH, 208V, L2/S/92 T2/V/97 DRIVE 1T3 (L3) T3 CIRCUIT L3 (L3) (T3) 1L3 BLK [F15C] 2L3 (L3) (T3) 3L3 4T3 (L3) (T3) PROTECTION L3/T/93 T3/W/98 -TF18CT (AFD) 60Hz (SEE NOTE 3) DRIVE INPUT FUSES MAIN MAIN *AC MOTOR 2 DISCONNECT **FUSES** (L1) (T1) (L2) (T2) OL2 (SEE NOTES 6) 3T1 (L1) T1 3T2 (L2) T2 EARTH GROUND GRN [F19A] F19B (L3) (T3) 3T3 (L3) F19C 1 H2 H3 H49 163 RED X3 100 WHT -| F12 | 115VAC CR6 (12) 5 (11) TS1 HEATER (SET: 65° F) CR6 167 2)FAN 1 (SET: 80° F) (9) (5) (23) (24) TB2 TS1 FAN 2 TO SHEET 2 TO SHEET 2

WARNING!

THE FOLLOWING TABLE LISTS THE PARAMETERS THAT ARE SET DIFFERENT FROM THE DRIVE DEFAULT SETTINGS. ADDITIONAL PARAMETER SETTINGS MAY BE REQUIRED FOR YOUR APPLICATION.

NOTES:

1. * INDICATES COMPONENTS NOT SUPPLIED BY MANUFACTURER.

- REFER TO THE INSTALLATION AND OPERATION MANUAL FOR DRIVE FUNCTIONS AND PARAMETER SETTINGS.
- FEEDER CIRCUIT PROTECTION, INPUT POWER AND MOTOR WIRING MUST BE SELECTED IN ACCORDANCE WITH THE N.E.C., ANY APPLICATION LOCAL CODES AND THE LOAD CURRENT RATING.
- 4. REPLACE JUMPER 'J1' WITH NORMALLY CLOSED SAFETY INTERLOCK CONTACT AS NECESSARY, CONTACT MUST BE RATED 1/4 HP @ 120VAC MINIMUM.
- PANEL MAY REQUIRE DERATING, CONSULT DRIVE MANUAL OR FACTORY FOR FOLLOWING CONDITIONS:
- HIGHER SWITCHING FREQUENCY THAN DRIVE DEFAULT
- HIGHER THAN PANEL LISTED AMBIENT TEMPERATURES
- ELEVATION ABOVE 3300 FEET (1000 METERS) 5.3.
- LONG MOTOR LEAD LENGTHS
- 6. WHEN MOTOR OVERLOADS SIZES ARE DIFFERENT, MOTOR 1 WILL BE THE LARGER OF THE TWO MOTORS

DTM

DRIVE PARAMETER SETTINGS

PAGE <u>1</u> OF <u>2</u>

PARAMETER #	NAME	SETTING	VALUE	
0-02	MOTOR SPEED UNIT	1	HZ	
0-03	REGIONAL SETTINGS	1	NORTH AMERICA	
1-03	1-03 TORQUE CHAR.		VARIABLE TORQUE	
5-02	5-02 TERMINAL 29 TYPE		OUTPUT	
5-11	11 TERMINAL 19		RUN PERMISSIVE	
5-31 TERMINAL 29		5	RUNNING	
5-40[0] RELAY 1		160	NO ALARM	
5-40[1] RELAY 2		167	START COMMAND	
14-20	RESET MODE	13	INFINITE AUTO REST	

В			- NOTICE - THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF DANFOSS DRIVES.		
А	SP10119	11/10	IT IS LOANED BY DANFOSS DRIVES SUBJECT TO THE CONDITIONS THAT IT AND THE INFORMATION EMBODIED THEREIN SHALL BE USED ONLY FOR RECORD AND REFERENCE PURPOSES, SHALL NOT BE USED OR CAUSED TO BE USED		
DR	SP10076	09/10	IN ANY WAY PREJUDICIAL TO THE INTERESTS OF DANFOSS DRIVES, SHALL NOT BE REPRODUCED OR COPIED IN WHOLE OR IN PART, OR DISCLOSED		
REV	ECN	DATE	TO ANYONE WITHOUT THE DIRECT WRITTEN PERMISSION OF DANFOSS DRIVES AND SHALL BE RETURNED UPON REQUEST.		

DRN	NAME	NEMA 3R,208V,3C
D TM		, MAIN DISC, MAIN & DRIVE FUSI
APR		,3MB2,DUAL MOTOR,2 FAN
	MODEL	NUT BASE 1 OF 2 SIZE A

VLT

