


PANEL ADAPTER KIT - MOUNTING INSTRUCTIONS

Loose option: VACON-PAN-HMPA-MK01, Plus code: +HMPA

Introduction

The Panel Adapter is intended to replace the standard keypad in cases where a keypad is not needed or a door installation kit (loose option: VACON-PAN-HMDR-MK01-...) is used. The Panel Adapter is IP54 protected.

For the installation, you need the following parts included in the delivery. **Make sure that you have received all the necessary parts!**




1. Cover A
2. Cover B
3. Screws PT3.5 x 8 (4 pcs)
4. Foam rubber gasket

Indication LED

The LED on the Panel adapter gives indications about the status of the drive. The status of the LED on the panel adapter and door installation kit depends on the drive type.

Note the location of the LED on the panel adapter in the picture to the right.



Indication LED

| Drive type | LED location | LED status | | | | |
|--------------------|-----------------------|------------|-----------|---------|------------|-------------------|
| | | Ready | Run | Fault | Alarm | Software download |
| Vacon 100/ Flow | Panel adapter | - | - | - | - | - |
| | Door installation kit | ** | * (green) | * (red) | * (orange) | *** |
| HVAC | Panel adapter | ** | ** | ** | ** | *** |
| | Door installation kit | - | - | - | - | - |




- OFF

* ON

** Blinking slowly (1 sec ON - 1 sec OFF)

*** Blinking fast

Mounting procedure

| | | |
|---|--|--|
| 1 | <p>Fix the transparent cover B to the keypad base using the two screws provided. Tighten the screws to max. 0.8 Nm.</p> |  |
| 2 | <p>If a connection cable for the keypad is needed, detach the foam rubber gasket from the cover and punch out the cylinder-formed piece of foam rubber in order to open way for the cable. The gasket can then be split into two pieces.</p> |  |
| 3 | <p>Then fix the black cover A with the two screws provided. Tighten the screws to max. 0.8 Nm.</p> |  |

