



KIT MAINS INPUT COVER ASSEMBLY

100056-3, 4, 6, 7, & 8.



Installation and servicing of Danfoss Turbocor® compressors by qualified and product trained personnel only. Follow these instructions and sound refrigeration/electrical/servicing practices relating to installation, commissioning, maintenance and service.

<p>Consult the appropriate Danfoss Turbocor Compressors Inc. (DTC) Service Manual on turbocor.danfoss.com for detailed service instructions.</p>	<p>Never power compressor without covers in place and secured.</p> <p>Removing the mains input cover will expose you to a voltage hazard of up to 575V. Ensure the mains input power is off and locked out before removing cover.</p> <p>Before removing top cover, wait at least 20 minutes after isolating AC power to allow the high voltage capacitors to discharge.</p>	<p>Always wear appropriately rated safety equipment when working around equipment and/or components energized with high voltage.</p> <p>This equipment contains hazardous voltages that can cause serious injury or death.</p>	<p>Recover all refrigerant from compressor in accordance with local codes and ensure pressure is fully vented before the removal of refrigerant containing components.</p>
--	---	---	---

1 - Introduction:

MAINS INPUT COVER ASSEMBLY Removal and Installation Instructions.

⚠ Note: Care must be taken in removal and installation of the covers to prevent the screws from falling in to the power electronic compartment. Dropping cover screws can cause short circuit, energized components to explode, and damage to the power electronic parts of the compressor. Place the screws carefully after positioning the covers to minimize the risk of screws falling in to the power electronic areas.

2 - Suggested Tools:

The following tools are suggested:

- Philips/torx screwdriver


3 - Removal Instructions:

- Release the four (4) screws that secure the mains input cover. Lift away the cover.

4 - Installation Instruction:

1. Ensure that no residue remains on the contact surfaces of mains input cover and top side cover.

- Place the new mains input cover and secure it with the four (4) M5x15 screws. Tighten according to the following sequence.



- Follow the sequence twice. The first time, only fasten the screws half way down to allow for adjustment. Fasten the # 4 screw only once and be sure to not overtighten the screw. Torque to 13 in.lb. on the second pass.

Kit Contents

Kit numbers	Compressor models
100056-3	ALL TT MODELS, BLACK - MOLDED AVAILABLE TO ALL OEMS
100056-4	ALL TT MODELS, BLUE - MOLDED, OEM SPECIFIC
100056-6	TG MODELS, GREEN - MOLDED
100056-7	KIT – COVER MAINS INPUT ASSEMBLY (BLUE – MOLDED) EN/FR LABELS, OEM SPECIFIC
100056-8	KIT – COVER MAINS INPUT ASSEMBLY (GREEN – MOLDED) DE LABELS, OEM SPECIFIC

QTY	Part(s) Description	Picture(s)
1	COVER - MAINS INPUT ASSEMBLY, BLUE/BLACK/GREEN	
4	SCREW DOUBLE SEMS M5X15 TORX PAN HEAD	



Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.