WIRE COLOR SCHEME TERMINAL IDENTIFICATION BLACK - LINE VOLTAGE RED - AC CONTROL - DRIVE TERMINAL WHITE - AC GROUNDED - CUSTOMER TERMINAL CIRCUIT CONDUCTOR
BLUE - DC CONTROL GREEN - CHASSIS GROUND EARTH GROUND EARTH GROUND \neg 4T1 (L1) M2 4T2 (L2) (T2) 2T1 * AC MOTOR 1 *CUSTOMER L1_(L1) (T1) BLK 2L1 3L1 (U1) (U2) 4L1 (F16A) 5L1 L1/R/91 VLT INPUT SUPPLIED T1/U/96 POWER 3L2 (V1) (V2) 4L2 [F16B] 5L2 L2/S/92 ADJUSTABLE FREQUENCY (L2) (T2) 1T2 (L2) T2 2T2 FEEDER L2 (L2) T15B] (T2) BLK 2L2 T2/V/97 3 PH, 600V, 3L3 (W1) (W2) 4L3 ||F16C|| 5L3 ||L2/5/92 ||L3/T/93 || DRIVE 2T3 (L3) (T3) 1T3 (L3) T3 CIRCUIT L3 (L3) - IF15CII (T3) BLK 2L3 4T3 (L3) (T3) PROTECTION T3/W/98 (AFD) 60Hz (SEE NOTE 3) INPUT DRIVE INPUT FUSES DRIVE DISCONNECT DISCONNECT REACTOR (L1) (T1) (L2) (T2) *AC MOTOR 2 EARTH GROUND GRN (L3) (T3) (L3) (T3) 3T3 (L3) 163 RED 100 WHT F12 X2 X3 250V 115VAC T2 (12) (4) HEATER (SET: 65° F) (12) 5 (11) TS1 CR6 167 2)FAN 1 (SET: 80° F) (9) (5) (23) (24) TB2 TS1

TO SHEET 2

WARNING!

THE FOLLOWING TABLE LISTS THE PARAMETERS THAT ARE SET DIFFERENT FROM THE DRIVE DEFAULT SETTINGS. ADDITIONAL PARAMETER SETTINGS MAY BE REQUIRED FOR YOUR APPLICATION.

1. * INDICATES COMPONENTS NOT SUPPLIED BY MANUFACTURER.

- REFER TO THE INSTALLATION AND OPERATION MANUAL FOR DRIVE FUNCTIONS AND PARAMETER SETTINGS.
- 3. FEEDER CIRCUIT PROTECTION, INPUT POWER AND MOTOR WRING MUST BE SELECTED IN ACCORDANCE WITH THE N.E.C., ANY APPLICATION LOCAL CODES AND THE LOAD CURRENT RATING.
- 4. REPLACE JUMPER 'J1' WITH NORMALLY CLOSED SAFETY INTERLOCK CONTACT AS NECESSARY. CONTACT MUST BE RATED 1/4 HP @ 120VAC MINIMUM.
- 5. PANEL MAY REQUIRE DERATING, CONSULT DRIVE MANUAL OR FACTORY FOR FOLLOWING CONDITIONS: 5.1. HIGHER SWITCHING FREQUENCY THAN DRIVE DEFAULT


TO SHEET 2

- HIGHER THAN PANEL LISTED AMBIENT TEMPERATURES
- 5.3. ELEVATION ABOVE 3300 FEET (1000 METERS)
- 5.4. LONG MOTOR LEAD LENGTHS

DRIVE PARAMETER SETTINGS

PARAMETER #	NAME	SETTING	VALUE
0-02	MOTOR SPEED UNIT	1	HZ
0-03	REGIONAL SETTINGS	1	NORTH AMERICA
1-03	TORQUE CHAR.	3	AUTO ENERGY OPTIM VT
5-02	TERMINAL 29 TYPE	1	OUTPUT
5-31	TERMINAL 29	5	RUNNING
14-20	RESET MODE	13	INFINITE AUTO REST

В			- NOTICE - THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF DANFOSS DRIVES.	DRN	NAME		EMA 3R,600V,2C			The less
Α	SP10119	11/10	IT IS LOANED BY DANFOSS DRIVES SUBJECT TO THE CONDITIONS THAT IT AND THE INFORMATION EMBODIED THEREIN SHALL BE USED ONLY FOR RECORD AND REFERENCE PURPOSES, SHALL NOT BE USED OR CAUSED TO BE USED	DIM	,M		SC, DRIVE DISC,			Janjoso
DR	SP10076	09/10	IN ANY WAY PREJUDICIAL TO THE INTERESTS OF DANFOSS DRIVES, SHALL NOT BE REPRODUCED OR COPIED IN WHOLE OR IN PART, OR DISCLOSED	APR	MODEL ,	,311181,118,0011	TACT MOTOR SE	CITE A	DWC 4	
REV	ECN		TO ANYONE WITHOUT THE DIRECT WRITTEN PERMISSION OF DANFOSS DRIVES AND SHALL BE RETURNED UPON REQUEST.	DIM	MODEL	VLT	page <u>1</u> of <u>2</u>	31ZLA	NO. 8	280/82



CUSTOMER DRY CONTACT RATINGS


RELAY	CONTACT RATING			
CR1, CR6	5A @ 120VAC 1/10 HP @ 120VAC			
M2, M3, M4, M5	10A @ 120/240VAC			




A INDICATES CONTACT CLUSED					
POSITION					
CONTACT	DRIVE	OFF	BYPASS		
13-14			Χ		
23-24	Χ				

CONTACT SEQUENCE CHART FOR S2

A INDICATES CONTACT CEOSED					
POSITION CONTACT	MOTOR 1	AUTO	MOTOR 2		
11-12	X	—X			
13-14			Χ		
21-22		X	—X		
23-24	Х				





В		
Α	SP10119	11/10
DR	SP10076	09/10
REV	ECN	DATE

- NOTICE
THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF DANFOSS DRIVES.
IT IS LOANED BY DANFOSS DRIVES SUBJECT TO THE CONDITIONS THAT IT AND
THE INFORMATION EMBODIED THEREIN SHALL BE USED ONLY FOR RECORD
AND REFERENCE PURPOSES, SHALL NOT BE USED OR CAUSED TO BE USED
IN ANY WAY PREJUDICIAL TO THE INTERESTS OF DANFOSS DRIVES, SHALL
NOT BE REPRODUCED OR COPIED IN WHOLE OR IN PART, OR DISCLOSED
TO ANYONE WITHOUT THE DIRECT WRITTEN PERMISSION OF DANFOSS DRIVES
AND SHALL BE RETURNED UPON REQUEST.

DRN D TM

DTM

APR

NAME NEMA 3R,600V,2C ,MAIN FUSE DISC, DRIVE DISC, DRIVE FUSE ,3MB1,IR,CONTACT MOTOR SELECT,1 FAN

Danfoss

MODEL

VLT

PAGE 2 OF 2 | SIZE

PWG 185B0785