WIRE COLOR SCHEME TERMINAL IDENTIFICATION BLACK - LINE VOLTAGE - DRIVE TERMINAL RED - AC CONTROL WHITE - AC GROUNDED - CUSTOMER TERMINAL CIRCUIT CONDUCTOR BLUE - DC CONTROL GREEN - CHASSIS GROUND EARTH GROUND EARTH GROUND H4T1 (L1) M2 (T1) 2T1 * AC MOTOR 1 *CUSTOMER L1 (L1) (T1) 1L1 BLK [F15A] 2L1 5L1 VLT(L1) | (T1) 1T1 (L1) \(\infty\) T1 INPUT SUPPLIED [F16A] L1/R/91 T1/U/96 POWER ADJUSTABLE FREQUENCY 5L2 4T2 (L2) (T2) 2T2 (L2) (T2) 1T2 (L2) T2 FEEDER L2 (L2) (T2) 1L2 BLK [F15B] 2L2 3L2 [F16B] L2/S/92 T2/V/97 3 PH. DRIVE CIRCUIT L3 (L3) (T3) 1L3 BLK |F15C|| 2L3 4T3 (L3) (T3) _2T3 (L3) (T3) 1T3 (L3) 480V, PROTECTION L3/T/93 T3/W/98 (AFD) 60Hz (SEE NOTE 3) DRIVE INPUT FUSES DRIVE DISCONNECT FUSES DISCONNECT OL2 *AC MOTOR 2 EARTH GROUND GRN (L1) (T1) (L2) (T2) (L3) (T3) (L3) (T3) 3T3 (L3) 163 RED X2 F12 115VAC HEATER (SET: 65° F) (12) 5 (11) TS1 CR6 167 7)FAN 1 (SET: 80°F) (9) (23) (24) TB2 TS1 FAN 2 TO SHEET 2 TO SHEET 2

WARNING!

THE FOLLOWING TABLE LISTS THE PARAMETERS THAT ARE SET DIFFERENT FROM THE DRIVE DEFAULT SETTINGS. ADDITIONAL PARAMETER SETTINGS MAY BE REQUIRED FOR YOUR APPLICATION.

NOTES:

1. * INDICATES COMPONENTS NOT SUPPLIED BY MANUFACTURER.

- 2. REFER TO THE INSTALLATION AND OPERATION MANUAL FOR DRIVE FUNCTIONS AND PARAMETER SETTINGS.
- 3. FEEDER CIRCUIT PROTECTION, INPUT POWER AND MOTOR WIRING MUST BE SELECTED IN ACCORDANCE WITH THE N.E.C., ANY APPLICATION LOCAL CODES AND THE LOAD CURRENT RATING.
- 4. REPLACE JUMPER 'J1' WITH NORMALLY CLOSED SAFETY INTERLOCK CONTACT AS NECESSARY. CONTACT MUST BE RATED 1/4 HP @ 120VAC MINIMUM.
- 5. PANEL MAY REQUIRE DERATING, CONSULT DRIVE MANUAL OR FACTORY FOR FOLLOWING CONDITIONS:
- 5.1. HIGHER SWITCHING FREQUENCY THAN DRIVE DEFAULT
- 5.2. HIGHER THAN PANEL LISTED AMBIENT TEMPERATURES
- 5.3. ELEVATION ABOVE 3300 FEET (1000 METERS)
- 5.4. LONG MOTOR LEAD LENGTHS

DRIVE PARAMETER SETTINGS

PARAMETER # NAME		SETTING	VALUE
0-02 MOTOR SPEED UNIT		1	HZ
0-03	REGIONAL SETTINGS	1	NORTH AMERICA
1-03	1-03 TORQUE CHAR.		AUTO ENERGY OPTIM VT
5-02	5-02 TERMINAL 29 TYPE 5-31 TERMINAL 29		OUTPUT
5-31			RUNNING
14-20 RESET MODE		13	INFINITE AUTO REST

В		
Α	SP10119	11/10
DR	SP10076	09/10
REV	ECN	DATE

- NOTICE
THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF DANFOSS DRIVES.
IT IS LOANED BY DANFOSS DRIVES SUBJECT TO THE CONDITIONS THAT IT AND
THE INFORMATION EMBODIED THEREIN SHALL BE USED ONLY FOR RECORD
AND REFERENCE PURPOSES, SHALL NOT BE USED OR CAUSED TO BE USED
IN ANY WAY PREJUDICIAL TO THE INTERESTS OF DANFOSS DRIVES, SHALL
NOT BE REPRODUCED OR COPIED IN WHOLE OR IN PART, OR DISCLOSED
TO ANYONE WITHOUT THE DIRECT WRITTEN PERMISSION OF DANFOSS DRIVES
AND SHALL BE RETURNED UPON REQUEST.

DRN D TM

DTM

APR


NAME NEMA 3R,480V,2C ,MAIN & DRIVE DISC, MAIN & DRIVE FUSE ,3MB1,CONTACT MOTOR SELECT,2 FAN


Danfoss

MODEL VLT

PAGE <u>1</u> OF <u>2</u>

DWG 185B134(





В		
Α	SP10119	11/10
DR	SP10076	09/10
REV	ECN	DATE

- NOTICE -		
THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF DANFOSS DRIVES.		
IT IS LOANED BY DANFOSS DRIVES SUBJECT TO THE CONDITIONS THAT IT AND		
THE INFORMATION EMBODIED THEREIN SHALL BE USED ONLY FOR RECORD		
AND REFERENCE PURPOSES, SHALL NOT BE USED OR CAUSED TO BE USED		
IN ANY WAY PREJUDICIAL TO THE INTERESTS OF DANFOSS DRIVES, SHALL		
NOT BE REPRODUCED OR COPIED IN WHOLE OR IN PART, OR DISCLOSED		
TO ANYONE WITHOUT THE DIRECT WRITTEN PERMISSION OF DANFOSS DRIVES		
AND SHALL BE RETURNED UPON REQUEST.		

)	DRN	D TM
	APR	

DTM

NAME NEMA 3R,480V,2C ,MAIN & DRIVE DISC, MAIN & DRIVE FUSE ,3MB1,CONTACT MOTOR SELECT,2 FAN



MODEL

PAGE <u>2</u> OF <u>2</u>

VLT

. SIZE A

DWG 185B1340