WIRE COLOR SCHEME TERMINAL IDENTIFICATION BLACK - LINE VOLTAGE RED - AC CONTROL - DRIVE TERMINAL WHITE - AC GROUNDED - CUSTOMER TERMINAL CIRCUIT CONDUCTOR
BLUE - DC CONTROL GREEN - CHASSIS GROUND EARTH GROUND EARTH GROUND H* AC MOTOR 1 4T1 (L1) (T1) 2T1 *CUSTOMER (U1) (U2) 4L1 (F16A) (L1) | (T1) 1T1 (L1) x T1 L1 (L1) (T1) 1L1 BLK [F15A] 2L1 VLT INPUT SUPPLIED T1/U/96 POWER L2 (L2) (T2) 1L2 BLK | F15B| 2L2 3L2 (V1) (V2) 4L2 [F16B] 5L2 L2/S/92 ADJUSTABLE FREQUENCY 4T2 (L2) (T2) 2T2 (L2) (T2) 1T2 (L2) T2 FEEDER 3 PH, 480V, T2/V/97 3L3 (W1) (W2) 4L3 (F16C) 5L3 (L2/5/92) 1.3/T/93 DRIVE 2T3 (L3) (T3) 1T3 (L3) T3 CIRCUIT L3 (L3) (T3) 1L3 BLK [F15C] 2L3 4T3 (L3) (T3) PROTECTION T3/W/98 (AFD) 60Hz (SEE NOTE 3) INPUT DRIVE INPUT FUSES DRIVE MAIN LINE DISCONNECT DISCONNECT **FUSES** REACTOR (L1) (T1) (L2) (T2) *AC MOTOR 2 EARTH GROUND GRN (L3) (T3) (L3) (T3) 3T3 (L3) 163 RED X2 F12 115VAC CR6 (12) 5 (11) TS1 HEATER (SET: 65' F) CR6 167 (9) (5) (2) FAN 1 (SET: 80° F) (23) (24) TB2 TS1 FAN 2

TO SHEET 2

WARNING!

THE FOLLOWING TABLE LISTS THE PARAMETERS THAT ARE SET DIFFERENT FROM THE DRIVE DEFAULT SETTINGS. ADDITIONAL PARAMETER SETTINGS MAY BE REQUIRED FOR YOUR APPLICATION.

1. * INDICATES COMPONENTS NOT SUPPLIED BY MANUFACTURER.

- 2. REFER TO THE INSTALLATION AND OPERATION MANUAL FOR DRIVE FUNCTIONS AND PARAMETER SETTINGS.
- 3. FEEDER CIRCUIT PROTECTION, INPUT POWER AND MOTOR WIRING MUST BE SELECTED IN ACCORDANCE WITH THE N.E.C., ANY APPLICATION LOCAL CODES AND THE LOAD CURRENT RATING.
- 4. REPLACE JUMPER 'J1' WITH NORMALLY CLOSED SAFETY INTERLOCK CONTACT AS NECESSARY. CONTACT MUST BE RATED 1/4 HP @ 120VAC MINIMUM.
- 5. PANEL MAY REQUIRE DERATING, CONSULT DRIVE MANUAL OR FACTORY FOR FOLLOWING CONDITIONS:


TO SHEET 2

- 5.1. HIGHER SWITCHING FREQUENCY THAN DRIVE DEFAULT
- 5.2. HIGHER THAN PANEL LISTED AMBIENT TEMPERATURES
- 5.3. ELEVATION ABOVE 3300 FEET (1000 METERS)
- 5.4. LONG MOTOR LEAD LENGTHS

DRIVE PARAMETER SETTINGS

PARAMETER #	NAME	SETTING	VALUE		
0-02	MOTOR SPEED UNIT	1	HZ		
0-03	REGIONAL SETTINGS	1	NORTH AMERICA		
1-03	TORQUE CHAR.	3	AUTO ENERGY OPTIM VT		
5-02	TERMINAL 29 TYPE	1	OUTPUT RUNNING		
5-31	TERMINAL 29	5			
14-20	RESET MODE	13	INFINITE AUTO REST		

В			NOTICE - THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF DANFOSS DRIVES. IT IS LOANED BY DANFOSS DRIVES SUBJECT TO THE CONDITIONS THAT IT AND THE INFORMATION EMBODIED THEREIN SHALL BE USED ONLY FOR RECORD AND REFERENCE PURPOSES, SHALL NOT BE USED OR CAUSED TO BE USED IN ANY WAY PREJUDICIAL TO THE INTERESTS OF DANFOSS DRIVES, SHALL	DRN D TM	NAME NEMA 3R,480V,2C					
А	SP10119	11/10			1	,MAIN & DRIVE DISC, MAIN & DRIVE FUS				
DR	SP10076	na /1n		APR	- ,3MB1,IR,CONTACT MOTOR SELECT,2 FAN					
	31 10070	037 10	NOT BE REPRODUCED OR COPIED IN WHOLE OR IN PART, OR DISCLOSED		MODEL	\	1 0	SIZE A	DWG 1	
REV	ECN	DATE	TO ANYONE WITHOUT THE DIRECT WRITTEN PERMISSION OF DANFOSS DRIVES AND SHALL BE RETURNED UPON REQUEST.	<i>D 110</i> 1 	VL I	VLT	PAGE <u>1</u> OF <u>2</u>	$\mid A \mid$	NO.	



В

Α

DR

REV

ECN

